

INDEX BY SUBJECTS (continued)

O

Oil Cooler	15
Oil Cooler Parts	36, 37
Oil Filter	15, 17
Oil Filter Parts	43
Oil Flow	7
Oil Level	16
Oil Pump	8
Oil Pump Parts	28, 29
Oil Pump Relief Valve Parts	49
Oil Separator Element	11
Oil Separator and Minimum Pressure Valve Parts	34, 35
Oil Storage Reservoir in Receiver-Separator	15
Oil Temperature By-Pass Valve Parts	49
Ordering Parts	25
Out-Of-Level Operation	12

P

Parallel Operation	12
Parts List—General	25
Parts List—Introduction	25
Protective Thermal Switch	11
Pump-up Jobs	12

R

Radiator	10
Radiator and Oil Cooler Parts	36, 37
Receiver-Separator	11
Receiver-Separator System Parts	34, 35
Recommended Spare Parts	51, 52
Regulation	20
Regulator, Adjustments	22
Regulator, Changing Pressure Range	22
Regulator, UL-88 "Air Glide"	20

Regulator, UL-89 Volumetric	21
Returning Parts	26
Running Gear	12
Running Gear Parts	40, 41

S

Safety Valve	11
Serial Number Location	26, 27
Spare Parts	26
Spare Parts Boxes	51, 52
Speed and Pressure Adjustments	22
Speed and Pressure Regulation	20
Spring Mounting	10
Starting	13
Stopping	14

T

Tires	12
Towing Speeds	12

U

UL-88 Regulator Parts	32
UL-88 Regulator and Linkage Parts	33
UL-89 Volumetric Regulator Parts	30
UL-108 Automatic Blowdown Valve Parts	50

V

Volumetric Regulation	21
-----------------------	----

W

Warming Up Engine	13
Wheel Parts	42
Winter Starting	13

PART I

DESCRIPTION

GENERAL DESCRIPTION

The Gyro-Flo Portable Compressor consists of a single stage rotary air compressor directly connected to and driven by a heavy duty industrial type engine. This unit assembly is mounted on a sturdy, channel section, welded steel frame.

The running gear is a two wheel spring mounting, having pneumatic tired wheels. "Less running gear" and utility units are furnished on wooden shipping skids.

Large capacity tool boxes with lockable covers, as well as wheel fenders, can be furnished as optional equipment.

Operating accessories include oil cooler, fuel supply tank, combination air receiver-oil separator, and the necessary regulating devices, instruments, air filter, oil filter, etc.

COMPRESSOR

The compressor is single stage, and is of the sliding vane rotary type. The rotor chamber is supported by a yoke which is bolted directly to the flywheel housing of the engine with pilot fit to insure proper alignment. A rear bearing housing and oil pump casing with cover closes the rear end of the rotor chamber.




Fig. 3—Cross-sectional view of Gyro-Flo Single Stage Compressor.

A front bearing, with rotary shaft oil seal, is contained in the yoke. Special end plate inserts are located at each end of the rotor chamber and act as end guides for the vanes.

The cylinder bore (or rotor chamber) is offset from the shaft center line. This causes the cylinder bore to be eccentric to its rotor.

The rotor is slotted to receive sliding vanes which are sealed by the copious amount of lubricating oil fed to the bearings and bore. They are held against the bore wall by centrifugal force when operating.

AIR FLOW (Fig. 4)

Free air is taken into the chambers through large ports at an area where the vanes are well out of the rotor slots, thus filling the spaces or volumes between the vanes. As rotation proceeds, the vanes are moved radially inward in their slots by the bore wall. This causes the volume between the vanes to decrease and compresses the air trapped in this space. As this space volume approaches zero, a second series of ports is uncovered allowing the compressed air to discharge into the receiver-separator.

OIL FLOW (Figs. 13 and 14)

Relatively cool lubricating oil is admitted under pressure to the precision roller bearings and also is injected in metered amounts directly to the rotor chamber. The oil passes through the bearings at each end of the rotor, enters the close clearances at the vane ends, and thence to the rotor chamber.

All of the oil thus introduced, mixes with, and passes on with the air being compressed. This removes the heat of compression to a large degree and results in an unusually low final air discharge temperature.

The discharge air passes through a short connection into a combination air receiver-oil separator where the oil is removed from the air and collects in the storage reservoir formed by the lower portion of the receiver-separator shell. From there, the oil is forced through piping to an oil cooler assembly. This cooler is located at the radiator end of the portable in such a manner that the engine radiator fan serves to cool both the engine jacket water and the compressor lubricating and cooling oil.




Fig. 5—Instrument Panel.
Non-Utility

AIR RECEIVER-OIL SEPARATOR (Figs. 6, 10 and 13)

The combination air receiver-oil separator (herein-after called the receiver-separator) is comprised of a special ASME - National Board Code welded steel receiver shell designed for 150 psi (10.55 kg/cm²) working pressure.

Located entirely within the shell is a secondary separator nest and support tube. Removing the secondary separator nest and the support tube provides a very large opening through which perfect cleaning and inspection can be performed. An internal strainer at the receiver-separator tank (bottom) outlet connection provides a means of trapping any solids which might be carried by the oil flow toward the oil cooler. This strainer fitting is removable for cleaning. The delivery end of the receiver-separator is arranged to provide connections for the minimum pressure valve, service valves, a manual blowdown valve and the required safety valve.

It is continuously drained of any oil accumulation by a scavenger line which drains to the cylinder.

HOSE REELS (Fig. 7)

Hose reels are available as optional equipment. Each reel has a capacity for 50 ft. (15¼ meters) of ¾" (19 mm) air hose and includes a minimum pressure service valve "H".




Fig. 6—Rear View of Compressor showing Receiver-Separator and Service Fittings.

The following "call-outs" are referenced on Fig. 6.

- A. Plugged Drains
- B. Fuel Tank Filler Cap
- C. Fuel Shut-off Valve
- D. Receiver-Separator Oil Filler Plug
- E. Oil Level Indicator
- F. Receiver-Separator Manual Blowdown Valve
- G. Minimum Pressure Valve
- H. Service Valves




Fig. 7—Model GR85 with Hose Reels. Manual Blowdown Valve shown at "F". Minimum Pressure Service Valve shown at "H".

PROTECTIVE THERMAL SWITCH

The compressor is protected against overheating by a thermal switch located in the cylinder discharge chamber. The switch is of the "normally-closed" type and serves to open the ignition circuit to cause immediate shutdown should the temperature of the discharge air rise above 220°F to 230°F (104.4°C to 110°C).

Should the engine be shut down during operation by this switch, check immediately to determine where the trouble lies and correct it before attempting further operation.

SAFETY VALVE

A safety valve is connected to the receiver-separator to protect the compressor against any serious over-pressure. It should be operated manually once a month to make sure it is in proper operating condition. Should this safety valve "blow" at any time due to excessive discharge pressure, check the regulating devices for improper settings.

AIR FILTER

Both the engine and the compressor intake are protected against entrance of dust and foreign objects by an efficient, stack type, oil bath air filter which takes its air from above the roof.

The filter should be serviced as often as required in accordance with operating conditions; daily, if in a very dusty location.

Normal servicing requires only emptying and cleaning the bottom oil pan as shown in Fig. 8 and refilling with engine oil to the bead line "C". The oil pan can be dropped as shown after loosening the two wing nuts. Use the same oil as used in the engine or a heavier grade in hot weather. **The precleaner**, Fig. 9, located above the roof, should be checked occasionally to see that it is not clogged with dirt or foreign material.

If the screen element of the stack type air filter becomes clogged, remove the complete filter, and wash in a tub of hot water and soap powder or detergent. Then rinse thoroughly, drain and dry, re-oiling before reassembly to the unit.

NOTE:—Air filters on units for export are drained of oil when shipped and must be refilled before operation of unit.

RECEIVER-SEPARATOR

The secondary oil separator is mounted within a removable inner shell which is placed inside the primary receiver-separator shell. The inside of the primary receiver-separator shell may be cleaned by withdrawing the inner shell, allowing access to the inside of the receiver-separator.




Fig. 8—Dropping Air Filter bottom pan for cleaning and renewing the oil. Fill to bead line "C" on the pan.

OIL SEPARATOR ELEMENT

The secondary oil separator element consists of a series of chambers each packed with an oil diverting medium through which the compressed air passes on its way to the final discharge connection. (Most




Fig. 9—Filter Pre-Cleaner, serves as a rain cap and screen to prevent entrance of leaves, etc. Keep screen open.

PART III

STARTING

BEFORE STARTING

1. Set the portable compressor on level ground and in as clean a location as possible.
Note:—For Out-of-Level Operation, see page 12.
2. Check the oil level in both the compressor receiver-separator reservoir and engine crankcase. Add make up oil if required. (See special instructions under Lubrication.)
3. Check air filter for proper oil level in the bottom pan.
4. Check engine radiator to see that it is correctly filled with clean, soft water. Use permanent type anti-freeze solution if operating in below freezing temperatures. The use of a commercial rust inhibitor is recommended to prevent internal corrosion of the cooling system.
5. See that the fuel tank is filled with a good quality engine fuel. Use a good grade of regular motor fuel of at least 84-86 octane rating. Premium fuels are not required and highly leaded fuels should be avoided. Open shut-off valve underneath fuel tank to its fully open position.
6. Insure there is no air pressure in the receiver-separator system, either by observing the pressure gauge or by opening the manual blowdown valve. (See paragraph on "Stopping" and "F", Fig. 6).

STARTING

A manual speed control is furnished for easy starting of the gasoline engine any time after it has been shut down long enough to have cooled down to surrounding temperatures. The manual speed control holds the engine at a definite "warm-up" speed high enough to prevent stalling.

1. Refer to Fig. 11 and pull the manual speed control handle all the way out. Turn $\frac{1}{4}$ turn clockwise to lock. Depress the starter button to start the engine. **ALL SERVICE VALVES AND THE MANUAL BLOWDOWN VALVE ON THE AIR RECEIVER-OIL SEPARATOR SYSTEM MUST BE CLOSED TO BUILD UP FULL AIR PRESSURE.** This causes compressor unloading and results in minimum load on the engine while it is warming up. It also applies full pressure to




Fig. 11—Pulling Manual Speed Control Handle out and locking, preliminary to starting, Model GR85. Operating Instruments are located on the end of the Model GRU85.

the lubricating oil in the storage reservoir. This causes the oil to flow to the oil cooler or through the by-pass valve direct to the oil pump inlet to establish full lubricating pressure in the compressor immediately.

2. Keep the manual speed control handle pulled all the way out until the engine is warmed up.
3. When the unit is fully warmed up, the manual speed control handle should be turned $\frac{1}{4}$ turn counterclockwise to unlock it and then should be pushed all the way in. Now, air demand will regulate output as required.
4. In extremely cold weather, it may be necessary to turn the engine over two or three compressions with the choke completely closed and the ignition turned "off". Then, open choke part way, turn on ignition and start.
5. Normally the unit must be started with the manual blowdown valve closed; but, in extremely cold weather, it may be advisable to leave the valve partially open. This will allow the engine to be

PART IV

LUBRICATION




Fig. 13—Diagram showing the Cooling System of the Oil Cooled Compressor and Water Cooled Engine.

LUBRICATION (COMPRESSOR)

Compressor lubrication and cooling are both accomplished by the compressor lubricating oil. The compressor is cooled by oil injection directly into the rotor chamber. The compressor lubricating system consists of an oil pump, a storage reservoir, an oil cooler, and the necessary piping together with an oil filter.

The **oil cooler** is a radiator-like heat transfer core section placed immediately in front of the engine radiator core and having approximately the same frontal area. It is so arranged internally that the oil passes through the cooling air stream on its way through the core. Oil is piped from the storage space in the separator shell to the inlet opening of the cooler core. On leaving the cooler, it flows through the piping and the oil filter to the oil pump intake.

COMPRESSOR OIL FILTER

The oil filter (Fig. 13) is located in a loop of the oil piping so that the filter shell may be removed for servicing without having to drain any other part of

the system. Only the oil in the filter shell itself is removed when the shell is removed for cleaning.

The oil filter is of a continuously cleanable type with a permanent all metal filtering element or cartridge. The filter operates on the principle of edge filtration. The positive combing action of the cleaner blades frees it of all solids collected on the filtering surface, restoring the initial conditions of flow. The handle should be turned one turn each day, preferably immediately after shutting down while the oil is still warm. Also, twice a month remove the filter shell and clean out any sludge or foreign material which may have collected. While shell is removed, inspect for lacquer deposit. If lacquer deposit is noted, change compressor oil completely to avoid vane sticking in the compressor.

OIL STORAGE RESERVOIR IN RECEIVER-SEPARATOR

The oil storage reservoir is the lower portion of the shell of the receiver-separator, where most of the oil collects as it is thrown out of the compressed

has operated for 500 hours or until oil level gauge indicates about half full (when unit is standing approximately level and shut down).

A complete replacement of the old compressor oil with clean new oil every 500 hours is desirable and is good insurance. This practice tends to prevent accumulation of dirt or sludge or oxidized oil products in the system.

6. Frequent inspection and cleaning of the oil filter has several advantages. It makes the job of cleaning it much easier and provides a check on the condition of the oil and therefore of the whole compressor. Neglect of this operation results in the by-passing of unfiltered oil in reduced quantity, overheating of compressor and probable automatic shut-down.

If any varnish or lacquer deposits are found in the filter, this indicates that the oil is deteriorating and it should be changed immediately.

COMPRESSOR OIL FILTER

Turn handle one full turn daily, preferably after stopping unit. Remove shell and clean out sludge every 100 hours of operation. While shell is removed, inspect for lacquer deposit. **If lacquer deposit is noted**, change compressor oil completely to avoid vane sticking in the compressor.

UNITS FOR DOMESTIC USE

Do not add oil to the compressor lubricating system of new units. These units are shipped with an initial supply sufficient to operate for 500 hours or until oil level gauge indicates about half full when unit is shut down and standing approximately level.

UNITS FOR EXPORT USE

The compressor lubricating system of units for export is completely drained at time of shipment and system must be refilled with new oil to the preceding recommendations before operation.

LUBRICATION (ENGINE)

Refer to manufacturer's instruction book. Use S.A.E. 10W-30 for the first 50 hours of operation, then S.A.E. 10-W, 20-W or 30 in accordance with surrounding temperatures:

Over 75°F (23.9°C)	SAE 30
75°F (23.9°C) to 32°F (0°C)	SAE 20-W
32°F (0°C) to -10°F (-23.3°C)	SAE 10-W
Below -10°F (-23.3°C)	SAE 5W-20

Change oil at regular intervals of 50 hours of operation. Lubricate the starter and generator sparingly once a week, using 3-5 drops of the same oil as for the engine. **Do not over oil.**

NOTE:—Engines of units for export are completely drained of oil before shipping and must be refilled before operation.

GR85 GYRO-FLO COMPRESSOR




Fig. 16—Lubrication Chart - Left Hand Side of Unit.

TWICE A MONTH (or every 100 hours of operation)

1. Service the compressor lubricating oil filter "K". Remove filter shell and clean out sludge or foreign material.
2. Check the electrolyte level in each cell of the battery "L". Add distilled water if electrolyte is below battery manufacturer's recommended level.

ONCE A MONTH

1. Operate separator-receiver safety valve manually to make sure it is in proper operating condition.
2. Remove fuel tank drain plugs to draw off any collection of water and sediment.

EVERY THREE MONTHS (or every 500 hours of operation)

1. Lubricate the running gear spring bolts "M" by applying grease to fittings with a grease gun.
2. Lubricate the running gear springs "N" by applying light grease (or heavy oil with a brush) to the slip end of each spring.
3. Change compressor lubricating oil. If lacquer deposits are found, increase the frequency of oil change. To drain system, remove pipe plugs "P" and open valve "A". Never remove the pipe

plugs "P", the oil filler plug "Q", or open drain "A" when the receiver-separator is under pressure.

4. Remove scavenger line and clean the oil line screen assembly "R". Also clean the inlet unloader orifice "S".

TWICE A YEAR (or every 1250 hours of operation)

1. Remove wheels. Replace any worn parts and repack wheel bearings "T" (not over one-half full with wheel bearing grease).
2. Clean the engine cooling system. Refer to the engine book for complete instructions.
3. Lubricate third wheel by applying grease to grease fittings "Y" with a grease gun. **Do not overgrease.**

ONCE A YEAR (or every 2000 hours of operation)

1. Inspect rotor vane tips for wear and breakage.

EVERY TWO YEARS (or every 4000 hours of operation)

1. Replace rotor vanes as a matter of routine preventive maintenance.
2. In normal operation, service secondary separator element.
3. Replace regulator diaphragms.




Fig. 18—UL-88 "Air Glide" Regulator Instruction Plate.

sion to prevent movement of the regulator diaphragm, (and the valve) until the pressure in chambers "B" and "L" has increased to a predetermined value. This allows compressor volumetric regulation to start approximately 60%. From there on it will become progressively more effective as the air demand decreases and the pressure in chamber "L" increases above the balancing point.

ADJUSTMENTS FOR SPEED AND PRESSURE

Maximum Rated Speed (Fig. 18)

With final pressure held at 100 psi (7.03 kg/cm²) and governor link rod attached to UL-88 lever arm, adjust screw "H" so that lever "C" remains firmly against stop "E", then adjust the length of link rod "F" to maintain full rated speed of 2100 RPM.

Minimum Low Speed

Close service valves, causing final pressure to increase and complete unloading to occur (zero de-

livery). Then adjust low speed stop screw "P" (Fig. 18) on UL-88 Regulator to hold engine speed at 1000 RPM.

Start of Speed Regulation

Hold final pressure at 100 psi (7.03 kg/cm²) and readjust screw "H" so that lever "C" is just leaving stop "E". (Speed starts to fall off if pressure is raised above 100 psi (7.03 kg/cm²).

Changing Pressure Range

By simple readjustment of screw "H", Fig. 18, the start of regulation can be raised or lowered from the normal 100 psi (7.03 kg/cm²) setting. This enables the operator to select an average operating pressure suitable for the tools being operated, or to compensate for pipe line loss to a certain extent where long lines must be used. Do not attempt to adjust for more than plus or minus 10 per cent from the normal 100 psi (7.03 kg/cm²) setting.




Fig. 19—Capacity-Pressure Chart.

PART VI

PARTS LIST

GENERAL

The Model GR85 Gyro-Flo Air Compressor is manufactured with the finest quality material. Years of research and experience have been combined with quality workmanship and careful inspection to provide many years of dependable trouble-free operation.

This section, which contains an illustrated parts breakdown, has been carefully prepared as an aid in locating those parts which may be required in the maintenance of the unit. All of the compressor parts listed in the parts breakdown are manufactured with the same precision as the original equipment. For the greatest protection, always insist on genuine Ingersoll-Rand Company parts for your compressor.

Ingersoll-Rand Company service facilities and genuine parts are available world-wide. There are Ingersoll-Rand Company branch offices and authorized distributors or dealers conveniently located in the principle cities of the United States and throughout the free world. Each branch office, or authorized distributor or dealer, is thoroughly equipped with a full and adequate supply of genuine Ingersoll-Rand Company parts. For faster and better service, your parts requirements should be ordered from your nearest Ingersoll-Rand Company branch office or authorized distributor or dealer. A list of branch offices will be found in the rear of this publication. Each branch office is ably equipped to provide technical assistance with prompt, intelligent, and courteous service, either through correspondence or personal contact.

All parts orders pertaining to the gasoline engine should be referred to your nearest Continental Motors Corporation distributor or dealer. Correspondence concerning the engine should always include the information found on the engine Name Plate attached to the side of the cylinder block. This information should include the engine model, specification number and engine serial number stamped in engine block.

INTRODUCTION

The illustrated parts breakdown illustrates, lists and describes the various assemblies, subassemblies and detail parts which make up the Models GR85 and GRU85 Air Compressors. Each group of parts is accompanied by an illustration which shows each individual part as clearly as possible and in its correct location relative to the other parts in the illustration.

Reference numbers only are used on each illustration. These numbers correspond to those in the illustration number column in the list of parts which follows each illustration.

Each illustration is followed immediately by a listing of the component parts. These component parts are listed in numerical order according to the reference number shown in the illustration.

A special feature of this parts listing is a system of identifying those parts which are included with an assembly or with other parts. The included part, or parts, is denoted by being indented from the previous item. When a part is ordered that has an indented item, or items, following the part, the indented items are always included with that part. Indented items may also be ordered individually.

There are a number of items in the parts listing that are located on the rear or front of the unit, or that are identified as being either right hand or left hand parts. These parts are modified with the necessary descriptive information to properly identify them. In referring to the rear, the front or to either side of the unit, always consider the receiver-separator as the rear of the unit. Standing at the rear of the unit facing the receiver-separator, will determine the right and left sides.

The right hand column show both the part number and the quantity of each item. The quantity given is the total quantity required per assembly or per group of parts.

HOW TO ORDER

The satisfactory ordering of parts by a purchaser is greatly dependent upon the proper use of all available information. By supplying your nearest Ingersoll-Rand Company branch office, or authorized distributor or dealer with complete information, you will enable them to fill your order correctly and to avoid any unnecessary delays. In order that all avoidable errors may be eliminated, the following instructions are offered as a guide to the purchaser when ordering replacement parts.

- a. Always specify the model number of the unit as shown on the model plate attached to the front housing. (Figure 21).
- b. Always specify the serial number of the unit. **THIS IS VERY IMPORTANT.** The serial




Fig. 22—Location of Unit Serial Number.

Pages 51 and 52 will give you the correct part number and the contents of each box in the event they were not obtained at the time the compressor was purchased.

In addition to the spare parts boxes available for the Models GR85 and GRU85 Air Compressors, a selection of spare parts is available for the Continental F-163 Gasoline Engine.


One complete set of instruction books and parts lists covering both the engine and compressor is shipped with each machine. For additional copies of the engine literature, consult your nearest engine authorized distributor or dealer. Additional copies of the compressor literature may be obtained from the nearest Ingersoll-Rand branch office.

AIR END PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	AIR END ASSEMBLY	R85P150	1
1	Coupling Driven Gear	2H16351	1
2	Coupling Driven Gear "O" Ring	X1514T253C	1
3	Cylinder	2F9828	1
4	Bearing Housing to Cylinder "O" Ring	X1514T267C	2
5	Cylinder to Regulator Gasket	2W41172	1
6	Cylinder Discharge Cover Gasket	2W41171	1
*	Pipe Plug	30A752	1
7	Rotor	2F9826	1
8	Coupling Drive Key	X1495T13	1
9	Coupling Lock Nut	2W37667	1
10	Coupling Lock Washer	2W37668	1
11	Bearing Spacer	2W37373	2
12	Cylinder End Plate	2R16440P2	2
13	Rotor Vane - Set (Consists of 8 Vanes)	R85P110	1
14	Cylinder Roller Bearing	2W41186	2
15	Outer Bearing Retaining Ring	X1318T22	1
16	Inner Bearing Housing	2H16107	1
17	Rotary Shaft Seal Replacement Parts	2W56901	1
18	Seal to Housing "O" Ring	X1514T228C	1
19	Seal to Housing Cap Screw - Allen Head	91A2A173	5
20	Ever-Lock Lock Washer	X1619T2	5
21	Bearing Housing to Cylinder Cap Screw	35A2-1D222	15
22	Bearing Housing to Cylinder Cap Screw	35A2-1D225	1
23	Cap Screw Steel Washer	X1016T91	16
24	Outer Bearing Housing	2H16110	1
25	Cylinder Discharge Cover	2W41165	1
6	Cylinder Discharge Cover Gasket	2W41171	1
26	Cover to Cylinder Cap Screw	35A2-1D111	6
27	Oil Pump Cylinder	2R22313	1
28	Cylinder to Housing, Cover "O" Ring	X1514T243C	2
29	Oil Pump Vane	2W43773	4
30	Oil Pump Cover	2W43772	1
31	Oil Pump Rotor	2W43776	1
32	Oil Pump Cap Screw	35A2-1D63	6
33	Coupling Drive Gear	2H16350	1
34	Coupling Drive Gear "O" Ring	X1514T258C	1
35	Coupling Drive Gear Cap Screw	35A2-1D111	6
*	Coupling Drive Gear Cap Screw Lock Washer	14A5C76	6
36	Housing to Engine Cap Screw	35A2-1D111	8

Always give the serial number of your compressor.

R26325 Includes: Spacer & Cover



AIR FILTER PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	AIR FILTER ASSEMBLY	X1398T15	1
1	Air Filter Pre-Cleaner	AME 16291	1
2	Filter Top Bracket	J140-145	1
3	Filter Bracket Bolt, Nut 21202 and Washer 22701	17214	1
4	Filter Bottom Bracket with Clamp Assembly	J140-240	1
3	Filter Bracket Bolt, Nut 21202 and Washer 22701	17214	1
5	Filter Top Assembly	J140AJ-800	1
6	Filter Bowl and Baffle Plate Assembly	J140-862	1
7	Koroseal "O" Ring	A19163-2125	1
8	Air Inlet Elbow and Filter Bracket Assembly	2H16171	1
*	Pipe Plug	30A7S2	1
9	Air Inlet Elbow Gasket	2W37558	1
10	Air Inlet Elbow Cap Screw	35A2-1C109	4
11	Air Inlet Elbow Hose	2W37428	1
12	Air Inlet Elbow Hose Clamp	2W86719	2
13	Engine Air Inlet Tube	2R35234	1
14	Engine Air Inlet Tube Hose Clamp	2W86684	2
15	Filter to Bracket Cap Screw	35A2-1C109	4
16	Filter to Bracket Cap Screw Nut	16A4C3	4
17	Filter to Bracket Cap Screw Nut Lock Washer	14A5C76	4

Always give the serial number of your compressor.

GR85 GYRO-FLO COMPRESSOR

UL-88 REGULATOR AND LINKAGE PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM			
17	UL-88 Regulator Pilot Valve Adjusting Screw.....	W26388	1
18	UL-88 Regulator Pilot Valve Adjusting Screw Lock Nut.....	W46062	1
19	UL-88 Regulator Pilot Valve Adjusting Screw Nut.....	W12826 P1	1
20	UL-88 Regulator Bottom Cover.....	R17469 P1	1
21	UL-88 Regulator Lever.....	R35135	1
*	UL-88 Regulator Lever Bushing.....	W37528	1
22	UL-88 Regulator Shaft.....	W26387	2
23	UL-88 Regulator Retaining Ring.....	X1318T9	4
24	UL-88 Regulator Range Spring - Outside.....	PP604	1
25	UL-88 Regulator Range Spring - Inside.....	PP327	1
26	UL-88 Regulator Range Spring Seat.....	W32830	1
27	UL-88 Regulator Range Spring Support.....	W34629	1
28	UL-88 Support Socket Head Cap Screw.....	1/4" - 20 x 1"	4
29	UL-88 Regulator Minimum Speed Screw.....	5/16" - 18 x 2 3/4"	1
30	UL-88 Regulator Minimum Speed Screw Lock Nut.....	5/16" - 18	1
31	UL-88 Regulator Name Plate.....	R35207	1
32	UL-88 Regulator Name Plate Drive Screw.....	7A16X172	1
*	UL-88 Regulator Bracket.....	#2 x 1/4"	2
*	UL-88 Regulator to Bracket Cap Screw.....	2R22238	1
*	UL-88 Regulator to Bracket Cap Screw Lock Washer.....	35A2-1C216	2
36	UL-88 Regulator Governor Lever Link Rod.....	14A5C101	2
37	UL-88 Regulator Adjustable Rod End Yoke.....	X1580T15	1
38	UL-88 Regulator Rod End Lock Nut.....	2W86703T1	1
39	UL-88 Regulator Rod End Pin.....	22A4C1	1
40	UL-88 Regulator Rod End Cotter Pin.....	2W86704T2	1
41	UL-88 Regulator Governor Spring.....	11A13C3E	1
42	UL-88 Regulator Adjustable Rod End Yoke.....	2W34949	1
43	UL-88 Regulator Rod End Lock Nut.....	2W86703T2	1
44	UL-88 Regulator Rod End Yoke Stud.....	22A4C2	1
45	UL-88 Regulator Latch Pin.....	2W26696P1	1
46	UL-88 Regulator Latch Pin Cotter.....	2W86704T1	1
47	UL-88 Regulator Manual Speed Control Cable.....	11A13C16E	1
*	UL-88 Regulator Manual Speed Control Cable (Model GRU-85).....	2R35265	1
*	UL-88 Regulator Control Cable Clamp.....	2R25640P3	1
*	UL-88 Regulator Control Cable Clamp Cap Screw.....	X1182T22	1
*	UL-88 Regulator Control Cable Clamp Cap Screw Nut.....	35A2-1C3	1
*	UL-88 Regulator Control Cable Clamp Cap Screw Nut Lock Washer.....	16A4C1	1
52	UL-88 Regulator Control Cable Connector.....	14A5C55	1
53	UL-88 Regulator Control Cable Connector Set Screw.....	2W86583	1
54	UL-88 Regulator Control Cable Lever Stop.....	2W88450	2
55	UL-88 Regulator Control Cable Lever Stop Set Screw.....	2W56972	2
*	UL-88 Regulator to Unloader Tubing.....	2W88450	1
*	Copper Tube.....	2W44155	1
*	Copper Tube Nut.....	X1617T3x15 7/8	1
*	90° Tube Elbow.....	X1086T68	2
*	90° Tube Elbow.....	X1086T25	1
		X1086T3	1

*Not Illustrated.

Always give the serial number of your compressor.

OIL SEPARATOR AND MINIMUM PRESSURE VALVE PARTS

35 576209

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM			
1	OIL SEPARATOR TANK	2F15352	1
*	Pipe Plug.....	30A7S3	1
2	Oil Separator Shell to Tank, Cover Gasket.....	2W41049	2
5	Oil Filler Hole Plug.....	2W48777	1
6	Oil Filler Hole Plug "O" Ring.....	X1514T214C	1
*	Oil Separator Filter Screen Assembly	2R22177	1
*	Oil Separator Filter Screen Nut.....	16A4C3	2
*	Oil Separator Filter Screen Nut Lock Washer.....	14A5C76	2
7	Oil Separator Tank Support Cushion.....	X1222T2	4
*	Support Cushion Rivet.....	2W86676	4
8	Oil Separator Tank Strap - Front.....	2W41125	2
9	Oil Separator Tank Strap Nut.....	X1302T36	4
10	Oil Separator Tank Strap - Rear.....	2W41124	2
9	Oil Separator Tank Strap Nut.....	X1302T36	4
11	Oil Separator Cover.....	2R22172	1
2	Oil Separator Shell to Tank, Cover Gasket.....	2W41049	2
12	Oil Separator Cover Cap Screw.....	35A2-1J221	6
12	Oil Separator Cover Cap Screw.....	35A2-1J225	2
13	Oil Separator Inner Shell.....	2R22167	1
2	Oil Separator Shell to Tank, Cover Gasket.....	2W41049	2
14	Oil Separator Screen Assembly with Packing	2H16478TA	1
2	Oil Separator Shell to Tank, Cover Gasket.....	2W41049	2
15	Oil Separator Screen "O" Ring.....	X1514T216C	1
16	Oil Separator Tank Oil Level Gauge.....	2R17410	1
17	Oil Separator Tank Oil Level Gauge Gasket.....	2W31890	1
18	Oil Separator Oil Level Gauge Cap Screw.....	2W41051	4
*	Condensate Drain Reducing Bushing.....	23A7M5	1
*	Condensate Drain Pipe Nipple.....	19A7W20	1
*	Condensate Drain Globe Valve.....	60A17B2	1
*	Condensate Drain Valve Pipe Plug.....	30A7S3	1
19	Oil Separator to Safety Valve Piping Complete	2W57898	1
19A	Close Nipple - Extra Heavy.....	19A7W5	1
20	Female Union Elbow - 90°.....	90A7M4	1
20A	Pipe Nipple - Extra Heavy.....	2W86677	1
21	Pipe Cross.....	73A7M5	1
21A	Reducing Bushing.....	23A7M9	1
22	Pipe Nipple.....	18A7W23	1
22A	Reducing Tee.....	74A7M16	1
23	Safety Valve - Standard.....	X1396T4-125	1
24	Pipe Nipple for Manual Blowdown.....	2W86678	1
25	Angle Valve for Manual Blowdown.....	84A17B2	1
*	Oil Separator to UL-88 Regulator Tubing (From Reducing Bushing in Safety Valve Line).....	2W57870	1
*	Copper Tube.....	X1617T3x22	1
*	Copper Tube Nut.....	X1086T68	2
*	90° Tube Elbow.....	X1086T25	1
*	Tube Tee.....	X1086T8	1
The following used on units up to and including Compressor Serial Number 85MR21720:			
MINIMUM PRESSURE VALVE COMPLETE		R125P510	1
27	Valve Body.....	2H16116	1
28	Valve.....	2R22122	1
29	Valve Ring.....	X1244T2	1
30	Valve Spring.....	PP763	1
31	Valve Body Cover.....	2R22123	1
32	Valve Body Cover "O" Ring.....	X1514T224C	1
33	Valve Body Cover Cap Screw and Lock Washer.....	3/8" - 16 x 1"	2
The following used on units Compressor Serial Number 85MR21721 and up:			
MINIMUM PRESSURE VALVE COMPLETE		RA125P510A	1
35	Valve Body.....	2H209T4	1
36	Valve.....	2R26640	1
37	Valve Ring.....	X1440T18A	1
38	Valve Spring.....	2W56947	1
39	Valve Body Cover.....	2R26641	1
40	Valve Body Cover "O" Ring.....	X1514T216C	1
41	Valve Body Cover Cap Screw.....	35A2-1D111	2
*	Valve Body Cover Cap Screw Lock Washer.....	14A5C76	2
42	Pipe Plug.....	31A7M8	1
*	Air Double Male Valve.....	2W57548	2

*Not Illustrated.

Always give the serial number of your compressor.

RADIATOR AND OIL COOLER PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM			
1	Radiator to Engine Water Pump Hose.....	2R22237	1
2	Radiator to Engine Water Pump Hose Clamp.....	2W86681	1
3	Radiator Top Inlet Elbow.....	2W56995P1	1
4	Radiator Top Inlet Elbow Hose Clamp.....	2W86684	3
5	Radiator Drain Cock.....	X1086T20	1
6	Radiator Drain Coupling.....	11A7W2	1
7	Radiator Drain Nipple.....	18A7W20	1
8	Radiator Fan Wing - Right Hand.....	2W43736	1
*	Radiator Fan Wing - Left Hand.....	2W43895	1
10	Radiator Fan Wing R.H. Machine Screw.....	83A2C69	6
11	Radiator Fan Wing R.H. Machine Screw Nut.....	21A4C8	6
12	Radiator Fan Wing R.H. Machine Screw Nut Flat Washer.....	12A5C25	6
13	Radiator Fan Wing R.H. Machine Screw Nut Lock Washer.....	14A5C28	6
14	Radiator Fan Shroud Assembly.....	2H16177	1
15	Fan Shroud to Radiator R.H. Machine Screw.....	83A2C95	12
16	Fan Shroud to Radiator R.H. Machine Screw Nut.....	21A4C9	12
17	Fan Shroud to Radiator R.H. Machine Screw Flat Washer.....	11A5C1	12
18	Fan Shroud to Radiator R.H. Machine Screw Nut Lock Washer.....	14A5C36	12
19	Radiator†.....	2F18724	1
19	Radiator††.....	2F18725	1
19	Radiator†††.....	2F18726	1
20	Radiator Pressure Cap.....	2R26T66	1
21	Radiator Shims.....	X1406T17	2
22	Radiator to Support Stud Nut.....	X1302T8	2
23	Radiator and Oil Cooler Support Bracket - Right Hand.....	2H30047	1
*	Radiator and Oil Cooler Support Bracket - Left Hand.....	2R35245	1
25	Bracket to Radiator Cap Screw.....	35A2-1C109	6
26	Bracket to Radiator Cap Screw Nut.....	16A4C3	4
27	Bracket to Radiator Cap Screw Nut Lock Washer.....	14A5C76	6
28	Bracket to Radiator Cap Screw Nut Plain Washer.....	11A5C4	6
29	Bracket to Radiator Cap Screw.....	35A2-1C1	4
30	Bracket to Radiator Cap Screw Lock Washer.....	14A5C55	4
31	Bracket to Radiator Cap Screw Plain Washer.....	11A5C1	1
32	Oil Cooler Support Rod.....	2R35244	1
33	Oil Cooler Support Rod Nut.....	11A5C3	4
34	Oil Cooler Support Rod Plain Washer.....	14A5C76	4
35	Oil Cooler Support Rod Lock Washer.....	16A4C3	2
36	Oil Cooler... <i>STEEL</i>.....	2F15302	1
36	Oil Cooler (Aluminum).....	2F15484	1
37	Oil Cooler Support Rod Cap Screw.....	35A2-1C107	2
38	Oil Cooler Support Rod Cap Screw Lock Washer.....	14A5C76	2
39	Oil Cooler to Bracket Cap Screw.....	35A2-1C109	2
40	Oil Cooler to Bracket Cap Screw Nut.....	16A4C3	2
41	Oil Cooler to Bracket Cap Screw Lock Washer.....	14A5C76	2
42	Radiator and Oil Cooler Support Bracket.....	2H16174	1
43	Support Bracket to Frame Cap Screw.....	35A2-1C110	4
44	Support Bracket to Frame Cap Screw Nut.....	16A4C3	4
45	Support Bracket to Frame Cap Screw Nut Lock Washer.....	14A5C76	4


*Not Illustrated.

Always give the serial number of your compressor.

†Manufactured by Modine Manufacturing Company.

††Manufactured by Perflex Corporation.

†††Manufactured by G and O Manufacturing Company and Equipped with integral Fan Shroud, does not require Items 12 and 13.



RUNNING GEAR

RUNNING GEAR PARTS

ILLUS. NO.	NAME OF PART PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM	UNITED MFG. CO. PART NO.	QTY.	ELECTRIC WHEEL CO. PART NO. †	QTY.	UNITED MFG. CO. PART NO. ††	QTY.
1	Truck Frame.....	2F9614	1	2F11057	1	2F15475	1
1	Truck Frame (Model GRU-85).....	***	1	***	1	2F10300	1
	RUNNING GEAR ASSEMBLY.....	***	1	***	1	R85P631F ¹	1
	Spring and Axle Mounting.....	***	1	***	1	R85P631D	1
2	Axle Beam.....	5" 107	2	HNRSF2H	2	31-4501	1
3	Spindle Nut.....	31624	2	FS11928	2	5X-407	2
4	Spindle Nut Washer.....	1648	2	INCLUDED	2	1TX-144	2
5	Spindle Nut Cotter.....	31093	2	A937	2	9X-146	2
6	Spring.....	1520-2	2	AFS2893	2	1648-1	2
7	Spring Bracket - Slip End.....	30269	2			1520-2 35106178	2
8	Spring Bracket Pin - Slip End.....	9X-146	2			6804 35106152	2
*	Spring Bracket Pin Cotter Pin.....	31624	2	AFS2892	2	9X-146	2
9	Spring Bracket - Fixed End.....	35A2-1C219	8	35A2-1C219	6	1521-4	2
10	Spring Bracket to Frame Cap Screw.....	X1302T8	8	X1302T8	6	35A2-1C219	8
11	Spring Bracket to Frame Cap Screw Nut.....	31093	2	3/8"-11 x 4"	2	X1302T8 6744CS	8
12	Spring Bracket Bolt - Fixed End.....	31095	2	X1302T10	2	10-801	2
*	Spring Bracket Bolt Nut - Fixed End.....	9X-146	2			1-906	2
*	Spring Bracket Bolt Nut Cotter Pin.....	1504-8	2			9X-146	2
13	Lubrication Fitting.....	30327	4	FS12394 No. 2	4	1504-8	2
14	Spring "U" Bolt.....	35X-192	8	INCLUDED	8	4-1728	4
15	Spring "U" Bolt Nut.....	***	2	B4468	2	35X-192	8
16	Spring to Axle Clamp.....	2H16197	1	2H16197	1	3-1722	2
17	Draw Bar.....	1/2"-13 x 1 3/4"	8	1/2"-13 x 1 3/4"	8	2H250064	1
18	Draw Bar to Frame Cap Screw.....	2W32950	3	2W32950	3	35A2-1D323	8
*	Draw Bar to Frame Bevel Washer.....	1/2"-13 x 1 3/4"	4	1/2"-13 x 1 3/4"	4		
19	Draw Bar to Frame Cap Screw.....	X1302T8	7	X1302T8	7	X1302T10	8
*	Draw Bar to Frame Cap Screw Lock Nut.....	2R10315	1	2R10315	1		
20	Draw Bar Leg Support.....						
21	Draw Bar to Leg Support Cap Screw, Nut and Lock Washer.....	1/2"-13 x 1 1/4"	2	1/2"-13 x 1 1/4"	2		
22	Draw Bar Drop Leg.....	5/8"-11 x 2 1/4"	1	5/8"-11 x 2 1/4"	1	2W69302	1
23	Draw Bar Drop Leg Pivot Bolt.....	X1302T10	1	X1302T10	1	35A2-1C327	1
24	Draw Bar Drop Leg Pivot Bolt Nut.....	2W24532	2	2W24532	2	X1302T10	1
25	Drop Leg Locking Pin.....	2W34825	2	2W34825	2	2W24890	1
26	Drop Leg Locking Pin Chain with Hooks.....	2W41099	1	2W41099	1	2W34825	1
27	Front Drop Leg.....	2W41098	1	2W41098	1	2W41099	1
28	Front Drop Leg Pivot Bolt.....	11A5C9	1	11A5C9	1	2W41098	1
*	Front Drop Leg Pivot Bolt Washer.....	X1302T8	1	X1302T8	1	11A5C9	1
*	Front Drop Leg Pivot Bolt Nut.....	11A5C6	1	11A5C6	1	X1302T8	1
*	Front Drop Leg Pivot Bolt Plain Washer.....	R85P50A	1	R85P50A	1	11A5C6	1
	PNEUMATIC CASTER ASSEMBLY.....	***	1	***	1	R85P50B	1
29	Draw Bar Drop Leg.....	2W24532	1	2W24532	1	2W69217	1
25	Drop Leg Locking Pin.....	2W34825	1	2W34825	1	2W24532	1
26	Drop Leg Locking Pin Chain with Hooks.....	35A2-1C113	4	35A2-1C113	4	2W34825	1
30	Caster to Leg Cap Screw.....	16A4C3	4	16A4C3	4	35A2-1C113	4
*	Caster to Leg Cap Screw Nut.....	14A5C76	4	14A5C76	4	16A4C3	4
*	Caster to Leg Cap Screw Nut Lock Washer.....	FS-890	1	FS-890	1	14A5C76	4
31	Special Sealed Swivel Assembly Complete, less Wheel.....	8 x 2.50	1	8 x 2.50	1	FS-890	1
32	Steel Disc Rubber Tired Wheel.....					8 x 2.50	1

*Not illustrated.

†Electric Wheel Company Mountings used on Serial Numbers 85MR14842, 85MR15628 up to and including 85MR24170.


††Units with Serial Numbers 85MR29181, 85MR29531 and up.

**For United Mfg. Co. Running Gear Axle Beam replacement, order as follows:

Units up thru Serial No. 85MR14848 (except 85MR14842) with 52" track, order Axle Beam UM-12-3500. The Axle Clamp is UM-30311. Spring and Axle Mounting is R85P631. Running Gear Assembly is R85P631A. Units 85MR14849 and up through 85MR15627 with 1 3/4" axle and 54" track, order 2" Axle Beam UM-31-4501 and Axle Clamp UM-30312. Spring and Axle Mounting is R85P631D. Running Gear Assembly is R85P631E. Units 85MR24171 and up with 54" track and 2" axle, order Axle Beam UM-31-4501. The Axle Clamp is UM-30312. Spring and Axle Mounting is R85P631D. Running Gear Assembly is R85P631E. (Units 85MR29181, 85MR29531 and up use R85P631F).

***If Axle Beam, or Spring and Axle Mounting required, replacement is by United Mfg. Co. Spring and Axle Mounting R85P631D, old frame have to be drilled to suit new running gear.

W Bar Drop Leg 2W41122 is used with 5.00x15 implement tires and Leg 2W56931 is used with 6.40x15 and 6.50x15 passenger tires. Caster Mountings, Draw Bar Drop Leg 2W43908 is used with 5.00x15 implement tires and Leg 2W56392 is used with 6.40x15 and 6.50x15 passenger tires.



OIL FILTER PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
1	OIL FILTER ASSEMBLY.....	10159-01	1
2	Oil Filter Sump Drain Plug.....	32151-01	1
3	Oil Filter Sump Screw - Long.....	31456-34	1
4	Oil Filter Sump Screw - Short.....	32504-40	2
5	Oil Filter Sump Screw Nut.....	32504-37	8
6	Oil Filter Sump Screw Lock Washer.....	31259-49	2
7	Oil Filter Mounting Bracket.....	31255-38	12
8	Oil Filter Head.....	31259-32	1
9	Oil Filter Head Gasket.....	32223-43	1
10	Oil Filter Vent Plug.....	32160-36	1
11	Oil Filter Relief Valve Spring (15 psi).....	31784-32	1
12	Oil Filter Relief Valve Ball.....	32167-34	1
13	Oil Filter Relief Valve Seat.....	32061-32	1
14	Oil Filter Cartridge Assembly.....	32157-31	1
15	Oil Filter Cartridge Handle.....	13008-07	1
*	Oil Filter Cartridge Mounting Screw.....	31528-32	1
*	Oil Filter Cartridge Mounting Screw Lock Washer.....	32499-34	2
18	Oil Filter Cartridge Gland Nut.....	31251-37	2
19	Oil Filter Cartridge Gland Follower.....	32158-31	1
20	Oil Filter Cartridge Gland Packing.....	32059-31	1
		32058-31	1

il number of your compressor.


MISCELLANEOUS PARTS

(Not Illustrated)

REF. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
1	Continental Model F-163 Gasoline Engine.....	2W86652	1
2	Engine Front Mounting Spacer.....	2W41079	1
3	Engine Rear Support Bracket.....	2R22192	2
4	Bracket to Engine Cap Screw.....	35A2-1D219	2
5	Bracket to Engine Cap Screw Lock Washer.....	14A5C101	2
6	Bracket to Engine Cap Screw.....	35A2-1D222	3
7	Bracket to Engine Cap Screw Lock Washer.....	14A5C101	3
8	Bracket to Frame Cap Screw.....	35A2-1D221	4
9	Bracket to Frame Cap Screw Lock Nut.....	X1302T8	4
10	Bracket to Engine Cap Screw.....	35A2-1D221	3
11	Bracket to Engine Cap Screw Lock Washer.....	14A5C101	3
12	Lifting Bale to Inlet Tube Clamp.....	X1182T18	1
13	Air Inlet Tube Clamp.....	2W37388	1
14	Air Inlet Tube Clamp Cap Screw.....	35A2-1C1	1
15	Air Inlet Tube Clamp Cap Screw Nut.....	16A4C1	1
16	Air Inlet Tube Clamp Cap Screw Nut Lock Washer.....	14A5C55	1
17	Engine Muffler.....	2H16312	1
18	Engine Exhaust Muffler Pipe.....	2W41102	1
19	Engine Exhaust Muffler Pipe Bronze Nut.....	16A4Z3	2
20	Engine Muffler Clamp.....	2W48119	1
21	Rain Cap.....	2W34780	1
22	Instrument Panel Assembly.....	2H24740	1
23	Instrument Panel Mounting Bracket.....	2H16413	1
24	Mounting Bracket to Panel Cap Screw.....	35A2-1C57	3
25	Mounting Bracket to Panel Cap Screw Nut.....	16A4C2	3
26	Mounting Bracket to Panel Cap Screw Nut Lock Washer.....	14A5C65	3
27	Ignition Control Switch.....	2W86698	1
28	Switch to Panel Nut.....	22A4C3	1
29	Switch to Panel Nut Lock Washer.....	14A5C76	1
30	Discharge Pressure Gauge.....	2R26709	1
31	Discharge Pressure Gauge (Model GRU-85).....	X26T19A	1
32	Engine Water Temperature Gauge.....	2W37272	1
33	Engine Oil Pressure Gauge.....	X26T16A	1
34	Ammeter.....	2W86700	1
35	Magnetic Control Switch (Starter).....	2W67915	1
36	Choke Wire.....	2R22280	1
37	Choke Wire (Model GRU-85).....	2R17913	1
38	Hourmeter - 12 Volt.....	2W86696	1
39	Battery - 12 Volt.....	2W86690	1
40	Battery Bracket Assembly.....	2H16202	1
41	Bracket to Frame Cap Screw.....	35A2-1C110	4
42	Bracket to Frame Cap Screw Nut.....	16A4C3	4
43	Bracket to Frame Cap Screw Nut Lock Washer.....	14A5C76	4
44	Battery Lock Stud.....	2W48278	2
45	Battery Lock Stud Nut.....	16A4C3	6
46	Battery Lock Stud Plain Washer.....	12A5C4	2
47	Battery Hold Down Frame.....	2R26356	1
48	Battery Cover to Frame Spacer.....	2W48922	1
49	Battery Lock Cover.....	2R18587	1
50	Battery Lock Cover Washer.....	14A5C76	2
51	Battery Lock Cover Wing Nut.....	2W86691	2
52	Compressor Discharge Temperature Control Switch.....	2R17460	1
53	Temperature Control Switch Brass Nut.....	21A4B9	2
54	Temperature Control Switch Brass Nut Lock Washer.....	X1619T1	2
55	Battery to Ground Cable.....	X1467T1	1
56	Battery to Magnetic Switch Cable.....	X1467T6	1
57	Magnetic Switch (Mounted on Frame).....	2W48252	1
58	Magnetic Switch Cap Screw.....	35A2-1C3	2
59	Magnetic Switch Cap Screw Nut.....	16A4C1	2
60	Magnetic Switch Cap Screw Nut Lock Washer.....	14A5C55	2
61	Magnetic Switch to Starter Connector.....	2W48285	1
62	Hourmeter to Switch Wire.....	2W88436T1	1
63	Hourmeter to Ground Wire.....	2W88436T3	1
64†	Voltage Regulator Bracket.....	2W88493	1
65†	Voltage Regulator Bracket Cap Screw.....	35A2-1C113	2
66†	Voltage Regulator Bracket Cap Screw Lock Washer.....	14A5C3	2
67†	Wiring Harness.....	2H30051	1
68	Tubing to High Pressure Discharge Gauge (From Tube Tee in Safety Valve Line).....	2W57869	1
69	Copper Tube.....	X1617T1x37½	1
70	Copper Tube Nut.....	X1086T38	2
71	Tube Elbow.....	X1086T119	1

ed when Delco Remy Voltage Regulator and Alternator are furnished.
 Ignition System used on Serial Numbers 85MR15629, 85MR15632, 85MR15711 and up.
 give the serial number of your compressor.

Hose Assy
 for gauge
 is 1/2" NPT
 W5750




Hose from
Discharge Press. Gauge
to Tank is W57869

Consider 02
COMM
REC'D
TUBI
INC

COMPRESSOR TUBING AND FITTINGS




GR85 GYRO-FLO COMPRESSOR



OIL TEMPERATURE BY-PASS VALVE PARTS


ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	OIL TEMPERATURE BY-PASS VALVE ASSEMBLY..... 35500974	2W40886P1	1
1	By-Pass Valve Body.....	2H16018P1	1
2	By-Pass Valve Body "O" Ring.....	X1514T220C	1
3	By-Pass Valve Assembly.....	2W40885	1
4	By-Pass Valve Pipe Plug.....	30A7S5	1



OIL PUMP RELIEF VALVE PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	OIL PUMP RELIEF VALVE ASSEMBLY..... 35500982	2W43854T	1
1	Oil Pump Relief Valve Body.....	3W21461	1
2	Oil Pump Relief Valve Valve.....	3W21462	1
3	Oil Pump Relief Valve Spring.....	PP755	1
4	Oil Pump Relief Valve Cap.....	2W43853	1
5	Shim - if necessary (to decrease spring load).....	X1026T26	1
6	Shim - if necessary (to increase spring load).....	X1026T48	1

Always give the serial number of your compressor.



UL-108 AUTOMATIC BLOWDOWN VALVE PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	AUTOMATIC BLOWDOWN VALVE ASSEMBLY.....	UL-108-1	1
1	Automatic Blowdown Valve Body.....	2W56993	1
2	Automatic Blowdown Valve Ball.....	2W86706	1
3	Automatic Blowdown Valve Spring.....	PP888 X1091T888	1
4	Automatic Blowdown Valve Retaining Ring.....	X1319T12	1
5	Automatic Blowdown Valve Piston.....	2W56922	1
6	Automatic Blowdown Valve Diaphragm.....	2W48114	1
7	Automatic Blowdown Valve Cover.....	2W48116	1
*	Automatic Blowdown Valve Cap Screw.....	35A2-1D58	4

PARTS NECESSARY TO CONVERT TO UL-108 AUTOMATIC BLOWDOWN VALVE

	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	Kit, Automatic Blowdown Valve Conversion.....	R85P55A	1
	Valve Assembly, Automatic Blowdown.....	UL108-1 35501337	1
	Gasket, Inlet Elbow.....	2W37558	1
	Gasket, Regulator Body to Cylinder.....	2W41172	1
	Cross, Pipe.....	3/4"	1
	Bushing, Reducing.....	3/4" x 1/4"	1
	Tube Assembly, Blowdown Valve.....	2W57868	1
	Tube Assembly, Gauge Line.....	2W57869	1
	Tube Assembly, Pressure Line.....	2W57870	1

*Not illustrated.

Always give the serial number of your compressor.



HOSE REEL AND FITTINGS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	DOUBLE HOSE REEL ASSEMBLY	R85P785	1
1	Hose Reel.....	2H16275	2
2	Hose Reel Bearing.....	2R16217	2
3	Hose Reel Bracket.....	2W32959	2
4	Hose Reel Bearing "O" Ring.....	X1514T326C	4
5	Hose Reel Bearing Retaining Ring.....	2W26741	2
6	Hose Reel Bearing Cover.....	2W26742	2
7	Hose Reel Bearing Cover "O" Ring.....	X1514T230C	2
8	Revolution Retard Spring.....	PP331	2
9	Revolution Retard Ball.....	2W86708	2
10	Revolution Retard Spring Hole Plug.....	30A7M4	2
11	Grease Fitting.....	2W86707	2
12	Hose Reel to Cover Cap Screw.....	35A2-1C109	4
*	Hose Reel to Cover Cap Screw Lock Washer.....	14A5C76	4
13	Hose Reel to Bearing Cap Screw.....	35A2-1C113	8
*	Reel to Bearing Cap Screw Lock Washer.....	14A5C76	8
14	Close Nipple.....	18A7W5	2
15	Short Nipple.....	18A7W45	2
16	Elbow - 90°.....	65A7M5	4
*	Long Nipple.....	18A7W53	2
	Minimum Pressure Service Valve Assembly	R125P510A	2
17	Minimum Pressure Valve Body.....	2H16138	2
18	Minimum Pressure Valve.....	2R22147	2
19	Minimum Pressure Valve Ring.....	X1440T15A	2
20	Minimum Pressure Valve Spring.....	PP762	2
21	Minimum Pressure Valve Stem.....	2W41017	2
22	Minimum Pressure Valve Body Cover.....	2R22256	2
23	Body Cover "O" Ring.....	X1514T214C	2
24	Minimum Pressure Valve Stem Handle.....	2W41178	2
25	Valve Handle Nut.....	# 12 - 24	2
26	Valve Body Cover Cap Screw.....	5/16" - 18 x 3/4"	4
*	Valve Body Cover Cap Screw Lock Washer.....	5/16"	4
*	Hose Lock.....	2W86709	2
*	Hose Lock Coupling Cap.....	2W20684	2
*	Plain Washer.....	11A5C10	2

*Not Illustrated.


Always give the serial number of your compressor.

970 - 245 - 7268


MISCELLANEOUS PARTS (Cont'd)

(Not Illustrated)

REF. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
72	Tube Elbow.....	X1086T138	1
73	Tubing to Engine Oil Pressure Gauge.....	2W44158	1
74	Copper Tube.....	X1617T1x17½	1
75	Copper Tube Nut.....	X1086T38	2
76	90° Tube Elbow.....	X1086T119	1
77	90° Tube Elbow.....	X1086T138	1
78	Instruction Plate Set.....	2W57816	1
79	Complete Set of Gaskets and "O" Rings.....	R85P750	1



HOSE REEL AND FITTINGS




FUEL TANK PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
1	Fuel Tank	2R22194	1
2	Fuel Tank Cap	2R18674	1
*	Fuel Tank Pipe Plug - Drain	30A7S3	2
3	Fuel Tank Strap	2W41134	2
4	Fuel Tank Strap Nut	X1302T36	4
5	Fuel Tank Saddle	2R22193	2
6	Fuel Tank Cushion	X1221T1	4
7	Oil Separator Lining	X1222T1	4
*	Drive Rivet	2W86676	8
*	Fuel Tank to Fuel Pump Tubing	2W44154	1
*	90° Street Elbow	67A7M2	1
*	Shut-off Valve	X1086T102	1
*	Copper Tube	X1617T2x31	1
*	Copper Tube Nut	X1086T56	2
*	90° Tube Elbow	X1086T55	1
*	Tube Clamp	X1182T12	1
*	Tube Clamp Cap Screw	35A2-1C4	1
*	Tube Clamp Cap Screw Nut	16A4C1	1
*	Tube Clamp Cap Screw Nut Lock Washer	14A5C55	1

*Not Illustrated.


Always give the serial number of your compressor.

038553



ELECTRIC WHEEL CO. WHEEL PARTS

For units with 52" track, thru Serial
No. 85MR14848 (except 85MR14842),
500 x 15 Ribbed Implement Tires
and Tubes are used.

UNITED MANUFACTURING
CO. WHEEL PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM			
ELECTRIC WHEEL CO. WHEEL PARTS			
	Wheel Complete, Pneumatic Tired.....	X39TC12851B	1
	Tire and Tube, Passenger, 4 Ply.....	2W88438 650415	1
	Wheel Complete.....	X39TC12851A	1
1	Disc and Rim.....	C11895	1
2	Hub.....	Q833	1
3	Bolt, Wheel.....	FS8449K	6
	Cup, Inner Bearing.....	LM67010	1
	Cup, Outer Bearing.....	LM11910	1
4	Seal, Grease.....	AFS2782	1
5	Cap, Grease.....	FS12063	1
6	Cone, Inner Bearing.....	LM7048 LM67048	1
7	Cone, Outer Bearing.....	LM11949	1
UNITED MANUFACTURING CO. WHEEL PARTS			
	Wheel Complete, Pneumatic Tired.....	X39T11-1596T	1
	Tire and Tube, Passenger, 4 Ply.....	2W88438	1
	Wheel Complete.....	X39T11-1596TA	1
2	Wheel.....	U.M. 11-1596	1
3	Hub Assembly.....	U.M. 9-604	1
5	Nut, Hexagon.....	U.M. 6-904	5
6	Seal, Grease.....	U.M. 12-1000	1
7	Cap, Grease.....	U.M. 12-1001	1
8	Cone, Inner Bearing.....	15118	1
9	Cone, Outer Bearing.....	09074	1
3	Hub, Sub-Assembly.....	11-604	1
4	Stud.....	13-806	5
	Cup, Inner Bearing.....	15250	1
	Cup, Outer Bearing.....	09196	1
3	Hub.....	2-604	1

*Not illustrated.

†Electric Wheel Company Mountings used on Serial Numbers 85MR14842, 85MR15629 and up to and including 85MR24170.
Always give the serial number of your compressor.

GR85 GYRO-FLO COMPRESSOR

HOUSING PARTS (Cont'd)


ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
*	Tool Box Complete - Specify Right Hand or Left Hand.....	2H17785T	2
12	Tool Box End Plate - R.H. Front and L.H. Rear.....	2H17785	2
*	Tool Box End Plate - L.H. Front and R.H. Rear.....	2R26064	2
*	Tool Box End Plate Cap Screw.....	35A2-1C109	12
*	Tool Box End Plate Cap Screw Nut.....	16A4C3	12
*	Tool Box End Plate Cap Screw Nut Lock Washer.....	14A5C76	12
*	Tool Box Rear End Plate Spacer.....	2W41152	2
14	Tool Box Main Sheet.....	2H17786	2
*	Tool Box Main Sheet to Frame Cap Screw.....	35A2-1C2	34
*	Tool Box Main Sheet Cap Screw Nut.....	16A4C1	34
*	Tool Box Main Sheet Cap Screw Nut Lock Washer.....	14A5C55	34
*	Tool Box Main Sheet Cap Screw Nut Plain Washer.....	11A5C2	34
15	Side Cover Hood Latch.....	2W30144	4
*	Side Cover Hood Latch Cap Screw.....	35A2-1C1	8
*	Side Cover Hood Latch Cap Screw Nut.....	16A4C1	8
*	Side Cover Hood Latch Cap Screw Nut Lock Washer.....	14A5C55	8
*	Reflex Marker Unit.....	2W31704	2
*	Reflex Marker Unit Cap Screw.....	35A2-1C2	4
*	Reflex Marker Unit Cap Screw Nut.....	16A4C1	4
*	Reflex Marker Unit Cap Screw Nut Lock Washer.....	14A5C55	4
16	Fender†.....	2R22029 R22290	2
16	Fender††.....	2R26068	2
*	Fender Cap Screw.....	35A2-1C2	10
*	Fender Cap Screw Nut.....	16A4C1	10
*	Fender Cap Screw Nut Lock Washer.....	14A5C55	10
*	Fender Cap Screw Nut Plain Washer.....	11A5C2	10

*Not Illustrated.

Always give the serial number of your compressor.

†Used on units up to and including Serial Number 85MR14848.


††Used on units Serial Number 85MR14842 and 85MR14849 and up.



LIFTING BAIL PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
1	Lifting Bail.....	2H16364	1
2	Lifting Bail Nut.....	16A4C7	4
*	Lifting Bail Nut Lock Washer.....	14A5C120	4
3	Lifting Bail Cotter Pin.....	11A13C36H	2
4	Lifting Bail Hole Cover.....	2W43858	1
5	Lifting Bail Hole Cover Cap Screw.....	35A2-1C2	4
*	Lifting Bail Hole Cover Cap Screw Nut.....	16A4C1	4
*	Lifting Bail Hole Cover Cap Screw Nut Lock Washer.....	14A5C55	4


Always give the serial number of your compressor.




HOUSING PARTS

X1591P25


ILLUS. NO.	NAME OF PART	PART NO.	QTY.
PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM			
1	Housing Front Plate Assembly	2H17868	1
*	Front Plate to Frame Cap Screw	35A2-1C110	6
*	Front Plate to Frame Cap Screw Nut	16A4C3	6
*	Front Plate to Frame Cap Screw Nut Lock Washer	14A5C76	6
2	Rear Housing Plate - Right Hand	2H16193	1
*	Rear Housing Plate - Left Hand	2H16194	1
*	Rear Housing Plate Cap Screw	35A2-1C109	6
*	Rear Housing Plate Cap Screw Nut	16A4C3	4
*	Housing Plate Cap Screw Nut Lock Washer	14A5C76	4
3	Side Cover Support Arm	2W24025	4
4	Cupped Spring Washer - Slotted	2W30033	4
*	Cap Screw Nut	X1302T6	2
*	Front Plate Cap Screw	35A2-1C109	2
*	Front Plate Cap Screw Lock Nut	16A4C3	2
*	Top Cover Rear Support	2R22223	1
*	Top Cover Rear Support to Housing Plate Cap Screw	35A2-1C109	2
*	Top Cover Rear Support to Housing Plate Cap Screw Nut	16A4C3	2
*	Top Cover Rear Support to Housing Plate Cap Screw Nut Lock Washer	14A5C76	2
*	Nut Retainer	2W86714T2	14
5	Top Cover Rear Visor	2H16210	1
*	Visor to Rear Housing Cap Screw	35A2-1C2	4
*	Visor to Rear Housing Cap Screw Nut	16A4C1	4
*	Visor to Rear Housing Cap Screw Lock Washer	14A5C55	4
6	Top Cover	2H16201P1	1
*	Top Cover to Support Cap Screw	35A2-1C1	14
7	Housing Side Sheet - Right Hand	2H17787	1
*	Housing Side Sheet - Left Hand	2R26069	1
*	Housing Side Sheet Cap Screw	35A2-1C2	8
*	Housing Side Sheet Cap Screw Nut	16A4C1	8
*	Housing Side Sheet Cap Screw Nut Lock Washer	14A5C55	8
8	Side Cover Assembly	2H17788	2
9	Ingersoll-Rand Nameplate for Tool Box	20A16A2D	2
*	Ingersoll-Rand Nameplate Rivet	2W86689T1	8
10	Rubber Bumper	2W13762	6
11	Nameplate for Top Cover	22A16X1	1
*	Nameplate Cap Screw	35A2-1X2	3
*	Nameplate Cap Screw Nut	16A4C1	3
*	Nameplate Cap Screw Nut Copper Washer	X1026T45	3
*	Nameplate Cap Screw Lock Washer	14A5C55	3



RADIATOR AND OIL COOLER



OIL SEPARATOR AND MINIMUM PRESSURE VALVE




UL-88 REGULATOR PARTS

ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
1	UL-88 SPEED AND PRESSURE REGULATOR ASSEMBLY (Includes 1 thru 32)	UL88R85A	1
	UL-88 Regulator Body.....	R15427P2	1
	UL-88 Regulator Repair Kit.....	W52536	1
2	UL-88 Regulator Metering Pin.....	W32936	1
3	UL-88 Regulator Metering Pin Seat.....	W31748P2	1
4	UL-88 Regulator Metering Pin Seat Gasket.....	E1293	1
5	UL-88 Regulator Metering Pin Spring.....	PP607	1
6	UL-88 Regulator Socket Head Cap Screw.....	5/16" - 24 x 3/8"	1
7	UL-88 Regulator Cap Screw Gasket.....	X1108T20	1
8	UL-88 Regulator Top Cover Diaphragm.....	W37087	1
9	UL-88 Regulator Top Cover Diaphragm Bolt.....	W32937	1
10	UL-88 Regulator Top Cover Diaphragm Washer.....	1W1619P1	1
11	UL-88 Regulator Top Cover Diaphragm Bolt Nut.....	W32938	1
12	UL-88 Regulator Bottom Cover Diaphragm.....	W34874	1
13	UL-88 Regulator Top Cover.....	R15430	1
14	UL-88 Regulator Top Cover Cap Screw.....	7/16" - 14 x 3"	4
15	UL-88 Regulator Pilot Valve Spring.....	PP412	1
16	UL-88 Regulator Pilot Valve Spring Seat.....	D42616	1
		UL83-2B	1
		UL88-200	1
		UL88-5B	1
		UL88-6B	1
		UF1-31	1
		UL83-33A	1
		UL88-7A	1
		UL83-40	1
		UF1-38	1

Always give the serial number of your compressor.

10-380

ML



UL-89 VOLUMETRIC REGULATOR PARTS


ILLUS. NO.	NAME OF PART	PART NO.	QTY.
	PARTS INDENTED AFTER AN ITEM ARE INCLUDED WITH THE ITEM		
	UL-89 VOLUMETRIC REGULATOR ASSEMBLY.....	UL89R85A - 35701184-625	1
1	UL-89 Volumetric Regulator Body.....	2F9507P3 - 35000	1
2	UL-89 Regulator Body to Cylinder Gasket.....	2W41172	1
3	Compressor Air Inlet Elbow Gasket.....	2W37558	1
4	UL-89 Regulator Valve Bushing.....	2W43898	2
5	UL-89 Regulator Diaphragm Body Gasket.....	2W37988	1
6	UL-89 Regulator Body Orifice Plug.....	X1080T38	1
7	UL-89 Regulator Body Plug.....	2W57581	1
8	UL-89 Regulator to Cylinder Cap Screw.....	35A2-1D219	1
9	UL-89 Regulator Unloader Valve.....	2W37985	1
10	UL-89 Regulator Diaphragm Body.....	2R22315	1
11	UL-89 Regulator Diaphragm Body Gasket.....	2W37988	1
12	UL-89 Regulator Diaphragm Piston.....	2W37987	1
13	UL-89 Regulator Diaphragm Piston Spring.....	PP754	1
14	UL-89 Regulator Diaphragm.....	2W43779	1
15	UL-89 Regulator Diaphragm Cover.....	2R22316	1
16	UL-89 Regulator Diaphragm Cover Pipe Plug.....	30A7S2	1
*	UL-89 Diaphragm Cover to Diaphragm Body Cap Screw.....	35A2-1D111	1
*	UL-89 Diaphragm Cover to Regulator Body Cap Screw.....	35A2-1D116	1
*	Atmospheric Relief Valve Tubing (From Regulator Body).....	2W57868	1
*	Copper Tube.....	X1617T3X14½	1
*	Copper Tube Nut.....	X1086T68	1
*	Tube Elbow.....	X1086T3	1
*	Inverted Tube Elbow.....	X1086T118	1
*	Inverted Tube Nut.....	X1086T116	1

*Not Illustrated.

Always give the serial number of your compressor.

404-691-5701

214-838-5048



AIR END



Fig. 21—Location of Unit Serial Number.

number of the unit will be found stamped on a brass instruction plate attached to the housing. The serial number of the unit will also be found stamped in the metal on the top edge of the L.P. Inner Bearing Housing. (Figure 22).

- c. Always specify the form number of this publication.
- d. Always specify the description of the part, or parts, as well as the part number exactly as it is given in the parts listing. Do not order a part, or parts, using the illustration number.
- e. Never use such terms as "Assembly", "Complete" or "Sets" unless these terms appear specifically in the parts listing.
- f. Always specify the quantity of parts required.

In the event parts are being returned to your nearest Ingersoll-Rand Company branch office, or authorized distributor or dealer, for inspection or repair, it is extremely important to include the serial number

of the unit from which the parts were removed. This is necessary if the branch, distributor, or dealer is to take care of your order promptly.

Engine parts must be ordered from your nearest engine authorized distributor or dealer.

SPARE PARTS

Special selections of spare parts have been prepared as insurance against prolonged shutdown periods. These selected parts, called spare parts boxes, are shown itemized in the rear of this section. The contents of each spare parts box are carefully selected so as to provide maximum protection for the unit with a minimum number of parts. Three sizes of spare parts boxes, ranging from small to extra large, are available. The small spare parts box is suitable for minimum domestic use while the large is suitable for average domestic use or for minimum export use. The extra large spare parts box is suitable to maintain up to five units, domestically; or up to two units in foreign countries, or in remote locations, where transportation facilities may be slow.




Fig. 20—Capacity-Speed Chart.

GR85 GYRO-FLO COMPRESSOR




Fig. 17—UL-89 Volumetric Regulator, UL-88 Speed and Pressure Regulator and Linkage.

and chamber "A" pressure to rise above 100 psi (7.03 kg/cm²), then movement of the needle valve will permit sufficient air to pass to chamber "B" to overcome the bleed loss. This will build up enough pressure to move lever "C" in an infinitely variable manner from the full speed position to a reduced speed, just sufficient to meet the reduced air demand. This speed and capacity change, from 100% down to 60% capacity, results in a drop of from full engine speed of 2100 RPM down to approximately 1400 RPM, and occurs with a discharge pressure increase of approximately six psi (.42 kg/cm²); for example, from 100 to 106 psi (7.03 to 7.45 kg/cm²).

On further reduction of air demand, the final discharge pressure will rise above 106 psi (7.45 kg/cm²); lifting the chamber "A" needle valve still more and further increasing the pressure in chamber "B", whereupon two controlling functions occur simultaneously.

1. Since movement of lever "C" continues with further increase of pressure in chamber "B", there will be additional speed reduction, which, carried to its full limit, will reduce the speed proportionately from 1400 RPM approximately down to 1000 RPM. The low speed limit is adjusted by the low speed stop screw "P" on the UL-88 regulator. It limits the movement of the regulator lever in this direction.

2. At the same time, the increase in chamber "B" pressure, which is also effective on the operating diaphragm "L" of the UL-89 Volumetric Regulator, is now sufficient to start closing the intake regulator valve "M". Here again the closing of the valve is in an infinitely variable manner and the resulting capacity of the unit is progressively reduced.

The combined effect of functions (1) and (2) is such that the capacity of the unit is reduced from 60% capacity to zero capacity while the final discharge pressure is rising from 106 to 110 psi (7.45 kg/cm² to 7.73 kg/cm²).

Complete regulation therefore has occurred within a pressure range of approximately 10 psi (.703 kg/cm²) and in an infinitely variable or stepless manner. (See Speed and Volumetric Regulation Diagrams, Figs. 19 and 20).

UL-89 VOLUMETRIC REGULATOR (Fig. 17)

The UL-89 Volumetric Regulator consists of an intake housing equipped with a port and a diaphragm operated valve "M". The diaphragm chamber "L" receives its operating pressure from the UL-88 Speed and Pressure Regulator as explained previously.

Balancing control of the diaphragm is obtained by spring "J". This spring maintains sufficient ten-

IDENTIFICATION OF OTHER SERVICE PARTS

1. Engine crankcase drain plug "U".
2. Air filter pre-cleaner "V". Keep screen free of dirt, leaves, etc. at all times. To remove dirt, wash screen in a non-flammable safety solvent.
3. Radiator drain plug "W". Drain engine cooling water in freezing weather if system not protected by antifreeze. Refer to the engine book.
4. Engine cylinder block drain cocks "X". Drain engine cooling water in freezing weather if system not protected by antifreeze. Refer to the engine book.
5. The tightness of all screws and nuts should be checked periodically, especially the wheel nuts.

PART V REGULATION

REGULATION

100% regulation is provided for by a proportional speed reduction from full capacity down to approximately 60% capacity, and a combination of further speed reduction with volumetric regulation of the compressor for capacities from 60% down to zero capacity.

The total effect is accomplished by the "Air Glide" UL-88 Speed and Pressure Regulator in conjunction with the UL-89 Volumetric Regulator. (See Figure 17.)

UL-88 "AIR GLIDE" SPEED AND PRESSURE REGULATOR (Fig. 17)

The UL-88 Speed and Pressure Regulator is an air pressure operated device consisting of a spring loaded diaphragm on one side of a central body with an operating diaphragm on the opposite side of the same body. The central body forms two chambers "A" and "B", with a needle valve orifice located to pass air from one chamber to the other.

Chamber "A" is directly connected through tubing to the air delivery end of the receiver-separator and thus is subject to final discharge pressure at all times. Chamber "B" is connected through tubing to the operating diaphragm chamber "L" of the UL-89 Volumetric Regulator, where a small orifice "K" is provided to bleed off a portion of the regulating air to give range control to the system.

The spring loaded diaphragm of chamber "A" controls the positioning of the orifice needle, thus controlling the amount of pressure passing from chamber "A" to chamber "B". A spring loaded lever "C"

is so arranged against the chamber "B" diaphragm that movement of this diaphragm is multiplied, and conveyed by linkage, to the engine governing system.

The pressure in chamber "B" will always be less than that in chamber "A" because of the throttling effect of the needle valve orifice and the fact that, when less than full capacity is being used and the discharge pressure is above the set pressure, chamber "B" pressure is then constantly bleeding off through the small vent "K" in the UL-89 Volumetric Regulator. Thus, when final discharge pressure (and chamber "A" pressure) is sufficient to cause the diaphragm to raise the needle valve off its seat, chamber "B" pressure will slowly raise and gradually overcome force of spring "D" and move lever "C" to cause speed reduction of the engine and compressor.

Since spring "D" is designed to be stronger than the engine governor spring, lever "C" will be held against the stop "E" as long as there is insufficient pressure in chamber "B" to overcome the difference in balance between spring "D" and the engine governor spring. Therefore, the engine will operate at full rated speed as long as the pressure in chamber "A" is insufficient to raise the needle valve.

The force of spring "G" on the needle valve diaphragm is so adjusted by screw "H" that no lever movement occurs until final discharge pressure has reached 100 psi (7.03 kg/cm²); or whatever set pressure between 90 and 110 psi (6.33 and 7.73 kg/cm²) is desired, in accordance with the tools being operated. Do not attempt to adjust below 90 psi (6.33 kg/cm²) or above 110 psi (7.73 kg/cm²).

If the air demand is less than the full capacity of the compressor, causing the final discharge pressure

LUBRICATION AND PREVENTIVE MAINTENANCE

(For Periodic Engine Maintenance, Refer To Engine Operation and Maintenance Instructions)




Fig. 15—Lubrication Chart - Right Hand Side of Unit.

ONCE A DAY (or every 8 hours of operation)

1. Open the small condensate drain valve "A" under the receiver-separator to draw off any accumulated condensate which may collect under the compressor lubricating oil. Close as soon as oil appears. Do this each morning before starting the days run.
2. Maintain an oil level in the receiver-separator between one-half and full on the oil level indicator gauge "B". Check this gauge each morning before starting.
3. Service the air filter "C" if the compressor is operating in an extremely dusty location. Remove the bottom oil pan; drain off the oil and clean out the sludge and dirt; refill with new oil to bead line and replace pan.
4. Turn handle "D" of oil filter one complete revolution, preferably immediately after shutting down while oil is still warm.
5. Check engine fuel strainer. See engine book.
6. Check the coolant level in the engine radiator "E". Add make-up coolant if necessary.

7. Check the oil level in the engine crankcase by removing the oil level dipstick "F". Add make-up oil if necessary. Refer to the engine book.

ONCE A WEEK (or every 50 hours of operation)

1. Service the air filter "C" if the unit is being operated in a reasonably clean atmosphere. Remove the bottom oil pan; drain off the oil and clean out the sludge and dirt; refill with new oil to bead line and replace pan.
2. Lubricate the regulator to engine governor linkage "G" with a few drops of oil. Use the same grade of oil as that used in the engine crankcase.
3. Lubricate the hose reel bearings "H" (where applicable). Apply grease to the fittings on each reel, using a low pressure grease gun.
4. Change engine lubricating oil. Refer to engine book.
5. Lubricate the starter "I" and generator "J" sparingly. Use a few drops of oil the same grade as that used in the engine crankcase.




Fig. 14—Diagram of Compressor Lubricating and Cooling Oil Systems.

air before it enters the secondary receiver-separator section. The **level of the oil** in this storage reservoir is indicated by an oil level dial gauge, visible from the rear of the unit. This should indicate at least between "½ and full" when the unit is shut down and on **fairly level ground**. The storage reservoir (shell) is equipped with a special filler plug and a small drain valve "A" Fig. 14.

The small drain valve "A" is used in testing for condensate which may accumulate under the oil in the bottom of the reservoir during certain climatic conditions, especially if operating at less than 40% load capacity. For **complete draining** of the reservoir and piping, open the small drain valve "A" at the low end of the receiver-separator. Also, remove the drain plug "B", under the oil cooler, and the drain plug "C" in the cylinder discharge elbow.

Do not attempt to remove the oil filler plug "D" without first releasing all pressure in the receiver-separator by opening manual blowdown valve "F", Fig. 6.

COMPRESSOR LUBRICATING OIL RECOMMENDATIONS

These instructions are very important.

1. Use a quality turbine type oil, containing only rust and oxidation inhibitors, that has a viscosity

at 100°F. of 150-220 sec. Saybolt (37.8°C of 33-48 Centistokes) and having a pour point low enough so it will flow at the lowest starting temperature encountered.

2. Service the compressor lubricating oil filter every 100 hours.
3. The oils specified previously provide adequate lubrication at all ambient temperatures and load conditions. They give maximum efficiency and easiest cold starting and make seasonal changes unnecessary. The absence of detergents minimizes water pick-up and emulsification under low load conditions. Thus, swelling of vanes and consequent loss of slot clearance is prevented.
4. Some oil mixtures are incompatible, resulting in the formation of varnishes, shellacs or lacquers which may be insoluble. Such deposits can cause serious troubles, including clogging of oil filter, sticking vanes and possibly vane breakage.

Therefore, Do Not Mix Different Brands Of Oils.

5. The receiver-separator, oil cooler and oil filter should be drained completely and refilled with new oil, as supplied by your preferred oil supplier to meet preceding recommendations, when unit




Fig. 12—Operating the Starter Button on Model GR85.
Operating Instruments are mounted on the end of the
Model GRU85.

started against a lighter load than normal. However, the manual blowdown valve must be closed as soon as it is possible to do so without stalling the engine.

STOPPING

Close the service valves and the manual blowdown valve causing compressor to unload and engine to operate at minimum reduced speed. Continue to operate at this reduced speed until the engine has cooled down sufficiently to prevent the radiator from boiling over, then turn ignition switch off.

Air pressure must now be relieved from the receiver-separator system. Normally, this is accomplished by the automatic blowdown valve; however, on earlier models not equipped with an automatic blowdown valve, the operator must relieve the pressure from the receiver-separator by opening the manual blowdown valve. The unit should never stand idle with pressure in the system.

Close shut-off valve underneath fuel tank.

MINIMUM PRESSURE VALVE (G. Fig. 6)

This is an automatic valve which maintains a minimum pressure of about 45 psi (3.16 kg/cm²) in the receiver-separator so as to insure oil circulation.

Shut-off of discharge is accomplished by means of service valves located on the downstream side of the receiver-separator. On units equipped with hose reels, minimum pressure service valves with hand wheels are provided so that manual shut-off may be accomplished.

The minimum pressure valve cannot be used as a check valve in any operation where a check valve is required to prevent back flow of line pressure such as in parallel operation, etc.

Note:—See page 12 for special warning on Rotary Compressors on Pump-up Jobs.

See page 12 for special warning for Parallel Operation.

AUTOMATIC BLOWDOWN VALVE

The air flow system is equipped with an air actuated automatic blowdown valve, located in the air receiver safety valve piping, to automatically relieve the air pressure in the air flow system each time the unit is shutdown. When the compressor is stopped and no longer pumps air, the pressure within the compressor and the receiver-separator system becomes equalized. This equalization of pressure creates a positive pressure within the UL-89 Volumetric Regulator. This positive pressure is then transmitted, through tubing, to the automatic blowdown valve diaphragm chamber. This positive pressure, acting upon the larger area of the blowdown valve diaphragm, causes a piston to unseat a ball check. This allows the receiver-separator air pressure to be blown down to atmospheric pressure.

On earlier units not equipped with an automatic blowdown valve, the receiver-separator pressure must be relieved by use of the manual blowdown valve.

The unit should never stand idle with pressure in the receiver-separator.




Fig. 10—Secondary Oil Separator Element, factory packed, and replaceable as a complete unit only.

of the oil is thrown out of the air mechanically in the primary oil separator, before the air enters the secondary oil separator.)

The secondary separator section (as shown in Fig. 10) is removable as a unit for replacement when required. This is indicated by more oil consumption by the compressor than usual. In normal operation, servicing of the secondary separator element should not be required for two or three years.

The diverting medium is a very special material, purchased to a strict specification and installed in the screen element to a definite density. Servicing, therefore, is by replacement only with a complete factory packed screen assembly as shown in Fig. 10.

CHASSIS (GENERAL)

The spring mounting is equipped with grease fittings at wear points for use of a normal grease gun. The wheels should be removed and the bearings cleaned and repacked twice a year. The slip ends of the springs should be lubricated every three months with heavy oil or light grease.

In greasing tapered roller bearing equipped wheels **do NOT overgrease**. Keep the outside of the dust seal clean and free of grease. **Keep the disc wheel hub bolts tight.**

Grease fittings are provided on the third wheel swivel and on the hub. **Do not overgrease.** Keep the third wheel disc nuts tight.

Maintain 26 psi (1.82 kg/cm²) air pressure in the 6.50 x 15, 4 ply tires to obtain maximum tire life.

MAXIMUM ALLOWABLE TOWING SPEED

Speed on this unit is 35 MPH (56 km/hr.)

ROTARY COMPRESSORS ON PUMP-UP JOBS

The oil separator on the rotary portable air compressor is designed to function correctly at normal operating pressures.

The high air velocities (zero pressure or low pressure) will carry considerable quantities of oil from the secondary oil separator over into the discharge line; therefore, it is essential to hold a minimum pressure of 45 psi (3.16 kg/cm²) in the receiver-separator system until such time as the discharge line pressure has increased to that amount. This is accomplished by a minimum pressure valve which automatically maintains a minimum pressure of 45 psi (3.16 kg/sq. cm²) in the air receiver and oil separator system.

Attempting to operate at discharge pressures below 45 psi (3.16 kg/cm²) will not increase the actual delivery.

OUT-OF-LEVEL OPERATION

The limit of out-of-level operation is 15° lengthwise and 15° sidewise. The engine, and not the compressor, is the limiting factor in all cases. When the unit is to be operated out of level, it is more important to keep engine crankcase oil level near the high level mark than when operating on level ground. The above out-of-level degrees are given on the assumption that the engine crankcase is filled to the high level mark (with the unit level) and the compressor oil gauge shows nearly full. Do not overfill either the compressor lubricating system or the engine crankcase.

Another factor that must be kept in mind is that the static tipping angle of the unit is approximately 42° (90% slope) sideways.

COMPRESSOR COUPLING

The complete coupling assembly is sealed to prevent the entrance of dirt and to retain the permanent lubrication installed on the original assembly.

If the engine and compressor are separated during a major overhaul, the coupling gear teeth should be repacked with grease before reassembling.

Use an automotive type front wheel bearing grease available at any service station. Use only enough to fill the gear teeth, as an excess of grease in the chamber will expand with heat and the resulting end thrust may cause compressor failure.

SPECIAL WARNING FOR PARALLEL OPERATION

Do not connect a Gyro-Flo Portable Air Compressor into a common header with any other units of any description, or any other source of compressed air, without placing a check valve between the header and each Gyro-Flo Compressor.

Backflow of line pressure and possible contamination of the receiver-separator and lubricating system with oil, water, or scale MUST BE PREVENTED.

SPRING MOUNTING

The complete unit is carried on sturdy two wheel mounting.

The mounting has semi-elliptic springs of the self-snubbing type. Pneumatic tired disc-type wheels equipped with tapered roller bearings are standard.

LESS RUNNING GEAR UNITS

"Less running gear" units are furnished on temporary wooden shipping skids. If customer mounts

a "less running gear" unit on other equipment, it is his responsibility to see that the frame is not stressed or warped because of the mounting arrangement. The use of special rubber mounts may be desirable or necessary.

MODEL GRU85 COMPRESSOR

The GRU85 units, designed for truck mounting, are furnished on temporary wooden shipping skids. The operating instruments are mounted at the end of the unit.

PART II

CARE and OPERATION

ENGINE RADIATOR AND COMPRESSOR OIL COOLER

Keep all core sections of both the radiator and oil cooler clean by using a cleaning solution. Higher efficiency and lower temperatures will result when the external grease and grime and the internal oxidation of the lubricating oil is thoroughly removed. Use only clean, soft water for filling the radiator. Where the water is known to be "hard" or alkaline, treat it with a softening compound to prevent formation of scale and rust, both in the engine jacket spaces and in the radiator itself.

Freezing of water in the cooling system may result in serious damage. If the unit is to stand idle in freezing temperatures, the only safe plan is to drain the system unless an anti-freeze solution is used.

Before adding any anti-freeze solution, tighten up all joints in the cooling system and make sure there are no leaks.

Ethylene-glycol solutions are recommended since they are not lost by evaporation and only water need be added to maintain a full system. If any of the solution is lost by leakage, foaming, etc., it must be replaced by new anti-freeze solution.

The entire cooling system must be thoroughly cleaned and flushed before using an ethylene-glycol solution. All hose connections and joints must be kept tight, as any leakage of air into the system may cause acid formation and corrosion.

ANTI-FREEZE SOLUTIONS

Percentages by volume
Ethylene Glycol

Freezing
Temperature

16%
25%
33%
39%
44%
48%

20°F (-6.6°C)
10°F (-12.2°C)
0°F (-17.8°C)
-10°F (-23.3°C)
-20°F (-28.9°C)
-30°F (-34.4°C)

FUEL SYSTEM

The compressor is equipped with a cylindrical fuel tank located above the receiver-separator. The fuel tank filler cap, "B" Fig. 6, is of the lockable type.

The capacity of the fuel tank is 14 U. S. Gallons (52.7 Liters).

The outlet connection of the tank is so arranged that fuel is taken from a point somewhat above the floor of the tank thus providing a settling space where water and sediment can collect without being drawn into the fuel system. Bottom drain openings, "A" Fig. 6, are provided for removal of any collected water and sediment.

Drain the settlings frequently. See that the vent hole in the filler cap does not become plugged with dirt, or gum from the fuel.

Clean fuel is vitally important and every precaution should be taken to insure the fuel being clean when it is poured or pumped into the supply tank.




Fig. 4—Diagram showing compression cycle of the Gyro-Flo.

The **oil pump** is located at the rear end of the rotor chamber. This is of the sliding vane type with the rotor mounted on and driven by the rotor shaft.

The oil pump receives its supply from the oil cooler through piping and an oil filter. It discharges the oil through internal passages directly to the rotor bearings and chambers.

An adjustable spring loaded by-pass valve in the receiver-separator prevents any possibility of damage due to over-pressure.

When the compressor is operating at low capacity, some of the oil may by-pass the cooler through a thermostatically controlled by-pass valve. This arrangement helps to maintain a higher average compressor oil temperature, thereby reducing the possi-

bility of water vapor condensation in the oil system. This valve, located in the oil piping, by-passes varying amounts of oil, depending on the temperature, until the oil being circulated reaches a temperature of 185°F (85°C). At this point, the valve closes the by-pass completely and all the oil is circulated through the cooler.

GENERAL - AIR END

The rotor chamber intake is equipped with a UL-89 Volumetric Regulator (Fig. 17). The incoming air passes through an efficient oil bath (stack type) air filter before entering the regulator and the compressor.

The rotor shaft extends forward to carry an internal-external gear toothed coupling, the outer ring of which is bolted directly to the engine flywheel. This coupling assembly is lubricated and sealed against the entrance of dirt or moisture and provides necessary flexibility. The rotor, which rides in its own set of caged roller bearings, also serves to drive the oil pump.

Regulation is 100%, from full capacity to zero capacity, and is accomplished by a combination of engine (and compressor) speed reduction together with proportional compressor volumetric regulation.

It is recommended that vane tips be inspected at 2000 hours or after one year. Vanes should be replaced after 4000 hours service or every two years as a matter of routine preventive maintenance. When vanes are replaced, make sure that driving or trailing tips of rotor slots are not razor sharp. They should be slightly rounded. This can be easily accomplished by using a fine grained stone to produce a radius of about $\frac{1}{4}$ " (0.4 mm).

To make an inspection of the vanes with a minimum removal of parts, the following procedure is recommended. Remove UL-89 Regulator Assembly and then "inch" engine over with the starter and inspect vanes through the exposed air intake in cylinder.

INSTRUMENT PANEL (Fig. 5)

The instruments are located on one panel at the center of the unit. Instruments include discharge air pressure gauge, engine water temperature indicator, engine oil pressure gauge and ammeter. Other panel mounted items include ignition switch, choke, starting button, manual speed control handle and hourmeter.

ELECTRIC STARTING

Electric starting is standard and includes starting motor, generator, voltage regulator, and battery with necessary wiring and terminals.

GENERAL DATA

Gyro-Flo Air Compressor	Model GR85
Actual Delivery of Compressor	85 Cubic Feet Per Minute (2405 Liters Per Minute)
Normal Operating Pressure	100 Pounds Per Square Inch (7.03 Kilograms Per Centimeter Squared)
Continental Gasoline Engine	Model F163
Engine Speed at Full Load	2100 Revolutions Per Minute
Engine Speed at No Load (Approximate)	1000 Revolutions Per Minute
Air Maze Air Filter	Model J140AJ
Capacity of Air Cleaner (To Beading)	1.75 Pints (.825 Liters)
Electrical Starting System	12 Volt
Capacity of Compressor Lubricating and Cooling Oil System	4.5 U. S. Gallons (17 Liters)
Capacity of Engine Lubricating Oil System, Including Oil Filter	4.5 Quarts (4.25 Liters)
Capacity of Engine Cooling System	3.5 U. S. Gallons (13.2 Liters)
Capacity of Fuel Tank	14 U. S. Gallons (52.7 Liters)
Size of Pneumatic Tires	6.50 x 15, 4 Ply
*Net Weight, Including Lubricating Oil and Running Gear	1724 Pounds (781 Kilograms)
Net Weight, Including Lubricating Oil and Shipping Skid, Less Running Gear	1470 Pounds (665 Kilograms)
Add for Required Engine Fuel and Coolant (Approximate)	135 Pounds (61.2 Kilograms)
Add for Boxing of Export Unit	34 Percent
Length, Including Pneumatic Tires and Drawbar	117 $\frac{1}{8}$ Inches (2910 Millimeters)
Length, Less Running Gear	67 $\frac{1}{8}$ Inches (1719 Millimeters)
Height	59 $\frac{3}{8}$ Inches (2700 Millimeters)
Height, Less Running Gear	42 $\frac{3}{8}$ Inches (1078 Millimeters)
Width, Including Pneumatic Tires and Fenders	62 $\frac{1}{8}$ Inches (1588 Millimeters)
Width, Including Minimum Pressure Valve, Less Running Gear	37 $\frac{1}{4}$ Inches (946 Millimeters)
Track Width	54 Inches (1372 Millimeters)
Cubage (For Export)	167 Cubic Feet (4.72 Cubic Meters)
Cubage, Less Running Gear (For Export) (Approximate)	69 Cubic Feet (1.95 Cubic Meters)

*Deduct 114 lbs. when unit is furnished less Tool Boxes and Fenders.

LUBRICATING OILS

Air Compressor	See Part IV
Continental F163 Gasoline Engine	Over 75°F (23.9°C) SAE 30 75°F (23.9°C) to 32°F (0°C) SAE 20-W 32°F (0°C) to -10°F (-23.3°C) SAE 10-W Below -10°F (-23.3°C) SAE 5W-20

NOTE

Units for export are completely drained of all lubricating oil before shipment. This includes the engine, compressor and air filter. All Domestic and Export units are shipped less fuel and engine coolant.