

ENGINE OPERATION and MAINTENANCE MANUAL



Cummins QSL9 Engine

Bulletin: 3666472-00 (January 2000)

“Portions Copyright Cummins Inc.”

**“Reproduced for limited licensed use only, with permission
from Cummins Inc. unlicensed use and/or reproduction are
expressly prohibited”**

Doosan Infracore Portable Power
1293 Glenway Drive
Statesville, N.C. 28625
www.doosanportablepower.com


Book: 22326748



**Doosan Infracore
Portable Power**



Operation and Maintenance Manual QSL9 Engine



00d00016

Foreword

This manual contains information for the correct operation and maintenance of your Cummins engine. It also includes important safety information, engine and systems specifications, troubleshooting guidelines, and listings of Cummins Authorized Repair Locations and component manufacturers.

Read and follow all safety instructions. Refer to the WARNING in the General Safety Instructions in Section I - Introduction.

Keep this manual with the equipment. If the equipment is traded or sold, give the manual to the new owner.

The information, specifications, and recommended maintenance guidelines in this manual are based on information in effect at the time of printing. Cummins Engine Company, Inc. reserves the right to make changes at any time without obligation. If you find differences between your engine and the information in this manual, contact your local Cummins Authorized Repair Location or call 1-800-DIESELS (1-800-343-7357) toll free in the U.S. and Canada.

The latest technology and the highest quality components were used to produce this engine. When replacement parts are needed, we recommend using only genuine Cummins or ReCon® exchange parts. These parts can be identified by the following trademarks:



Note: Warranty information is located in Section W. Make sure you are familiar with the warranty or warranties applicable to your engine.

Table of Contents

	Section
Introduction	i
Engine Identification	E
Operating Instructions	1
Maintenance Guidelines	2
Maintenance Procedures at Daily Interval	3
Maintenance Procedures at 14,500 Kilometers [9000 Miles], 250 Hours, or 3 Months	4
Maintenance Procedures at 29,000 Kilometers [18,000 Miles], 500 Hours, or 6 Months	5
Maintenance Procedures at 58,000 Kilometers [36,000 Miles], 1000 Hours, or 1 Year	6
Maintenance Procedures at 116,000 Kilometers [72,000 Miles], 2000 Hours, or 2 Years	7
Maintenance Procedures at 241,500 Kilometers [150,000 Miles], 5000 Hours, or 4 Years	8
Adjustment, Repair, and Replacement	A
System Diagrams	D
Service Literature	L
Component Manufacturers	M
Service Assistance	S
Troubleshooting Symptoms	TS
Maintenance Specifications	V
Warranty	W
Index	X

Important Reference Numbers

Fill in the part name and number in the blank spaces provided below. This will give you a reference whenever service or maintenance is required.

Part Name	Part Number	Part Number
Engine Model		
Engine Serial Number (ESN)		
Control Parts List (CPL)		
Fuel Pump Part Number		
Electronic Control Module (ECM)		
Electronic Control Module Serial Numbers (ECM)		
Filter Part Numbers:		
• Air Cleaner Element		
• Lubricating Oil Filter		
• Fuel		
• Fuel-Water Separator		
• Coolant		
• Remote Gas		
Governor Control Module (GCM) (if applicable)		
Belt Part Numbers:		
•		
•		
•		
Clutch or Marine Gear (if applicable):		
• Model		
• Serial Number		
• Part Number		
• Oil Type		
• Sea Water Pump		
– Model		
– Part Number		

Acronyms and Abbreviations	i-5
General Safety Instructions	i-4
Important Safety Notice	i-4
How to Use the Manual	i-1
Illustrations	i-3
Symbols	i-2
To the Owner and Operator	i-1

THIS PAGE LEFT INTENTIONALLY BLANK

To the Owner and Operator

Preventative maintenance is the easiest and least expensive type of maintenance. Follow the maintenance schedule recommendations outlined in the Maintenance Guidelines (Section 2).

Keep records of regularly scheduled maintenance.

Use the correct fuel, oil, and coolant in the engine as specified in the Maintenance Specifications (Section V).

Cummins Engine Company, Inc. uses the latest technology and the highest quality components to produce its engines. Cummins recommends using **only** genuine Cummins parts and ReCon® exchange parts.

The personnel at Cummins Authorized Repair Facilities have been trained to provide expert service and parts support. If there is a problem that can **not** be resolved by a Cummins Authorized Repair Facility, follow the steps outlined in Service Assistance (Section S).

CAUTION

Welding on a vehicle with an electronically controlled fuel system is not recommended. Disconnect both the positive (+) and ground (-) battery cables from the battery before welding on the vehicle. Attach the welder ground (-) cable no more than 0.61 m [2 ft] from the part being welded. Do not connect the ground (-) cable of the welder to the electronic control module (ECM). Welding on the engine or engine-mounted components is not recommended.

About the Manual

This manual contains information needed to operate and maintain the engine correctly as recommended by Cummins Engine Company, Inc. Additional service literature can be ordered from a local Cummins Distributor or by calling 1-800-DIESELS (1-800-343-7357) in the U.S.A. and Canada.

This manual does **not** cover vehicle or equipment maintenance procedures. Consult the vehicle or original equipment manufacturer (OEM) for specific maintenance recommendations.

Both metric and U.S. customary values are listed in this manual. The metric value is listed first, followed by the U.S. customary equivalent in brackets [].

Numerous illustrations and symbols are used to aid in understanding the meaning of the text. Refer to Symbols in this section for a complete list of the symbols and their definitions.

Each section is preceded by a Section Contents to aid in locating information quickly.

How to Use the Manual

This manual is organized according to the intervals that maintenance on the engine is to be performed. A maintenance chart (table) that lists the intervals and required maintenance procedures is in Section 2. Locate the interval of the maintenance to be performed; then follow the procedures in that section. In addition, the procedures listed under previous maintenance intervals **must** also be performed.

Keep a record of all the checks and inspections made. A form for recording the maintenance checks performed is in Section 2.

Refer to Section TS for a guide to troubleshooting the engine. Follow the directions to locate and repair engine problems.

Refer to Section V for the specifications recommended by Cummins Engine Company, Inc. for the engine. Refer to Section V for the specifications and torque values for each engine.

Symbols

The following symbols have been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below:



WARNING - Serious personal injury or extensive property damage can result if the warning instructions are **not** followed.



CAUTION - Minor personal injury can result or a part, an assembly, or the engine can be damaged if the caution instructions are **not** followed.



Indicates a **REMOVAL** or **DISASSEMBLY** step.



Indicates an **INSTALLATION** or **ASSEMBLY** step.



INSPECTION is required.



CLEAN the part or assembly.



PERFORM a mechanical or time **MEASUREMENT**.



LUBRICATE the part or assembly.



Indicates that a **WRENCH** or **TOOL SIZE** will be given.



TIGHTEN to a specific torque.



PERFORM an electrical **MEASUREMENT**.



Refer to another location in this manual or another publication for additional information.




The component weighs 23 kg [50 lb] or more. To avoid personal injury, use a hoist or get assistance to lift the component.


17800006

Illustrations

Some of the illustrations throughout this manual are generic and will **not** look exactly like the engine or parts used in your application. The illustrations can contain symbols to indicate an action required and an acceptable or **not** acceptable condition.



The illustrations are intended to show repair or replacement procedures. The procedure will be the same for all applications, although the illustration can differ.



General Safety Instructions

Important Safety Notice



Improper practices or carelessness can cause burns, cuts, mutilation, asphyxiation or other bodily injury or death.

Read and understand all of the safety precautions and warnings before performing any repair. This list contains the general safety precautions that **must** be followed to provide personal safety. Special safety precautions are included in the procedures when they apply.

- Make sure the work area surrounding the product is dry, well lit, ventilated, free from clutter, loose tools, parts, ignition sources and hazardous substances. Be aware of hazardous conditions that can exist.
- **Always** wear protective glasses and protective shoes when working.
- Rotating parts can cause cuts, mutilation or strangulation.
- Do **not** wear loose-fitting or torn clothing. Remove all jewelry when working.
- Disconnect the battery (negative [-] cable first) and discharge any capacitors before beginning any repair work. Disconnect the air starting motor if equipped to prevent accidental engine starting. Put a "Do **Not** Operate" tag in the operator's compartment or on the controls.
- Use **ONLY** the proper engine barring techniques for manually rotating the engine. Do **not** attempt to rotate the crankshaft by pulling or prying on the fan. This practice can cause serious personal injury, property damage, or damage to the fan blade(s) causing premature fan failure.
- If an engine has been operating and the coolant is hot, allow the engine to cool before you slowly loosen the filler cap and relieve the pressure from the cooling system.
- Do **not** work on anything that is supported **ONLY** by lifting jacks or a hoist. **Always** use blocks or proper stands to support the product before performing any service work.
- Relieve all pressure in the air, oil, fuel and the cooling systems before any lines, fittings, or related items are removed or disconnected. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do **not** check for pressure leaks with your hand. High pressure oil or fuel can cause personal injury.
- To prevent suffocation and frostbite, wear protective clothing and **ONLY** disconnect fuel and liquid refrigerant (freon) lines in a well ventilated area. To protect the environment, liquid refrigerant systems **must** be properly emptied and filled using equipment that prevents the release of refrigerant gas (fluorocarbons) into the atmosphere. Federal law requires capturing and recycling refrigerant.
- To avoid personal injury, use a hoist or get assistance when lifting components that weigh 23 kg [50 lb] or more. Make sure all lifting devices such as chains, hooks, or slings are in good condition and are of the correct capacity. Make sure hooks are positioned correctly. **Always** use a spreader bar when necessary. The lifting hooks **must not** be side-loaded.
- Corrosion inhibitor, a component of SCA and lubricating oil, contains alkali. Do **not** get the substance in your eyes. Avoid prolonged or repeated contact with skin. Do **not** swallow internally. In case of contact, immediately wash skin with soap and water. In case of contact, immediately flood eyes with large amounts of water for a minimum of 15 minutes. IMMEDIATELY CALL A PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.
- Naptha and Methyl Ethyl Ketone (MEK) are flammable materials and **must** be used with caution. Follow the manufacturer's instructions to provide complete safety when using these materials. KEEP OUT OF REACH OF CHILDREN.
- To avoid burns, be alert for hot parts on products that have just been turned off, and hot fluids in lines, tubes, and compartments.
- **Always** use tools that are in good condition. Make sure you understand how to use them before performing any service work. Use **ONLY** genuine Cummins or Cummins ReCon® replacement parts.
- **Always** use the same fastener part number (or equivalent) when replacing fasteners. Do **not** use a fastener of lesser quality if replacements are necessary.
- Do **not** perform any repair when fatigued or after consuming alcohol or drugs that can impair your functioning.
- Some state and federal agencies in the United States of America have determined that used engine oil can be carcinogenic and can cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil.
- Coolant is toxic. If **not** reused, dispose of in accordance with local environmental regulations.

Acronyms and Abbreviations

AFC	Air Fuel Control	kPa	Kilopascal
API	American Petroleum Institute	LNG	Liquid Natural Gas
ASA	Air Signal Attenuator	LTA	Low Temperature Aftercooling
ASTM	American Society of Testing and Materials	MIP	Mixer Inlet Pressure
°C	Celsius	MPa	Megapascal
CARB	California Air Resources Board	mph	Miles Per Hour
C.I.D.	Cubic Inch Displacement	mpq	Miles Per Quart
CNG	Compressed Natural Gas	N•m	Newton-meter
CPL	Control Parts List	NG	Natural Gas
cSt	Centistokes	OEM	Original Equipment Manufacturer
ECM	Electronic Control Module	ppm	Parts Per Million
ECS	Emission Control System	psi	Pounds Per Square Inch
EPA	Environmental Protection Agency	PTO	Power Takeoff
EPS	Engine Position Sensor	rpm	Revolutions Per Minute
°F	Fahrenheit	SAE	Society of Automotive Engineers
GVW	Gross Vehicle Weight	SCA	Supplemental Coolant Additive
Hg	Mercury	STC	Step Timing Control
hp	Horsepower	VS	Variable Speed
H₂O	Water	VSS	Vehicle Speed Sensor
ICM	Ignition Control Module		
km/l	Kilometers per Liter		

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.


Section E - Engine Identification


Section Contents

	Page
Engine Diagrams	E-5
Engine Views	E-5
Engine Identification	E-1
Cummins Engine Nomenclature	E-2
ECM Dataplate	E-2
Engine Dataplate	E-1
Fuel Injection Pump Dataplate	E-2
Specifications	E-3
Air Intake System	E-4
Batteries (Specific Gravity)	E-4
Cooling System	E-4
Electrical System	E-4
Exhaust System	E-4
Fuel System	E-3
General Specifications	E-3
Lubricating Oil System	E-3


THIS PAGE LEFT INTENTIONALLY BLANK

Engine Dataplate


 Cummins Engine Company, Inc. Box 3006 Columbus, Indiana 47301-0006 Warning: Import Reel (Patent) Not Warranted is Void and of Fuel System & Oil System Not Warranted Because: Not For This Model and Application. Date of Info: Made in U.S.A.	Engine Conf. LD	C.I.D./ L	SERIES	CPL	Engine Serial No.
	Timing TDC	Injection P/N	Gross S/H	Net S/H	Net S/H
	Injection Valve	Int.	Exh.	Fuel Inlet at Intake P/N	Min. S/H
	Piping Order	Low Idle RPM	E.C.S.	Model Name	




1. Engine serial number (ESN)
2. Control parts list (CPL)
3. Model number
4. Horsepower and rpm rating.



20000000


 Cummins Engine Company, Inc. Box 2004 Columbus, Indiana 47324-2004	Engine Cert. I.D.	C.I.D. / L	SERIES	CPL.	Engine Serial No.
					Injection P/W
					Cut 1 Speed
Timing TDC		Valve lash (in)		In.	Out.
Timing Belt (in)		In.		Out.	
Firing Order		Low idle RPM		Model Name	
Drive of Blg.		S.C.S.			
Made in U.S.A.					



XXXXXXX

Cummins Engine Nomenclature


The Cummins engine nomenclature provides the engine model and horsepower rating.



Fuel Injection Pump Dataplate

The Cummins accumulator pump system (CAPS) fuel injection pump dataplate is located on the side of the injection pump. The dataplate contains the following information:

- A. Cummins part number
- B. Pump serial number
- C. Factory code.




ECM Dataplate

The electronic control module (ECM) dataplate shows important facts about the ECM and how it is programmed. The dataplate is located on the ECM above the ECM connectors.

The following information is found on the ECM dataplate:

- ECM part number (PN)
- ECM serial number (SN)
- ECM date code (DC)
- Engine serial number (ESN)
- ECM Code identifying the software number that indicates how the ECM is programmed.

NOTE: When communicating with a Cummins Authorized Repair Facility, the ECM code is required.



Specifications

General Specifications

Horsepower	(Refer to engine dataplate)
QSL9 Engine Speed @ Maximum Power Output:	
Standard Rating	2100 rpm
Governed Speed	2300 rpm
Bore and Stroke	114 mm [4.49 in] x 144.5 mm [5.69 in]
Displacement	8.9 liters [543 C.I.D.]
Compression Ratio	16.6:1
Firing Order	1-5-3-6-2-4
QSL9 Approximate Engine Weight (with standard accessories)	706 kg [1556 lb]
Crankshaft Rotation (viewed from the front of the engine)	Clockwise
Valve Clearance:	
Intake	0.3048 mm [0.012 in]
Exhaust	0.5588 mm [0.022 in]

NOTE: The QSL9 engine features a no-adjust overhead. The QSL9 valve train is designed such that adjustment of the valve lash is **not** required for normal service during the first 241,500 km [150,000 mi] or 5000 hours. The valve train operates acceptably within the limits of 0.152 to 0.559 mm [0.006 to 0.022 in] intake valve lash and 0.381 to 0.813 mm [0.015 to 0.032 in] exhaust valve lash.

Fuel System

Engine Idle Speed	600 to 1200 rpm
Maximum Lift Pump Inlet Restriction at Rated	102 mm Hg [4 in Hg]
Maximum Fuel Filter Outlet Restriction at Rated	254 mm Hg [10 in Hg]
Minimum Fuel Filter Inlet Pressure during Cranking	508 mm Hg [20 in Hg]
Maximum Fuel Drain Line Pressure	254 mm Hg [10 in Hg]
Maximum Fuel Inlet Temperature	71°C [160°F]
Minimum Engine Cranking Speed	150 rpm

Lubricating Oil System

Oil Pressure:	
At Low Idle (minimum allowable)	69 kPa [10 psig]
At Rated Speed (minimum allowable)	207 kPa [30 psig]
Regulated Pressure	517 kPa [75 psi]
Oil Pan Capacity, Low to High:	
Standard Oil Pan	18.9 to 22.7 liters [20 to 24 qt]
Standard Oil Pan with Block Stiffener	19.9 to 23.7 liters [21 to 25 qt]
Total System Capacity:	
Standard Oil Pan	22.7 liters [24 qt]
Standard Oil Pan with Block Stiffener	23.7 liters [25 qt]
Oil Capacity of Standard Engine:	
Standard Oil Pan	
Pan Only	22.7 liters [24 qt]

NOTE: Some applications use a slightly different oil pan capacity. Contact a local Cummins Distributor if there are any questions.

Cooling System

Coolant Capacity (engine only)	10.9 liters [11.5 qt]
Standard Modulating Thermostat - Range	84 to 91°C [183 to 196°F]
Maximum Allowable Operating Temperature	100°C [212°F]
Minimum Recommended Operating Temperature	70°C [158°F]
Minimum Recommended Pressure Cap	50 kPa [7 psi]

Air Intake System

Maximum Intake Restriction (clean air filter element)	254 mm H ₂ O [10.0 in H ₂ O]
Maximum Intake Restriction (dirty air filter element)	635 mm H ₂ O [25.0 in H ₂ O]

Exhaust System

Maximum Exhaust Back Pressure	76 mm Hg [3 in Hg]
-------------------------------	--------------------

Electrical System

Recommended Battery Capacity

System Voltage	Ambient Temperature			
	-18°C [0°F]		-29°C [-20°F]	
	Cold Cranking Amperes	Reserve Capacity (Minutes) ⁽¹⁾	Cold Cranking Amperes	Reserve Capacity (Minutes) ⁽¹⁾
12 VDC	1500	360	1875	360
24 VDC ⁽²⁾	750	180	900	180

1. The number of plates within a given battery size determines reserve capacity. Reserve capacity determines the length of time for which a battery at 27°C [81°F] can supply 25 amperes at 10.5 volts or greater.
2. CCA ratings are based on two 12-VDC batteries in series.

Batteries (Specific Gravity)


Specific Gravity at 27°C [81°F]	State of Charge
1.260 to 1.280	100%
1.230 to 1.250	75%
1.200 to 1.220	50%
1.170 to 1.190	25%
1.110 to 1.130	Discharged

Engine Diagrams

Engine Views

The following illustrations provide the locations of the major external engine components, filters, and other service and maintenance points. Some external components will be at different locations for different engine models.


NOTE: The illustrations are **only** a reference to show a typical engine.



00d00024

Fuel Pump Side View


- | | |
|--|---|
| 1. Engine air inlet | 13. Electronic control module (ECM) |
| 2. Intake manifold pressure sensor | 14. Dipstick location |
| 3. Intake manifold temperature sensor | 15. M10 (STOR) oil pressure port |
| 4. M10 (STOR) fuel pressure after-lift pump | 16. Engine position sensor (EPS) - (inboard) |
| 5. M10 (STOR) fuel pressure before-lift pump | 17. Engine speed sensor (ESS) - (outboard) |
| 6. Magnetic pickup location 3/4-16 UNF | 18. Engine dataplate |
| 7. Fuel return connection | 19. High-pressure fuel lines |
| 8. Fuel inlet connection | 20. Cummins accumulator pump system (CAPS) injection pump |
| 9. Fuel lift pump | 21. Intake air heater |
| 10. Starter mounting flange | 22. Engine brake spacer (optional) |
| 11. Oil pressure sensor | 23. Engine brake harness pass-through. |
| 12. Fuel filter/water separator | |



00900119

Rear View


1. Rear engine lifting bracket
2. Turbocharger exhaust outlet
3. Clutch mounting holes
4. Flywheel housing
5. Flywheel.



00d00025

Exhaust Side View

- | | |
|------------------------------------|--|
| 1. 1/2-inch (NPTF) coolant taps | 8. Coolant inlet |
| 2. Turbocharger wastegate actuator | 9. Lubricating oil cooler |
| 3. Engine oil fill | 10. Engine oil pan drain plug |
| 4. Coolant outlet | 11. Lubricating oil filter |
| 5. Front engine lifting bracket | 12. Dipstick location |
| 6. Coolant temperature sensor | 13. Coolant filter |
| 7. Coolant heater port | 14. Injector drain fuel outlet connection. |



00d00026

Front View

- | | |
|-------------------------------|-----------------------------|
| 1. Fan pulley | 7. Water inlet |
| 2. Top dead center (TDC) mark | 8. Water pump |
| 3. Front gear cover | 9. Alternator |
| 4. Vibration damper | 10. Water outlet |
| 5. Engine oil pan drain plug | 11. Turbocharger air outlet |
| 6. Automatic belt tensioner | 12. Turbocharger air inlet |
| | 13. Engine oil fill. |

Section 1 - Operating Instructions

Section Contents

	Page
Cold Weather Operation	1-7
Customer Precharge Method	1-8
General Information	1-7
Shutters	1-9
Winterfronts	1-9
Cold Weather Starting Using Starting Fluid	1-4
Ether Starting Aids	1-4
Driving Techniques	1-40
General Information	1-40
Electromagnetic Interference (EMI)	1-41
General Information	1-41
System EMI Radiation Levels	1-41
System EMI Susceptibility	1-41
Electronic Controlled Fuel System	1-9
Basic Features	1-12
Diagnostic Fault Codes	1-37
Engine Protection System	1-11
General Information	1-9
Programmable Features	1-16
Engine Operating Range	1-5
General Information	1-5
Engine Shutdown	1-9
General Information	1-9
Normal Starting Procedure	1-2
Operating Instructions - General Information	1-1
Operating the Engine	1-4
General Information	1-4

THIS PAGE LEFT INTENTIONALLY BLANK

Operating Instructions - General Information

▲ WARNING ▲

Cummins Engine Company, Inc., does not know how you will use your engine. The equipment owner and operator, therefore, is responsible for safe operation in a hostile environment. Consult your Cummins Authorized Repair Location for further information.

Correct care of the engine will result in longer life, better performance, and more economical operation.

- Follow the daily maintenance checks listed in Maintenance Guidelines (Section 2).
- Avoid exposing the engine to corrosive chemicals.




Check the oil pressure indicator, temperature indicator, warning lights, and other gauges daily to make sure they are operational.


The Cummins engine associated with this manual does **not** require a "break-in" procedure. This manual provides all of the necessary information required for proper engine operation.

▲ WARNING ▲

Do not operate a diesel engine where there are or can be combustible vapors. These vapors can be sucked through the air intake system and cause engine acceleration and overspeeding, which can result in a fire, an explosion, and extensive property damage.

These vapors can be drawn in through the air intake system and can cause engine acceleration and overspeeding that can result in a fire, explosion, and extensive property damage.






Normal Starting Procedure

⚠ CAUTION ⚠


To prevent damage to the starting motor, do not engage the starting motor for more than 30 seconds. Wait 2 minutes between each attempt to start (electrical starting motors only).

- Disengage the drive unit, or if equipped, put the transmission in neutral.
- With the throttle in the idle position, turn the key to the ON position; wait for the WAIT TO START lamp to extinguish; then turn the key to the START position.
- If the engine does **not** start after three attempts, check the fuel supply system. An absence of blue or white exhaust smoke during cranking indicates that no fuel is being delivered to the combustion chambers.



⚠ CAUTION ⚠

The engine must have adequate oil pressure within 15 seconds after starting. If the WARNING lamp indicating low oil pressure has not extinguished, or there is no oil pressure indicated on the gauge within 15 seconds, shut off the engine immediately to avoid engine damage. Confirm the correct oil level in the oil pan.




Idle the engine for 3 to 5 minutes before operating with a load.

QSL9
Section 1 - Operating Instructions


Normal Starting Procedure
Page 1-3

Increase the engine speed (rpm) slowly to provide adequate lubrication to the bearings and to allow the oil pressure to stabilize.



⚠ CAUTION ⚠

Do not keep the engine at low idle for long periods. Long periods at low idle, more than 10 minutes, can damage an engine because combustion chamber temperatures drop so low that the fuel will not burn completely. This will cause carbon to build up around the injector spray holes and piston rings, which can cause the valves to stick.




⚠ WARNING ⚠


Batteries can emit explosive gases. To avoid personal injury, always ventilate the compartment before servicing the batteries. To avoid arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

⚠ CAUTION ⚠

To avoid damage to the QSL9 engine parts, do not connect jumper starting or battery charging cables to any QSL9 parts. When using an external electrical source to start the engine, turn the disconnect switch to the OFF position.


The accompanying illustration shows a typical parallel battery connection. This arrangement, positive (+) to positive (+) and negative (-) to negative (-), doubles the cranking amperage.





The accompanying illustration shows a typical series battery connection.

This arrangement, positive (+) to negative (-), doubles the voltage.




Cold Weather Starting Using Starting Fluid

Ether Starting Aids



WARNING

To avoid personal injury and property damage, never use starting fluid if the grid heater option is used. Starting fluid, which contains ether, can cause an explosion.



Operating the Engine

General Information




Continuous operation with a low coolant temperature, below 60°C [140°F], or a high coolant temperature, above 100°C [212°F], can damage the engine.

Monitor the oil pressure and coolant temperature gauges frequently. Refer to Lubricating Oil System Specifications and Cooling System Specifications in Section V for recommended operating pressures and temperatures. Shut off the engine if any pressure or temperature does **not** meet the specifications.




If an overheating condition starts to occur, reduce the power output of the engine by releasing the throttle pedal pressure or shifting the transmission to a lower gear, or both, until the temperature returns to the normal operating range. If the engine temperature does **not** return to normal, shut off the engine, and refer to Troubleshooting Symptoms (Section TS), or contact a Cummins Authorized Repair Facility.



Most failures give an early warning. Look and listen for changes in performance, sound, or engine appearance that can indicate service or engine repair is needed. Some changes to look for are as follows:



- Engine misfires
- Vibration
- Unusual engine noises
- Sudden changes in engine operating temperatures or pressures
- Excessive smoke
- Loss of power
- An increase in oil consumption
- An increase in fuel consumption
- Fuel, oil, or coolant leaks.




Engine Operating Range

General Information





Do not operate the engine at excessive full throttle below peak torque rpm for more than 30 seconds. This will shorten engine life to overhaul, can cause serious engine damage, and is considered driver abuse.

Cummins engines are designed to operate successfully at full throttle under transient conditions down to peak torque engine speed. This is consistent with recommended operating practices.



Operation of the engine below peak torque rpm can occur during gear shifting due to the difference of ratios between transmission gears, but engine operation **must not** be sustained for more than 30 seconds at full throttle below peak torque rpm.





△ CAUTION △

Do not operate the engine beyond high-idle speed (2600 rpm) under any circumstances. Operating the engine beyond high-idle speed can cause severe engine damage. When descending a steep grade, use a combination of transmission gears and engine or service brakes to control the vehicle and engine speed.

Cold Weather Operation


General Information

It is possible to operate diesel engines in extremely cold environments if they are properly prepared and maintained. The correct lubricants, fuels, and coolants **must** be used for the cold weather range in which the vehicle is operated. Refer to the chart below for recommendations in different operating ranges.

Winterize -32°C to 0°C [-26°F to 32°F]	Arctic Specification -54°C to -32°C [-65°F to -26°F]
Use 50-percent ethylene glycol or propylene glycol antifreeze and 50-percent water in the coolant mixture. Use multiviscosity oil meeting API CG-4 or CH-4 specifications. Fuel to have maximum cloud and pour points 6°C [43°F] lower than ambient temperature in which engine operates.	Use 60-percent ethylene glycol or propylene glycol antifreeze and 40-percent water in the coolant mixture. Use arctic oil meeting API CG-4 or CH-4 specifications. Fuel to have maximum cloud and pour points 6°C [43°F] lower than ambient temperature in which engine operates.


The following cold weather operating aids are suggested for cold weather situations:

Cold Weather Operating Aids



Customer Precharge Method


The temperatures listed in the following chart for coolant temperature sensing fan control and intake manifold temperature sensing fan control are correct for vehicles that allow the electronic control module (ECM) to control the on and off operation of the cooling fan. Consult the local original equipment manufacturer (OEM) for other kinds and styles of controls.



08900116

Winterfronts


Winterfronts can be used on a vehicle equipped with charge-air cooling, but they **must** be designed to partially cover the frontal area of the cooling system **only**. An area of 784 sq cm [120 sq in], or approximately 28 x 28 cm [11 x 11 in], **must** be left open to allow airflow for the charge-air cooler to function correctly.



Shutters




A charge-air cooled engine with shutters also requires an intake manifold air temperature switch to open the shutters to prevent excessive intake manifold temperatures. This reduces possibility of engine damage from high intake manifold temperatures as a result of blocked airflow across the charge-air cooler.



Engine Shutdown

General Information

- Allow the engine to idle 3 to 5 minutes after a full-load operation before shutting it off. This allows the engine to cool gradually and uniformly.
- Turn the ignition keyswitch to the OFF position.





Electronic Controlled Fuel System

General Information

The QSL9 engine control system is electronically controlled and also provides many operator and vehicle or equipment features.


The base functions of the control system include fueling and timing control, limiting the engine speed operating range between the low- and high-idle set points, and reducing exhaust emissions while optimizing engine performance.






The control system uses inputs from the operator and engine sensors to determine the fueling and timing required to operate at the desired engine speed.

The electronic control module (ECM) is the control center of the system. It processes all of the inputs and sends commands to the fuel system, vehicle, and engine control devices.



The electronic control module (ECM) performs diagnostic tests on most of its circuits and will activate a fault code if a problem is detected in one of these circuits. Along with the fault code identifying the problem, a snapshot of the engine operating parameters at the time of the fault activation is stored in memory.

Most fault codes will activate a diagnostic lamp to signal the driver.



The ECM communicates with service tools and other vehicle controllers such as the transmission, antilock brake system (ABS), and antislip reduction (ASR) through an SAE J1939 datalink.

Some vehicles and equipment will have J1939 networks that link many of the "smart" controllers together. Vehicle control devices can temporarily command engine speed or torque to perform one of its functions such as transmission shifting or antilock braking.

The control system utilizes a number of sensors to provide data on engine operating parameters. These sensors include the following:

1. Coolant temperature sensor
2. Oil pressure sensor
3. Cummins accumulator pump system (CAPS) fuel pressure sensor
4. Intake air temperature sensor
5. Intake manifold pressure sensor
6. Engine speed and position sensors
7. CAPS fuel temperature sensor
8. Injection control valve (ICV)
9. Pumping control valves (PCVs).

The following inputs are provided by original equipment manufacturer (OEM)-selected devices:

1. Accelerator pedal position sensor
2. Idle validation switch
3. Coolant level sensor
4. Vehicle speed sensor (VSS)
5. Feature control switches such as cruise control, power take-off (PTO), and fan clutch control
6. Accelerator interlock (**not shown**)
7. OEM pressure sensor (**not shown**)
8. Intermediate speed control (**not shown**).

NOTE: These inputs are application-dependent. Some applications will **not** use all of these inputs.




Engine Protection System

The QSL9 engine is equipped with an engine protection system. The system monitors critical engine temperatures and pressures, and it will log diagnostic faults if an over or under normal operation condition occurs. If an out-of-range condition exists, and an engine derate action is initiated, the operator will be alerted by an in-cab **WARNING** lamp. The **WARNING** lamp will blink or flash if out-of-range conditions worsen.

The engine protection system monitors the following data:


- Coolant temperature
- Coolant level (optional)
- Oil pressure
- Intake manifold temperature
- Engine overspeed
- Fuel temperature
- OEM switch (optional).

NOTE: Engine power and speed will gradually reduce depending on the severity of the observed condition. The engine protection system will **not** shut down the engine unless the engine protection shutdown feature has been enabled.



Basic Features


The electronic control module (ECM) for the QSL9 engine provides some basic electronic features that are calibration-dependent. The following section describes the function of each feature. Whether a feature is available in a given application is calibration-dependent.



19900864

Intake Air Heater


This feature controls the heating elements that are located in the engine's intake airstream. These elements heat the intake air when starting the engine in cold ambient conditions. Startability and white smoke control are enhanced by the use of an intake air heater. A WAIT TO START lamp is located on the operator controls to indicate when to crank the engine.



19901052

The ECM checks the intake manifold temperature to determine how long to energize the air heater before extinguishing the WAIT TO START lamp. (This is for the preheat phase.)

Once the engine is started, the heater will be energized again for a time period determined by intake air temperature and fuel temperature. (This is for the post-heat phase.) To minimize cranking time in cold weather, the engine can **not** be started until the WAIT TO START lamp is extinguished.




19901052



Water-in-Fuel Sensor

This sensor is located in the canister of the fuel filter housing. Once the storage space in the bottom of the filter housing fills with a certain amount of water, the sensor will signal the ECM. A WATER IN FUEL lamp will illuminate at the operator controls indicating that the water needs to be drained from the fuel filter assembly.


NOTE: Refer to Section 3 for instructions to drain the fuel filter water separator.



19901053

Electric Lift Pump


The ECM controls the electric lift pump (located in between the fuel tank and the injection pump). When the keyswitch is turned on, the lift pump will be energized for 30 seconds to make sure that the low-pressure fuel lines are fully primed. The electric lift pump does **not** start again unless the keyswitch is cycled off for 30 seconds allowing the ECM to power down and cycle back on.



Engine Warm-Up Protection

This feature inhibits the throttle, datalink control, and intermediate speed control switches to keep the engine at low idle for a brief time after the engine starts or until adequate oil pressure is obtained. This allows oil to reach all the critical engine components before the engine speed is increased above low idle.

NOTE: The maintenance lamp is illuminated while this feature is in operation.





Engine Protection Shutdown

This feature automatically shuts off the engine when the temperature, pressure, or coolant level sensors indicate that the engine is operating over or under normal operating conditions.

The red STOP lamp in the cab will flash for 30 seconds prior to shutdown to alert the driver.


NOTE: The length of time that the red STOP lamp flashes can be adjusted using INSITE™.





Engine Protection Shutdown Override

This feature, when enabled, allows the operator to override a pending engine shutdown. Prior to engine shut down, the red STOP lamp will flash for 30 seconds to notify the operator that the engine is about to shutdown. The operator can override the engine shutdown through the use of an OEM switch (such as the clutch switch). If the vehicle is **not** equipped with a clutch switch, then the OEM will provide a dash-mounted switch marked as the engine protection shutdown override switch. When the operator triggers this switch, while the red STOP lamp is flashing, a timer within the ECM will reset and allow the engine to run an additional 30 seconds before engine shutdown occurs. Each time the operator triggers the switch, the time within the ECM is reset, allowing the engine to run for an additional 30 seconds.




Vehicle Speed Sensor (VSS) Type

The sensor communicates the type of vehicle speed sensor (VSS) being used to the ECM.

The sensor can be one of the following:

- None - No vehicle speed sensor (VSS)
- Magnetic - Most typical, usually located on transmission
- Other - OEM device, also known as mechanical
- J1939 datalink - Speed sensor connected to J1939 datalink
- Tachograph - Primarily used for European applications.




Maximum Engine Speed without Vehicle Speed Sensor (VSS)

This sets the maximum engine speed allowed when no vehicle speed sensor is detected.

- Maximum engine speed without vehicle speed sensor (VSS) (5)
- Maximum engine speed with vehicle speed sensor (VSS) (6).


Tire Revolutions per Mile

This is used to tell the electronic control module (ECM) how many times the tire makes a complete revolution in 1 mile.




Rear Axle Ratio

This feature tells the ECM the gear ratio of the rear axle.



Number of Transmission Tailshaft Gear Teeth


This feature tells the ECM the number of gear teeth on the transmission tailshaft.




Vehicle Speed Sensor (VSS) Antitampering (Fault Code 242)

This feature gives the customer the option of disabling Fault Code 242.

NOTE: Fault Code 242 is logged when an invalid or inappropriate vehicle speed signal is detected by the ECM indicating an intermittent connection or signal tampering. This fault code is **not** proof that vehicle speed sensor (VSS) tampering has occurred.






Programmable Features

The electronic control system provides many features that are integrated into the vehicle operation. Some of these features can be adjusted, enabled, or disabled with a service tool, but some are set at the factory and can **not** be changed.


The following section describes the functions of each feature. Whether a feature is available in a given application is OEM-dependent.



Fan Clutch Enable


The ECM can control the cooling fan based on inputs from the coolant temperature sensor and the intake manifold temperature sensor.

Some applications also provide inputs to the ECM for auxiliary device cooling (such as air conditioner pressure and power steering temperature). An application can also include a manual switch for fan control.



Fan On with Exhaust Brake

This feature enables an electric fan when the exhaust brake is engaged. This increases the total braking power by increasing the parasitic load on the engine.




Programmable Fan Logic

Select either 0 VDC = ON or 12 VDC = ON to match the fan clutch logic used in the application. A relay can be used for fans that draw more than 6 amps.


Minimum Fan On Time with Air Conditioner Pressure Switch

This feature controls the minimum amount of time that the fan will stay on when activated by the air conditioner pressure switch. This reduces excessive fan cycling.



Air Conditioner Pressure Switch Input

This allows the air conditioner pressure switch input to be disabled if that input into the ECM is **not** being used. Enable this feature if the air conditioner pressure switch input into the ECM is used to control the fan.



Maintenance Monitor Data

Using the INSITE™ service tool, the following maintenance data can be viewed or printed from the ECM:

- Percent of current interval consumed (by time or fuel burned)
- Time since last reset
- Fuel burned since last reset
- Current maintenance monitor mode.


Maintenance Monitor Data	
Percent of Current Maintenance Interval	XXX.X%
Time Since Last MM Reset	XXXXX Hrs.
Fuel Burned Since Last MM Reset	XXXX Gal.
Current MM Mode	XXXX

19d00575

Alerting the Operator

The maintenance monitor, if enabled, will alert the operator of the need to change oil by flashing the FLUID lamp for approximately 12 seconds after keyswitch is turned on. The flashing sequence will be three quick flashes followed by a pause. This flash sequence will go through five cycles in the 12-second period. This sequence will occur every time the keyswitch is turned on until the maintenance monitor has been reset.

NOTE: The diagnostic switch **must** be in the OFF position for the flashing sequence to occur.



Maintenance Monitor Reset Log 1

	Maximum Threshold	Adjusted Threshold	Interval Reset@
Fuel:	XXXX	XXXX	XXXX
Time:	XXXX	XXXX	XXXX

19d00576

Maintenance Monitor Reset Log

The maximum threshold is entered by the user either directly using the time mode, or by entering the interval factor in the automatic mode.

The adjusted threshold is the new threshold set automatically by the maintenance monitor when the automatic mode is selected, and it automatically reduces the maintenance intervals.

The “interval reset at” is the interval time and fuel recorded by the ECM at the time the maintenance monitor was reset.

Maintenance Monitor Reset Log 2

	Cumulative Reset @	Possible Error
Fuel:	XXXX	XXXX
Time:	XXXX	XXXX

19d00577

The “cumulative reset at” is the total time and fuel recorded by the ECM at the time the maintenance monitor was reset.

The possible error will contain an “X” next to a row of data that can be inaccurate due to a system fault. The “X” will be triggered when a vehicle speed sensor fault or power-down fault occurs. These faults can cause data to either **not** accumulate or accumulate inaccurately.

Maintenance Monitor Reset

The maintenance monitor reset can be accomplished by clicking the reset button on the maintenance monitor screen using the INSITE™ service tool, or using one of the following procedures:


- 1) Procedure for applications **with** a throttle pedal.
 - a. Turn the keyswitch to the ON position (but do **not** start the engine) and turn the diagnostic switch to the ON position.
 - b. Fully depress the throttle pedal (100 percent) for at least 3 seconds and then release it.
 - c. Fully depress the throttle pedal (100 percent), twice, for less than 3 seconds each time.
 - d. Fully depress the throttle pedal (100 percent) for at least 3 seconds and then release it.
- 2) Procedure for applications **without** a throttle pedal.
 - a. Turn the keyswitch to the ON position (but do **not** start the engine).
 - b. Turn the diagnostic switch to the ON position for at least 3 seconds and then turn it to the OFF position.
 - c. Turn the diagnostic switch to the ON position (for less than 3 seconds) and then to the OFF position, twice, with less than 3 seconds between each switching.
 - d. Turn the diagnostic switch to the ON position for at least 3 seconds and then turn it to the OFF position.


NOTE: Procedure **must** be completed within 20 seconds after initiating steps 1)a through d or steps 2)a through d or the data will **not** reset.

NOTE: The WARNING lamp will flash three times to indicate that the reset has been completed.

Trip Information System

The trip information system records fuel consumption and time information for the engine during normal operation, and in certain operating modes such as intermediate speed control and idle. Either data can be displayed using the INSITE™ service tool. Some data can **not** be reset and reflect the performance of the engine over its lifetime. Other data, as well as trip data, can be reset using the INSITE™ service tool.






Duty Cycle Monitor

With this feature the ECM tracks engine load and speed. These data are stored in the ECM, and the INSITE™ service tool is used to display the data. The INSITE™ service tool display shows a duty cycle “map” that shows the whole engine’s operating range in terms of speed and load. This “map” is divided into fifty regions. The percent of the engine operating time spent in each region is shown on the display.

The ECM contains duty cycle data for the whole life of the engine and for two 500-hour operating periods. The two 500-hour maps can be reset with the INSITE™ service tool.




Road Speed Governor

The road speed governor limits the maximum road speed of the vehicle in top gear.

The maximum vehicle speed in top gear is the maximum road speed for the vehicle. This speed **must** be greater than or equal to the maximum cruise speed if the cruise control feature is enabled.

The maximum road speed in top gear can be adjusted by using the INSITE™ service tool.

NOTE: The auxiliary governor needs to be disabled to utilize the road speed governor.



Cruise Control




Do not use cruise control when the road is slippery, in heavy traffic, or when the weather is inclement. Loss of vehicle control can result.

The cruise control feature gives the driver the capability of a foot-off accelerator cruise operation. It is similar to an automobile’s cruise control.

The cruise control feature can be enabled or disabled using the INSITE™ service tool.

NOTE: Both cruise control and intermediate speed control can **not** be active at the same time.



Maximum Cruise Control Speed

This speed is the maximum allowable cruise set speed.


The maximum cruise control speed can be adjusted using the INSITE™ service tool.

NOTE: The maximum cruise control speed can **not** exceed the maximum vehicle speed in top gear setting.


Intermediate Speed Control

The intermediate speed control feature controls the engine at a constant rpm. Up to three intermediate speed control set speeds (1, 2, and 3) can be selected depending on original equipment manufacturer (OEM) availability (the axis 4 equals engine speed and 5 equals engine torque).


NOTE: An additional 5 set speeds can be obtained through use of the variable intermediate speed input signal.




The intermediate speed control feature provides the ability to select an intermediate speed control set speed by an original equipment manufacturer (OEM)-provided switch (1 is the OFF position and 2 is the ON position), depending on original equipment manufacturer availability.




This feature will override the throttle and control the engine speed to the intermediate speed control speed setting. This feature allows throttle control above the set speed or below the set speed, according to the calibration setup.




The intermediate speed control feature provides a single droop (6) for up to three intermediate speeds (1, 2, and 3). An additional 5 set speeds can be obtained through use of the variable intermediate speed input signal. This droop is independent of all other selectable droops and is enforced during intermediate speed control operation **only** (the axis 4 equals engine speed and 5 equals engine torque).






The intermediate speed control set speed can be adjusted by the intermediate speed control increment (1) or decrement (2) switch. Setting speed changes using this switch will be saved to the electronic control module (ECM) when the keyswitch is turned to the OFF position if the save increment or decrement option is enabled.




The intermediate speed control feature can be enabled or disabled using the INSITE™ service tool if this feature is available in the calibration. The intermediate speed control set speeds (1, 2, and 3) can be adjusted using the INSITE™ service tool along with the intermediate speed control droop.

NOTE: This option is **not** allowed by some OEM's.



Hybrid Governor

The hybrid governor can be enabled or disabled with the INSITE™ service tool if the feature is available in the calibration. The hybrid governor achieves partial-throttle operation with the same power and torque rise characteristics of the full-throttle operation. It will allow the application to be operated in a more fuel efficient manner and with a greater capability of driving at partial throttle.




Auxiliary Speed Governor


The auxiliary speed governor is an application-specific feature that allows the engine to be governed by either an auxiliary speed or pressure signal. The feature uses a manual switch input to turn the governor operation on and off.

NOTE: The switch **must** go from OFF to ON position while the engine is running to activate this feature. It can **not** be on all the time.

Depending on original equipment manufacturer (OEM) availability the alternate droop feature provides the ability to select up to two additional alternate droop settings (1, 2, or 3) by an original equipment manufacturer (OEM) provided switch.




Each alternate droop setting provides the ability to select the high speed governor break point speed and droop percent. Droop percent at minimum and maximum throttle for the all speed governor is also adjustable. The break point speed determines the position on the engine torque curve where high speed governor will start to limit engine torque output. Selection of the alternate droop feature is accomplished by using the INSITE™ service tool if the alternate droop feature is available in the calibration.





Switched Torque

The switched torque feature allows the operator to switch between the 100-percent throttle torque curve (1) and up to two derated torque curves (2 and 3). (The axis 4 is engine speed and 5 is engine torque.)




This feature improves operating efficiency in loaded (1) versus unloaded (2), as well as protecting the transmission and drivetrain.






Depending on original equipment manufacturer (OEM) availability the switched torque feature provides the ability to select two additional derated torque curves with an original equipment manufacturer (OEM)-provided switch.




This feature can be enabled or disabled by using the INSITE™ service tool if the alternate torque feature is available in the calibration.



Boost Power

The boost power feature provides the operator with enhanced torque and power for a fraction of the operating period. If the feature is enabled, boost power can be engaged by a cab-mounted switch or automatically if the automatic boost power feature is enabled. The additional power is limited by a calibrated time period, thresholds for intake manifold temperature, coolant temperature, and engine speed.

NOTE: Boost power is **not** available continuously.



The INSITE™ service tool can enable or disable the boost power feature if the feature is available in the calibration. The service tool can also monitor the cab-mounted boost power switch.

If the boost power feature is enabled, the boost power can be engaged by using a cab-mounted switch. When the automatic boost power feature is enabled, it automatically switches the engine to boost power curve based on the engine operating conditions, and no manual switch is needed.


The automatic boost power feature can be enabled or disabled using the INSITE™ service tool.

Remote Throttle

The remote throttle feature allows the operator to control the engine from a position other than the driver's seat. This feature is selected by the operator through an original equipment manufacturer (OEM) cab-mounted switch.

There are three modes available for the remote throttle feature.

The remote throttle feature, if allowed, can be enabled or disabled using the INSITE™ service tool if the feature is available in the calibration.




Remote Throttle Mode One (default)

This mode will override the primary throttle (1) control and control the engine speed with the remote throttle setting.

NOTE: Remote throttle mode one does **not** employ idle validation and is intended for stationary applications, **only**.


NOTE: The interlock feature (if enabled) switches the throttle to be equal or less than the throttle in control before the control is switched.



Remote Throttle Mode Two (select minimum)

Remote throttle mode two is a select minimum throttle using two different throttles. One example is equipment that uses a hand throttle as your primary throttle and a foot throttle as a decelerating throttle.


NOTE: Remote throttle mode two does **not** employ idle validation.




Remote Throttle Mode Three (select maximum)

Remote throttle mode three is a select maximum throttle using two different throttles. One example is, equipment using a hand throttle as your primary throttle and a foot throttle as an accelerating throttle.

NOTE: Remote throttle mode three does **not** employ idle validation.






Frequency Throttle

The frequency throttle feature converts a frequency input into a requested throttle percentage. The frequency throttle feature is applicable in industrial and marine applications in which a position (electronic or log signal) is **not** appropriate. The frequency throttle feature supports idle validation.


The frequency throttle feature can be enabled or disabled using the INSITE™ service tool if the feature is available in the calibration.



Multiple Unit Synchronization

The multiple unit synchronization feature allows two or more engines to be controlled by a single throttle signal.

The multiple unit synchronization feature can be enabled or disabled using the INSITE™ service tool if the feature is available in the calibration.




All soft-coupled marine configuration engines are connected to a J1939 datalink.


Pulse-Width Modulate Output

This feature allows the electronic control module to output a pulse-width modulation signal that is proportional to either engine speed, engine load, engine torque output, or throttle input.

The pulse-width modulate output signal is intended to be used to control an engine or transmission that relies on an analog signal input. This signal can also be configured as an on/off signal where the signal is either 12 VDC (v battery) or open, depending on the load.




The pulse-width modulate output feature can be adjusted using the INSITE™ service tool if the feature is adjustable in the calibration.



Low-Idle Speed


This parameter is the engine speed at which the engine will idle. This speed can be adjusted by a cab switch if the switch is installed and the low-idle adjustment feature is enabled.


Low-idle speed feature can be adjusted using the INSITE™ service tool if the feature is adjustable in the calibration.



Low-Idle Adjustment

This feature allows the idle speed range to be increased or decreased in 25-rpm standard increments with the in-cab increment or decrement switch. Depending on the calibration, the rpm increment could not be 25-rpm. There are limits on how high or low the low-idle speed can be adjusted. The allowable adjustment range for a QSL9 engine is 600 to 1200 rpm.






Alternate Low-Idle Speed Control

This feature allows the operator to switch between the low idle speed setting (3) and an alternate low-idle speed setting (4) (the axis 1 is engine speed and 2 is engine torque).

NOTE: On the QSL9 engine during cold start-ups, and with engine temperatures less than 21°C [70°F], pilot injection has priority over alternate low-idle speed until the engine is properly warmed up.



Depending on original equipment manufacturer (OEM) availability the alternate low-idle speed control feature provides the ability to select an alternate idle speed by an original equipment manufacturer (OEM)-provided switch (1 is in the OFF position, and 2 is in the ON position).

NOTE: The alternate low idle speed can **not** be adjusted by the idle increment or decrement switch.

Idle Shutdown

This feature automatically shuts off an engine after a period of engine idling when there is no activity from the driver such as engine speed changing or having the engine under load.

The idle shutdown system will **not** be active at coolant temperatures below 37.8°C [100°F].

After an engine has been automatically shut off, the keyswitch **must** be turned off for 15 to 20 seconds before attempting a restart.

The idle shutdown feature can be enabled or disabled using the INSITE™ service tool.


NOTE: This feature will shut off the engine **only**. It will **not** remove power from other accessories powered by the keyswitch. These can drain the battery.

Idle Shutdown Time

This is a period of engine idling time when there is no activity from the driver before the engine automatically shuts off.

The idle shutdown time, if allowed, can be changed using the INSITE™ service tool.


NOTE: This parameter will **not** appear if the idle shutdown feature is turned off.



Idle Shutdown Override

This feature allows the driver to override the idle shutdown by changing the engine speed (2) or putting the engine under load (1).


The idle shutdown warning period lasts for a calibrated period of time prior to engine shutdown. The yellow WARNING lamp on the dash will flash during the idle shutdown warning period.



Manual Fan Switch Enable

The ECM can control the cooling fan based on inputs from the coolant temperature sensor and the intake manifold temperature sensor.


Some applications will also provide inputs to the electronic control module (ECM) for auxiliary device cooling, such as air conditioner pressure and power steering temperature. Your application also can include a manual switch for fan control.




Minimum Fan-on Time with Air Conditioner Pressure Switch

This feature controls the minimum amount of time that the fan will stay on when it is activated by the air conditioner pressure switch to reduce excessive fan cycling.

The minimum fan-on time with air conditioner pressure switch can be adjusted by using the INSITE™ service tool.






Engine Brakes

Some engines are equipped with engine brakes.

Engine brakes are devices that use the energy of engine compression to provide vehicle retardation. Engine brakes provide the maximum retarding power at rated speed; therefore, gear selection is important.


The engine brakes convert the engine to an energy-absorbing device to reduce vehicle speed.

This is accomplished by a hydraulic circuit that opens an exhaust valve near the end of the compression stroke.




⚠ CAUTION ⚠

Engine brakes can be operated continuously at engine speeds below 2300 rpm. Engine brakes can be operated intermittently at engine speeds between 2300 and 2600 rpm. Do not exceed 2600 rpm under any circumstances because engine damage can occur. The engine brakes are designed to assist the vehicle's service brakes to slow down the vehicle. Do not use the engine brakes as the primary means to stop the vehicle. If other engine brakes are used, refer to the component manufacturer's manual.



Engine brake controls with the fuel system consist of the following:

- A two-position selector switch (optional)
- An on/off switch
- A clutch switch
- A throttle sensor.




Several operating conditions **must** be true to activate the compression brake:

1. The exhaust brake switch **must** be in the ON position.
2. The operator's foot **must** be off of the accelerator pedal (pedal at low-idle position).
3. The engine speed **must** be above 1000 rpm.

The optional two-position selector switch is located near the on/off switch in the cab and allows the selection of the retarding power of one or two brakes.


LOW activates the engine brakes on three cylinders, and HI activates the engine brakes on six cylinders.



⚠ CAUTION ⚠


Do not use the engine brakes while bobtailing or pulling an empty trailer. With the engine brakes in operation, wheel lockup can occur more quickly when the service brakes are applied, especially on vehicles with single-drive axles.

Make sure that the engine brakes are switched to the OFF position when bobtailing or pulling an empty trailer.




NOTE: The engine brakes are designed to assist the vehicle's service brakes when slowing the vehicle to a stop.


Remember, service brakes will be required to bring the vehicle to a stop.




⚠ CAUTION ⚠

Do not use the engine brakes to aid in clutchless gear shifting. This can cause the engine to stall or lead to engine damage.






The ECM will disable the engine brakes when engine speed is below 1000 rpm or when certain electronic fault codes are active.



CAUTION

Do not operate the engine if the engine brakes will not deactivate. To do so can cause severe engine damage.

If the engine brakes will **not** shut off, shut off the engine immediately, and contact a Cummins Authorized Repair Facility.



Engine Warm-up Protection

This feature inhibits the throttle, intermediate control switch, and datalink control inputs to keep the engine at low idle. This allows oil to reach all critical engine components before engine speed is increased above low idle.

To limit the engine's speed at start-up, the following inputs are limited:


1. Throttle input
2. Intermediate speed control switches
3. Datalink control inputs.

NOTE: The MAINTENANCE lamp is turned on while this feature is operating. Once adequate oil pressure is supplied to the engine, the lamp is turned off.

Hot Shutdown Monitor/Hot Shutdown Load Percent

This feature is **always** enabled. The electronic control module (ECM) will log an inactive fault code when the engine is turned off while still "hot" by the operator or by the engine protection feature.

An engine is considered "hot" when the hot shutdown load percent of the engine is above the threshold set by the INSITE™ service tool. The hot shutdown load percent is based on the duty cycle load factor that is determined from the engine's fueling levels.



Maintenance Monitor

⚠ CAUTION ⚠

The maintenance monitor is designed to alert the operator of the need for a routine maintenance stop. Maintenance records must still be maintained for historical purposes.

⚠ CAUTION ⚠



The maintenance monitor uses data received from the electronic control module (ECM) to determine the amount of fuel burned. Whenever a battery voltage fault has occurred, the maintenance monitor data can be inaccurate.

The maintenance monitor is an optional feature that will alert the operator when it is time to change oil and perform any other simultaneous maintenance tasks. The maintenance monitor continuously monitors the time the engine has been operating and the amount of fuel burned, to determine when it is time to change oil.

NOTE: The operator **must** still be alert for any indications that the engine needs other service.

The maintenance monitor has two modes of operation:

- Automatic mode
- Manual mode




Maintenance Monitor Automatic Mode


⚠ CAUTION ⚠

The use of synthetic-base oil does not justify extended oil change intervals. Extended oil change intervals will decrease engine life because of factors such as corrosion, deposits, and wear.

The automatic mode alerts the operator when it is time to change oil based on Cummins recommended interval. It determines the maintenance interval based on coolant temperature and load factor.

When the automatic mode is selected, the severe oil drain interval duty cycle is the default.






Maintenance Monitor Interval Factor

The interval factor is used **only** in the maintenance monitor automatic mode. It is used to adjust the maintenance interval for severe, normal, or light-duty applications.

The original factory programmed value is SEVERE.




Maintenance Monitor Manual Mode



When selecting the correct oil-change interval for your application, Cummins Engine Company, Inc. does not recommend exceeding published intervals and is not responsible for damage sustained from overextended drain intervals.

Refer to Lubricating Oil Drain Intervals in Section V.



Maintenance Monitor Interval Alert Percentage

This feature allows the user to enter the percentage of the current interval at which the light comes on, indicating the need for an oil change. The parameter allows the user to obtain an early warning of the need for a maintenance stop.

For example, if the time mode is set to 100 hours, and the interval alert percentage is set to 90 percent, the MAINTENANCE lamp will illuminate at 90 hours (90 percent of 100 hours).

Engine Time Offset

This parameter is part of the trip information system. The value entered here will be added to total ECM time to get total engine time. This parameter allows the time on the engine to be entered when an ECM is replaced.

Engine time offset can be adjusted using the INSITE™ service tool.

Engine Distance Offset


This feature is part of the Trip Information System. The value entered here will be added to the total ECM distance to equal the total engine distance. This allows the distance on the engine to be entered when the ECM is replaced.


NOTE: This feature can be used when there is **not** a vehicle speed sensor installed.

Real-Time Clock

The real-time clock provides time and date for stamping of operational events. The real time clock will maintain time value in units of year, month, day, hour (24-hour base), minute, and second. Loss of clock accuracy will be indicated with a diagnostic fault code. This feature can be set manually or automatically (to the PC time and date) through the INSITE™ service tool.

	Standard Setting	Customer Selection
Auto Set (set to PC time and date)	No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Manual Date	<input type="text"/>	<input type="text"/>
Date	<input type="text"/>	Adjust Date
Time	<input type="text"/>	Adjust Time






Reduced accuracy will be indicated with the diagnostic Fault Code 319. Upon loss of clock accuracy, the real-time clock will be "initialized" with the last known real time.

The loss of the real-time clock can occur due to a hardware failure (chip fails) or a loss of power. There is no battery backup for the clock. Therefore, if the battery is removed from the system for 5 seconds, the real-time clock will be lost.

To reinitialize the real-time clock, use the INSITE™ service tool, the menu item "Adjustments - Feature and Parameters." At this point a screen will pop up in which you can manually enter a new time and date, or you can select "Real-Time Clock Autoset" and the time and date will be set to the PC's time and date. After reinitializing the real time clock, INSITE™ service tool will set the Fault Code 319 inactive.

NOTE: Once the real-time clock has been enabled, you can **not** disable the feature.




Throttle-Activated Diagnostic Switch

Throttle-activated diagnostic switch is intended to eliminate the need for a dash-mounted diagnostic switch, which is used to activate the diagnostic mode to display active fault codes in a sequence of flashing lamps. The throttle-activated diagnostic switch feature eliminates the need for a dash-mounted diagnostic switch by providing a simple sequence of throttle movements that activate the diagnostic mode.

NOTE: The feature will work with all throttle types.

NOTE: In order to reset the maintenance monitor data, a diagnostic switch **must** be installed.



When the engine is **not** running, a sequence of three throttle cycles after the keyswitch is turned on will activate the diagnostic mode. The increment or decrement switch can be used to navigate to the next or previous fault code. In the case that these switches are **not** available, a single throttle cycle will also increment to the next fault code.

Diagnostic Fault Codes

The QSL9 control system can show and record operation anomalies that present themselves as fault codes. These codes will make troubleshooting easier. The fault codes are recorded in the ECM. They can be read using the fault lamps on the dash or with the INSITE™ service tool.

NOTE: Not all QSL9 control system anomalies are shown as fault codes.

There are three kinds of system codes:





- Engine electronic control system fault codes
- Engine protection system fault codes
- Engine maintenance indicator codes.


All fault codes recorded will be either active (fault code is currently active on the engine) or inactive (fault code was active at some time but at the moment is **not** active).

Most, but **not** all, of the electronic fault codes will light a lamp when they are active. There are three possible lamps that can be illuminated when a fault code is active:


- The WARNING or CHECK ENGINE lamp is yellow and indicates the need to repair the fault at the first available opportunity.
- The STOP or STOP ENGINE lamp is red and indicates the need to stop the engine as soon as it can be safely done. It is recommended that the engine remains shut down until the fault can be repaired.
- The MAINTENANCE lamp will illuminate when an engine maintenance function needs to be performed.

Some vehicles will also have a WAIT TO START lamp and a WATER IN FUEL lamp. The WAIT TO START lamp is illuminated during the preheat time that takes place at key-on during cold-weather starting. To minimize cranking time during cold-weather starting, the engine can **not** be cranked until the WAIT TO START lamp has been extinguished.






The WATER IN FUEL lamp indicates that the engine's fuel-water separator needs to be drained. This task **must** be performed as soon as possible whenever this lamp is illuminated. Some vehicle OEMs will combine the functions of the MAINTENANCE and WATER IN FUEL lamps. In these cases, the MAINTENANCE lamp indicates a WATER IN FUEL warning, in addition to other maintenance indicators.




To check for active engine electronic system fault codes and maintenance indicator codes, turn the keyswitch to the OFF position, and move the diagnostic switch to the ON position, or connect the shorting plug into the diagnostic connector.



Turn the vehicle keyswitch to the ON position.

If no active fault codes are recorded, both the WARNING and STOP lamps will illuminate and stay on.

If active fault codes are recorded, both the WARNING and STOP lamps will illuminate momentarily then begin to flash the codes of the recorded faults.




The fault code will flash in the following sequence:


1. A yellow WARNING lamp will flash.
2. There is a short 1- or 2-second pause.
3. The fault code will flash on the red STOP lamp.
4. There is a short 1- or 2-second pause between each number.

When the number has finished flashing in red, a yellow WARNING lamp will appear again. The fault code sequence will repeat.

Each fault code will flash two times before advancing to the next code. To skip to the next fault code, move the IDLE SPEED ADJUST switch (if equipped) momentarily to the (+) position. Go back to the previous fault code by momentarily moving the IDLE SPEED ADJUST switch (if equipped) to the (-) position. If **only** one active fault code is recorded, the QSL9 control system will continuously display the same fault code with either the (+) or (-) selected.




When **not** using the diagnostic system, turn off the diagnostic switch, or remove the shorting plug. If the diagnostic switch is left on or the shorting plug left in, the electronic control module (ECM) will **not** log some fault codes.



Fault Code Snapshot Data

This additional fault code information can be obtained by using the INSITE™ service tool. The snapshot data records the value or state of the control system sensors and switches at the time a fault code occurred. Either set of data is stored for the first occurrence of the fault, since it was last cleared, and for the most recent occurrence. This data can be very valuable when trying to re-create or determine engine operating conditions at the time of a fault.



Trip Information


The Trip Information System records fuel consumption, distance, and time information for the engine during normal operation and in certain operating modes such as PTO and idle. This data can be displayed using the INSITE™ service tool. Some data can **not** be reset and reflects the performance of the engine over its lifetime. Other data, such as trip data, can be reset using the INSITE™ service tool.

Engine Time Offset

This feature is part of the Trip Information System. The value entered here will be added to the total ECM time to equal the total engine time. This allows the time on the engine to be entered when the ECM is replaced.

Engine Distance Offset


This feature is part of the Trip Information System. The value entered here will be added to the total ECM distance to equal the total engine distance. This allows the distance on the engine to be entered when the ECM is replaced.



Duty Cycle Monitor

With this feature, the ECM tracks engine load and speed. This data is stored in the ECM until the INSITE™ service tool is used to display it. The INSITE™ service tool displays a duty cycle “map” that shows the whole engine operating range in terms of speed and load. This “map” is divided into 50 regions. The percent of engine operating time spent in each region is shown on the display.

The ECM contains duty cycle data for the whole life of the engine and for two 500-hour operating periods. The two 500-hour maps can be reset with the INSITE™ service tool.



Driving Techniques

General Information

The QSL9 engine produces maximum power at an rpm less than governed engine speed. Placement of maximum power has been changed on QSL9 engines to encourage operation in the most fuel efficient engine speed range.

To obtain optimum engine performance on a grade, allow the engine speed to load down to near torque peak before shifting. This technique will result in an engine operating speed in the maximum power zone after the shift is completed.

Electromagnetic Interference (EMI)

General Information

Some diesel engine applications utilize accessories (such as CB radios and mobile transmitters) that generate and use radio frequency energy that, if **not** installed and used properly, can cause electromagnetic interference (EMI) conditions to exist between the accessory and the Cummins QSL9 electronically controlled fuel system. Cummins is **not** liable for any performance problems with either the QSL9 fuel system or the accessory due to EMI. EMI is **not** considered by Cummins to be an engine failure and, therefore, is **not** warrantable.

System EMI Susceptibility

The Cummins product has been designed and tested for minimum sensitivity to incoming electromagnetic energy. Testing has shown that there is no engine performance degradation at relatively high energy levels; however, if very high energy levels are encountered, then some noncritical diagnostic fault code logging can occur. The QSL9 fuel system EMI susceptibility level will protect the engine from most, if **not** all, electromagnetic energy-emitting devices that meet the FCC legal requirements.

System EMI Radiation Levels

Cummins products have also been designed and tested to emit minimum electromagnetic energy. Testing has shown that the QSL9 fuel system, when properly installed in a vehicle, meets or exceeds by a wide margin Part 15 of the FCC Rules and SAE J1551 specifications. Other accessories can be designed with proper filtering to reject electromagnetic noise emission from their system. Experience has shown that the QSL9 control system on a vehicle will **not** interfere with on-board communication equipment for urban and suburban background electromagnetic noise levels; however, the system, if used with accessories which are **not** installed properly or do **not** utilize adequate filtering designs, can interfere with on-board communications equipment in rural applications where background radio frequency noise levels are very low.

If an interference condition is observed, follow the suggestions below to reduce the amount of interference:

1. Locate the receiving antenna as far away from the engine and as high as possible.
2. Locate the receiving antenna as far away as possible from all metal obstructions such as exhaust stacks.
3. Consult a representative of the accessory supplier to
 - Accurately calibrate the device for proper frequency, power output, and sensitivity (both base- and remote-site devices **must** be properly calibrated).
 - Obtain antenna reflective energy data measurements to determine the optimum antenna location.
 - Obtain optimum antenna-type and mounting arrangement for an application.
 - Make sure the accessory equipment model is built for maximum filtering to reject incoming electromagnetic noise.

Welding on a Vehicle with Electronic Components is Not Recommended



Disconnect both the positive (+) and ground, or negative, (-) battery cables from the battery before welding on the vehicle. Attach the welder ground cable no more than 0.61 m [2 ft] from the part being welded. Do not connect the ground cable of the welder to any electronic component or component-mounting location. Welding on the engine or engine-mounted components is not recommended.

NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There is no text or other markings on the paper.

Section 2 - Maintenance Guidelines
Section Contents

	Page
Maintenance Guidelines - General Information	2-1
Maintenance Record Form	2-5
Maintenance Schedule	2-2
Oil Drain Intervals	2-3
Page References for Maintenance Instructions	2-4
Tool Requirements	2-1

THIS PAGE LEFT INTENTIONALLY BLANK

Maintenance Guidelines - General Information

Cummins Engine Company, Inc. recommends that the engine be maintained according to the Maintenance Schedule in this section.

If the engine is operating in ambient temperatures consistently below -18°C [0°F] or above 38°C [100°F], perform maintenance at shorter intervals. Shorter maintenance intervals are also required if the engine is operated in a dusty environment or if frequent stops are made. See a Cummins Authorized Repair Facility for recommended intervals.

If the engine is equipped with a component or an accessory **not** manufactured by Cummins Engine Company, Inc., refer to the component manufacturer's maintenance recommendations. A listing of suppliers' addresses and telephone numbers is provided in Component Manufacturers (Section M).

Use the chart provided at the end of this section as a convenient way to keep a record of maintenance performed.

NOTE: The QSL9 engine features a no-adjust overhead. The QSL9 valve train is designed such that adjustment of the valve lash is **not** required for normal service within the first 241,500 km [150,000 mi] or 5000 hours. The valve train operates acceptably within the limits of 0.152 to 0.559 mm [0.006 to 0.022 in] intake valve lash and 0.381 to 0.813 mm [0.015 to 0.032 in] exhaust valve lash. It is recommended that the valve lash be checked around 241,500 km [150,000 mi] or 5000 hours.

Tool Requirements

Most of the maintenance operations described in this manual can be performed with common hand tools (metric and SAE wrenches, sockets, and screwdrivers).

The following is a list of special service tools required for some maintenance operations:

Tool Part No.	Description
ST-1273	Pressure Gauge
3375045	Torque Wrench (0 to 175 ft-lb)
3375049	Oil Filter Wrench
3376807	Engine Coolant and Fuel Filter Wrench
3822524	Belt Tension Gauge, Click-Type (v-belts and v-ribbed with 4 or 5 ribs)
3822525	Belt Tension Gauge, Click-Type (v-ribbed with 6 to 12 ribs)
3824556	Charge-Air Cooler (CAC) Pressure Kit
3824591	Engine Barring Gear
3824783	Torque Wrench (0 to 300 in-lb)
CC-2800	Refractometer
CC-2802	Coolant Test Kit
3163468	Roller Follower Removal and Installation Tool
3163681	Brake Lash Feeler Gauge
3824842	Compucheck® Fitting

Contact the nearest Cummins Authorized Repair Facility for the required service tools.

A computer is required to run the OEM software. Contact a Cummins Authorized Repair Facility for information on hardware requirements.

Maintenance Schedule

QSL9 Engine Maintenance Schedule					
Daily or Refueling	Every 14,500 km [9000 mi], 250 Hours, or 3 Months	Every 29,000 km [18,000 mi], 500 Hours, or 6 Months (1), (2), (4)	Every 58,000 km [36,000 mi], 1000 Hours, or 1 Year (4)	Every 116,000 km [72,000 mi], 2000 Hours, or 2 Years (3)	Every 241,500 km [150,000 mi], 5000 Hours, or 4 Years (4)
Maintenance Check	Check/Inspect	Change/Replace/Inspect	Check/Inspect	Check/Inspect/Replace	Check/Inspect
<ul style="list-style-type: none"> • Check and correct <ul style="list-style-type: none"> – Engine oil level – Coolant level • Drain air tanks and reservoirs • Drain fuel-water separator • Inspect cooling fan • Check crankcase breather tube • Check intake piping 	<ul style="list-style-type: none"> • Mounting hardware such as injection pump and air compressor • Operate engine, and check air intake system 	<ul style="list-style-type: none"> • Fuel filter • Lubricating oil (1) • Lubricating oil filter (1) • Coolant filter • Check engine (2) coolant SCA concentration level 	<ul style="list-style-type: none"> • Fan hub • Belt tensioner • Drive belts 	<ul style="list-style-type: none"> • Replace anti-freeze (2) • Vibration damper 	<ul style="list-style-type: none"> • Overhead valve lash (5) • Engine brake lash
<ol style="list-style-type: none"> 1. The lubricating oil and lubricating oil filter interval can be adjusted based on application, fuel consumption, gross vehicle weight, and idle time. Refer to Maintenance Specifications (Section V). 2. Service interval is every oil change or 29,000 km [18,000 mi], 500 hours, or 6 months, whichever occurs first. A heavy-duty year-round antifreeze that meets the chemical composition of GM6038M must be used. The change interval is 2 years or 385,000 km [239,227 mi], whichever occurs first. Antifreeze is essential for freeze, overheat, and corrosion protection. 3. Service interval is 2 years or 385,000 km [239,227 mi], whichever occurs first. 4. Follow the manufacturers' recommended maintenance procedures for the starter, alternator, batteries, electrical components, engine brake, exhaust brake, charge-air cooler, radiator, air compressor, air cleaner, freon compressor, and fan clutch. Refer to Component Manufacturers (Section M). 5. Reset valve lash, if needed, to nominal specification 0.305 mm [0.012 in] for intake valve lash and 0.559 mm [0.022 in] for exhaust valve lash. 					

Oil Drain Intervals

Refer to the following flowchart to determine the maximum recommended oil change and filter change intervals in kilometers, miles, hours, or months, whichever occurs first.

Is the vehicle one of those listed below?

- Truck crane/yard spotter
- Paver/crane/backhoe
- Dozer/scrapper/skidder

If Yes -

Select the correct oil drain interval from Table 1.

If No -

Is the vehicle one of those listed below?

- Tractor/combine/irrigation equipment
- Genset/air compressor/fire pump

If Yes -

Select the correct oil drain interval from Table 2.

If No -

Select the correct oil drain interval from Table 3.

Table 1, Oil Drain Intervals				
Vehicle/Equipment	Kilometers	Miles	Hours	Months
Truck crane/ yard spotter	14,500	9000	500	6
Paver/crane/backhoe	N/A	N/A	500	6
Dozer/scrapper/ skidder	N/A	N/A	500	6

Table 2, Oil Drain Intervals				
Vehicle/Equipment	Kilometers	Miles	Hours	Months
Tractor/combine/ irrigation equipment	N/A	N/A	500	6
Genset/ air compressor/ fire pump	N/A	N/A	500	6

Table 3, Oil Drain Intervals				
Vehicle/Equipment	Kilometers	Miles	Hours	Months
All Others	14,500	9000	500	6

Page References for Maintenance Instructions

For convenience, listed below are the page numbers that contain specific instructions for performing the maintenance checks listed in the maintenance schedule.

Daily or Refueling - Maintenance Check

• Air Intake Piping - Check	3-4
• Cooling Fan - Inspect	3-3
• Crankcase Breather Tube - Check	3-5
• Engine Coolant Level - Check/Correct	3-2
• Engine Lubricating Oil Level - Check/Correct	3-2
• Fuel-Water Separator - Drain	3-2

Every 14,500 km [9000 mi], 250 Hours, or 3 Months - Maintenance Check

• Charge-Air Piping - Check/Inspect	4-2
• Charge-Air Cooler (CAC) - Check/Inspect	4-2
• Air Intake Restriction - Check/Inspect	4-2
• Fuel Injection Pump Mounting - Check/Inspect	4-3
• Air Compressor Mounting - Check/Inspect	4-3

Every 29,000 km [18,000 mi], 500 Hours, or 6 Months - Maintenance Check

• Lubricating Oil - Change	5-2
• Lubricating Oil Filters - Replace	5-2
• Fuel Filter (Spin-On Type) - Replace	5-4
• Cooling System - Antifreeze Check	5-7
• Coolant Filter - Replace	5-8

Every 58,000 km [36,000 mi], 1000 Hours, or 1 Year - Maintenance Check

• Drive Belts - Check/Inspect	6-2
• Fan Hub, Belt-Driven - Check/Inspect	6-2
• Belt Tensioner, Automatic - Check/Inspect	6-3

Every 116,000 km [72,000 mi], 2000 Hours, or 2 Years - Maintenance Check

• Cooling System - Clean	7-2
• Vibration Damper, Rubber - Check/Inspect	7-5
• Vibration Damper - Check/Inspect	7-5

Every 241,500 km [150,000 mi], 5000 Hours, or 4 Years - Maintenance Check

• Overhead Set - Measure/Reset - Check/Inspect	8-2
• Engine Brake Lash	8-4

Maintenance Record	
Engine Serial No.:	Engine Model:
Owner's Name:	Equipment Name/Number:

A = Date
B = km [Miles], Hours or Time Interval
C = Actual km [Miles] or Hours
D = Maintenance Check Performed
E = Check Performed By
F = Comments

[illegible]

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Section 3 - Maintenance Procedures at Daily Interval

Section Contents

	Page
Air Intake Piping	3-4
Maintenance Check	3-4
Coolant Level	3-2
Maintenance Check	3-2
Crankcase Breather Tube	3-5
Maintenance Check	3-5
Daily Maintenance Procedures - General Information	3-1
General Information	3-1
Fan, Cooling	3-3
Inspect for Reuse	3-3
Fuel-Water Separator	3-2
Drain	3-2
Lubricating Oil Level	3-2
Maintenance Check	3-2


THIS PAGE LEFT INTENTIONALLY BLANK

Daily Maintenance Procedures - General Information

General Information

Preventative maintenance begins with day-to-day awareness of the condition of the engine and its systems. Before starting the engine, check the oil and coolant levels. Look for the following:

- Leaks
- Loose or damaged parts, especially in fuel or exhaust systems
- Worn or damaged belts
- Any change in engine appearance
- Odor of fuel.



Fuel-Water Separator

Drain

⚠ WARNING ⚠

Drain the fuel-water separator into a container, and dispose of contents in accordance with local environmental regulations. Avoid contact with skin.


NOTE: The water and sediment can contain petroleum products. Please consult the local environmental agency for recommended disposal guidelines.

Cummins Engine Company, Inc. requires a fuel-water separator be installed in the fuel supply system. Drain the water and sediment from the separator daily.

Shut off the engine. Open the drain valve by hand.

Open the drain valve until fluid drains out of the drain tube.

Drain the filter sump until clear fuel is visible.



Lubricating Oil Level

Maintenance Check




The vehicle **must** be level when checking the oil level to make sure the measurement is correct.

Shut off the engine for an accurate reading.

Do **not** operate the engine with the oil level below the "L" (low) mark or above the "H" (high) mark. Wait at least 10 minutes after shutting off the engine to check the oil. This allows time for the oil to drain into the oil pan.

For additional oil recommendations, refer to Lubricating Oil Recommendations and Specifications in Section V.



Coolant Level

Maintenance Check

⚠ WARNING ⚠

Do **not** remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

⚠ CAUTION ⚠

Never use a sealing additive to stop leaks in the cooling system. This can result in cooling system plugging and inadequate coolant flow, causing the engine to overheat and the cooling system to fail.

The coolant level **must** be checked daily.

⚠ CAUTION ⚠



Do not add cold coolant to a hot engine. Engine castings can be damaged. Allow the engine to cool to below 50°C [122°F] before adding coolant.

If additional coolant is added to the cooling system, a 50-percent mixture of water and antifreeze **must** be premixed before being added to the system. Since the ability of antifreeze to remove heat from the engine is **not** as good as water, pouring antifreeze into the engine first could contribute to an overheated condition before the liquids are completely mixed. Refer to Coolant Recommendations and Specifications (Section V).

NOTE: On applications that use a coolant recovery system, check to make sure that the coolant is at the appropriate level in the coolant recovery tank, depending on the engine temperature.

Fill the cooling system with coolant to the bottom of the fill neck in the radiator fill or expansion tank.

NOTE: Some radiators have two fill necks: Both **must** be filled when the cooling system is drained.




Fan, Cooling


Inspect for Reuse

⚠ WARNING ⚠


Do not rotate the engine by pulling or prying on the fan. The fan blade(s) can be damaged and cause the fan to fail and cause serious personal injury or property damage. Use the engine barring gear to rotate the crankshaft.



Section 3 - Maintenance Procedures at Daily Interval




Inspect the cooling fan daily. Check for cracks, loose rivets, and bent or loose blades. Check the fan to make sure that it is securely mounted. Tighten the capscrews, if necessary.




⚠ WARNING ⚠

Do not straighten a bent fan blade or continue to use a damaged fan. A bent or damaged fan blade can fail during operation and cause serious personal injury or property damage.



Replace any original equipment fan that is damaged with a fan of the identical part number. Cummins Engine Company, Inc. **must** approve any other fan changes.



Air Intake Piping Maintenance Check



Inspect the intake piping daily for wear points, damage to piping, loose clamps, and punctures that can damage the engine.

Replace damaged pipes, and tighten loose clamps, as necessary, to prevent the air system from leaking.

Torque Value: 8 N•m [71 in-lb]

Check for corrosion under the clamps and hoses of the intake system piping. Corrosion can allow corrosive products and dirt to enter the intake system. Remove clamps and hoses, and clean as required.


Crankcase Breather Tube

Maintenance Check

Check the crankcase breather tube daily during cold weather operation for ice buildup, that can obstruct the tube.

If an ice buildup is present, remove the breather tube, if necessary, and clear the obstruction.

The QS9 engine is equipped with a block-mounted breather tube.



Maintenance Procedures at 14,500 Kilometers [9000 Miles], 250 Hours, or 3 Months

Section Contents

	Page
Air Compressor	4-3
Maintenance Check	4-3
Air Intake Restriction	4-2
Maintenance Check	4-2
Charge-Air Cooler (CAC)	4-2
Maintenance Check	4-2
Charge-Air Piping	4-2
Maintenance Check	4-2
Fuel Pump	4-3
Maintenance Check	4-3
Maintenance Procedures - General Information	4-1
General Information	4-1

THIS PAGE LEFT INTENTIONALLY BLANK

Maintenance Procedures - General Information

General Information

All checks or inspections listed under daily or periodic maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

Fleetguard® is a subsidiary of Cummins Engine Company, Inc. Fleetguard® filters are developed through joint testing at Cummins and Fleetguard®. Fleetguard® filters are standard on new Cummins engines. Cummins Engine Company, Inc. recommends their use.


Fleetguard® products meet all Cummins Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, insist on products that the supplier has tested to meet Cummins high-quality standards.

Cummins can **not** be responsible for problems caused by nongenuine filters that do **not** meet Cummins performance or durability requirements.

Welding on a Vehicle with an Electronically Controlled System Is Not Recommended

CAUTION

Disconnect both the positive (+) and ground (-) (negative) battery cables from the battery before welding on the vehicle. Attach the welder ground (-) cable no more than 0.61 m [2 ft] from the part being welded. Do not connect the ground (-) cable of the welder to the electronic control module (ECM) cooling plate or the ECM. Welding on the engine or engine-mounted components is not recommended because engine component damage can result.



Charge-Air Piping


Maintenance Check



Inspect the charge-air piping and hoses for holes, cracks, and loose connections.

Tighten the hose clamps, if necessary.


Torque Value: 8 N•m [71 in-lb]



Charge-Air Cooler (CAC)

Maintenance Check

Inspect the charge-air cooler for dirt and debris blocking the fins. Check for cracks, holes, and other damage. If damage is found, refer to the original equipment manufacturer (OEM) dealer.




Air Intake Restriction

Maintenance Check

The maximum intake air restriction is 635 mm [25 in] of water for turbocharged engines.

Turbocharged engines **must** be operated at rated rpm and full load to check maximum intake air restriction. Replace the air cleaner element when the restriction reaches the maximum allowable limit, or clean according to the manufacturer's recommendations.



⚠ CAUTION ⚠

Never operate the engine without an air cleaner. Intake air must be filtered to prevent dirt and debris from entering the engine and causing premature wear.

NOTE: Follow the manufacturer's instructions when cleaning or replacing the air cleaner element.


Check the air cleaner service indicator, if equipped. Change the filter element when the red indicator flag (2) is at the raised position in the window (1).

After the air cleaner has been serviced, push the button (3) to reset the service indicator.

Fuel Pump

Maintenance Check


Inspect the fuel injection pump mounting nuts, including the tail support bracket and the top support bracket, for loose and damaged hardware.



Air Compressor

Maintenance Check

Inspect the air compressor mounting nuts, including the tail support bracket, for loose and damaged hardware.



[illegible]

Maintenance Procedures at 29,000 Kilometers [18,000 Miles], 500 Hours, or 6 Months

Section Contents

	Page
Coolant Filter	5-8
Clean	5-9
Install	5-10
Preparatory	5-8
Remove	5-9
Cooling System	5-7
Maintenance Check	5-7
Fuel Filter (Spin-On Type)	5-4
Inspect for Reuse	5-6
Install	5-6
Preparatory	5-4
Remove	5-5
Lubricating Oil and Filters	5-2
Oil Drain Intervals	5-2
Maintenance Procedures - General Information	5-1
General Information	5-1

THIS PAGE LEFT INTENTIONALLY BLANK

Maintenance Procedures - General Information

General Information

All checks or inspections listed under daily or periodic maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

Fleetguard® is a subsidiary of Cummins Engine Company, Inc. Fleetguard® filters are developed through joint testing at Cummins and Fleetguard®. Fleetguard® filters are standard on new Cummins engines. Cummins Engine Company, Inc. recommends their use.

Fleetguard® products meet all Cummins Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, insist on products that the supplier has tested to meet Cummins high-quality standards.

Cummins can **not** be responsible for problems caused by nongenuine filters that do **not** meet Cummins performance or durability requirements.

Welding on a Vehicle with an Electronically Controlled System Is Not Recommended


△ CAUTION △

Disconnect both the positive (+) and ground (-) (negative) battery cables from the battery before welding on the vehicle. Attach the welder ground (-) cable no more than 0.61 m [2 ft] from the part being welded. Do not connect the ground (-) cable of the welder to the electronic control module (ECM) cooling plate or the ECM. Welding on the engine or engine-mounted components is not recommended because engine component damage can result.

Lubricating Oil and Filters

Oil Drain Intervals

Refer to Maintenance Guidelines (Section 2) to determine the maximum recommended oil change and filter change intervals in kilometers, miles, hours, or months, whichever occurs first.




⚠ WARNING ⚠

Some state and federal agencies have determined that used engine oil can be carcinogenic and cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil.

⚠ WARNING ⚠

To avoid personal injury, avoid direct contact of hot oil with your skin.


Change the lubricating oil and filter(s) at the specified oil change interval. Refer to Lubricating Oil Recommendations and Specifications in Section V to find the correct change interval for the application.



Operate the engine until the water temperature reaches 60°C [140°F]. Shut off the engine.

NOTE: Use a container that can hold at least 24 liters [25 qt] of lubricating oil.

Remove the oil drain plug from the bottom of the lubricating oil pan.



Remove the Oil Filter

Clean the area around the lubricating oil filter head. Remove the filter. Clean the gasket surface of the filter head.




NOTE: The o-ring can stick on the filter head. Make sure that it is removed before installing the new filter.

Make sure that the correct oil filter is used:


Fleetguard® Part No. LF9009 or

Cummins Part No. 3401544.



NOTE: Fill the filter with clean lubricating oil before installation.


Apply a light film of lubricating oil to the gasket sealing surface before installing the filter.



⚠ CAUTION ⚠

Mechanical overtightening can distort the threads or damage the filter element seal.


Install the filter as specified by the filter manufacturer.




Check and clean the oil drain plug threads and sealing surface.


Install the drain plug.

Torque Value: 80 N•m [59 ft-lb]





NOTE: Use a high-quality 15W-40 multiviscosity lubricating oil such as Valvoline® Premium Blue®, or its equivalent, in Cummins engines. Choose the correct lubricating oil for the operating climate as outlined in Section V.




Fill the engine with clean lubricating oil to the proper level.


NOTE: Total system capacity assumes lubricating oil pan plus lubricating oil filter.

Some applications use a slightly different lubricating oil pan capacity, and all lubricating oil quantities **must** be adjusted accordingly. Contact the local Cummins Distributor if there are any questions.

	Lubricating Oil Capacity		
	liters		U.S.qt
Standard Oil Pan	22.7	MAX	24
Standard Oil Pan with Block Stiffener	23.7	MAX	25



Operate the engine, and check for leaks at the filters and the oil drain plug.



Fuel Filter (Spin-On Type)


Preparatory

⚠ WARNING ⚠

Water can contain toxic and carcinogenic material. Avoid contact with skin. Drain the fuel filter into a container and dispose of in accordance with local environmental regulations.


Use the filter drain valve to drain fuel out of the filter for approximately 5 seconds. This will prevent fuel from running over the top of the filter upon removal.

Clean all debris from around the fuel filter head.




Remove

Disconnect the water-in-fuel sensor from the wiring harness.





Remove the fuel filter.



Drain the fuel filter.


Remove the water-in-fuel sensor from the fuel filter.





Inspect for Reuse


Inspect the water-in-fuel sensor for cracks and damage.



Install

Install the water-in-fuel sensor into the new fuel filter, Cummins Part No. 3944269 (Fleetguard® Part No. FS1022), if necessary.


The reusable water-in-fuel assembly is Cummins Part No. 3944270.



CAUTION

The QSL9 engine has a self-priming, low-pressure system that purges the air from the fuel system. Do not prefill the fuel filter. Prefilling the fuel filter can cause fuel pump damage.

Lubricate the o-ring with clean lubricating oil.




CAUTION

Mechanical overtightening can distort the threads as well as damage the filter element seal or filter canister.

Install the filter as specified by the filter manufacturer.

Connect the water-in-fuel sensor to the wiring harness.
Connect the wiring harness to the heater (if equipped).




Turn the key to the RUN position, but do **not** attempt to start the engine for 30 seconds. The electric fuel transfer pump will run and purge air from the system for about 30 seconds. After 30 seconds, attempt to start the engine. If the engine does **not** start, turn the key to the OFF position for approximately 30 seconds to allow the electronic module to power down. Turn the key to the ON position allowing the electric fuel transfer pump to cycle again. After 30 seconds, attempt to start the engine again.



If the engine cranks for 30 seconds without starting, vent the fuel supply lines.

To vent the fuel supply lines, loosen the banjo fitting on the fuel pump inlet. Run the electric fuel transfer pump until the air has been bled from the system.

Operate the engine, and check for leaks.



Cooling System Maintenance Check



Overconcentration of antifreeze or use of high-silicate antifreeze can cause engine damage.


Check the antifreeze concentration. Use a mixture of 50-percent water and 50-percent ethylene glycol or propylene-glycol-based antifreeze to protect the engine to -32°C [-26°F] year-around.

The Fleetguard® refractometer, Part No. C2800, provides a reliable, easy-to-read, and accurate measurement of freezing point protection and glycol (antifreeze) concentration.

NOTE: Antifreeze is essential in every climate.

Antifreeze broadens the operating temperature range by lowering the coolant freezing point and by raising its boiling point.

The corrosion inhibitors also protect the cooling system components from corrosion and prolong component life.






Coolant Additive Concentration Checking

⚠ CAUTION ⚠


Inadequate concentration of the coolant additive can result in major corrosive damage to the cooling system components. Overconcentration can cause formation of a "gel" that can cause restriction, plugging of coolant passages, or overheating.

NOTE: If the engine coolant is changed, the coolant filters **must** also be changed.



The cooling system **must** contain the proper coolant additive units to provide the best chemical protection. Refer to Maintenance Specifications (Section V).


NOTE: Use **only** the DCA4 Coolant Test Kit, Fleetguard® Part No. CC-2626, to check the coolant additive concentration in the cooling system.



Coolant Filter/DCA4 Corrosion Resistor Cartridge

The correct coolant filter is determined by the total cooling system capacity and other operational factors.

Refer to the DCA4 Maintenance Guide in Maintenance Specifications (Section V) for the correct selection of the filter.



Coolant Filter

Preparatory

⚠ WARNING ⚠


Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

Remove




Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

Turn the shutoff valve to the OFF position by rotating the knob from vertical to horizontal in the direction shown in the accompanying illustration.





Remove and discard the coolant filter.



Clean

Clean the gasket surface.





Install

CAUTION



Do not allow oil to get into the filter. Oil will damage the DCA.

CAUTION

Mechanical overtightening can distort the threads or damage the filter head.

Apply a thin film of lubricating oil to the gasket sealing surface before installing the new coolant filter.



Install the coolant filter on the filter head. Tighten the filter until the gasket contacts the filter head surface.

Tighten the coolant filter an additional 1/2 to 3/4 of a turn, or as specified by the manufacturer.


CAUTION

The valve must be in the ON position to prevent engine damage.

Turn the shutoff valve to the ON position by rotating the knob from horizontal to vertical in the direction shown in the accompanying illustration.



Install the coolant system pressure cap.



Operate the engine, and check for coolant leaks.

After the air has been purged from the system, check the coolant level again.

Maintenance Procedures at 58,000 Kilometers [36,000 Miles], 1000 Hours, or 1 Year
Section Contents

	Page
Belt Tensioner, Automatic	6-3
Maintenance Check	6-3
Drive Belts	6-2
Maintenance Check	6-2
Fan Hub, Belt Driven	6-2
Maintenance Check	6-2
Maintenance Procedures - General Information	6-1
General Information	6-1

THIS PAGE LEFT INTENTIONALLY BLANK

Maintenance Procedures - General Information

General Information

All checks or inspections listed under daily or periodic maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

Fleetguard® is a subsidiary of Cummins Engine Company, Inc. Fleetguard® filters are developed through joint testing at Cummins and Fleetguard®. Fleetguard® filters are standard on new Cummins engines. Cummins Engine Company, Inc. recommends their use.


Fleetguard® products meet all Cummins Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, insist on products that the supplier has tested to meet Cummins high-quality standards.

Cummins can **not** be responsible for problems caused by nongenuine filters that do **not** meet Cummins performance or durability requirements.

Welding on a Vehicle with an Electronically Controlled System Is Not Recommended

△ CAUTION △

Disconnect both the positive (+) and ground (-) (negative) battery cables from the battery before welding on the vehicle. Attach the welder ground (-) cable no more than 0.61 m [2 ft] from the part being welded. Do not connect the ground (-) cable of the welder to the electronic control module (ECM) cooling plate or the ECM. Welding on the engine or engine-mounted components is not recommended because engine component damage can result.



Drive Belts


Maintenance Check



Inspect the belts daily. Check the belts for intersecting cracks. Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of the belt length) cracks that intersect the transverse cracks are **not** acceptable. Replace a belt if it is frayed or has pieces of material missing. Refer to Section A for belt adjustment and replacement procedures.

Belt damage can be caused by

- Incorrect tension
- Incorrect size or length
- Pulley misalignment
- Incorrect installation
- Severe operating environment
- Oil and grease on the belts.



Fan Hub, Belt Driven

Maintenance Check

Remove the drive belt.




NOTE: The fan hub **must** rotate without any wobble or excessive end play.

- Check the fan hub bearing.



Fan Hub End Play		
mm		in
0.15	MAX	0.006




Belt Tensioner, Automatic


Maintenance Check

Every 58,000 km [36,000 mi], 1000 hours, or 1 year, whichever occurs first, inspect the automatic belt tensioner.


With the engine turned off, check that neither the top nor the bottom tensioner arm stop is touching the cast boss on the tensioner body. If either of the stops is touching a boss, the alternator belt **must** be replaced. Check to make sure that the correct belt part number is being used if either condition exists.




Check the tensioner pulley and body for cracks. If any cracks are noticed, the tensioner **must** be replaced. Refer to a Cummins Authorized Repair Facility. Check the tensioner for dirt buildup. If this condition exists, the tensioner **must** be removed and steam-cleaned.



Check that the bottom tensioner arm stop is in contact with the bottom tensioner arm stop boss on the tensioner body. If these two are **not** touching, the tensioner **must** be replaced.



Inspect the tensioner for evidence of the pivoting tensioner arm contacting the stationary circular base. If there is evidence of these two areas touching, the pivot tube bushing has failed, and the tensioner **must** be replaced.



NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Maintenance Procedures at 116,000 Kilometers [72,000 Miles], 2000 Hours, or 2 Years

Section Contents

	Page
Cooling System	7-2
Drain	7-2
Fill	7-4
Flush	7-3
Maintenance Procedures - General Information	7-1
General Information	7-1
Vibration Damper	7-5
Inspect	7-5
Vibration Damper, Rubber	7-5
Inspect	7-5

THIS PAGE LEFT INTENTIONALLY BLANK

Maintenance Procedures - General Information

General Information

All checks or inspections listed under daily or periodic maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

Fleetguard® is a subsidiary of Cummins Engine Company, Inc. Fleetguard® filters are developed through joint testing at Cummins and Fleetguard®. Fleetguard® filters are standard on new Cummins engines. Cummins Engine Company, Inc. recommends their use.

Fleetguard® products meet all Cummins Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, insist on products that the supplier has tested to meet Cummins high-quality standards.

Cummins can **not** be responsible for problems caused by nongenuine filters that do **not** meet Cummins performance or durability requirements.


Welding on a Vehicle with an Electronically Controlled System Is Not Recommended

CAUTION

Disconnect both the positive (+) and ground (-) (negative) battery cables from the battery before welding on the vehicle. Attach the welder ground (-) cable no more than 0.61 m [2 ft] from the part being welded. Do not connect the ground (-) cable of the welder to the electronic control module (ECM) cooling plate or the ECM. Welding on the engine or engine-mounted components is not recommended because engine component damage can result.

Cooling System

Drain



⚠ WARNING ⚠

Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

⚠ WARNING ⚠

Avoid prolonged or repeated skin contact with used antifreeze. Such prolonged, repeated contact can cause skin disorders or other bodily injury. Wash skin thoroughly after contact. Keep out of reach of children.



⚠ CAUTION ⚠

Protect the environment: Handling and disposing of used antifreeze is subject to federal, state, and local regulations. Use authorized waste disposal facilities, including civic amenity sites and garages providing authorized facilities for the receipt of used antifreeze. If in doubt, contact local authorities of the Environmental Protection Agency (EPA) for guidance as to proper handling of used antifreeze.

⚠ WARNING ⚠

Coolant is toxic. If not reused, dispose of in accordance with local environmental regulations.

Drain the cooling system by opening the drain valve on the radiator and removing the plug in the bottom of the water inlet hose. A drain pan with a capacity of 19 liters [5 gal] will be adequate for most applications.



Check for damaged hoses and loose or damaged hose clamps. Replace as required.



Check the radiator for leaks, damage, and buildup of dirt.


Clean and replace as required.

Flush

⚠ CAUTION ⚠

The system must be filled properly to prevent air locks. During filling, air must be purged from the engine coolant passages. Be sure to open the petcock on the aftercooler for aftercooled engines. Wait 2 to 3 minutes to allow air to be vented; then add mixture to bring the level to the top.

NOTE: Adequate venting is provided for a fill rate of 19 liters [5 gal] per minute.




⚠ CAUTION ⚠

Do not install the radiator cap. The engine is to be operated without the cap for this process.

Fill the system with a mixture of sodium carbonate and water (or a commercially available equivalent).

NOTE: Use 0.5 kg [1lb] of sodium carbonate for every 23 liters [6 gal] of water.




⚠ WARNING ⚠

Coolant is toxic. If not reused, dispose of in accordance with local environmental regulations.

Operate the engine for 5 minutes with the coolant temperature above 80°C [176°F].


Shut the engine off, and drain the cooling system.




Fill the cooling system with high-quality water.

NOTE: Be sure to vent the engine and aftercooler for complete filling.

NOTE: Do not install the radiator cap or the new coolant filter.






Operate the engine for 5 minutes with the coolant temperature above 80°C [176°F].

Shut the engine off, and drain the cooling system.

NOTE: If the water being drained is still dirty, the system must be flushed again until the water is clean.



Fill

⚠ CAUTION ⚠

The system must be filled properly to prevent air locks. During filling, the air must be vented from the engine coolant passages. Be sure to open the petcock on the aftercooler for aftercooled engines. Wait 2 to 3 minutes to allow the air to be vented; then add the mixture to bring the level to the top.

The system is designed to use a specific quantity of coolant. If the coolant level is low, the engine will run hot.


If frequent addition of coolant is necessary, the engine or system has a leak. Find and repair the leak.

The system has a designed fill rate of 19 liters [5 gal] per minute.

⚠ CAUTION ⚠


Never use water alone for coolant. This can result in damage from corrosion.

Use a mixture of 50-percent water and 50-percent ethylene glycol or propylene-glycol-based antifreeze to fill the cooling system.



Coolant Capacity (Engine Only)

	liters	MAX	U.S.qt
QSL9 (Charge-Air Cooled)	10.9		11.5



⚠ WARNING ⚠

Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.


Install the pressure cap. Operate the engine until the coolant reaches a temperature of 80°C [176°F], and check for coolant leaks.

Check the coolant level again to make sure that the system is full of coolant or that the coolant level has risen to the hot level in the recovery bottle on the system, if so equipped.

Vibration Damper, Rubber


Inspect

Check the index lines (A) in the vibration damper hub (B) and the inertia member (C). If the lines are more than 1.59 mm [0.06 in] out of alignment, replace the vibration damper.



Inspect the rubber member for deterioration. If pieces of the rubber are missing, or if the elastic member is more than 3.18 mm [0.13 in] below the metal surface, replace the damper.

NOTE: Look for forward movement on the damper ring on the hub. Replace the vibration damper if any movement is detected.



Vibration Damper


Inspect



The silicone fluid in the vibration damper will become solid after extended service and will make the damper inoperative. An inoperative vibration damper can cause major engine or drivetrain failures.

Check the vibration damper for evidence of fluid loss, dents, and wobble. Inspect the vibration damper thickness for any deformation or raising of the damper cover plate.

If any variations or deformations are detected, refer to the Troubleshooting and Repair Manual, ISL Engine, Bulletin No. 3666469, for inspection procedures.



Maintenance Procedures at 241,500 Kilometers [150,000 Miles], 5000 Hours, or 4 Years

Section Contents

	Page
Maintenance Procedures - General Information	8-1
General Information	8-1
Overhead Set	8-2
General Information	8-2
Measure	8-2

THIS PAGE LEFT INTENTIONALLY BLANK

Maintenance Procedures - General Information

General Information

All checks or inspections listed under daily or periodic maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

Fleetguard® is a subsidiary of Cummins Engine Company, Inc. Fleetguard® filters are developed through joint testing at Cummins and Fleetguard®. Fleetguard® filters are standard on new Cummins engines. Cummins Engine Company, Inc. recommends their use.

Fleetguard® products meet all Cummins Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, insist on products that the supplier has tested to meet Cummins high-quality standards.

Cummins can **not** be responsible for problems caused by nongenuine filters that do **not** meet Cummins performance or durability requirements.

Welding on a Vehicle with an Electronically Controlled System Is Not Recommended


CAUTION

Disconnect both the positive (+) and ground (-) (negative) battery cables from the battery before welding on the vehicle. Attach the welder ground (-) cable no more than 0.61 m [2 ft] from the part being welded. Do not connect the ground (-) cable of the welder to the electronic control module (ECM) cooling plate or the ECM. Welding on the engine or engine-mounted components is not recommended because engine component damage can result.

Overhead Set

General Information

A valve lash check **must** be performed at 241,500 km [150,000 mi] and at 81,000 km [50,000 mi] intervals thereafter.




Measure




Engine coolant temperature must be less than 60°C [140°F].

Remove the plastic fuel pump drive cover located on the front of the engine.



Engine Barring Tool, Part No. 3824591

Use the barring tool, Cummins Part No. 3824591, to rotate the crankshaft to align the top dead center (TDC) marks on the gear cover and fuel pump gear.



Remove the rocker lever cover and gasket.

QSL9
Maintenance Procedures at 241,500 km [150,000 mi]

With the engine in this position, the lash can be reset on the following rocker arms: 1I, 1E, 2I, 3E, 4I, and 5E.

Nominal Valve Lash			
Intake	0.305 mm	Nominal	0.012 in
Exhaust	0.559 mm	Nominal	0.022 in



Reset the lash to the nominal specification above.

NOTE: Valve lash measurements are sometimes performed as part of a troubleshooting procedure. If the lash measurement does **not** coincide with a scheduled lash reset (at 241,500 km [150,000 mi] or 81,000 km [50,000 mi] intervals thereafter), and the measurement falls within the following range, the lash does **not** need to be reset. Lash measurements in this range will **not** affect engine performance, noise, emissions, or durability.

Valve Lash Acceptable Range			
	mm		in
Intake	0.152	MIN	0.006
	0.559	MAX	0.022
Exhaust	0.381	MIN	0.015
	0.813	MAX	0.032

Reset the valve lash by inserting the proper feeler gauge between the crosshead and the rocker lever ball insert and socket. If the lash measurement is out of specification, loosen the locknut, and adjust the lash to nominal specifications.


Tighten the locknut to the rocker lever, and measure again.




Engine Barring Tool, Part No. 3824591

Use a barring tool, Cummins Part No. 3824591, to rotate the crankshaft 360 degrees (the mark on the fuel pump gear rotates 180 degrees), and measure the lash for rocker arms 2E, 3I, 4E, 5I, 6I, and 6E.


Reset to nominal specifications.






Install the gasket and rocker lever cover.

Torque Value: 12 N•m [106 in-lb]



Install the fuel pump drive cover.




Engine Brake Lash Adjustment

CAUTION

To get maximum brake operating efficiency and to prevent engine damage, the instructions in this section must be followed.

Remove the rocker lever cover.




Remove the plastic fuel pump drive cover located on the front of the engine.

QSL9
Maintenance Procedures at 241,500 km [150,000 mi]

Engine Barring Tool, Part No. 3824591


Use the barring tool, Part No. 3824591, to rotate the crankshaft to align the mark on the fuel pump gear with the top dead center (TDC) mark on the gear cover.



05d00003

When the engine is in the top dead center (TDC) position, the brake lash can be set on cylinders No. 1, 3, and 5.

Use two wrenches to hold the adjusting nut and loosen the locknuts on the brake at cylinders No. 1, 3, and 5.




20d00014

Brake Lash - Feeler Gauge Method

Insert the appropriate brake lash feeler gauge between the brake slave piston and the exhaust crosshead pin on cylinder No. 1.




Brake Lash - Feeler Gauge		
Turbo	Tool Part No.	Lash Specification
Wastegate	3163681	2.286 mm [0.090 in]




20d00015

Use the 6 in-lb torque wrench, Part No. 3376592, to tighten the adjusting nut until the torque wrench “clicks,” or until drag is felt on the feeler gauge.

Torque Value: 0.7 N•m [6 in-lb]



20d00016




Remove the feeler gauge, and use two wrenches to hold the adjusting nut and tighten the locknut.

Torque Value: 35 N•m [26 ft-lb]




Repeat for cylinders No. 3 and 5.



Engine Barring Tool, Part No. 3824591

Use the engine barring tool, Part No. 3824591, to rotate the crankshaft 360 degrees to align the mark on the fuel pump gear with the mark on the gear cover, which is 180 degrees away from top dead center (TDC).


When the engine is in position, the back lash can be set on cylinders No. 2, 4, and 6.



Insert the appropriate brake lash feeler gauge between the brake sleeve piston and the exhaust crosshead pin on cylinder No. 2.

Brake Lash - Feeler Gauge

Turbo	Tool Part No.	Lash Specification
Wastegate	3613681	2.286 mm [0.090 in]



Use the 6 in-lb torque wrench, Part No. 3376592, to tighten the adjusting nut until the torque wrench "clicks," or until drag is felt on the feeler gauge.




Torque Value: 0.7 N•m [6 in-lb]

Remove the feeler gauge, and use two wrenches to hold the adjusting nut and tighten the locknut.


Torque Value: 35 N•m [26 ft-lb]

Repeat for cylinders No. 4 and 6.



Brake Lash Dial Indicator Method

Tighten the brake lash adjusting nut on cylinder No. 1 until resistance is felt. Place the dial indicator tip on the adjusting nut, and zero the dial indicator. Turn the lash adjusting nut in a **counterclockwise** direction until the appropriate lash is reached.




Brake Lash	
Turbo	Lash Specification
Wastegate	2.286 mm [0.090 in]

Use two wrenches to hold the adjusting nut and tighten the locknut.

Torque Value: 35 N•m [26 ft-lb]


Repeat for cylinders No. 3 and 5.




Engine Barring Tool, Part No. 3824591

Use the engine barring tool, Part No. 3824591, to rotate the crankshaft 360 degrees to align the mark on the fuel pump gear with the mark on the gear cover, which is 180 degrees away from top dead center (TDC).


When the engine is in position, the back lash can be set on cylinders No. 2, 4, and 6.





Tighten the brake lash adjusting nut on cylinder No. 2 until resistance is felt. Place the dial indicator tip on the adjusting nut, and zero the dial indicator. Turn the lash adjusting nut in a **counterclockwise** direction until the appropriate lash is reached.


Brake Lash	
Turbo	Lash Specification
Wastegate	2.286 mm [0.090 in]




Use two wrenches to hold the adjusting nut and tighten the locknut.

Torque Value: 35 N•m [26 ft-lb]

Repeat for cylinders No. 4 and 6.



Install the plastic fuel pump drive cover located on the front of the engine.



Install the rocker lever cover.

Torque Value: 12 N•m [106 in-lb]



Section A - Adjustment, Repair, and Replacement

Section Contents

	Page
Alternator	A-8
Install	A-9
Preparatory	A-8
Remove	A-9
Belt Tensioner, Automatic	A-1
Install	A-2
Preparatory	A-1
Remove	A-2
Charge-Air Cooler (CAC)	A-5
General Information	A-5
Leak Test	A-6
Pressure Test	A-6
Temperature Differential Test	A-6
Coolant Thermostat	A-4
Clean	A-4
Install	A-5
Preparatory	A-4
Remove	A-4
Drive Belt, Water Pump	A-1
Install	A-1
Remove	A-1
Fan Spacer and Pulley	A-3
Install	A-3
Preparatory	A-3
Remove	A-3
Starting Motor	A-7
Install	A-8
Preparatory	A-7
Remove	A-7

THIS PAGE LEFT INTENTIONALLY BLANK


Drive Belt, Water Pump

Remove

3/8-Inch Square Drive


Lift the tensioner to remove the drive belt.

NOTE: The belt tensioner winds in the direction that the spring tang is bent over the tensioner body. To loosen the tension on the belt, rotate the tensioner to wind the spring tighter.



⚠ CAUTION ⚠

Applying excessive force in the opposite direction of wind-up or after the tensioner has been wound-up to the positive stop can cause the tensioner arm to break.




Install

3/8-Inch Square Drive

⚠ CAUTION ⚠

The belt tensioner is spring-loaded and must be pivoted away from the drive belt. Pivoting in the wrong direction can damage the belt tensioner.


Lift the tensioner to install the drive belt.




Belt Tensioner, Automatic

Preparatory

Remove the drive belt.





Remove


3/8-Inch Square Drive



CAUTION


The belt tensioner is spring-loaded and must be pivoted away from the drive belt. Pivoting in the wrong direction can damage the belt tensioner.

Lift the belt tensioner to relieve tension in the belt, and remove the belt.



15 mm

Remove the capscrew and belt tensioner from the bracket.




Install

15 mm

Install the belt tensioner and capscrews.



Torque Value: 43 N•m [32 ft-lb]



3/8-Inch Square Drive

Lift and hold the tensioner. Install the drive belt, and release the tensioner.




Service Tip: If difficulty is experienced installing the drive belt, or if the belt seems too short, position the belt over the grooved pulleys first; then, while holding the tensioner up, slide the belt over the water pump pulley.

Fan Spacer and Pulley

Preparatory

Remove the drive belt.

SERVICE TIP: Loosen the capscrews before removing the belt, and tighten the capscrews after the belt is installed.




Remove

3/8-Inch Square Drive




The belt tensioner is spring-loaded and must be pivoted away from the drive belt. Pivoting in the wrong direction can result in damage to the belt tensioner.

Lift the tensioner to relieve tension in the belt. Remove the belt.



Remove the fan capscrews, fan, and spacer.

Remove the fan pulley.




Install

13 mm


Install the fan pulley.

Install the spacer, fan, and fan capscrews.

Torque Value: 24 N•m [18 ft-lb]



Section A - Adjustment, Repair, and Replacement




3/8-Inch Square Drive

Lift the tensioner, and install the belt.



Service Tip: If difficulty is experienced installing the drive belt, or if the belt seems to short, position the belt over the grooved pulleys first; then, while holding the tensioner up, slide the belt over the water pump pulley.



Coolant Thermostat
Preparatory



WARNING

Coolant is toxic. If not reused, dispose of in accordance with local environmental regulations.




WARNING

Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

Drain the coolant from the radiator.

Disconnect the upper radiator hose.




Remove

10 mm



Remove the water outlet tube capscrews and water outlet tube.

Remove the thermostat.



Clean




CAUTION

Do not let any debris fall into the thermostat cavity when cleaning the surfaces. Failure to do so will result in engine damage.

Clean all the mating surfaces.

Install


Install the new thermostat into the thermostat housing. Make sure that the top and bottom o-rings are in place.



10 mm

Install the water outlet tube and capscrews.

Torque Value: 24 N•m [18 ft-lb]




⚠ CAUTION ⚠

Always vent the engine and aftercooler during filling to remove air from the coolant system, or overheating will result.

Fill the cooling system.


Operate the engine, and check for leaks.




Charge-Air Cooler (CAC)

General Information

NOTE: The long-term integrity of the charge-air cooler (CAC) system is the responsibility of the vehicle and component manufacturers; however, the following can be checked by any Cummins Authorized Repair Facility.





Pressure Test

Pressure Gauge, Part No. ST-1273




Install the pressure gauge, Part No. ST-1273, to the fitting in the turbocharger outlet.



Install another pressure gauge, Part No. ST-1273, in the intake manifold.

Operate the engine at rated rpm and load. Record the readings on the two gauges.

If the differential pressure is greater than 50 kPa [7 psi], check the charge-air cooler (CAC) for plugging. Clean or replace, if necessary.




Temperature Differential Test

Install a temperature gauge in the intake manifold.



Lock the fan drive in the ON mode to prevent erratic test results. This can be done by installing a jumper across the temperature switch or supplying shop air to the fan. Refer to the fan drive manufacturer for lockup procedure.

NOTE: Some trucks have a manual switch that will lock on the fan.




Operate the engine at rated rpm and load. Record the intake manifold temperature.



Measure the ambient temperature at least 2 feet in front of the vehicle.

The maximum temperature differential **must not** be greater than 25°C [77°F].

If the temperature differential is greater than 25°C [77°F], check the charge-air cooler (CAC) or dirt and debris on the fins, and clean as necessary. If the problem still exists, check the cooler for internal contamination or plugging.



Leak Test

CAUTION



Pressure caps must be attached with a chain to the charge-air cooler (CAC).

To check the charge-air cooler (CAC) for cracked tubes or header, remove the inlet and outlet hoses from the cooler.

Remove the charge-air cooler (CAC).


Use service tool No. 3824556 to install a cap over the outlet side of the cooler. Install a pressure gauge and a shop air supply line to the inlet side of the cooler.

QSL9
Section A - Adjustment, Repair, and Replacement

Starting Motor
Page A-7


Apply 207 kPa [30 psi] of air pressure to the cooler. If the pressure drop is 48 kPa [7 psi] or more in 15 seconds, the charge-air cooler (CAC) **must** be repaired or replaced. Refer to the charge-air cooler (CAC) manufacturer for repair instructions.

NOTE: A leak tank can be used to locate the air leak.



CAUTION


The charge-air cooler (CAC) must be cleaned following any turbocharger or air cleaner failure. Debris trapped in the charge-air cooler (CAC), if not cleaned, can cause internal engine damage.



Starting Motor

Preparatory


Disconnect the ground cable from the battery terminal.
Identify each electrical wire with a tag indicating location.




Remove

Remove the electrical connections from the batteries, negative (-) cable first.


Remove the electrical connections from the starter motor, and identify each wire with a tag indicating location.





10 mm

Remove the three capscrews and the starter motor.




Install

10 mm

Install the starter motor in the reverse order of removal.

Connect all the cables. Connect the negative (-) cable last.


Torque Value: 43 N•m [32 ft-lb]



WARNING

Batteries can emit explosive gases. To avoid personal injury, always ventilate the compartment before servicing the batteries. To avoid arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

Install and tighten the battery electrical connections. Connect the negative (-) cable last.



**Alternator
Preparatory**


WARNING

Batteries can emit explosive gases. To avoid personal injury, always ventilate the compartment before servicing the batteries. To avoid arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

Disconnect the ground (-) cable from the battery terminal.

Remove and tag all the wires.


Remove the drive belt from the alternator pulley.



Remove

13 mm


Remove the alternator link capscrew.



16 mm

Remove the alternator mounting capscrew.

Remove the alternator.




Install

To install the alternator, the alternator mounting components **must** be tightened in the following sequence:

1. Alternator-to-alternator bracket capscrew
2. Lower brace-to-alternator capscrew
3. Lower alternator brace-to-water pump capscrew
4. Water inlet-to-block capscrews.

NOTE: The wrench size and torque value is determined by the make and model of the alternator. Refer to the OEM service manual.



This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Section D - System Diagrams
Section Contents

	Page
Flow Diagram, Air Intake System.....	D-8
Flow Diagram, Compressed Air System	D-10
Flow Diagram, Cooling System.....	D-7
Flow Diagram, Exhaust System	D-9
Flow Diagram, Fuel System	D-2
Flow Diagram, Lubricating Oil System	D-3
System Diagrams - General Information.....	D-1

THIS PAGE LEFT INTENTIONALLY BLANK


System Diagrams - General Information

The following drawings show the flow through the engine systems. Although the parts can be different for various applications and installations, the flow remains the same. The systems shown are

- Fuel system
- Lubricating oil system
- Coolant system
- Intake air system
- Exhaust system
- Compressed air system.


Knowledge of the engine systems can help in troubleshooting, servicing, and general maintenance of the engine.

Flow Diagram, Fuel System



- | | |
|--|---------------------------------|
| 1. Fuel from supply tank | 6. Distributor outlet fitting |
| 2. Electronic lift pump | 7. High-pressure supply lines |
| 3. Fuel filter and water separator | 8. Fuel connector |
| 4. Fuel drain line | 9. Injectors |
| 5. Cummins accumulator pump system (CAPS) injection pump | 10. Fuel return to supply tank. |


Flow Diagram, Lubricating Oil System




1. Gerotor lubricating oil pump
2. Pressure-regulating valve closed
3. Pressure-regulating valve open
4. From lubricating oil pump
5. To lubricating oil cooler
6. To lubricating oil pan
7. Lubricating oil cooler

8. Filter bypass valve
9. Filter bypass valve closed
10. Filter bypass valve open
11. To lubricating oil filter
12. Full-flow lubricating oil filter
13. From lubricating oil filter
14. Main lubricating oil rifle.

Lubrication for the Turbocharger



Insert Color File
07900133.CDR
Pantone 185 (Red)




07900133

1. Lubricating oil filter
2. Turbocharger lubricating oil supply
3. Turbocharger lubricating oil drain
4. To main lubricating oil rifle.

Lubrication for the Power Components

Insert Color File
07d00001.CDR
Pantone 185 (Red)




07d00001

1. From lubricating oil cooler
2. Main lubricating oil rifle
3. To camshaft

4. From main lubricating oil rifle
5. To piston cooling nozzle
6. To connecting rod bearing.

Lubrication for the Overhead




07d00002

1. From cam bushings
2. Transfer slot
3. Rocker lever support

4. Rocker lever shaft
5. Rocker lever bore
6. Rocker lever.


Flow Diagram, Cooling System



1. Coolant inlet from radiator
2. Water pump suction
3. Coolant flow through lubricating oil cooler
4. Block lower water manifold (to cylinders)
5. Coolant filter inlet
6. Coolant filter outlet


7. Coolant supply to cylinder head
8. Coolant return from cylinder head
9. Block upper water manifold
10. Thermostat bypass
11. Coolant return to radiator.

Flow Diagram, Air Intake System



1. Intake air inlet to turbocharger
2. Turbocharger air to charge-air cooler (CAC)
3. Charge-air cooler (CAC)
4. Intake manifold (integral part of cylinder head)
5. Intake valve.


Flow Diagram, Exhaust System



11d00001

1. Exhaust valve
2. Exhaust manifold (pulse-type)
3. Dual-entry turbocharger
4. Turbocharger exhaust outlet.

Flow Diagram, Compressed Air System



- 1. Coolant
- 2. Air

- 3. Lubricant

Section L - Service Literature
Section Contents

	Page
Additional Service Literature	L-1
General Information	L-1
Service Literature Ordering Location	L-2
General Information	L-2

THIS PAGE LEFT INTENTIONALLY BLANK

Additional Service Literature

General Information

The following publications can be purchased.

Bulletin No.	Title of Publication
3666469	Troubleshooting and Repair Manual, ISL Engine
3666271	Troubleshooting and Repair Manual, Electronic Controlled System, ISC, QSC8.3, and ISL Engines
3666416	ISL Wiring/Fault Code Diagram
3669001	Fuel for Cummins Engines Bulletin
3810340	Cummins Engine Oil Recommendations Bulletin
3666132	Coolant Requirements and Maintenance Bulletin

Service Literature Ordering Location

General Information

Region

United States and Canada

U.K., Europe, Mid-East, Africa,
and Eastern European Countries

South and Central America
(excluding Brazil and Mexico)

Brazil and Mexico

Far East (excluding
Australia and New Zealand)

Australia and New Zealand

Ordering Location

Cummins Distributors

or

Contact 1-800-DIESELS
(1-800-343-7357)

Cummins Engine Co., Ltd.
Royal Oak Way South
Daventry
Northants, NN11 5NU, England

Cummins Americas, Inc.
16085 N.W. 52nd Avenue
Hialeah, FL 33104

Cummins Engine Co., Inc.
International Parts Order Dept., MC 40931
Box 3005
Columbus, IN 47202-3005

Cummins Diesel Sales Corp.
Literature Center
8 Tanjong Penjuru
Jurong Industrial Estate
Singapore

Cummins Diesel Australia
Maroondah Highway, P.O.B. 139
Ringwood 3134
Victoria, Australia

Obtain current price information from your local Cummins Distributor.

Section M - Component Manufacturers

Section Contents

	Page
Component Manufacturers' Addresses	M-1
Air Compressors.....	M-1
Air Cylinders	M-1
Air Heaters.....	M-1
Air Starting Motors	M-1
Alternators.....	M-1
Auxiliary Brakes	M-1
Belts.....	M-1
Catalytic Converters	M-1
Clutches.....	M-1
Coolant Heaters	M-2
Coolant Level Switches	M-1
Drive Plates.....	M-2
Electric Starting Motors	M-2
Electronic Switches	M-2
Engine Protection Controls	M-2
Fan Clutches.....	M-2
Fans.....	M-2
Fault Lamps	M-2
Filters.....	M-2
Flexplates.....	M-2
Fuel Coolers.....	M-2
Fuel Pumps.....	M-2
Fuel Warmers.....	M-2
Gauges	M-3
General Information.....	M-1
Governors	M-3
Heat Sleeves.....	M-3
Hydraulic and Power Steering Pumps.....	M-3
In-Line Connectors	M-3
Oil Heaters	M-3
Prelubrication Systems.....	M-3
Radiators.....	M-3
Throttle Assemblies	M-3
Torque Converters	M-3

THIS PAGE LEFT INTENTIONALLY BLANK

Component Manufacturers' Addresses

General Information

NOTE: The following list contains addresses and telephone numbers of suppliers of accessories used on Cummins engines. Suppliers can be contacted directly for any specifications **not** covered in this manual.

Air Compressors

Bendix Heavy Vehicles Systems
Div. of Allied Automotive
901 Cleveland Street
Elyria, OH 44036
Telephone: (216) 329-9000

Holset Engineering Co., Inc.
1320 Kemper Meadow Drive
Suite 500
Cincinnati, OH 45240
Telephone: (513) 825-9600

Midland-Grau
Heavy Duty Systems
Heavy Duty Group Headquarters
10930 N. Pamon Avenue
Kansas City, MO 64153
Telephone: (816) 891-2470

Air Cylinders

Bendix Ltd.
Douglas Road
Kingswood
Bristol
England
Telephone: 0117-671881

Catching Engineering
1733 North 25th Avenue
Melrose Park, IL 60160
Telephone: (708) 344-2334

TEC - Hackett Inc.
8909 Rawles Avenue
Indianapolis, IN 46219
Telephone: (317) 895-3670

Air Heaters

Fleetguard, Inc.
1200 Fleetguard Road
Cookeville, TN 38502
Telephone: (615) 526-9551

Kim Hotstart Co.
P.O. Box 11245
Spokane, WA 99211-0245
Telephone: (509) 534-6171

Air Starting Motors

Ingersoll Rand
Chorley New Road
Horwich
Bolton
Lancashire
England
BL6 6JN
Telephone: 01204-65544

Ingersoll-Rand Engine
Starting Systems
888 Industrial Drive
Elmhurst, IL 60126
Telephone: (708) 530-3875

StartMaster
Air Starting Systems
A Division of Sycon Corporation
9595 Cheney Avenue
P. O. Box 491
Marion, OH 43302
Telephone: (614) 382-5771

Alternators

Robert Bosch Ltd.
P.O. Box 98
Broadwater Park
North Orbital Road
Denham
Uxbridge
Middlesex UD9 5HG
England
Telephone: 01895-833633

Butec Electrics
Cleveland Road
Leyland
PR5 1XB
England
Telephone: 01744-21663

C.A.V. Electrical Equipment
P.O. Box 36
Warple Way
London
W3 7SS
England
Telephone: 01-743-3111

A.C. Delco Components Group
Civic Offices
Central Milton Keynes
MK9 3EL
England
Telephone: 01908-66001

C. E. Niehoff & Co.
2021 Lee Street
Evanston, IL 60202
Telephone: (708) 866-6030

Delco-Remy America
2401 Columbus Avenue
P.O. Box 2439
Anderson, IN 46018
Telephone: (317) 646-3528

Leece-Neville Corp.
400 Main Street
Arcade, NY 14009
Telephone: (716) 492-1700

Auxiliary Brakes

The Jacobs Manufacturing Company
Vehicle Equipment Division
22 East Dudley Town Road
Bloomfield, CT 06002
Telephone: (203) 243-1441

Belts

Dayco Rubber U.K.
Sheffield Street
Stockport
Cheshire
SK4 1RV
England
Telephone: 061-432-5163

T.B.A. Belting Ltd.
P.O. Box 77
Wigan
Lancashire
WN2 4XQ
England
Telephone: 01942-59221

Dayco Mfg.
Belt Technical Center
1955 Enterprise
Rochester Hills, MI 48309
Telephone: (810) 853-8300

Gates Rubber Company
900 S. Broadway
Denver, CO 80217

Goodyear Tire and
Rubber Company
Industrial Products Div.
2601 Fortune Circle East
Indianapolis, IN 46241
Telephone: (317) 898-4170

Catalytic Converters

Donaldson Company, Inc.
1400 West 94th Street
P.O. Box 1299
Minneapolis, MN 55440
Telephone: (612) 887-3835

Nelson Division
Exhaust and Filtration Systems
1801 U.S. Highway 51 P.O. Box 428
Stoughton, WI 53589
Telephone: (608) 873-4200

Walker Manufacturing
3901 Willis Road
P.O. Box 157
Grass Lake, MI 49240
Telephone: (517) 522-5500

Coolant Level Switches

Robertshaw Controls Company
P.O. Box 400
Knoxville, TN 37901
Telephone: (216) 885-1773

Clutches

Twin Disc International S.A.
Chaussee de Namur
Nivelles
Belguim
Telephone: 067-224941

Twin Disc Incorporated
1328 Racine Street
Racine, WI 53403
Telephone: (414) 634-1981

Coolant Heaters

Fleetguard, Inc.
1200 Fleetguard Road
Cookeville, TN 38502
Telephone: (615) 526-9551

Drive Plates

Detroit Diesel Allison
Division of General Motors
Corporation
P.O. Box 894
Indianapolis, IN 46206-0894
Telephone: (317) 242-5000

Electric Starting Motors

Bute Electric
Cleveland Road
Leyland
PR5 1XB
England
Telephone: 01744-21663
C.A.V. Electrical Equipment
P.O. Box 36
Warple Way
London
W3 7SS
England
Telephone: 01-743-3111

A.C. Delco Components Group
Civic Offices
Central Milton Keynes
MK9 3EL
England
Telephone: 0908-66001

Delco-Remy America
2401 Columbus Avenue
P.O. Box 2439
Anderson, IN 46018
Telephone: (317) 646-3528

Leece-Neville Corp.
400 Main Street
Arcade, NY 14009
Telephone: (716) 492-1700

Nippondenso Inc.
2477 Denso Drive
P.O. Box 5133
Southfield, MI 48086
Telephone: (313) 350-7500

Electronic Switches

Cutler-Hammer Products
Eaton Corporation
4201 N. 27th Street
Milwaukee, WI 53216
Telephone: (414) 449-6600

Engine Protection Controls

Flight Systems Headquarters
Hempt Road
P.O. Box 25
Mechanicsburg, PA 17055
Telephone: (717) 697-0333

The Nason Company
2810 Blue Ridge Blvd.
West Union, SC 29696
Telephone: (803) 638-9521

Teddington Industrial
Equipment
Windmill Road
Sunburn on Thames
Middlesex
TW16 7HF
England
Telephone: 09327-85500

Fan Clutches

Kysor Cooling Systems N.A.
6040 West 62nd Street
Indianapolis, IN 46278
Telephone: (317) 328-3330

Holset Engineering Co. Ltd.
P.O. Box A9
Turnbridge
Huddersfield, West Yorkshire
England HD6 7RD
Telephone: 01484-22244

Horton Industries, Inc.
P.O. Box 9455
Minneapolis, MN 55440
Telephone: (612) 378-6410

Rockford Clutch Company
1200 Windsor Road
P.O. Box 2908
Rockford, IL 61132-2908
Telephone: (815) 633-7460

Fans

Truflo Ltd.
Westwood Road
Birmingham
B6 7JF
England
Telephone: 021-557-4101

Hayes-Albion Corporation
Jackson Manufacturing Plant
1999 Wildwood Avenue
Jackson, MI 49202
Telephone: (517) 782-9421

Engineered Cooling Systems, Inc.
201 W. Carmel Drive
Carmel, IN 46032
Telephone: (317) 846-3438

Brookside Corporation
P.O. Box 30
McCordsville, IN 46055
Telephone: (317) 335-2014

TCF Aerovent Company
9100 Purdue Rd., Suite 101
Indianapolis, IN 46268-1190
Telephone: (317) 872-0030

Kysor-Cadillac
1100 Wright Street
Cadillac, MI 49601
Telephone: (616) 775-4681

Schwitzer
6040 West 62nd Street
P.O. Box 80-B
Indianapolis, IN 46206
Telephone: (317) 328-3010

Fault Lamps

Cutler-Hammer Products
Eaton Corporation
4201 N. 27th Street
Milwaukee, WI 53216
Telephone: (414) 449-6600

Filters

Fleetguard International Corp.
Cavalry Hill Industrial Park
Weedon
Northampton NN7 4TD
England
Telephone: 01327-41313

Fleetguard, Inc.
1200 Fleetguard Road
Cookeville, TN 38502
Telephone: 1-800-22-Filters
(1-800-223-4583)

Flexplates

Corrugated Packing and
Sheet Metal
Hamsterley
Newcastle Upon Tyne
England
Telephone: 01207-560-505

Allison Transmission
Division of General Motors
Corporation
P.O. Box 894
Indianapolis, IN 46206-0894
Telephone: (317) 242-5000

Midwest Mfg. Co.
29500 Southfield Road, Suite 122
Southfield, MI 48076
Telephone: (313) 642-5355

Wohlert Corporation
708 East Grand River Avenue
P.O. Box 20217
Lansing, MI 48901
Telephone: (517) 485-3750

Fuel Coolers

Hayden, Inc.
1531 Pomona Road
P.O. Box 848
Corona, CA 91718-0848
Telephone: (909) 736-2665

Fuel Pumps

Robert Bosch Corp.
Automotive Group
2800 South 25th Ave.
Broadview, IL 60153

Fuel Warmers

Fleetguard, Inc.
1200 Fleetguard Road
Cookeville, TN 38502
Telephone: (615) 526-9551

Gauges

A.I.S.
Dyffon Industrial Estate
Ystrad Mynach
Hengoed
Mid Glamorgan
CF8 7XD
England
Telephone: 01443-812791

Grasslin U.K. Ltd.
Vale Rise
Tonbridge
Kent
TN9 1TB
England
Telephone: 01732-359888

Icknield Instruments Ltd.
Jubilee Road
Letchworth
Herts
England
Telephone: 04626-5551

Superb Tool and Gauge Co.
21 Princip Street
Birmingham
B4 61E
England
Telephone: 021-359-4876

Kabi Electrical and Plastics
Cranborne Road
Potters Bar
Herts
EN6 3JP
England
Telephone: 01707-53444

Datcon Instruments
P.O. Box 128
East Petersburg, PA 17520
Telephone: (717) 569-5713

Rochester Gauges, Inc.
11616 Harry Hines Blvd.
P.O. Box 29242
Dallas, TX 75229
Telephone: (214) 241-2161

Governors

Woodward Governors Ltd.
P.O. Box 15
663/664 Ajax Avenue
Slough
Bucks
SL1 4DD
England
Telephone: 01753-26835

Woodward Governor Co.
P.O. Box 1519
Fort Collins, CO 80522
Telephone: (303) 482-5811
(800) 523-2831

Barber Colman Co.
1354 Clifford Avenue
Loves Park, IL 61132
Telephone: (815) 637-3000

United Technologies
Diesel Systems
1000 Jorie Blvd.
Suite 111
Oak Brook, IL 69521
Telephone: (312) 325-2020

Heat Sleeves

Bentley Harris Manufacturing Co.
100 Bentley Harris Way
Gordonville, TN 38563
Telephone: (313) 348-5779

Hydraulic and Power Steering Pumps

Hobourn Automotive
Temple Farm Works
Priory Road
Strood
Rochester
Kent, England
ME2 2BD
Telephone: 01634-71773

Honeywell Control Systems Ltd.
Honeywell House
Charles Square
Bracknell
Berk RG12 1EB
Telephone: 01344-4245

Sundstrand Hydratec Ltd.
Cheney Manor Trading Estate
Swindon
Wiltshire
SN2 2PZ
England
Telephone: 01793-30101

Sperry Vickers
P.O. Box 302
Troy, MI 48084
Telephone: (313) 280-3000

Z.F.
P.O. Box 1340
Grafvonsoden Strasse
5-9 D7070
Schwaebisch Gmuend
Germany
Telephone: 7070-7171-31510

In-Line Connectors

Pioneer-Standard Electronics, Inc.
5440 Neiman Parkway
Solon, OH 44139
Telephone: (216) 349-1300

Deutsch
Industrial Products Division
37140 Industrial Avenue
Hemet, CA 92343
Telephone: (714) 929-1200

Oil Heaters

Fleetguard, Inc.
1200 Fleetguard Road
Cookeville, TN 38502
Telephone: (615) 526-9551

Kim Hotstart Co.
P.O. Box 11245
Spokane, WA 99211-0245
Telephone: (509) 534-6171

Prelubrication Systems

RPM Industries, Inc.
Suite 109
55 Hickory Street
Washington, PA 15301
Telephone: (412) 228-5130

Radiators

JB Radiator Specialties, Inc.
P.O. Box 292087
Sacramento, CA 95829-2087
Telephone: (916) 381-4791

The G&O Manufacturing Company
100 Gando Drive
P.O. Box 1204
New Haven, CT 06505-1204
Telephone: (203) 562-5121

Young Radiator Company
2825 Four Mile Road
Racine, WI 53404
Telephone: (910) 271-2397

L and M Radiator, Inc.
1414 East 37th Street
Hibbing, MN 55746
Telephone: (218) 263-8993

Throttle Assemblies

Williams Controls, Inc.
14100 SW 72nd Avenue
Portland, OR 97224
Telephone: (503) 684-8600

Torque Converters

Twin Disc International S.A.
Chaussee de Namur
Nivelles
Belgium
Telephone: 067-224941

Twin Disc Incorporated
1328 Racine Street
Racine, WI 53403-1758
Telephone: (414) 634-1981

Rockford Powertrain, Inc.
Off-Highway Systems
1200 Windsor Road
P.O. Box 2908
Rockford, IL 61132-2908
Telephone: (815) 633-7460

Modine Mfg. Co.
1500 DeKoven Avenue
Racine, WI 53401
Telephone: (414) 636-1640

NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Section S - Service Assistance

Section Contents

	Page
Service Assistance	S-1
Distributors - International	S-19
Distributors and Branches - Australia	S-16
Distributors and Branches - Canada	S-14
Distributors and Branches - New Zealand	S-18
Distributors and Branches - United States	S-7
Division and Regional Offices	S-3
Emergency and Technical Service	S-1
Problem Solving	S-2
Regional Offices - International	S-4
Routine Service and Parts	S-1

THIS PAGE LEFT INTENTIONALLY BLANK

Service Assistance

Routine Service and Parts

Personnel at Cummins Authorized Repair Locations can assist you with the correct operation and service of your engine. Cummins has a worldwide service network of more than 5,000 Distributors and Dealers who have been trained to provide sound advice, expert service, and complete parts support. Check the telephone directory yellow pages or refer to the directory in this section for the nearest Cummins Authorized Repair Location.

Emergency and Technical Service

The Cummins Customer Assistance Center provides a 24-hour, toll free telephone number to aid in technical and emergency service when a Cummins Authorized Repair Location can **not** be reached or is unable to resolve an issue with a Cummins product.

If additional assistance is required, call Toll-Free:

1-800-DIESELS
(1-800-343-7357)

- Includes all 50 states, Bermuda, Puerto Rico, Virgin Islands, and the Bahamas.
- Outside of North America contact your Regional Office. Telephone numbers and addresses are listed in the International Directory.



Problem Solving

Normally, any problem that arises with the sale, service, or repair of your engine can be handled by a Cummins Authorized Repair Location in your area. Refer to the telephone directory yellow pages for the one nearest you. If the problem has **not** been handled satisfactorily, follow the steps outlined below:

1. If the disagreement is with a Dealer, talk to the Cummins Distributor with whom he has his service agreement.
2. If the disagreement is with a Distributor, call the nearest Cummins Division or Regional Office; however, most problems are solved below the Division or Regional office level. Telephone numbers and addresses are listed in this section. Before calling, write down the following information:
 - a. Engine model and serial number
 - b. Type and make of equipment
 - c. Total kilometers [miles] or hours of operation
 - d. Warranty start date
 - e. Nature of problem
 - f. Summary of the current problem arranged in the order of occurrence
 - g. Name and location of the Cummins Distributor or Dealer
3. If a problem can **not** be resolved satisfactorily through your Cummins Authorized Repair Location or Division Office, write to:

Cummins Customer Assistance Center - 41403, Cummins Engine Company, Inc., Box 3005, Columbus, IN 47202-3005

Division and Regional Offices

NOTE: The following list contains offices in U.S., Canada, Australia, New Zealand, and Puerto Rico.

United States

Southern Division Office

Cummins Engine Company, Inc.
425 Franklin Road S.W.
Suite 500
Marietta, GA 30067
Telephone: (770) 423-1108
FAX: (770) 499-8240

Plains Regional Office

Cummins Engine Company, Inc.
1901 Central Drive
Suite 356
Bedford, TX 76021
Telephone: (817) 267-3172
FAX: N/A

Canada

Canadian Division Office

Cummins Diesel of Canada, Ltd.
5575 North Service Road
Burlington, Ontario L7R6M1
Telephone: (905) 331-5944
FAX: (905) 331-0276

Western Canada Regional Office

Cummins Diesel of Canada, Ltd.
18452 - 96th Avenue
Surrey, B.C. V3T 4W2
Telephone: (604) 882-5727
FAX: (604) 882-9110

Eastern Canada Regional Office

Cummins Diesel of Canada Ltd.
7200 Trans Canada Hwy.
Pt. Cuaire, Quebec H9R 1C0
Telephone: (514) 695-2402
FAX: (514) 695-8917

Central Canada Regional Office

Cummins Diesel of Canada Ltd.
4887 - 35th Street SE
Calgary, Alberta T2B 3C6
FAX: (403) 569-9974

Australia Regional Office

Cummins Engine Company Pty. Ltd.

2 Caribbean Drive
Scoresby, Victoria 3179
Australia
Telephone: (61-3) 9765-3222
FAX: (61-3) 9763-0079

NOTE: This office also serves New Zealand.

Cummins Americas Regional Office

Cummins Latin America

3088 N. Commence Parkway
MPC #14, Building A
Miramar, FL 33025
Telephone: (305) 621-1300

NOTE: This office serves Puerto Rico and South America excluding Brazil.

Regional Offices - International

North Africa Regional Office - Algiers

Cummins Corporation
Bureau de Liaison
38, Lotissement Benachour Abdelkader
Cheraga
42300 Wilaya de Tipasa
Algeria
Telephone: (213) 2374326

Country
Covered: Algeria

European Regional Office - Mechelen

Cummins Diesel N.V.
Blarenberglaan 4
Industriepark Noord 2
2800 Mechelen
Brussels
Telephone: (32-15) 20003

Countries
Covered: Austria Luxembourg
Belgium Netherlands
Czech Republic Norway
Denmark Portugal
Finland Slovakia
Greece Spain
Hungary Sweden
Iceland Switzerland
Israel

Cumbrasa Regional Office - Brazil

Cummins Brasil S.A.
Rua Jati, 266
07180-900 Guarulhos
Sao Paulo, Brazil
Mailing Address:
P.O. Box 13
07180-900 Guarulhos
Sao Paulo, Brazil
Telephone: (55-11) 945-9811

Country
Covered: Brazil

Beijing Regional Office - China

Cummins Corporation
China World Tower, Suite 917
China World Trade Center
No. 1 Jian Guo Men Wai
Beijing 100004
People's Republic of China
Telephone: (86-1) 505-4209/10

Countries
Covered: China
Mongolia

Bogota Regional Office - Columbia

Cummins Engine Co. de Colombia S.A.
Carrera 11A No. 90-15 Of. 601/602
Bogota, D.E., Colombia
Telephone: (57-1) 610-4849
Mailing Address:
Apartado Aereo 90988
Bogota D.E., Colombia

Countries
Covered: Argentina Ecuador
Bolivia Paraguay
Chile Peru
Colombia Uruguay

Lyon Regional Office - France

Cummins Diesel Sales Corporation
39, rue Ampere - Zone Industrielle
69680 Chassieu
France
Telephone: (33) 72-22-92-72

Countries
Covered: Algeria Martinique
France New Caledonia
Guadeloupe Reunion
Guyana

Gross-Gerau Regional Office - Germany

Cummins Diesel Deutschland GmbH
Odenwaldstr. 23
D-6080 Gross-Gerau
Germany
Telephone: (49-6152) 174-0

Countries
Covered: Albania Poland
Bulgaria Romania
*Czech Southeastern
Republic Europe
Germany Slovakia
Luxembourg

* Marine Only

Hong Kong Regional Office - Hong Kong

Cummins Engine H.K. Ltd.
Unison Industrial Centre
15th Floor, Units C & D
27-31 Au Pui Wan Street
P. O. Box 840 Shatin
Fo Tan, Shatin, N.T.
Hong Kong
Telephone: (852) 606-5678

Country
Covered: Hong Kong

Pune Kirloskar Regional Office - India

Kirloskar Cummins Limited
Kothrud
Pune - 411 029, India
Telephone: (91-212) 33-0240, 33-5435, 33-1105

Countries
Covered: Bhutan
India
Nepal

Milan Regional Office - Italy

Cummins Diesel Italia S.P.A.
Piazza Locatelli 8
Zona Industriale
20098 San Giuliano Milanese
Milan, Italy
Telephone: (39-2) 982-81235/6/7

Country

Covered: Italy

North Asia Regional Office - Japan

Cummins Diesel Sales Corporation
1-12-10 Shintomi
Chuo-ku, Tokyo 104
Japan
Telephone: (81-3) 3555-3131/2/3/4/5

Country

Covered: Japan

Seoul Regional Office - Korea

Cummins Korea Ltd.
5th Floor, Hye Sung Building
35-26 Sam Sung Dong, Kang Nam Ku
Seoul, South Korea
Telephone: (82-2) 516-0431/2/3, 517-3370/1

Country

Covered: South Korea

Cummsa Regional Office - Mexico

Cummins, S.A. de C.V.
Arquimedes No. 209
Col. Polanco
11560 Mexico, D.F.
Mexico
Telephone: (52-5) 254-3822/3783/3622

Mailing/Shipping Address:
Gonzalez de Castilla Inc.
P.O. Box 1391
4605 Modern Lane
Modern Industrial Park
Laredo, TX 78040
Telephone: (512) 722-5207

Country

Covered: Mexico

Moscow Regional Office - Russia

Cummins Engine Co., Inc.
Park Place
Office E708
Leninsky Prospect 113
Russia 11798
Telephone: (7-502) 256-5122 or 256-5123

Countries

Covered:	Armenia	Lithuania
	Azerbaijan	Moldova
	Bolarus	Russia
	Estonia	Tadzhikstan
	Georgia	Turkmenistan
	Kirghizia	Ukraina
	Latvia	Uzbekistan

South And East Asia Area Office - Singapore

Cummins Diesel Sales Corporation
8 Tanjong Penjuru
Jurong Industrial Estate
Singapore 2260
Telephone: (65) 265-0155

Countries

Covered:	Bangladesh	Malaysia
	Brunei	Mongolia
	Burma/Mynamar	Philippines
	Cambodia	Singapore
	China	Sri Lanka
	Hong Kong	Taiwan
	Indonesia	Thailand
	Laos	Vietnam
	Macau	

Taipei Regional Office - Taiwan

Cummins Corporation - Taiwan
12th Floor, No. 149
Min-Sheng E. Road
Section 2
Taipei, Taiwan
R.O.C. 104
Telephone: (886-2) 515-0891

Country

Covered: Taiwan

Turkey and Iran Regional Office - Turkey

Cummins Corporation
Istanbul Office
Buyukdere Cad.
Beytem Han, Kat 11
Sisli 80220
Istanbul
Telephone: (90-1) 246-2575/2775/2545

Countries

Covered: Iran
Turkey

Middle East Regional Office - Daventry (U.K.)

Cummins Engine Company Ltd.
Royal Oak Way South
Daventry, Northants NN11 5NU
England
Telephone: (44-1327) 76000

Countries Covered:

MIDEAST		
Afghanistan	Jordan	Saudi Arabia
Bahrain	Kuwait	Sudan
Cyprus	Lebanon	Syria
Djibouti	Oman	U.A.E.
Egypt	Pakistan	Yemen
Iraq	Qatar	

Africa Regional Office - Daventry (U.K.)

Cummins Engine Company Ltd.
Royal Oak Way South
Daventry, Northants NN11 5NU
England
Telephone: (44-1327) 76000

Countries Covered:

NORTH/WEST AFRICA

Benin	Gabon	Mauritania
Burkina-Paso	Gambia	Morocco
Cameroon	Ghana	Niger
Cape Verde	Guinea	Nigeria
Central African Republic	Guinea-Bissau	Sao Tome & Principe
Chad	Liberia	Senegal
Cote d'Ivoire	Libya	Siera Leone
Equatorial Guinea	Mali	Togo
	Malta	Tunisia

SOUTH AFRICA

Botswana	Namibia	Swaziland
Lesotho	South Africa	

New Malden Regional Office - U.K.

Cummins Engine Company Limited
46-50 Coombe Road
New Malden
Surrey KT3 4QL
England
Telephone: (44-81) 949-6171

Countries

Covered: Ireland
United Kingdom

Latin America Regional Office - Miramar (U.S.A.)

Cummins Americas, Inc.
Miramar Park of Commerce
3450 Executive Way
Miramar, FL 33025
Telephone: (305) 431-5511

Countries

Covered:	Argentina	Guatemala
	Bolivia	Honduras
	Chile	Nicaragua
	Colombia	Panama
	Costa Rica	Paraguay
	Dominican Republic	Peru
	El Salvador	Uruguay
	Ecuador	Venezuela

Caracas Regional Office - Venezuela

Cummins Engine Company
Oficina de Delegado
Torre La Primera, Oficina 5-D
Av. Francisco de Miranda
Chacao, Caracas 1060

Mailing Address:

Cummins Engine Company M-227
c/o Jet Cargo International
P.O. Box 020010
Miami, FL 33102-0010 U.S.A.
Telephone: (58-2) 32-0563, 32-718

Countries

Covered:	Costa Rica	Honduras
	Dominican Republic	Nicaragua
	El Salvador	Panama
	Guatemala	Venezuela

East/Southern Africa Regional Office - Harare, Zimbabwe

Cummins Zimbabwe (Private) Limited
72 Birmingham Road
Southerton
Harare, Zimbabwe

Mailing Address:

P.O. Box ST363
Southerton
Harare, Zimbabwe
Telephone: (263-4) 67645, 60553, 69220

Countries

Covered:	Angola	Reunion
	Burundi	Rwanda
	Comoros Island	Seychelles
	Congo	Somalia
	Ethiopia	Tanzania
	Kenya	Uganda
	Madagascar	Zaire
	Malawi	Zambia
	Mauritius	Zimbabwe
	Mozambique	

Distributors and Branches - United States

Alabama

Birmingham Distributor

Cummins Alabama, Inc.
2200 Pinson Highway
P.O. Box 1147
Birmingham, AL 35201
Telephone: (205) 841-0421
FAX: (205) 849-5926

Mobile Branch

Cummins Alabama, Inc.
1924 N. Beltline Hwy.
Mobile, AL 36601-1598
Telephone: (334) 456-2236
FAX: (334) 452-6419

Mobile Onan/Marine Branch

Cummins Alabama, Inc.
3422 Georgia Pacific Avenue
Mobile, AL 36617
Telephone: (334) 452-6426
FAX: (334) 473-6657

Montgomery Branch

Cummins Alabama, Inc.
2325 West Fairview Avenue
Montgomery, AL 36108
Telephone: (205) 263-2594
FAX: (205) 263-2594

Alaska

Anchorage - (Branch of Seattle)

Cummins Northwest, Inc.
2618 Commercial Drive
Anchorage, AK 99501-3095
Telephone: (907) 279-7594
FAX: (907) 276-6340

Arizona

Phoenix Distributor and Branch

Cummins Southwest, Inc.
2239 N. Black Canyon Hgwy
Phoenix, AZ 85009
Telephone: (602) 252-8021
FAX: (602) 253-6725

Tucson Branch

Cummins Southwest, Inc.
1912 West Prince Road
Tucson, AZ 85705
Telephone: (520) 887-7440
FAX: (520) 887-4173

Arkansas

Little Rock - (Branch of Memphis)

Cummins Mid-South, Inc.
6600 Interstate 30
Little Rock, AR 72209
Telephone:
Sales: (501) 569-5600
Service: (501) 569-5656
Parts: (501) 569-5613
FAX: (501) 565-2199

California

San Leandro Distributor

Cummins West, Inc.
14775 Wicks Blvd.
San Leandro, CA 94577-6779
Telephone: (510) 351-6101
FAX: (510) 352-3925

Arcata Branch

Cummins West, Inc.
4801 West End Road
Arcata, CA 95521
Telephone: (707) 822-7392
FAX: (707) 822-7585

Bakersfield Branch

Cummins West, Inc.
4601 East Brundage Lane
Bakersfield, CA 93307
Telephone: (805) 325-9404
FAX: (805) 861-8719

Fresno Branch

Cummins West, Inc.
2740 Church Avenue
Fresno, CA 93706
Telephone: (209) 495-4745
FAX: (209) 486-7402

Redding Branch

Cummins West, Inc.
20247 Charianne Drive
Redding, CA 96001
Telephone: (916) 222-4070
FAX: (916) 224-4075

Stockton Branch

Cummins West, Inc.
41 West Yokuts Avenue
Suite 131
Stockton, CA 95207
Telephone: (209) 473-0386
FAX: (209) 478-2454

West Sacramento Branch

Cummins West, Inc.
2661 Evergreen Avenue
West Sacramento, CA 95691
Telephone: (916) 371-0630
FAX: (916) 371-2849

Los Angeles Distributor

Cummins Cal Pacific Inc.
1939 Deere Avenue (Irvine)
Irvine, CA 92606
Telephone: (949) 253-6000
FAX: (949) 253-6080

Montebello Branch

Cummins Cal Pacific Inc.
1105 South Greenwood Avenue
Montebello, CA 90640
Telephone: (323) 728-8111
FAX: (323) 889-7422

Bloomington Branch

Cummins Cal Pacific Inc.
3061 S. Riverside Avenue
Bloomington, CA 92377
Telephone: (909) 877-0433
FAX: (909) 877-3787

San Diego Branch

Cummins Cal Pacific Inc.
310 N. Johnson Avenue
El Cajon, CA 92020
Telephone: (619) 593-3093
FAX: (619) 593-0600

Ventura Branch

Cummins Cal-Pacific Inc.
3958 Transport St.
Ventura, CA 93003
Telephone: (805) 644-7281
FAX: (805) 644-7284

Colorado

Denver Distributor

Cummins Rocky Mountain, Inc.
5100 East 58th Avenue
Commerce City, CO 80022
Telephone: (303) 287-0201
FAX: (303) 288-7080

Denver Onan/Industrial Branch

Cummins Rocky Mountain, Inc.
5100 East 58th Ave.
Commerce City, CO 80022
Telephone: (303) 286-7697
FAX: (303) 287-4837

Durango Branch

Cummins Rocky Mountain, Inc.
13595 County Road 213
Durango, CO 81301
Telephone: (970) 259-7470
FAX: (970) 259-7482

Grand Junction Branch

Cummins Rocky Mountain, Inc.
2380 U.S. Highway 6 & 50
P.O. Box 339
Grand Junction, CO 81501
Telephone: (303) 242-5776
FAX: (303) 243-5495

Connecticut

Rocky Hill - (Branch of Bronx)

Cummins Metropower, Inc.
914 Cromwell Ave.
Rocky Hill, CT 06067
Telephone: (860) 529-7474
FAX: (860) 529-7524

Florida

Tampa Distributor

Cummins Southeastern Power, Inc.
Corporate Office
5421 N. 59th Street
Tampa, FL 33610
Telephone: (813) 621-7202
FAX: (813) 621-8250

Ft. Myers Branch

Cummins Southeastern Power, Inc.
2671 Edison Avenue
Ft. Myers, FL 33902
Telephone: (941) 337-1211
FAX: (941) 337-5374

Jacksonville Branch

Cummins Southeastern Power, Inc.
755 Pickettville Rd.
Jacksonville, FL 32220
Telephone: (904) 378-1902
FAX: (904) 378-1904

Hialeah (Miami) Branch

Cummins Southeastern Power, Inc.
9900 N.W. 77th Avenue
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200
FAX: (305) 557-2992

Ocala Branch

Cummins Southeastern Power
321 Southwest 52nd Ave.
Ocala, FL 34474-1892
Telephone: (352) 861-1122
FAX: (352) 861-1130

Orlando Branch

Cummins Southeastern Power, Inc.
4020 North
Orange Blossom Trail
Orlando, FL 32810
Telephone: (407) 298-2080
FAX: (407) 290-8727

Tampa Branch

Cummins Southeastern Power, Inc.
5912 E. Hillsborough Avenue
Tampa, FL 33610
Telephone: (813) 626-1101
FAX: (813) 628-4183

Georgia

Atlanta Distributor

Cummins South, Inc.
5125 Georgia Highway 85
College Park, GA 30349
Telephone: (404) 763-0151
FAX: (404) 766-2132

Albany Branch

Cummins South, Inc.
1915 W. Oakridge Drive
Albany, GA 31707-4938
Telephone: (912) 888-6210
FAX: (912) 883-1670

Atlanta Branch

Cummins South, Inc.
100 University Avenue, S.W.
Atlanta, GA 30315-2202
Telephone: (404) 527-7800
FAX: (404) 527-7832

Augusta Branch

Cummins South, Inc.
1255 New Savannah Road
Augusta, GA 30901-3891
Telephone: (706) 722-8825
FAX: (706) 722-7553

Savannah Branch

Cummins South, Inc.
8 Interchange Court
Savannah, GA 31401-1627
Telephone: (912) 232-5565
FAX: (912) 232-5145

Hawaii

Kapolei Distributor

Cummins Hawaii Diesel Power, Inc.
91-230 Kalaeloa Blvd.
Kapolei, HI 96707
Telephone: (808) 682-8110
FAX: (808) 682-8477

Idaho

Boise - (Branch of Salt Lake City)

Cummins Intermountain, Inc.
2851 Federal Way City
Boise, ID 83705
Telephone: (208) 336-5000
FAX: (208) 338-5436

Pocatello - (Branch of Salt Lake City)

Cummins Intermountain, Inc.
14299 Highway 30 West
Pocatello, ID 83201
Telephone: (208) 234-1661
FAX: (208) 234-1662

Illinois

Chicago Distributor

Cummins Northern Illinois, Inc.
7145 Santa Fe Drive
Hodgkins, IL 60525
Telephone: (708) 579-9222
FAX: (708) 352-7547

Bloomington-Normal - (Branch of Indianapolis)

Cummins Mid-States Power, Inc.
(at U.S. 51 N and I-55)
414 W. Northtown Road
Bloomington-Normal, IL 61761
Telephone: (309) 452-4454
FAX: (309) 452-1642

Onan Branch

Cummins/Onan Northern Illinois
8745 W. 82nd Place
Justin, IL 60458
Telephone: (708) 563-7070
FAX: (708) 563-7095

Harrisburg (Branch of St. Louis)

Cummins Gateway, Inc.
Highway 45 North
Harrisburg, IL 62946
Telephone: (618) 273-4138
FAX: (618) 273-4531

Rock Island - (Branch of Omaha)

Cummins Great Plains Diesel, Inc.
7820 - 42nd Street West
Rock Island, IL 61204
Telephone: (309) 787-4300
FAX: (309) 787-4397

Onan Branch

Cummins Gateway, Inc.
#1 Extra Mile Drive
Collinsville, IL 62234
Telephone: (618) 345-0123
FAX: (314) 531-6604

Indiana

Indianapolis Distributor

Cummins Mid-States Power, Inc.
P.O. Box 42917
3762 West Morris Street
Indianapolis, IN 46242-0917
Telephone: (317) 243-7979
FAX: (317) 240-1925

Evansville - (Branch of Louisville)

Cummins Cumberland, Inc.
7901 Highway 41 North
Evansville, IN 47711
Telephone: (812) 867-4400
FAX: (812) 421-3282

Ft. Wayne Branch

Cummins Mid-States Power, Inc.
3415 Coliseum Blvd. West
(At Jct. I-69 & 30/33)
Ft. Wayne, IN 46808
Telephone: (219) 482-3691
FAX: (219) 484-8930

Gary - (Branch of Chicago)

Cummins Northern Illinois, Inc.
1440 Texas Street
Gary, IN 46402
Telephone: (219) 885-5591
FAX: (219) 883-4817

Indianapolis Branch

Cummins Mid-States Power, Inc.
P. O. Box 42917
3621 West Morris Street
Indianapolis, IN 46242-0917
Telephone: (317) 244-7251
FAX: (317) 240-1215

Onan Branch

Mid-States Power, Inc.
4301 W. Morris Street
P.O. Box 42917
Indianapolis, IN 46240-0917
Telephone: (317) 240-1967
FAX: (317) 240-1975

Iowa

Cedar Rapids - (Branch of Omaha)

Cummins Great Plains Diesel, Inc.
625 - 33rd Avenue SW
Cedar Rapids, IA 52406
Telephone: (319) 366-7537 (24 hours)
FAX: (319) 366-7562

Des Moines - (Branch of Omaha)

Cummins Great Plains Diesel, Inc.
1680 N.E. 51st Avenue
P.O. Box B
Des Moines, IA 50313
Telephone: (515) 262-9591
Parts: (515) 262-9744
FAX: (515) 262-0626

Des Moines - (Branch of Omaha)

Midwestern Power Products
Division of Cummins Great Plains Diesel, Inc.
5194 N.E. 17th Street
Des Moines, IA 50313
Telephone: (515) 264-1650
FAX: (515) 264-1651

Kansas

Colby - (Branch of Kansas City, Missouri)

Cummins Mid-America, LLC.
1880 South Range
Colby, KS 67701
Telephone: (785) 462-3945
FAX: (785) 462-3970

Garden City - (Branch of Kansas City, Missouri)

Cummins Mid-America, Inc.
1285 Acraway
Garden City, KS 67846
Telephone: (316) 275-2277
FAX: (316) 275-2533

Wichita - (Branch of Kansas City, Missouri)

Cummins Mid-America, Inc.
5101 North Broadway
Wichita, KS 67201
Telephone: (316) 838-0875
FAX: (316) 838-0704

Kentucky

Louisville Distributor

Cummins Cumberland, Inc.
(Corporate Office)
2301 Nelsonville Parkway
Louisville, KY 40223
Telephone: (502) 254-3363
FAX: (502) 254-9272

Hazard Branch

Cummins Cumberland, Inc.
Highway 15 South
P.O. Box 510
Hazard, KY 41701
Telephone: (606) 436-5718
FAX: (606) 436-5038

Louisville Branch

Cummins Cumberland, Inc.
9820 Bluegrass Parkway
Louisville, KY 40299
Telephone: (502) 491-4263
FAX: (502) 499-0896

Louisiana

Morgan City - (Branch of Memphis)

Cummins Mid-South, Inc.
Hwy. 90 East
P.O. Box 1229
Amelia, LA 70340
Telephone: (504) 631-0576
FAX: (504) 631-0081

New Orleans - (Branch of Memphis)

Cummins Mid-South, Inc.
110 E. Airline Highway
Kenner, LA 70062
Telephone: (504) 468-3535
FAX: (504) 465-3408

Maine

Bangor (Branch of Boston)

Cummins Northeast, Inc.
221 Hammond Street
Bangor, ME 04401
Telephone: (207) 941-1061
FAX: (207) 945-3170

Scarborough - (Branch of Boston)

Cummins Northeast, Inc.
10 Gibson Road
Scarborough, ME 04074
Telephone: (207) 883-8155
FAX: (207) 883-5526

Maryland

Baltimore Distributor

Cummins Power Systems, Inc.
1907 Parkwood Drive
MD 21061
Telephone: (410) 590-8700
FAX: (410) 590-8723

Massachusetts

Boston Distributor

Cummins Northeast, Inc.
100 Allied Drive
Dedham, MA 02026
Telephone: (781) 329-1750
FAX: (781) 329-4428

Springfield Branch

Cummins Northeast, Inc.
177 Rocus Street
Springfield, MA 01104
Telephone: (413) 737-2659
FAX: (413) 731-1082

Mexico

Tijuana - (Branch of Los Angeles)

Distribuidora Cummins De Baja
Blvd. 3ra. Oeste No. 17523
Fracc. Industrial
Garita de Otay C.P. 22400
Tijuana, Baja California
Mexico
Telephone: 011-52-66-238433
FAX: 011-52-66-238649

Michigan

Detroit (Novi) Distributor

Cummins Michigan, Inc.
41216 Vincent Court
Novi, MI 48375
Telephone: (248) 478-9700
FAX: (248) 478-1570

Blissfield, Michigan

Diesel Fuel Systems, Inc.
Subsidiary of Cummins Michigan Inc.
211 N. Jipson Street
Blissfield, MI 49228
Telephone: (517) 486-4324
FAX: (517) 486-3614

Dearborn Branch

Cummins Michigan, Inc.
3760 Wyoming Avenue
Dearborn, MI 48120
Telephone: (313) 843-6200
FAX: (313) 843-6070

Grand Rapids Branch

Cummins Michigan, Inc.
3715 Clay Avenue, S.W.
Grand Rapids, MI 49508
Telephone: (616) 538-2250
FAX: (616) 538-3830

Grand Rapids Branch

Standby Power, Inc.
7580 Expressway Drive S.W.
Grand Rapids, MI 49548
Telephone: (616) 281-2211
FAX: (616) 281-3177

Iron Mountain - (Branch of De Pere)

Cummins Great Lakes, Inc.
1901 Stevenson Avenue
Iron Mountain, MI 49801
Telephone: (906) 774-2424
(800) 236-2424
FAX: (906) 774-1190

Novi Branch

Cummins Michigan, Inc.
25100 Novi Road
Novi, MI 48375
Telephone: (248) 380-4300
FAX: (248) 380-0910

Power Products (Branch of Detroit)

Cummins Michigan, Inc.
41326 Vincent Ct.
Novi, MI 48375
Telephone: (248) 426-9300
FAX: (248) 473-8560

Saginaw Branch

Cummins Michigan, Inc.
722 N. Outer Drive
Saginaw, MI 48605
Telephone: (517) 752-5200
FAX: (517) 752-4194

Standby Power - (Branch of Detroit)

Cummins Michigan, Inc.
12130 Dixie
Redford, MI 48239
Telephone: (313) 538-0200
FAX: (313) 538-3966

Minnesota

St. Paul Distributor

Cummins North Central, Inc.
3030 Centre Pointe Drive
Suite 500
Roseville, MN 55113
Telephone: (651) 636-1000
FAX: (651) 638-2442

Duluth Branch

Cummins Diesel Sales, Inc.
3115 Truck Center Drive
Duluth, MN 55806-1786
Telephone: (218) 628-3641
FAX: (218) 628-0488

St. Paul Branch

Cummins North Central, Inc.
2690 Cleveland Ave. North
St. Paul, MN 55113
Telephone: (651) 636-1000
FAX: (651) 638-2497

Mississippi

Jackson - (Branch of Memphis)

Cummins Mid-South, Inc.
325 New Highway 49 South
Jackson, MS 39288-4224
Telephone:
Admin.: (601) 932-7016
Parts: (601) 932-2720
Service: (601) 939-1800
FAX: (601) 932-7399

Missouri

Kansas City Distributor and Branch

Cummins Mid-America, Inc.
8201 NE Parvin Road
Kansas City, MO 64161
Telephone: (816) 414-8200
FAX: (816) 414-8299

Joplin Branch

Cummins Mid-America, Inc.
3507 East 20th Street
Joplin, MO 64801
Telephone: (417) 623-1661
FAX: (417) 623-1817

Springfield Branch

Cummins Mid-America, Inc.
3637 East Kearney
Springfield, MO 65803
Telephone: (417) 862-0777
FAX: (417) 862-4429

St. Louis Distributor

Cummins Gateway, Inc.
7210 Hall Street
St. Louis, MO 63147
Telephone: (314) 389-5400
FAX: (314) 389-9671

Columbia Branch

Cummins Gateway, Inc.
5221 Highway 763 North
Columbia, MO 65202
Telephone: (314) 449-3711
FAX: (314) 449-3712

Sikeston Branch

Cummins Gateway, Inc.
101 Keystone Drive
Sikeston, MO 63801
Telephone: (314) 472-0303
FAX: (314) 472-0306

Industrial Power Branch

Cummins Gateway, Inc.
3256 E. Outer Road
Scott City, MO 63788
Telephone: (573) 335-9399
FAX: (573) 335-7062

Montana

Billings - (Branch of Denver)

Cummins Rocky Mountain, Inc.
5151 Midland Road
Billings, MT 59101
Telephone: (406) 245-4194
FAX: (406) 245-7923

Great Falls - (Branch of Denver)

Cummins Rocky Mountain, Inc.
415 Vaughn Road
Great Falls, MT 59404
Telephone: (406) 452-8561
FAX: (406) 452-9911

Missoula - (Branch of Seattle)

Cummins Northwest, Inc.
4950 North Reserve Street
Missoula, MT 59802-1498
Telephone: (406) 728-1300
FAX: (406) 728-8523

Nebraska

Omaha Distributor and Branch

Cummins Great Plains Diesel, Inc.
5515 Center Street
P.O. Box 6068
Omaha, NE 68106
Telephone: (402) 551-7678 (24 Hours)
FAX: (402) 551-1952

Kearney Branch

Cummins Great Plains Diesel, Inc.
515 Central Avenue
Kearney, NE 68847
Telephone: (308) 234-1994
FAX: (308) 234-5776

Nevada

Elko - (Branch of Salt Lake City)

Cummins Intermountain, Inc.
5370 East Idaho Street
Elko, NV 89801
Telephone: (775) 738-6405
FAX: (775) 738-1719

Las Vegas - (Branch of Salt Lake City)

Cummins Intermountain, Inc.
2750 Losee Road
North Las Vegas, NV 89030
Telephone: (702) 399-2339
FAX: (702) 399-7457

Sparks - (Branch of Salt Lake City)

Cummins Intermountain, Inc.
150 Glendale Avenue
Sparks, NV 89431
Telephone: (775) 331-4983
FAX: (775) 331-7429

New Jersey

Newark - (Branch of Bronx)

Cummins Metropower, Inc.
41-85 Doremus Ave.
Newark, NJ 07105
Telephone: (973) 491-0100
FAX: (973) 578-8873

New Mexico

Albuquerque - (Branch of Phoenix)

Cummins Southwest, Inc.
1921 Broadway N.E.
Albuquerque, NM 87102
Telephone: (505) 247-2441
FAX: (505) 842-0436

Farmington - (Branch of Phoenix)

Cummins Southwest, Inc.
1101 North Troy King Road
Farmington, NM 87401
Telephone: (505) 327-7331
FAX: (505) 326-2948

New York

Bronx Distributor

Cummins Metropower, Inc.
890 Zerega Avenue
Bronx, NY 10473
Telephone: (718) 892-2400
FAX: (718) 892-0055

Albany - (Branch of Boston)

Cummins Northeast, Inc.
101 Railroad Avenue
Albany, NY 12205
Telephone: (518) 459-1710
FAX: (518) 459-7815

Buffalo - (Branch of Boston)

Cummins Northeast, Inc.
480 Lawrence Bell Dr.
Williamsville, NY 14221-7090
Telephone: (716) 631-3211
FAX: (716) 626-0799

Syracuse - (Branch of Boston)

Cummins Northeast, Inc.
29 Eastern Avenue
Syracuse, NY 13211
Telephone: (315) 437-2751
FAX: (315) 437-8141

North Carolina

Charlotte Distributor

Cummins Atlantic, Inc.
11101 Nations Ford Road (28273)
P.O. Box 240729
Charlotte, NC 28224-0729
Telephone: (704) 588-1240
FAX: (704) 587-4870

Charlotte Branch

Cummins Atlantic, Inc.
3700 North Interstate 85
Charlotte, NC 28206
Telephone: (704) 596-7690
FAX: (704) 596-3038

Greensboro Branch

Cummins Atlantic, Inc.
513 Preddy Boulevard (27406)
P.O. Box 22066
Greensboro, NC 27420-2066
Telephone: (336) 275-4531
FAX: (336) 275-8304

Wilson Branch

Cummins Atlantic, Inc.
1514 Cargill Avenue (27893)
P.O. Box 1177
Wilson, NC 27894-1177
Telephone: (252) 237-9111
FAX: (252) 237-9132

North Dakota

Fargo - (Branch of St. Paul)

Cummins North Central, Inc.
3801 - 34th Ave. SW
Fargo, ND 58104
Telephone: (701) 282-2466
FAX: (701) 277-5399

Grand Forks - (Branch of St. Paul)

Cummins North Central, Inc.
4728 Gateway Drive
Grand Forks, ND 58201
Telephone: (701) 775-8197
FAX: (701) 775-4833

Minot - (Branch of St. Paul)

Cummins North Central, Inc.
1501 - 20th Avenue, S.E.
Minot, ND 58702
Telephone: (701) 852-3585
FAX: (701) 852-3588

Ohio

Columbus Distributor and Branch

Cummins Interstate Power, Inc.
4000 Lyman Drive
Hilliard (Columbus), OH 43026
Telephone: (614) 771-1000
FAX: (614) 771-0769

Columbus Distributor

Cummins Interstate Power, Inc.
2297 Southwest Blvd., Suite K
Grove City, OH 43123
Telephone: (614) 771-1000
FAX: (614) 527-2576

Cincinnati Branch

Cummins Interstate Power, Inc.
10470 Evendale Drive
Cincinnati, OH 45241
Telephone: (513) 563-6670
FAX: (513) 563-0594

Cleveland Branch

Cummins Interstate Power, Inc.
7585 Northfield Road
Cleveland, OH 44146
Telephone: (440) 439-6800
FAX: (440) 439-7390

Strasburg Branch

Cummins Interstate Power, Inc.
777 South Wooster Avenue
Strasburg, OH 44680
Telephone: (216) 878-5511
FAX: (216) 878-7666

Toledo Branch

Cummins Interstate Power, Inc.
801 Illinois Avenue
Maumee
(Toledo), OH 43537
Telephone: (419) 893-8711
FAX: (419) 893-5362

Youngstown Branch

Cummins Interstate Power, Inc.
7145 Masury Road
Hubbard
(Youngstown), OH 44425
Telephone: (216) 534-1935
FAX: (216) 534-5606

Oklahoma

Oklahoma City - (Branch of Arlington)

Cummins Southern Plains, Inc.
5800 West Reno
Oklahoma City, OK 73127
Telephone: (405) 946-4481 (24 hours)
FAX: (405) 946-3336

Tulsa - (Branch of Arlington)

Cummins Southern Plains, Inc.
16525 East Skelly Drive
Tulsa, OK 74116
Telephone: (918) 234-3240
FAX: (918) 234-2342

Oregon

Bend - (Branch of Seattle)

Cummins Northwest, Inc.
3500 N. Highway 97 (97701-5729)
P.O. Box 309
Bend, OR 97709-0309
Telephone: (541) 389-1900
FAX: (541) 389-1909

Coburg/Eugene - (Branch of Seattle)

Cummins Northwest, Inc.
91201 Industrial Parkway
Coburg, OR 97401
(Mailing Address)
P.O. Box 10877
Eugene, OR 97440-2887
Telephone: (541) 687-0000
FAX: (541) 687-1977

Medford - (Branch of Seattle)

Cummins Northwest, Inc.
4045 Crater Lake Highway
Medford, OR 97504-9796
Telephone: (541) 779-0151
FAX: (541) 772-2395

Pendleton - (Branch of Seattle)

Cummins Northwest, Inc.
223 S.W. 23rd Street
Pendleton, OR 97801-1810
Telephone: (541) 276-2561
FAX: (541) 276-2564

Portland - (Branch of Seattle)

Cummins Northwest, Inc.
4711 N. Basin Avenue
P. O. Box 2710 (97208-2710)
Portland, OR 97217-3557
Telephone: (503) 289-0900
FAX: (503) 286-5938

Pennsylvania

Philadelphia Distributor

Cummins Power Systems, Inc.
2727 Ford Road
Bristol, PA 19007
Telephone: (215) 785-6005 and
(609) 563-0005
FAX: (215) 785-4085

Bristol Branch

Cummins Power Systems, Inc.
2727 Ford Road
Bristol, PA 19007
Telephone: (215) 785-6005 and
(609) 563-0005
FAX: (215) 785-4728

Pittsburgh Branch

Cummins Power Systems, Inc.
3 Alpha Drive
Pittsburgh, PA 15238-2901
Telephone: (412) 820-8300
FAX: (412) 820-8308

Harrisburg Branch

Cummins Power Systems, Inc.
4499 Lewis Road
Harrisburg, PA 17111-2541
Telephone: (717) 564-1344
FAX: (717) 558-8217

Puerto Rico

Puerto Nuevo - (Branch of Tampa)

Cummins Diesel Power, Inc.
#31 Calle "C"
El Matadero
Puerto Nuevo, Puerto Rico 00920
Telephone: (787) 793-0300
FAX: (787) 793-1072

South Carolina

Charleston - (Branch of Charlotte)

Cummins Atlantic, Inc.
3028 West Montague Avenue
Charleston, SC 29418-5593
Telephone: (843) 554-5112
FAX: (843) 745-0745

Charleston - (Branch of Charlotte)

Cummins Atlantic Inc.
231 Farmington Road
Charleston, SC 29483
Telephone: (843) 851-9819
FAX: (843) 875-4338

Columbia - (Branch of Charlotte)

Cummins Atlantic, Inc.
1233 Bluff Road (29201)
P.O. Box 13543
Columbia, SC 29201-3543
Telephone: (803) 799-2410
FAX: (803) 779-3427

South Dakota

Sioux Falls - (Branch of Omaha)

Cummins Great Plains Diesel, Inc.
701 East 54th Street North
Sioux Falls, SD 57104
Telephone: (605) 336-1715
FAX: (605) 336-1748

Tennessee

Memphis Distributor & Distribution Center

Cummins Mid-South, Inc.
666 Riverside Drive
Memphis, TN 38703
Telephone: (901) 577-0666
FAX: (901) 522-8758

Chattanooga - (Branch of Atlanta)

Cummins South, Inc.
1509 East 26th Street
Chattanooga, TN 37407-1095
Telephone: (615) 629-1447
FAX: (615) 629-1494

Knoxville - (Branch of Louisville)

Cummins Cumberland, Inc.
1211 Ault Road
Knoxville, TN 37914
Telephone: (423) 523-0446
FAX: (423) 523-0343

Memphis Branch

Cummins Mid-South, Inc.
1784 E. Brooks Road
Memphis, TN 38116
Telephone:
Sales/Admin.: (901) 345-7424
Parts: (901) 345-1784
Service: (901) 345-6185
FAX: (901) 346-4735

Nashville - (Branch of Louisville)

Cummins Cumberland, Inc.
706 Spence Lane
Nashville, TN 37217
Telephone: (615) 366-4341
FAX: (615) 366-5693

Texas

Arlington Distributor

Cummins Southern Plains, Inc.
600 N Watson Road
Arlington, TX 76004-3027
Telephone: (817) 640-6801
FAX: (817) 640-6852

Amarillo Branch

Cummins Southern Plains, Inc.
5224 Interstate 40 -
Expressway East
P.O. Box 31570
Amarillo, TX 79120-1570
Telephone: (806) 373-3793 (24 hours)
FAX: (806) 372-8547

Dallas Branch

Cummins Southern Plains, Inc.
3707 Irving Boulevard
Dallas, TX 75247
Telephone: (214) 631-6400 (24 hours)
FAX: (214) 631-2322

El Paso - (Branch of Phoenix)

Cummins Southwest, Inc.
14333 Gateway West
El Paso, TX 79927
Telephone: (915) 852-4200
FAX: (915) 852-3295

Fort Worth Branch

Cummins Southern Plains, Inc.
3250 North Freeway
Fort Worth, TX 76111
Telephone: (817) 624-2107 (24 hours)
FAX: (817) 624-3296

Houston Branch

Cummins Southern Plains, Inc.
4750 Homestead Road
P.O. Box 1367
Houston, TX 77251-1367
Telephone: (713) 675-7421 (24 hours)
FAX: (713) 675-1515

Mesquite Branch

Cummins Southern Plains, Inc.
2615 Big Town Blvd.
Mesquite, TX 75150
Telephone: (214) 321-5555 (24 hours)
FAX: (214) 328-2732

Odessa Branch

Cummins Southern Plains, Inc.
1210 South Grandview
P.O. Box 633
Odessa, TX 79760-0633
Telephone: (915) 332-9121 (24 hours)
FAX: (915) 333-4655

San Antonio Branch

Cummins Southern Plains, Inc.
6226 Pan Am Expressway North
P.O. Box 18385
San Antonio, TX 78218-0385
Telephone: (512) 655-5420 (24 hours)
FAX: (512) 655-3865

Houston Onan Branch

Southern Plains Power
A Division of Cummins Southern Plains
1155 West Loop North
Houston, TX 77055
Telephone: (713) 956-0020
FAX: (713) 956-0266

Utah

Salt Lake City Distributor

Cummins Intermountain, Inc.
1030 South 300 West
Salt Lake City, UT 84101
Telephone: (801) 355-6500
FAX: (801) 524-1351

Vernal Branch

Cummins Intermountain, Inc.
1435 East 335 South
Vernal, UT 84078
Telephone: (435) 789-5732
FAX: (435) 789-2853

Virginia

Cloverdale - (Branch of Charlotte)

Cummins Atlantic, Inc.
263 Simmons Drive
Cloverdale, VA 24077
Telephone: (540) 966-3169
FAX: (540) 966-3749

Richmond - (Branch of Charlotte)

Cummins Atlantic, Inc.
3900 Deepwater Terminal Road
Richmond, VA 23234
Telephone: (804) 232-7891
FAX: (804) 232-7428

Tidewater - (Branch of Charlotte)

Cummins Atlantic, Inc.
Atlantic Power Generation
3729 Holland Blvd.
Chesapeake, VA 23323
Telephone: (757) 485-4848
FAX: (757) 485-5085

Washington

Seattle Distributor

Cummins Northwest, Inc.
811 S.W. Grady Way (98055-2944)
P.O. Box 9811
Renton, WA 98057-9811
Telephone: (425) 235-3400
FAX: (425) 235-8202

Chehalis Branch

Cummins Northwest, Inc.
926 N.W. Maryland
Chehalis, WA 98532-0339
Telephone: (360) 748-8841
FAX: (360) 748-8843

Spokane Branch

Cummins Northwest, Inc.
11134 W. Westbow Blvd.
Spokane, WA 99204
Telephone: (509) 455-4411
FAX: (509) 624-4681

Tacoma Branch

Cummins Northwest, Inc.
3701 Pacific Highway East
Tacoma, WA 98424-1135
Telephone: (253) 922-2191
FAX: (253) 922-2379

Yakima Branch

Cummins Northwest, Inc.
1905 East Central Avenue (98901-3609)
P.O. Box 9129
Yakima, WA 98909-0129
Telephone: (509) 248-9033
FAX: (509) 248-9035

West Virginia

Charleston - (Branch of Louisville)

Cummins Cumberland, Inc.
3100 MacCorkle Ave. SW
P.O. Box 8456
South Charleston, WV 25303
Telephone: (304) 744-6373
FAX: (304) 744-8605

Fairmont - (Branch of Louisville)

Cummins Cumberland, Inc.
South Fairmount Exit, I-79
145 Middletown Road
Fairmont, WV 26554
Telephone: (304) 367-0196
FAX: (304) 367-1077

Wisconsin

DePere Distributor

Cummins Great Lakes, Inc.
Corporate Office
875 Lawrence Drive
P.O. Box 5070
DePere, WI 54115-5070
Telephone: (920) 337-1991
FAX: (920) 337-9746

Chippewa Falls Branch

Cummins Great Lakes, Inc.
2030 St. Highway 53
Chippewa Falls, WI 54729
Telephone: (715) 720-0680
FAX: (715) 720-0685

DePere Branch

Cummins Great Lakes, Inc.
939 Lawrence Drive
P. O. Box 5070
DePere, WI 54115-5070
Telephone: (920) 336-9631
(800) 236-1191
FAX: (920) 336-8984

Milwaukee Branch

Cummins Great Lakes, Inc.
9401 South 13th Street
P.O. Box D
Oak Creek, WI 53154
Telephone: (414) 768-7400
(800) 472-8283
FAX: (414) 768-9441

Wausau Branch

Cummins Great Lakes, Inc.
4703 Rib Mountain Drive
Wausau, WI 54401
Telephone: (715) 359-6888
(800) 236-3744
FAX: (715) 359-3744

Wyoming

Gillette - (Branch of Denver)

Cummins Rocky Mountain, Inc.
2700 Hwy. 14 & 16 North
P.O. Box 1207 (82717)
Gillette, WY 82716
Telephone: (307) 682-9611
FAX: (307) 682-8242

Rock Springs - (Branch of Salt Lake City)

Cummins Intermountain, Inc.
2000 Foothill Blvd.
P.O. Box 1634
Rock Springs, WY 82901
Telephone: (307) 362-5168
FAX: (307) 362-5171

Distributors and Branches - Canada

Alberta

Edmonton Distributor and Branch

Cummins Alberta
11751 - 181 Street
Edmonton, AB T5S 2K5
Telephone: (780) 455-2151
FAX: (780) 454-9512

Calgary Branch

Cummins Alberta
4887 - 35th Street S.E.
Calgary, Alberta T2B 3H6, Canada
Telephone: (403) 569-1122
FAX: (403) 569-0027

Grande Prairie

Cummins Alberta - Grande Prairie
RR2, Site 9, Box 22
Sexsmith, AB CN T0H 3C0
Telephone: (780) 568-3359
FAX: (780) 568-2263

Hinton Branch

Cummins Alberta
135 Veats Avenue
Hinton, Alberta T7V 1S8, Canada
Telephone: (780) 865-5111
FAX: (780) 865-5714

Lethbridge Branch

Cummins Alberta
240 - 24th Street North
Lethbridge, Alberta T1H 3T8, Canada
Telephone: (403) 329-6144
FAX: (403) 320-5383

British Columbia

Vancouver Distributor

Cummins British Columbia
18452 - 96th Avenue
Surrey, B.C., Canada
V4N 3P8
Telephone: (604) 882-5000
FAX: (604) 882-5080

Kamloops Branch

Cummins British Columbia
976 Laval Crescent
Kamloops, B.C. Canada V2C 5P5
Telephone: (250) 828-2388
FAX: (250) 828-6713

Prince George Branch

Cummins British Columbia
102- 3851- 18th Avenue
Prince George, B.C. V2N 1B1
Telephone: (250) 564-9111
FAX: (250) 564-5853

Sparwood Branch

Cummins British Columbia
731 Douglas Fir Road
Sparwood, B.C. VOB 2G0, Canada
Telephone: (250) 425-0522
FAX: (250) 425-0323

Tumbler Ridge Branch

Cummins British Columbia
Industrial Site, Box 226
Tumbler Ridge, B.C.
Canada VOC 2W0
Telephone: (250) 242-4217
FAX: (250) 242-4906

Manitoba

Winnipeg Distributor

Cummins Mid-Canada Ltd.
489 Oak Point Road
P.O. Box 1860
Winnipeg, MB R3C 3R1, Canada
Telephone: (204) 632-5470
FAX: (204) 697-0267

New Brunswick

Fredericton - (Branch of Montreal)

Cummins Eastern Canada, Inc.
R.R.#1 Doak Road
P.O. Box 1178, Station 'A'
Fredericton,
New Brunswick E3B 4X2, Canada
Telephone: (506) 451-1929
FAX: (506) 451-1921

Newfoundland

St. John's - (Branch of Montreal)

Cummins Eastern Canada, Inc.
122 Clyde Avenue
Donovans Industrial Park
Mount Pearl, Newfoundland A1N 2C2
Canada
Telephone: (709) 747-0176
FAX: (709) 747-2283

Wabush - (Branch of Montreal)

Cummins Eastern Canada, Inc.
Wabush Industrial Park
Wabush, Newfoundland A0R 1B0
Telephone: (709) 282-3626
FAX: (709) 282-3108

Nova Scotia

Halifax - (Branch of Montreal)

Cummins Eastern Canada, Inc.
50 Simmonds Drive
Dartmouth, Nova Scotia B3B 1R3
Telephone: (902) 468-7938
FAX: (902) 468-5177
Parts: (902) 468-6560

Ontario

Toronto Distributor

Cummins Ontario, Inc.
7175 Pacific Circle
Mississauga, ON L5T 2A5
Telephone: (905) 795-0050
FAX: (905) 795-0021

Kenora - (Branch of Winnipeg)

Cummins Mid-Canada Ltd.
Highway 17 East
P.O. Box 8
Kenora, Ontario P9N 3X1
Telephone: (807) 548-1941
FAX: (807) 548-8302

Ottawa Branch

Cummins Ontario Inc.
3189 Swansea Crescent
Ottawa, Ontario K1G 3W5,
Telephone: (613) 736-1146
FAX: (613) 736-1202

Thunder Bay Branch

Cummins Ontario Inc.
1400 W. Walsh Street
Thunder Bay
Ontario P7E 4X4
Telephone: (807) 577-7561
FAX: (807) 577-1727

Whitby Branch

Cummins Ontario Inc.
1311 Hopkins Street
Whitby, Ontario L1N 2C2, Canada
Telephone: (905) 668-6886
FAX: (905) 668-1375

Quebec

Montreal Distributor

Cummins Eastern Canada, Inc.
7200 Trans Canada Highway
Pointe Claire, Quebec H9R 1C2,
Telephone: (514) 695-8410
FAX: (514) 695-8917

Montreal Branch

Cummins Eastern Canada, Inc.
7200 Trans Canada Highway
Pointe Claire, Quebec H9R 1C2,
Canada
Telephone: (514) 695-8410
Sales: (514) 695-4555
Parts: (514) 694-5880
FAX: (514) 695-8917

Dorval Onan Branch

Cummins, Eastern Canada, Inc.
580 Lepihe
Dorval, Quebec H9H 1G2
Telephone: (514) 631-5000
FAX: (514) 631-0104

Quebec City Branch

Cummins Diesel
Branch of Cummins Americas, Inc.
2575 Dalton Street
Ste. Foy, Quebec G1P 3S7
Telephone: (418) 653-6411
FAX: (418) 653-5844

Val D'Or Branch

Cummins, Eastern Canada, Inc.
1025 Rue Del
Val D'Or, Quebec 59P 4P6
Telephone: (819) 825-0993
FAX: (819) 825-8488

Saskatchewan

Lloydminster - (Branch of Winnipeg)

Cummins Mid-Canada Ltd.
4005 52nd
Lloydminster, SK S9V 0Y9
Telephone: (305) 825-2062
FAX: (305) 825-6702

Regina - (Branch of Winnipeg)

Cummins Mid-Canada Ltd.
110 Kress Street
P.O. Box 98
Regina, SK S4P 2Z5
Telephone: (306) 721-9710
FAX: (306) 721-2962

Saskatoon - (Branch of Winnipeg)

Cummins Mid-Canada, Ltd.
3001 Faithful Avenue
P.O. Box 7679
Saskatoon, SK S7K 4R4, Canada
Telephone: (306) 933-4022
FAX: (306) 242-1722

Distributors and Branches - Australia

Branches:

Gepps Cross

Cummins Engine Company, Pty. Ltd.
P.O. Box 108
Blair Athol, 5084
South Australia, Australia
Location:
45-49 Cavan Road
Gepps Cross, 5094
Telephone: (61-8) 8262-5211

Dosra

Cummins Engine Company, Pty. Ltd.
P.O. Box 124
Darra, 4076
Queensland, Australia
Location:
33 Kimberley Street
Darra, 4076, Australia
Telephone: (61-7) 3375-3277

Bunbury

Cummins Engine Company, Pty. Ltd.
P.O. Box 1751
Bunbury, WA 6230
Australia
Location:
11 Dryanda Court
Picton, WA 6230
Telephone: (61-8) 9725-6777
FAX: (61-8) 9725-6444

Cairns

Cummins Engine Company, Pty. Ltd.
P.O. Box 7189
Cairns Mail Centre, 4870
Queensland, Australia
Location:
Liberty Street
Cairns, 4870
Telephone: (61-7) 935-2999

Campbellfield

Cummins Engine Company, Pty. Ltd.
Private Bag 9
Campbellfield, 3061
Victoria, Australia
Location:
1788-1800 Hume Highway
Campbellfield, 3061
Telephone: (613) 9357-9200

Dandenong

Cummins Engine Company, Pty. Ltd.
Lot 7 Greens Road
Dandenong, 3175
Victoria, Australia
Telephone: (613) 9706-8088

Darwin

Cummins Engine Company, Pty. Ltd.
P.O. Box 37587
Winnellie, 0821
Northern Territory, Australia
Location:
Lot 1758 Graffin Crescent
Winnellie, 0821
Telephone: (61-8) 8947-0766

Devonport

Cummins Engine Company, Pty. Ltd.
P.O. Box 72E
Tasmania, Australia
Location:
2 Matthews Way
Devonport, 7310
Telephone: (61-3) 6424-8800

Emerald

Cummins Engine Company, Pty. Ltd.
P.O. Box 668
Emerald, 4720
Queensland, Australia
Location:
Capricorn Highway
Emerald, 4720
Telephone: (61-7) 4982-4022

Grafton

Cummins Engine Company, Pty. Ltd.
P.O. Box 18
South Grafton, 2461
New South Wales, Australia
Location:
18-20 Induna Street
South Grafton, 2461
Telephone: (61-2) 6642-3655

Hexham

Cummins Engine Company, Pty. Ltd.
21 Galleghan Street
Hexham
New South Wales, Australia
Telephone: (61-2) 4964-8466
FAX: (61-2) 4964-8616

Kalgoorlie

Cummins Engine Company, Pty. Ltd.
P.O. Box 706
Kalgoorlie, 6430
Western Australia, Australia
Location:
16 Atbara Street
Kalgoorlie, 6430
Telephone: (61-8) 9021-2588

Karratha

Cummins Engine Company, Pty. Ltd.
P.O. Box 377
Karratha, WA 6714
Australia
Location:
1490 Lambert Road
Karratha, WA 6714
Australia
Telephone: (61-8) 9144-4646
FAX: (61-8) 9143-1507

Laverton

Cummins Engine Company, Pty. Ltd.
Locked Bag 1
Laverton, Victoria 3028
Australia
Location:
195 Boundary Road
Laverton North, Victoria 3028
Australia
Telephone: (61-3) 9360-0800
FAX: (61-3) 9360-0438

Leeton

Cummins Engine Company, Pty. Ltd.
P.O. Box 775
Leeton, NSW 2705
Australia
Location:
29 Brady Way
Leeton, NSW 2705
Australia
Telephone: (61-2) 6953-3077
FAX: (61-2) 6953-3109

Mackay

Cummins Engine Company, Pty. Ltd.
P.O. Box 842
Mackay, 4740
Queensland, Australia
Location:
4 Presto Avenue
Mackay, 4746
Telephone: (61-7) 4955-1222

Mount Gambier

Cummins Engine Company, Pty. Ltd.
P.O. Box 2219
Mount Gambier, 5290
South Australia, Australia
Location:
2 Avey Road
Mount Gambier, 5290
Telephone: (61-87) 25-6422

Penrith

Cummins Engine Company, Pty. Ltd.
P.O. Box 132
Cambridge Park, 2747
New South Wales, Australia
Location:
7 Andrews Road
Penrith, 2750
Telephone: (61-2) 4729-1313

Queanbeyan

Cummins Engine Company, Pty. Ltd.
P.O. Box 527
Queanbeyan, 2620
New South Wales, Australia
Location:
15-27 Bayldon Road
Queanbeyan, 2620
Telephone: (61-2) 6297-3433
FAX: (61-2) 6297-6709

Regency Park

Cummins Engine Company, Pty. Ltd.
P.O. Box 2147
Regency Park, SA 5942
Australia
Location:
11 Manton Street
Hindmarsh, SA 5942
Australia
Telephone: (61-8) 8346-3832
FAX: (61-8) 8340-2045

Swan Hill

Cummins Engine Company, Pty. Ltd.
P.O. Box 1264
Swan Hill, 3585
Victoria, Australia
Location:
5 McAllister Road
Swan Hill, 3585
Telephone: (61-3) 5032-1511

Tamworth

Cummins Engine Company, Pty. Ltd.
P.O. Box 677
Tamworth, 2320
New South Wales, Australia
Location:
Lot 65 Gunnedah Road
Tamworth, 2340
Telephone: (61-2) 6765-5455

Townsville

Cummins Engine Company, Pty. Ltd.
P.O. Box 7339
Garbutt Business Centre, QLD4814
Australia
Location:
704-710 Ingham Road
Townsville, QLD 4814
Telephone: (61-7) 4774-7733
FAX: (61-7) 4774-7640

Welshpool

Cummins Engine Company, Pty. Ltd.
P. O. Box 52
Welshpool, 6986
Western Australia, Australia
Location:
50 Kewdale Road
Welshpool, 6106
Telephone: (61-8) 9458-5911

Wetherill Park

Cummins Engine Company, Pty. Ltd.
Private Bag 150
Wetherill Park, NSW 2164
Australia
Location:
492-494 Victoria Street
Wetherill Park, NSW 2164
Australia
Telephone: (61-2) 9616-5300
FAX: (61-2) 9616-5399

Wodonga

Cummins Engine Company, Pty. Ltd.
P.O. Box 174
Wodonga, 3690
Victoria, Australia
Location:
9-11 McKoy Street
Wodonga, 3690
Telephone: (61-2) 6024-3655

Distributors and Branches - New Zealand

Auckland

Cummins Diesel Sales & Service (NZ)
Ltd.
Private Bag 92804
Penrose, Auckland, New Zealand
Location:
440 Church Street
Penrose
Telephone: (64-9) 579-0085

Branches:

Auckland

Cummins Diesel Engines
Private Bag 92804
Penrose, Auckland, New Zealand
Location:
440 Church Street
Penrose
Telephone: (64-9) 579-0085

Christchurch

Cummins Diesel Engines
P.O. Box 16-149
Hornby, Christchurch, New Zealand
Location:
35 Parkhouse Road
Sockburn, Christchurch
Telephone: (64-3) 348-8170

Mt. Maunganui

Cummins Diesel Engines
P.O. Box 4005
Mt. Maunganui, New Zealand
Location:
101 Totara Street
Mt. Maunganui
Telephone: (64-7) 575-0545

Palmerston North

Cummins Diesel Engines
P.O. Box 9024
Palmerston North, New Zealand
Location:
852-860 Tremain Avenue
Telephone: (64-6) 356-2209

Distributors - International

ABU DHABI

- See United Arab Emirates

AFGHANISTAN

- See Middle East Regional Office

ALBANIA

- See Germany Regional Office -
Gross-Gerau

ALGERIA

Algiers

Cummins Corporation
Bureau de Liaison
38, Lotissement Benachour Abdelkader
Cheraga
43200 Wilaya de Tipasa
Algeria
Telephone: (213) 237-43-26

AMERICAN SAMOA

- See South Pacific Regional Office

ANDORRA

- See European Regional Office -
Mechelen

ANTIGUA

Miami (Office In U.S.A.)
Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

ARGENTINA

Buenos Aires

Distribuidora Cummins, S.A.
(DICUMAR)
Av. Del Libertador 602 Piso 5
Buenos Aires, Argentina
Telephone: (54-1)814-1895/1395/1393

ARUBA, ISLAND OF

- See Netherlands Antilles

AUSTRIA

Neudoerfl

Cummins Diesel Motorenvertriebsges
m.b.H. Trenner & Co.
Bickfordstr. 25
A-7201 Neudoerfl
Austria
Telephone: (43-2622) 77418/77625

BAHAMAS

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

BAHRAIN

Bahrain

Yusuf Bin Ahmed Kanoo W.L.L.
P.O. Box 45, Manama
Bahrain
Telephone: (973) 400414/400506

BALEARIC ISLANDS

Madrid (Office in Spain)

Cummins Ventas y Servicio, S.A.
Torrelaguna, 56
28027 Madrid, Spain
Telephone: (34-91) 367-2000
376-2404

BANGLADESH

Dhaka

Equipment & Engineering Co., Ltd.
G.P.O. Box 2339
Dhaka 1000, Bangladesh
Location:
56, Dilkusha Commercial Area
2nd Floor/Eastern Block
Telephone: (880-2) 234357, 234060

BARBADOS

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

BELGIUM

Brussels

Cummins Distributor
Belgium S.A.
623/629 Chaussee de Haecht
B-1030 Brussels, Belgium
Telephone: (24 hr.)
(32-2) 216-81-10

BELIZE

Tampa (Office in U.S.A.)

Cummins Southeastern Power, Inc.
5421 N. 59th Street
Tampa, FL 33610
Telephone: (813) 621-7202

BENIN

- See Togo

BERMUDA

Bronx (Office in U.S.A.)

Cummins Metropower, Inc.
890 Zerega Avenue
Bronx, NY 10473
Telephone: (718) 892-2400

BHUTAN

Pune (Office in India)

Cummins Diesel Sales &
Service (India) Ltd.
35A/1/2, Erandawana
Pune - 411 038, India
(State of Maharashtra) India
Telephone: (91-212) 331234/331554/
331635/330066/
330166/330356/
31703

BOLIVIA

La Paz

Machinery & Auto Service
Casilla 4042
La Paz, Bolivia
Location:
Av. 20 de Octubre Esq.
Rosendo Gutierrez
Telephone: (591-2) 379650, 366394

BONAIRE, ISLAND OF

- See Netherlands Antilles

BOTSWANA

- See East and Southern Africa Re-
gional Office - Harare

BRAZIL

Ananindeua

Marcos Marcelino & Companhia
Ltda.
Rodovia BR-316, Km 9
67020-010 Ananindeua, Para,
Brazil
Telephone: (55-91) 235-4100/4132/
4143/4012

Belo Horizonte

Distribuidora Cummins
Minas S.A.
31950-640 Olhos D'Agua Norte
Belo Horizonte, MG
Brazil
Telephone: (55-31) 288-1344

Campo Grande

Distribuidora Cummins
Mato Grosso Ltda.
Rodovia BR 163 Km 01
79060-000 Campo Grande
Mato Grosso do Sul, Brazil
Telephone: (55-67) 787-1166

Curitiba

Distribuidora Cummins Parana S.A.
Rua Brasílio Itiberê, 2195
80230 Curitiba, Parana
Brazil
Telephone: (55-41) 222-4036

Fortaleza

Distribuidora Cummins Diesel
Do Nordeste Ltda.
Av. da Abolicao, 3882,
Mucuripe
60165-081 Fortaleza, Ceara
Brazil
Telephone: (55-85) 263-1212

Goianian

Distribuidora de Motores Cummins
Centro Oeste Ltda.
Av. Caiapo 777 - Setor Sta. Genoveva
74672-400 Goiania, Goias
Brazil
Telephone: (55-62) 207-1010

Manaus

Distribuidora Cummins
Amazonas Ltda.
Estrada da Ponta Negra, 6080 - Sao
Jorge
69037 Manaus, Amazonas,
Brazil
Telephone: (55-92) 656-5444

Porto Alegre

Distribuidora Cummins
Meridional S.A.
Rua Dona Alzira, 98, Sarandi
91110-010 Porto Alegre,
Rio Grande do Sul, Brazil
Telephone: (55-51) 340-8222

Rio de Janeiro

Distribuidora Cummins
Leste Ltda.
Rua Sariema, 138-Olaria
21030-550 Rio de Janeiro,
Rio de Janeiro, Brazil
Telephone: (55-21) 290-7899

Sao Paulo

Companhia Distribuidora
de Motores Cummins
Rua Martin Burchard, 291 - Bras
03043-020 Sao Paulo,
Sao Paulo, Brazil
Telephone: (55-11) 270-2311

BRITISH VIRGIN ISLANDS

- See Puerto Rico

BRUNEI

- See Malaysia

BURKINA - FASO

- See North/West Africa Regional
Office - Daventry

BULGARIA

- See Germany Regional Office - Gross-
Gerau

BURMA

Kuala Lumpur (Office in Malaysia)

Contact: Scott &
English (M) Sdn Bhd
P.O. Box 10324
50710 Kuala Lumpur
West Malaysia
Location:
16 Jalan Chan Sow Lin
55200 Kuala Lumpur
West Malaysia
Telephone: (60-3) 2211033

BURUNDI

Brussels (Office in Belgium)

Bia, S.A.
Rameistraat, 123
B-3090 - Overijse, Belgium
Telephone: (32-2) 6892811

CAMBODIA

- See South & East Asia Regional Office
- Singapore

CANARY ISLANDS

Madrid (Office in Spain)

Cummins Ventas y
Servicio, S.A.
Torrelauna, 56
28027 Madrid, Spain
Telephone: (34-91) 3672000/3672404

CAPE VERDE

- See North/West Africa Regional Office
- Daventry

CENTRAL AFRICAN REPUBLIC

- See North/West Africa Regional Office
- Daventry

CEYLON

- See Sri Lanka

CHAD

- See North/West Africa Regional Office
- Daventry

CHILE

Santiago
Distribuidora Cummins Diesel
S.A.C.I.
Casilla Postal 1230
Calle Bulnes 1203
Santiago, Chile
Corporate Office:
Av. Providencia 2653, Office 1901
Santiago, Chile
Telephone: (56-2) 698-2113/4/5,
697-3566/7/8,
697-2709

CHINA, PEOPLE'S REPUBLIC

- See China Regional Office - Beijing

COLOMBIA

Barranquilla

Cummins de Colombia S.A.
Apartado Aereo 5347
Barranquilla, Colombia
Location: Calle 30, No. 19 - 21
Telephone: (57-58) 40-02-06/40-13-46

Bogota

Cummins Colombiana Ltda.
Apartado Aereo No. 7431
Bogota, D.E. Colombia
Location:
Av. Americas X Carrera
42C No. 19-45
Telephone: (57-1) 244-5688/5882

Bucaramanga

Cummins API, Ltda.
Apartado Aereo 352
Bucaramanga, Colombia
Location:
Autopista a Giron, Km 7
Telephone: (57-76) 468060

Cali

Distribuidora Cummins del Valle, Ltda.
Apartado Aereo No. 6398
Cali, Colombia
Location:
Av. 3a. # 39-35 - Vipasa
Telephone: (57-3) 65-4343

Medellin

Equipos Tecnicos Ltda.
Apartado Aereo No. 2046
Medellin, Colombia
Location: Carrera 52 No. 10-184
Telephone: (57-4) 255-4200

Pereira

Equipos Tecnicos Ltda. C.Q.R.
Apartado Aereo No. 1240
Pereira, Colombia
Location: Carrera 8a. No. 45-39
Telephone: (57-63) 366341

COMOROS

- See East and Southern Africa Re-
gional Office - Harare

CONGO, PEOPLE'S REPUBLIC

Brussels (Office in Belgium)

Bia, S.A.
Rameistraat, 123
B-3090
Overijse, Belgium
Telephone: (32-2) 6892811

CORSICA

- See France

COSTA RICA

San Jose

Servicios Unidos, S.A.
P.O. Box 559
San Jose, Costa Rica
Location:
100 metros al este de
Excelsior Antiguo
Curridabat, San Jose
Telephone Office: (506) 53-93-93
Telephone Service Shop:
(506) 26-00-76

CUBA

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

CYPRUS

Nicosia

Alexander Dimitriou & Sons Ltd.
P.O. Box 1932
Nicosia, Cyprus
Location:
4 Salamis Avenue
Telephone: (357-2) 349450

CZECH REPUBLIC

- See European Regional Office -
Mechelen

DENMARK

Glostrup

Preben Lange Industrimaskiner A/S
Post Box 166
2605 Broendby, Denmark
Location:
Midtager 22
Telephone: (45-43) 96-21-61

DJIBOUTI

- See Middle East Regional Office -
Daventry

DOMINICA

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

DOMINICAN REPUBLIC

Santo Domingo

Argico C. Por A.
P.O. Box 292-2 Feria
Santo Domingo
Dominican Republic, ZP-6
Location:
Calle Jose A. Soler
No. 3, ESQ.
Avenida Lope de Vega
Telephone: (809) 562-6281

DUBAI

- See United Arab Emirates

ECUADOR

Guayaquil

Motores Cummins (MOTCUM) S.A.
P.O. Box 1062
Guayaquil, Ecuador
Location:
Avenida Carlos Julio
Arosemena Km. 4
Telephone: (593-4) 203995/201177

Quito

Rectificadora Botar S.A.
P.O. Box 17-01-3344
Quito, Ecuador
Location:
Av. 10 de Agosto No. 5980
Telephone: (593-2) 465-176/177/
178/195/197

EGYPT

Cairo

ADAT
P.O. Box 1572
Cairo, Egypt
Sales and Service Location:
25, Pyramid Road
Giza, Cairo, Egypt
Telephone: (20-2) 384-6607/384-6609
385-4001/2/4/5/6/8/9

EL SALVADOR

San Salvador

Salvador Machinery
Company, S.A. de C.V.
P.O. Box 125
San Salvador, El Salvador
Location:
Blvd. Ejercito Nacional
Telephone: (503) 711022, 228388

ENGLAND

- See United Kingdom

EQUATORIAL GUINEA

- See North/West Africa Regional Office
- Daventry

ESTONIA

- See Moscow Regional Office - Moscow

FAROE ISLANDS

Wellingborough (Office in United Kingdom)

Cummins Diesel
Denington Industrial Estate
Wellingborough
Northants NN8 2QH,
England
Telephone: (44-933) 276231

FERNANDO PO

- See Spain

FIJI

- See Cummins Diesel Sales & Service
New Zealand Ltd.

FINLAND

Helsinki

Machinery OY
P.O. Box 56
SF 00511 Helsinki, Finland
Location:
Teollisuuskatu 29
Telephone: Int: (358-9) 77221

FRANCE

Lyon

Cummins Diesel
Sales Corporation
39, rue Ampere Z.I.
69680 Chassieu, France
Telephone: (33) 72-22-92-72
Parts and Service Telephone:
(33) 72-22-92-69

GABON

- See North/West Africa Regional Office
- Daventry

GAMBIA

Senegal (Matforce)

GEORGIA

- See Moscow Regional Office - Moscow

GERMANY

Gross-Gerau

Cummins Diesel Deutschland GmbH
P.O. Box 1134
D-6080 Gross-Gerau,
Germany
Location: Odenwaldstr. 23
Telephone: (49-6152) 174-0

GHANA

Accra

Leyland DAF (Ghana) Ltd.
P.O. Box 2969
Accra, Ghana
Location:
39/40 Ring Road South
Industrial Estate
Telephone: (233-21) 22-88-06

GREECE

Athens

Eliopoulos Brothers Ltd.
P.O.B. 51528
14 Km. National Rd.
Athens-Lamia
14510 Kifissia, Greece
Telephone: (30-1) 6202401/6202066/
6201955

GREENLAND

- See Denmark

GRENADA

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

GUADELOUPE

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

GUAM

Barrigada

Mid-Pac Far East, Inc.
Airport Industrial Park
825 Tiyan Parkway
Barrigada, Guam 96921
Telephone: (671) 632-5160

GUATEMALA

Guatemala City

Maquinaria y Equipos, S.A.
P.O. Box 2304
Guatemala City, Guatemala
Location:
Carretera Amatitlan
Km 12 zona 12
Telephone: (502-2) 773334/7/9

GUINEA BISSAU

- See North/West Africa Regional Office
- Daventry

GUYANA

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

GUYANA, FRENCH

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

HAITI

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

HOLLAND

- See Netherlands

HONDURAS

Tegucigalpa

Comercial Laeisz
Honduras, S.A.
P.O. Box 1022
Tegucigalpa, D.C., Honduras
Location:
Zona La Burrera,
Blvd. Toncontin
Frente a Gasolinera Esso.
Telephone: (504) 333570/335615

HONG KONG

Kowloon

Cummins Engine H. K. Ltd.
P.O. Box 840 Shatin
N.T., Hong Kong
Location:
Unison Industrial Centre
15th Floor, Units C & D
27-31 Au Pui Wan Street
Fo Tan, Shatin, Hong Kong
Telephone: (852) 606-5678

INDIA

Pune

Cummins Diesel Sales &
Service (India) Ltd.
35A/1/2, Erandawana
Pune - 411 038, (State of Maharashtra)
India
Telephone: (91-212) 331234, 331554,
331635, 330066,
330166, 330356,
331703

Bombay

Cummins Diesel Sales &
Service (I) Ltd.
298, Perin Nariman Street, Fort,
Bombay 400001, India
Telephone: (91-22) 2863566/2862247

Calcutta

Cummins Diesel Sales &
Service (I) Ltd.
94, Tivoli Court, I/C Ballygunge
Circular Road
Calcutta 700 019 (West Bengal), India
Telephone: (91-33) 2478065/2470481/
2470774

New Delhi

Cummins Diesel Sales &
Service (I) Ltd.
Flat No. 307, Meghdoot Building
94 Nehru Place
New Delhi 110 019, India
Telephone: (91-11) 6431051/6445756/
6452817

Raipur

Cummins Diesel Sales &
Service (I) Ltd.
Plot No. 15, Jalashay Marg
Choube Colony
Raipur 492 001 (Madhya Pradesh),
India
Telephone: (91-771) 24994/23157/29498

Ranchi

Cummins Diesel Sales &
Service (I) Ltd.
Shanti Kunj' C-202, Vidyalaya Marg
Road No. 1, Ashoknagar
Ranchi 834 002 (Bihar)
India
Telephone: (91-651) 301948/303623

INDONESIA

Jakarta

P.T. Alltrak 1978
P.O. Box 64/KBYL
Jakarta Selatan 12330, Indonesia
Location:
J1. R.S.C. Veteran No. 4
Bintaro, Rempoa
Telephone: (62-21) 736-1978/736-3302

IRAN

Tehran

Technical Service Development
Company
P.O. Box 13445/741
No. 152 Sohravardi Crossing
Dr. Beheshti Avenue
Tehran, Iran
Telephone:
Head Office: (98-21) 846666, 851021-7
Work Shop: (98-21) 995021-2/993240

IRAQ

- See Middle East Regional Office -
Daventry

IRELAND

Wellingborough (Office in England)

Cummins Diesel
Denington Estate
Wellingborough
Northants NN8 2QH, England
Telephone: (44-933) 276231

ISRAEL

Tel Aviv

Israel Engines &
Trailers Co. Ltd.
Levinson Brothers Engineers
P. O. Box 390
33 Hahashmal Street
Tel Aviv, Israel 61003
Telephone: (972-3) 5607671

ITALY

Milan

Cummins Diesel Italia S.p.A.
Piazza Locatelli, 8
Zona Industriale Sesto Uteriano
20098 S. Giuliano
Milanese (Milan), Italy
Telephone: (39-2) 9828-1235/6/7

IVORY COAST

- See Cote d' Ivoire

JAMAICA

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

JAPAN

Tokyo

Cummins Diesel (Japan) Ltd.
1-12-10-Shintomi
Chuo-ku, Tokyo 104
Japan
Telephone: (81-3) 3555-8511

JORDAN

Amman

S.E.T.I. Jordan Limited
P.O. Box 8053
Amman, Jordan
Telephone: (962-6) 621867/621884

KENYA

Nairobi

Werrot & Company Limited
P.O. Box 41216
Nairobi, Kenya
Location:
Lusaka Road
Telephone: (254-150) 20316

KOREA, SOUTH

Seoul

Hwa Chang Trading Co., Ltd.
Central P.O. Box No. 216
Seoul, South Korea
Location:
143-11 Doksan-dong, Kuro-ku
Telephone: (82-2) 854-0071/2/3/4/5,
869-1411/2/3

KUWAIT

Kuwait

General Transportation &
Equipment Co.
(Sales Department)
P.O. Box 1096
13011 Safat, Kuwait
Location:
Shuwaikh Behind
Canada Dry Factory
Telephone: (965) 4833380/1/2

Kuwait

General Transportation &
Equipment Co.
(Service Department)
East Ahmadi Area
13011 Safat, Kuwait
Telephone: (965) 3981577

LAOS

- See South and East Asia Regional Of-
fice - Singapore

LATVIA

- See Moscow Regional Office - Moscow

LEBANON

Beirut

S.E.T.I. Charles Keller
S.A.L.
B.P. 16-6726
Beirut, Lebanon
Location:
Corniche du Fleuve
Telephone: (961-1) 425040/41

LESOTHO

- See South Africa

LIBYA

- See North/West Africa Regional Office
- Davenport

LIECHTENSTEIN

- See Switzerland

LUXEMBOURG

Gross-Gerau (Office in Germany)

Cummins Diesel Deutschland GmbH
P.O. Box 11 34
Odenwaldstrasse 23
D-6080 Gross-Gerau, Germany
Telephone: (49-6152) 174-0

MACAU

- See Hong Kong

MADAGASCAR

- See East and Southern Africa Re-
gional Office - Harare

MADEIRA ISLANDS

- See Portugal

MALAYSIA

Kuala Lumpur

Cummins Diesel Sales & Service
Div. of Scott & English
(M) Sdn. Bhd.
P.O. Box 10324
50710 Kuala Lumpur, West Malaysia
Location:
16 Jalan Chan Sow Lin
55200 Kuala Lumpur
Telephone: (60-3) 2211033

MALI

- See Senegal (Matforce)

MALTA

Valletta

Plant & Equipment Ltd.
Regency House
254, Republic Street
Valletta, Malta
Telephone: (356) 23-26-20, 23-33-43,
23-16-23, 24-75-17

MARTINIQUE

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

MEXICO

Guadalajara

Cummins Del Occidente, S.A.
Lazaro Cardenas No. 2950
Fracc. Alamo Industrial
45560 Guadalajara, Jal. Mexico
Telephone: (52-3) 670-93-06, 670-53-38,
670-63-61, 670-62-33

Monterrey

Tecnica Automotriz, S.A.
Av. Alfonso Royes
No. 3637 Nte.
Monterrey, Nuevo Leon, Mexico
Telephone: (52-83) 51-41-51, 51-46-56

Merida

Cummins Del Sureste, S.A. de C.V.
Av. Aviacion Civil No. 647
Esquina Calle 100
Col. Sambula
97259 Merida, Yucatan, Mexico
Telephone: (52-99) 24-11-55, 24-00-15

Puebla

Cummins de Oriente, S.A. de C.V.
Av. Reforma No. 2112,
Puebla, Pue. Mexico
Telephone: (52-22) 48-76-74, 48-76-75

Queretaro

Distribuidor Cummins Del Centro, S.A.
de C.V.
Blvd. Bernardo Quintana No. 518
Col. Arboledas
C.P. 76140 Queretaro, Oro., Mexico
Telephone: (52-42) 12-41-90, 12-58-90,
12-62-94, 14-04-16,
14-08-81, 14-15-91

Tlalnepantla

Distribuidor Cummins
Metropolitana, S.A. DE C.V.
Sor Juana Ines de la Cruz No. 555
54000 Tlalnepantla, Edo. de Mexico,
Mexico
Telephone: (52-5) 327-38-00, 390-64-37,
390-12-27

MOROCCO

Casablanca

Societe Auto-Hall, S.A.
44 Avenue Lalla Yacout
Casablanca, Morocco
Telephone: (212) 31-84-60, 31-70-52,
31-90-56, 31-70-44

MOZAMBIQUE

- See East and Southern Africa Regional Office - Harare

NAMIBIA (Southwest Africa)

Windhoek

Propower, Namibia
P.O. Box 3637, Windhoek 9000
Namibia (Southwest Africa)
Location:
7 Nasmyth Street
Southern Inudustria
Telephone: (264-61) 37693

NEPAL

Pune (Office in India)

Cummins Diesel Sales &
Service (India) Ltd.
35A/1/2, Erandawana
Pune, - 411 038, (State of Maharashtra)
India
Telephone: (91-212) 331234, 331554,
331635, 330066,
330166, 330356,
331703

NETHERLANDS

Dordrecht

Cummins Diesel Sales &
Service, b.v.
Galvanistraat 35
3316 GH Dordrecht
Netherlands
Telephone: (31-78) 18-12-00

NETHERLANDS ANTILLES

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

NEW CALEDONIA

- See South Pacific Regional Office - Melbourne

NEW GUINEA

- See Papua New Guinea

NICARAGUA

Managua

F. Alf. Pellas & Cia.
Apartado Postal No. 46
Managua, Nicaragua
Location:
6a. Calle
30 y 31 Avs. N.O., Zona 5
Telephone: (505-2) 660616

NIGERIA

Lagos

SCOATRAC MOSEL
P.M.B. 21108
Ikeja, Lagos
Nigeria
Location:
Apapa-Oshodi Expressway
Isolo Industrial Estate,
Isolo
Telephone: (234-1) 52-15-39, 52-19-31,
52-46-70

Paris (Office in France)

SCOATRAC MOSEL
c/o SCOA
9 et 11 rue Robert de Fliers
75740 Paris, Cedex 15
France
Telephone: (33-1) 40-58-48-48

NORTHERN IRELAND

- See United Kingdom

NORWAY

Oslo

Cummins Diesel Salg & Service A/S
P.O. 6288
Etterstad 0603, Oslo 6
Norway
Location:
Verkseler Furulunds vei 11
Telephone: (47) 22326110

OMAN

Ruwi

Universal Engineering
Services L.L.C.
P.O. Box 5688
Ruwi
Sultanate of Oman
Telephone: (968) 590830, 591304

PAKISTAN

Karachi

- See Middle East Regional Office - Daventry

PANAMA

Panama City

Grupo Tiesa, S.A.
Apartado Postal #55-0549
Partillo, Panama
Telephone: (507) 67-3866

PAPUA NEW GUINEA

Sydney (Office in Australia)

Cummins Diesel Sales & Service
P.O. Box 150
Cabramatta, 2166
New South Wales, Australia

PARAGUAY

Asuncion

Automotores y Maquinaria,
S.R.L.
Yegros y Fulgencio R. Moreno
P.O. Box 1160
Asuncion, Paraguay
Telephone: (595-21) 493111, 493115

PERU

Lima

Comercial Diesel
del Peru S.A.
P.O. Box 14-0234
Lima, Peru
Location:
Ave. V.R. Haya
de la Torre 2648
Lima 3, Peru
Telephone: (51-14) 74-3173/4374/
3144/2281

PHILIPPINES

EDSA

Power Systems, Inc. EDSA
P.O. Box 3241
Manila
Philippines 1501
Location:
79E. Delos Santos Ave.
Mandaluyong, Metro Manila
Telephone: (63-2) 791769, 791771,
5311945, 5315448,
5311934, 5312531,
53414513

POLAND

- See Germany Regional Office - Gross-Gerau

PORTUGAL

Lisbon

Electro Central
Vulcanizadora, Lda.
P.O. Box 3077
1302 Lisbon, Portugal
Location:
Rua Conselheiro
Martins de Carvalho
Lote 1480
1400 Lisboa (Restelo)
Telephone: (351-1) 3015361

QATAR -

Doha

Jaidah Motors & Trading Co.
P.O. Box 150
Doha, Qatar (Arabian Gulf)
Telephone: (974) 810000

REUNION

- See Lyon Regional Office - Lyon

RIO DE ORO

- See Spain

ROMANIA

- See Germany Regional Office - Gross-Gerau

RUSSIA

- See Moscow Regional Office - Moscow

RWANDA

Brussels (Office in Belgium)

Bia, S.A.
Rameistraat, 123
B-3090 - Overijse, Belgium
Telephone: (32-2) 6892811

ST. LUCIA

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

ST. VINCENT

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

SAN MARINO

- See Italy

SAO TOME AND PRINCIPE

- See North/West Africa Regional Office
- Davenport

SAUDI ARABIA

Dammam

General Contracting Company
P.O. Box 5111
Dammam 31422, Saudi Arabia
Telephone: (966-3) 842-1216

SCOTLAND

- See United Kingdom

SENEGAL

Dakar

Matforce
B.P. 397
Dakar, Senegal
Location:
10 Avenue Faidherbe
Telephone: (221) 22-30-40

SEYCHELLES

- See East/Southern Africa Regional Office - Harare

SIERRA LEONE

- See North/West Africa Regional Office
- Davenport

SINGAPORE

Singapore

Applied Diesel Sales & Service Pte Ltd
8 Tanjong Penjuru
Jurong Industrial Estate
Singapore 2260
Telephone: (65) 261-3555

SLOVAKIA

- See European Regional Office - Mechelen

SOLOMON ISLANDS

- See South Pacific Regional Office - Melbourne

SOMALIA

- See East and Southern Africa Regional Office - Harare

SOUTH AFRICA

Johannesburg

Propower Pty. Ltd.
Private Bag X4
Wendywood 2144
South Africa
Location:
13 Eastern Service Road
Kelvin 2054
Telephone: (27-11) 444-3225

SOUTHWEST AFRICA

- See Namibia

SPAIN

Madrid

Cummins Ventas y
Servicio S.A.
Torrelaguna, 56
28027 Madrid, Spain
Telephone: (34-91) 367-2000/3672404

SPANISH GUINEA

- See Spain

SRI LANKA

Colombo

Trade Promoters Ltd
P.O. Box 321
69, Walukarama Road
Colombo 3
Sri Lanka
Telephone: (94-1) 573927, 574651,
575005

SUDAN

Khartoum

Bittar Engineering Ltd.
P.O. Box 1011
Gamhouria Street
Khartoum, Sudan
Telephone: (249-11) 70952, 71245,
70306

SURINAM

Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

SWAZILAND

- See South Africa

SWEDEN

Stockholm

SMA Maskin AB
Aggelundavagen 7
S-17562 Jarfalla
Sweden
Telephone: (46-8) 621-25-00

SWITZERLAND

Regensdorf

Robert Aebi AG
Riedthofstrasse 100
8105 Regensdorf
Switzerland
Telephone: (41-1) 842-5111

SYRIA

Damascus

Puzant Yacoubian & Sons
P.O. Box 3617
Damascus, Syria
Location:
Abou Baker El Saddik Street
Kafar Sousse Square
Telephone: (963-11) 231547/8/9

TAHITI, ISLAND OF

- See French Polynesia

TAIWAN

Taipei

Cummins Corporation - Taiwan Branch
12th Floor, No. 149
Min-Sheng E. Road, Sec. 2
Taipei, Taiwan
Telephone: (886-2) 515-0891

TANZANIA

Dar es Salaam

Riddoch Motors 1987 Ltd
P.O. Box 40040
Dar es Salaam
Tanzania
Location:
92 Kipawa-Pugu Road-
Dar es Salaam
Telephone: (255-51) 44493, 41140

THAILAND

Bangkok

Diethelm & Company Ltd.
1696 New Petchburi Road
Bangkok 10310, Thailand
Telephone: (66-2) 254-4900

TOGO (and BENIN)

Lome

Togomat
B.P. 1641
Lome, Togo
Location:
Zone Industrielle CNPPME
Telephone: (228) 21-23-95

TONGA, ISLAND OF

- See South Pacific Regional Office -
Melbourne

TRINIDAD and TOBAGO

Miami (Office in U.S.A.)

Cummins Southeastern Power Inc.
9900 N.W. 77 Court
Hialeah Gardens, FL 33016
Telephone: (305) 821-4200

TURKEY

Istanbul

Hamamcioglu Mueseseseleri
Ticaret T.A.S.
P.K. 136
80222 Sisli
Istanbul, Turkey
Location:
Buyukdere Caddesi, 13/A
80260 Sisli
Istanbul, Turkey
Telephone: (90-1) 231-3406, 234-5123

UKRAINA

- See Moscow Regional Office - Moscow

UNITED ARAB EMIRATES

Abu Dhabi

Technical Oilfield Supplies Centre
P.O. Box 2647
Abu Dhabi,
United Arab Emirates
Telephone: (971-2) 723863, 723298

UNITED KINGDOM

Wellingborough

Cummins Diesel
Denington Estate
Wellingborough
Northants NN8 2QH, England
Telephone: (44-933) 276231

UPPER VOLTA

- See Burkina - Faso

URUGUAY

Montevideo

Santaro S.A.
P.O. Box 379
Montevideo
Uruguay
Location:
Avenida Millan No. 2441
Telephone: (598-2) 293908

U.S.S.R.

- See Moscow Regional Office - Moscow

VATICAN CITY

- See Italy

VENEZUELA

Caracas

Sudimat
Apartado Postal 1322
Carmelitas
Caracas 1010
Venezuela
Location:
Final Avenida San Martin
Urb. la Quebradita
Caracas 1061
Telephone: (58-2) 442-6161/2647

VIETNAM

Hanoi

Diethelm & Co. Ltd. Engineering
Room No. 1, 2nd Floor
8 Trang Thi Street
Hanoi, Vietnam
Telephone: (84-4) 260-332, 244-394

Ho Chi Minh City

Diethelm & Co. Ltd. Engineering
3rd Floor, IBC Building
1 Me Linh Square
District 1
Ho Chi Minh City, Vietnam
Telephone: (84-8) 294-102, 294-103

WESTERN SAMOA

- See South Pacific Regional Office -
Melbourne

YEMEN ARAB REPUBLIC

Sana'a

Zubieri Trading Co.
P.O. Box 535
Sana'a, Yemen Arab Republic
Location:
Zubieri Street
Telephone: (967-1) 244400/79149

YEMEN, SOUTH

- See Middle East Regional Office -
Daventry

YUGOSLAVIA

- See Southeastern Europe

ZAIRE

Brussels (Office in Belgium)

N.V. Bia, S.A.
Rameistraat, 123
B-3090 - Overijse, Belgium
Telephone: (32-2) 689-28-11

ZAMBIA

Ndola

N.E.I. (Zambia) Ltd.
P.O. Box 71501
Ndola, Zambia
Telephone: (260-2) 610729

ZIMBABWE

Harare

Cummins Zimbabwe (Pvt) Ltd.
P.O. Box ST363
Southerton
Harare, Zimbabwe
Location:
72 Birmingham Road
Southerton, Harare
Telephones: (263-4) 67645, 69220

Section TS - Troubleshooting Symptoms

Section Contents

	Page
Troubleshooting Procedures and Techniques	TS-1
General Information	TS-1
Troubleshooting Symptoms Charts	TS-2
Alternator Not Charging or Insufficient Charging	TS-3
Alternator Overcharging	TS-4
Coolant Loss – External	TS-5
Coolant Temperature Above Normal – Gradual Overheat	TS-6
Coolant Temperature is Above Normal – Sudden Overheat	TS-8
Coolant Temperature is Below Normal	TS-9
Cranking Fuel Pressure is Low	TS-10
Engine Acceleration or Response Poor	TS-11
Engine Difficult to Start or Will Not Start (Exhaust Smoke)	TS-13
Engine Difficult to Start or Will Not Start (No Exhaust Smoke)	TS-15
Engine Noise Excessive	TS-16
Engine Noise Excessive — Combustion Knocks	TS-18
Engine Power Output Low	TS-19
Engine Runs Rough at Idle	TS-21
Engine Runs Rough or Misfires	TS-22
Engine Shuts Off Unexpectedly or Dies During Deceleration	TS-23
Engine Speed Surges at Low or High Idle	TS-24
Engine Speed Surges in PTO or Cruise Control	TS-26
Engine Speed Surges Under Load or in Operating Range	TS-25
Engine Starts But Will Not Keep Running	TS-27
Engine Vibration Excessive	TS-28
Engine Will Not Crank or Cranks Slowly (Air Starter)	TS-29
Engine Will Not Crank or Cranks Slowly (Electric Starter)	TS-30
Engine Will Not Reach Rated Speed (RPM)	TS-31
Fault Code Warning Lamps Do Not Illuminate	TS-33
Fault Code Warning Lamps Stay On (No Apparent Reason)	TS-32
Fuel Consumption Excessive	TS-34
Fuel in Coolant	TS-35
Fuel in the Lubricating Oil	TS-36
General Information	TS-2
Intake Manifold Air Temperature Above Specification	TS-37
Intake Manifold Pressure (Boost) is Below Normal	TS-39
Lubricating Oil Consumption Excessive	TS-40
Lubricating Oil Contaminated	TS-41
Lubricating Oil Pressure High	TS-42
Lubricating Oil Pressure Low	TS-43
Lubricating Oil Sludge in the Crankcase Excessive	TS-44
Smoke, Black — Excessive	TS-45
Smoke, White — Excessive	TS-46
Turbocharger Leaks Engine Oil or Fuel	TS-48

THIS PAGE LEFT INTENTIONALLY BLANK

Troubleshooting Procedures and Techniques

General Information

This guide describes some typical engine operating problems, their causes, and some acceptable corrections to those problems. Unless noted otherwise, the problems listed are those which an operator can diagnose and repair.

WARNING

Performing troubleshooting procedures NOT outlined in this section can result in equipment damage or personal injury or death. Troubleshooting must be performed by trained, experienced technicians. Consult a Cummins Authorized Repair Location for diagnosis and repair beyond that which is outlined, and for symptoms not listed in this section. Before beginning any troubleshooting, refer to General Safety Instructions in Section i of this manual.

Follow the suggestions below for troubleshooting:

- Study the complaint thoroughly before acting
- Refer to the engine system diagrams
- Do the easiest and most logical things first
- Find and correct the cause of the complaint

Troubleshooting Symptoms Charts

General Information

Use the following charts to aid in diagnosing specific engine symptoms. Read each row of blocks from top to bottom. Follow the arrows through the chart to identify corrective action.




Troubleshooting presents the risk of equipment damage, personal injury or death. Troubleshooting must be performed by trained experienced technicians.


Alternator Not Charging or Insufficient Charging

Cause	Correction
Alternator pulley is loose on the shaft	Tighten the pulley. Refer to the OEM service manual.
OK ↓	
Batteries have failed	Check the condition of the batteries. Replace the batteries, if necessary. Refer to the OEM service manual.
OK ↓	
Battery cables or connections are loose, broken, or corroded (excessive resistance)	Check the battery cables and connections.
OK ↓	
Alternator is overloaded, or alternator capacity is below specification	Install an alternator with a higher capacity. Refer to the OEM service manual.
OK ↓	
Alternator or voltage regulator is malfunctioning	Test the alternator output. Replace the alternator or voltage regulator if necessary. Refer to the OEM service manual.
OK ↓	
Battery temperature is above specification	Position the batteries away from heat sources. Refer to the OEM service manual.
OK ↓	
Electrical system is "open" (blown fuses, broken wires, or loose connections)	Check the fuses, wires, and connections. Refer to the OEM service manual and the manufacturer's wiring diagrams.
OK ↓	
Vehicle gauge is malfunctioning	Check the vehicle gauge. Refer to the OEM service manual.
OK ↓	
Contact a Cummins Authorized Repair Facility	

Alternator Overcharging



Coolant Loss – External



Coolant Temperature Above Normal – Gradual Overheat

Cause

Correction

Charge-air cooler (CAC) fins, radiator fins, or air conditioner condenser fins are damaged or obstructed with debris

Inspect the CAC, air conditioner condenser, and radiator fins. Clean, if necessary. Refer to Section 4.

OK

Cold weather radiator cover or winterfront is closed

Open the cold weather radiator cover or the winterfront. Maintain a minimum of 784 cm² [120 in²], or approximately 28 x 28 cm [11 x 11 in], of opening at all times. Refer to Section 1.

OK

Coolant level is below specification

Inspect the engine and cooling system for external coolant leaks. Repair if necessary. Add coolant. Refer to Section 3.

OK

Electronic fault codes are active

For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.

OK

Fan shroud is damaged or missing, or the air recirculation baffles are damaged or missing

Inspect the shroud and the recirculation baffles. Repair, replace, or install, if necessary. Refer to the OEM service manual.

OK

Lubricating oil is contaminated with coolant or fuel

Contact a Cummins Authorized Repair Facility.

OK

Cooling system hose(s) collapsed, restricted, or leaking

Inspect the cooling system hose(s), for restrictions or obstructions. Refer to the OEM service manual.

OK

Coolant mixture of antifreeze and water is **not** correct

Verify the concentration of antifreeze in the coolant. Add antifreeze or water to correct the concentration. Refer to Section 5.

OK

(Continued)


Coolant Temperature Above Normal – Gradual Overheat (Continued)

Cause	Correction
Lubricating oil level is above or below specification	Check the oil level. Add or drain oil, if necessary. Refer to Section 3.
OK ↓	
Radiator fins are damaged or obstructed with debris	Inspect the radiator fins. Clean and repair the fins as necessary. Refer to the OEM service manual.
OK ↓	
Coolant temperature gauge is malfunctioning	Test the temperature gauge. Repair or replace the gauge, if necessary.
OK ↓	
Fan drive belt is loose, tight, or not in alignment	Check the fan drive belt. Refer to Section 6.
OK ↓	
Vehicle cooling system is not adequate	Verify that the engine and vehicle cooling systems are using the correct components. Refer to the OEM specifications.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Coolant Temperature is Above Normal – Sudden Overheat

Cause	Correction
Coolant level is below specification	Inspect the engine and cooling system for external coolant leaks. Repair if necessary. Add coolant. Refer to Section 3.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Fan drive belt is broken	Check the fan drive belt. Replace the belt, if necessary. Refer to Section 6.
OK ↓	
Radiator cap is not correct, is malfunctioning, or has low-pressure rating	Check the radiator pressure cap. Refer to the OEM service manual.
OK ↓	
Cooling system hose(s) collapsed, restricted, or leaking	Inspect the cooling system hose(s), for restrictions or obstructions. Refer to the OEM service manual.
OK ↓	
Coolant temperature gauge is malfunctioning	Test the temperature gauge. Repair or replace the gauge, if necessary.
OK ↓	
Charge-air cooler (CAC) fins, radiator fins, or air conditioner condenser fins are damaged or obstructed with debris	Inspect the CAC, air conditioner condenser, and radiator fins. Clean, if necessary. Refer to Section 4.
OK ↓	
Cold weather radiator cover or winterfront is closed	Open the cold weather radiator cover or the winterfront. Maintain a minimum of 784 cm ² [120 in ²], or approximately 28 x 28 cm [11 x 11 in], of opening at all times. Refer to Section 1.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Coolant Temperature is Below Normal



Cranking Fuel Pressure is Low



Engine Acceleration or Response Poor



Engine Acceleration or Response Poor (Continued)

Cause	Correction
Fuel supply line restriction between the fuel pump and the injectors	Check the fuel supply line from the fuel pump to the cylinder head for sharp bends that can cause restrictions. Refer to a Cummins Authorized Repair Facility.
OK	
Charge-air cooler (CAC) is restricted or leaking	Inspect the CAC for air restrictions or leaks.
OK	
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting.
OK	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK	
Fuel grade is not correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Section V.
OK	
Contact a Cummins Authorized Repair Facility	

Engine Difficult to Start or Will Not Start (Exhaust Smoke)

Cause	Correction
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Starting aid is necessary for cold weather, or starting aid is malfunctioning	Check for the correct operation of the starting aid. Refer to the manufacturer's instructions. Refer to Cold Weather Starting Aids in Section 1.
OK ↓	
Engine block heater is malfunctioning (if equipped)	Check the electrical sources and wiring to the cylinder block heater. Replace the block heater, if necessary. Refer to the OEM service manual.
OK ↓	
Fuel heater is malfunctioning (if equipped)	Check the fuel heater and replace, if necessary. Refer to the manufacturer's instructions.
OK ↓	
Battery voltage is low	Inspect the batteries and the unswitched battery supply circuit. Refer to the OEM service manual.
OK ↓	
Engine cranking speed is too slow	If the cranking speed is slower than 150 rpm, refer to the Engine Will Not Crank or Cranks Slowly (Electric Start) symptom tree.
OK ↓	
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK ↓	
(Continued)	

Engine Difficult to Start or Will Not Start (Exhaust Smoke) (Continued)

Cause	Correction
Fuel leak	Check the fuel lines, fuel connections, and fuel filters for leaks. Check the fuel lines to the supply tanks. Refer to the OEM service manual.
OK	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe, and fuel filters as necessary.
OK	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK	
Fuel grade is not correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Section V.
OK	
Contact a Cummins Authorized Repair Facility	

Engine Difficult to Start or Will Not Start (No Exhaust Smoke)

Cause	Correction
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
OEM engine protection system is malfunctioning	Isolate the OEM engine protection system. Follow the OEM service manuals to check for a malfunction.
OK ↓	
Battery voltage is low	Inspect the batteries and the unswitched battery supply circuit. Refer to the OEM service manual.
OK ↓	
Battery voltage supply to the electronic control module (ECM) is low, interrupted, or open	Check the battery connections. Check the fuses and the unswitched battery supply circuit. Refer to the OEM service manual.
OK ↓	
Moisture in the wiring harness connectors	Dry the connectors with Cummins electronic cleaner, Part No. 3824510.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe, and fuel filters as necessary.
OK ↓	
Electronic control module (ECM) is locked up	Disconnect the battery cables for 30 seconds. Connect the battery cables, and start the engine.
OK ↓	
Contact a Cummins Authorized Repair Facility	

Engine Noise Excessive

Cause	Correction
Fan drive belt is loose, tight, or not in alignment	Check the fan drive belt. Refer to Section 6.
OK ↓	
Lubricating oil is thin or diluted	Refer to the Lubricating Oil Contaminated symptom tree or the Lubricating Oil Specifications in Section V.
OK ↓	
Vibration damper is damaged	Inspect the vibration damper. Refer to Section 7.
OK ↓	
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting.
OK ↓	
Air intake or exhaust piping is contacting the chassis or cab	Inspect the air piping, chassis, and cab for contact points. Refer to Section 4.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	
Coolant temperature is above specification	Refer to the Coolant Temperature is Above Normal - Sudden Overheat symptom tree.
OK ↓	
Engine mounts are worn, damaged, or not correct	Inspect the engine mounts. Refer to the OEM service manual.
OK ↓	
Fan clutch, hydraulic pump, or freon compressor noise is excessive	Isolate each component and check for noise. Refer to the OEM service manual.
OK ↓	
(Continued)	

Engine Noise Excessive (Continued)

Cause

Fan is loose, damaged, or has excessive hub bearing end play

Correction


Check the fan. Refer to Section 6.

OK




Contact a Cummins Authorized
Repair Facility

Engine Noise Excessive — Combustion Knocks



Engine Power Output Low



Engine Power Output Low (Continued)

Cause	Correction
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK	
Charge-air cooler (CAC) is restricted or leaking	Inspect the CAC for air restrictions or leaks.
OK	
Lubricating oil level is above specification	Check the oil level. Verify the dipstick calibration and oil pan capacity. Fill the system to the specified level. Refer to Section 3.
OK	
Contact a Cummins Authorized Repair Facility	

Engine Runs Rough at Idle

Cause	Correction
Engine is cold	Allow the engine to warm to operating temperature. If the engine will not reach operating temperature, refer to the Coolant Temperature is Below Normal symptom tree.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe, and fuel filters as necessary.
OK ↓	
Fuel supply line restriction between the fuel pump and the injectors	Check the fuel supply line from the fuel pump to the cylinder head for sharp bends that can cause restrictions. Refer to a Cummins Authorized Repair Facility.
OK ↓	
Engine mounts are worn, damaged, or not correct	Check the engine mounts. Refer to the OEM service manual.
OK ↓	
Moisture in the wiring harness connectors	Dry the connectors with Cummins electronic cleaner, Part No. 3824510.
OK ↓	
Fuel grade is not correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	

Engine Runs Rough or Misfires

Cause

Correction

Engine is cold

Allow the engine to warm to operating temperature. If the engine will **not** reach operating temperature, refer to the Coolant Temperature is Below Normal symptom tree.

OK
↓

Electronic fault codes are active

For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.

OK
↓

Air in the fuel system

Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe, and fuel filters as necessary.

OK
↓

Fuel supply line restriction between the fuel pump and the injectors

Check the fuel supply line from the fuel pump to the cylinder head for sharp bends that can cause restrictions. Refer to a Cummins Authorized Repair Facility.

OK
↓

Engine mounts are worn, damaged, or **not** correct

Check the engine mounts. Refer to the OEM service manual.

OK
↓

Moisture in the wiring harness connectors

Dry the connectors with Cummins electronic cleaner, Part No. 3824510.

OK
↓

Contact a Cummins Authorized Repair Facility

Engine Shuts Off Unexpectedly or Dies During Deceleration

Cause	Correction
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Idle shutdown or PTO shutdown features are activated	Refer to Electronically Controlled Fuel System in Section 1.
OK ↓	
Moisture in the wiring harness connectors	Dry the connectors with Cummins electronic cleaner, Part No. 3824510.
OK ↓	
OEM engine protection system is malfunctioning	Isolate the OEM engine protection system. Follow the OEM service manuals to check for a malfunction.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe, and fuel filters as necessary.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Engine Speed Surges at Low or High Idle

Cause	Correction
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK	
Moisture in the wiring harness connectors	Dry the connectors with Cummins electronic cleaner, Part No. 3824510.
OK	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe, and fuel filters as necessary.
OK	
Fuel grade is not correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK	
Contact a Cummins Authorized Repair Facility	


Engine Speed Surges Under Load or in Operating Range

Cause	Correction
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Moisture in the wiring harness connectors	Dry the connectors with Cummins electronic cleaner, Part No. 3824510.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank stand pipe, and fuel filters as necessary.
OK ↓	
Idling with excessive load	Use the PTO feature for loaded conditions at low engine speeds. Refer to Programmable Features in Section 1.
OK ↓	
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK ↓	
Clutch is malfunctioning or is not correct	Compare the drivetrain specifications to Cummins recommendations. Check the clutch for correct operation. Refer to the OEM service manual.
OK ↓	
Fuel grade is not correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Engine Speed Surges in PTO or Cruise Control




Engine Starts But Will Not Keep Running




Engine Vibration Excessive




Engine Will Not Crank or Cranks Slowly (Air Starter)




Engine Will Not Crank or Cranks Slowly (Electric Starter)




Engine Will Not Reach Rated Speed (RPM)



Fault Code Warning Lamps Stay On (No Apparent Reason)



Fault Code Warning Lamps Do Not Illuminate



Fuel Consumption Excessive

Cause	Correction
Operator technique is not correct	Refer to the Operating Instructions in Section 1.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Fuel leak	Check the fuel lines, fuel connections, and fuel filters for leaks. Check the fuel lines to the supply tanks. Refer to the OEM service manual.
OK ↓	
Hubometer or odometer is miscalibrated	Check the hubometer and odometer calibrations. Calibrate or replace the hubometer or odometer, if necessary. Calculate fuel consumption with new mileage figures.
OK ↓	
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	
Equipment and environmental factors are affecting fuel consumption	Consider ambient temperatures, wind, tire size, axle alignment, routes, and use of aerodynamic aids when evaluating fuel consumption.
OK ↓	
Lubricating oil level is above specification	Check the oil level. Verify the dipstick calibration and oil pan capacity. Fill the system to the specified level. Refer to Section 3.
OK ↓	
Contact a Cummins Authorized Repair Facility	

Fuel in Coolant

Cause

Bulk coolant supply is contaminated


OK
↓

Contact a Cummins Authorized
Repair Facility

Correction

Check the bulk coolant supply. Drain the coolant and replace with noncontaminated coolant. Replace the coolant filters. Refer to Section 5.

Fuel in the Lubricating Oil




Intake Manifold Air Temperature Above Specification


Cause	Correction
Charge-air cooler (CAC) fins, radiator fins, or air conditioner condenser fins are damaged or obstructed with debris	Inspect the CAC, air conditioner condenser, and radiator fins. Clean, if necessary. Refer to Section 4.
OK ↓	
Cold weather radiator cover or winterfront is closed	Open the cold weather radiator cover or the winterfront. Maintain a minimum of 784 cm ² [120 in ²], or approximately 28 x 28 cm [11 x 11 in], of opening at all times. Refer to Section 1.
OK ↓	
Fan drive belt or water pump belt is broken	Check the fan drive belt and water pump belt. Replace the belts if necessary. Refer to Section 6.
OK ↓	
Fan shroud is damaged or missing, or the air recirculation baffles are damaged or missing	Inspect the shroud and the recirculation baffles. Repair, replace, or install, if necessary. Refer to the OEM service manual.
OK ↓	
Radiator shutters are not opening completely, or the shutterstat setting is wrong	Inspect the radiator shutters. Repair or replace if necessary. Refer to the manufacturer's instructions. Check the shutterstat setting.
OK ↓	
Vehicle speed is too low for adequate cooling with high engine load	Reduce the engine load. Increase the engine (fan) rpm by downshifting.
OK ↓	
Vehicle cooling system is not adequate	Verify that the engine and vehicle cooling systems are using the correct components. Refer to the OEM service manual.
OK ↓	
Intake manifold temperature gauge is malfunctioning, if equipped	Test the temperature gauge. Refer to the OEM service manual.
OK ↓	

(Continued)


Intake Manifold Air Temperature Above Specification (Continued)




Intake Manifold Pressure (Boost) is Below Normal




Lubricating Oil Consumption Excessive



Lubricating Oil Contaminated




Lubricating Oil Pressure High




Lubricating Oil Pressure Low

Cause	Correction
Engine angularity during operation exceeds specification	Refer to the Engine Specification data sheet.
OK ↓	
Lubricating oil does not meet specifications for operating conditions	Change the oil and filters. Refer to Section 5. Use the oil recommended in Section V.
OK ↓	
Lubricating oil filter is plugged	Change the oil and filter. Refer to Section 5. Review the oil change interval.
OK ↓	
Lubricating oil is contaminated with coolant or fuel	Contact a Cummins Authorized Repair Facility.
OK ↓	
Lubricating oil leak (external)	Inspect the engine for external oil leaks. Tighten the capscrews, pipe plugs, and fittings. Replace gaskets, if necessary. Refer to a Cummins Authorized Repair Facility.
OK ↓	
Lubricating oil level is above or below specification	Check the oil level. Add or drain oil, if necessary. Refer to Section 3 or Section 5.
OK ↓	
Lubricating oil pressure switch, gauge, or sensor is malfunctioning or is not in the correct location	Check the oil pressure switch, gauge, or sensor for correct operation and location. Refer to the OEM service manual.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Contact a Cummins Authorized Repair Facility	

Lubricating Oil Sludge in the Crankcase Excessive



Smoke, Black — Excessive



Smoke, White — Excessive

Cause	Correction
Engine is cold	Allow the engine to warm to operating temperature. If the engine will not reach operating temperature, refer to the Coolant Temperature Below Normal symptom tree.
OK ↓	
Engine is operating at low ambient temperature	Check the winterfront, shutters, and underhood air. Refer to the Cold Weather Operation, Bulletin No. 3387266, and Section 1. Use intake air from under the hood in cold weather.
OK ↓	
Starting aid is necessary for cold weather, or starting aid is malfunctioning	Check for the correct operation of the starting aid. Refer to the manufacturer's instructions. Refer to Cold Weather Starting Aids in Section 1.
OK ↓	
Electronic fault codes are active	For instructions on how to read active fault codes. Refer to Diagnostic Fault Codes in Section 1. If fault codes are active, contact a Cummins Authorized Repair Facility.
OK ↓	
Fuel grade is not correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	

(Continued)

Smoke, White — Excessive (Continued)

Cause	Correction
Charge-air cooler (CAC) is restricted or leaking	Inspect the CAC for air restrictions or leaks.
OK ↓ Contact a Cummins Authorized Repair Facility	

Turbocharger Leaks Engine Oil or Fuel

Cause	Correction
Engine is operating for extended periods under light- or no-load conditions (slobbering)	Review the engine operating instructions in Section 1.
OK ↓	
Lubricating oil or fuel is entering the turbo-charger	Remove the intake and exhaust piping, and check for oil or fuel.
OK ↓	
Turbocharger drain line is restricted	Remove the turbocharger drain line, and check for restriction. Clean or replace the drain line.
OK ↓	
Contact a Cummins Authorized Repair Facility	

Section V - Maintenance Specifications

Section Contents

	Page
Arctic Operation	V-14
Capscrew Markings and Torque Values	V-15
Capscrew Markings and Torque Values - Metric	V-16
Capscrew Markings and Torque Values - U.S. Customary	V-17
Coolant Recommendations and Specifications	V-7
Cooling System Additives	V-9
Cooling System Soluble Oils	V-11
Fully Formulated Coolant/Antifreeze	V-7
Drive Belt Tension	V-12
Engine Component Torque Values	V-13
Torque Table	V-13
Fuel Recommendations and Specifications	V-3
Cummins/Fleetguard®/Nelson Filter Specifications	V-4
Fuel Filters	V-4
Fuel Recommendations	V-3
Lubricating Oil Recommendations and Specifications	V-5
Cummins/Fleetguard®/Nelson Filter Specifications	V-7
General Information	V-6
New Engine Break-in Oils	V-5
Arctic Operation Engine Oil.....	V-5
Sealants	V-14
Specifications	V-1
Air Intake System	V-2
Batteries (Specific Gravity)	V-2
Cooling System	V-2
Cummins/Fleetguard®/Nelson Filter Specifications	V-3
Electrical System	V-2
Exhaust System	V-2
Fuel System	V-1
General Specifications	V-1
Lubricating Oil System	V-1

THIS PAGE LEFT INTENTIONALLY BLANK

Specifications

General Specifications

Horsepower	(Refer to engine dataplate)
QSL9 Engine Speed @ Maximum Power Output:	
Standard Rating	2100 rpm
Governed Speed	2300 rpm
Bore and Stroke	114 mm [4.49 in] x 144.5 mm [5.69 in]
Displacement	8.9 liters [543 C.I.D.]
Compression Ratio	16.6:1
Firing Order	1-5-3-6-2-4
QSL9 Approximate Engine Weight (with standard accessories)	706 kg [1556 lb]
Crankshaft Rotation (viewed from the front of the engine)	Clockwise
Valve Clearance:	
Intake	0.3048 mm [0.012 in]
Exhaust	0.5588 mm [0.022 in]

NOTE: The QSL9 engine features a no-adjust overhead. The QSL9 valve train is designed such that adjustment of the valve lash is **not** required for normal service during the first 241,500 km [150,000 mi] or 5000 hours. The valve train operates acceptably within the limits of 0.152 to 0.559 mm [0.006 to 0.022 in] intake valve lash and 0.381 to 0.813 mm [0.015 to 0.032 in] exhaust valve lash.

Fuel System

Engine Idle Speed	600 to 1200 rpm
Maximum Lift Pump Inlet Restriction at Rated	102 mm Hg [4 in Hg]
Maximum Fuel Filter Outlet Restriction at Rated	254 mm Hg [10 in Hg]
Minimum Fuel Filter Inlet Pressure during Cranking	508 mm Hg [20 in Hg]
Maximum Fuel Drain Line Pressure	254 mm Hg [10 in Hg]
Maximum Fuel Inlet Temperature	71°C [160°F]
Minimum Engine Cranking Speed	150 rpm

Lubricating Oil System

Oil Pressure:	
At Low Idle (minimum allowable)	69 kPa [10 psig]
At Rated Speed (minimum allowable)	207 kPa [30 psig]
Regulated Pressure	517 kPa [75 psi]
Oil Pan Capacity, Low to High:	
Standard Oil Pan	18.9 to 22.7 liters [20 to 24 qt]
Standard Oil Pan with Block Stiffener	19.9 to 23.7 liters [21 to 25 qt]
Total System Capacity:	
Standard Oil Pan	22.7 liters [24 qt]
Standard Oil Pan with Block Stiffener	23.7 liters [25 qt]
Oil Capacity of Standard Engine:	
Standard Oil Pan	
Pan Only	22.7 liters [24 qt]

NOTE: Some applications use a slightly different oil pan capacity. Contact a local Cummins Distributor if there are any questions.

Cooling System

Coolant Capacity (engine only)	10.9 liters [11.5 qt]
Standard Modulating Thermostat - Range	84 to 91°C [183 to 196°F]
Maximum Allowable Operating Temperature	100°C [212°F]
Minimum Recommended Operating Temperature	70°C [158°F]
Minimum Recommended Pressure Cap	50 kPa [7 psi]

Air Intake System

Maximum Intake Restriction (clean air filter element)	254 mm H ₂ O [10.0 in H ₂ O]
Maximum Intake Restriction (dirty air filter element)	635 mm H ₂ O [25.0 in H ₂ O]

Exhaust System

Maximum Exhaust Back Pressure	76 mm Hg [3 in Hg]
-------------------------------------	--------------------

Electrical System

Recommended Battery Capacity

System Voltage	Ambient Temperature			
	-18°C [0°F]		-29°C [-20°F]	
	Cold Cranking Amperes	Reserve Capacity (Minutes) ⁽¹⁾	Cold Cranking Amperes	Reserve Capacity (Minutes) ⁽¹⁾
12 VDC	1500	360	1875	360
24 VDC ⁽²⁾	750	180	900	180

1. The number of plates within a given battery size determines reserve capacity. Reserve capacity determines the length of time for which a battery at 27°C [81°F] can supply 25 amperes at 10.5 volts or greater.
2. CCA ratings are based on two 12-VDC batteries in series.

Batteries (Specific Gravity)

Specific Gravity at 27°C [81°F]	State of Charge
1.260 to 1.280	100%
1.230 to 1.250	75%
1.200 to 1.220	50%
1.170 to 1.190	25%
1.110 to 1.130	Discharged

Cummins/Fleetguard®/Nelson Filter Specifications

Fleetguard® is a subsidiary of Cummins Engine Company, Inc. Fleetguard® filters are developed through joint testing at Cummins and Fleetguard®. Fleetguard® filters are standard on new Cummins engines. Cummins Engine Company, Inc. recommends their use.

Fleetguard® products meet all Cummins Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, insist on products that the supplier has tested to meet Cummins high-quality standards.

Cummins can **not** be responsible for problems caused by nongenuine filters that do **not** meet Cummins performance or durability requirements.

Fuel Recommendations and Specifications

Fuel Recommendations

WARNING

Do not mix gasoline, alcohol, or gasohol with diesel fuel. This mixture can cause an explosion.

CAUTION

Due to the precise tolerances of diesel injection systems, it is extremely important that the fuel be kept clean and free of dirt or water. Dirt or water in the system can cause severe damage to both the fuel pump and the fuel injectors.

CAUTION

Lighter fuels can reduce fuel economy and can damage the fuel injection pump.

Cummins Engine Company, Inc. recommends the use of ASTM No. 2D fuel. The use of No. 2D fuel will result in optimum engine performance.


At operating temperatures below 0°C [32°F], acceptable performance can be obtained by using blends of No. 2D and No. 1D.

The viscosity of the fuel **must** be kept above 1.3 cSt at 40°C [104°F] to provide adequate fuel system lubrication.

The following chart lists acceptable alternate fuels for QSL9 Series engines.

Acceptable Substitute Fuels - Cummins QSL9 Fuel System									
No. 1D Diesel(1)(2)	No. 2D Diesel	No. 1K Kerosene	Jet-A	Jet-A1	JP-5	JP-8	Jet-B	JP-4	CITE
OK	OK	OK	OK	OK	OK	OK	NOT OK	NOT OK	NOT OK
1. Any adjustment to compensate for reduced performance with a fuel system using alternate fuel is not warrantable.									
2. Winter blend fuels, such as those found at commercial fuel dispensing outlets, are combinations of No. 1D and No. 2D diesel fuel and are acceptable.									

Additional information for fuel recommendations and specifications can be found in Fuel for Cummins Engines, Bulletin No. 3379001. See the ordering information in the back of this manual.



Cummins/Fleetguard®/Nelson Filter Specifications

Fuel Filters

- Fuel-water separator with a water-in-fuel sensor used in single filter applications
- Spin-on filter (Fleetguard® Part No. FS1022) (Cummins Part No. 3944264, element)
- Reusable water-in-fuel assembly (Cummins Part No. 3944270)
- Efficiency rating **must** meet Cummins specifications for the Cummins accumulator pump system (CAPS) fuel system.

Lubricating Oil Recommendations and Specifications

New Engine Break-in Oils

△ CAUTION △

A sulfated ash limit of 1.85 percent has been placed on all engine lubricating oils recommended for use in Cummins engines. Higher ash oils can cause valve and/or piston damage and lead to excessive oil consumption.

△ CAUTION △

The use of a synthetic-based oil does not justify extended oil change intervals. Extended oil change intervals can decrease engine life due to factors such as corrosion, deposits, and wear.

Special "break-in" engine lubricating oils are **not** recommended for new or rebuilt Cummins engines. Use the same kind of oil during the "break-in" as used in normal operation.

Additional information regarding lubricating oil availability throughout the world is available in the E.M.A. Lubricating Oils Data Book for Heavy-Duty Automotive and Industrial Engines. The data book can be ordered from the Engine Manufacturers Association, One Illinois Center, 111 East Wacker Drive, Chicago, IL U.S.A. 60601. The telephone number is (312) 644-6610.

Arctic Operation Engine Oil

If an engine is operated in ambient temperatures consistently below -23°C [-9°F], and there are no provisions to keep the engine warm when it is **not** in operation, use a synthetic CE/SF or higher API classification engine oil with adequate low-temperature properties (such as 5W-20 or 5W-30).

The oil supplier is responsible for meeting the performance service specification represented with its product.

General Information


The use of quality engine lubricating oils, combined with appropriate oil drain and filter change intervals, are critical factors in maintaining engine performance and durability.

Cummins Engine Company, Inc. recommends the use of a high-quality SAE 15W-40 multiviscosity heavy-duty engine oil, such as Cummins Premium Blue®, that meets the requirements of Cummins Engineering Specification CES20071 or CES20076 or the American Petroleum Institute (API) performance classification CG-4 or CH-4.


NOTE: In areas where CG-4 or CH-4 lubricating oils are **not** available, CES20075 or CF-4 lubricating oil can be used, but the lubricating oil change interval **must** be reduced to 14,400 km [9000 mi], 250 hours or 6 months.

A sulfated ash limit of 1.0 mass percent is suggested for optimum valve and piston deposit and oil consumption control. The sulfated ash **must not** exceed 1.85 mass percent.

For further details and discussion of engine lubricating oils for Cummins engines, refer to Cummins Engine Oil Recommendations, Bulletin No. 3810340, or a Cummins Authorized Repair Facility.



The use of low-viscosity oils, such as 10W or 10W-30, can be used to aid in starting the engine and in providing sufficient oil flow at ambient temperatures below -5°C [23°F]. However, continuous use of low-viscosity oils can decrease engine life due to wear. Refer to the accompanying chart.



The API service symbols are shown in the accompanying illustration. The upper half of the symbol displays the appropriate oil categories.


The lower half can contain a description of oil energy conserving features.

The center section identifies the SAE oil viscosity grade.

As the engine oil becomes contaminated, essential oil additives are depleted. Lubricating oils protect the engine as long as these additives are functioning properly. Progressive contamination between oil and filter change intervals is normal. The amount of contamination will vary depending on the operation of the engine, kilometers [miles] on the oil, fuel consumed, and new oil added.


Extending oil and filter change intervals beyond the recommendations will decrease engine life due to factors such as corrosion, deposits, and wear.

Refer to the Oil Drain Interval Chart in this section to determine which oil drain interval to use for an application.



Cummins/Fleetguard®/Nelson Filter Specifications


- Fleetguard® Part No. LF9009
- Cummins Part No. 3401544.



Coolant Recommendations and Specifications

Fully Formulated Coolant/Antifreeze

Cummins Engine Company, Inc. recommends using either a 50/50 mixture of high-quality water and fully formulated antifreeze or fully formulated coolant when filling the cooling system. The fully formulated antifreeze or coolant **must** meet TMC RP 329 or TMC RP 330 specifications.




High-quality water is important for cooling system performance. Excessive levels of calcium and magnesium contribute to scaling problems, and excessive levels of chlorides and sulfates cause cooling system corrosion.

Water Quality	
Calcium Magnesium (Hardness)	Maximum 170 ppm as (CaCO ₃ + MgCO ₃)
Chloride	40 ppm as(Cl)
Sulfur	100 ppm as (SO ₄)


18200001




Cummins Engine Company, Inc. recommends using Fleetguard® Compleat. It is available in both glycol forms (ethylene and propylene) and complies with TMC standards.



Fully formulated antifreeze **must** be mixed with high-quality water at a 50/50 ratio (40- to 60-percent working range). A 50/50 mixture of antifreeze and water has a -36°C [-33°F] freezing point and a 110°C [230°F] boiling point, which is adequate for North America. The actual lowest freezing point of ethylene glycol antifreeze is at 68 percent. Using higher concentrations of antifreeze will raise the freezing point of the solution and increase the possibility of a silicate gel problem.



A refractometer **must** be used to measure the freezing point of the coolant accurately.



Do **not** use a floating ball hydrometer. Use of a floating ball hydrometer can give an incorrect reading.

Specifications

Use a low-silicate antifreeze that meets ASTM4985 test (GM6038M specification) criteria.

Concentration

Antifreeze **must** be used in any climate for both freezing- and boiling-point protection. Cummins recommends a 50-percent concentration level (40- to 60-percent range) of ethylene glycol or propylene glycol in most climates. Antifreeze at 68-percent concentration provides the maximum freeze protection and **must never** be exceeded under any condition. Antifreeze protection decreases above 68 percent.

Ethylene Glycol

40% equals -23°C [-9°F]
50% equals -37°C [-35°F]
60% equals -54°C [-65°F]
68% equals -71°C [-96°F]

Propylene Glycol

40% equals -21°C [-6°F]
50% equals -33°C [-27°F]
60% equals -49°C [-56°F]
68% equals -63°C [-81°F]

Concentration Testing

Antifreeze concentration **must** be checked using a refractometer (such as Fleetguard® Part No. CC2800). "Floating-Ball"-type density testers or hydrometers are **not** accurate enough for use with heavy-duty diesel cooling systems.

Coolant Change Recommendation

The coolant **must** be drained and replaced every 2 years or 385,000 km [239,227 mi] to eliminate buildup of harmful chemicals.

Cooling System Additives

Supplemental Coolant Additives (SCA)

Supplemental coolant additives (SCA) are recommended for all Cummins cooling systems. Antifreeze alone does **not** provide sufficient protection for heavy-duty diesel engines.

DCA4

DCA4 is the recommended SCA for all Cummins engines. Other brands can be used if they provide adequate engine protection and do **not** cause seal or gasket degradation or corrosion/fouling.

SCA Concentration

The recommended concentration level of DCA4 is 1.5 units for every 3.7 liters [1 gal]. The DCA4 concentration **must never** exceed 3.0 units for every 3.7 liters [1 gal] nor fall below 1.2 units for every 3.7 liters [1 gal].

DCA4 Filter Change Interval

Supplemental coolant additives deplete during normal engine operation. Cummins recommends that the level be maintained by installation of a service coolant filter on the engine at every 10,000-km [6214-mi], 250-hour, or 3-month interval.

DCA4 Concentration Test

As noted above, the primary method is to maintain proper DCA4 concentration levels by changing the service coolant filter at every 10,000 km [6214 mi], 250 hours, or 3 months. Fleetguard® DCA4 "dipstick" test kit, Part No. CC2626, or Fleetguard® Monitor C™, Part No. CC2700, **must** be used if testing is deemed necessary due to one of the following reasons:

- Addition of untreated make-up coolant in excess of 5.7 liters [6 qt] between maintenance intervals
- Troubleshooting of cooling system problems in the fleet (such as corrosion or seal leakage)
- An optional program in some fleets to monitor SCA levels to determine if maintenance intervals are acceptable.

NOTE: The practice of using a test kit to determine when to add or change the coolant filter is specifically **not** recommended. No other test kit (such as Fleetguard® titration test kit, Part No. 3300846-S or 3825379-S) can be used on Cummins engines with DCA4.

DCA4 Unit Maintenance Guide

Fleetguard® Part No.	Cummins Part No.	DCA4 Units
DCA4 Liquid		
DCA 60L	3315459	4*
DCA4 Filter		
WF-2070	3318157	2
WF-2071	3315116	4
WF-2072	3318201	6
WF-2073	3315115	8
WF-2074	3316053	12
WF-2077	None	0
*If DCA 60L is used, do not use a coolant filter that contains coolant additives. The combination of liquid and filter coolant additives will result in overconcentration.		

DCA4 Maintenance Guide

Maintenance Intervals		
Total Cooling System Capacity	Initial Charge (B)	10,000 km [6000 mi], 250 Hours, or 3 Months
30 to 57 liters [8 to 15 gal]	WF-2074	WF-2070


Notes:

- Consult the vehicle equipment manufacturer's maintenance information for the total cooling system capacity.
- After draining and replacing the coolant, install the initial per-charge coolant filter to provide the recommended level of DCA4 concentration.
- Change the coolant filter at regular intervals to protect the cooling system.
- Check the coolant additive concentration regularly. Check the cooling system using Fleetguard® DCA4 **only** with DCA4 coolant test kit, Part No.CC-2626.

Cooling System Sealing Additives

Do **not** use sealing additives in the cooling system. The use of sealing additives will


- Build up in coolant low-flow areas
- Clog coolant filters
- Plug the radiator and oil cooler
- Possibly damage the water pump seal.



Cooling System Soluble Oils

Do **not** use soluble oils in the cooling system. The use of soluble oils will

- Allow cylinder liner pitting
- Corrode brass and copper
- Damage heat transfer surfaces
- Damage seals and hoses.



Drive Belt Tension

SAE Belt Size	Belt Tension Gauge Part No.		Belt Tension New		Belt Tension Range Used*	
	Click-type	Burroughs	N	lbf	N	lbf
0.380 in	3822524		620	140	270 to 490	60 to 110
0.440 in	3822524		620	140	270 to 490	60 to 110
1/2 in	3822524	ST-1138	620	140	270 to 490	60 to 110
11/16 in	3822524	ST-1138	620	140	270 to 490	60 to 110
3/4 in	3822524	ST-1138	620	140	270 to 490	60 to 110
7/8 in	3822524	ST-1138	620	140	270 to 490	60 to 110
4 rib	3822524	ST-1138	620	140	270 to 490	60 to 110
5 rib	3822524	ST-1138	670	150	270 to 530	60 to 120
6 rib	3822525	ST-1293	710	160	290 to 580	65 to 130
8 rib	3822525	ST-1293	890	200	360 to 710	80 to 160
10 rib	3822525	3823138	1110	250	440 to 890	100 to 200
12 rib	3822525	3823138	1330	300	530 to 1070	120 to 240
12 rib K section	3822525	3823138	1330	300	890 to 1070	200 to 240

NOTE: This chart does not apply to automatic belt tensioners.

- * A belt is considered used if it has been in service for ten minutes or longer.
- * If used belt tension is less than the minimum value, tighten the belt to the maximum used belt value.

Engine Component Torque Values

Torque Table

Component	Wrench Size	Torque Value		
		N•m	ft-lb	in-lb
Aftercooler mounting	10 mm	24	18	
Aftercooler water hose clamp	8 mm	5		44
Alternator link (Delco 10-15 SI)	13 mm	24	18	
Alternator link (Delco 20-27 SI)	3/4 in	43	32	
Alternator mtg. bolt 10-15 SI	15 mm	43	32	
Alternator mtg. 27 SI	18 mm	77	57	
Alternator support (upper)	10 mm	24	18	
Belt tensioner flat bracket	Allen 5 mm	24	18	
Belt tensioner mounting	15 mm	43	32	
Crankshaft damper and pulley	15 mm	137	101	
Crossover clamp	5/16 in	5		44
Tee-bolt-type clamp	11 mm	8		71
Exhaust outlet pipe, v-band clamp	7/16 in	8		71
Fan bracket mounting	10 mm	24	18	
Fan pulley	10 mm	24	18	
Fan pulley	13 mm	43	32	
Fuel filter	75 to 85 mm	Install as specified by filter manufacturer.		
Fuel filter adapter nut	24 mm	32	24	
Lubricating oil filter	75 to 85 mm	3/4 of a turn after contact		
Lubricating oil cooler assembly	10 mm	24	18	
Lubricating oil pan drain plug	17 mm	80	59	
Lubricating oil pan heater plug	27 mm	80	59	
Lubricating oil pressure regulator plug	19 mm	80	59	
Starter mounting	10 mm	43	32	
Thermostat housing	10 mm	24	18	
Water inlet connection	15 mm	43	32	
Water pump mounting	13 mm	24	18	
Rocker lever (valve) cover	15 mm	12		106
Water-in-fuel sensor	19 mm	Hand-tighten		

Arctic Operation

△ CAUTION △

The use of a synthetic-based oil does not justify extended oil change intervals. Extended oil change intervals can decrease engine life due to factors such as corrosion, deposits, and wear.

If an engine is operated in ambient temperatures consistently below -23°C [-9°F], and there are no provisions to keep the engine warm when it is **not** in operation, use a synthetic CE/SF or higher API classification engine oil with adequate low-temperature properties (such as 5W-20 or 5W-30).

The oil supplier is responsible for meeting the performance service specifications represented with its product.

Sealants

Use either the sealants listed below or sealants containing equivalent properties.

Item Description	Sealing Method
Pipe plugs	Precoated teflon or pipe sealer
Cup plugs	Loctite 277 or 11,264
O-rings	Lubriplate™ 105
Rear camshaft expansion plug	Precoated or Loctite 59,241 liquid teflon
Fuel block mounting studs	Loctite 609
Turbocharger drain in block	Loctite 277 or 11,264
Front seal in gear cover	Loctite 277 or 11,264
Rear seal in gear cover	No sealant
Oil pan at T-joint	Three-Bond™ 1207C (Cummins Part No. 3823494)



Capscrew Markings and Torque Values



When replacing capscrews, always use a capscrew of the same measurement and strength as the capscrew being replaced. Using the wrong capscrews can result in engine damage.

Metric capscrews and nuts are identified by the grade number stamped on the head of the capscrew or on the surface of the nuts. U.S. Customary capscrews are identified by radial lines stamped on the head of the capscrew.







The following examples indicate how capscrews are identified:






NOTES:

1. **Always** use the torque values listed in the following tables when specific torque values are **not** available.
2. Do **not** use the torque values in place of those specified in other sections of this manual.
3. The torque values in the table are based on the use of lubricated threads.
4. When the ft-lb value is less than 10, convert the ft-lb value to in-lb to obtain a better torque with an in-lb torque wrench. Example: 6 ft-lb equals 72 in-lb.

Capscrew Markings and Torque Values - Metric

Commercial Steel Class													
8.8					10.9				12.9				
Capscrew Head Markings													
													
Body Size		Torque				Torque				Torque			
Diameter		Cast Iron		Aluminum		Cast Iron		Aluminum		Cast Iron		Aluminum	
mm		N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
6		9	5	7	4	13	10	7	4	14	9	7	4
7		14	9	11	7	18	14	11	7	23	18	11	7
8		23	17	18	14	33	25	18	14	40	29	18	14
10		45	33	30	25	65	50	30	25	70	50	30	25
12		80	60	55	40	115	85	55	40	125	95	55	40
14		125	90	90	65	180	133	90	65	195	145	90	65
16		195	140	140	100	280	200	140	100	290	210	140	100
18		280	200	180	135	390	285	180	135	400	290	180	135
20		400	290	—	—	550	400	—	—	—	—	—	—

Capscrew Markings and Torque Values - U.S. Customary

SAE Grade Number			5		8			
Capscrew Head Markings								
These are all SAE Grade 5 (3 line)								
								
Capscrew Torque - Grade 5 Capscrew					Capscrew Torque - Grade 8 Capscrew			
Capscrew Body Size	Cast Iron		Aluminum		Cast Iron		Aluminum	
	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
1/4 - 20	9	7	8	6	15	11	8	6
1/4 - 28	12	9	9	7	18	13	9	7
5/16 - 18	20	15	16	12	30	22	16	12
5/16 - 24	23	17	19	14	33	24	19	14
3/8 - 16	40	30	25	20	55	40	25	20
3/8 - 24	40	30	35	25	60	45	35	25
7/16 - 14	60	45	45	35	90	65	45	35
7/16 - 20	65	50	55	40	95	70	55	40
1/2 - 13	95	70	75	55	130	95	75	55
1/2 - 20	100	75	80	60	150	110	80	60
9/16 - 12	135	100	110	80	190	140	110	80
9/16 - 18	150	110	115	85	210	155	115	85
5/8 - 11	180	135	150	110	255	190	150	110
5/8 - 18	210	155	160	120	290	215	160	120
3/4 - 10	325	240	255	190	460	340	255	190
3/4 - 16	365	270	285	210	515	380	285	210
7/8 - 9	490	360	380	280	745	550	380	280
7/8 - 14	530	390	420	310	825	610	420	310
1 - 8	720	530	570	420	1100	820	570	420
1 - 14	800	590	650	480	1200	890	650	480

Section W - Warranty

Section Contents

	Page
California Emission Control System Warranty, Off-Highway	W-6
Off-Highway Engines International	W-4
Off-Highway Engines United States and Canada	W-1

THIS PAGE LEFT INTENTIONALLY BLANK

Off-Highway Engines United States and Canada

Coverage

Products Warranted

This warranty applies to new Engines sold by Cummins and delivered to the first user on or after April 1, 1999, that are used in industrial (off-highway) applications in the United States* and Canada, except for Engines used in marine, generator drive and certain defense applications, for which different warranty coverage is provided.

Base Engine Warranty

This warranty covers any failures of the Engine, under normal use and service, which result from a defect in material or factory workmanship (Warrantable Failures).

Coverage begins with the sale of the Engine by Cummins. Coverage continues for two years or 2,000 hours of operation, whichever occurs first, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first. If the 2,000 hour limit is exceeded during the first year, Coverage continues until the end of the first year.

Extended Major Components Warranty

The Extended Major Components Warranty covers Warrantable Failures of the Engine cylinder block, camshaft, crankshaft and connecting rods (Covered Parts).

Bushing and bearing failures are not covered.

This Coverage begins with the expiration of the Base Engine Warranty and ends three years or 10,000 hours of operation from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

Consumer Products

The warranty on Consumer Products in the United States is a LIMITED warranty. **CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Any implied warranties applicable to Consumer Products in the United States terminate concurrently with the expiration of the express warranties applicable to the product. In the United States, some states do not allow the exclusion of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the limitations or exclusions herein may not apply to you.

These warranties are made to all Owners in the chain of distribution, and Coverage continues to all subsequent Owners until the end of the periods of Coverage.

Cummins' Responsibilities

During The Base Engine Warranty

Cummins will pay for all parts and labor needed to repair the damage to the Engine resulting from a Warrantable Failure.

Cummins will pay for the lubricating oil, antifreeze, filter elements, and other maintenance items that are not reusable due to the Warrantable Failure.

Cummins will pay reasonable costs for mechanics to travel to and from the equipment site, including meals, mileage and lodging, when the repair is performed at the site of the failure.

Cummins will pay reasonable labor costs for Engine removal and reinstallation when necessary to repair a Warrantable Failure.

During The Extended Major Components Warranty

Cummins will pay for the repair or, at its option, replacement of the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered part.

Owner's Responsibilities

During The Base Engine Warranty

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items provided during warranty repairs unless such items are not reusable due to the Warrantable Failure.

During The Extended Major Components Warranty

Owner is responsible for the cost of all labor needed to repair the Engine, including the labor to remove and reinstall the Engine. When Cummins elects to repair a part instead of replacing it, Owner is not responsible for the labor needed

to repair the part.

Owner is responsible for the cost of all parts required for the repair except for the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during repair of a Warrantable Failure.

During The Base Engine and Extended Major Components Warranties

Owner is responsible for the operation and maintenance of the Engine as specified in the applicable Cummins Operation and Maintenance Manual. Owner is also responsible for providing proof that all recommended maintenance has been performed.

Before the expiration of the applicable warranty, Owner must notify a Cummins distributor, authorized dealer or other repair location approved by Cummins of any Warrantable Failure and make the Engine available for repair by such facility. Locations in the United States and Canada are listed in the Cummins Off Highway Authorized Dealer Directory.

Owner is responsible for communication expenses, meals, lodging and similar costs incurred as a result of a Warrantable Failure.

Owner is responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all applicable taxes, all business costs and other losses resulting from a Warrantable Failure.

Limitations

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolants or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect oil or fuel or by water, dirt or other contaminants in the fuel or oil.

For power units and fire pumps (package units), this warranty applies to accessories, except for clutches and filters, supplied by Cummins which bear the name of another company.

Except for power units and fire pumps, this warranty does not apply to accessories which bear the name of another company. Such non-warranted accessories include, but are not limited to: alternators, starters, fans**, air conditioning compressors, clutches, filters, transmissions, torque converters, steering pumps, and non-Cummins fan drives, engine compression brakes and air compressors.

Cummins Compusave units are covered by a separate warranty.

Before a claim for excessive oil consumption will be considered, Owner must submit adequate documentation to show that consumption exceeds Cummins published standards.

Failures of belts and hoses supplied by Cummins are not covered beyond the first 500 hours or one year of operation, whichever occurs first.

Parts used to repair a Warrantable Failure may be new Cummins parts, Cummins-approved rebuilt parts, or repaired parts. Cummins is not responsible for failures resulting from the use of parts not approved by Cummins.

A new Cummins or Cummins-approved rebuilt part used to repair a Warrantable Failure assumes the identity of the part it replaced and is entitled to the remaining coverage hereunder.

CUMMINS DOES NOT COVER WEAR OR WEAROUT OF COVERED PARTS.

CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

THESE WARRANTIES SET FORTH HEREIN ARE THE SOLE WARRANTIES MADE BY CUMMINS IN REGARD TO THESE ENGINES. CUMMINS MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Emission Warranty

Products Warranted

This emission warranty applies to new Engines marketed by Cummins that are used in the United States* in vehicles designed for Industrial off-highway use. This warranty applies to Engines delivered to the ultimate purchaser on or after April 1, 1999 for engines up to 750 horsepower, on or after January 1, 2000 for engines 751 horsepower and over.

Coverage

Cummins warrants to the ultimate purchaser and each subsequent purchaser that the Engine is designed, built and equipped so as to conform at the time of sale by Cummins with all U.S. Federal emission regulations applicable at the time of manufacture and that it is free from defects in workmanship or material which would cause it not to meet these regulations within the longer of the following periods: (A) Five years or 3,000 hours of operation, whichever occurs first, as measured from the date of delivery of the Engine to the ultimate purchaser, or (B) The Base Engine Warranty.

If the vehicle in which the Engine is installed is registered in the state of California, a separate California Emission Warranty also applies.

Limitations

Failures, other than those resulting from defects in materials, or workmanship, are not covered by this warranty.

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolant or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect fuel or by water, dirt or other contaminants in the fuel.

Cummins is not responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all business costs or other losses resulting from a Warrantable Failure.

CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

* Includes American Samoa, the Commonwealth of Northern Mariana Islands, Guam, Puerto Rico, and the U.S. Virgin Islands.

** Alternators, starters, and fans ARE covered for the duration of the base engine warranty on B3.3 engines.

Off-Highway Engines International

Coverage

PRODUCTS WARRANTED

This warranty applies to new Engines sold by Cummins and delivered to the first user on or after April 1, 1999, that are used in industrial (off-highway) applications anywhere in the world where Cummins-approved service is available, except the United States* and Canada. Different warranty coverage is provided for Engines used in marine, generator drive and certain defense applications.

BASE ENGINE WARRANTY

This warranty covers any failures of the Engine, under normal use and service, which result from a defect in material or factory workmanship (Warrantable Failure).

Coverage begins with the sale of the Engine by Cummins. Coverage continues for two years or 2,000 hours of operation, whichever occurs first, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first. If the 2,000 hour limit is exceeded during the first year, coverage continues until the end of the first year.

EXTENDED MAJOR COMPONENTS WARRANTY

The Extended Major Components Warranty covers Warrantable Failures of the Engine cylinder block, camshaft, crankshaft and connecting rods (Covered Parts).

Bushing and bearing failures are not covered.

This coverage begins with the expiration of the Base Engine Warranty and ends three years or 10,000 hours of operation, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

These warranties are made to all Owners in the chain of distribution, and Coverage continues to all subsequent Owners until the end of the periods of Coverage.

Cummins' Responsibilities

DURING THE BASE ENGINE WARRANTY

Cummins will pay for all parts and labor needed to repair the damage to the Engine resulting from a Warrantable Failure.

Cummins will pay for the lubricating oil, antifreeze, filter elements, and other maintenance items that are not reusable due to a Warrantable Failure.

Cummins will pay reasonable costs for mechanics to travel to and from the equipment site, including meals, mileage and lodging, when the repair is performed at the site of the failure.

Cummins will pay reasonable labor costs for Engine removal and reinstallation when necessary to repair a Warrantable Failure.

DURING THE EXTENDED MAJOR COMPONENTS WARRANTY

Cummins will pay for the repair or, at its option, replacement of the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered part.

Owner's Responsibilities

DURING THE BASE ENGINE WARRANTY

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during warranty repairs unless such items are not reusable due to the Warrantable Failure.

DURING THE EXTENDED MAJOR COMPONENTS WARRANTY

Owner is responsible for the cost of all labor needed to repair the Engine, including the labor to remove and reinstall the Engine. When Cummins elects to repair a part instead of replacing it, Owner is not responsible for the labor needed to repair the part.

Owner is responsible for the cost of all parts required for the repair except for the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during repair of a Warrantable Failure.

DURING THE BASE ENGINE AND EXTENDED MAJOR COMPONENTS WARRANTIES

Owner is responsible for the operation and maintenance of the Engine as specified in the applicable Cummins Operation and Maintenance Manual. Owner is also responsible for providing proof that all recommended maintenance has been performed.

Before the expiration of the applicable warranty, Owner must notify a Cummins distributor, authorized dealer or other repair location approved by Cummins of any Warrantable Failure and make the product available for repair by such facility. Locations are listed in the Cummins International Sales and Service Directory.

Owner is responsible for communication expenses, meals, lodging and similar costs incurred as a result of a Warrantable Failure.

Owner is responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all applicable taxes, all business costs and other losses resulting from a Warrantable Failure.

Limitations

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolants or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect oil or fuel or by water, dirt or other contaminants in the fuel or oil.

For power units and fire pumps (package units) the warranty applies to accessories, except for clutches and filters supplied by Cummins which bear the name of another company.

Starters, alternators, power steering pumps and non-Cummins air compressors supplied by Cummins on B or C Series Engines that are not supplied as part of a package unit are covered for six months* from the date of delivery of the Engine to the first user, or the date the Engine is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

Except for the accessories noted previously, Cummins does not warrant accessories which bear the name of another company. Such non-warranted accessories include, but are not limited to: alternators, starters, fans*, air conditioning compressors, clutches, filters, transmissions, torque converters, steering pumps, non-Cummins fan drives, and air cleaners.

Cummins Compusave units are covered by a separate warranty.

Before a claim for excessive oil consumption will be considered, Owner must submit adequate documentation to show that consumption exceeds Cummins published standards.

Failures of belts and hoses supplied by Cummins are not covered beyond the first 500 hours or one year of operation, whichever occurs first.

Parts used to repair a Warrantable Failure may be new Cummins parts, Cummins-approved rebuilt parts, or repaired parts. Cummins is not responsible for failures resulting from the use of parts not approved by Cummins.

A new Cummins or Cummins-approved rebuilt part used to repair a Warrantable Failure assumes the identity of the part it replaced and is entitled to the remaining coverage hereunder.

CUMMINS DOES NOT COVER WEAR OR WEAROUT OF COVERED PARTS.

CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

THESE WARRANTIES SET FORTH HEREIN ARE THE SOLE WARRANTIES MADE BY CUMMINS IN REGARD TO THESE ENGINES. CUMMINS MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

In case of consumer sales, in some countries, the Owner has statutory rights which cannot be affected or limited by the terms of this warranty.

Nothing in this warranty excludes or restricts any contractual rights the Owner may have against third parties.

* Alternators, starters, and fans ARE covered for the duration of the base engine warranty on B3.3 engines.

California Emission Control System Warranty, Off-Highway

Products Warranted

This Emission Control System Warranty applies to off-road diesel engines certified with the California Air Resources Board beginning with the year 1996 for engines up to 750 horsepower, beginning with the year 2000 for 751 horsepower and over, marketed by Cummins, and registered in California for use in industrial off-highway applications.

Your Warranty Rights and Obligations

The California Air Resources Board and Cummins Engine Company, Inc., are pleased to explain the emission control system warranty on your engine. In California, new off-road diesel engines must be designed, built and equipped to meet the State's stringent anti-smog standards. Cummins must warrant the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel injection system and the air induction system. Also included may be hoses, belts, connectors and other emission-related assemblies.

Where a warrantable condition exists, Cummins will repair your off-road diesel engine at no cost to you including diagnosis, parts and labor.

Manufacturer's Warranty Coverage

This warranty coverage is provided for 5 years or 3,000 hours of engine operation, whichever first occurs from the date of delivery of the engine to the first user. If any emission-related part on your engine is defective, the part will be repaired or replaced by Cummins.

Coverage

This emission control system warranty applies only to the following emission control parts:

Fuel Pump

Static Timing
Delivery Valve
Injector Supply Line
Injection Control Valve Module

Intake Manifold

Charge Air Cooler

Exhaust Manifold

Oxidation Catalyst

Injectors

Calibration
Needle
Nozzle
Spring

Electronic Control System

Control Module
Boost Pressure Sensor
Coolant Temperature Sensor
Fuel Pressure Sensor

Turbocharger

Compressor Wheel
Turbine Wheel
Turbine Oil Seal
Wastegate Valve

Owner's Warranty Responsibilities

As the off-road diesel engine owner, you are responsible for the performance of the required maintenance listed in your Cummins Operation and Maintenance Manual. Cummins recommends that you retain all receipts covering maintenance on your off-road diesel engine, but Cummins cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your off-road diesel engine to a Cummins dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

As the off-road diesel engine owner, you should also be aware that Cummins may deny you warranty coverage if your off-road diesel engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

Your engine is designed to operate on diesel fuel only. Use of any other fuel may result in your engine no longer operating in compliance with California's emissions requirements.

If you have any questions regarding your warranty rights and responsibilities, you should contact Cummins Customer Assistance Department at 1-800-343-7357 (1-800-DIESELS) or the California Air Resources Board at 9528 Telstar Avenue, El Monte, CA 91731.

Prior to the expiration of the applicable warranty, Owner must give notice of any warranted emission control failure to a Cummins distributor, authorized dealer or other repair location approved by Cummins and deliver the engine to such facility for repair. Repair locations are listed in Cummins United States and Canada Service Directory.

Owner is responsible for incidental costs such as: communication expenses, meals, lodging incurred by Owner or employees of Owner as a result of a warrantable failure.

Owner is responsible for business costs and losses, "downtime" expenses, and cargo damage resulting from a warrantable failure. CUMMINS IS NOT RESPONSIBLE FOR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDE BUT ARE NOT LIMITED TO FINES, THEFT, VANDALISM OR COLLISIONS.

Replacement Parts

Cummins recommends that any service parts used for maintenance, repair or replacement of emission control systems be new, genuine Cummins or Cummins approved rebuilt parts and assemblies, and that the engine be serviced by a Cummins distributor, authorized dealer or the repair location approved by Cummins. The owner may elect to have maintenance, replacement or repair of the emission control parts performed by a facility other than a Cummins distributor, an authorized dealer or a repair location approved by Cummins, and may elect to use parts other than new genuine Cummins or Cummins approved rebuilt parts and assemblies for such maintenance, replacement or repair; however, the cost of such service or parts will not be covered under this emission control system warranty.

Cummins Responsibilities

Repairs and service will be performed by any Cummins distributor, authorized dealer or other repair location approved by Cummins using new, genuine Cummins or Cummins approved rebuilt parts and assemblies. Cummins will repair any of the emission control parts found by Cummins to be defective without charge for parts or labor (including diagnosis which results in determination that there has been a failure of a warranted emission control part).

Emergency Repairs

In the case of an emergency where a Cummins distributor, authorized dealer, or other repair location approved by Cummins is not available, repairs may be performed by any available repair location using any replacement parts. Cummins will reimburse the Owner for expenses (including diagnosis), not to exceed the manufacturer's suggested retail price for all warranted parts replaced and labor charges based on the manufacturer's recommended time allowance for the warranty repair and the geographically appropriate hourly labor rate. A part not being available within 30 days or a repair not being complete within 30 days constitutes an emergency. Replaced parts and paid invoices must be presented at a Cummins authorized repair facility as a condition of reimbursement for emergency repairs not performed by a Cummins distributor, authorized dealer, or other repair location approved by Cummins.

Warranty Limitations

Cummins is not responsible for failures resulting from Owner or operator abuse or neglect, such as: operation without adequate coolant, fuel or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or air intake systems; improper storage, starting, warm-up, run-in or shutdown practices.

The manufacturer warrants to the ultimate purchaser and each subsequent purchaser that the engine is designed, built, and equipped so as to conform with all applicable regulations adopted by the Air Resources Board, and that it is free from defects in materials and workmanship which cause the failure of a warranted part.

Any warranted part which is not scheduled for replacement as required maintenance, or which is scheduled only for regular inspection to the effect of "repair or replace as necessary" is warranted for the warranty period.

Any warranted part which is scheduled for replacement as required maintenance is warranted for the period of time prior to the first scheduled replacement point for that part.

The owner will not be charged for diagnostic labor which leads to the determination that a warranted part is defective, if the diagnostic work is performed at a warranty station.

The manufacturer is liable for damages to other engine components caused by the failure under warranty of any warranted part.

Cummins is not responsible for failures resulting from improper repair or the use of parts which are not genuine Cummins or Cummins approved parts.

These warranties, together with the express commercial warranties and emission warranty are the sole warranties of Cummins. There are no other warranties, express or implied, or of merchantability or fitness for a particular purpose.


This image shows a single page of white paper with horizontal black lines, resembling notebook paper. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

About the Manual	i-1	Preparatory	5-8
Acronyms and Abbreviations	i-5	Remove	5-9
Additional Service Literature	L-1	Coolant Level	3-2
General Information	L-1	Maintenance Check	3-2
Air Compressor	4-3	Coolant Recommendations and Specifications	V-7
Maintenance Check	4-3	Cooling System Additives	V-9
Air Intake Piping	3-4	Cooling System Soluble Oils	V-11
Maintenance Check	3-4	Fully Formulated Coolant/Antifreeze	V-7
Air Intake Restriction	4-2	Coolant Thermostat	A-4
Maintenance Check	4-2	Clean	A-4
Alternator	A-8	Install	A-5
Install	A-9	Preparatory	A-4
Preparatory	A-8	Remove	A-4
Remove	A-9	Cooling System	7-2
Arctic Operation	V-14	Drain	7-2
Belt Tensioner, Automatic	A-1	Fill	7-4
Install	A-2	Flush	7-3
Maintenance Check	6-3	Maintenance Check	5-7
Preparatory	A-1	Crankcase Breather Tube	3-5
Remove	A-2	Maintenance Check	3-5
California Emission Control System Warranty, Off-Highway .	W-6	Daily Maintenance Procedures - General Information	3-1
Capscrew Markings and Torque Values	V-15	General Information	3-1
Capscrew Markings and Torque Values - Metric	V-16	Drive Belt Tension	V-12
Capscrew Markings and Torque Values - U.S. Customary	V-17	Drive Belt, Water Pump	A-1
Charge-Air Cooler (CAC)	A-5	Install	A-1
General Information	A-5	Remove	A-1
Leak Test	A-6	Drive Belts	6-2
Maintenance Check	4-2	Maintenance Check	6-2
Pressure Test	A-6	Driving Techniques	1-40
Temperature Differential Test	A-6	General Information	1-40
Charge-Air Piping	4-2	Electromagnetic Interference (EMI)	1-41
Maintenance Check	4-2	General Information	1-41
Cold Weather Operation	1-7	System EMI Radiation Levels	1-41
Customer Precharge Method	1-8	System EMI Susceptibility	1-41
General Information	1-7	Electronic Controlled Fuel System	1-9
Shutters	1-9	Basic Features	1-12
Winterfronts	1-9	Diagnostic Fault Codes	1-37
Cold Weather Starting Using Starting Fluid	1-4	Engine Protection System	1-11
Ether Starting Aids	1-4	General Information	1-9
Component Manufacturers' Addresses	M-1	Programmable Features	1-16
Air Compressors	M-1	Engine Component Torque Values	V-13
Air Cylinders	M-1	Torque Table	V-13
Air Heaters.....	M-1	Engine Diagrams	E-5
Air Starting Motors	M-1	Engine Views	E-5
Alternators	M-1	Engine Identification	E-1
Auxiliary Brakes	M-1	Cummins Engine Nomenclature	E-2
Belts	M-1	ECM Dataplate	E-2
Catalytic Converters	M-1	Engine Dataplate	E-1
Clutches	M-1	Fuel Injection Pump Dataplate	E-2
Coolant Heaters	M-2	Engine Operating Range	1-5
Coolant Level Switches	M-1	General Information	1-5
Drive Plates	M-2	Engine Shutdown	1-9
Electric Starting Motors	M-2	General Information	1-9
Electronic Switches	M-2	Fan, Cooling	3-3
Engine Protection Controls.....	M-2	Inspect for Reuse	3-3
Fan Clutches.....	M-2	Fan Hub, Belt Driven	6-2
Fans.....	M-2	Maintenance Check	6-2
Fault Lamps.....	M-2	Fan Spacer and Pulley	A-3
Filters.....	M-2	Install	A-3
Flexplates	M-2	Preparatory	A-3
Fuel Coolers	M-2	Remove	A-3
Fuel Pumps	M-2	Flow Diagram, Air Intake System	D-8
Fuel Warmers	M-2	Flow Diagram, Compressed Air System	D-10
Gauges	M-3	Flow Diagram, Cooling System	D-7
General Information	M-1	Flow Diagram, Exhaust System	D-9
Governors	M-3	Flow Diagram, Fuel System	D-2
Heat Sleeves.....	M-3	Flow Diagram, Lubricating Oil System	D-3
Hydraulic and Power Steering Pumps	M-3	Fuel Filter (Spin-On Type)	5-4
In-Line Connectors.....	M-3	Inspect for Reuse	5-6
Oil Heaters.....	M-3	Install	5-6
Prelubrication Systems.....	M-3	Preparatory	5-4
Radiators	M-3	Remove	5-5
Throttle Assemblies.....	M-3	Fuel Pump	4-3
Torque Converters.....	M-3	Maintenance Check	4-3
Coolant Filter	5-8	Fuel Recommendations and Specifications	V-3
Clean	5-9	Cummins/Fleetguard®/Nelson Filter Specifications	V-4
Install	5-10	Fuel Filters	V-4

Index

Page 2

Fuel Recommendations	V-3	Engine Difficult to Start or Will Not Start (No Exhaust Smoke)	TS-15
Fuel-Water Separator	3-2	Engine Noise Excessive	TS-16
Drain	3-2	Engine Noise Excessive — Combustion Knocks	TS-18
General Safety Instructions	i-4	Engine Power Output Low	TS-19
Important Safety Notice	i-4	Engine Runs Rough at Idle	TS-21
How to Use the Manual	i-1	Engine Runs Rough or Misfires	TS-22
Illustrations	i-3	Engine Shuts Off Unexpectedly or Dies During Deceleration	TS-23
Lubricating Oil and Filters	5-2	Engine Speed Surges at Low or High Idle	TS-24
Oil Drain Intervals	5-2	Engine Speed Surges in PTO or Cruise Control	TS-26
Lubricating Oil Level	3-2	Engine Speed Surges Under Load or in Operating Range ..	TS-25
Maintenance Check	3-2	Engine Starts But Will Not Keep Running	TS-27
Lubricating Oil Recommendations and Specifications	V-5	Engine Vibration Excessive	TS-28
Cummins/Fleetguard®/Nelson Filter Specifications	V-7	Engine Will Not Crank or Cranks Slowly (Air Starter)	TS-29
General Information	V-6	Engine Will Not Crank or Cranks Slowly (Electric Starter)	TS-30
New Engine Break-in Oils	V-5	Engine Will Not Reach Rated Speed (RPM)	TS-31
Arctic Operation Engine Oil	V-5	Fault Code Warning Lamps Do Not Illuminate	TS-33
Maintenance Guidelines - General Information	2-1	Fault Code Warning Lamps Stay On (No Apparent Reason) ..	TS-32
Maintenance Procedures - General Information	4-1	Fuel Consumption Excessive	TS-34
General Information	4-1	Fuel in Coolant	TS-35
Maintenance Record Form	2-5	Fuel in the Lubricating Oil	TS-36
Maintenance Schedule	2-2	General Information	TS-2
Oil Drain Intervals	2-3	Intake Manifold Air Temperature Above Specification	TS-37
Normal Starting Procedure	1-2	Intake Manifold Pressure (Boost) is Below Normal	TS-39
Off-Highway Engines International	W-4	Lubricating Oil Consumption Excessive	TS-40
Off-Highway Engines United States and Canada	W-1	Lubricating Oil Contaminated	TS-41
Operating Instructions - General Information	1-1	Lubricating Oil Pressure High	TS-42
Operating the Engine	1-4	Lubricating Oil Pressure Low	TS-43
General Information	1-4	Lubricating Oil Sludge in the Crankcase Excessive	TS-44
Overhead Set	8-2	Smoke, Black — Excessive	TS-45
General Information	8-2	Smoke, White — Excessive	TS-46
Measure	8-2	Turbocharger Leaks Engine Oil or Fuel	TS-48
Page References for Maintenance Instructions	2-4	Vibration Damper	7-5
Sealants	V-14	Inspect	7-5
Service Assistance	S-1	Vibration Damper, Rubber	7-5
Distributors - International	S-19	Inspect	7-5
Distributors and Branches - Australia	S-16		
Distributors and Branches - Canada	S-14		
Distributors and Branches - New Zealand	S-18		
Distributors and Branches - United States	S-7		
Division and Regional Offices	S-3		
Emergency and Technical Service	S-1		
Problem Solving	S-2		
Regional Offices - International	S-4		
Routine Service and Parts	S-1		
Service Literature Ordering Location	L-2		
General Information	L-2		
Specifications	E-3		
Air Intake System	E-4 , V-2		
Batteries (Specific Gravity)	E-4 , V-2		
Cooling System	E-4 , V-2		
Cummins/Fleetguard®/Nelson Filter Specifications	V-3		
Electrical System	E-4 , V-2		
Exhaust System	E-4 , V-2		
Fuel System	E-3 , V-1		
General Specifications	E-3 , V-1		
Lubricating Oil System	E-3 , V-1		
Starting Motor	A-7		
Install	A-8		
Preparatory	A-7		
Remove	A-7		
Symbols	i-2		
System Diagrams - General Information	D-1		
To the Owner and Operator	i-1		
Tool Requirements	2-1		
Troubleshooting Procedures and Techniques	TS-1		
General Information	TS-1		
Troubleshooting Symptoms Charts	TS-2		
Alternator Not Charging or Insufficient Charging	TS-3		
Alternator Overcharging	TS-4		
Coolant Loss — External	TS-5		
Coolant Temperature Above Normal — Gradual Overheat	TS-6		
Coolant Temperature is Above Normal — Sudden Overheat ...	TS-8		
Coolant Temperature is Below Normal	TS-9		
Cranking Fuel Pressure is Low	TS-10		
Engine Acceleration or Response Poor	TS-11		
Engine Difficult to Start or Will Not Start (Exhaust Smoke) ..	TS-13		




NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 15, COLUMBUS INDIANA

—POSTAGE WILL BE PAID BY ADDRESSEE—

Cummins Engine Company, Inc.
Product Registration Dept. (CAC)
P O Box 3005 M/C 91200
Columbus, IN 47202-3005



In order to serve you better it is very important that you fill out and return this card **within** 30 days of purchase.

Customer Name _____

Address _____

City / State _____

Zip Code _____

Home Phone Number (____)_____


Truck Phone / Cell Phone (____)_____

E-mail Address _____

Engine Serial Number _____

Date Purchased ____/____/____ VIN # _____

THANK YOU!!




NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 15, COLUMBUS INDIANA

—POSTAGE WILL BE PAID BY ADDRESSEE—

CUMMINS ENGINE COMPANY, INC.
MAIL CODE 41302
BOX 3005
COLUMBUS, IN 47202-3005



**Do not use this form to order additional literature. Refer to
Section L - Service Literature for literature information.**

Literature Survey Form

Bulletin No.: 3666472-00

We are always open to any suggestions or recommendations that will aid in improving our manuals. Use this postage paid survey form to evaluate this manual. Please check the appropriate response and use the space provided below to list any additional comments:

	Yes	No
Is the needed information easy to locate in the manual?	<input type="checkbox"/>	<input type="checkbox"/>
Is the information easy to read?	<input type="checkbox"/>	<input type="checkbox"/>
Is the information easy to understand?	<input type="checkbox"/>	<input type="checkbox"/>
Does the information sufficiently cover the subject?	<input type="checkbox"/>	<input type="checkbox"/>
Are subjects in the Index specific enough to locate in the manual?	<input type="checkbox"/>	<input type="checkbox"/>
Are the important points sufficiently emphasized?	<input type="checkbox"/>	<input type="checkbox"/>
Are the illustrations easy to understand?	<input type="checkbox"/>	<input type="checkbox"/>
Does the text support the operation being illustrated?	<input type="checkbox"/>	<input type="checkbox"/>
Do you use the Table of Contents and Section Contents?	<input type="checkbox"/>	<input type="checkbox"/>
Do you use the Index?	<input type="checkbox"/>	<input type="checkbox"/>

Please provide comments on any response(s) marked No in this survey and on any suggestions you feel could improve our manuals.

Name:

Company:

Street Address:

City: State/Province:

Country: Zip/Postal Code:

Do not use this form to order additional literature. Refer to Section L - Service Literature for literature information.

Cummins Engine Company, Inc.
Box 3005
Columbus, Indiana, U.S.A., 47202

Registered Office
Cummins Engine Company, Ltd.
46-50 Coombe Road
New Malden,
Surrey KT3 4QL,
England
Registration No. 573951 England

Copyright© 2000
Cummins Engine Company, Inc.