



# Ingersoll-Rand

## Utility Equipment

### C8.3 CUMMINS ENGINE OPERATION & MAINTENANCE MANUAL FOR:

**HP675WCU**

**XP825WCU**

**HP750WCU**

**XP750WCU**

**CODE: D**

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.


**Ingersoll-Rand®**

**Utility Equipment**  
**P.O. Box 868 - 501 Sanford Ave**  
**Mocksville, N.C. 27028**  
**[www.portablepower.irco.com](http://www.portablepower.irco.com)**

**Revised (10-12)**



# Operation and Maintenance Manual Industrial C8.3 Series Engine



ew900gu

## Foreword

This manual contains information for the correct operation and maintenance of your Cummins engine. It also includes important safety information, engine and systems specifications, troubleshooting guidelines, and listings of Cummins Authorized Repair Locations and component manufacturers.

**Read and follow all safety instructions. Refer to the WARNING in the General Safety Instructions in Section I - Introduction.**

Keep this manual with the equipment. If the equipment is traded or sold, give the manual to the new owner.

The information, specifications, and recommended maintenance guidelines in this manual are based on information in effect at the time of printing. Cummins Inc. reserves the right to make changes at any time without obligation. If you find differences between your engine and the information in this manual, contact your local Cummins Authorized Repair Location or call 1-800-DIESELS (1-800-343-7357) toll free in the U.S. and Canada.

The latest technology and the highest quality components were used to produce this engine. When replacement parts are needed, we recommend using only genuine Cummins or ReCon® exchange parts. These parts can be identified by the following trademarks:



**NOTE:** Note: Warranty information is located in Section W. Make sure you are familiar with the warranty or warranties applicable to your engine.

# Table of Contents

	Section
Introduction .....	i
Engine Identification .....	E
Operating Instructions .....	1
Maintenance Guidelines .....	2
Maintenance Procedures at Daily Interval .....	3
Maintenance Procedures at 10,000 Kilometers [6000 Miles], 250 Hours, or 3 Months .....	4
Maintenance Procedures at 19,000 Kilometers [12,000 Miles], 500 Hours, or 6 Months .....	5
Maintenance Procedures at 38,000 Kilometers [24,000 Miles], 1000 Hours, or 12 Months .....	6
Maintenance Procedures at 77,000 Kilometers [48,000 Miles], 2000 Hours, or 2 Years .....	7
Adjustment, Repair, and Replacement .....	A
System Diagrams .....	D
Service Literature .....	L
Component Manufacturers .....	M
Service Assistance .....	S
Troubleshooting Symptoms .....	TS
Maintenance Specifications .....	V
Warranty .....	W
Index .....	X



## Important Reference Numbers

Fill in the part name and number in the blank spaces provided below. This will give you a reference whenever service or maintenance is required.

Part Name	Part Number	Part Number
Engine Model		
Engine Serial Number (ESN)		
Control Parts List (CPL)		
Fuel Pump Part Number		
Electronic Control Module (ECM)		
Electronic Control Module Serial Numbers (ECM)		
Filter Part Numbers:		
• Air Cleaner Element		
• Lubricating Oil Filter		
• Fuel		
• Fuel-Water Separator		
• Coolant		
• Remote Gas		
Governor Control Module (GCM) (if applicable)		
Belt Part Numbers:		
•		
•		
•		
Clutch or Marine Gear (if applicable):		
• Model		
• Serial Number		
• Part Number		
• Oil Type		
• Sea Water Pump		
– Model		
– Part Number		

Section i - Introduction  
Section Contents

	Page
<b>Maintenance Guidelines - Overview</b> .....	2-1
General Information .....	2-1
<b>Tool Requirements</b> .....	2-1
General Information .....	2-1
<b>Maintenance Schedule</b> .....	2-1
General Information .....	2-1
Maximum Oil Drain Intervals .....	2-2
<b>Maintenance Record Form</b> .....	2-3
Maintenance Data .....	2-3

**THIS PAGE LEFT INTENTIONALLY BLANK**

## To the Owner and Operator

### General Information

Preventive maintenance is the easiest and least expensive type of maintenance. Follow the maintenance schedule recommendations outlined in Maintenance Guidelines (Section 2).

Keep records of regularly scheduled maintenance.

Use the correct fuel, lubricating oil, and coolant in your engine as specified in Maintenance Specifications (Section V).

Cummins Inc. uses the latest technology and the highest quality components to produce its engines. Cummins Inc. recommends using genuine Cummins new parts and ReCon® exchange parts.

Personnel at Cummins Authorized Repair Locations have been trained to provide expert service and parts support. If you have a problem that can **not** be resolved by a Cummins Authorized Repair Location, follow the steps outlined in the Service Assistance (Section S).

Product coverage, warranty limitations and owner responsibilities are available in Warranty (Section W).

### CAUTION

**Disconnect both the positive (+) and negative (-) battery cables from the battery before welding on the vehicle. Attach the welder ground cable no more than 0.61 meters [2 feet] from the part being welded. Do not connect the ground cable of the welder to the ECM cooling plate or ECM. Welding on the engine or engine mounted components is not recommended.**

## About the Manual

### General Information

This manual contains information needed to correctly operate and maintain your engine as recommended by Cummins Inc. For additional service literature and ordering locations, refer to Service Literature (Section L).

This manual does not cover vehicle, vessel, or equipment maintenance procedures. Consult the original vehicle, vessel, or equipment manufacturer for specific maintenance recommendations.

Both metric and U.S. customary values are listed in this manual. The metric value is listed first, followed by the U.S. customary in brackets.

Numerous illustrations and symbols are used to aid in understanding the meaning of the text. Refer to Symbols in this section for a complete listing of symbols and their definitions.

Each section of the manual is preceded by a Section Contents to aid in locating information.

## How to Use the Manual

### General Information

This manual is organized according to intervals at which maintenance on your engine is to be performed. A maintenance schedule, that states the required intervals and maintenance checks, is located in Maintenance Guidelines (Section 2). Locate the interval at which you are performing maintenance; then follow the steps given in that section for all the procedures to be performed.

Keep a record of all the checks and inspections made. A maintenance record form is located in Maintenance Guidelines (Section 2).

Engine troubleshooting procedures for your engine are located in Troubleshooting Symptoms (Section TS).

Specifications for your engine are located in Maintenance Specifications (Section V).

## Symbols

### General Information

The following symbols have been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below:



**WARNING** - Serious personal injury or extensive property damage can result if the warning instructions are not followed.



**CAUTION** - Minor personal injury can result or a part, an assembly, or the engine can be damaged if the caution instructions are not followed.



Indicates a **REMOVAL** or **DISASSEMBLY** step.



Indicates an **INSTALLATION** or **ASSEMBLY** step.



**INSPECTION** is required.



**CLEAN** the part or assembly.



**PERFORM** a mechanical or time **MEASUREMENT**.



**LUBRICATE** the part or assembly.



Indicates that a **WRENCH** or **TOOL SIZE** will be given.



**TIGHTEN** to a specific torque.



**PERFORM** an electrical **MEASUREMENT**.



Refer to another location in this manual or another publication for additional information.




The component weighs 23 kg [50 lbs] or more. To reduce the possibility of personal injury, use a hoist or get assistance to lift the component.

17800009


## Illustrations

### General Information

Some of the illustrations throughout this manual are generic and will **not** look exactly like the engine or parts used in your application. The illustrations can contain symbols to indicate an action required and an acceptable or **not** acceptable condition.



The illustrations are intended to show repair or replacement procedures. The procedure will be the same for all applications, although the illustration can differ.



## General Safety Instructions

### Important Safety Notice



**Improper practices, carelessness, or ignoring the warnings can cause burns, cuts, mutilation, asphyxiation or other personal injury or death.**

Read and understand all of the safety precautions and warnings before performing any repair. This list contains the general safety precautions that **must** be followed to provide personal safety. Special safety precautions are included in the procedures when they apply.

- Work in an area surrounding the product that is dry, well lit, ventilated, free from clutter, loose tools, parts, ignition sources and hazardous substances. Be aware of hazardous conditions that can exist.
- **Always** wear protective glasses and protective shoes when working.
- Rotating parts can cause cuts, mutilation or strangulation.
- Do **not** wear loose-fitting or torn clothing. Remove all jewelry when working.
- Disconnect the battery (negative [-] cable first) and discharge any capacitors before beginning any repair work. Disconnect the air starting motor if equipped to prevent accidental engine starting. Put a “Do **Not** Operate” tag in the operator’s compartment or on the controls.
- Use **ONLY** the proper engine barring techniques for manually rotating the engine. Do **not** attempt to rotate the crankshaft by pulling or prying on the fan. This practice can cause serious personal injury, property damage, or damage to the fan blade(s) causing premature fan failure.
- If an engine has been operating and the coolant is hot, allow the engine to cool before slowly loosening the filler cap to relieve the pressure from the cooling system.
- **Always** use blocks or proper stands to support the product before performing any service work. Do **not** work on anything that is supported **ONLY** by lifting jacks or a hoist.
- Relieve all pressure in the air, oil, fuel, and cooling systems before any lines, fittings, or related items are removed or disconnected. Be alert for possible pressure when disconnecting any device from a system that utilizes pressure. Do **not** check for pressure leaks with your hand. High pressure oil or fuel can cause personal injury.
- To reduce the possibility of suffocation and frostbite, wear protective clothing and **ONLY** disconnect liquid refrigerant (Freon) lines in a well ventilated area. To protect the environment, liquid refrigerant systems **must** be properly emptied and filled using equipment that prevents the release of refrigerant gas (fluorocarbons) into the atmosphere. Federal law requires capturing and recycling refrigerant.
- To reduce the possibility of personal injury, use a hoist or get assistance when lifting components that weigh 23 kg [50 lb] or more. Make sure all lifting devices such as chains, hooks, or slings are in good condition and are of the correct capacity. Make sure hooks are positioned correctly. **Always** use a spreader bar when necessary. The lifting hooks **must not** be side-loaded.
- Corrosion inhibitor, a component of SCA and lubricating oil, contains alkali. Do **not** get the substance in eyes. Avoid prolonged or repeated contact with skin. Do **not** swallow internally. In case of contact, immediately wash skin with soap and water. In case of contact, immediately flood eyes with large amounts of water for a minimum of 15 minutes. **IMMEDIATELY CALL A PHYSICIAN. KEEP OUT OF REACH OF CHILDREN.**
- Naptha and Methyl Ethyl Ketone (MEK) are flammable materials and **must** be used with caution. Follow the manufacturer’s instructions to provide complete safety when using these materials. **KEEP OUT OF REACH OF CHILDREN.**
- To reduce the possibility of burns, be alert for hot parts on products that have just been turned off, and hot fluids in lines, tubes, and compartments.
- **Always** use tools that are in good condition. Make sure you understand how to use the tools before performing any service work. Use **ONLY** genuine Cummins or Cummins ReCon® replacement parts.
- **Always** use the same fastener part number (or equivalent) when replacing fasteners. Do **not** use a fastener of lesser quality if replacements are necessary.
- Do **not** perform any repair when fatigued or after consuming alcohol or drugs that can impair your functioning.
- Some state and federal agencies in the United States of America have determined that used engine oil can be carcinogenic and can cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil.
- Liquified petroleum gas is heavier than air and can accumulate near the floor, in sumps, and low-lying areas.
- Natural gas is lighter than air and can accumulate under hood and awnings.
- To reduce the possibility of suffocation and frostbite, wear protective clothing and **ONLY** disconnect natural gas and liquified petroleum gas lines in a well ventilated area.
- Coolant is toxic. If **not** reused, dispose of in accordance with local environmental regulations.

## General Repair Instructions

### General Information

This engine incorporates the latest technology at the time it was manufactured; yet, it is designed to be repaired using normal repair practices performed to quality standards.

- **Cummins Inc. does not recommend or authorize any modifications or repairs to engines or components except for those detailed in Cummins Service Information. In particular, unauthorized repair to safety-related components can cause personal injury or death. Below is a partial listing of components classified as safety-related:**

Air Compressor  
Air Controls  
Air Shutoff Assemblies  
Balance Weights  
Cooling Fan  
Fan Hub Assembly  
Fan Mounting Bracket(s)  
Fan Mounting Capscrews  
Fan Hub Spindle  
Flywheel  
Flywheel Crankshaft Adapter

Flywheel Mounting Capscrews  
Fuel Shutoff Assemblies  
Fuel Supply Tubes  
Lifting Brackets  
Throttle Controls  
Turbocharger Compressor Casing  
Turbocharger Oil Drain Line(s)  
Turbocharger Oil Supply Line(s)  
Turbocharger Turbine Casing  
Vibration Damper Mounting Capscrews

- **Follow all safety instructions noted in the procedures**
  - Follow the manufacturer's recommendations for cleaning solvents and other substances used during the repair of the engine. Some solvents and used engine oil have been identified by government agencies as toxic or carcinogenic. Avoid excessive breathing, ingestion and contact with such substances. **Always** use good safety practices with tools and equipment.
- **Provide a clean environment and follow the cleaning instructions specified in the procedures**
  - The engine and its components **must** be kept clean during any repair. Contamination of the engine or components will cause premature wear.
- **Perform the inspections specified in the procedures**
- **Replace all components or assemblies which are damaged or worn beyond the specifications**
- **Use genuine Cummins new or ReCon® service parts and assemblies**
  - The assembly instructions have been written to use again as many components and assemblies as possible. When it is necessary to replace a component or assembly, the procedure is based on the use of new Cummins or Cummins ReCon® components. All of the repair services described in this manual are available from all Cummins Distributors and most Dealer locations.
- **Follow the specified disassembly and assembly procedures to reduce the possibility of damage to the components**

Complete rebuild instructions are available in the shop manual which can be ordered or purchased from a Cummins Authorized Repair Location. Refer to Section L — Service Literature for ordering instructions.

### Welding on a Vehicle with an Electronic Controlled Fuel System

#### CAUTION

Disconnect both the positive (+) and negative (-) battery cables from the battery before welding on the vehicle. Attach the welder ground cable no more than 0.61 meters [2 feet] from the part being welded. Do not connect the ground cable of the welder to the ECM cooling plate or ECM. Welding on the engine or engine mounted components is not recommended or damage to the engine or components can result.

## General Cleaning Instructions

### Solvent and Acid Cleaning

Several solvent and acid-type cleaners can be used to clean the engine parts. Experience has shown that the best results can be obtained using a cleaner that can be heated to 90 to 95 degrees Celsius [180 to 200 degrees Fahrenheit]. A cleaning tank that provides a constant mixing and filtering of the cleaning solution will give the best results. **Cummins**



**Inc. does not recommend any specific cleaners. Always** follow the cleaner manufacturer's instructions.

Remove all the gasket material, o-rings, and the deposits of sludge, carbon, etc., with a wire brush or scraper before putting the parts in a cleaning tank. Be careful **not** to damage any gasket surfaces. When possible, steam clean the parts before putting them in the cleaning tank.

**▲ WARNING ▲**

**Acid is extremely dangerous and can cause personal injury and damage the machinery. Always provide a tank of strong soda water as a neutralizing agent. Wear goggles and protective clothing to reduce the possibility of serious personal injury.**

Rinse all of the parts in hot water after cleaning. Dry completely with compressed air. Blow the rinse water from all of the capscrew holes and the oil drillings.

If the parts are **not** to be used immediately after cleaning, dip them in a suitable rustproofing compound. The rustproofing compound **must** be removed from the parts before installation on the engine.

### Steam Cleaning

Steam cleaning can be used to remove all types of dirt that can contaminate the cleaning tank. It is a good way to clean the oil drillings.

**▲ WARNING ▲**

**When using a steam cleaner, wear safety glasses or a face shield, as well as protective clothing. Hot steam can cause serious personal injury.**

Do **not** steam clean the following parts:

- |                          |                                    |
|--------------------------|------------------------------------|
| 1. Electrical Components | 5. Belts and Hoses                 |
| 2. Wiring                | 6. Bearings                        |
| 3. Injectors             | 7. Electronic Control Module (ECM) |
| 4. Fuel Pump             | 8. ECM Connectors                  |

### Glass or Plastic Bead Cleaning

Glass or plastic bead cleaning can be used on many engine components to remove carbon deposits. The cleaning process is controlled by the size of the glass or plastic beads, the operating pressure, and the cleaning time.

**▲ CAUTION ▲**

**Do not use glass or plastic bead cleaning on aluminum piston skirts. Do not use glass bead cleaning on aluminum ring grooves. Small particles of glass or plastic will embed in the aluminum and result in premature wear. Valves, turbocharger shafts, etc., can also be damaged. Follow the cleaning directions listed in the procedures.**

**NOTE:** Plastic bead blasting media, Part No. 3822735, can be used to clean aluminum ring grooves. Do **not** use any bead blasting media on pin bores or aluminum skirts.

Follow the equipment manufacturer's cleaning instructions. The following guidelines can be used to adapt to manufacturer's instructions:

1. Bead size:
  - a. Use U.S. size No. 16-20 for piston cleaning with plastic bead media, Part No. 3822735.
  - b. Use U.S. size No. 70 for piston domes with glass media.
  - c. Use U.S. size No. 60 for general purpose cleaning with glass media.
2. Operating Pressure:
  - a. Glass: Use 620 kPa [90 psi] for general purpose cleaning.
  - b. Plastic: Use 270 kPa [40 psi] for piston cleaning.
3. Steam clean or wash the parts with solvent to remove all of the foreign material and glass or plastic beads after cleaning. Rinse with hot water. Dry with compressed air.
4. Do **not** contaminate the wash tanks with glass or plastic beads.

## Acronyms and Abbreviations

### General Information

The following list contains some of the acronyms and abbreviations used in this manual.

<b>API</b>	American Petroleum Institute
<b>ASTM</b>	American Society of Testing and Materials
<b>°C</b>	Celsius
<b>CARB</b>	California Air Resources Board
<b>C.I.D.</b>	Cubic Inch Displacement
<b>CNG</b>	Compressed Natural Gas
<b>CPL</b>	Control Parts List
<b>cSt</b>	Centistokes
<b>ECM</b>	Electronic Control Module
<b>EGR</b>	Exhaust Gas Recirculation
<b>EPA</b>	Environmental Protection Agency
<b>°F</b>	Fahrenheit
<b>FMI</b>	Failure Mode Identifier
<b>GVW</b>	Gross Vehicle Weight
<b>LPG</b>	Liquefied Petroleum Gas
<b>Hg</b>	Mercury
<b>hp</b>	Horsepower
<b>H<sub>2</sub>O</b>	Water
<b>ICM</b>	Ignition Control Module
<b>km/l</b>	Kilometers per Liter
<b>kPa</b>	Kilopascal
<b>LNG</b>	Liquid Natural Gas
<b>LTA</b>	Low Temperature Aftercooling
<b>MPa</b>	Megapascal
<b>mph</b>	Miles Per Hour
<b>mpq</b>	Miles Per Quart
<b>N•m</b>	Newton-meter
<b>NG</b>	Natural Gas
<b>OEM</b>	Original Equipment Manufacturer
<b>PID</b>	Parameter Identification Descriptions
<b>ppm</b>	Parts Per Million
<b>psi</b>	Pounds Per Square Inch
<b>PTO</b>	Power Takeoff
<b>rpm</b>	Revolutions Per Minute
<b>SAE</b>	Society of Automotive Engineers
<b>SCA</b>	Supplemental Coolant Additive
<b>STC</b>	Step Timing Control
<b>SID</b>	Subsystem Identification Descriptions
<b>VS</b>	Variable Speed
<b>VSS</b>	Vehicle Speed Sensor

## NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

**Section E - Engine and System Identification**  
**Section Contents**

	Page
<b>Engine Diagrams</b> .....	E-3
Engine Views .....	E-3
<b>Engine Identification</b> .....	E-1
Cummins Engine Nomenclature .....	E-2
Industrial Applications .....	E-2
Engine Dataplate .....	E-1
Industrial Applications .....	E-1
Fuel Injection Pump Dataplate .....	E-2

**THIS PAGE LEFT INTENTIONALLY BLANK**

## Engine Identification

### Engine Dataplate


#### Industrial Applications

The engine dataplates show specific information about your engine. The engine serial number and control parts list (CPL) provide information for ordering parts and service manuals.


**NOTE:** The engine dataplate **must not** be changed unless approved by Cummins Inc.

The dataplate is located on the top side of the gear housing. Have the following engine data available when communicating with a Cummins Authorized Repair Location. The information on the dataplate is **mandatory** when sourcing service parts.

1. Control parts list (CPL)
2. Model
3. Engine serial number
4. Emissions certification
5. Horsepower and rpm rating.

 <p>Cummins Engine Company, Inc. Columbus, Indiana 47202-3005 Assembled in U.S.A.</p> <p>Warnings: Injury can result and warranty is voided If fuel rate rpm or altitudes exceed published maximum values for this model and application.</p> <p>Date of MFG. 20010501 Assembled in U.S.A. 3284906</p>	CID/L		CPL		Engine Serial No.		FEL	EPA
	Family				C/S		Nox	
					Engine Model		Pm	
	Valve lash		Inch	Int.	Exh	Timing -		
Cold		MM	Int.	Exh	Fuel rate at rated HP/Kw mm3/st			
Firing Order 1 5 3 6 2 4					FR		Low Idle RPM	
Gross Rated HP/KW					at		RPM	

0000075



## Cummins Engine Nomenclature

### Industrial Applications

The following example shows a model name of an engine for industrial applications:

**Example:** 6CTAA8.3


8.3 = displacement in liters

AA = charge air aftercooled

T = turbocharged


C = engine series

6 = number of cylinders



### Fuel Injection Pump Dataplate

The Bosch® fuel injection pump dataplate is located on the side of the injection pump. It provides information for fuel pump calibration.




The Cummins part number for the fuel pump-governor combination is located on the governor dataplate.

## Engine Diagrams

### Engine Views

The following drawings illustrate the major components. You **must** be familiar with each component to conduct the maintenance and service procedures discussed in this manual.

**NOTE:** The drawings in this section reflect a standard configuration. Your engine will possibly be equipped with optional accessories such as port- or starboard-side dipsticks. Location of optional items can be different from those shown.




00900322

Fuel Pump Side View

- |  |                                   |
|--|-----------------------------------|
| 1. Engine air inlet                          | 10. Lubricating oil dipstick      |
| 2. Shutoff solenoid                          | 11. Front engine mounting bracket |
| 3. M22 x 1.5 (air)                           | 12. Engine dataplate              |
| 4. Rear lifting bracket                      | 13. Fuel injection pump           |
| 5. Fuel filter                               | 14. Delivery valve                |
| 6. Fuel/water separator                      | 15. Fuel drain line               |
| 7. Fuel transfer pump                        | 16. High-pressure fuel lines      |
| 8. 3/4 x 16-inch UNF tap for magnetic pickup | 17. 1/2-inch NPTF (air)           |
| 9. Lubricating oil pan drain plug            | 18. Intake air heater.            |






00900321

Rear View


- |                                |                                 |
|--------------------------------|---------------------------------|
| 1. Turbocharger exhaust outlet | 4. Flywheel                     |
| 2. Flexplate mounting holes    | 5. Crankcase breather tube      |
| 3. Flywheel housing            | 6. Rear engine lifting bracket. |



00900323

Exhaust Side View


- |   |                                     |
|---|-------------------------------------|
| 1. Front engine lifting bracket             | 10. Turbocharger oil drain          |
| 2. Water/coolant outlet connection          | 11. Coolant filter                  |
| 3. Lubricating oil pressure (after filter)  | 12. Starting motor                  |
| 4. Lubricating oil pressure (before filter) | 13. Rear engine lifting bracket     |
| 5. Coolant heater port                      | 14. Turbocharger exhaust outlet     |
| 6. Lubricating oil cooler                   | 15. Turbocharger wastegate actuator |
| 7. Water/coolant inlet                      | 16. Turbocharger air outlet         |
| 8. Lubricating oil filter                   | 17. Engine oil fill.                |
| 9. Lubricating oil pan drain plug           |                                     |



00900320

Front View

- |                                   |                             |
|-----------------------------------|-----------------------------|
| 1. Engine air inlet               | 8. Fan belt tensioner       |
| 2. Fan pulley                     | 9. Water pump               |
| 3. Fuel pump drive cover          | 10. Alternator              |
| 4. Front gear cover               | 11. Turbocharger air outlet |
| 5. Drive belt                     | 12. Turbocharger air inlet  |
| 6. Lubricating oil pan drain plug | 13. Engine oil fill.        |
| 7. Vibration damper               |                             |



00900324

Top View

- |  |                      |
|--|----------------------|
| 1. Turbocharger                              | 4. Engine air inlet  |
| 2. 3/4 x 16-inch UNF tap for magnetic pickup | 5. Thermostat        |
| 3. Crankcase breather                        | 6. Exhaust manifold. |

## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

# Section 1 - Operating Instructions

## Section Contents

	Page
<b>Cold Weather Starting</b> .....	1-5
General Information .....	1-5
Using Starting Aids .....	1-5
<b>Engine Operating Range</b> .....	1-8
General Information .....	1-8
<b>Engine Shutdown</b> .....	1-8
General Information .....	1-8
<b>Normal Starting Procedure</b> .....	1-2
General Information .....	1-2
Jump Starting .....	1-4
<b>Operating Instructions - Overview</b> .....	1-1
General Information .....	1-1
<b>Operating the Engine</b> .....	1-5
Ambient Temperature .....	1-7
0 to -32°C [32 to -25°F] .....	1-7
-32 to -54°C [-25 to -65°F] .....	1-7
Cold Weather .....	1-7
Normal .....	1-5
<b>Starting Procedure After Extended Shutdown or Oil Change</b> .....	1-5
General Information .....	1-5

**THIS PAGE LEFT INTENTIONALLY BLANK**

## Operating Instructions - Overview




### General Information

Correct care of your engine will result in longer life, better performance, and more economical operation.

Follow the daily maintenance checks listed in Maintenance Guidelines (Section 2).

The **new** Cummins engine associated with this manual does **not** require a "break-in" procedure. This section of the manual provides all of the necessary information required for proper engine operation.



Check the oil pressure indicators, temperature indicators, warning lights, and other gauges daily to make sure they are operational.



### ▲ WARNING ▲

**DO NOT OPERATE A DIESEL ENGINE WHERE THERE ARE OR CAN BE COMBUSTIBLE VAPORS.** The vapors can be sucked through the air intake system and cause engine acceleration and overspeeding that can result in a fire, an explosion, and extensive property damage. Numerous safety devices are available, such as air intake shutoff devices, to minimize the risk of overspeeding where an engine, due to its application, due to a fuel spill or gas leak. Remember, Cummins has no way of knowing the use you have for your engine. **THE EQUIPMENT OWNER AND OPERATOR ARE RESPONSIBLE FOR SAFE OPERATION IN A HOSTILE ENVIRONMENT. CONSULT YOUR CUMMINS AUTHORIZED REPAIR LOCATION FOR FURTHER INFORMATION.**


Cummins recommends the installation of an air intake shutoff device or a similar safety device to minimize the risk of overspeeding where an engine, due to the vehicle, vessel or equipment being operated in a combustible environment, such as due to a fuel spill or gas leak.





**⚠ CAUTION ⚠**

Do not expose the engine to corrosive chemicals. Corrosive chemicals can damage the engine.



## Normal Starting Procedure

### General Information

**⚠ WARNING ⚠**


Do not depress the accelerator pedal or move the accelerator lever from the idle position while cranking the engine. This can result in engine overspeed and severe damage to the engine.

**⚠ CAUTION ⚠**

To prevent damage to the starting motor, do not engage the starting motor for more than 30 seconds. Wait 2 minutes between each attempt to start (electrical starting motors only).

**NOTE:** Engines equipped with air starting motors require a minimum of 480 kPa [70 PSI].


- Disengage the driven unit, or if equipped, put the transmission in neutral.
- With the accelerator pedal or lever in the idle position, turn the key switch to the ON position, and wait for the WAIT-TO-START lamp to go out; then, turn the key to the START position.
- If the engine does **not** start after three attempts, check the fuel supply system. Absence of blue or white exhaust smoke during cranking indicates no fuel is being delivered.




**⚠ CAUTION ⚠**

The engine must have adequate oil pressure within 15 seconds after starting. If the WARNING lamp indicating low oil pressure has not gone out or there is no oil pressure indicated on a gauge within 15 seconds, shut off the engine immediately to avoid engine damage. The low oil pressure troubleshooting procedure is located in Troubleshooting Symptoms (Section TS).

Idle the engine 3 to 5 minutes before operating with a load.




After starting a cold engine, increase the engine speed (rpm) slowly to provide adequate lubrication to the bearings and to allow the oil pressure to stabilize.



**⚠ CAUTION ⚠**

**Do not operate engine at low idle for long periods with engine coolant temperature below the minimum specification in Maintenance Specifications (Section V). This can result in the following:**

- Fuel Dilution of the lubricating oil
- Carbon build up in the cylinder
- Cylinder head valve sticking
- Reduced performance



## Jump Starting

### ⚠ WARNING ⚠

Batteries can emit explosive gases. To avoid personal injury, always ventilate the compartment before servicing the batteries. To avoid arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.



### ⚠ CAUTION ⚠

When using jumper cables to start the engine, make sure to connect the cables in parallel: Positive (+) to positive (+) and negative (-) to negative (-). When using an external electrical source to start the engine, turn the disconnect switch to the OFF position. Remove the key before attaching the jumper cables.

### ⚠ CAUTION ⚠

To avoid damage to engine parts, do not connect jumper starting or battery charging cable to any fuel system or electronic component.

The accompanying illustration shows a typical parallel battery connection. This arrangement doubles the cranking amperage.



This illustration shows a typical series battery connection. This arrangement, positive (+) to negative (-), doubles the voltage.

## Cold Weather Starting

### General Information


Follow the Normal Starting Procedures in this section. In cold weather, the Wait-To-Start lamp will stay on longer.

### Using Starting Aids



**Do not use starting fluids with this engine. This engine is equipped with an intake air heater; use of starting fluid can cause an explosion, fire, personal injury, severe damage to the engine and property damage.**

Cold weather starting aids are available for your engine. Contact the local Cummins Authorized Repair Location for more information.



## Starting Procedure After Extended Shutdown or Oil Change

### General Information


Follow the Normal Starting Procedure in this section. The engine will not start until the minimum cranking oil pressure is detected by the ECM. It can take more cranking time to start the engine after an extended shut down or oil change.


## Operating the Engine

### Normal


If equipped, monitor the oil pressure and coolant temperature gauges frequently. Refer to Lubricating Oil System specifications and Cooling System specifications, in Maintenance Specifications (Section V) for recommended operating pressures and temperatures. Shut off the engine if any pressure or temperature does **not** meet the specifications.

Continuous operation with engine coolant temperature above or below the engine coolant temperature specifications listed in Maintenance Specifications (Section V) can damage the engine.





If an overheating condition starts to occur, reduce the power output of the engine by releasing the accelerator pedal or lever or shifting the transmission to a lower gear, or both, until the temperature returns to the normal operating range. If the engine temperature does **not** return to normal, shut off the engine, and refer to Troubleshooting Symptoms (Section TS), or contact a Cummins Authorized Repair Location.



Most failures give an early warning. Look and listen for changes in performance, sound, or engine appearance that can indicate service or engine repair is needed. Some changes to look for are:

- Engine misfires
- Vibration
- Unusual engine noises
- Sudden changes in engine operating temperatures or pressures
- Excessive smoke
- Loss of power
- An increase in oil consumption
- An increase in fuel consumption
- Fuel, oil, or coolant leaks.

## Cold Weather

It is possible to operate diesel engines in extremely cold environments if they are properly prepared and maintained. Satisfactory performance of a diesel engine in low ambient temperature conditions requires modification of the engine, surrounding equipment, operating practices and maintenance procedures.

The correct engine coolant lubricating oil and fuels **must** be used for the cold weather range in which the engine is being operated. Below are the recommendations for these critical engine fluids:

### Ambient Temperature

#### 0 to -32°C [32 to -25°F]

Use 50-percent ethylene glycol antifreeze and 50-percent water for the engine coolant mixture.

Refer to Maintenance Specifications (Section V) Lubricating Oil recommendations for the correct specifications.

The Diesel fuel must have maximum cloud and pour points 6°C [10°F] lower than the ambient temperature in which the engine operates.

#### -32 to -54°C [-25 to -65°F]

Use 60-percent ethylene glycol antifreeze and 40-percent water for the engine coolant mixture.

Refer to Maintenance Specifications (Section V) Lubricating Oil recommendations for the correct specifications.

The Diesel fuel must have maximum cloud and pour points 6°C [10°F] lower than the ambient temperature in which the engine operates.


The following cold weather operating aids are required for cold weather situations:

Cold Weather Operating Aids										
Temperature	Starting Aid	Coolant Heater	Oil Heater	Under-hood Air	Fuel Heater	Battery Heater	Radiator Shutters	Engine Enclosure	Winter Front	Thermatic Fan
50 to 32° F 10 to 0° C										
32 to -10° F 0 to -23° C	↑	↑	↑	↑	↑	↑	↑	↑	↑	Suggested
-10 to -25° F -23 to -32° C	Required	Required	Required	Required	Required	Required	Required	Required	Required	Required
-25 to -65° F -32 to -54° C	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓

\* Required dependent upon viscosity/pour point.

oi202vj

Winterfronts and shutters can be used on a vehicle or equipment to reduce air flow through the radiator core into the engine compartment. This can reduce the time required to warm the engine and help maintain the engine coolant temperature. The engine coolant temperature specifications are in the Maintenance Specification (Section V).



## Engine Operating Range

### General Information


#### ⚠ CAUTION ⚠

Do not operate the engine at full throttle operation below peak torque rpm (refer to engine dataplate for peak torque rpm) for more than 30 seconds. Operating the engine at full throttle below peak torque will shorten engine life to overhaul, can cause serious engine damage, and is considered engine abuse.

Cummins engines are designed to operate successfully at full throttle under transient conditions down to peak torque engine speed. This is consistent with recommended operating practices.

#### ⚠ CAUTION ⚠

Do not operate the engine beyond the maximum engine speed. Operating the engine beyond the maximum engine speed can cause severe engine damage. Use proper operating techniques for the vehicle, vessel, or equipment to prevent engine overspeed. The maximum engine speed specification is listed in Maintenance Specifications (Section V).



## Engine Shutdown

### General Information

Allow the engine to idle 3 to 5 minutes before shutting it off after a full-load operation. This allows adequate cooldown of pistons, cylinders, bearings, and turbocharger components.

Turn the ignition keyswitch to the OFF position. If the engine does not shut down, refer to Troubleshooting Symptom (Section TS).

Section 2 - Maintenance Guidelines  
Section Contents

	Page
<b>Maintenance Guidelines - Overview</b> .....	2-1
General Information .....	2-1
<b>Maintenance Record Form</b> .....	2-3
Maintenance Data .....	2-3
<b>Maintenance Schedule</b> .....	2-1
General Information .....	2-1
Maximum Oil Drain Intervals .....	2-2
<b>Tool Requirements</b> .....	2-1
General Information .....	2-1



**THIS PAGE LEFT INTENTIONALLY BLANK**

## Maintenance Guidelines - Overview

### General Information

Cummins Inc. recommends that the engine be maintained according to the Maintenance Schedule in this section.

If the engine is operating in ambient temperatures below -18°C [0°F] or above 38°C [100°F], perform maintenance at shorter intervals. Shorter maintenance intervals are also required if the engine is operated in a dusty environment or if frequent stops are made. Contact your local Cummins Authorized Repair Location for recommended maintenance intervals.

Some of these maintenance procedures require special tools or must be completed by qualified personnel. Contact your local Cummins Authorized Repair Location for detailed information.

If your engine is equipped with a component or accessory not manufactured by Cummins Inc., refer to the component manufacturer's maintenance recommendations.

Use the chart provided in this section as a convenient way to record maintenance performed.

### Tool Requirements

#### General Information

The maintenance schedules **must** be used for routine and periodic maintenance. Perform each function at the indicated time interval. The intervals stated are for normal operating conditions. Service the unit more frequently under severe conditions. Neglecting maintenance can result in failures or permanent damage to the engine. If the engine is operating in ambient temperatures consistently below -18°C [0°F] or above 38°C [100°F], perform maintenance at shorter intervals.

Sockets		Wrenches	Other Tools
1/2-Inch Drive	3/8-Inch Drive		
19 mm	14 mm	28 mm	Ratchets, 1/2- and 3/8-inch drive
17 mm	13 mm	19 mm	Socket extensions, 1/2- and 3/8-inch long and short
15 mm	10 mm	18 mm	Socket universal joint, 3/8-inch drive
	8 mm	17 mm	Adapter, 1/2-inch female-to-3/8-inch male socket
	7/16 deep socket	15 mm	Torque wrench, 1/2-inch drive, 100 ft-lb capacity
	3/8 inch	14 mm	Breaker bar, 1/2-inch drive
	5/16 inch	13 mm	Plastic hammer
		10 mm	5/16-inch allen hex key
		8 mm	Spray can of silicone lubricant
		7/8 inch	Flat blade screwdriver
		11/16 inch	Brass rod, 4.76-mm (3/16-in) diameter
		9/16 inch	DCA4 test kit, Fleetguard® Part Number CC-2602J
		1/2 inch	Engine barring gear, Part Number 3377371
		7/16 inch	Filter wrenches (75- to 80-, 90- to 95-, and 118- to 131-mm)
		3/8 inch	
		1/4 inch	

### Maintenance Schedule

#### General Information

For your convenience, listed below are the section numbers that contain specific instructions for performing the maintenance checks listed in the maintenance schedule.

Perform maintenance at whichever interval occurs first. At each scheduled maintenance interval, perform all previous checks that are due for scheduled maintenance.

- Daily or Refueling - Maintenance Check<sup>4</sup>** ..... Section 3
- Air Intake Piping - Inspect
  - Air Tanks and Reservoirs - Drain
  - Cooling Fan - Check/Correct
  - Crankcase Breather Tube - Inspect
  - Drive Belts - Check/Correct
  - Engine Coolant Level - Check/Correct
  - Engine Lubricating Oil Level - Check/Correct
  - Fuel-Water Separator - Drain

- Every 10,000 km [6000 mi], 250 Hours, or 3 Months - Maintenance Check<sup>1, 4</sup> ..... Section 4**
- Air Compressor Mounting Hardware - Check/Correct
  - Air Cleaner Restriction - Check/Correct
  - Charge Air Cooler - Check/Correct
  - Charge Air Piping - Check/Correct
  - Lubricating Oil and Filters - Change
- Every 19,000 km [12,000 mi], 500 Hours, or 6 Months - Maintenance Check<sup>2, 3, 4</sup> ..... Section 5**
- Coolant Filters - Replace
  - Supplemental Coolant Additives (SCA) and Antifreeze - Check
  - Fuel Filter (Spin-On Type) - Replace
- Every 38,000 km [24,000 mi], 1000 Hours, or 12 Months - Maintenance Check<sup>4</sup> ..... Section 6**
- Fan Belt Tensioner - Check/Correct
  - Overhead Set - Adjust
- Every 77,000 km [48,000 mi], 2000 Hours, or 2 Years - Maintenance Check<sup>2, 3, 4</sup> ..... Section 7**
- Air Compressor Discharge Lines - Check/Correct
  - Cooling System - Drain, Flush, and Fill
  - Vibration Damper, Rubber - Check

**Notes:**

1. The lubricating oil and lubricating oil filter interval can be adjusted based on fuel consumption, gross vehicle weight, and idle time. Refer to Oil Drain Intervals in this section.
2. Test the SCA concentration level every 6 months unless concentration is over three units; then check at every oil drain interval until concentration is below three units.
3. Antifreeze check interval is every oil change or 19,000 km [12,000 mi], 500 hours or 6 months, whichever occurs first. The operator **must** use a heavy-duty year-round antifreeze that meets the chemical composition of GM6038M. The antifreeze change interval is 2 years or 77,000 km [48,000 mi], whichever occurs first. Antifreeze is essential for freeze, overheat, and corrosion protection.
4. Follow the manufacturer's recommended maintenance procedures for the starter, alternator, generator, batteries, electrical components, engine brakes, exhaust brake, charge air cooler, air compressor, air conditioner compressor, and fan clutch. Refer to Section M for addresses and telephone numbers.

**Maximum Oil Drain Intervals**

Refer to the following flowchart to determine the maximum recommended oil change and filter change intervals in kilometers, miles, hours, or months, whichever comes first.

Is the vehicle one of those listed below?

- Truck crane/yard spotter
- Paver/crane/backhoe
- Dozer/scrape/skipper

**If Yes -**

Select the correct oil drain interval from Table 1.

**If No -**

Is the vehicle one of those listed below?

- Tractor/combine/irrigation equipment
- Genset/air compressor/fire equipment

**If Yes -**

Select the correct oil drain interval from Table 2.

**If No -**

Select the correct oil drain interval from Table 3.

**Table 1, Oil Drain Intervals**

Vehicle/Equipment	Kilometers	Miles	Hours	Months
Truck crane/yard spotter	10,000	6,000	250	3

(Continued)

Table 3, Oil Drain Intervals				
Vehicle/Equipment	Kilometers	Miles	Hours	Months
All others	10,000	6,000	250	3

## Maintenance Data

Maintenance Record	
Engine Serial No.:	Engine Model:
Owner's Name:	Equipment Name/Number:

Key to table headings:

- A = Date
- B = km [Miles], Hours or Time Interval
- C = Actual km [Miles] or Hours
- D = Maintenance Check Performed
- E = Check Performed By
- F = Comments

[illegible]

(Continued)

A	B	C	D	E	F

## Section 3 - Maintenance Procedures at Daily Interval

### Section Contents

	Page
<b>Air Intake Piping</b> .....	3-2
Maintenance Check .....	3-2
<b>Air Tanks and Reservoirs</b> .....	3-7
Drain .....	3-7
<b>Coolant Level</b> .....	3-2
Maintenance Check .....	3-2
<b>Crankcase Breather Tube</b> .....	3-6
Maintenance Check .....	3-6
<b>Daily Maintenance Procedures - Overview</b> .....	3-1
Engine Operation Report .....	3-1
General Information .....	3-1
Unusual Engine Noise .....	3-1
<b>Drive Belts</b> .....	3-3
Maintenance Check .....	3-3
Cogged Belt .....	3-3
Poly-Vee Belt .....	3-3
<b>Fan, Cooling</b> .....	3-4
Inspect for Reuse .....	3-4
<b>Fuel-Water Separator</b> .....	3-5
Drain .....	3-5
Canister Type .....	3-5
Spin-on Type .....	3-6
<b>Lubricating Oil Level</b> .....	3-6
Maintenance Check .....	3-6

**THIS PAGE LEFT INTENTIONALLY BLANK**

## Daily Maintenance Procedures - Overview

### General Information

Preventative maintenance begins with day-to-day awareness of the engine and its system. Before starting the engine, check the oil and coolant levels. Look for:

- Leaks
- Loose or damaged parts
- Worn or damaged belts
- Any change in engine appearance.
- Odor of fuel

### Engine Operation Report

The engine **must** be maintained in top mechanical condition if the operator is to get optimum satisfaction from its use. The maintenance department needs daily running reports from the operator to make necessary adjustments in the time allocated. The daily running report also helps to make provisions for more extensive maintenance work as the reports indicate the necessity.


Comparison and intelligent interpretation of the daily report, along with a practical follow-up action, will eliminate most failures and emergency repairs.

Report to the maintenance department any of the following conditions:


- Low lubricating oil pressure
- Low power
- Power increases or engine surge
- Erratic or no accelerator control or response
- Any warning lights flashing or staying on
- Abnormal water or oil temperature
- Unusual engine noise
- Excessive smoke
- Excessive use of coolant, fuel, or lubricating oil
- Any fuel, coolant, or lubricating oil leaks
- Loose or damaged parts
- Worn or damaged belts

### Unusual Engine Noise

During daily maintenance checks, listen for any unusual engine noise that can indicate that service is required.







## Air Intake Piping

### Maintenance Check




Visually inspect the intake piping daily for wear points and damage to piping, loose clamps, or punctures that can damage the engine.

Replace damaged pipes, and tighten loose clamps, as necessary, to prevent the air system from leaking.

**Torque Value:** 8 N•m [72 in-lb]

Check for corrosion under the clamps and hoses of the intake system piping. Corrosion can allow corrosive products and dirt to enter the intake system. Disassemble and clean, as required.



## Coolant Level

### Maintenance Check


#### ⚠ WARNING ⚠

Do not remove a pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [120°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

#### ⚠ CAUTION ⚠

Never use a sealing additive to stop leaks in the cooling system. This can result in cooling system plugging and inadequate coolant flow, causing the engine to overheat.

The coolant level **must** be checked daily.



#### ⚠ CAUTION ⚠


Do not add cold coolant to a hot engine. Engine castings can be damaged. Allow the engine to cool to below 50°C [120°F] before adding coolant.

Make up coolant added to the engine **must** be mixed with the correct proportions of antifreeze, supplemental coolant additive, and water to avoid engine damage.

Coolant recommendations and specification details on correct mixing of coolant can be found in Maintenance Specifications (Section V).

Fill the cooling system with coolant to the bottom of the fill neck in the radiator fill or expansion tank.

**NOTE:** Some radiators have two fill necks, both of which **must** be filled when the cooling system is drained.



## Drive Belts


### Maintenance Check

#### Poly-Vee Belt

Inspect the belts daily. Check the belt for intersecting cracks. Traverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are **not** acceptable. Replace the belt if it is frayed or has pieces of material missing. Refer to Section A for belt adjustment and replacement procedures.

Belt damage can be caused by:

- Incorrect tension
- Incorrect size or length
- Pulley misalignment
- Incorrect installation
- Severe operating environment
- Oil or grease on the side of belts.




#### Cogged Belt

Inspect the belts daily. Replace the belts if they are cracked, frayed, or have chunks of material missing. Small cracks are acceptable.


Adjust the belts that have a glazed or shiny surface, which indicates belt slippage. Correctly installed and tensioned belts will show even pulley and belt wear. Refer to Section A for belt adjustment and replacement procedures.

Belt damage can be caused by:

- Incorrect tension
- Incorrect size or length
- Pulley misalignment
- Incorrect installation
- Severe operating environment
- Oil or grease on the belts



### Section 3 - Maintenance Procedures at Daily Interval




Measure the belt tension in the center span of the pulleys.

Refer to the Belt Tension Chart in Section V for the correct gauge and tension value for the belt width used.




An alternate method (deflection method) can be used to check belt tension by applying 110 N [25 lbf] force between the pulleys on v-belts. If the deflection is more than one belt thickness per foot of pulley center distance, the belt tension **must** be adjusted.

Refer to Section A for adjustment procedures.



For cogged belts, **make sure** that the belt tension gauge is positioned so that the center tensioning leg is placed directly over the high point (hump) of a cog. Other positioning will result in incorrect measurement.



## Fan, Cooling


### Inspect for Reuse



**WARNING**




**Do not rotate the engine by pulling or prying on the fan. The fan blade(s) can be damaged and cause the fan to fail and cause personal injury or property damage. Use the accessory drive shaft to rotate the crankshaft.**



A visual inspection of the cooling fan is required daily. Check for cracks, loose rivets, and bent or loose blades. Check the fan to make sure it is securely mounted. Tighten the capscrews, if necessary.


**⚠ WARNING ⚠**

Do not straighten a bent fan blade or continue to use a damaged fan. A bent or damaged fan blade can fail during operation and cause personal injury or property damage.



Replace original equipment fan that is damaged with a fan of the identical part number. Cummins Engine Company, Inc. **must** approve any other fan changes to be covered under warranty.

Refer vehicle or equipment manufacturers specifications for capscrew torque.



## Fuel-Water Separator

### Drain

**⚠ WARNING ⚠**

Drain the water-fuel separator into a container and dispose of in accordance with local environmental regulations.

Cummins Inc. requires a fuel-water separator or fuel filter be installed in the fuel supply system.


Drain the water and sediment from the separator daily.


### Canister Type

Shut off the engine.

Pull up on the drain valve lever until fluid drains out of the drain tube. Drain the filter sump until clear fuel is visible.

Push up on the drain valve until fluid drains out of the drain tube.





### Spin-on Type

Shut off the engine.


Use your hand to open the drain valve. Turn the valve **counterclockwise** approximately  $3\frac{1}{2}$  turns until the valve drops down 25.4mm [1 in] and draining occurs.

Drain the filter sump until clear fuel is visible.



**When closing the drain valve, do not overtighten the valve. Overtightening can damage the threads.**

To close the valve, lift the valve and turn **clockwise** until it is hand-tight.



### Lubricating Oil Level

#### Maintenance Check




**Never operate the engine with oil level below the L (low) mark or above the H (high) mark. Poor engine performance or engine damage can occur.**

The engine **must** be level when checking the oil level to make sure the measurement is correct.

Shut off the engine for an accurate reading.

Wait at least 15 minutes after shutting off the engine to check the oil level. This allows time for the oil to drain into the oil pan.

For additional lubricating oil recommendations and oil pan capacity information, refer to Maintenance Specifications (Section V).



### Crankcase Breather Tube

#### Maintenance Check


Inspect the breather tube for sludge, debris, or ice in the tube.

Inspect the tube more frequently in icy conditions.

## Air Tanks and Reservoirs

### Drain

If automatic purging or spitter valves are used, confirm the valves are operating correctly. If a manual drain valve is used on the wet tank, open the draincock on the wet tank to drain any moisture accumulated in the air system. If oil is present, the air compressor system **must** be checked. Contact your Cummins Authorized Repair Location.



## NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

**Maintenance Procedures at 10,000 Kilometers [6000 Miles],  
250 Hours, or 3 Months**  
**Section Contents**

	Page
<b>Air Cleaner Restriction</b> .....	4-1
Maintenance Check .....	4-1
<b>Air Compressor</b> .....	4-1
Maintenance Check .....	4-1
<b>Charge-Air Cooler</b> .....	4-2
Maintenance Check .....	4-2
<b>Charge-Air Piping</b> .....	4-2
Maintenance Check .....	4-2
<b>Lubricating Oil and Filters</b> .....	4-3
Drain .....	4-3
Fill .....	4-5
Install .....	4-4
Remove .....	4-4
<b>Maintenance Procedures - Overview</b> .....	4-1
General Information .....	4-1



**THIS PAGE LEFT INTENTIONALLY BLANK**

## Maintenance Procedures - Overview

### General Information

All maintenance checks and inspections listed in previous maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

### Air Compressor

#### Maintenance Check

**NOTE:** Depending on application, all engines will possibly not be equipped with an air compressor.

Inspect compressor housing for cracks and damage.

Inspect hydraulic pump couplings for cracks, wear, or damage (if equipped).

Inspect air plumbing for splits or cracks.

Inspect the air compressor mounting nuts, including support bracket, for loose or damaged hardware.


Operate the engine and check for correct compressor operation and air, oil, and coolant leaks.

#### Torque Value:

Mounting	18 mm	77 N•m	[57 ft-lb]
----------	-------	--------	------------

#### Torque Value:

Bracket	10 mm	45 N•m	[33 ft-lb]
---------	-------	--------	------------



### Air Cleaner Restriction


#### Maintenance Check


##### Mechanical Indicator

**NOTE:** Do **not** remove the felt washer from the indicator. The felt washer absorbs moisture.

A mechanical restriction indicator is available to indicate excessive air restriction through a dry-type air cleaner. This instrument can be mounted in the air cleaner outlet or on the instrument panel. The red flag (1) in the window gradually rises as the cartridge loads with dirt. After changing or replacing the cartridge, reset the indicator by pushing the reset button.


Restriction or vacuum indicators need to be installed as close as possible to the turbocharger air inlet in order to obtain a true indication of restrictions.





### Vacuum Indicator


Vacuum switches actuate a warning light on the instrument panel when the air restriction becomes excessive.



### Charge-Air Cooler Maintenance Check



Inspect the charge-air cooler (CAC) for dirt and debris blocking the fins. Check for cracks, holes, or other damage. If damage is found, refer to the vehicle, vessel, or equipment manufacturer.



### Charge-Air Piping Maintenance Check



Inspect the charge-air piping and hoses for leaks, holes, cracks, or loose connections. Tighten the hose clamps if necessary. Refer to the vehicle or equipment manufacturer's specifications for the correct torque value.


## Lubricating Oil and Filters

### Drain

#### WARNING

**Some state and federal agencies have determined that used engine oil can be carcinogenic and cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil. If not reused, dispose of in accordance with local environmental regulations.**


PROTECT THE ENVIRONMENT: Handling and disposal of used lubricating engine oil is subject to federal, state, and local laws and regulations. Use authorized waste disposal facilities, including civic amenity sites and garages providing authorized facilities for receipt of used lubricating oil. If in doubt, contact your state and local environmental authorities or the Environmental Protection Agency for guidance as to proper handling and disposal of used lubricating engine oil.



**NOTE:** If the engine is in service, under no circumstances can the lubricating oil drain interval extend beyond the intervals given in the charts.

Change the lubricating oil and filters to remove the contaminants suspended in the lubricating oil.

**NOTE:** Drain the lubricating oil **only** when it is hot and the contaminants are in suspension.




**WARNING**

To avoid personal injury, avoid direct contact of hot oil with your skin.

**NOTE:** Use a container that can hold at least 25 liters [26 qt] of lubricating oil.

Operate the engine until the water temperature reaches 60°C [140°F]. Shut the engine off. Remove the lubricating oil drain plug.




**Remove**

Clean the area around the lubricating oil filter head. Remove the filter. Clean the gasket surface of the filter head.



**NOTE:** The o-ring can stick on the filter head. Make sure it is removed.



**Install**

**NOTE:** Fill the filters with clean lubricating oil before installation.


**NOTE:** The LF3000 lubricating oil filter has two gaskets. Lubricate both gaskets.

Apply a light film of oil to the gasket sealing surface before installing the filters.

**⚠ CAUTION ⚠**

**Mechanical overtightening can distort the threads or damage the lubricating oil filter element seal.**

Install the lubricating oil filter as specified by the filter manufacturer.



Check and clean the lubricating oil drain plug threads and sealing surface.


Install the lubricating oil pan drain plug.

**Torque Value:**

For steel stamp  
oil pans                      80 N•m              [59 ft-lb]


**Torque Value:**

For aluminum  
oil pans                      60 N•m              [44 ft-lb]



**Fill**


**NOTE:** Use a high-quality 15W-40 multiviscosity lubricating oil, such as Cummins Premium Blue®, or equivalent, in Cummins engines. Choose the correct oil for your operating climate as outlined in Section V.




Fill the engine with clean lubricating oil to the proper level.


**System Capacity:**

23.8 liters [25.1 qt]





Operate the engine at low idle to inspect for leaks at the lubricating oil filter and the drain plug.



Stop the engine. Wait approximately 15 minutes to let the lubricating oil drain from the upper parts of the engine. Check the level again.

Add oil as necessary to bring the oil level to the H (high) mark on the dipstick.

# Maintenance Procedures at 19,000 Kilometers [12,000 Miles], 500 Hours, or 6 Months

## Section Contents

	Page
<b>Coolant Filter</b> .....	5-1
Clean .....	5-1
Install .....	5-2
Remove .....	5-1
<b>Fuel Filter (Spin-On Type)</b> .....	5-4
Clean .....	5-4
Install .....	5-4
Prime .....	5-5
Remove .....	5-4
<b>Maintenance Procedures - Overview</b> .....	5-1
General Information .....	5-1
<b>Supplemental Coolant Additive (SCA) and Antifreeze Concentration</b> .....	5-3
Maintenance Check .....	5-3
Antifreeze .....	5-3
Supplemental Coolant Additive (SCA) .....	5-3



**THIS PAGE LEFT INTENTIONALLY BLANK**

## Maintenance Procedures - Overview

### General Information

All maintenance checks and inspections listed in previous maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.


### Coolant Filter

#### Remove




Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Remove the coolant system pressure cap and close the shutoff valve before removing the coolant filter. Failure to do so can result in personal injury from heated coolant spray.

Turn the shutoff valve to the OFF position by rotating the knob from vertical to horizontal in the direction shown.





Remove and discard the coolant filter.



#### Clean

Clean the gasket surface.





### Install

**CAUTION**

Do not allow oil to get into the filter. Oil will damage the DCA.



**CAUTION**


Mechanical overtightening can distort the threads or damage the filter head.



Apply a thin film of lubricating oil to the gasket sealing surface before installing the new coolant filter.

Install the coolant filter on the filter head. Tighten the filter until the gasket contacts the filter head surface.


Tighten the coolant filter an additional 1/2 to 3/4 of a turn, or as specified by the filter manufacturer.



**CAUTION**

The valve must be in the ON position to prevent engine damage.


Turn the shutoff to the ON position by rotating the knob from horizontal to vertical in the direction shown.



Install the coolant system pressure cap.

Operate the engine and check for coolant leaks.

After the air has been purged from the system, check the coolant level again.



## Supplemental Coolant Additive (SCA) and Antifreeze Concentration


### Maintenance Check

#### Supplemental Coolant Additive (SCA)

Check the SCA concentration level:

- At least twice a year
- At every subsequent oil drain interval if the concentration is above 3 units
- Whenever coolant is added to the cooling system between filter changes.

Use Fleetguard® coolant test kit, Part No. CC2602, to check the SCA concentration level. Instructions are included with the test kit. Refer to Coolant Recommendations and Specifications in Maintenance Specifications (Section V) for the correct SCA and antifreeze level.



#### Antifreeze



**Overconcentration of antifreeze or use of high-silicate antifreeze can damage the engine.**


Check the antifreeze concentration. Use a mixture of 50-percent water and 50-percent ethylene glycol or propylene glycol-based antifreeze to protect the engine to -32°C [-26°F] year-around.


The Fleetguard® refractometer, Part Number C2800, provides a reliable, easy-to-read, and accurate measurement of freezing point protection and glycol (antifreeze) concentration.

Antifreeze is essential in every climate.

Antifreeze broadens the operating temperature range by lowering the coolant freezing point and by raising its boiling point.

The corrosion inhibitors also protect the cooling system components from corrosion and prolong component life.






## Fuel Filter (Spin-On Type)

### Clean


Clean the area around the fuel filter head.



### Remove

75- to 80-mm and 90- to 95-mm Wrenches


Remove the fuel filter. Clean the gasket surface of the fuel filter head.



### Install

Replace the o-ring.

Fill the new fuel filter(s) with clean fuel, and lubricate the o-ring seal with clean lubricating engine oil.



### CAUTION

To reduce the possibility of fuel leaks, make sure the fuel filter is installed tightly but not too tightly. Mechanical overtightening will damage the fuel filter.



Install the fuel filter as specified by the filter manufacturer.


## Prime

Controlled venting is provided at the injection pump through the fuel drain manifold. Small amounts of air introduced by changing the fuel filters or fuel injection pump supply line will be vented automatically if the fuel filter is changed in accordance with the instructions.

**NOTE:** Manual bleeding is required if:

- The fuel filter is **not** filled prior to installation
- Fuel injection pump is replaced
- High-pressure fuel line connections are loosened or fuel lines replaced
- Initial engine start up or start up after an extended period of no engine operation occurs
- Vehicle fuel tank has been run until empty.


Open the bleed screw.




Operate the plunger on the fuel transfer pump until the fuel flowing from the fitting is free of air.

Tighten the bleed screw.

**Torque Value:** 9 N•m [80 in-lb]






**WARNING**

The pressure of the fuel in the line is sufficient to penetrate the skin and cause serious personal injury. Wear gloves and protective clothing.

**17-mm (PES.A, PES.MW) and 19-mm (PES.P) Wrenches**

Loosen the fittings at the injectors, and crank the engine to allow entrapped air to vent from the lines. Tighten the fittings.



**WARNING**

It is necessary to put the engine in the run position. Because the engine could start, be sure to follow all the safety precautions. Use the normal engine starting procedure.

Start the engine and vent one line at a time until the engine runs smoothly.

**NOTE:** Do **not** engage the starter for more than 30 seconds each time when it is used to vent the system: Wait 2 minutes between engagements.

Maintenance Procedures at 38,000 Kilometers [24,000  
Miles], 1000 Hours, or 1 Year

Section Contents

	Page
Cooling Fan Belt Tensioner .....	6-1
Maintenance Check .....	6-1
Maintenance Procedures - Overview .....	6-1
General Information .....	6-1
Overhead Set .....	6-2
Adjust .....	6-2



**THIS PAGE LEFT INTENTIONALLY BLANK**

## Maintenance Procedures - Overview

### General Information


All maintenance checks and inspections listed in previous maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

### Cooling Fan Belt Tensioner


#### Maintenance Check

Every 48,000 km [30,000 mi], 1000 hours, or 1 year, whichever occurs first, inspect the automatic belt tensioner.


With the engine turned off, check that neither the top nor bottom tensioner arm stop is touching the cast boss on the tensioner body. If either of the stops is touching a boss, the alternator belt **must** be replaced. Check to make sure the correct belt part number is being used if either condition exists.




Check the tensioner pulley and body for cracks. If any cracks are noticed, the tensioner **must** be replaced. Refer to a Cummins Authorized Repair Facility. Check the tensioner for dirt buildup. If this condition exists, the tensioner **must** be removed and steam-cleaned.




Check that the bottom tensioner arm stop is in contact with the bottom tensioner arm stop boss on the tensioner body. If these two are **not** touching, the tensioner **must** be replaced.





Inspect the tensioner for evidence of the pivoting tensioner arm contacting the stationary circular base. If there is evidence of these two areas touching, the pivot tube bushing has failed and the tensioner **must** be replaced.




A worn tensioner that has play in it or a belt that “walks” off its pulley possibly indicates pulley misalignment.

**NOTE:** Maximum pulley misalignment is 3 degrees.




This measurement can be taken with a straightedge and an inclinometer.

Install the belt.




## Overhead Set Adjust

Remove the air crossover tube from the engine if equipped.




Disconnect the support clamps, hose clamp, and wastegate sensing line. Remove the crankcase vent tube and any other parts that would prevent removal of the valve cover.

Remove valve cover.




Locate top dead center for cylinder No. 1 by rotating the crankshaft slowly while pressing on the engine timing pin.

The barring gear inserts into the flywheel housing and engages the flywheel ring gear. The engine can then be rotated by hand using a 1/2-inch ratchet or breaker bar.





When the engine timing pin engages the hole in the camshaft gear, cylinder No. 1 is at top dead center on the compression stroke.



**⚠ CAUTION ⚠**

Be sure to disengage the engine timing pin after locating top dead center to prevent damage to the engine timing pin.






Intake clearance: 0.30 mm [0.012 in].

Exhaust clearance: 0.61 mm [0.024 in].

Check/set valves with engine cold - below 60°C [140°F].

**NOTE:** The clearance is correct when some resistance is "felt" when the feeler gauge is slipped between the valve stem and the rocker lever.




Locate top dead center for cylinder No. 1.

Check/adjust the valves indicated for STEP A (I = intake; E = exhaust).



After tightening the rocker lever locknut, check the valve clearance to make sure the valve clearance has **not** changed.


**Torque Value:** 24 N•m [212 in-lb]



### CAUTION

Be sure the engine timing pin is disengaged to prevent damage to the engine timing pin.

Mark vibration damper and rotate the crankshaft 360 degrees.



Set the valves indicated for STEP B.


After tightening the rocker lever locknut, check the valve clearance to make sure the valve clearance has **not** changed.

**Torque Value:** 24 N•m [212 in-lb]


**NOTE:** If the seal is **not** damaged, it can be used again. If the seal is damaged, install a new seal.

Install the rubber seal into the groove in the valve cover. Start the installation at the overlap area shown in the illustration. Do **not** stretch the rubber seal.

If the seal has more overlap than shown in the illustration, trim the length to provide the correct overlap.




Install new sealing o-rings on the capscrews.  
Install the valve cover and wastegate sensing tube.  
**Torque Value:** 24 N•m [212 in-lb]




Install the crankcase vent tube, and secure with the support clamps and hose clamp.

**Torque Value:**

- A = 24 N•m [212 in-lb].
- B = 43 N•m [32 in-lb].



Install the air crossover tube and any other parts previously removed to gain access to the valve cover.



## This image shows a full page of a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page, providing a guide for writing. There are no margins, text, or other markings on the paper.

# Maintenance Procedures at 77,000 Kilometers [48,000 Miles], 2000 Hours, or 2 Years

## Section Contents

	Page
<b>Air Compressor Discharge Lines</b> .....	7-1
General Information .....	7-1
Maintenance Check .....	7-1
<b>Cooling System</b> .....	7-3
Drain .....	7-3
Fill .....	7-5
Flush .....	7-4
<b>Maintenance Procedures - Overview</b> .....	7-1
General Information .....	7-1
<b>Vibration Damper, Rubber</b> .....	7-6
Inspect .....	7-6



**THIS PAGE LEFT INTENTIONALLY BLANK**

## Maintenance Procedures - Overview

### General Information

All maintenance checks and inspections listed in previous maintenance intervals **must** also be performed at this time, in addition to those listed under this maintenance interval.

## Air Compressor Discharge Lines

### General Information

All air compressors have a small amount of lubricating oil carryover that lubricates the piston rings and moving parts. When this lubricating oil is exposed to normal air compressor operating temperatures over time, the lubricating oil will form varnish or carbon deposits. If the following maintenance check are not performed, the air compressor piston rings will wear and not seal correctly.

### Maintenance Check




**WARNING**


**Wear appropriate eye and face protection when using compressed air. Flying debris and dirt can cause personal injury.**


Shut off the engine.

Open the drain valve on the wet tank to release the system air pressure.




Remove the air compressor discharge line from the air compressor. Location of the air compressor discharge line can be found in Flow Diagram, Compressed Air System in System Diagrams (Section D).






Measure the total carbon deposit thickness inside the air discharge line as shown. If the total carbon deposit ( $X + X$ ) exceeds 2 mm [1/16 in], clean and inspect the cylinder head, the valve assembly, and the discharge line. Replace if necessary. Contact the Cummins Authorized Repair Location for procedures.



If the total carbon deposit exceeds specifications, continue checking the air discharge line connections up to the first tank until total carbon deposit is less than 2 mm [1/16 in]. Clean or replace any lines or connections that exceed this specification.



Inspect any air driers, splitter valves, pressure relief valves, and alcohol injectors for carbon deposits or malfunctioning parts. Inspect for air leaks. Maintain and repair the parts according to the manufacturer's specifications.

## Cooling System

### Drain

#### ⚠ WARNING ⚠

Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [120°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

#### ⚠ WARNING ⚠

Coolant is toxic. Keep away from children and pets. If not reused, dispose of in accordance with local environmental regulations.

#### ⚠ CAUTION ⚠

Protect the environment: Handling and disposing of used antifreeze is subject to federal, state, and local regulations. Use authorized waste disposal facilities, including civic amenity sites and garages providing authorized facilities for the receipt of used antifreeze. If in doubt, contact local authorities of the Environmental Protection Agency (EPA) for guidance as to proper handling of used antifreeze.

- Avoid excessive contact, and wash thoroughly after contact.
- Keep out of reach of children.

#### ⚠ WARNING ⚠




Coolant is toxic. Keep away from children and pets. If not reused, dispose of in accordance with local environmental regulations.


Drain the cooling system by opening the drain valve on the radiator and removing the plug in the bottom of the water inlet hose. A drain pan with a capacity of 19 liters [5 gal] will be adequate for most applications.

Check for damaged hoses and loose or damaged hose clamps. Replace as required.

Check the radiator for leaks, damage, and buildup of dirt. Clean and replace as required.

Clean and replace as required.






## Flush

### ⚠ CAUTION ⚠

The system must be filled properly to prevent air locks. During filling, air must be purged from the engine coolant passages. Be sure to open the petcock on the aftercooler for aftercooled engines. Wait 2 to 3 minutes to allow air to be vented; then add mixture to bring the level to the top.

**NOTE:** Adequate venting is provided for a fill rate of 19 liters [5 gal] per minute.




### ⚠ CAUTION ⚠

Do not install the radiator cap. The engine is to be operated without the cap for this process.

Fill the system with a mixture of sodium carbonate and water (or a commercially available equivalent).

**NOTE:** Use 0.5 kg [1 lb] of sodium carbonate for every 23 liters [6 gal] of water.




### ⚠ WARNING ⚠

Coolant is toxic. If not reused, dispose of in accordance with local environmental regulations.

Operate the engine for 5 minutes with the coolant temperature above 80°C [176°F].

Shut the engine off, and drain the cooling system.



Fill the cooling system with high-quality water.


**NOTE:** Be sure to vent the engine and aftercooler for complete filling.

**NOTE:** Do **not** install the radiator cap or the new coolant filter.

Operate the engine for 5 minutes with the coolant temperature above 80°C [176°F].

Shut the engine off, and drain the cooling system.

**NOTE:** If the water being drained is still dirty, the system **must** be flushed again until the water is clean.



## Fill


### ⚠ CAUTION ⚠

The system must be filled properly to prevent air locks. During filling, air must be purged from the engine coolant passages. Be sure to open the petcock on the aftercooler for aftercooled engines. Wait 2 to 3 minutes to allow air to be vented; then add mixture to bring the level to the top.

The system is designed to use a specific quantity of coolant. If the coolant level is low, the engine will run hot.

If frequent addition of coolant is necessary, the engine or system has a leak. Find and repair the leak.

The system has a designed fill rate of 19 liters [5 gal] per minute.




### ⚠ CAUTION ⚠

Never use water alone for coolant. This can result in damage from corrosion.

Use a mixture of 50-percent water and 50-percent ethylene glycol or propylene glycol antifreeze to fill the cooling system.

Coolant Capacity (Engine Only)			
	liters		U.S.gal
QSC8.3	10.9	MAX	11.5





### ⚠ WARNING ⚠

Before removing the pressure cap, wait until the coolant temperature is below 50°C [120°F]. Failure to do so can cause personal injury from heated coolant spray.

Install the pressure cap. Operate the engine until the coolant reaches a temperature of 80°C [180°F], and check for coolant leaks.

Check the coolant level again to make sure the system is full of coolant or that the coolant level has risen to the hot level in the recovery bottle on the system, if so equipped.






## Vibration Damper, Rubber

### Inspect

Check the index lines (A) in the vibration damper hub (B) and the inertia member (C). If the lines are more than 1.59 mm [1/16 in] out of alignment, replace the vibration damper.



Inspect the rubber member for deterioration. If pieces of rubber are missing or if the elastic member is more than 3.18 mm [1/8 in] below the metal surface, replace the damper.

Look for forward movement on the damper ring on the hub. Replace the vibration damper if any movement is detected.

For vibration damper location, refer to Engine Diagrams in Engine Identification (Section E).

## Section A - Adjustment, Repair, and Replacement

### Section Contents

	Page
<b>Air in Fuel</b> .....	A-19
General Information .....	A-19
Test .....	A-20
<b>Alternator</b> .....	A-1
Install .....	A-2
Preparatory Steps .....	A-1
Remove .....	A-1
<b>Charge-Air Cooler</b> .....	A-2
Clean .....	A-3
General Information .....	A-2
Initial Check .....	A-2
Install .....	A-4
Leak Test .....	A-5
Pressure Test .....	A-4
Remove .....	A-3
Temperature Differential Test .....	A-6
<b>Cooling Fan Belt Tensioner</b> .....	A-7
Inspect for Reuse .....	A-8
Install .....	A-8
Preparatory Steps .....	A-7
Remove .....	A-7
<b>Drive Belt, Cooling Fan</b> .....	A-6
Inspect for Reuse .....	A-7
Install .....	A-7
Remove .....	A-6
<b>Fan Spacer and Pulley</b> .....	A-9
Inspect for Reuse .....	A-9
Install .....	A-10
Preparatory Steps .....	A-9
Remove .....	A-9
<b>Fuel Filter Adapter</b> .....	A-10
Install .....	A-11
Bosch® .....	A-11
Preparatory Steps .....	A-10
Bosch® .....	A-10
Remove .....	A-10
Bosch® .....	A-10
<b>Fuel Lift Pump</b> .....	A-11
Clean .....	A-12
Install .....	A-12
Preparatory Steps .....	A-11
Remove .....	A-11
<b>Fuel Manifold (Drain)</b> .....	A-12
Install .....	A-13
Preparatory Steps .....	A-12
Remove .....	A-12
<b>Fuel Shutoff Valve</b> .....	A-13
Install .....	A-13
Preparatory Steps .....	A-13
Remove .....	A-13
<b>Lubricating Oil Pressure Regulator (Main Rifle)</b> .....	A-14
Clean .....	A-15
Install .....	A-15
Preparatory Steps .....	A-14
Remove .....	A-15
<b>Lubricating Oil Thermostat</b> .....	A-15
Clean .....	A-16



	Page
Install .....	A-16
Preparatory Steps .....	A-15
Remove .....	A-16
<b>Starting Motor</b> .....	A-16
Initial Check .....	A-16
Install .....	A-17
Remove .....	A-17
Rotation Check .....	A-18

## Alternator

### Preparatory Steps




**WARNING**

**Always connect the ground or negative (-) cable last to avoid arcing that can ignite explosive battery gases.**


Disconnect the ground cable from the battery terminal.

Remove and tag all wires.



Remove the drive belt from the alternator pulley.


Refer to the Troubleshooting and Repair Manual, ISC Engine, Bulletin No. 3666245.



### Remove

#### 13 mm


Remove the alternator link capscrew.




#### 16 mm

Remove the alternator mounting capscrew.

Remove the alternator.






### Install

To install the alternator, the alternator mounting components **must** be tightened in the following sequence:

1. Alternator-to-alternator bracket capscrew
2. Lower brace-to-alternator capscrew
3. Lower alternator brace-to-water pump capscrew
4. Water inlet-to-block capscrews.

**NOTE:** The wrench size and torque value is determined by the make and model of the alternator. Refer to the Troubleshooting and Repair Manual, ISC Engine, Bulletin No. 3666245.



To install the alternator, the alternator mounting components **must** be tightened in the following sequence:

1. Alternator-to-alternator bracket capscrew

**Torque Value:** 43 N•m [32 ft-lb]

2. Lower brace-to-alternator capscrew


**Torque Value:** 24 N•m [18 ft-lb]

3. Lower alternator brace-to-water pump capscrew

**Torque Value:** 24 N•m [18 ft-lb]

4. Water inlet-to-block capscrews.

**Torque Value:** 24 N•m [18 ft-lb]




## Charge-Air Cooler

### General Information

The long-term integrity of the charge air cooler system is the responsibility of the vehicle and component manufacturers; however, the following can be checked by any Cummins Authorized Repair Facility.

**NOTE:** If the engine experiences a turbocharger failure or any other occasion where oil or debris is put into the charge air cooler, the charge air cooler **must** be cleaned.



### Initial Check

Inspect the charge air cooler for cracks, holes, and damage.

Inspect the tubes, fins, and welds for tears, breaks, or other damage. If any damage causes the charge air cooler to fail the air leak check, the charge air cooler **must** be replaced.

Inspect the charge air cooler plumbing for cracks and damage.

## Remove

### ⚠ WARNING ⚠

Coolant is toxic. Keep away from children and pets. If not reused, dispose of in accordance with local environmental regulations.

### ⚠ WARNING ⚠


Wear appropriate eye and face protection when using compressed air. Flying debris and dirt can cause personal injury.

Use compressed air to clean debris from the outside of the charge air cooler.

Drain the coolant. Refer to Section 7.

Remove the charge air cooler plumbing.


Remove the charge air cooler. Refer to the OEM service manual.



## Clean

**NOTE:** If the engine experiences a turbocharger failure or any other occasion where oil or debris is put into the charge air cooler, the charge air cooler **must** be cleaned.

Remove the charge air cooler piping and charge air cooler from the vehicle. Refer to the original equipment manufacturer's instructions.



### ⚠ WARNING ⚠

When using solvents, acids, or alkaline materials for cleaning, follow the manufacturer's recommendations for use. Wear goggles and protective clothing to reduce the possibility of personal injury.


### ⚠ CAUTION ⚠


**Do not use caustic cleaners to clean the charge air cooler. Damage to the charge air cooler will result.**

Flush the charge air cooler internally with solvent in the opposite direction of normal airflow. Shake the charge air cooler and lightly tap on the end tanks with a rubber mallet to dislodge trapped debris. Continue flushing until all debris or oil is removed (i.e., the water runs clear).

**NOTE:** Make sure that the tubes are in the vertical direction when flushing.

If the debris can **not** be totally removed from the charge air cooler, the charge air cooler **must** be replaced.





**WARNING**

Wear appropriate eye and face protection when using compressed air. Flying debris and dirt can cause personal injury.

**WARNING**


When using solvents, acids, or alkaline materials for cleaning, follow the manufacturer's recommendations for use. Wear goggles and protective clothing to reduce the possibility of personal injury.

**CAUTION**

The charge air cooler must be rinsed, dried, and cleaned of solvent, oil, and debris, or engine damage will result.

After the charge air cooler has been thoroughly cleaned of all oil and debris with solvent, wash the charge air cooler internally with hot, soapy water to remove the remaining solvent. Rinse thoroughly with clean water.

Blow compressed air through the inside of the charge air cooler in the opposite direction of normal airflow until the charge air cooler is dry internally.




**Install**

Install the charge air cooler.

Install the charge air cooler plumbing.



Refer to the OEM service manual for instructions.



**Pressure Test**

**Pressure Gauge, Part Number ST-1273**



Install the pressure gauge, Part Number ST-1273, to the fitting in the turbocharger outlet.

Install another pressure gauge, Part Number ST-1273, in the intake manifold.



Operate the engine at rated rpm and load. Record the readings on the two gauges.

If the differential pressure is greater than 21 kPa [3 psi], check the charge air cooler for plugging. Clean or replace if necessary.

## Leak Test

### ▲ WARNING ▲

To reduce the possibility of injury if either plug blows off during the test, secure safety chains on the test plugs to any convenient capscrew on the radiator assembly. This test must not be performed without securely fastened safety chains.

To check the charge air cooler for cracked tubes or header, remove the inlet and outlet hoses from the cooler. The charge air cooler does **not** have to be removed from the chassis.



Install a plug or cap over the outlet side of the cooler. Install a pressure gauge and a regulated shop air supply line with a shutoff valve to the inlet side of the cooler.

Apply air pressure to the cooler until the pressure gauge reads a steady 207 kPa [30 psi] of air pressure.

Shut off the airflow to the cooler and start a stopwatch at the same time. Record the leakage at 15 seconds.

If the pressure drop is 48 kPa [7 psi] or less in 15 seconds, the cooler is operational.


If the pressure drop is greater than 48 kPa [7 psi] in 15 seconds, check all connections again.



Determine if the pressure drop is caused by a leaky charge air cooler or a leaky connection. Spray soapy water on all hose connections, and watch for bubbles to appear at the location of the leak.

If the pressure drop is caused by a leaky connection, repair the connection and repeat the test. If the leak is within the charge air cooler, repeat the test to verify the accuracy of the pressure drop measurement. Similar pressure drop readings **must** be obtained in at least three consecutive tests before the reading can be considered accurate.


**NOTE:** If a charge air cooler leaks more than 48 kPa [7 psi] in 15 seconds, it will appear as a major leak in a leak tank.




If the pressure drop is greater than 48 kPa [7 psi] in 15 seconds, the charge air cooler **must** be replaced.

Refer to the equipment manufacturer's service manual for replacement instructions.

**NOTE:** Charge air coolers are **not** designed to be 100-percent leak free. If the pressure drop is less than 48 kPa [7 psi] in 15 seconds, then the charge air cooler does **not** need to be replaced.






### Temperature Differential Test

Install a temperature gauge in the intake manifold.



Lock the fan drive in the ON mode to prevent erratic test results. This can be done by installing a jumper across the temperature switch or supplying shop air to the fan. Refer to the fan drive manufacturer for lockup procedure.

**NOTE:** Some trucks have a manual switch that will lock the fan on.




Operate the engine at rated rpm and load. Record the intake manifold temperature.



Measure the ambient temperature at least 2 feet in front of the vehicle.

The maximum temperature differential **must not** be greater than 25°C [45°F].

If the temperature differential is greater than 25°C [45°F], check the charge air cooler for dirt and debris on the fins, and clean as necessary. If the problem still exists, check the cooler for internal contamination or plugging.



### Drive Belt, Cooling Fan


#### Remove



#### 3/8-Inch Square Drive

Lift the tensioner to remove the drive belt.

**NOTE:** The belt tensioner winds in the direction that the spring tang is bent over the tensioner body. To loosen the tension on the belt, rotate the tensioner to wind the spring tighter.




### ⚠ CAUTION ⚠

Applying excessive force in the opposite direction of wind-up or after the tensioner has been wound up to the positive stop can cause the tensioner arm to break.

## Inspect for Reuse

Inspect the drive belt for:

- Cracks
- Glazing
- Tears or cuts
- Hardening
- Excessive wear.




## Install



The belt tensioner is spring-loaded and must be pivoted away from the drive belt. Pivoting in the wrong direction can result in damage to the belt tensioner.

### 3/8-Inch Square Drive


Lift the tensioner to install the drive belt.



## Cooling Fan Belt Tensioner

### Preparatory Steps

Remove the drive belt.




## Remove




The belt tensioner is spring loaded and must be pivoted away from the drive belt. Pivoting in the wrong direction can damage the belt tensioner.

### 3/8-Inch Square Drive

Lift the belt tensioner to relieve tension in the belt, and remove the belt.









15 mm

Remove the capscrew and belt tensioner from the bracket.



### Inspect for Reuse

Inspect the tensioner bushing between the arm and the spring case.




### Install

15 mm

Install the belt tensioner and capscrews.



**Torque Value:** 43 N•m [32 ft-lb]



### 3/8-Inch Square Drive

Lift and hold the tensioner. Install the drive belt, and release the tensioner.




**Service Tip:** If difficulty is experienced installing the drive belt or if the belt seems too short, position the belt over the grooved pulleys first; then, while holding the tensioner up, slide the belt over the water pump pulley.

## Fan Spacer and Pulley

### Preparatory Steps

Remove the drive belt.

Loosen the capscrews before removing the belt, and tighten the capscrews after the belt is installed.




### Remove



The belt tensioner is spring-loaded and must be pivoted away from the drive belt. Pivoting in the wrong direction can result in damage to the belt tensioner.


#### 3/8-Inch Square Drive

Lift the tensioner to relieve tension in the belt. Remove the belt.



Remove the fan capscrews, fan, and spacer.


Remove the fan pulley.




### Inspect for Reuse

Inspect the fan pulley for cracks near bolt holes.

Check for cracks, loose rivets, and bent or loose blades.






### Install

13 mm

Install the fan pulley.

Install the spacer, fan, and fan cap screws.


**Torque Value:** 24 N•m [212 in-lb]



### 3/8-Inch Square Drive

Lift the tensioner, and install the belt.

**Service Tip:** If difficulty is experienced installing the drive belt or if the belt seems too short, position the belt over the grooved pulleys first; then, while holding the tensioner up, slide the belt over the water pump pulley.




### Fuel Filter Adapter

#### Preparatory Steps

**Bosch®**

Clean debris.

Remove fuel filters.



### Remove

**Bosch®**


Remove the retaining nut, fuel filter head adapter, and sealing washers.

## Install

**Bosch®**

Install in the reverse order of removal.


**Torque Value:** 32 N•m [24 ft-lb]




## Fuel Lift Pump

### Preparatory Steps

Clean all debris from the fuel lift pump.




Disconnect the fuel supply lines.




## Remove

Remove the two fuel lift pump mounting cap screws.


Remove the fuel lift pump.





### Clean

Clean the fuel transfer pump mounting surface on the cylinder block.



### Install

#### ⚠ CAUTION ⚠

Failure to tighten the fuel transfer pump mounting capscrews alternately can result in broken lift pump flanges.

Install a new fuel transfer pump gasket.

Alternately tighten the mounting bolts.

**Torque Value:** 24 N•m [212 in-lb]


Connect the fuel lines.



### Fuel Manifold (Drain)

#### Preparatory Steps

Clean all debris from around the fuel drain manifold.



### Remove

Remove the banjo capscrews from the injectors and fuel filter head.

## Install

Install the fuel drain manifold in the reverse order of removal.


### Torque Value:

Filter Head Banjo

15 N•m [133 in-lb]

Injector Banjo

9 N•m [80 in-lb].



## Fuel Shutoff Valve


### Preparatory Steps

Label and disconnect the wiring.

## Remove

Remove the two mounting capscrews, and remove the solenoid from the bracket.

1. Synchro-start
2. Trombetta
3. Direct link.




## Install


**NOTE:** Make sure the acorn nut is tightened to be snugly on the fuel shutoff solenoid shaft (Synchro-start **only**).

Install the new fuel shutoff solenoid to the bracket, and connect the wires. Make sure the wiring harness on the Trombetta solenoid is installed in the six-o'clock position.

**Torque Value:** 10 N•m [89 in-lb]

1. Synchro-start
2. Trombetta
3. Direct link.






Activate the switch and check the plunger travel.

	Synchro- start	Trombetta	Direct link
A =	86.8 mm [3.4 in]	91.4 mm [3.6 in]	
B =	60.2 mm [2.4 in]	63.5 mm [2.5 in]	117.1 mm [4.61 in]

The plunger **must** be retracted when the fuel shutoff solenoid is activated to the RUN position B. The fuel shutoff solenoid **must** operate without binding.




Remove the hitch pin clip, the mounting capscrews, and the fuel shutoff solenoid.




Install the new solenoid in reverse order of removal, and connect the wires.

**Torque Value:** 10 N•m [89 in-lb]



Adjust the solenoid linkage as necessary so that the plunger is magnetically held in with the shutoff lever in the absolute full-run position. Turn the large hex nut on the end of the plunger to make adjustments, and secure in place with a locknut.



## Lubricating Oil Pressure Regulator (Main Rifle)

### Preparatory Steps

#### ⚠ WARNING ⚠


When using solvents, acids, or alkaline materials for cleaning, follow the manufacturer's recommendations for use. Wear goggles and protective clothing to avoid personal injury.

Clean the area around the pressure regulator plug with solvent to prevent debris from falling into the plunger bore when the plug is removed.

## Remove


Remove the threaded plug, spring, and plunger.

**Service Tip:** The plunger normally can be removed by inserting one finger into the plunger bore until snug, and pulling up. If the plunger can **not** be removed in this manner, the plunger is probably stuck and will require removal of the housing for plunger removal and cleaning.



## Clean

Clean and inspect the bore and regulator valve before assembly.




## Install

**NOTE:** The valve **must** move freely in the bore.

Install the regulator, spring, and plug.

**Torque Value:** 80 N•m [59 ft-lb]




## Lubricating Oil Thermostat Preparatory Steps

Clean debris from oil thermostat.









### Remove

Remove the lubricating oil thermostat.



### Clean


Clean and inspect the lubricating oil thermostat bore before assembly.



### Install

Install and tighten the oil cooler bypass valve.

**Torque Value:** 50 N•m [37 ft-lb]



## Starting Motor

### Initial Check

If the starter solenoid is making a sound but the engine is **not** rotating, remove the starter motor and check for broken ring gear teeth or a broken starter motor spring.

## Remove

### ⚠ WARNING ⚠

Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To avoid arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

### ⚠ WARNING ⚠

Acid is extremely dangerous and can damage the machinery and can also cause serious burns. Always provide a tank of strong soda water as a neutralizing agent when servicing the batteries. Wear goggles and protective clothing to reduce the possibility of serious personal injury.



Remove the electrical connections from the batteries, negative (-) cable first.

Remove the electrical connections from the starter motor.

Identify each wire with a tag indicating location on starter motor.

Remove the capscrews from the flywheel housing.

Remove the starter motor.





## Install

Install the starter motor.

Install and tighten the mounting capscrews.


**Torque Value:** 43 N•m [32 ft-lb]





**NOTE:** Use the location tags to help identify where each wire connection goes.

Install the starter motor electrical connections.



### ⚠ WARNING ⚠


Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To avoid arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

### ⚠ WARNING ⚠

Acid is extremely dangerous and can damage the machinery and can also cause serious burns. Always provide a tank of strong soda water as a neutralizing agent when servicing the batteries. Wear goggles and protective clothing to reduce the possibility of serious personal injury.

Clean the inside of the battery terminal with a brush before connecting to battery.

Install battery cables, connecting the negative (-) cable last.



### Rotation Check


If the starter motor solenoid makes a sound, turn the keyswitch to the OFF position, and attempt to bar the crankshaft in both directions.

Bar the engine using the barring tool, Part Number 3824591.

Bar the crankshaft as follows:

1. Direction of engine rotation
2. Direction opposite engine rotation
3. Direction of engine rotation.

If the crankshaft will bar over, attempt to start the engine.  
If the starter motor cranks the engine, check the starter motor pinion gear and flywheel ring gear for damage.



## **Air in Fuel**

### **General Information**

#### **⚠ WARNING ⚠**

**Fuel is flammable. Keep all cigarettes, flames, pilot lights, arcing equipment, and switches out of the work area and areas sharing ventilation to reduce the possibility of severe personal injury or death when working on the fuel system.**

#### **⚠ WARNING ⚠**

**Do not vent the fuel system on a hot engine; this can cause fuel to spill onto a hot exhaust manifold, which can cause a fire.**

The low-pressure fuel system for Cummins diesel installed in the vehicle consists of the fuel tank, lines between tank and engine, transfer pump and lines, and fuel filter and lines. Air or bubbles at the injection pump can cause no or erratic engine operation and/or subsequent malfunction of the fuel injection pump. Air can be introduced by leaks in the fuel system prior to the transfer pump since fuel pressure is a vacuum. Bubbles can result from any number of restrictions in the system:

- Plugged fuel filter
- Crimped fuel line
- Stopped-up tank module
- Inoperative transfer pump.



If sufficient fuel reaches the injection pump from the low-pressure system, then solutions to engine operational problems are elsewhere. The following steps will aid in evaluating low-pressure fuel system performance in absence of fault codes.

**NOTE:** For cold-start/performance problems, perform the following steps:


- Leave vehicle outside in cold environment for at least 12 hours.
- Perform outlined test.
- If the system fails to meet test criteria, replace the fuel lift pump.

## Test

A replacement of fuel supply lines, fuel filters, fuel injection pump, high-pressure fuel lines, and injectors will let air enter the fuel system. Air in the system will make the engine hard to start, run rough, misfire, produce low power, and can cause excessive smoke and a fuel knock.




Since the fuel lift pump provides positive pressure through the fuel filter and supply line to the fuel injection pump, loose connections or defective seals can show as a fuel leak, **not** as an air leak.



**NOTE:** If an excessive amount of air has entered into the system, the system will need to be vented.

Loosen the return banjo fitting on the fuel lift pump. Run the fuel lift pump until all the air has been vented. When all the air has been vented, retighten the fitting.

**NOTE:** To run the fuel pump for 25 seconds, crank the engine for a split second, and leave the key in the ON position.




If air continues to bubble out of the system for several minutes, then an air leak is present.

An often overlooked source from which air can enter the fuel system is between the inlet of the fuel transfer pump and the suction tube in the tank. Fuel tanks that have the outlet fitting at the top will have a suction tube that extends to the bottom of the tank. Cracks or pin holes in the weld that join the tube to the fitting can let air enter the fuel system.

Also, check to make sure all the fittings from the fuel supply line on the tank to the inlet of the fuel transfer pump are tight.

Use a sight glass at the fuel lift pump inlet to check for air in the fuel supply lines.


Since the fuel pump provides a positive pressure through the fuel filter and supply line to the fuel injection pump, loose connections or defective seals should show as a fuel leak, **not** as an air leak.




A stuck-open injector can also blow combustion gas back into the pump and cause air to be present in the overflow. If the engine seems to be misfiring or running rough, break all the injector supply lines loose at the pump end. Crank the engine, and observe the lines. If combustion gas seems to be blowing back through the line, the injector is stuck open. Remove the injector. Take the vehicle to an Authorized Cummins Repair Facility/Dealer Location for testing.

**Torque Value:** 24 N•m [212 in-lb]


**NOTE:** Use two wrenches when loosening the lines at the fuel pump: One to hold the delivery valve and one to loosen the fuel line.





Disconnect the fuel line from the outlet of the fuel filter.



Attach a preferably clear hose to the outlet of the fuel filter. (Do **not** use pressure test fitting.) Place a pressure gauge on the inlet side of the fuel filter and a vacuum gauge on the inlet side to the transfer pump.



Insert a hose into an empty 3.8-liter [1-gal] container.




Operate the fuel lift pump by bumping the starter. (The lift pump should run for 25 to 30 seconds.) Check for bubbles in fuel.



Record filter inlet pressure and transfer pump inlet restriction.

If filter inlet pressure is greater than 34.8 kPa [5 psi], the filter element **must** be replaced. Repeat test.


If inlet restriction is greater than 152.4 mm Hg [6 in Hg] or 155.1 mm Hg [3 psi], then excessive restriction exists between fuel in the tank and the transfer pump, which **must** be repaired (e.g., fuel line or tank module). Repeat test.



If bubbles are present, check for air leaks in the fuel supply circuit.



Measure the amount of fuel in the container. If more than 1.33 liters [45 fl oz] are collected and the fuel is bubble-free, then it is unlikely the low-pressure fuel system is the cause of engine operational problems.




Reconnect the lift pump that is retaining the fuel filter pressure connections. Running engine at high idle, the filter inlet pressure should be greater than 42.3 kPa [6 psi]; otherwise, there is a fuel lift pump malfunction.



If the fuel transfer pump does **not** run, check electrical circuits, and verify voltage is present at lift pump connector.



**NOTE:** When an engine is **not** running, with key on, the lift pump will run less than 2 seconds (varies with ECM calibration); with starter bump, about 25 to 30 seconds. If voltage is present, replace fuel transfer pump. Resistance measurement across the transfer pump terminals can be made for confirmation of pump malfunction. Resistance greater than 200 ohms or less than 0.2 ohm does confirm an electrical fault when voltage is present but the fuel pump is **not** running.





[illegible]

## Section D - System Diagrams

### Section Contents

	Page
<b>Flow Diagram, Air Intake System</b> .....	D-11
General Information .....	D-11
<b>Flow Diagram, Compressed Air System</b> .....	D-13
General Information .....	D-13
General Information .....	D-13
<b>Flow Diagram, Cooling System</b> .....	D-7
General Information .....	D-7
General Information .....	D-7
<b>Flow Diagram, Exhaust System</b> .....	D-12
General Information .....	D-12
<b>Flow Diagram, Fuel System</b> .....	D-2
General Information .....	D-2
General Information .....	D-2
<b>Flow Diagram, Lubricating Oil System</b> .....	D-3
General Information .....	D-3
General Information .....	D-3
<b>System Diagrams - Overview</b> .....	D-1
General Information .....	D-1

**THIS PAGE LEFT INTENTIONALLY BLANK**

## **System Diagrams - Overview**

### **General Information**

The following drawings show the flow through the engine systems. Although the parts can be different for various applications and installations, the flow remains the same. The systems shown are


- Fuel system
- Lubricating oil system
- Coolant system
- Intake air system
- Exhaust system
- Compressed air system.

Knowledge of the engine systems can help in troubleshooting, servicing, and general maintenance of the engine.

## Flow Diagram, Fuel System

### General Information

### General Information




1. Fuel from supply tank
2. Prefilter or screen
3. Fuel transfer pump
4. Fuel/water separator
5. Fuel filter
6. Low-pressure supply line
7. Turbocharger boost control line

8. Bosch® PES.MW injection pump
9. Bosch® PES.A injection pump
10. Bosch® PES.P injection pump
11. Fuel drain manifold
12. High-pressure fuel lines
13. Hole-type injectors
14. Fuel return to supply tank.


## Flow Diagram, Lubricating Oil System

### General Information

#### General Information




- |                                     |                                      |
|-------------------------------------|--------------------------------------|
| 1. Gerotor lubricating oil pump     | 8. Filter bypass valve               |
| 2. Pressure regulating valve closed | 9. Filter bypass valve closed        |
| 3. Pressure regulating valve open   | 10. Filter bypass valve open         |
| 4. From lubricating oil pump        | 11. To lubricating oil filter        |
| 5. To lubricating oil cooler        | 12. Full-flow lubricating oil filter |
| 6. To lubricating oil pump oil pan  | 13. From lubricating oil filter      |
| 7. Lubricating oil cooler           | 14. Main lubricating oil rifle.      |



- 1. Lubrication oil filter
- 2. Turbocharger lubricating oil supply
- 3. Turbocharger lubricating oil drain
- 4. To main lubricating oil rifle.

**Insert Color File**  
07d00001.CDR  
Pantone 185 (Red)




07d00001

1. From lubricating oil cooler
2. Main lubricating oil rifle
3. To camshaft

4. To piston cooling nozzle
5. From main lubricating oil rifle
6. To connecting rod bearing.





07d00002

1. From cam bushings
2. Transfer slot
3. Rocker lever support

4. Rocker lever shaft
5. Rocker lever bore
6. Rocker lever.


## Flow Diagram, Cooling System

### General Information

#### General Information

**Insert Color File**

08900201.CDR  
Pantone 299 (Blue)




Cylinder Block

08900201

- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Coolant inlet              | 4. Coolant flow past oil cooler   |
| 2. Water pump impeller        | 5. Upper coolant manifold         |
| 3. Coolant flow to oil cooler | 6. Coolant flow to cylinder head. |

**Insert Color File**

08900203.CDR  
Pantone 299 (Blue)




08900203

Cylinder Head

- |                                     |                          |
|-------------------------------------|--------------------------|
| 1. Flow from upper coolant manifold | 3. Cylinder head gasket  |
| 2. Flow to liner cavity             | 4. Coolant flow orifice. |


**Insert Color File**  
08900200.CDR  
Pantone 299 (Blue)



08900200

1. Flow past cylinder liners

2. Lower coolant manifold.




08900202

1. Thermostats
2. Flow to water pump inlet
3. Bypass passage open
4. Flow from lower coolant manifold

5. Partial coolant flow to radiator
6. Restricted flow to bypass
7. Flow to radiator
8. Bypass closed.

## Flow Diagram, Air Intake System

### General Information




10900277

1. Intake air inlet to turbocharger
2. Turbocharger air to charge air cooler
3. Charge air cooler
4. Intake manifold - integral part of cylinder head
5. Intake valve.

## Flow Diagram, Exhaust System

### General Information




11900058

- |                                  |                                 |
|----------------------------------|---------------------------------|
| 1. Exhaust valve                 | 3. Dual entry to turbocharger   |
| 2. Exhaust manifold - pulse-type | 4. Turbocharger exhaust outlet. |

## Flow Diagram, Compressed Air System

### General Information


#### General Information



12900074


- |                        |                                    |
|------------------------|------------------------------------|
| 1. Compressor          | 8. Economy valve line              |
| 2. Compressor intake   | 9. Air drainer                     |
| 3. E-type unloader     | 10. Check valve (built into dryer) |
| 4. Reservoir line      | 11. Reservoir (wet tank)           |
| 5. Governor            | 12. Check valve                    |
| 6. Discharge line      | 13. Secondary pressure line.       |
| 7. Splitter valve line |                                    |





12900030

1. Air in
2. Air out
3. Coolant out
4. Coolant in
5. Lubricating oil in
6. Lubricating oil out.



## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

**Section L - Service Literature**  
**Section Contents**

	Page
<b>Additional Service Literature</b> .....	L-1
General Information .....	L-1
<b>Service Literature Ordering Location</b> .....	L-2
Contact Information .....	L-2

**THIS PAGE LEFT INTENTIONALLY BLANK**

## Additional Service Literature

### General Information

The following publications can be purchased by contacting the nearest local distributor.

<b>Bulletin Number</b>	<b>Title of Publication</b>
3666003	C Series Troubleshooting and Repair Manual
3666008	C Series Engine Shop Manual
3666021	C Series Specifications Manual
3379001	Fuel for Cummins Engines Bulletin
3666132	Coolant Requirements and Maintenance Bulletin
3379009	Operation, Cold Weather
3810340	Cummins Engine Oil Recommendations Bulletin
3666109	Alternative Repair Manual, B and C Series Engines
3379000	Air for Your Engines

## Service Literature Ordering Location

### Contact Information

#### Region

United States and Canada

U.K., Europe, Mid-East, Africa,  
and Eastern European Countries

South and Central America  
(excluding Brazil and Mexico)

Brazil and Mexico

Far East (excluding  
Australia and New Zealand)

Australia and New Zealand

#### Ordering Location

Cummins Distributors  
or  
Credit Cards at 1-800-646-5609  
or  
Order online at [www.powerstore.cummins.com](http://www.powerstore.cummins.com)

Cummins Engine Co., Ltd.  
Royal Oak Way South  
Daventry  
Northants, NN11 5NU, England

Cummins Americas, Inc.  
16085 N.W. 52nd Avenue  
Hialeah, FL 33104

Cummins Inc.  
International Parts Order Dept., MC 40931  
Box 3005  
Columbus, IN 47202-3005

Cummins Diesel Sales Corp.  
Literature Center  
8 Tanjong Penjuru  
Jurong Industrial Estate  
Singapore

Cummins Diesel Australia  
Maroondah Highway, P.O.B. 139  
Ringwood 3134  
Victoria, Australia

## Section M - Component Manufacturers

### Section Contents

	Page
<b>Component Manufacturers' Addresses</b> .....	M-1
Air Compressors.....	M-1
Air Cylinders .....	M-1
Air Heaters.....	M-1
Air Starting Motors .....	M-1
Alternators.....	M-1
Auxiliary Brakes .....	M-1
Belts.....	M-1
Catalytic Converters .....	M-1
Clutches.....	M-1
Coolant Heaters .....	M-1
Coolant Level Switches .....	M-1
Drive Plates.....	M-1
Electric Starting Motors .....	M-2
Electronic Switches .....	M-2
Engine Protection Controls .....	M-2
Fan Clutches .....	M-2
Fans.....	M-2
Fault Lamps .....	M-2
Filters.....	M-2
Flexplates.....	M-2
Fuel Coolers.....	M-2
Fuel Pumps.....	M-2
Fuel Warmers.....	M-2
Gauges .....	M-2
General Information .....	M-1
Governors .....	M-2
Heat Sleeves.....	M-3
Hydraulic and Power Steering Pumps.....	M-3
In-Line Connectors .....	M-3
Oil Heaters .....	M-3
Prelubrication Systems.....	M-3
Radiators.....	M-3
Throttle Assemblies .....	M-3
Torque Converters .....	M-3



**THIS PAGE LEFT INTENTIONALLY BLANK**

## **Component Manufacturers' Addresses**

### **General Information**

**NOTE:** The following list contains addresses and telephone numbers of suppliers of accessories used on Cummins engines. Suppliers can be contacted directly for any specifications **not** covered in this manual.

### **Air Compressors**

Bendix Heavy Vehicles Systems  
Div. of Allied Automotive  
901 Cleveland Street  
Elyria, OH 44036  
Telephone: (216) 329-9000

Holset Engineering Co., Inc.  
1320 Kemper Meadow Drive  
Suite 500  
Cincinnati, OH 45240  
Telephone: (513) 825-9600

Midland-Grau  
Heavy Duty Systems  
Heavy Duty Group Headquarters  
10930 N. Pamona Avenue  
Kansas City, MO 64153  
Telephone: (816) 891-2470

### **Air Cylinders**

Bendix Ltd.  
Douglas Road  
Kingswood  
Bristol  
England  
Telephone: 0117-671881

Catching Engineering  
1733 North 25th Avenue  
Melrose Park, IL 60160  
Telephone: (708) 344-2334

TEC - Hackett Inc.  
8909 Rawles Avenue  
Indianapolis, IN 46219  
Telephone: (317) 895-3670

### **Air Heaters**

Fleetguard, Inc.  
1200 Fleetguard Road  
Cookeville, TN 38502  
Telephone: (615) 526-9551

Kim Hotstart Co.  
P.O. Box 11245  
Spokane, WA 99211-0245  
Telephone: (509) 534-6171

### **Air Starting Motors**

Ingersoll Rand  
Chorley New Road  
Horwich  
Bolton  
Lancashire  
England  
BL6 6JN  
Telephone: 01204-65544

Ingersoll-Rand Engine  
Starting Systems  
888 Industrial Drive  
Elmhurst, IL 60126  
Telephone: (708) 530-3875

StartMaster  
Air Starting Systems  
A Division of Sycon Corporation  
9595 Cheney Avenue  
P. O. Box 491  
Marion, OH 43302  
Telephone: (614) 382-5771

### **Alternators**

Robert Bosch Ltd.  
P.O. Box 98  
Broadwater Park  
North Orbital Road  
Denham  
Uxbridge  
Middlesex UD9 5HG  
England  
Telephone: (0)1895-838383

Prestolite Electrics  
Cleveland Road  
Leyland  
PR5 1XB  
England  
Telephone: (0)1772-421663

C. E. Niehoff & Co.  
2021 Lee Street  
Evanston, IL 60202  
Telephone: (708) 866-6030

Delco-Remy America  
2401 Columbus Avenue  
P.O. Box 2439  
Anderson, IN 46018  
Telephone: (317) 646-3528

Leece-Neville Corp.  
400 Main Street  
Arcade, NY 14009  
Telephone: (716) 492-1700

### **Auxiliary Brakes**

The Jacobs Manufacturing Company  
Vehicle Equipment Division  
22 East Dudley Town Road  
Bloomfield, CT 06002  
Telephone: (203) 243-1441

### **Belts**

T.B.A. Belting Ltd.  
P.O. Box 77  
Wigan  
Lancashire  
WN2 4XQ  
England  
Telephone: (0)1942-259221

Dayco Mfg.  
Belt Technical Center  
1955 Enterprize  
Rochester Hills, MI 48309  
Telephone: (810) 853-8300

Gates Rubber Company  
900 S. Broadway  
Denver, CO 80217

Goodyear Tire and  
Rubber Company  
Industrial Products Div.  
2601 Fortune Circle East  
Indianapolis, IN 46241  
Telephone: (317) 898-4170

### **Catalytic Converters**

Donaldson Company, Inc.  
1400 West 94th Street  
P.O. Box 1299  
Minneapolis, MN 55440  
Telephone: (612) 887-3835

Nelson Division  
Exhaust and Filtration Systems  
1801 U.S. Highway 51 P.O. Box 428  
Stoughton, WI 53589  
Telephone: (608) 873-4200

Walker Manufacturing  
3901 Willis Road  
P.O. Box 157  
Grass Lake, MI 49240  
Telephone: (517) 522-5500

### **Coolant Level Switches**

Robertshaw Controls Company  
P.O. Box 400  
Knoxville, TN 37901  
Telephone: (216) 885-1773

### **Clutches**

Twin Disc International S.A.  
Chaussee de Namur  
Nivelles  
Belguim  
Telephone: 067-224941

Twin Disc Incorporated  
1328 Racine Street  
Racine, WI 53403  
Telephone: (414) 634-1981

### **Coolant Heaters**

Fleetguard, Inc.  
1200 Fleetguard Road  
Cookeville, TN 38502  
Telephone: (615) 526-9551

### **Drive Plates**

Detroit Diesel Allison  
Division of General Motors  
Corporation  
P.O. Box 894  
Indianapolis, IN 46206-0894  
Telephone: (317) 242-5000

## **Electric Starting Motors**

Prestolite Electrics  
Cleveland Road  
Leyland  
PR5 1XB  
England  
Telephone: 01772-421663

Delco-Remy America  
2401 Columbus Avenue  
P.O. Box 2439  
Anderson, IN 46018  
Telephone: (317) 646-3528

Leece-Neville Corp.  
400 Main Street  
Arcade, NY 14009  
Telephone: (716) 492-1700

Nippondenso Inc.  
2477 Denso Drive  
P.O. Box 5133  
Southfield, MI 48086  
Telephone: (313) 350-7500

## **Electronic Switches**

Cutler-Hammer Products  
Eaton Corporation  
4201 N. 27th Street  
Milwaukee, WI 53216  
Telephone: (414) 449-6600

## **Engine Protection Controls**

Flight Systems Headquarters  
Hempt Road  
P.O. Box 25  
Mechanicsburg, PA 17055  
Telephone: (717) 697-0333

The Nason Company  
2810 Blue Ridge Blvd.  
West Union, SC 29696  
Telephone: (803) 638-9521

Teddington Industrial  
Equipment  
Windmill Road  
Sunbury on Thames  
Middlesex  
TW16 7HF  
England  
Telephone: (0)9327-85500

## **Fan Clutches**

Kysor Cooling Systems N.A.  
6040 West 62nd Street  
Indianapolis, IN 46278  
Telephone: (317) 328-3330

Holset Engineering Co. Ltd.  
ST Andrews Road  
Huddersfield, West Yorkshire  
England HD1 6RA  
Telephone: (0)1484-22244

Horton Industries, Inc.  
P.O. Box 9455  
Minneapolis, MN 55440  
Telephone: (612) 378-6410

Rockford Clutch Company  
1200 Windsor Road  
P.O. Box 2908  
Rockford, IL 61132-2908  
Telephone: (815) 633-7460

## **Fans**

Truflo Ltd.  
Westwood Road  
Birmingham  
B6 7JF  
England  
Telephone: (0)121-3283041

Hayes-Albion Corporation  
Jackson Manufacturing Plant  
1999 Wildwood Avenue  
Jackson, MI 49202  
Telephone: (517) 782-9421

Engineered Cooling Systems, Inc.  
201 W. Carmel Drive  
Carmel, IN 46032  
Telephone: (317) 846-3438

Brookside Corporation  
P.O. Box 30  
McCordsville, IN 46055  
Telephone: (317) 335-2014

TCF Aerovent Company  
9100 Purdue Rd., Suite 101  
Indianapolis, IN 46268-1190  
Telephone: (317) 872-0030

Kysor-Cadillac  
1100 Wright Street  
Cadillac, MI 49601  
Telephone: (616) 775-4681

Schwitzer  
6040 West 62nd Street  
P.O. Box 80-B  
Indianapolis, IN 46206  
Telephone: (317) 328-3010

## **Fault Lamps**

Cutler-Hammer Products  
Eaton Corporation  
4201 N. 27th Street  
Milwaukee, WI 53216  
Telephone: (414) 449-6600

## **Filters**

Fleetguard International Corp.  
Cavalry Hill Industrial Park  
Weedon  
Northampton NN7 4TD  
England  
Telephone: 01327-341313

Fleetguard, Inc.  
1200 Fleetguard Road  
Cookeville, TN 38502  
Telephone: 1-800-22-Filters  
(1-800-223-4583)

## **Flexplates**

Corrugated Packing and  
Sheet Metal  
Hamsterley  
Newcastle Upon Tyne  
England  
Telephone: (0)1207-560-505

Allison Transmission  
Division of General Motors  
Corporation  
P.O. Box 894  
Indianapolis, IN 46206-0894  
Telephone: (317) 242-5000

Midwest Mfg. Co.  
29500 Southfield Road, Suite 122  
Southfield, MI 48076  
Telephone: (313) 642-5355

Wohlert Corporation  
708 East Grand River Avenue  
P.O. Box 20217  
Lansing, MI 48901  
Telephone: (517) 485-3750

## **Fuel Coolers**

Hayden, Inc.  
1531 Pomona Road  
P.O. Box 848  
Corona, CA 91718-0848  
Telephone: (909) 736-2665

## **Fuel Pumps**

Robert Bosch Corp.  
Automotive Group  
2800 South 25th Ave.  
Broadview, IL 60153

## **Fuel Warmers**

Fleetguard, Inc.  
1200 Fleetguard Road  
Cookeville, TN 38502  
Telephone: (615) 526-9551

## **Gauges**

Grasslin U.K. Ltd.  
Vale Rise  
Tonbridge  
Kent  
TN9 1TB  
England  
Telephone: (0)1732-359888

Datcon Instruments  
P.O. Box 128  
East Petersburg, PA 17520  
Telephone: (717) 569-5713

Rochester Gauges, Inc.  
11616 Harry Hines Blvd.  
P.O. Box 29242  
Dallas, TX 75229  
Telephone: (214) 241-2161

## **Governors**

Woodward Governor Co.  
P.O. Box 1519  
Fort Collins, CO 80522  
Telephone: (303) 482-5811  
(800) 523-2831

Barber Colman Co.  
1354 Clifford Avenue  
Loves Park, IL 61132  
Telephone: (815) 637-3000

United Technologies  
Diesel Systems  
1000 Jorie Blvd.  
Suite 111  
Oak Brook, IL 69521  
Telephone: (312) 325-2020

### **Heat Sleeves**

Bentley Harris Manufacturing Co.  
100 Bentley Harris Way  
Gordonville, TN 38563  
Telephone: (313) 348-5779

### **Hydraulic and Power Steering Pumps**

Honeywell Control Systems Ltd.  
Honeywell House  
Arlington Business Place  
Bracknell  
Berks RG12 1EB  
Telephone: (0)1344-656000

Sperry Vickers  
P.O. Box 302  
Troy, MI 48084  
Telephone: (313) 280-3000

Z.F.  
P.O. Box 1340  
Gravonsoden Strasse  
5-9 D7070  
Schwaebisch Gmuend  
Germany  
Telephone: 7070-7171-31510

### **In-Line Connectors**

Pioneer-Standard Electronics, Inc.  
5440 Neiman Parkway  
Solon, OH 44139  
Telephone: (216) 349-1300

Deutsch  
Industrial Products Division  
37140 Industrial Avenue  
Hemet, CA 92343  
Telephone: (714) 929-1200

### **Oil Heaters**

Fleetguard, Inc.  
1200 Fleetguard Road  
Cookeville, TN 38502  
Telephone: (615) 526-9551

Kim Hotstart Co.  
P.O. Box 11245  
Spokane, WA 99211-0245  
Telephone: (509) 534-6171

### **Prelubrication Systems**

RPM Industries, Inc.  
Suite 109  
55 Hickory Street  
Washington, PA 15301  
Telephone: (412) 228-5130

### **Radiators**

JB Radiator Specialties, Inc.  
P.O. Box 292087  
Sacramento, CA 95829-2087  
Telephone: (916) 381-4791

The G&O Manufacturing Company  
100 Gando Drive  
P.O. Box 1204  
New Haven, CT 06505-1204  
Telephone: (203) 562-5121

Young Radiator Company  
2825 Four Mile Road  
Racine, WI 53404  
Telephone: (910) 271-2397

L and M Radiator, Inc.  
1414 East 37th Street  
Hibbing, MN 55746  
Telephone: (218) 263-8993

### **Throttle Assemblies**

Williams Controls, Inc.  
14100 SW 72nd Avenue  
Portland, OR 97224  
Telephone: (503) 684-8600

### **Torque Converters**

Twin Disc International S.A.  
Chaussee de Namur  
Nivelles  
Belgium  
Telephone: 067-224941

Twin Disc Incorporated  
1328 Racine Street  
Racine, WI 53403-1758  
Telephone: (414) 634-1981

Rockford Powertrain, Inc.  
Off-Highway Systems  
1200 Windsor Road  
P.O. Box 2908  
Rockford, IL 61132-2908  
Telephone: (815) 633-7460

Modine Mfg. Co.  
1500 DeKoven Avenue  
Racine, WI 53401  
Telephone: (414) 636-1640

## NOTES

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## Section S - Service Assistance

### Section Contents

	Page
<b>Distributors - International</b> .....	S-18
Locations .....	S-18
<b>Distributors and Branches</b> .....	S-3
Australia.....	S-12
Canada .....	S-10
New Zealand.....	S-14
United States .....	S-3
<b>Division and Regional Offices</b> .....	S-2
Locations .....	S-2
<b>Emergency and Technical Service</b> .....	S-1
General Information .....	S-1
<b>Problem Solving</b> .....	S-1
General Information .....	S-1
<b>Regional Offices - International</b> .....	S-15
Locations .....	S-15
<b>Routine Service and Parts</b> .....	S-1
General Information .....	S-1

**THIS PAGE LEFT INTENTIONALLY BLANK**

## Routine Service and Parts

### General Information

Personnel at Cummins Authorized Repair Locations can assist you with the correct operation and service of your engine. Cummins has a worldwide service network of more than 5,000 Distributors and Dealers who have been trained to provide sound advice, expert service, and complete parts support. Check the telephone directory yellow pages or refer to the directory in this section for the nearest Cummins Authorized Repair Location.

### Emergency and Technical Service

#### General Information

The Cummins Customer Assistance Center provides a 24-hour, toll free telephone number to aid in technical and emergency service when a Cummins Authorized Repair Location can **not** be reached or is unable to resolve an issue with a Cummins product.

If additional assistance is required, call Toll-Free:

1-800-DIESELS  
(1-800-343-7357)

- Includes all 50 states, Bermuda, Puerto Rico, Virgin Islands, and the Bahamas.
- Outside of North America contact your Regional Office. Telephone numbers and addresses are listed in the International Directory.



## Problem Solving

### General Information

Normally, any problem that arises with the sale, service, or repair of your engine can be handled by a Cummins Authorized Repair Location in your area. Refer to the telephone directory yellow pages for the one nearest you. If the problem has **not** been handled satisfactorily, follow the steps outlined below:

1. If the disagreement is with a Dealer, talk to the Cummins Distributor with whom he has his service agreement.
2. If the disagreement is with a Distributor, call the nearest Cummins Division or Regional Office; however, most problems are solved below the Division or Regional office level. Telephone numbers and addresses are listed in this section. Before calling, write down the following information:
  - a. Engine model and serial number
  - b. Type and make of equipment
  - c. Total kilometers [miles] or hours of operation
  - d. Warranty start date
  - e. Nature of problem
  - f. Summary of the current problem arranged in the order of occurrence
  - g. Name and location of the Cummins Distributor or Dealer
3. If a problem can **not** be resolved satisfactorily through your Cummins Authorized Repair Location or Division Office, write to:

Cummins Customer Assistance Center - 41403, Cummins Inc., Box 3005, Columbus, IN 47202-3005



## Division and Regional Offices

### Locations

**NOTE:** The following list contains offices in U.S., Canada, Australia, New Zealand, and Puerto Rico.

#### United States

##### Southern Division Office

Cummins Engine Company, Inc.  
425 Franklin Road S.W.  
Suite 500  
Marietta, GA 30067  
Telephone: (770) 423-1108  
FAX: (770) 499-8240

##### Cummins Latin America

3088 N. Commerce Parkway  
MPC #14, Building A  
Miramar, FL 33025  
Telephone: (305) 621-1300

**NOTE:** This office serves Puerto Rico  
and South America excluding Brazil.

##### Plains Regional Office

Cummins Engine Company, Inc.  
1901 Central Drive  
Suite 356  
Bedford, TX 76021  
Telephone: (817) 267-3172  
FAX: N/A

#### Canada

##### Canadian Division Office

Cummins Diesel of Canada, Ltd.  
5575 North Service Road  
Burlington, Ontario L7Z6M1  
Telephone: (905) 331-5944  
FAX: (905) 331-0276

##### Western Canada Regional Office

Cummins Diesel of Canada, Ltd.  
18452 - 96th Avenue  
Surrey, B.C. V3T 4W2  
Telephone: (604) 882-5727  
FAX: (604) 882-9110

##### Eastern Canada Regional Office

Cummins Diesel of Canada Ltd.  
7200 Trans Canada Hwy.  
Pt. Cuaire, Quebec H9R 1C0  
Telephone: (514) 695-2402  
FAX: (514) 695-8917

##### Central Canada Regional Office

Cummins Diesel of Canada Ltd.  
4887 - 35th Street SE  
Calgary, Alberta T2B 3C6  
FAX: (403) 569-9974

##### Australia Regional Office

##### Cummins Engine Company Pty. Ltd.

2 Caribbean Drive  
Scoresby, Victoria 3179  
Australia  
Telephone: (61-3) 9765-3222  
FAX: (61-3) 9763-0079

**NOTE:** This office also serves New  
Zealand.

##### Cummins Americas Regional Office

## Distributors and Branches

### United States

#### Alabama

##### Birmingham Distributor

Cummins Alabama, Inc.  
2200 Pinson Highway  
P.O. Box 1147  
Birmingham, AL 35201  
Telephone: (205) 841-0421  
FAX: (205) 849-5926

##### Mobile Branch

Cummins Alabama, Inc.  
1924 N. Beltline Hwy.  
Mobile, AL 36601-1598  
Telephone: (334) 456-2236  
FAX: (334) 452-6419

##### Mobile Onan/Marine Branch

Cummins Alabama, Inc.  
3422 Georgia Pacific Avenue  
Mobile, AL 36617  
Telephone: (334) 452-6426  
FAX: (334) 473-6657

##### Montgomery Branch

Cummins Alabama, Inc.  
2325 West Fairview Avenue  
Montgomery, AL 36108  
Telephone: (205) 263-2594  
FAX: (205) 263-2594

#### Alaska

##### Anchorage - (Branch of Seattle)

Cummins Northwest, Inc.  
2618 Commercial Drive  
Anchorage, AK 99501-3095  
Telephone: (907) 279-7594  
FAX: (907) 276-6340

#### Arizona

##### Phoenix Distributor and Branch

Cummins Southwest, Inc.  
2239 N. Black Canyon Hgwy  
Phoenix, AZ 85009  
Telephone: (602) 252-8021  
FAX: (602) 253-6725

##### Tucson Branch

Cummins Southwest, Inc.  
1912 West Prince Road  
Tucson, AZ 85705  
Telephone: (520) 887-7440  
FAX: (520) 887-4173

#### Arkansas

##### Little Rock - (Branch of Memphis)

Cummins Mid-South, Inc.  
6600 Interstate 30  
Little Rock, AR 72209  
Telephone:  
Sales: (501) 569-5600  
Service: (501) 569-5656  
Parts: (501) 569-5613  
FAX: (501) 565-2199

#### California

##### San Leandro Distributor

Cummins West, Inc.  
14775 Wicks Blvd.  
San Leandro, CA 94577-6779  
Telephone: (510) 351-6101  
FAX: (510) 352-3925

##### Arcata Branch

Cummins West, Inc.  
4801 West End Road  
Arcata, CA 95521  
Telephone: (707) 822-7392  
FAX: (707) 822-7585

##### Bakersfield Branch

Cummins West, Inc.  
4601 East Brundage Lane  
Bakersfield, CA 93307  
Telephone: (805) 325-9404  
FAX: (805) 861-8719

##### Fresno Branch

Cummins West, Inc.  
2740 Church Avenue  
Fresno, CA 93706  
Telephone: (209) 495-4745  
FAX: (209) 486-7402

##### Redding Branch

Cummins West, Inc.  
20247 Charlanne Drive  
Redding, CA 96001  
Telephone: (916) 222-4070  
FAX: (916) 224-4075

##### Stockton Branch

Cummins West, Inc.  
41 West Yokuts Avenue  
Suite 131  
Stockton, CA 95207  
Telephone: (209) 473-0386  
FAX: (209) 478-2454

##### West Sacramento Branch

Cummins West, Inc.  
2661 Evergreen Avenue  
West Sacramento, CA 95691  
Telephone: (916) 371-0630  
FAX: (916) 371-2849

##### Los Angeles Distributor

Cummins Cal Pacific Inc.  
1939 Deere Avenue (Irvine)  
Irvine, CA 92606  
Telephone: (949) 253-6000  
FAX: (949) 253-6080

##### Montebello Branch

Cummins Cal Pacific Inc.  
1105 South Greenwood Avenue  
Montebello, CA 90640  
Telephone: (323) 728-8111  
FAX: (323) 889-7422

#### Bloomington Branch

Cummins Cal Pacific Inc.  
3061 S. Riverside Avenue  
Bloomington, CA 92377  
Telephone: (909) 877-0433  
FAX: (909) 877-3787

#### San Diego Branch

Cummins Cal Pacific Inc.  
310 N. Johnson Avenue  
El Cajon, CA 92020  
Telephone: (619) 593-3093  
FAX: (619) 593-0600

#### Ventura Branch

Cummins Cal-Pacific Inc.  
3958 Transport St.  
Ventura, CA 93003  
Telephone: (805) 644-7281  
FAX: (805) 644-7284

#### Colorado

##### Denver Distributor

Cummins Rocky Mountain, Inc.  
5100 East 58th Avenue  
Commerce City, CO 80022  
Telephone: (303) 287-0201  
FAX: (303) 288-7080

##### Denver Onan/Industrial Branch

Cummins Rocky Mountain, Inc.  
5100 East 58th Ave.  
Commerce City, CO 80022  
Telephone: (303) 286-7697  
FAX: (303) 287-4837

##### Durango Branch

Cummins Rocky Mountain, Inc.  
13595 County Road 213  
Durango, CO 81301  
Telephone: (970) 259-7470  
FAX: (970) 259-7482

##### Grand Junction Branch

Cummins Rocky Mountain, Inc.  
2380 U.S. Highway 6 & 50  
P.O. Box 339  
Grand Junction, CO 81501  
Telephone: (303) 242-5776  
FAX: (303) 243-5495

#### Connecticut

##### Rocky Hill - (Branch of Bronx)

Cummins Metropower, Inc.  
914 Cromwell Ave.  
Rocky Hill, CT 06067  
Telephone: (860) 529-7474  
FAX: (860) 529-7524

## **Florida**

### **Tampa Distributor**

Cummins Southeastern Power, Inc.  
Corporate Office  
5421 N. 59th Street  
Tampa, FL 33610  
Telephone: (813) 621-7202  
FAX: (813) 621-8250

### **Ft. Myers Branch**

Cummins Southeastern Power, Inc.  
2671 Edison Avenue  
Ft. Myers, FL 33902  
Telephone: (941) 337-1211  
FAX: (941) 337-5374

### **Jacksonville Branch**

Cummins Southeastern Power, Inc.  
755 Pickettville Rd.  
Jacksonville, FL 32220  
Telephone: (904) 378-1902  
FAX: (904) 378-1904

### **Hialeah (Miami) Branch**

Cummins Southeastern Power, Inc.  
9900 N.W. 77th Avenue  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200  
FAX: (305) 557-2992

### **Ocala Branch**

Cummins Southeastern Power  
321 Southwest 52nd Ave.  
Ocala, FL 34474-1892  
Telephone: (352) 861-1122  
FAX: (352) 861-1130

### **Orlando Branch**

Cummins Southeastern Power, Inc.  
4020 North  
Orange Blossom Trail  
Orlando, FL 32810  
Telephone: (407) 298-2080  
FAX: (407) 290-8727

### **Tampa Branch**

Cummins Southeastern Power, Inc.  
5912 E. Hillsborough Avenue  
Tampa, FL 33610  
Telephone: (813) 626-1101  
FAX: (813) 628-4183

## **Georgia**

### **Atlanta Distributor**

Cummins South, Inc.  
5125 Georgia Highway 85  
College Park, GA 30349  
Telephone: (404) 763-0151  
FAX: (404) 766-2132

### **Albany Branch**

Cummins South, Inc.  
1915 W. Oakridge Drive  
Albany, GA 31707-4938  
Telephone: (912) 888-6210  
FAX: (912) 883-1670

## **Atlanta Branch**

Cummins South, Inc.  
100 University Avenue, S.W.  
Atlanta, GA 30315-2202  
Telephone: (404) 527-7800  
FAX: (404) 527-7832

## **Augusta Branch**

Cummins South, Inc.  
1255 New Savannah Road  
Augusta, GA 30901-3891  
Telephone: (706) 722-8825  
FAX: (706) 722-7553

## **Savannah Branch**

Cummins South, Inc.  
8 Interchange Court  
Savannah, GA 31401-1627  
Telephone: (912) 232-5565  
FAX: (912) 232-5145

## **Hawaii**

### **Kapolei Distributor**

Cummins Hawaii Diesel Power, Inc.  
91-230 Kalaeloa Blvd.  
Kapolei, HI 96707  
Telephone: (808) 682-8110  
FAX: (808) 682-8477

## **Idaho**

### **Boise - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
2851 Federal Way City  
Boise, ID 83705  
Telephone: (208) 336-5000  
FAX: (208) 338-5436

### **Pocatello - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
14299 Highway 30 West  
Pocatello, ID 83201  
Telephone: (208) 234-1661  
FAX: (208) 234-1662

## **Illinois**

### **Chicago Distributor**

Cummins Northern Illinois, Inc.  
7145 Santa Fe Drive  
Hodgkins, IL 60525  
Telephone: (708) 579-9222  
FAX: (708) 352-7547

### **Bloomington-Normal - (Branch of Indianapolis)**

Cummins Mid-States Power, Inc.  
(at U.S. 51 N and I-55)  
414 W. Northtown Road  
Bloomington-Normal, IL 61761  
Telephone: (309) 452-4454  
FAX: (309) 452-1642

### **Onan Branch**

Cummins/Onan Northern Illinois  
8745 W. 82nd Place  
Justin, IL 60458  
Telephone: (708) 563-7070  
FAX: (708) 563-7095

## **Harrisburg (Branch of St. Louis)**

Cummins Gateway, Inc.  
Highway 45 North  
Harrisburg, IL 62946  
Telephone: (618) 273-4138  
FAX: (618) 273-4531

## **Rock Island - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
7820 - 42nd Street West  
Rock Island, IL 61204  
Telephone: (309) 787-4300  
FAX: (309) 787-4397

## **Onan Branch**

Cummins Gateway, Inc.  
#1 Extra Mile Drive  
Collinsville, IL 62234  
Telephone: (618) 345-0123  
FAX: (314) 531-6604

## **Indiana**

### **Indianapolis Distributor**

Cummins Mid-States Power, Inc.  
P.O. Box 42917  
3762 West Morris Street  
Indianapolis, IN 46242-0917  
Telephone: (317) 243-7979  
FAX: (317) 240-1925

### **Evansville - (Branch of Louisville)**

Cummins Cumberland, Inc.  
7901 Highway 41 North  
Evansville, IN 47711  
Telephone: (812) 867-4400  
FAX: (812) 421-3282

### **Ft. Wayne Branch**

Cummins Mid-States Power, Inc.  
3415 Coliseum Blvd. West  
(At Jct. I-69 & 30/33)  
Ft. Wayne, IN 46808  
Telephone: (219) 482-3691  
FAX: (219) 484-8930

### **Gary - (Branch of Chicago)**

Cummins Northern Illinois, Inc.  
1440 Texas Street  
Gary, IN 46402  
Telephone: (219) 885-5591  
FAX: (219) 883-4817

### **Indianapolis Branch**

Cummins Mid-States Power, Inc.  
P. O. Box 42917  
3621 West Morris Street  
Indianapolis, IN 46242-0917  
Telephone: (317) 244-7251  
FAX: (317) 240-1215

### **Onan Branch**

Mid-States Power, Inc.  
4301 W. Morris Street  
P.O. Box 42917  
Indianapolis, IN 46240-0917  
Telephone: (317) 240-1967  
FAX: (317) 240-1975

**Iowa**

**Cedar Rapids - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
625 - 33rd Avenue SW  
Cedar Rapids, IA 52406  
Telephone: (319) 366-7537 (24 hours)  
FAX: (319) 366-7562

**Des Moines - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
1680 N.E. 51st Avenue  
P.O. Box B  
Des Moines, IA 50313  
Telephone: (515) 262-9591  
Parts: (515) 262-9744  
FAX: (515) 262-0626

**Des Moines - (Branch of Omaha)**

Midwestern Power Products  
Division of Cummins Great Plains Diesel, Inc.  
5194 N.E. 17th Street  
Des Moines, IA 50313  
Telephone: (515) 264-1650  
FAX: (515) 264-1651

**Kansas**

**Colby - (Branch of Kansas City, Missouri)**

Cummins Mid-America, LLC.  
1880 South Range  
Colby, KS 67701  
Telephone: (785) 462-3945  
FAX: (785) 462-3970

**Garden City - (Branch of Kansas City, Missouri)**

Cummins Mid-America, Inc.  
1285 Acraway  
Garden City, KS 67846  
Telephone: (316) 275-2277  
FAX: (316) 275-2533

**Wichita - (Branch of Kansas City, Missouri)**

Cummins Mid-America, Inc.  
5101 North Broadway  
Wichita, KS 67201  
Telephone: (316) 838-0875  
FAX: (316) 838-0704

**Kentucky**

**Louisville Distributor**

Cummins Cumberland, Inc.  
(Corporate Office)  
2301 Nelsonville Parkway  
Louisville, KY 40223  
Telephone: (502) 254-3363  
FAX: (502) 254-9272

**Hazard Branch**

Cummins Cumberland, Inc.  
Highway 15 South  
P.O. Box 510  
Hazard, KY 41701  
Telephone: (606) 436-5718  
FAX: (606) 436-5038

**Louisville Branch**

Cummins Cumberland, Inc.  
9820 Bluegrass Parkway  
Louisville, KY 40299  
Telephone: (502) 491-4263  
FAX: (502) 499-0896

**Louisiana**

**Morgan City - (Branch of Memphis)**

Cummins Mid-South, Inc.  
Hwy. 90 East  
P.O. Box 1229  
Amelia, LA 70340  
Telephone: (504) 631-0576  
FAX: (504) 631-0081

**New Orleans - (Branch of Memphis)**

Cummins Mid-South, Inc.  
110 E. Airline Highway  
Kenner, LA 70062  
Telephone: (504) 468-3535  
FAX: (504) 465-3408

**Maine**

**Bangor (Branch of Boston)**

Cummins Northeast, Inc.  
221 Hammond Street  
Bangor, ME 04401  
Telephone: (207) 941-1061  
FAX: (207) 945-3170

**Scarborough - (Branch of Boston)**

Cummins Northeast, Inc.  
10 Gibson Road  
Scarborough, ME 04074  
Telephone: (207) 883-8155  
FAX: (207) 883-5526

**Maryland**

**Baltimore Distributor**

Cummins Power Systems, Inc.  
1907 Parkwood Drive  
MD 21061  
Telephone: (410) 590-8700  
FAX: (410) 590-8723

**Massachusetts**

**Boston Distributor**

Cummins Northeast, Inc.  
100 Allied Drive  
Dedham, MA 02026  
Telephone: (781) 329-1750  
FAX: (781) 329-4428

**Springfield Branch**

Cummins Northeast, Inc.  
177 Rocus Street  
Springfield, MA 01104  
Telephone: (413) 737-2659  
FAX: (413) 731-1082

**Mexico**

**Tijuana - (Branch of Los Angeles)**

Distribuidora Cummins De Baja  
Blvd. 3ra. Oeste No. 17523  
Fracc. Industrial  
Garita de Otay C.P. 22400  
Tijuana, Baja California  
Mexico  
Telephone: 011-52-66-238433  
FAX: 011-52-66-238649

**Michigan**

**Detroit (Novi) Distributor**

Cummins Michigan, Inc.  
41216 Vincent Court  
Novi, MI 48375  
Telephone: (248) 478-9700  
FAX: (248) 478-1570

**Blissfield, Michigan**

Diesel Fuel Systems, Inc.  
Subsidiary of Cummins Michigan Inc.  
211 N. Jipson Street  
Blissfield, MI 49228  
Telephone: (517) 486-4324  
FAX: (517) 486-3614

**Dearborn Branch**

Cummins Michigan, Inc.  
3760 Wyoming Avenue  
Dearborn, MI 48120  
Telephone: (313) 843-6200  
FAX: (313) 843-6070

**Grand Rapids Branch**

Cummins Michigan, Inc.  
3715 Clay Avenue, S.W.  
Grand Rapids, MI 49508  
Telephone: (616) 538-2250  
FAX: (616) 538-3830

**Grand Rapids Branch**

Standby Power, Inc.  
7580 Expressway Drive S.W.  
Grand Rapids, MI 49548  
Telephone: (616) 281-2211  
FAX: (616) 281-3177

**Iron Mountain - (Branch of De Pere)**

Cummins Great Lakes, Inc.  
1901 Stevenson Avenue  
Iron Mountain, MI 49801  
Telephone: (906) 774-2424  
(800) 236-2424  
FAX: (906) 774-1190

**Novi Branch**

Cummins Michigan, Inc.  
25100 Novi Road  
Novi, MI 48375  
Telephone: (248) 380-4300  
FAX: (248) 380-0910

**Power Products (Branch of Detroit)**

Cummins Michigan, Inc.  
41326 Vincent Ct.  
Novi, MI 48375  
Telephone: (248) 426-9300  
FAX: (248) 473-8560

### **Saginaw Branch**

Cummins Michigan, Inc.  
722 N. Outer Drive  
Saginaw, MI 48605  
Telephone: (517) 752-5200  
FAX: (517) 752-4194

### **Standby Power - (Branch of Detroit)**

Cummins Michigan, Inc.  
12130 Dixie  
Redford, MI 48239  
Telephone: (313) 538-0200  
FAX: (313) 538-3966

### **Minnesota**

#### **St. Paul Distributor**

Cummins North Central, Inc.  
3030 Centre Pointe Drive  
Suite 500  
Roseville, MN 55113  
Telephone: (651) 636-1000  
FAX: (651) 638-2442

#### **Duluth Branch**

Cummins Diesel Sales, Inc.  
3115 Truck Center Drive  
Duluth, MN 55806-1786  
Telephone: (218) 628-3641  
FAX: (218) 628-0488

#### **St. Paul Branch**

Cummins North Central, Inc.  
2690 Cleveland Ave. North  
St. Paul, MN 55113  
Telephone: (651) 636-1000  
FAX: (651) 638-2497

### **Mississippi**

#### **Jackson - (Branch of Memphis)**

Cummins Mid-South, Inc.  
325 New Highway 49 South  
Jackson, MS 39288-4224  
Telephone:  
Admin.: (601) 932-7016  
Parts: (601) 932-2720  
Service: (601) 939-1800  
FAX: (601) 932-7399

### **Missouri**

#### **Kansas City Distributor and Branch**

Cummins Mid-America, Inc.  
8201 NE Parvin Road  
Kansas City, MO 64161  
Telephone: (816) 414-8200  
FAX: (816) 414-8299

#### **Joplin Branch**

Cummins Mid-America, Inc.  
3507 East 20th Street  
Joplin, MO 64801  
Telephone: (417) 623-1661  
FAX: (417) 623-1817

#### **Springfield Branch**

Cummins Mid-America, Inc.  
3637 East Kearney  
Springfield, MO 65803  
Telephone: (417) 862-0777  
FAX: (417) 862-4429

### **St. Louis Distributor**

Cummins Gateway, Inc.  
7210 Hall Street  
St. Louis, MO 63147  
Telephone: (314) 389-5400  
FAX: (314) 389-9671

### **Columbia Branch**

Cummins Gateway, Inc.  
5221 Highway 763 North  
Columbia, MO 65202  
Telephone: (314) 449-3711  
FAX: (314) 449-3712

### **Sikeston Branch**

Cummins Gateway, Inc.  
101 Keystone Drive  
Sikeston, MO 63801  
Telephone: (314) 472-0303  
FAX: (314) 472-0306

### **Industrial Power Branch**

Cummins Gateway, Inc.  
3256 E. Outer Road  
Scott City, MO 63788  
Telephone: (573) 335-9399  
FAX: (573) 335-7062

### **Montana**

#### **Billings - (Branch of Denver)**

Cummins Rocky Mountain, Inc.  
5151 Midland Road  
Billings, MT 59101  
Telephone: (406) 245-4194  
FAX: (406) 245-7923

#### **Great Falls - (Branch of Denver)**

Cummins Rocky Mountain, Inc.  
415 Vaughn Road  
Great Falls, MT 59404  
Telephone: (406) 452-8561  
FAX: (406) 452-9911

#### **Missoula - (Branch of Seattle)**

Cummins Northwest, Inc.  
4950 North Reserve Street  
Missoula, MT 59802-1498  
Telephone: (406) 728-1300  
FAX: (406) 728-8523

### **Nebraska**

#### **Omaha Distributor and Branch**

Cummins Great Plains Diesel, Inc.  
5515 Center Street  
P.O. Box 6068  
Omaha, NE 68106  
Telephone: (402) 551-7678 (24 Hours)  
FAX: (402) 551-1952

#### **Kearney Branch**

Cummins Great Plains Diesel, Inc.  
515 Central Avenue  
Kearney, NE 68847  
Telephone: (308) 234-1994  
FAX: (308) 234-5776

### **Nevada**

#### **Elko - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
5370 East Idaho Street  
Elko, NV 89801  
Telephone: (775) 738-6405  
FAX: (775) 738-1719

#### **Las Vegas - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
2750 Losee Road  
North Las Vegas, NV 89030  
Telephone: (702) 399-2339  
FAX: (702) 399-7457

#### **Sparks - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
150 Glendale Avenue  
Sparks, NV 89431  
Telephone: (775) 331-4983  
FAX: (775) 331-7429

### **New Jersey**

#### **Newark - (Branch of Bronx)**

Cummins Metropower, Inc.  
41-85 Doremus Ave.  
Newark, NJ 07105  
Telephone: (973) 491-0100  
FAX: (973) 578-8873

### **New Mexico**

#### **Albuquerque - (Branch of Phoenix)**

Cummins Southwest, Inc.  
1921 Broadway N.E.  
Albuquerque, NM 87102  
Telephone: (505) 247-2441  
FAX: (505) 842-0436

#### **Farmington - (Branch of Phoenix)**

Cummins Southwest, Inc.  
1101 North Troy King Road  
Farmington, NM 87401  
Telephone: (505) 327-7331  
FAX: (505) 326-2948

### **New York**

#### **Bronx Distributor**

Cummins Metropower, Inc.  
890 Zerega Avenue  
Bronx, NY 10473  
Telephone: (718) 892-2400  
FAX: (718) 892-0055

#### **Albany - (Branch of Boston)**

Cummins Northeast, Inc.  
101 Railroad Avenue  
Albany, NY 12205  
Telephone: (518) 459-1710  
FAX: (518) 459-7815

#### **Buffalo - (Branch of Boston)**

Cummins Northeast, Inc.  
480 Lawrence Bell Dr.  
Williamsville, NY 14221-7090  
Telephone: (716) 631-3211  
FAX: (716) 626-0799

**Syracuse - (Branch of Boston)**

Cummins Northeast, Inc.  
29 Eastern Avenue  
Syracuse, NY 13211  
Telephone: (315) 437-2751  
FAX: (315) 437-8141

**North Carolina**

**Charlotte Distributor**

Cummins Atlantic, Inc.  
11101 Nations Ford Road (28273)  
P.O. Box 240729  
Charlotte, NC 28224-0729  
Telephone: (704) 588-1240  
FAX: (704) 587-4870

**Charlotte Branch**

Cummins Atlantic, Inc.  
3700 North Interstate 85  
Charlotte, NC 28206  
Telephone: (704) 596-7690  
FAX: (704) 596-3038

**Greensboro Branch**

Cummins Atlantic, Inc.  
513 Freddy Boulevard (27406)  
P.O. Box 22066  
Greensboro, NC 27420-2066  
Telephone: (336) 275-4531  
FAX: (336) 275-8304

**Wilson Branch**

Cummins Atlantic, Inc.  
1514 Cargill Avenue (27893)  
P.O. Box 1177  
Wilson, NC 27894-1117  
Telephone: (252) 237-9111  
FAX: (252) 237-9132

**North Dakota**

**Fargo - (Branch of St. Paul)**

Cummins North Central, Inc.  
3801 - 34th Ave. SW  
Fargo, ND 58104  
Telephone: (701) 282-2466  
FAX: (701) 277-5399

**Grand Forks - (Branch of St. Paul)**

Cummins North Central, Inc.  
4728 Gateway Drive  
Grand Forks, ND 58201  
Telephone: (701) 775-8197  
FAX: (701) 775-4833

**Minot - (Branch of St. Paul)**

Cummins North Central, Inc.  
1501 - 20th Avenue, S.E.  
Minot, ND 58702  
Telephone: (701) 852-3585  
FAX: (701) 852-3588

**Ohio**

**Columbus Distributor and Branch**

Cummins Interstate Power, Inc.  
4000 Lyman Drive  
Hilliard (Columbus), OH 43026  
Telephone: (614) 771-1000  
FAX: (614) 771-0769

**Columbus Distributor**

Cummins Interstate Power, Inc.  
2297 Southwest Blvd., Suite K  
Grove City, OH 43123  
Telephone: (614) 771-1000  
FAX: (614) 527-2576

**Cincinnati Branch**

Cummins Interstate Power, Inc.  
10470 Evendale Drive  
Cincinnati, OH 45241  
Telephone: (513) 563-6670  
FAX: (513) 563-0594

**Cleveland Branch**

Cummins Interstate Power, Inc.  
7585 Northfield Road  
Cleveland, OH 44146  
Telephone: (440) 439-6800  
FAX: (440) 439-7390

**Strasburg Branch**

Cummins Interstate Power, Inc.  
777 South Wooster Avenue  
Strasburg, OH 44680  
Telephone: (216) 878-5511  
FAX: (216) 878-7666

**Toledo Branch**

Cummins Interstate Power, Inc.  
801 Illinois Avenue  
Maumee  
(Toledo), OH 43537  
Telephone: (419) 893-8711  
FAX: (419) 893-5362

**Youngstown Branch**

Cummins Interstate Power, Inc.  
7145 Masury Road  
Hubbard  
(Youngstown), OH 44425  
Telephone: (216) 534-1935  
FAX: (216) 534-5606

**Oklahoma**

**Oklahoma City - (Branch of Arlington)**

Cummins Southern Plains, Inc.  
5800 West Reno  
Oklahoma City, OK 73127  
Telephone: (405) 946-4481 (24 hours)  
FAX: (405) 946-3336

**Tulsa - (Branch of Arlington)**

Cummins Southern Plains, Inc.  
16525 East Skelly Drive  
Tulsa, OK 74116  
Telephone: (918) 234-3240  
FAX: (918) 234-2342

**Oregon**

**Bend - (Branch of Seattle)**

Cummins Northwest, Inc.  
3500 N. Highway 97 (97701-5729)  
P.O. Box 309  
Bend, OR 97709-0309  
Telephone: (541) 389-1900  
FAX: (541) 389-1909

**Coburg/Eugene - (Branch of Seattle)**

Cummins Northwest, Inc.  
91201 Industrial Parkway  
Coburg, OR 97401  
(Mailing Address)  
P.O. Box 10877  
Eugene, OR 97440-2887  
Telephone: (541) 687-0000  
FAX: (541) 687-1977

**Medford - (Branch of Seattle)**

Cummins Northwest, Inc.  
4045 Crater Lake Highway  
Medford, OR 97504-9796  
Telephone: (541) 779-0151  
FAX: (541) 772-2395

**Pendleton - (Branch of Seattle)**

Cummins Northwest, Inc.  
223 S.W. 23rd Street  
Pendleton, OR 97801-1810  
Telephone: (541) 276-2561  
FAX: (541) 276-2564

**Portland - (Branch of Seattle)**

Cummins Northwest, Inc.  
4711 N. Basin Avenue  
P. O. Box 2710 (97208-2710)  
Portland, OR 97217-3557  
Telephone: (503) 289-0900  
FAX: (503) 286-5938

**Pennsylvania**

**Philadelphia Distributor**

Cummins Power Systems, Inc.  
2727 Ford Road  
Bristol, PA 19007  
Telephone: (215) 785-6005 and  
(609) 563-0005  
FAX: (215) 785-4085

**Bristol Branch**

Cummins Power Systems, Inc.  
2727 Ford Road  
Bristol, PA 19007  
Telephone: (215) 785-6005 and  
(609) 563-0005  
FAX: (215) 785-4728

**Pittsburgh Branch**

Cummins Power Systems, Inc.  
3 Alpha Drive  
Pittsburgh, PA 15238-2901  
Telephone: (412) 820-8300  
FAX: (412) 820-8308

**Harrisburg Branch**

Cummins Power Systems, Inc.  
4499 Lewis Road  
Harrisburg, PA 17111-2541  
Telephone: (717) 564-1344  
FAX: (717) 558-8217

**Puerto Rico**

**Puerto Nuevo - (Branch of Tampa)**

Cummins Diesel Power, Inc.  
#31 Calle "C"  
El Matadero  
Puerto Nuevo, Puerto Rico 00920  
Telephone: (787) 793-0300  
FAX: (787) 793-1072

**South Carolina**

**Charleston - (Branch of Charlotte)**

Cummins Atlantic, Inc.  
3028 West Montague Avenue  
Charleston, SC 29418-5593  
Telephone: (843) 554-5112  
FAX: (843) 745-0745

**Charleston - (Branch of Charlotte)**

Cummins Atlantic Inc.  
231 Farmington Road  
Charleston, SC 29483  
Telephone: (843) 851-9819  
FAX: (843) 875-4338

**Columbia - (Branch of Charlotte)**

Cummins Atlantic, Inc.  
1233 Bluff Road (29201)  
P.O. Box 13543  
Columbia, SC 29201-3543  
Telephone: (803) 799-2410  
FAX: (803) 779-3427

**South Dakota**

**Sioux Falls - (Branch of Omaha)**

Cummins Great Plains Diesel, Inc.  
701 East 54th Street North  
Sioux Falls, SD 57104  
Telephone: (605) 336-1715  
FAX: (605) 336-1748

**Tennessee**

**Memphis Distributor & Distribution Center**

Cummins Mid-South, Inc.  
666 Riverside Drive  
Memphis, TN 38703  
Telephone: (901) 577-0666  
FAX: (901) 522-8758

**Chattanooga - (Branch of Atlanta)**

Cummins South, Inc.  
1509 East 26th Street  
Chattanooga, TN 37407-1095  
Telephone: (615) 629-1447  
FAX: (615) 629-1494

**Knoxville - (Branch of Louisville)**

Cummins Cumberland, Inc.  
1211 Ault Road  
Knoxville, TN 37914  
Telephone: (423) 523-0446  
FAX: (423) 523-0343

**Memphis Branch**

Cummins Mid-South, Inc.  
1784 E. Brooks Road  
Memphis, TN 38116  
Telephone:  
Sales/Admin.: (901) 345-7424  
Parts: (901) 345-1784  
Service: (901) 345-6185  
FAX: (901) 346-4735

**Nashville - (Branch of Louisville)**

Cummins Cumberland, Inc.  
706 Spence Lane  
Nashville, TN 37217  
Telephone: (615) 366-4341  
FAX: (615) 366-5693

**Texas**

**Arlington Distributor**

Cummins Southern Plains, Inc.  
600 N Watson Road  
Arlington, TX 76004-3027  
Telephone: (817) 640-6801  
FAX: (817) 640-6852

**Amarillo Branch**

Cummins Southern Plains, Inc.  
5224 Interstate 40 -  
Expressway East  
P.O. Box 31570  
Amarillo, TX 79120-1570  
Telephone: (806) 373-3793 (24 hours)  
FAX: (806) 372-8547

**Dallas Branch**

Cummins Southern Plains, Inc.  
3707 Irving Boulevard  
Dallas, TX 75247  
Telephone: (214) 631-6400 (24 hours)  
FAX: (214) 631-2322

**El Paso - (Branch of Phoenix)**

Cummins Southwest, Inc.  
14333 Gateway West  
El Paso, TX 79927  
Telephone: (915) 852-4200  
FAX: (915) 852-3295

**Fort Worth Branch**

Cummins Southern Plains, Inc.  
3250 North Freeway  
Fort Worth, TX 76111  
Telephone: (817) 624-2107 (24 hours)  
FAX: (817) 624-3296

**Houston Branch**

Cummins Southern Plains, Inc.  
4750 Homestead Road  
P.O. Box 1367  
Houston, TX 77251-1367  
Telephone: (713) 675-7421 (24 hours)  
FAX: (713) 675-1515

**Mesquite Branch**

Cummins Southern Plains, Inc.  
2615 Big Town Blvd.  
Mesquite, TX 75150  
Telephone: (214) 321-5555 (24 hours)  
FAX: (214) 328-2732

**Odessa Branch**

Cummins Southern Plains, Inc.  
1210 South Grandview  
P.O. Box 633  
Odessa, TX 79760-0633  
Telephone: (915) 332-9121 (24 hours)  
FAX: (915) 333-4655

**San Antonio Branch**

Cummins Southern Plains, Inc.  
6226 Pan Am Expressway North  
P.O. Box 18385  
San Antonio, TX 78218-0385  
Telephone: (512) 655-5420 (24 hours)  
FAX: (512) 655-3865

**Houston Onan Branch**

Southern Plains Power  
A Division of Cummins Southern Plains  
1155 West Loop North  
Houston, TX 77055  
Telephone: (713) 956-0020  
FAX: (713) 956-0266

**Utah**

**Salt Lake City Distributor**

Cummins Intermountain, Inc.  
1030 South 300 West  
Salt Lake City, UT 84101  
Telephone: (801) 355-6500  
FAX: (801) 524-1351

**Vernal Branch**

Cummins Intermountain, Inc.  
1435 East 335 South  
Vernal, UT 84078  
Telephone: (435) 789-5732  
FAX: (435) 789-2853

**Virginia**

**Cloverdale - (Branch of Charlotte)**

Cummins Atlantic, Inc.  
263 Simmons Drive  
Cloverdale, VA 24077  
Telephone: (540) 966-3169  
FAX: (540) 966-3749

**Richmond - (Branch of Charlotte)**

Cummins Atlantic, Inc.  
3900 Deepwater Terminal Road  
Richmond, VA 23234  
Telephone: (804) 232-7891  
FAX: (804) 232-7428

**Tidewater - (Branch of Charlotte)**

Cummins Atlantic, Inc.  
Atlantic Power Generation  
3729 Holland Blvd.  
Chesapeake, VA 23323  
Telephone: (757) 485-4848  
FAX: (757) 485-5085

## **Washington**

### **Seattle Distributor**

Cummins Northwest, Inc.  
811 S.W. Grady Way (98055-2944)  
P.O. Box 9811  
Renton, WA 98057-9811  
Telephone: (425) 235-3400  
FAX: (425) 235-8202

### **Chehalis Branch**

Cummins Northwest, Inc.  
926 N.W. Maryland  
Chehalis, WA 98532-0339  
Telephone: (360) 748-8841  
FAX: (360) 748-8843

### **Spokane Branch**

Cummins Northwest, Inc.  
11134 W. Westbow Blvd.  
Spokane, WA 99204  
Telephone: (509) 455-4411  
FAX: (509) 624-4681

### **Tacoma Branch**

Cummins Northwest, Inc.  
3701 Pacific Highway East  
Tacoma, WA 98424-1135  
Telephone: (253) 922-2191  
FAX: (253) 922-2379

### **Yakima Branch**

Cummins Northwest, Inc.  
1905 East Central Avenue (98901-3609)  
P.O. Box 9129  
Yakima, WA 98909-0129  
Telephone: (509) 248-9033  
FAX: (509) 248-9035

## **West Virginia**

### **Charleston - (Branch of Louisville)**

Cummins Cumberland, Inc.  
3100 MacCorkle Ave. SW  
P.O. Box 8456  
South Charleston, WV 25303  
Telephone: (304) 744-6373  
FAX: (304) 744-8605

### **Fairmont - (Branch of Louisville)**

Cummins Cumberland, Inc.  
South Fairmount Exit, I-79  
145 Middletown Road  
Fairmont, WV 26554  
Telephone: (304) 367-0196  
FAX: (304) 367-1077

## **Wisconsin**

### **DePere Distributor**

Cummins Great Lakes, Inc.  
Corporate Office  
875 Lawrence Drive  
P.O. Box 5070  
DePere, WI 54115-5070  
Telephone: (920) 337-1991  
FAX: (920) 337-9746

### **Chippewa Falls Branch**

Cummins Great Lakes, Inc.  
2030 St. Highway 53  
Chippewa Falls, WI 54729  
Telephone: (715) 720-0680  
FAX: (715) 720-0685

### **DePere Branch**

Cummins Great Lakes, Inc.  
939 Lawrence Drive  
P. O. Box 5070  
DePere, WI 54115-5070  
Telephone: (920) 336-9631  
(800) 236-1191  
FAX: (920) 336-8984

### **Milwaukee Branch**

Cummins Great Lakes, Inc.  
9401 South 13th Street  
P.O. Box D  
Oak Creek, WI 53154  
Telephone: (414) 768-7400  
(800) 472-8283  
FAX: (414) 768-9441

### **Wausau Branch**

Cummins Great Lakes, Inc.  
4703 Rib Mountain Drive  
Wausau, WI 54401  
Telephone: (715) 359-6888  
(800) 236-3744  
FAX: (715) 359-3744

## **Wyoming**

### **Gillette - (Branch of Denver)**

Cummins Rocky Mountain, Inc.  
2700 Hwy. 14 & 16 North  
P.O. Box 1207 (82717)  
Gillette, WY 82716  
Telephone: (307) 682-9611  
FAX: (307) 682-8242

### **Rock Springs - (Branch of Salt Lake City)**

Cummins Intermountain, Inc.  
2000 Foothill Blvd.  
P.O. Box 1634  
Rock Springs, WY 82901  
Telephone: (307) 362-5168  
FAX: (307) 362-5171



## Canada

### Alberta

#### Edmonton Distributor and Branch

Cummins Alberta  
11751 - 181 Street  
Edmonton, AB T5S 2K5  
Telephone: (780) 455-2151  
FAX: (780) 454-9512

#### Calgary Branch

Cummins Alberta  
4887 - 35th Street S.E.  
Calgary, Alberta T2B 3H6, Canada  
Telephone: (403) 569-1122  
FAX: (403) 569-0027

#### Grande Prairie

Cummins Alberta - Grande Prairie  
RR2, Site 9, Box 22  
Sexsmith, AB CN T0H 3C0  
Telephone: (780) 568-3359  
FAX: (780) 568-2263

#### Hinton Branch

Cummins Alberta  
135 Veats Avenue  
Hinton, Alberta T7V 1S8, Canada  
Telephone: (780) 865-5111  
FAX: (780) 865-5714

#### Lethbridge Branch

Cummins Alberta  
240 - 24th Street North  
Lethbridge, Alberta T1H 3T8, Canada  
Telephone: (403) 329-6144  
FAX: (403) 320-5383

### British Columbia

#### Vancouver Distributor

Cummins British Columbia  
18452 - 96th Avenue  
Surrey, B.C., Canada  
V4N 3P8  
Telephone: (604) 882-5000  
FAX: (604) 882-5080

#### Kamloops Branch

Cummins British Columbia  
976 Laval Crescent  
Kamloops, B.C. Canada V2C 5P5  
Telephone: (250) 828-2388  
FAX: (250) 828-6713

#### Prince George Branch

Cummins British Columbia  
102- 3851- 18th Avenue  
Prince George, B.C. V2N 1B1  
Telephone: (250) 564-9111  
FAX: (250) 564-5853

#### Sparwood Branch

Cummins British Columbia  
731 Douglas Fir Road  
Sparwood, B.C. VOB 2G0, Canada  
Telephone: (250) 425-0522  
FAX: (250) 425-0323

### Tumbler Ridge Branch

Cummins British Columbia  
Industrial Site, Box 226  
Tumbler Ridge, B.C.  
Canada VOC 2W0  
Telephone: (250) 242-4217  
FAX: (250) 242-4906

### Manitoba

#### Winnipeg Distributor

Cummins Mid-Canada Ltd.  
489 Oak Point Road  
P.O. Box 1860  
Winnipeg, MB R3C 3R1, Canada  
Telephone: (204) 632-5470  
FAX: (204) 697-0267

### New Brunswick

#### Fredericton - (Branch of Montreal)

Cummins Eastern Canada, Inc.  
R.R.#1 Doak Road  
P.O. Box 1178, Station 'A'  
Fredericton,  
New Brunswick E3B 4X2, Canada  
Telephone: (506) 451-1929  
FAX: (506) 451-1921

### Newfoundland

#### St. John's - (Branch of Montreal)

Cummins Eastern Canada, Inc.  
122 Clyde Avenue  
Donovans Industrial Park  
Mount Pearl, Newfoundland A1N 2C2  
Canada  
Telephone: (709) 747-0176  
FAX: (709) 747-2283

#### Wabush - (Branch of Montreal)

Cummins Eastern Canada, Inc.  
Wabush Industrial Park  
Wabush, Newfoundland A0R 1B0  
Telephone: (709) 282-3626  
FAX: (709) 282-3108

### Nova Scotia

#### Halifax - (Branch of Montreal)

Cummins Eastern Canada, Inc.  
50 Simmonds Drive  
Dartmouth, Nova Scotia B3B 1R3  
Telephone: (902) 468-7938  
FAX: (902) 468-5177  
Parts: (902) 468-6560

### Ontario

#### Toronto Distributor

Cummins Ontario, Inc.  
7175 Pacific Circle  
Mississauga, ON L5T 2A5  
Telephone: (905) 795-0050  
FAX: (905) 795-0021

### Kenora - (Branch of Winnipeg)

Cummins Mid-Canada Ltd.  
Highway 17 East  
P.O. Box 8  
Kenora, Ontario P9N 3X1  
Telephone: (807) 548-1941  
FAX: (807) 548-8302

### Ottawa Branch

Cummins Ontario Inc.  
3189 Swansea Crescent  
Ottawa, Ontario K1G 3W5,  
Telephone: (613) 736-1146  
FAX: (613) 736-1202

### Thunder Bay Branch

Cummins Ontario Inc.  
1400 W. Walsh Street  
Thunder Bay  
Ontario P7E 4X4  
Telephone: (807) 577-7561  
FAX: (807) 577-1727

### Whitby Branch

Cummins Ontario Inc.  
1311 Hopkins Street  
Whitby, Ontario L1N 2C2, Canada  
Telephone: (905) 668-6886  
FAX: (905) 668-1375

### Quebec

#### Montreal Distributor

Cummins Eastern Canada, Inc.  
7200 Trans Canada Highway  
Pointe Claire, Quebec H9R 1C2,  
Telephone: (514) 695-8410  
FAX: (514) 695-8917

#### Montreal Branch

Cummins Eastern Canada, Inc.  
7200 Trans Canada Highway  
Pointe Claire, Quebec H9R 1C2,  
Canada  
Telephone: (514) 695-8410  
Sales: (514) 695-4555  
Parts: (514) 694-5880  
FAX: (514) 695-8917

#### Dorval Onan Branch

Cummins, Eastern Canada, Inc.  
580 Lepihe  
Dorval, Quebec H9H 1G2  
Telephone: (514) 631-5000  
FAX: (514) 631-0104

### Quebec City Branch

Cummins Diesel  
Branch of Cummins Americas, Inc.  
2575 Dalton Street  
Ste. Foy, Quebec G1P 3S7  
Telephone: (418) 653-6411  
FAX: (418) 653-5844

**Val D'Or Branch**

Cummins, Eastern Canada, Inc.  
1025 Rue Del  
Val D'Or, Quebec 59P 4P6  
Telephone: (819) 825-0993  
FAX: (819) 825-8488

**Saskatchewan**

**Lloydminster - (Branch of Winnipeg)**

Cummins Mid-Canada Ltd.  
4005 52nd  
Lloydminster, SK S9V 0Y9  
Telephone: (305) 825-2062  
FAX: (305) 825-6702

**Regina - (Branch of Winnipeg)**

Cummins Mid-Canada Ltd.  
110 Kress Street  
P.O. Box 98  
Regina, SK S4P 2Z5  
Telephone: (306) 721-9710  
FAX: (306) 721-2962

**Saskatoon - (Branch of Winnipeg)**

Cummins Mid-Canada, Ltd.  
3001 Faithful Avenue  
P.O. Box 7679  
Saskatoon, SK S7K 4R4, Canada  
Telephone: (306) 933-4022  
FAX: (306) 242-1722

## Australia

### Branches:

#### Gepps Cross

Cummins Engine Company, Pty. Ltd.  
P.O. Box 108  
Blair Athol, 5084  
South Australia, Australia  
Location:  
45-49 Cavan Road  
Gepps Cross, 5094  
Telephone: (61-8) 8262-5211

#### Dosra

Cummins Engine Company, Pty. Ltd.  
P.O. Box 124  
Darra, 4076  
Queensland, Australia  
Location:  
33 Kimberley Street  
Darra, 4076, Australia  
Telephone: (61-7) 3375-3277

#### Bunbury

Cummins Engine Company, Pty. Ltd.  
P.O. Box 1751  
Bunbury, WA 6230  
Australia  
Location:  
11 Dryanda Court  
Picton, WA 6230  
Telephone: (61-8) 9725-6777  
FAX: (61-8) 9725-6444

#### Cairns

Cummins Engine Company, Pty. Ltd.  
P.O. Box 7189  
Cairns Mail Centre, 4870  
Queensland, Australia  
Location:  
Liberty Street  
Cairns, 4870  
Telephone: (61-7) 935-2999

#### Campbellfield

Cummins Engine Company, Pty. Ltd.  
Private Bag 9  
Campbellfield, 3061  
Victoria, Australia  
Location:  
1788-1800 Hume Highway  
Campbellfield, 3061  
Telephone: (613) 9357-9200

#### Dandenong

Cummins Engine Company, Pty. Ltd.  
Lot 7 Greens Road  
Dandenong, 3175  
Victoria, Australia  
Telephone: (613) 9706-8088

#### Darwin

Cummins Engine Company, Pty. Ltd.  
P.O. Box 37587  
Winnellie, 0821  
Northern Territory, Australia  
Location:  
Lot 1758 Graffin Crescent  
Winnellie, 0821  
Telephone: (61-8) 8947-0766

#### Devonport

Cummins Engine Company, Pty. Ltd.  
P.O. Box 72E  
Tasmania, Australia  
Location:  
2 Matthews Way  
Devonport, 7310  
Telephone: (61-3) 6424-8800

#### Emerald

Cummins Engine Company, Pty. Ltd.  
P.O. Box 668  
Emerald, 4720  
Queensland, Australia  
Location:  
Capricorn Highway  
Emerald, 4720  
Telephone: (61-7) 4982-4022

#### Grafton

Cummins Engine Company, Pty. Ltd.  
P.O. Box 18  
South Grafton, 2461  
New South Wales, Australia  
Location:  
18-20 Induna Street  
South Grafton, 2461  
Telephone: (61-2) 6642-3655

#### Hexham

Cummins Engine Company, Pty. Ltd.  
21 Gallegan Street  
Hexham  
New South Wales, Australia  
Telephone: (61-2) 4964-8466  
FAX: (61-2) 4964-8616

#### Kalgoorlie

Cummins Engine Company, Pty. Ltd.  
P.O. Box 706  
Kalgoorlie, 6430  
Western Australia, Australia  
Location:  
16 Atbara Street  
Kalgoorlie, 6430  
Telephone: (61-8) 9021-2588

#### Karratha

Cummins Engine Company, Pty. Ltd.  
P.O. Box 377  
Karratha, WA 6714  
Australia  
Location:  
1490 Lambert Road  
Karratha, WA 6714  
Australia  
Telephone: (61-8) 9144-4646  
FAX: (61-8) 9143-1507

#### Laverton

Cummins Engine Company, Pty. Ltd.  
Locked Bag 1  
Laverton, Victoria 3028  
Australia  
Location:  
195 Boundary Road  
Laverton North, Victoria 3028  
Australia  
Telephone: (61-3) 9360-0800  
FAX: (61-3) 9360-0438

#### Leeton

Cummins Engine Company, Pty. Ltd.  
P.O. Box 775  
Leeton, NSW 2705  
Australia  
Location:  
29 Brady Way  
Leeton, NSW 2705  
Australia  
Telephone: (61-2) 6953-3077  
FAX: (61-2) 6953-3109

#### Mackay

Cummins Engine Company, Pty. Ltd.  
P.O. Box 842  
Mackay, 4740  
Queensland, Australia  
Location:  
4 Presto Avenue  
Mackay, 4746  
Telephone: (61-7) 4955-1222

#### Mount Gambier

Cummins Engine Company, Pty. Ltd.  
P.O. Box 2219  
Mount Gambier, 5290  
South Australia, Australia  
Location:  
2 Avey Road  
Mount Gambier, 5290  
Telephone: (61-87) 25-6422

#### Penrith

Cummins Engine Company, Pty. Ltd.  
P.O. Box 132  
Cambridge Park, 2747  
New South Wales, Australia  
Location:  
7 Andrews Road  
Penrith, 2750  
Telephone: (61-2) 4729-1313

#### Queanbeyan

Cummins Engine Company, Pty. Ltd.  
P.O. Box 527  
Queanbeyan, 2620  
New South Wales, Australia  
Location:  
15-27 Bayldon Road  
Queanbeyan, 2620  
Telephone: (61-2) 6297-3433  
FAX: (61-2) 6297-6709

**Regency Park**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 2147  
Regency Park, SA 5942  
Australia  
Location:  
11 Manton Street  
Hindmarsh, SA 5942  
Australia  
Telephone: (61-8) 8346-3832  
FAX: (61-8) 8340-2045

**Swan Hill**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 1264  
Swan Hill, 3585  
Victoria, Australia  
Location:  
5 McAllister Road  
Swan Hill, 3585  
Telephone: (61-3) 5032-1511

**Tamworth**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 677  
Tamworth, 2320  
New South Wales, Australia  
Location:  
Lot 65 Gunnedah Road  
Tamworth, 2340  
Telephone: (61-2) 6765-5455

**Townsville**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 7339  
Garbutt Business Centre, QLD4814  
Australia  
Location:  
704-710 Ingham Road  
Townsville, QLD 4814  
Telephone: (61-7) 4774-7733  
FAX: (61-7) 4774-7640

**Welshpool**

Cummins Engine Company, Pty. Ltd.  
P. O. Box 52  
Welshpool, 6986  
Western Australia, Australia  
Location:  
50 Kewdale Road  
Welshpool, 6106  
Telephone: (61-8) 9458-5911

**Wetherill Park**

Cummins Engine Company, Pty. Ltd.  
Private Bag 150  
Wetherill Park, NSW 2164  
Australia  
Location:  
492-494 Victoria Street  
Wetherill Park, NSW 2164  
Australia  
Telephone: (61-2) 9616-5300  
FAX: (61-2) 9616-5399

**Wodonga**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 174  
Wodonga, 3690  
Victoria, Australia  
Location:  
9-11 McKoy Street  
Wodonga, 3690  
Telephone: (61-2) 6024-3655

## **New Zealand**

### **Auckland**

Cummins Engine Company, Pty. Ltd.  
Private Bag 92804  
Penrose, Auckland, New Zealand  
Location:  
440 Church Street  
Penrose  
Telephone: (64-9) 579-0085

#### **- Branches:**

### **Auckland**

Cummins Engine Company, Pty. Ltd.  
Private Bag 92804  
Penrose, Auckland, New Zealand  
Location:  
440 Church Street  
Penrose  
Telephone: (64-9) 579-0085

### **Christchurch**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 16-149  
Hornby, Christchurch, New Zealand  
Location:  
35 Parkhouse Road  
Sockburn, Christchurch  
Telephone: (64-3) 348-8170

### **Dunedin**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 2333  
South Dunedin, New Zealand  
Location:  
8 Devon Street  
Dunedin  
Telephone: (643) 477-8818

### **Palmerston North**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 9024  
Palmerston North, New Zealand  
Location:  
852-860 Tremaine Avenue  
Telephone: (64-6) 356-2209

### **Rotorua**

Cummins Engine Company, Pty. Ltd.  
P.O. Box 934  
Rotorua, New Zealand  
Location:  
328 Te Ngae Road  
Rotorua  
Telephone: (647) 345-6699

## Regional Offices - International

### Locations

#### European Regional Office - Mechelen

Cummins Diesel N.V.  
Blarenberglaan 4  
Industriepark Noord 2  
2800 Mechelen  
Brussels  
Telephone: (32-15) 89000

Countries

Covered:	Austria	Luxembourg
	Belgium	Netherlands
	Czech Republic	Norway
	Denmark	Portugal
	Finland	Slovakia
	Greece	Spain
	Hungary	Sweden
	Iceland	Switzerland
	Israel	

#### Cumbrasa Regional Office - Brazil

Cummins Brasil S.A.  
Rua Jati, 266  
07180-900 Guarulhos  
Sao Paulo, Brazil  
Mailing Address:  
P.O. Box 13  
07180-900 Guarulhos  
Sao Paulo, Brazil  
Telephone: (55-11) 945-9811

Country

Covered: Brazil

#### Beijing Regional Office - China

Cummins Corporation  
China World Tower, Suite 917  
China World Trade Center  
No. 1 Jian Guo Men Wai  
Beijing 100004  
People's Republic of China  
Telephone: (86-1) 6505-1658  
Fax: (88-10) 6505-4211

Countries

Covered: China  
Mongolia

#### Bogota Regional Office - Columbia

Cummins Engine Co. de Colombia S.A.  
Carrera 11A No. 90-15 Of. 601/602  
Bogota, D.E., Colombia  
Telephone: (57-1) 610-4849

Mailing Address:  
Apartado Aereo 90988  
Bogota D.E., Colombia

Countries

Covered:	Argentina	Ecuador
	Bolivia	Paraguay
	Chile	Peru
	Colombia	Uruguay

#### Gross-Gerau Regional Office - Germany

Cummins Diesel Deutschland GmbH  
Odenwaldstr. 23  
D-4521 Gross-Gerau  
Germany  
Telephone: (49-6152) 174-0

Countries

Covered:	Albania	Poland
	Bulgaria	Romania
	Latvia	Lithuania
	Germany	Estonia
	Luxembourg	Croatia
	Slovenia	Bosnia
	Macedonia	

#### Hong Kong Regional Office - Hong Kong

Cummins Engine H.K. Ltd.  
Unison Industrial Centre  
15th Floor, Units C & D  
27-31 Au Pui Wan Street  
P. O. Box 840 Shatin  
Fo Tan, Shatin, N.T.  
Hong Kong  
Telephone: (852) 2606-5678  
Fax: (852) 2691-1641, 2687-3552

Country

Covered: Hong Kong, Macau

#### Pune Kirloskar Regional Office - India

Kirloskar Cummins Limited  
Kothrud  
Pune - 411 029, India  
Telephone: (91-212) 33-0240, 33-5435, 33-1105

Countries

Covered: Bhutan  
India  
Nepal

#### Milan Regional Office - Italy

Cummins Diesel Italia S.P.A.  
Piazza Locatelli 8  
Zona Industriale  
20098 San Giuliano Milanese  
Milan, Italy  
Telephone: (+ 39-02) 98-83-111

Country

Covered: Italy

#### North Asia Regional Office - Japan

Cummins Diesel Sales Corporation  
1-12-10 Shintomi  
Chuo-ku, Tokyo 104  
Japan  
Telephone: (81-3) 3555-3131/2/3/4/5

Country

Covered: Japan

**Seoul Regional Office - Korea**

Cummins Korea Ltd.  
 5th Floor, Hye Sung Building  
 35-26 Sam Sung Dong, Kang Nam Ku  
 Seoul, South Korea  
 Telephone: (82-2) 516-0431/2/3, 517-3370/1

Country  
 Covered: South Korea

**Cummsa Regional Office - Mexico**

Cummins, S.A. de C.V.  
 Arquimedes No. 209  
 Col. Polanco  
 11560 Mexico, D.F.  
 Mexico  
 Telephone: (52-5) 254-3822/3783/3622  
 Mailing/Shipping Address:  
 Gonzalez de Castilla Inc.  
 P.O. Box 1391  
 4605 Modern Lane  
 Modern Industrial Park  
 Laredo, TX 78040  
 Telephone: (512) 722-5207

Country  
 Covered: Mexico

**Moscow Regional Office - Russia**

Cummins Engine Co., Inc.  
 Park Place  
 Office E708  
 Leninsky Prospect 113  
 Russia 117198  
 Telephone: (7-502) 256-5122 or 256-5123

Countries  
 Covered: Armenia  
 Azerbaijan  
 Belarus  
 Tajikistan  
 Georgia  
 Kyrgyzstan  
 Kazakhstan  
 Moldova  
 Russia  
 Turkmenistan  
 Ukraine  
 Uzbekistan

**South And East Asia Area Office - Singapore**

Cummins Diesel Sales Corporation  
 8 Tanjong Penjuru  
 Jurong Industrial Estate  
 Singapore 2260  
 Telephone: (65) 265-0155

Countries  
 Covered: Bangladesh  
 Brunei  
 Burma/Mynamar  
 Cambodia  
 Indonesia  
 Laos  
 Malaysia  
 Mongolia  
 Philippines  
 Singapore  
 Sri Lanka  
 Thailand  
 Vietnam

**Taipei Regional Office - Taiwan**

Cummins Corporation - Taiwan  
 12th Floor, No. 149  
 Min-Sheng E. Road  
 Section 2  
 Taipei, Taiwan  
 R.O.C. 104  
 Telephone: (886-2) 2503-8441

Country  
 Covered: Taiwan

**Middle East Regional Office**

Cummins Diesel FZE  
 Units ZF 5 & 6, Jebel Ali Free Zone  
 Dubai  
 United Arab Emirates  
 Telephone: (971) 4 883-8998  
 Fax: (971) 4 883-8997  
 E-mail: cdfze@emirates.net.ae)

Countries Covered:

MIDEAST		
Afghanistan	Jordan	Saudi Arabia
Bahrain	Kuwait	Sudan
Cyprus	Lebanon	Syria
Djibouti	Oman	U.A.E.
Egypt	Pakistan	United Kingdom
Iraq	Qatar	Yemen
Iran	Turkey	

**North/West/East and Central Africa Regional Office - Daventry (U.K.)**

Cummins Engine Company Ltd.  
 Royal Oak Way South  
 Daventry, Northants NN11 5NU  
 England  
 Telephone: (44-1327) 886000

Countries Covered:

NORTH/WEST/EAST AND CENTRAL AFRICA		
Benin (from Togo)	Gabon	Mauritania
Burkina-Paso	Gambia	Morocco
Burundi		
Cameroon	Ghana	Niger
Cape Verde	Guinea	Nigeria
Central African Republic	Guinea-Bissau	Sao Tome & Principe
	Ivory Coast	
Chad	Liberia	Senegal
Congo (D.R.)		Seychelles
Congo (P.R.)		
	Libya	Siera Leone
Djibouti		Somalia
Equatorial Guinea	Mali	Togo
	Malta	Tunisia
		Uganda

**Latin America Regional Office - Miramar  
(U.S.A.)**

Cummins Americas, Inc.  
Miramar Park of Commerce  
3450 Executive Way  
Miramar, FL 33025  
Telephone: (305) 431-5511

**Countries**

Covered:	Argentina	Guatemala
	Bolivia	Honduras
	Chile	Nicaragua
	Colombia	Panama
	Costa Rica	Paraguay
	Dominican	Peru
	Republic	Uruguay
	El Salvador	Venezuela
	Ecuador	

**Caracas Regional Office - Venezuela**

Cummins Engine Company  
Oficina de Delegado  
Torre La Primera, Oficina 5-D  
Av. Francisco de Miranda  
Chacao, Caracas 1060  
Mailing Address:  
Cummins Engine Company M-227  
c/o Jet Cargo International  
P.O. Box 020010  
Miami, FL 33102-0010 U.S.A.  
Telephone: (58-2) 32-0563, 32-718

**Countries**

Covered:	Costa Rica	Honduras
	Dominican	Nicaragua
	Republic	Panama
	El Salvador	Venezuela
	Guatemala	

**Southern Africa Regional Office**

Cummins Diesel South Africa (Pty) Ltd  
13 Eastern Service Road  
Kelvin View 2054  
South Africa  
Telephone: (00 27 11) 321 8700 (from U.K.)  
Fax: (00 27 11 444 1899)

Mailing Address:  
Wendywood 2144  
Gauteng  
South Africa

**Countries**

Covered:	Angola	Swaziland
	Botswana	South Africa
	Comoros Island	ST. Helena
	Lesotho	Tanzania
	Madagascar	
	Malawi	Zambia
	Mauritius	Zimbabwe
	Mozambique	
	Nambia	



## Distributors - International

### Locations

#### ABU DHABI

- See United Arab Emirates

#### AFGHANISTAN

- See Middle East Regional Office

#### ALBANIA

- See Germany Regional Office -  
Gross-Gerau

#### ALGERIA

- See Cummins Diesel S.A. - Lyon

#### AMERICAN SAMOA

- See South Pacific Regional Office

#### ANDORRA

- See European Regional Office -  
Mechelen

#### ANGOLA

##### Luanda

Hull Blyth (Angola) Ltd  
Casa Inglesa  
Rua Major Kahangulo, 134/140  
Luanda  
Republic of Angola  
Telephone: (244-2) 331817/337184/  
310026  
Fax: (244-2) 335602

#### ANTIGUA

Miami (Office In U.S.A.)  
Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

#### ARGENTINA

##### Buenos Aires

Distribuidora Cummins, S.A.  
(DICUMAR)  
Av. Del Libertador 602 Piso 5  
Buenos Aires, Argentina  
Telephone: (54-1)814-1895/1395/1393

#### ARUBA, ISLAND OF

- See Netherlands Antilles

#### AUSTRIA

##### Neudoerfl

Cummins Diesel Motorenvertriebsges  
m.b.H. Trenner & Co.  
Bickfordstr. 25  
A-7201 Neudoerfl  
Austria  
Telephone: (43-2622) 77418/77625

#### BAHAMAS

##### Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

#### BAHRAIN

##### Bahrain

Yusuf Bin Ahmed Kanoo W.L.L.  
P.O. Box 45, Manama  
Bahrain  
Telephone: (973) 738200

#### BALEARIC ISLANDS

##### Madrid (Office in Spain)

Cummins Ventas y Servicio, S.A.  
Torrelaguna, 56  
28027 Madrid, Spain  
Telephone: (34-91) 367-2000  
376-2404

#### BANGLADESH

##### Dhaka

Equipment & Engineering Co., Ltd.  
G.P.O. Box 2339  
Dhaka 1000, Bangladesh  
Location:  
56, Dilkusha Commercial Area  
2nd Floor/Eastern Block  
Telephone: (880-2) 234357, 234060

#### BARBADOS

##### Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

#### BELGIUM

##### Brussels

Cummins Distributor  
Belgium S.A.  
623/629 Chaussee de Haecht  
B-1030 Brussels, Belgium  
Telephone: (24 hr.)  
(32-2) 216-81-10

#### BELIZE

##### Tampa (Office in U.S.A.)

Cummins Southeastern Power, Inc.  
5421 N. 59th Street  
Tampa, FL 33610  
Telephone: (813) 621-7202

#### BENIN

- See Togo

#### BERMUDA

##### Bronx (Office in U.S.A.)

Cummins Metropower, Inc.  
890 Zerega Avenue  
Bronx, NY 10473  
Telephone: (718) 892-2400

#### BHUTAN

##### Pune (Office in India)

Cummins Diesel Sales &  
Service (India) Ltd.  
35A/1/2, Erandawana  
Pune - 411 038, India  
(State of Maharashtra) India  
Telephone: (91-212) 331234/331554/  
331635/330066/  
330166/330356/  
31703

#### BOLIVIA

##### La Paz

Machinery & Auto Service  
Casilla 4042  
La Paz, Bolivia  
Location:  
Av. 20 de Octubre Esq.  
Rosendo Gutierrez  
Telephone: (591-2) 379650, 366394

#### BONAIRE, ISLAND OF

- See Netherlands Antilles

#### BOTSWANA

- See Southern Africa Regional Office -  
Kelvin

#### BRAZIL

##### Ananindeua

Marcos Marcelino & Companhia  
Ltda.  
Rodovia BR-316, Km 9  
67020-010 Ananindeua, Para,  
Brazil  
Telephone: (55-91) 235-4100/4132/  
4143/4012

##### Belo Horizonte

Distribuidora Cummins  
Minas S.A.  
31950-640 Olhos D'Agua Norte  
Belo Horizonte, MG  
Brazil  
Telephone: (55-31) 288-1344

##### Campo Grande

Distribuidora Cummins  
Mato Grosso Ltda.  
Rodovia BR 163 Km 01  
79060-000 Campo Grande  
Mato Grosso do Sul, Brazil  
Telephone: (55-67) 787-1166

### **Curitiba**

Distribuidora Cummins Parana S.A.  
Rua Brasílio Itiberê, 2195  
80230 Curitiba, Parana  
Brazil  
Telephone: (55-41) 222-4036

### **Fortaleza**

Distribuidora Cummins Diesel  
Do Nordeste Ltda.  
Av. da Abolição, 3882,  
Mucuripe  
60165-081 Fortaleza, Ceara  
Brazil  
Telephone: (55-85) 263-1212

### **Goianian**

Distribuidora de Motores Cummins  
Centro Oeste Ltda.  
Av. Caiapo 777 - Setor Sta. Genoveva  
74672-400 Goiania, Goias  
Brazil  
Telephone: (55-62) 207-1010

### **Manaus**

Distribuidora Cummins  
Amazonas Ltda.  
Estrada da Ponta Negra, 6080 - Sao  
Jorge  
69037 Manaus, Amazonas,  
Brazil  
Telephone: (55-92) 656-5444

### **Porto Alegre**

Distribuidora Cummins  
Meridional S.A.  
Rua Dona Alzira, 98, Sarandi  
91110-010 Porto Alegre,  
Rio Grande do Sul, Brazil  
Telephone: (55-51) 340-8222

### **Rio de Janeiro**

Distribuidora Cummins  
Leste Ltda.  
Rua Sariema, 138-Olaria  
21030-550 Rio de Janeiro,  
Rio de Janeiro, Brazil  
Telephone: (55-21) 290-7899

### **Sao Paulo**

Companhia Distribuidora  
de Motores Cummins  
Rua Martin Burchard, 291 - Bras  
03043-020 Sao Paulo,  
Sao Paulo, Brazil  
Telephone: (55-11) 270-2311

### **BRITISH VIRGIN ISLANDS**

- See Puerto Rico

### **BRUNEI**

- See Malaysia

### **BURKINA - FASO**

- See North/West/East and Central Af-  
rica Regional  
Office - Daventry

### **BULGARIA**

-See Germany Regional Office - Gross-  
Gerau

### **BURMA**

#### **Kuala Lumpur (Office In Malaysia)**

Contact: Scott &  
English (M) Sdn Bhd  
P.O. Box 10324  
50710 Kuala Lumpur  
West Malaysia  
Location:  
16 Jalan Chan Sow Lin  
55200 Kuala Lumpur  
West Malaysia  
Telephone: (60-3) 2211033

### **BURUNDI**

#### **Brussels (Office in Belgium)**

Bia, S.A.  
Rameistraat, 123  
B-3090 - Overijse, Belgium  
Telephone: (32-2) 6892811

### **CAMBODIA**

- See South & East Asia Regional Office  
- Singapore

### **CANARY ISLANDS**

#### **Madrid (Office in Spain)**

Cummins Ventas y  
Servicio, S.A.  
Torrelaguna, 56  
28027 Madrid, Spain  
Telephone: (34-91) 3672000/3672404

### **CAPE VERDE**

- See ECV Portugal

### **CENTRAL AFRICAN REPUBLIC**

- See North/West Africa Regional Office  
- Daventry

### **CEYLON**

- See Sri Lanka

### **CHAD**

- See North/West/East and Central Af-  
rica Regional Office - Daventry

### **CHILE**

#### **Santiago**

Distribuidora Cummins Diesel  
S.A.C.I.  
Casilla Postal 1230  
Calle Bulnes 1203  
Santiago, Chile  
Corporate Office:  
Av. Providencia 2653, Office 1901  
Santiago, Chile  
Telephone: (56-2) 698-2113/4/5,  
697-3566/7/8,  
697-2709

### **CHINA, PEOPLE'S REPUBLIC**

#### **Beijing**

Cummins Engine (Beijing) Co., Ltd.  
No. 8, Wan Yuan Street  
Beijing Economic and Technology De-  
velopment Zone  
Beijing, 100176  
People's Republic of China  
Telephone: (86-10) 67882258  
Fax: (86-10) 67882285

#### **Shenyang**

Cummins Engine (China) Investment  
Co., Ltd. - Shenyang  
No. 198, Lianhe Rd., Dadong District  
Shenyang, 110044  
People's Republic of China  
Telephone: (86-24) 88094014, 88905794  
Fax: (86-24) 88905970

#### **Kunming**

Cummins Engine (China) Investment  
Co., Ltd. - Kunming  
Suite A4, A5 No. 114 East 2nd Ring Rd.  
Kunming, 650224  
People's Republic of China  
Telephone: (86-871) 5629579, 5630958  
Fax: (86-871) 5632210

#### **Urumqi**

Cummins Engine (China) Investment  
Co., Ltd. - Urumqi  
No. 275, A Le Tai Rd., Urumqi, 830011  
Xinjiang, People's Republic of China  
Telephone: (86-991) 3844712, 3844723  
Fax: (86-991) 3849232

#### **Shanghai**

Cummins Engine (China) Investment  
Co., Ltd. - Shanghai  
1st Floor, 555 Zhong Shan Nan Er Rd.,  
Shanghai, 200032  
People's Republic of China  
Telephone: (86-21) 64033999  
Fax: (86-21) 64033111

#### **Wuhan**

Cummins Engine (China) Investment  
Co., Ltd. - Wuhan  
No. 198, Jianshe Rd., Jiangnan District  
Wuhan, 430030  
People's Republic of China  
Telephone: (86-27) 83330180, 83330182  
Fax: (86-27) 83330180 ext. 812

#### **Guangzhou - South China Regional Office**

Cummins Engine (China) Investment  
Co., Ltd. - Guangzhou  
Rm. 211, Bai Yun Hotel, 367 Huan Shi  
Dong Rd.  
Guangzhou, 510065  
People's Republic of China  
Telephone: (86-20) 83313136, 83313137  
Fax: (86-20) 83313135

**Shenzhen (JV)**

Shenzhen Chongfa Cummins Engine Co., Ltd.  
Unit D2-F2.6  
Tian An Che Gong Miao Industrial Estate  
Shen Nan Rd.,  
Shenzhen, 518040  
People's Republic of China  
Telephone: (86-755) 3415479  
Fax: (86-755) 3415480

**COLOMBIA**

**Barranquilla**

Cummins de Colombia S.A.  
Apartado Aereo 5347  
Barranquilla, Colombia  
Location: Calle 30, No. 19 - 21  
Telephone: (57-58) 40-02-06/40-13-46

**Bogota**

Cummins Colombiana Ltda.  
Apartado Aereo No. 7431  
Bogota, D.E. Colombia  
Location:  
Av. Americas X Carrera  
42C No. 19-45  
Telephone: (57-1) 244-5688/5882

**Bucaramanga**

Cummins API, Ltda.  
Apartado Aereo 352  
Bucaramanga, Colombia  
Location:  
Autopista a Giron, Km 7  
Telephone: (57-76) 468060

**Cali**

Distribuidora Cummins del Valle, Ltda.  
Apartado Aereo No. 6398  
Cali, Colombia  
Location:  
Av. 3a. # 39-35 - Vipasa  
Telephone: (57-3) 65-4343

**Medellin**

Equipos Tecnicos Ltda.  
Apartado Aereo No. 2046  
Medellin, Colombia  
Location: Carrera 52 No. 10-184  
Telephone: (57-4) 255-4200

**Pereira**

Equipos Tecnicos Ltda. C.Q.R.  
Apartado Aereo No. 1240  
Pereira, Colombia  
Location: Carrera 8a. No. 45-39  
Telephone: (57-63) 366341

**COMOROS**

- See Southern Africa Regional Office - Kelvin

**CONGO, PEOPLE'S REPUBLIC**

**Brussels (Office in Belgium)**

Bia, S.A.  
Rameistraat, 123  
B-3090  
Overijse, Belgium  
Telephone: (32-2) 6892811

**CORSICA**

- See France

**COSTA RICA**

**San Jose**

Servicios Unidos, S.A.  
P.O. Box 559  
San Jose, Costa Rica  
Location:  
100 metros al este de  
Excelsior Antiguo  
Curridabat, San Jose  
Telephone Office: (506) 53-93-93  
Telephone Service Shop:  
(506) 26-00-76

**CUBA**

**Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**CYPRUS**

**Nicosia**

Alexander Dimitriou & Sons Ltd.  
P.O. Box 21932  
Nicosia, Cyprus  
CY-1515  
Location:  
4 Salamis Avenue  
Telephone: (357-2) 349450

**CZECH REPUBLIC**

- See Austrian Distributor

**DENMARK**

**Glostrup**

Cummins Diesel Salg & Service A/S  
Hovedvejen 233B  
Osted  
DK-4000 Roskilde  
Denmark  
Telephone: (45-46) 423 552

**DJIBOUTI**

- See North/West/East and Central Africa

**DOMINICA**

**Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

**DOMINICAN REPUBLIC**

**Santo Domingo**

Argico C. Por A.  
P.O. Box 292-2 FERIA  
Santo Domingo  
Dominican Republic, ZP-6  
Location:  
Calle Jose A. Soler  
No. 3, ESQ.  
Avenida Lope de Vega  
Telephone: (809) 562-6281

**DUBAI**

- See United Arab Emirates

**ECUADOR**

**Guayaquil**

Motores Cummins (MOTCUM) S.A.  
P.O. Box 1062  
Guayaquil, Ecuador  
Location:  
Avenida Carlos Julio  
Arosemena Km. 4  
Telephone: (593-4) 203995/201177

**Quito**

Rectificadora Botar S.A.  
P.O. Box 17-01-3344  
Quito, Ecuador  
Location:  
Av. 10 de Agosto No. 5980  
Telephone: (593-2) 465-176/177/  
178/195/197

**EGYPT**

**Cairo**

ADAT  
P.O. Box 1572  
Cairo, Egypt  
Sales and Service Location:  
25, Pyramid Road  
Giza, Cairo, Egypt  
Telephone: (20-2) 385-4001/2/4/5/6/8/9

**EL SALVADOR**

**San Salvador**

Salvador Machinery  
Company, S.A. de C.V.  
P.O. Box 125  
San Salvador, El Salvador  
Location:  
Blvd. Ejercito Nacional  
Telephone: (503) 711022, 228388

**ENGLAND**

- See United Kingdom

**EQUATORIAL GUINEA**

- See North/West/East and Central Africa Regional Office - Daventry

**ESTONIA**

- See Gross Gerau Regional Office - Germany

## **FAROE ISLANDS**

### **Wellingborough (Office in United Kingdom)**

Cummins Diesel  
Rutherford Drive  
Park Farm South  
Wellingborough  
Northants NN8 2QH,  
England  
Telephone: (44-1933) 334200

### **FERNANDO PO**

- See Spain

## **FIJI**

- See Cummins Diesel Sales & Service  
New Zealand Ltd.

## **FINLAND**

### **Helsinki**

Machinery OY  
P.O. Box 560  
FIN 01741 Varta Finland  
Telephone: Int: (358-9) 8955 2215

## **FRANCE**

### **Lyon**

Cummins Diesel S.A.  
Sales Corporation  
39, rue Ampere Z.I.  
69680 Chassieu, France  
Telephone: (33) 72-22-92-72  
Parts and Service Telephone:  
(33) 72-22-92-69

## **GABON**

- See North/West/East and Central Africa Regional Office - Daventry

## **GAMBIA**

- See Matforce Senegal

## **GEORGIA**

- See Moscow Regional Office - Moscow

## **GERMANY**

### **Gross-Gerau**

Cummins Diesel Deutschland GmbH  
P.O. Box 1134  
D-6080 Gross-Gerau,  
Germany  
Location: Odenwaldstr. 23  
Telephone: (49-6152) 174-0

## **GHANA**

### **Accra**

J&D Diesels and Systems  
P.O. Box c2381  
Cantonments  
Accra, Ghana  
Telephone: (233-21) 30-14-51

## **GREECE**

### **Athens**

Ergotrak  
Box 51528  
14 Km. National Rd.  
Athens-Lamia  
14510 Kifissia, Greece  
Telephone: (30-1) 6293400/41

## **GREENLAND**

- See Denmark

## **GRENADA**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **GUADELOUPE**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **GUAM**

### **Barrigada**

Mid-Pac Far East, Inc.  
Airport Industrial Park  
825 Tiyan Parkway  
Barrigada, Guam 96921  
Telephone: (671) 632-5160

## **GUATEMALA**

### **Guatemala City**

Maquinaria y Equipos, S.A.  
P.O. Box 2304  
Guatemala City, Guatemala  
Location:  
Carretera Amatitlan  
Km 12 zona 12  
Telephone: (502-2) 773334/7/9

## **GUINEA**

### **Brussels (Office in Belgium)**

BIA s.a.  
Rameistraat, 123  
B-3090 - Overijse, Belgium  
Telephone: (32-2) 6892811

## **GUINEA BISSAU**

- See North/West/East and Central Africa Regional Office - Daventry

## **GUYANA**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **GUYANA, FRENCH**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **HAITI**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **HOLLAND**

- See Netherlands

## **HONDURAS**

### **Tegucigalpa**

Comercial Laeisz  
Honduras, S.A.  
P.O. Box 1022  
Tegucigalpa, D.C., Honduras  
Location:  
Zona La Burrera,  
Blvd. Toncontin  
Frente a Gasolinera Esso.  
Telephone: (504) 333570/335615

## **HONG KONG**

### **Kowloon**

Cummins Engine H. K. Ltd.  
P.O. Box 840 Shatin  
N.T., Hong Kong  
Location:  
Unison Industrial Centre  
15th Floor, Units C & D  
27-31 Au Pui Wan Street  
Fo Tan, Shatin, Hong Kong  
Telephone: (852) 2606-5678  
Fax: (852) 2691-1641, 2687-3552

## **ICELAND**

### **Velasalan H.F.**

Ananaustrum 1  
121 Reykjavik  
Iceland  
Telephone: (354) 5526122

## **INDIA**

### **Pune**

Cummins Diesel Sales &  
Service (India) Ltd.  
35A/1/2, Erandawana  
Pune - 411 038, (State of Maharashtra)  
India  
Telephone: (91-212) 331234, 331554,  
331635, 330066,  
330166, 330356,  
331703

### **Bombay**

Cummins Diesel Sales &  
Service (I) Ltd.  
298, Perin Nariman Street, Fort,  
Bombay 400001, India  
Telephone: (91-22) 2863566/2862247

### **Calcutta**

Cummins Diesel Sales &  
Service (I) Ltd.  
94, Tivoli Court, I/C Ballygunge  
Circular Road  
Calcutta 700 019 (West Bengal), India  
Telephone: (91-33) 2478065/2470481/  
2470774

### **New Delhi**

Cummins Diesel Sales &  
Service (I) Ltd.  
Flat No. 307, Meghdoot Building  
94 Nehru Place  
New Delhi 110 019, India  
Telephone: (91-11) 6431051/6445756/  
6452817

### **Raipur**

Cummins Diesel Sales &  
Service (I) Ltd.  
Plot No. 15, Jalashay Marg  
Choube Colony  
Raipur 492 001 (Madhya Pradesh),  
India  
Telephone: (91-771) 24994/23157/29498

### **Ranchi**

Cummins Diesel Sales &  
Service (I) Ltd.  
'Shanti Kunj' C-202, Vidyalaya Marg  
Road No. 1, Ashoknagar  
Ranchi 834 002 (Bihar)  
India  
Telephone: (91-651) 301948/303623

### **INDONESIA**

#### **Jakarta**

P.T. Alltrak 1978  
P.O. Box 64/KBYL  
Jakarta Selatan 12330, Indonesia  
Location:  
J1. R.S.C. Veteran No. 4  
Bintaro, Rempoa  
Telephone: (62-21) 736-1978/736-3302

### **IRAN**

- See Middle East Regional Office -  
United Arab Emirates

### **IRAQ**

- See Middle East Regional Office or  
United Arab Emirates

### **IRELAND**

#### **Wellingborough (Office in England)**

Cummins Diesel  
Denington Estate  
Wellingborough  
Northants NN8 2QH, England  
Telephone: (44-1933) 334200

### **ISRAEL**

#### **Tel Aviv**

Israel Engines &  
Trailers Co. Ltd.  
Levinson Brothers Engineers  
P. O. Box 390  
33 Hahashmal Street  
Tel Aviv, Israel 61003  
Telephone: (972-3) 7106222

### **ITALY**

#### **Milan**

Cummins Diesel Italia S.p.A.  
Piazza Locatelli, 8  
Zona Industriale Sesto Uteriano  
20098 S. Giuliano  
Milanese (Milan), Italy  
Telephone: (39-2) 9828-1235/6/7

### **IVORY COAST**

- See Cote d' Ivoire

### **JAMAICA**

#### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

### **JAPAN**

#### **Tokyo**

Cummins Diesel (Japan) Ltd.  
1-12-10-Shintomi  
Chuo-ku, Tokyo 104  
Japan  
Telephone: (81-3) 3555-8511

### **JORDAN**

#### **Amman**

S.E.T.I. Jordan Limited  
P.O. Box 8053  
Amman, Jordan  
Telephone: (962-6) 621867/621884

### **KENYA**

#### **Nairobi**

Werrot & Company Limited  
P.O. Box 41216  
Nairobi, Kenya  
Location:  
Lusaka Road  
Telephone: (254-150) 20316

### **KOREA, SOUTH**

#### **Seoul**

Hwa Chang Trading Co., Ltd.  
Central P.O. Box No. 216  
Seoul, South Korea  
Location:  
143-11 Doksan-dong, Kuro-ku  
Telephone: (82-2) 854-0071/2/3/4/5,  
869-1411/2/3

### **KUWAIT**

#### **Kuwait**

General Transportation &  
Equipment Co.  
(Sales Department)  
P.O. Box 1096  
13011 Safat, Kuwait  
Location:  
Shuwaikh Behind  
Canada Dry Factory  
Telephone: (965) 4833380/1/2

#### **Kuwait**

General Transportation &  
Equipment Co.  
(Service Department)  
East Ahmadi Area  
13011 Safat, Kuwait  
Telephone: (965) 3981577

### **LAOS**

- See South and East Asia Regional Of-  
fice - Singapore

### **LATVIA**

- See Moscow Regional Office - Moscow

### **LEBANON**

#### **Beirut**

S.E.T.I. Charles Keller  
S.A.L.  
B.P. 16-6726  
Beirut, Lebanon  
Location:  
Corniche du Fleuve  
Telephone: (961-1) 425040/41

### **LESOTHO**

- See South Africa

### **LIBYA**

- See North/West Africa Regional Office  
- Davenport

### **LIECHTENSTEIN**

- See Switzerland

### **LUXEMBOURG**

#### **Gross-Gerau (Office in Germany)**

Cummins Diesel Deutschland GmbH  
P.O. Box 11 34  
Odenwaldstrasse 23  
D-6080 Gross-Gerau, Germany  
Telephone: (49-6152) 174-0

### **MACAU**

- See Hong Kong

### **MADAGASCAR**

- See East and Southern Africa Re-  
gional Office - Harare

### **MADEIRA ISLANDS**

- See Portugal

## **MALAYSIA**

### **Kuala Lumpur**

Cummins Diesel Sales & Service  
Div. of Scott & English  
(M) Sdn. Bhd.  
P.O. Box 10324  
50710 Kuala Lumpur, West Malaysia  
Location:  
16 Jalan Chan Sow Lin  
55200 Kuala Lumpur  
Telephone: (60-3) 2211033

### **MALI**

- See Senegal (Matforce)

## **MALTA**

### **Valletta**

Plant & Equipment Ltd.  
Regency House  
254, Republic Street  
Valletta, Malta  
Telephone: (356) 23-26-20, 23-33-43,  
23-16-23, 24-75-17

## **MARTINIQUE**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **MEXICO**

### **Guadalajara**

Cummins Del Occidente, S.A.  
Lazaro Cardenas No. 2950  
Fracc. Alamo Industrial  
45560 Guadalajara, Jal. Mexico  
Telephone: (52-3) 670-93-06, 670-53-38,  
670-63-61, 670-62-33

### **Monterrey**

Tecnica Automotriz, S.A.  
Av. Alfonso Royes  
No. 3637 Nte.  
Monterrey, Nuevo Leon, Mexico  
Telephone: (52-83) 51-41-51, 51-46-56

### **Merida**

Cummins Del Sureste, S.A. de C.V.  
Av. Aviacion Civil No. 647  
Esquina Calle 100  
Col. Sambula  
97259 Merida, Yucatan, Mexico  
Telephone: (52-99) 24-11-55, 24-00-15

### **Puebla**

Cummins de Oriente, S.A. de C.V.  
Av. Reforma No. 2112,  
Puebla, Pue. Mexico  
Telephone: (52-22) 48-76-74, 48-76-75

## **Queretaro**

Distribuidor Cummins Del Centro, S.A.  
de C.V.  
Blvd. Bernardo Quintana No. 518  
Col. Arboledas  
C.P. 76140 Queretaro, Qro., Mexico  
Telephone: (52-42) 12-41-90, 12-58-90,  
12-62-94, 14-04-16,  
14-08-81, 14-15-91

## **Tlalnepantla**

Distribuidor Cummins  
Metropolitana, S.A. DE C.V.  
Sor Juana Ines de la Cruz No. 555  
54000 Tlalnepantla, Edo. de Mexico,  
Mexico  
Telephone: (52-5) 327-38-00, 390-64-37,  
390-12-27

## **MOROCCO**

### **Casablanca**

Soberma (Groupe Auto Hall)  
Société Soberma  
Chamin Ain Borja  
Quartier Beausite  
Ain Sebaâ  
Casablanca, Morocco  
Telephone: (212-22) 66 66 40-43  
Fax: (212-22) 66 66 45-46

## **MOZAMBIQUE**

- See Southern Africa Regional Office -  
Kelvin

## **NAMIBIA (Southwest Africa)**

### **Walvis Bay**

Namib Diesel  
P.O. Box 2449, Walvis Bay, Namibia  
Location:  
210, 2nd Street  
Walvis Bay, Namibia  
Telephone: 064-203971

## **NEPAL**

### **Pune (Office in India)**

Cummins Diesel Sales &  
Service (India) Ltd.  
35A/1/2, Erandawana  
Pune, - 411 038, (State of Maharashtra)  
India  
Telephone: (91-212) 331234, 331554,  
331635, 330066,  
330166, 330356,  
331703

## **NETHERLANDS**

### **Dordrecht**

Cummins Diesel Sales &  
Service, B.C.  
Galvanistraat 35  
3316 GH Dordrecht  
Netherlands  
Telephone: (31-78) 618-12-00

## **NETHERLANDS ANTILLES**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **NEW CALEDONIA**

- See South Pacific Regional Office -  
Melbourne

## **NEW GUINEA**

- See Papua New Guinea

## **NICARAGUA**

### **Managua**

F. Alf. Pellas & Cia.  
Apartado Postal No. 46  
Managua, Nicaragua  
Location:  
6a. Calle  
30 y 31 Avs. N.O., Zona 5  
Telephone: (505-2) 660616

## **NIGERIA**

### **Lagos**

SCOA TRAC  
P.M.B. 21108  
Ikeja, Lagos  
Nigeria  
Location:  
Apapa-Oshodi Expressway  
Isolo Industrial Estate,  
Isolo  
Telephone: (234-1) 45-21-539/45-21-803

### **Paris (Office in France)**

SCOA INTER  
Immeuble Marie-Joseph  
Rue du Maréchal de Lattre de Tassigny  
78990 Elancourt  
France  
Telephone: (33-1) 30-68-82-68

## **NORTHERN IRELAND**

- See United Kingdom

## **NORWAY**

### **Oslo**

Cummins Diesel Salg & Service A/S  
Hestehagen 3  
Postboks 151  
N-1441 DRØBAK  
Norway  
Telephone: (47) 64 90 70 80

## **OMAN**

### **Ruwi**

Universal Engineering  
Services L.L.C.  
P.O. Box 2688  
Ruwi  
Sultanate of Oman  
Telephone: (968) 590830, 591304

## PAKISTAN

### Karachi

Diesel Power Systems  
2 Bangalore Town  
Main Shahrah-e-Faisal  
Karachi 75350  
Pakistan  
Telephone: (92) 21-453 9603/4/5

## PANAMA

### Panama City

Grupo Tiesa, S.A.  
Apartado Postal #55-0549  
Partillo, Panama  
Telephone: (507) 67-3866

## PAPUA NEW GUINEA

### Sydney (Office in Australia)

Cummins Diesel Sales & Service  
P.O. Box 150  
Cabramatta, 2166  
New South Wales, Australia

## PARAGUAY

### Asuncion

Automotores y Maquinaria,  
S.R.L.  
Yegros y Fulgencio R. Moreno  
P.O. Box 1160  
Asuncion, Paraguay  
Telephone: (595-21) 493111, 493115

## PERU

### Lima

Comercial Diesel  
del Peru S.A.  
P.O. Box 14-0234  
Lima, Peru  
Location:  
Ave. V.R. Haya  
de la Torre 2648  
Lima 3, Peru  
Telephone: (51-14) 74-3173/4374/  
3144/2281

## PHILIPPINES

### EDSA

Power Systems, Inc. EDSA  
P.O. Box 3241  
Manila  
Philippines 1501  
Location:  
79E. Delos Santos Ave.  
Mandaluyong, Metro Manila  
Telephone: (63-2) 791769, 791771,  
5311945, 5315448,  
5311934, 5312531,  
53414513

## POLAND

Polremaco  
30-709 Krakow  
Ul. Stoczniewcow 3  
Poland  
Telephone: (48-12) 6561917

## PORTUGAL

### Lisbon

Electro Central  
Vulcanizadora, Lda.  
P.O. Box 3077  
1302 Lisbon, Portugal  
Location:  
Rua Conselheiro  
Martins de Carvalho  
Lote 1480  
1400 Lisboa (Restelo)  
Telephone: (351-2) 303 4800

## QATAR

### Doha

Jaidah Motors & Trading Co.  
P.O. Box 150  
Doha, Qatar (Arabian Gulf)  
Telephone: (974) 442-6161

## REUNION

- See Lyon Regional Office - Lyon

## RIO DE ORO

- See Spain

## ROMANIA

- See Germany Regional Office - Gross-  
Gerau

## RUSSIA

- See Moscow Regional Office - Moscow

## RWANDA

### Brussels (Office in Belgium)

Bia, S.A.  
Rameistraat, 123  
B-3090 - Overijse, Belgium  
Telephone: (32-2) 6892811

## ST. LUCIA

### Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## ST. VINCENT

### Miami (Office in U.S.A.)

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## SAN MARINO

- See Italy

## SAO TOME AND PRINCIPE

- See North/West/East and Central Af-  
rica Regional Office - Daventry

## SAUDI ARABIA

### Al-Khobar

GCC Olayan  
P.O. Box 356  
Al-Khobar 31952  
Saudi Arabia  
Telephone: (966-3) 882-0888

## SCOTLAND

- See United Kingdom

## SENEGAL

### Dakar

Matforce  
B.P. 397  
Dakar, Senegal  
Location:  
10 Avenue Faidherbe  
Telephone: (221-8) 399500  
Fax: (221-8) 399531/399550

Equipements et Services (Mining Only)

BP 15372-Fann

Dakar

Senegal

Contacts: Mr. Jean Smets

Tel: (221-8) 60 77 76 & 24 73 62

Fax: (221-8) 60 95 98

## SEYCHELLES

- See North/West/East & Central Re-  
gional Office - Daventry

## SIERRA LEONE

- See North/West/East and Central Af-  
rica Regional Office - Daventry

## SINGAPORE

### Singapore

Applied Diesel Sales & Service Pte Ltd  
8 Tanjong Penjuru  
Jurong Industrial Estate  
Singapore 2260  
Telephone: (65) 261-3555

## SLOVAKIA

- See European Regional Office - Gross-  
Gerau

## SOLOMON ISLANDS

- See South Pacific Regional Office -  
Melbourne

## SOMALIA

- See East and Southern Africa Re-  
gional Office - Harare

## SOUTH AFRICA

### Johannesburg

Cummins Diesel South Africa Pty. Ltd.  
Private Bag X7  
Wendywood 2144  
South Africa  
Location:  
13 Eastern Service Road  
Kelvin View 2054  
Telephone: (27-11) 321 8700

## **SOUTHWEST AFRICA**

- See Namibia

## **SPAIN**

### **Madrid**

Cummins Ventas y  
Servicio S.A.  
Torrelaguna, 56  
28027 Madrid, Spain  
Telephone: (34-91) 367-2000/3672404

## **SPANISH GUINEA**

- See Spain

## **SRI LANKA**

### **Colombo**

Trade Promoters Ltd  
P.O. Box 321  
69, Walukarama Road  
Colombo 3  
Sri Lanka  
Telephone: (94-1) 573927, 574651,  
575005

## **SUDAN**

- See Middle East Regional Office -  
United Arab Emirates

## **SURINAM**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power, Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **SWAZILAND**

- See South Africa

## **SWEDEN**

### **Stockholm**

SMA Maskin AB  
Aggelundavagen 7  
S-17562 Jarfalla  
Sweden  
Telephone: (46-8) 56-222-500

## **SWITZERLAND**

### **Regensdorf**

Robert Aebi S.A.  
Riedhofstrasse 100  
8105 Regensdorf  
Switzerland  
Telephone: (41-1) 842-5111

## **SYRIA**

### **Damascus**

Puzant Yacoubian & Sons  
P.O. Box 3617  
Damascus, Syria  
Location:  
Abou Baker El Saddik Street  
Kafar Sousse Square  
Telephone: (963-11) 212-8600

## **TAHITI, ISLAND OF**

- See French Polynesia

## **TAIWAN**

### **Taipei (JV)**

Cummins Power Service & Parts Corp.  
No. 115, Wu Ko 1st Rd.,  
Wu Ku, Industrial District  
Taipei, Taiwan, R.O.C.  
Telephone: (886-2) 2290-0331  
Fax: (886-2) 2290-0393

## **TANZANIA**

- See South African Regional Office -  
Kelvin

## **THAILAND**

### **Bangkok**

Diethelm & Company Ltd.  
1696 New Petchburi Road  
Bangkok 10310, Thailand  
Telephone: (66-2) 254-4900

## **TOGO (and BENIN)**

### **Lome**

Togomat  
B.P. 1641  
Lome, Togo  
Location:  
Zone Industrielle CNPPME  
Telephone: (228) 27-23-95

## **TONGA, ISLAND OF**

- See South Pacific Regional Office -  
Melbourne

## **TRINIDAD and TOBAGO**

### **Miami (Office in U.S.A.)**

Cummins Southeastern Power Inc.  
9900 N.W. 77 Court  
Hialeah Gardens, FL 33016  
Telephone: (305) 821-4200

## **TURKEY**

### **Istanbul**

Hamamcioglu Mueseseleri  
Okul Cad. No. 9  
81474 Orhanli - Tuzia  
Istanbul, Turkey  
Telephone: (90) 216-394-3210

## **UKRAINE**

- See Moscow Regional Office - Moscow

## **UNITED ARAB EMIRATES**

### **Dhabi**

Cummins Diesel FZE  
P.O. Box 17636  
Units ZF516, Jebel Ali Free Zone  
Dhabi,  
United Arab Emirates  
Telephone: (971) 4-883-8998

## **UNITED KINGDOM**

### **Wellingborough**

Cummins Diesel  
Rutherford Drive  
Park Farm South  
Wellingborough  
Northants NN8 2QH, England  
Telephone: (44-1933) 334200

## **URUGUAY**

### **Montevideo**

Santaro S.A.  
P.O. Box 379  
Montevideo  
Uruguay  
Location:  
Avenida Millan No. 2441  
Telephone: (598-2) 293908

## **VATICAN CITY**

- See Italy

## **VENEZUELA**

### **Caracas**

Sudimat  
Apartado Postal 1322  
Carmelitas  
Caracas 1010  
Venezuela  
Location:  
Final Avenida San Martin  
Urb. la Quebradita  
Caracas 1061  
Telephone: (58-2) 442-6161/2647

## **VIETNAM**

### **Hanoi**

Diethelm & Co. Ltd. Engineering  
Room No. 1, 2nd Floor  
8 Trang Thi Street  
Hanoi, Vietnam  
Telephone: (84-4) 260-332, 244-394

### **Ho Chi Minh City**

Diethelm & Co. Ltd. Engineering  
3rd Floor, IBC Building  
1 Me Linh Square  
District 1  
Ho Chi Minh City, Vietnam  
Telephone: (84-8) 294-102, 294-103

## **WESTERN SAMOA**

- See South Pacific Regional Office -  
Melbourne

## **YEMEN**

### **Sana'a**

Zubieri Trading Co.  
P.O. Box 535  
Sana'a, Yemen Arab Republic  
Telephone: (967) 1-223943/224051



**YUGOSLAVIA**

Cummins Dizel Motori Doo  
Prodaja I Servis  
Autoput 22  
11080 Zemun  
Beograd  
F.R. Yugoslavia  
Telephone: (381-11) 314 9071

**ZAMBIA**

**Ndola**

Cummins Diesel Services (Zambia) Ltd.  
P.O. Box 71501  
Ndola, Zambia  
Telephone: (260-2) 610729

**ZIMBABWE**

**Harare**

Cummins Zimbabwe (Pvt) Ltd.  
P.O. Box ST363  
Southerton  
Harare, Zimbabwe  
Location:  
72 Birmingham Road  
Southerton, Harare  
Telephones: (263-4) 621871/2/3/4/5

## Section TS - Troubleshooting Symptoms

### Section Contents

	Page
<b>Troubleshooting Procedures and Techniques .....</b>	<b>TS-1</b>
General Information .....	TS-1
<b>Troubleshooting Symptoms Charts.....</b>	<b>TS-1</b>
Air Compressor Air Pressure Rises Slowly .....	TS-2
Air Compressor Cycles Frequently .....	TS-3
Air Compressor Noise is Excessive .....	TS-4
Air Compressor Pumping Excess Lubricating Oil into the Air System .....	TS-5
Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously).....	TS-6
Air Compressor Will Not Stop Pumping.....	TS-7
Alternator Not Charging or Insufficient Charging .....	TS-8
Alternator Overcharging .....	TS-9
Coolant Contamination .....	TS-10
Coolant Loss – External.....	TS-11
Coolant Temperature Above Normal – Gradual Overheat.....	TS-12
Coolant Temperature is Above Normal – Sudden Overheat.....	TS-14
Coolant Temperature is Below Normal.....	TS-15
Engine Acceleration or Response Poor.....	TS-16
Engine Difficult to Start or Will Not Start (Exhaust Smoke) .....	TS-18
Engine Difficult to Start or Will Not Start (No Exhaust Smoke).....	TS-20
Engine Noise Excessive .....	TS-22
Engine Noise Excessive — Combustion Knocks.....	TS-24
Engine Power Output Low .....	TS-25
Engine Runs Rough at Idle .....	TS-28
Engine Runs Rough or Misfires.....	TS-29
Engine Speed Surges at Low or High Idle.....	TS-30
Engine Speed Surges Under Load or in Operating Range.....	TS-31
Engine Starts But Will Not Keep Running.....	TS-32
Engine Vibration Excessive .....	TS-33
Engine Will Not Crank or Cranks Slowly (Air Starter).....	TS-34
Engine Will Not Crank or Cranks Slowly (Electric Starter).....	TS-36
Engine Will Not Reach Rated Speed (RPM) .....	TS-38
Engine Will Not Shut Off .....	TS-40
Exhaust Smoke Excessive Under Load.....	TS-41
Fuel Consumption Excessive.....	TS-42
Fuel in Coolant.....	TS-43
Fuel in the Lubricating Oil .....	TS-44
Fuel or Lubricating Oil Leaking From Exhaust Manifold.....	TS-45
General Information .....	TS-1
Intake Manifold Air Temperature Above Specification.....	TS-46
Intake Manifold Pressure (Boost) is Below Normal .....	TS-48
Lubricating Oil Consumption Excessive.....	TS-49
Lubricating Oil Contaminated .....	TS-50
Lubricating Oil Loss.....	TS-51
Lubricating Oil Pressure High.....	TS-52
Lubricating Oil Pressure Low.....	TS-53
Lubricating Oil Sludge in the Crankcase Excessive .....	TS-55
Smoke, Black — Excessive .....	TS-56
Smoke, White — Excessive .....	TS-57
Turbocharger Leaks Engine Oil or Fuel.....	TS-59

**THIS PAGE LEFT INTENTIONALLY BLANK**

## Troubleshooting Procedures and Techniques

### General Information

This guide describes some typical engine operating problems, their causes, and some acceptable corrections to those problems. Unless noted otherwise, the problems listed are those which an operator can diagnose and repair.

#### **WARNING**

Performing troubleshooting procedures NOT outlined in this section can result in equipment damage or personal injury or death. Troubleshooting must be performed by trained, experienced technicians. Consult a Cummins Authorized Repair Location for diagnosis and repair beyond that which is outlined, and for symptoms not listed in this section. Before beginning any troubleshooting, refer to General Safety Instructions in Section i of this manual.

Follow the suggestions below for troubleshooting:

- Study the complaint thoroughly before acting
- Refer to the engine system diagrams
- Do the easiest and most logical things first
- Find and correct the cause of the complaint

## Troubleshooting Symptoms Charts

### General Information

Use the charts on the following pages of this section to aid in diagnosing specific engine symptoms. Read each row of blocks from top to bottom. Follow through the chart to identify the corrective action.

#### **WARNING**

Troubleshooting presents the risk of equipment damage, personal injury or death. Troubleshooting must be performed by trained, experienced technicians.

### Air Compressor Air Pressure Rises Slowly

#### Cause

#### Correction

Air intake system restriction to air compressor is excessive

Replace the air compressor air cleaner (if installed). Check the air intake piping. Check engine air intake restriction if the air compressor inlet is plumbed to the vehicle or equipment intake system. Refer to Section 4.

OK

Air system leaks

Block the vehicle wheels and check the air system for leaks with spring brakes applied and released. Check for leaks from the air compressor gaskets and the air system hoses, fittings, tanks, and valves. Refer to the OEM service manuals.

OK


Carbon buildup is excessive in the air discharge line, downstream air valves, or cylinder head

Check for carbon buildup. Replace the air compressor discharge line and cylinder head assembly if necessary. Refer to Section 7.

OK

Contact a Cummins Authorized Repair Facility


### Air Compressor Cycles Frequently



### Air Compressor Noise is Excessive


Cause	Correction
Carbon buildup is excessive in the air discharge line, downstream air valves, or cylinder head	Check for carbon buildup. Replace the air compressor discharge line and cylinder head assembly if necessary. Refer to Section 7.
OK	
Air compressor is sending air pulses into the air tanks	Install a ping tank between the air dryer and the wet tank. Refer to the manufacturer's instructions.
OK	
Ice buildup in the air system components	For all models, check for ice in low spots of the air discharge line, dryer inlet, and elbow fittings. On Holset® models, also check the Econ valve (if equipped). Refer to the OEM service manual.
OK	
Contact a Cummins Authorized Repair Facility	

### Air Compressor Pumping Excess Lubricating Oil into the Air System





**Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously)**



### Air Compressor Will Not Stop Pumping

#### Cause

Air system leaks

#### Correction

Block the vehicle wheels and check the air system for leaks with spring brakes applied and released. Check for leaks from the air compressor gaskets and the air system hoses, fittings, tanks, and valves. Refer to the OEM service manual.


OK  
↓

Contact a Cummins Authorized  
Repair Facility

### Alternator Not Charging or Insufficient Charging

Cause	Correction
Alternator pulley is loose on the shaft	Tighten the pulley. Refer to OEM service manual.
OK ↓	
Batteries have malfunctioned	Check the condition of the batteries. Replace the batteries, if necessary. Refer to OEM service manual.
OK ↓	
Battery cables or connections are loose, broken, or corroded (excessive resistance)	Check the battery cables and connections.
OK ↓	
Alternator is overloaded, or alternator capacity is below specification	Install an alternator with a higher capacity. Refer to the OEM service manual.
OK ↓	
Alternator or voltage regulator is malfunctioning	Test the alternator output. Replace the alternator or voltage regulator if necessary. Refer to the OEM service manual.
OK ↓	
Battery temperature is above specification	Position the batteries away from heat sources. Refer to the OEM service manual.
OK ↓	
Electrical system is "open" (blown fuses, broken wires, or loose connections)	Check the fuses, wires, and connections. Refer to the OEM service manual and the manufacturer's wiring diagram.
OK ↓	
Vehicle gauge is malfunctioning	Check the vehicle gauge. Refer to the OEM service manual.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Alternator Overcharging



Coolant Contamination

Cause	Correction
Coolant is rusty and has debris	Drain and flush the cooling system. Fill with correct mixture of antifreeze and water. Refer to Section 7.
OK	
Transmission oil cooler or torque converter cooler is leaking	Check the transmission oil cooler and torque converter cooler for coolant leaks. Refer to the OEM service manual.
OK	
Lubricating oil cooler is leaking	Check the lubricating oil cooler for coolant leaks and cracks. Refer to Section 7.
OK	
Cylinder head gasket is leaking	Check the cylinder head gasket. Refer to the OEM service manual.
OK	
Contact a Cummins Authorized Repair Facility	

### Coolant Loss – External



### Coolant Temperature Above Normal – Gradual Overheat

Cause	Correction
Charge air cooler fins, radiator fins, or air conditioner condenser fins are damaged or obstructed with debris	Inspect the charge air cooler, air conditioner condenser, and radiator fins. Clean, if necessary. Refer to Section 4 and the OEM service manual.
OK ↓	
Cold weather radiator cover or winterfront is closed	Open the cold weather radiator cover or the winterfront. Maintain a minimum of 784 cm <sup>2</sup> [122 in <sup>2</sup> ], or approximately 28 x 28 cm [11 x 11 in], of opening at all times. Refer to Section 1.
OK ↓	
Coolant level is below specification	Inspect the engine and cooling system for external coolant leaks. Repair if necessary. Add coolant. Refer to Section 7.
OK ↓	
Fan shroud is damaged or missing, or the air recirculation baffles are damaged or missing	Inspect the shroud and the recirculation baffles. Repair, replace, or install, if necessary. Refer to the OEM service manual.
OK ↓	
Lubricating oil is contaminated with coolant or fuel	Contact a Cummins Authorized Repair Facility.
OK ↓	
Cooling system hose is collapsed, restricted, or leaking	Inspect the hoses. Refer to Section 7.
OK ↓	
Coolant mixture of antifreeze and water is <b>not</b> correct	Verify the concentration of antifreeze in the coolant. Add antifreeze or water to correct the concentration. Refer to Section 5 and Section V.
OK ↓	
Lubricating oil level is above or below specification	Check the oil level. Add or drain oil, if necessary. Refer to Section 3. Check the dipstick calibration.
OK ↓	

(Continued)

Coolant Temperature Above Normal – Gradual Overheat (Continued)

Cause	Correction
Radiator fins are damaged or obstructed with debris	Inspect the radiator fins. Clean and repair the fins as necessary. Refer to the manufacturer's instructions.
OK ↓	
Coolant temperature gauge is malfunctioning	Test the temperature gauge. Repair or replace the gauge, if necessary.
OK ↓	
Fan drive belt is loose, tight, or <b>not</b> in alignment	Check the fan drive belt. Refer to Section 3.
OK ↓	
Vehicle cooling system is <b>not</b> adequate	Verify that the engine and vehicle cooling systems are using the correct components. Refer to the OEM specifications.
OK ↓	
Contact a Cummins Authorized Repair Facility	



### Coolant Temperature is Above Normal – Sudden Overheat

Cause	Correction
Coolant level is below specification	Inspect the engine and cooling system for external coolant leaks. Repair if necessary. Add coolant. Refer to Section 3.
OK ↓	
Air in the cooling system	Inspect and vent the cooling system. Refer to Section 1.
OK ↓	
Fan drive belt is broken	Check the fan drive belt. Replace the belt, if necessary. Refer to Section A.
OK ↓	
Radiator cap is <b>not</b> correct, is malfunctioning, or has low-pressure rating	Check the radiator pressure cap. Refer to the OEM service manual.
OK ↓	
Cooling system hose is collapsed, restricted, or leaking	Inspect the hoses. Refer to Section 7.
OK ↓	
Coolant temperature gauge is malfunctioning	Test the temperature gauge. Repair or replace the gauge, if necessary.
OK ↓	
Charge air cooler fins, radiator fins, or air conditioner condenser fins are damaged or obstructed with debris	Inspect the charge air cooler, air conditioner condenser, and radiator fins. Clean, if necessary. Refer to Section 4 and the OEM service manual.
OK ↓	
Cold weather radiator cover or winterfront is closed	Open the cold weather radiator cover or the winterfront. Maintain a minimum of 784 cm <sup>2</sup> [122 in <sup>2</sup> ], or approximately 28 x 28 cm [11 x 11 in], of opening at all times. Refer to Section 1.
OK ↓	
Contact a Cummins Authorized Repair Facility	

### Coolant Temperature is Below Normal

Cause	Correction
Coolant temperature gauge or sensor is malfunctioning	Test the gauge and the sensor. Repair or replace, if necessary. Refer to OEM service manual.
OK ↓	
Engine is operating at low ambient temperature	Check the winterfront, shutters, and under-the-hood air. Use under-the-hood intake air in cold weather. Refer to Cold Weather Operation, Bulletin 3387266, and Section 1.
OK ↓	
Fan drive or fan controls are malfunctioning	Check the fan drive and controls. Refer to the OEM service manual.
OK ↓	
Coolant temperature gauge is malfunctioning	Test the temperature gauge. Repair or replace the gauge, if necessary.
OK ↓	
Thermostat is <b>not</b> correct or is malfunctioning	Check the thermostat for the correct part number and for correct operation. Contact a Cummins Authorized Repair Facility.
OK ↓	
Contact a Cummins Authorized Repair Facility	

### Engine Acceleration or Response Poor

Cause	Correction
Operator technique is <b>not</b> correct	Refer to Section 1, Operating Instructions.
OK ↓	
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK ↓	
Clutch is malfunctioning or is <b>not</b> correct	Compare the drivetrain specifications to Cummins recommendations. Check the clutch for correct operation. Refer to the OEM service manual.
OK ↓	
Drivetrain is <b>not</b> correctly matched to the engine	Check for correct gearing and drivetrain components. Refer to the OEM vehicle specifications.
OK ↓	
Fuel leak	Check the fuel lines, fuel connections, and fuel filters for leaks. Check the fuel lines to the supply tanks. Refer to the OEM service manual.
OK ↓	
Intake manifold air temperature is above specification	Refer to the Intake Manifold Air Temperature Above Specification symptom tree.
OK ↓	
Fuel supply line or passage restriction between the fuel pump and the injectors	Check the fuel supply line or passage for sharp bends or restriction.
OK ↓	
Charge air cooler is restricted or leaking	Inspect the charge air cooler for air restrictions or leaks. Refer to Section 4.
OK ↓	

(Continued)

### Engine Acceleration or Response Poor (Continued)

Cause	Correction
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting. Refer to Section 3.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	
Fuel grade is <b>not</b> correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	

### Engine Difficult to Start or Will Not Start (Exhaust Smoke)

Cause	Correction
Starting procedure is <b>not</b> correct	Verify the correct starting procedure. Refer to Section 1.
OK ↓	
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Starting aid, if necessary for cold weather, is malfunctioning	Check for correct operation of the cold weather starting aid. Refer to Cold Weather Starting Aids in Section 1. Refer to the manufacturer's instructions.
OK ↓	
Engine block heater is malfunctioning (if equipped)	Check the electrical sources and wiring to the cylinder block heater. Replace the block heater, if necessary. Refer to the OEM service manual.
OK ↓	
Fuel heater is malfunctioning (if equipped)	Check the fuel heater and replace, if necessary. Refer to the manufacturer's instructions.
OK ↓	
Battery voltage is low	Check the batteries and the unswitched battery supply circuit. Refer to the OEM service manual.
OK ↓	
Keyswitch circuit is malfunctioning	Check the vehicle keyswitch circuit. Refer to the OEM service manual.
OK ↓	
Engine cranking speed is too slow	If the cranking speed is slower than 150 rpm, refer to the Engine Will Not Crank or Cranks Slowly symptom tree.
OK ↓	
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK ↓	

(Continued)

## Engine Difficult to Start or Will Not Start (Exhaust Smoke) (Continued)

Cause	Correction
Fuel leak	Check the fuel lines, fuel connections, and fuel filters for leaks. Check the fuel lines to the supply tanks. Refer to the OEM service manual.
OK ↓	
Fuel pump overflow valve is malfunctioning	Check the overflow valve. Replace if necessary. Refer to the OEM service manual.
OK ↓	
Fuel transfer pump malfunctioning	Inspect the fuel transfer pump. Replace if necessary. Refer to Section A.
OK ↓	
Throttle linkage adjustment is <b>not</b> correct	Check the fuel pump throttle linkage adjustment. Refer to the OEM service manual.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank standpipe and fuel filters as necessary. Vent air from the system. Refer to Section 5.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	
Fuel grade is <b>not</b> correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	

## Engine Difficult to Start or Will Not Start (No Exhaust Smoke)

Cause	Correction
Starting procedure is <b>not</b> correct	Verify the correct starting procedure. Refer to Section 1.
OK ↓	
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Fuel shutoff valve is malfunctioning	Check for loose wires and verify that the fuel shutoff valve is functioning. Check to be sure manual shutoff lever is in the run position. Refer to the OEM service manual.
OK ↓	
OEM engine protection system is malfunctioning	Isolate the OEM engine protection system. Follow the OEM service manuals to check for a malfunction.
OK ↓	
Battery voltage is low	Check the batteries and the unswitched battery supply circuit. Refer to the OEM service manual.
OK ↓	
Keyswitch circuit is malfunctioning	Check the vehicle keyswitch circuit. Refer to the OEM service manual.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank standpipe and fuel filters as necessary. Vent air from the system. Refer to Section 5.
OK ↓	
Fuel transfer pump malfunctioning	Inspect the fuel transfer pump. Replace if necessary. Refer to Section A.
OK ↓	
Fuel drain backup	Verify the fuel return line is plumbed to the bottom of the fuel tank.
OK ↓	

(Continued)

Engine Difficult to Start or Will Not Start (No Exhaust Smoke) (Continued)

Cause	Correction
Fuel pump overflow valve is malfunctioning	Check or replace the return overflow valve. Refer to the OEM service manual.
OK	
Throttle linkage misadjusted or damaged	Adjust or repair the linkage. Refer to the OEM service manual.
OK	
Contact a Cummins Authorized Repair Facility	



## Engine Noise Excessive

Cause	Correction
Fan drive belt is loose, tight, or <b>not</b> in alignment	Check the fan drive belt. Refer to Section 3.
OK ↓	
Lubricating oil is thin or diluted	Refer to the Lubricating Oil Specifications in Section V.
OK ↓	
Vibration damper is damaged	Inspect the vibration damper. Refer to Section 7.
OK ↓	
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting. Refer to Section 3.
OK ↓	
Air intake or exhaust piping is contacting the chassis or cab	Inspect the air piping, chassis, and cab for contact points. Refer to the OEM service manual.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	
Coolant temperature is above specification	Refer to the Coolant Temperature is Above Normal - Sudden Overheat or the Coolant Temperature is Above Normal - Gradual Overheat symptom tree.
OK ↓	
Engine mounts are worn, damaged, or <b>not</b> correct	Check the engine mounts. Refer to the OEM service manual.
OK ↓	
Fan clutch, hydraulic pump, or freon compressor noise is excessive	Isolate each component, and check for noise. Refer to the OEM service manual.
OK ↓	

(Continued)


### Engine Noise Excessive (Continued)

Cause	Correction
Fan is loose, damaged, or has excessive hub bearing end play	Check the fan. Refer to Section 3.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Engine Noise Excessive — Combustion Knocks

Cause

Correction



## Engine Power Output Low



(Continued)

### Engine Power Output Low (Continued)

Cause	Correction
Fuel leak	Check the fuel lines, fuel connections, and fuel filters for leaks. Check the fuel lines to the supply tanks. Refer to the OEM service manual.
OK ↓	
Fuel quality is poor	Operate the engine from a temporary tank of number 2 diesel fuel. Refer to the OEM service manual.
OK ↓	
Fuel supply is <b>not</b> adequate	Check the flow through the filter to locate the source of the restriction. Refer to the OEM service manual.
OK ↓	
Fuel return restriction excessive	Inspect the fuel return lines for restrictions. Refer to the OEM service manual.
OK ↓	
Fuel pump overflow valve is malfunctioning	Check the overflow valve. Replace if necessary. Refer to the OEM service manual.
OK ↓	
Fuel lift pump is malfunctioning	Check the fuel lift pump for correct operation. Check the pump output pressure. Replace the fuel lift pump if necessary. Refer to Section A.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank standpipe and fuel filters as necessary. Vent air from the system. Refer to Section 5.
OK ↓	
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK ↓	

(Continued)


### Engine Power Output Low (Continued)

Cause	Correction
Charge air cooler is restricted or leaking	Inspect the charge air cooler for air restrictions or leaks. Refer to Section 4.
OK ↓	
Lubricating oil level is above specification	Check the oil level. Verify the dipstick calibration and oil pan capacity. Fill the system to the specified level. Refer to Section 3.
OK ↓	
Contact a Cummins Authorized Repair Facility	

### Engine Runs Rough at Idle


Cause	Correction
Engine is cold	Allow the engine to warm to operating temperature. If the engine will <b>not</b> reach operating temperature, refer to the Coolant Temperature Below Normal symptom tree.
OK ↓	
Idle speed is set too low for accessories	Check and adjust the low-idle screw. Refer to the OEM service manual.
OK ↓	
Fuel pump overflow valve is malfunctioning	Check the overflow valve. Replace if necessary. Refer to the OEM service manual.
OK ↓	
Fuel transfer pump malfunctioning	Inspect the fuel transfer pump. Replace if necessary. Refer to Section A.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank standpipe and fuel filters as necessary. Vent air from the system. Refer to Section 5.
OK ↓	
Fuel supply line or passage restriction between the fuel pump and the injectors	Check the fuel supply line or passage for sharp bends or restriction.
OK ↓	
Engine mounts are worn, damaged, or <b>not</b> correct	Check the engine mounts. Refer to the OEM service manual.
OK ↓	
Fuel grade is <b>not</b> correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	

## Engine Runs Rough or Misfires





Engine Speed Surges at Low or High Idle




### Engine Speed Surges Under Load or in Operating Range

Cause	Correction
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank standpipe and fuel filters as necessary. Vent air from the system. Refer to Section 5.
OK ↓	
Idling with excessive load	Use the PTO feature for loaded conditions at low engine speeds. Refer to Section 1.
OK ↓	
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK ↓	
Clutch is malfunctioning or is <b>not</b> correct	Compare the drivetrain specifications to Cummins recommendations. Check the clutch for correct operation. Refer to the OEM service manual.
OK ↓	
Fuel grade is <b>not</b> correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	

### Engine Starts But Will Not Keep Running

Cause	Correction
Fuel level is low in the tank	Fill the supply tank. Refer to the OEM service manual.
OK ↓	
Idle speed is set too low for accessories	Check and adjust the low-idle screw. Refer to Section A.
OK ↓	
Engine-driven units are engaged	Disengage engine-driven units.
OK ↓	
Fuel shutoff lever (mechanical) partially engaged	Check for correct solenoid operation. Refer to the OEM service manual.
OK ↓	
Air in the fuel system	Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank standpipe and fuel filters as necessary. Vent air from the system. Refer to Section 5.
OK ↓	
Fuel filter or fuel suction line is restricted	Replace the fuel filter. Refer to the OEM service manual.
OK ↓	
Fuel supply line or passage restriction between the fuel pump and the injectors	Check the fuel supply line or passage for sharp bends or restriction.
OK ↓	
Fuel grade is <b>not</b> correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	

### Engine Vibration Excessive



### Engine Will Not Crank or Cranks Slowly (Air Starter)

Cause	Correction
Air pressure is low in the air tanks	Increase air pressure with an external air source. Refer to the OEM service manual.
OK ↓	
Engine-driven units are engaged	Disengage engine-driven units.
OK ↓	
Lubricating oil level is above specification	Check the oil level. Verify the dipstick calibration and oil pan capacity. Fill the system to the specified level. Refer to Section 3.
OK ↓	
Lubricating oil does <b>not</b> meet specifications for operating conditions	Change the oil and filters. Refer to Section 4. Use the oil recommended in Section V.
OK ↓	
Electrical system is "open" (blown fuses, broken wires, or loose connections)	Check the fuses, wires, and connections. Refer to the OEM service manual and manufacturer's wiring diagram.
OK ↓	
Battery charge is low	Check battery. If the battery is low, check the alternator for proper charging. Charge the battery, and replace if necessary. Refer to the OEM service manual.
OK ↓	
Keyswitch circuit is malfunctioning	Check the vehicle keyswitch circuit. Refer to the OEM service manual.
OK ↓	
Starter solenoid is <b>not</b> receiving voltage	Check the battery supply to the starter solenoid. Refer to the OEM service manual.
OK ↓	

(Continued)

Engine Will Not Crank or Cranks Slowly (Air Starter) (Continued)

Cause	Correction
Starting motor is malfunctioning, or starting motor is <b>not</b> correct	Check the starting motor operation. Compare the starting motor with the engine and vehicle specifications. Refer to the manufacturer's instructions.
OK ↓	
Contact a Cummins Authorized Repair Facility	

### Engine Will Not Crank or Cranks Slowly (Electric Starter)

Cause	Correction
Batteries are cold	Check the battery heater. Refer to the manufacturer's instructions.
OK ↓	
Battery cables or connections are loose, broken, or corroded (excessive resistance)	Check the battery cables and connections.
OK ↓	
Electrical system is "open" (blown fuses, broken wires, or loose connections)	Check the fuses, wires, and connections. Refer to the OEM service manual and manufacturer's wiring diagram.
OK ↓	
Battery charge is low	Check battery. If the battery is low, check the alternator for proper charging. Charge the battery, and replace if necessary. Refer to the OEM service manual.
OK ↓	
Keyswitch circuit is malfunctioning	Check the vehicle keyswitch circuit. Refer to the OEM service manual.
OK ↓	
Starter solenoid is <b>not</b> receiving voltage	Check the battery supply to the starter solenoid. Refer to the OEM service manual.
OK ↓	
Engine-driven units are engaged	Disengage engine-driven units.
OK ↓	
Lubricating oil level is above specification	Check the oil level. Verify the dipstick calibration and oil pan capacity. Fill the system to the specified level. Refer to Section 3.
OK ↓	

(Continued)

Engine Will Not Crank or Cranks Slowly (Electric Starter) (Continued)

Cause	Correction
Lubricating oil does <b>not</b> meet specifications for operating conditions	Change the oil and filters. Refer to Section 4. Use the oil recommended in Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	



### Engine Will Not Reach Rated Speed (RPM)

Cause	Correction
Vehicle speed is too low for adequate cooling with high engine load	Reduce the engine load. Increase the engine (fan) rpm by downshifting.
OK ↓	
Throttle linkage adjustment is <b>not</b> correct	Check throttle linkage adjustment. Refer to the OEM service manual.
OK ↓	
Tachometer is <b>not</b> calibrated or is malfunctioning	Compare the tachometer reading with a handheld tachometer or an electronic service tool reading. Calibrate or replace the tachometer as necessary. Refer to the OEM service manual.
OK ↓	
Air-fuel tube leaking, wastegate diaphragm ruptured, or wastegate plumbing damaged	Tighten the fittings, repair plumbing, replace wastegate diaphragm. Refer to the OEM service manual or an Authorized Cummins Repair Facility.
OK ↓	
Charge air cooler restricted (if equipped)	Inspect the air cooler for internal and external restrictions. Replace the restricted cooler if necessary. Refer to the OEM service manual.
OK ↓	
Fuel supply is <b>not</b> adequate	Check the flow through the filter to locate the source of the restriction. Refer to the OEM service manual.
OK ↓	
Fuel shutoff lever (mechanical) partially engaged	Make sure fuel shutoff lever is in the RUN position. Replace if necessary. Refer to the OEM service manual.
OK ↓	
Exhaust back pressure too high	Measure and correct if above specification. Refer to an Authorized Cummins Repair Facility.
OK ↓	

(Continued)


Engine Will Not Reach Rated Speed (RPM) (Continued)

Cause	Correction
Fuel transfer pump malfunctioning	Inspect the fuel transfer pump. Replace if necessary. Refer to Section A.
OK	
Vehicle parasitics are excessive	Check the vehicle brakes for dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to the OEM service manual.
OK	
Engine power output is low	Refer to the Engine Power Outlet Low symptom tree.
OK	
Contact a Cummins Authorized Repair Facility	

Engine Will Not Shut Off

Cause	Correction
Fuel shutoff valve is malfunctioning	Check for loose wires and verify that the fuel shutoff valve is functioning. Check to be sure manual shutoff lever is in the run position. Refer to the OEM service manual.
OK	
Engine running on fumes drawn into the air intake	Inspect the air intake ducts. Locate and isolate the source of the fumes. Make repairs as needed. Refer to the OEM service manual.
OK	
Fuel leak	Check the fuel lines, fuel connections, and fuel filters for leaks using the combustible gas detector service tool. Refer to the OEM service manual.
OK	
Contact a Cummins Authorized Repair Facility	

### Exhaust Smoke Excessive Under Load



## Fuel Consumption Excessive

Cause	Correction
Operator technique is <b>not</b> correct	Refer to Section 1, Operating Instructions.
OK ↓	
Fuel leak	Check the fuel lines, fuel connections, and fuel filters for leaks. Check the fuel lines to the supply tanks. Refer to the OEM service manual.
OK ↓	
Hubometer or odometer is miscalibrated	Check the hubometer and odometer calibrations. Calibrate or replace the hubometer or odometer, if necessary. Calculate fuel consumption with new mileage figures.
OK ↓	
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting. Refer to Section 3.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	
Equipment and environmental factors are affecting fuel consumption	Consider ambient temperatures, wind, tire size, axle alignment, routes, and use of aerodynamic aids when evaluating fuel consumption.
OK ↓	
Lubricating oil level is above specification	Check the oil level. Verify the dipstick calibration and oil pan capacity. Fill the system to the specified level. Refer to Section V.
OK ↓	
Contact a Cummins Authorized Repair Facility	

**Fuel in Coolant**

**Cause**

Bulk coolant supply is contaminated

OK  
↓

Contact a Cummins Authorized  
Repair Facility


**Correction**

Check the bulk coolant supply. Drain the coolant, and replace with noncontaminated coolant. Replace the coolant filters. Section 5

Fuel in the Lubricating Oil

Cause	Correction
Engine idle time is excessive	Low oil and coolant temperatures can be caused by long idle time (greater than 10 minutes). Shut off the engine rather than idle for long periods. If idle time is necessary, raise the idle speed.
OK	
Bulk oil supply is contaminated	Check the bulk oil supply. Drain the oil and replace with noncontaminated oil. Replace the oil filter(s). Refer to Section 4.
OK	
Contact a Cummins Authorized Repair Facility	

### Fuel or Lubricating Oil Leaking From Exhaust Manifold





### Intake Manifold Air Temperature Above Specification


Cause	Correction
Charge air cooler fins, radiator fins, or air conditioner condenser fins are damaged or obstructed with debris	Inspect the charge air cooler, air conditioner condenser, and radiator fins. Clean, if necessary. Refer to Section 4 and the OEM service manual.
OK ↓	
Cold weather radiator cover or winterfront is closed	Open the cold weather radiator cover or the winterfront. Maintain a minimum of 784 cm <sup>2</sup> [122 in <sup>2</sup> ], or approximately 28 x 28 cm [11 x 11 in], of opening at all times. Refer to Section 1.
OK ↓	
Fan drive belt or water pump belt is broken	Check the fan drive belt and water pump belt. Replace the belts if necessary. Refer to Section A.
OK ↓	
Fan shroud is damaged or missing, or the air recirculation baffles are damaged or missing	Inspect the shroud and the recirculation baffles. Repair, replace, or install, if necessary. Refer to the OEM service manual.
OK ↓	
Radiator shutters are <b>not</b> opening completely or the shutterstat setting is wrong	Inspect the radiator shutters. Repair or replace if necessary. Refer to the manufacturer's instructions. Check the shutterstat setting. Refer to the OEM service manual.
OK ↓	
Vehicle speed is too low for adequate cooling with high engine load	Reduce the engine load. Increase the engine (fan) rpm by downshifting.
OK ↓	
Vehicle cooling system is <b>not</b> adequate	Verify that the engine and vehicle cooling systems are using the correct components. Refer to the OEM vehicle specifications.
OK ↓	
Intake manifold temperature gauge is malfunctioning, if equipped	Test the temperature gauge. Refer to the OEM service manual.
OK ↓	

(Continued)

Intake Manifold Air Temperature Above Specification (Continued)

Cause	Correction
Fan is <b>not</b> an adequate size for the application	Verify that the fan is the correct size. Refer to the engine and OEM vehicle specifications.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Intake Manifold Pressure (Boost) is Below Normal




### Lubricating Oil Consumption Excessive

Cause	Correction
Crankcase ventilation system is plugged	Check and clean the crankcase breather and vent tube. Refer to Section 3.
OK ↓	
Lubricating oil does <b>not</b> meet specifications for operating conditions	Change the oil and filters. Refer to Section 4. Use the oil recommended in Section V.
OK ↓	
Lubricating oil drain interval is excessive	Verify the correct lubricating oil drain interval. Refer to Section 2.
OK ↓	
Lubricating oil leak (external)	Inspect the engine for external oil leaks. Tighten the capscrews, pipe plugs, and fittings. Replace gaskets, if necessary. Refer to Section V for specifications.
OK ↓	
Verify the oil consumption rate	Check the amount of oil added versus the mileage.
OK ↓	
Air compressor is pumping lubricating oil into the air system	Check the air lines for carbon buildup and lubricating oil. Refer to Section 7.
OK ↓	
Contact a Cummins Authorized Repair Facility	


Lubricating Oil Contaminated



## Lubricating Oil Loss



Lubricating Oil Pressure High




### Lubricating Oil Pressure Low

Cause	Correction
Engine angularity during operation exceeds specification	Refer to the Engine Data Sheet.
OK ↓	
Lubricating oil does <b>not</b> meet specifications for operating conditions	Change the oil and filters. Refer to Section 4. Use the oil recommended in Section V.
OK ↓	
Lubricating oil is diluted with water	Check for a missing dipstick, rain caps, or oil fill caps. Change the oil. Refer to the OEM service manual.
OK ↓	
Lubricating oil viscosity <b>not</b> correct	Make sure the correct lubricating oil is being used. Refer to Section 4.
OK ↓	
Lubricating oil filter is plugged	Change the oil and filter. Refer to Section 4. Verify the oil change interval is correct. Refer to Section 2.
OK ↓	
Lubricating oil is contaminated with coolant or fuel	Change the oil and filters. Refer to the Lubricating Oil Contaminated symptom tree.
OK ↓	
Lubricating oil leak (external)	Inspect the engine for external oil leaks. Tighten the capscrews, pipe plugs, and fittings. Replace gaskets, if necessary. Refer to Section V for specifications.
OK ↓	
Lubricating oil level is above or below specification	Check the oil level. Add or drain oil, if necessary. Refer to Section 3. Check the dipstick calibration.
OK ↓	


(Continued)




Lubricating Oil Pressure Low (Continued)



### Lubricating Oil Sludge in the Crankcase Excessive



### Smoke, Black — Excessive




### Smoke, White — Excessive

Cause	Correction
Starting procedure is <b>not</b> correct	Verify the correct starting procedure. Refer to Section 1.
OK ↓	
Engine is cold	Allow the engine to warm to operating temperature. If the engine will <b>not</b> reach operating temperature, refer to the Coolant Temperature Below Normal symptom tree.
OK ↓	
Engine is operating at low ambient temperature	Check the winterfront, shutters, and under-the-hood air. Use under-the-hood intake air in cold weather. Refer to Cold Weather Operation, Bulletin 3387266, and Section 1.
OK ↓	
Starting aid is malfunctioning	Check for correct operation of cold-starting aid. Refer to Cold Weather Starting Aids in Section 1. Refer to the manufacturer's instructions.
OK ↓	
Coolant temperature is below specification	Refer to the Coolant Temperature is Below Normal symptom tree.
OK ↓	
Fuel grade is <b>not</b> correct for the application, or the fuel quality is poor	Operate the engine from a tank of high-quality fuel. Refer to Fuel Recommendations and Specifications in Section V.
OK ↓	
Air intake or exhaust leaks	Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting. Refer to Section 3.
OK ↓	
Air intake system restriction is above specification	Check the air intake system for restriction. Clean or replace the air filter and inlet piping as necessary. Refer to Section 4.
OK ↓	

(Continued)

**Smoke, White — Excessive (Continued)**



### Turbocharger Leaks Engine Oil or Fuel

Cause	Correction
Engine is operating for extended periods under light or no-load conditions (slobbering)	Review the engine operating instructions. Refer to Section 1.
OK ↓	
Lubricating oil or fuel is entering the turbo-charger	Remove the intake and exhaust piping, and check for oil or fuel.
OK ↓	
Turbocharger drain line is restricted	Remove the turbocharger drain line, and check for restriction. Clean or replace the drain line. Refer to an Authorized Cummins Repair Facility.
OK ↓	
Turbocharger oil supply line loose or leaking	Check and tighten oil supply line fitting(s), if necessary. Refer to an Authorized Cummins Repair Facility.
OK ↓	
Contact a Cummins Authorized Repair Facility	

## NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## Section V - Maintenance Specifications

### Section Contents

	Page
<b>Air Intake System</b> .....	V-2
Specifications .....	V-2
<b>Capscrew Markings and Torque Values</b> .....	V-13
Capscrew Markings and Torque Values - Metric .....	V-14
Capscrew Markings and Torque Values - U.S. Customary .....	V-15
General Information .....	V-13
<b>Coolant Recommendations and Specifications</b> .....	V-5
Cooling System Additives .....	V-8
Cooling System Soluble Oils .....	V-10
Fully Formulated Coolant/Antifreeze .....	V-5
<b>Cooling System</b> .....	V-2
Specifications .....	V-2
<b>Cummins/Fleetguard® Specifications</b> .....	V-2
General Information .....	V-2
Fuel Filters .....	V-3
Lubricating Oil Filter .....	V-3
<b>Drive Belt Tension</b> .....	V-11
Tension Chart .....	V-11
<b>Electrical System</b> .....	V-2
Batteries (Specific Gravity) .....	V-2
Specifications .....	V-2
<b>Engine Component Torque Values</b> .....	V-11
Torque Table .....	V-11
<b>Exhaust System</b> .....	V-2
Specifications .....	V-2
<b>Fuel Recommendations and Specifications</b> .....	V-3
Fuel Recommendations .....	V-3
<b>Fuel System</b> .....	V-1
Specifications .....	V-1
<b>General Engine</b> .....	V-1
Specifications .....	V-1
<b>Lubricating Oil Recommendations and Specifications</b> .....	V-3
General Information .....	V-4
New Engine Break-in Oils .....	V-3
<b>Lubricating Oil System</b> .....	V-1
Specifications .....	V-1
<b>Sealants</b> .....	V-12
General Information .....	V-12



**THIS PAGE LEFT INTENTIONALLY BLANK**

## General Engine

### Specifications

#### General Engine Data

Bore .....	114 mm [4.49 in]
Stroke .....	135 mm [5.32 in]
Displacement .....	8.27 liters [504.7 C.I.D.]
Engine Weight (dry) with Standard Accessories .....	603 to 612 kg [1330 to 1350 lb]
Wet Weight .....	635 to 658 kg [1400 to 1450 lb]
Firing Order .....	1-5-3-6-2-4
Valve Clearances:	
Intake .....	0.30 mm [0.012 in]
Exhaust .....	0.61 mm [0.024 in]
Rotation, Viewed from the Front of the Engine .....	<b>Clockwise</b>
Compression Ratio:	
Naturally Aspirated .....	16.4:1
Turbocharged .....	17.3:1
Turbocharged/Aftercooled .....	16.5:1
Charge Air Cooled .....	18.0:1

## Fuel System

### Specifications

Maximum Fuel Filter Pressure Drop across Filters .....	34 kPa [5 psi]
Maximum Inlet Restriction to Fuel Transfer Pump .....	100 mm Hg [4 in Hg]
Maximum Allowable Return Line Restriction .....	518 mm Hg [20.4 in Hg]

## Lubricating Oil System

### Specifications

Oil Pressure:	
At Low Idle (minimum allowable) .....	69 kPa [10 psig]
At Rated Speed (minimum allowable) .....	207 kPa [30 psig]
Regulated Pressure .....	517 kPa [75 psi]
Oil Capacity of Standard Engine:	
Standard Oil Pan	
Pan <b>Only</b> .....	18.9 liters [20 qt]
Total System Capacity .....	19.9 liters [21 qt]
Standard Oil Pan with Cylinder Block Stiffener Plate	
Pan <b>Only</b> .....	19.9 liters [21 qt]
Oil Pan Low to High:	
Standard Oil Pan .....	15.1 to 18.9 liters [16 to 20 qt]
Standard Oil Pan with Cylinder Block Stiffener Plate .....	16.1 to 19.9 liters [17 to 21 qt]

**NOTE:** Some applications have a slightly different oil pan capacity. Contact the local Cummins Distributor if there are any questions.

Oil Pressure	
At Idle Speed - Minimum .....	69 kPa [10 psi]
Normal Operating Range .....	205 to 517 kPa [30 to 75 psi]
Maximum Allowable Oil Temperature .....	120°C [250°F]
Oil Pan Capacity High/Low .....	17/13 liters [18/14 qt]
Total System Capacity (excluding bypass filter) .....	21.9 liters [23.2 qt]

Maximum Operational Angularity of Oil Pan (see Engine Mounting)

Front Down .....	45 degrees
Front Up .....	35 degrees
Side to Side .....	45 degrees

## Cooling System

### Specifications

Coolant Capacity (engine <b>only</b> ) .....	10.9 liters [11.5 qt]
Standard Modulating Thermostat - Range .....	84 to 91°C [184 to 195°F]
Maximum Allowable Operating Temperature .....	100°C [212°F]
Minimum Recommended Operating Temperature .....	70°C [158°F]
Minimum Recommended Pressure Cap .....	50 kPa [7 psi]

## Air Intake System

### Specifications

Maximum Intake Restriction (clean air filter element) .....	254 mm H <sub>2</sub> O [10.0 in H <sub>2</sub> O]
Maximum Intake Restriction (dirty air filter element) .....	635 mm H <sub>2</sub> O [25.0 in H <sub>2</sub> O]

## Exhaust System

### Specifications

Maximum Exhaust Back Pressure .....	76 mm Hg [3 in Hg]
-------------------------------------	--------------------

## Electrical System

### Specifications

Recommended Battery Capacity

System Voltage	Ambient Temperature			
	-18°C [0°F]		-29°C [-20°F]	
	Cold Cranking Amperes	Reserve Capacity (Minutes) <sup>(1)</sup>	Cold Cranking Amperes	Reserve Capacity (Minutes) <sup>(1)</sup>
12 VDC	1250	360	1875	360
24 VDC <sup>(2)</sup>	625	180	900	180

1. The number of plates within a given battery size determines reserve capacity. Reserve capacity is the length of time for which a battery at 27°C [80°F] can supply 25 amperes at 10.5 volts or greater.

2. CCA ratings are based on two 12-VDC batteries in series.

### Batteries (Specific Gravity)

Specific Gravity at 27°C [80°F]	State of Charge
1.260 to 1.280	100%
1.230 to 1.250	75%
1.200 to 1.220	50%
1.170 to 1.190	25%
1.110 to 1.130	Discharged

## Cummins/Fleetguard® Specifications

### General Information

Fleetguard® is a subsidiary of Cummins Inc. Fleetguard® filters are developed through joint testing at Cummins and Fleetguard®. Fleetguard® filters are standard on new Cummins engines. Cummins Inc. recommends their use.

Fleetguard® products meet all Cummins Source Approval Test standards to provide the quality filtration necessary to achieve the engine's design life. If other brands are substituted, insist on products that the supplier has tested to meet Cummins high-quality standards.

Cummins can **not** be responsible for problems caused by nongenuine filters that do **not** meet Cummins performance or durability requirements.

#### Fuel Filters

Fuel Filter:

- Cummins Part Number 3931063
- Fleetguard® Part Number FF5052.

Fuel-Water Separator:

- Cummins Part Number 3930942
- Fleetguard® Part Number FS1280.

#### Lubricating Oil Filter

- Cummins Part Number 3401544
- Fleetguard® Part Number LF9009.

## Fuel Recommendations and Specifications

### Fuel Recommendations

#### ▲ WARNING ▲

Do not mix gasoline, alcohol, or gasohol with diesel fuel. This mixture can cause an explosion.

#### ▲ CAUTION ▲

Due to the precise tolerances of diesel injection systems, it is extremely important that the fuel be kept clean and free of dirt or water. Dirt or water in the system can cause severe damage to both the fuel pump and the fuel injectors.

#### ▲ CAUTION ▲

Lighter fuels can reduce fuel economy and can possibly damage the fuel injection pump.

Cummins Engine Company, Inc. recommends the use of ASTM No. 2D fuel. The use of No. 2D fuel will result in optimum engine performance.

At operating temperatures below 0°C [32°F], acceptable performance can be obtained by using blends of No. 2D and No. 1D.

The viscosity of the fuel **must** be kept above 1.3 cSt at 40°C [104°F] to provide adequate fuel system lubrication.

The following chart lists acceptable alternate fuels for C8.3 Series engines.

Acceptable Substitute Fuels - Cummins C8.3 Fuel System									
No. 1D Diesel(1)(2)	No. 2D Diesel	No. 1K Kerosene	Jet-A	Jet-A1	JP-5	JP-8	Jet-B	JP-4	CITE
OK	OK	OK	OK	OK	OK	OK	NOT OK	NOT OK	NOT OK
<p>1. Any adjustment to compensate for reduced performance with a fuel system using alternate fuel is <b>not</b> warrantable.</p> <p>2. Winter blend fuels, such as those found at commercial fuel dispensing outlets, are combinations of No. 1D and No. 2D diesel fuel and are acceptable.</p>									

Additional information for fuel recommendations and specifications can be found in Fuel for Cummins Engines, Bulletin No. 3379001. See the ordering information in the back of this manual.

## Lubricating Oil Recommendations and Specifications

### New Engine Break-in Oils

#### ▲ CAUTION ▲

A sulfated ash limit of 1.85 percent has been placed on all engine lubricating oils recommended for use in Cummins engines. Higher ash oils can cause valve and/or piston damage and lead to excessive oil consumption.

**△ CAUTION △**

**The use of a synthetic-based oil does not justify extended oil change intervals. Extended oil change intervals can decrease engine life due to factors such as corrosion, deposits, and wear.**

Special “break-in” engine lubricating oils are **not** recommended for new or rebuilt Cummins engines. Use the same type of oil during the “break-in” as used in normal operation.

Additional information regarding lubricating oil availability throughout the world is available in the E.M.A. Lubricating Oils Data Book for Heavy-Duty Automotive and Industrial Engines. The data book can be ordered from the Engine Manufacturers Association, One Illinois Center, 111 East Wacker Drive, Chicago, IL U.S.A. 60601. The telephone number is (312) 644-6610.

**Arctic Operation Engine Oil**

If an engine is operated in ambient temperatures consistently below -23°C [-9°F], and there are no provisions to keep the engine warm when it is **not** in operation, use a synthetic CE/SF or higher API classification engine oil with adequate low-temperature properties such as 5W-20 or 5W-30.

The oil supplier is responsible for meeting the performance service specification represented with its product.

**General Information**

Midrange engines with 1999 U.S.A. certification will have 500-hour maximum oil drain intervals using CES20071 (CH-4) or better lubricating oil.

Non-U.S.A. certified engines will have 500-hour oil drain intervals using CES20071 (CH-4) or better lubricating oil.

The use of quality engine lubricating oils, combined with appropriate oil drain and filter change intervals, are critical factors in maintaining engine performance and durability.


Cummins Engine Company, Inc. recommends the use of a high-quality SAE 15W-40 multiviscosity heavy-duty engine oil, such as Cummins Premium Blue®, that meets the requirements of Cummins Engineering Specification CES20071 or CES20076, or the American Petroleum Institute (API) performance classification CG-4 or CH-4.

**NOTE:** In areas where CG-4 or CH-4 lubricating oils are **not** available, CES20075 can be used but the lubricating oil change interval **must** be reduced to 12,070 km [7500 mi], or 250 hours.

A sulfated ash limit of 1.0 mass percent is suggested for optimum valve and piston deposit and oil consumption control. The sulfated ash **must not** exceed 1.85 mass percent.

For further details and discussion of engine lubricating oils for Cummins engines, refer to Cummins Engine Oil Recommendations, Bulletin No. 3810340, or a Cummins Authorized Repair Facility.


The use of low-viscosity oils, such as 10W or 10W-30, can be used to aid in starting the engine and in providing sufficient oil flow at ambient temperatures below -5°C [23°F]. However, continuous use of low-viscosity oils can decrease engine life due to wear. Refer to the accompanying chart.



The API service symbols are shown in the accompanying illustration. The upper half of the symbol displays the appropriate oil categories.

The lower half can contain a description of oil energy conserving features.


The center section identifies the SAE oil viscosity grade.



As the engine oil becomes contaminated, essential oil additives are depleted. Lubricating oils protect the engine as long as these additives are functioning properly. Progressive contamination between oil and filter change intervals is normal. The amount of contamination will vary depending on the operation of the engine, kilometers or [miles] on the oil, fuel consumed, and new oil added.

Extending oil and filter change intervals beyond the recommendations will decrease engine life due to factors such as corrosion, deposits, and wear.


Refer to the Oil Drain Interval Chart in this section to determine which oil drain interval to use for an application.



## Coolant Recommendations and Specifications

### Fully Formulated Coolant/Antifreeze

Cummins Engine Company, Inc. recommends using either a 50/50 mixture of high-quality water and fully formulated antifreeze or fully formulated coolant when filling the cooling system. The fully formulated antifreeze or coolant **must** meet TMC RP 329 or TMC RP 330 specifications.




Water Quality	
Calcium Magnesium (Hardness)	Maximum 170 ppm as ( $\text{CaCO}_3 + \text{MgCO}_3$ )
Chloride	40 ppm as(Cl)
Sulfur	100 ppm as ( $\text{SO}_4$ )

18200001


### ⚠ CAUTION ⚠

High-quality water is important for cooling system performance. Excessive levels of calcium and magnesium contribute to scaling problems, and excessive levels of chlorides and sulfates cause cooling system corrosion.




oi805vn

Cummins Engine Company, Inc. recommends using Fleetguard™ Compleat. It is available in both glycol forms (ethylene and propylene) and complies with TMC standards.



oi801wh

Fully formulated antifreeze **must** be mixed with high-quality water at a 50/50 ratio (40- to 60-percent working range). A 50/50 mixture of antifreeze and water has a  $-36^{\circ}\text{C}$  [ $-33^{\circ}\text{F}$ ] freezing point and a  $110^{\circ}\text{C}$  [ $230^{\circ}\text{F}$ ] boiling point, which is adequate for North America. The actual lowest freezing point of ethylene glycol antifreeze is at 68 percent. Using higher concentrations of antifreeze will raise the freezing point of the solution and increase the possibility of a silicate gel problem.




ra8toda

A refractometer **must** be used to measure the freezing point of the coolant accurately.

**C8.3 Industrial**  
**Section V - Maintenance Specifications**

Do **not** use a floating ball hydrometer. Use of a floating ball hydrometer can give an incorrect reading.

**Coolant Recommendations and Specifications**  
**Page V-7**





### Specifications

Use a low-silicate antifreeze that meets ASTM4985 test (GM6038M specification) criteria.

### Concentration

Antifreeze **must** be used in any climate for both freezing- and boiling-point protection. Cummins recommends a 50-percent concentration level (40- to 60-percent range) of ethylene glycol or propylene glycol in most climates. Antifreeze at 68-percent concentration provides the maximum freeze protection and **must never** be exceeded under any condition. Antifreeze protection decreases above 68 percent.

**Ethylene Glycol**  
40% equals -23°C [-9°F]  
50% equals -37°C [-35°F]  
60% equals -54°C [-65°F]  
68% equals -71°C [-96°F]

**Propylene Glycol**  
40% equals -21°C [-6°F]  
50% equals -33°C [-27°F]  
60% equals -49°C [-56°F]  
68% equals -63°C [-81°F]

### Concentration Testing

Antifreeze concentration **must** be checked using a refractometer (such as Fleetguard® Part No. CC2800). “Floating-Ball”-type density testers or hydrometers are **not** accurate enough for use with heavy-duty diesel cooling systems.

### Coolant Change Recommendation

The coolant **must** be drained and replaced every 2 years or 385,000 km [239,227 mi] to eliminate buildup of harmful chemicals.

### Cooling System Additives

#### Supplemental Coolant Additives (SCA)

Supplemental coolant additives (SCA) are recommended for all Cummins cooling systems. Antifreeze alone does **not** provide sufficient protection for heavy-duty diesel engines.

#### DCA4

DCA4 is the recommended SCA for all Cummins engines. Other brands can be used if they provide adequate engine protection and do **not** cause seal or gasket degradation or corrosion/fouling.

#### SCA Concentration

The recommended concentration level of DCA4 is 1.5 units for every 3.7 liters [1 gal]. The DCA4 concentration **must never** exceed 3.0 units for every 3.7 liters [1 gal] nor fall below 1.2 units for every 3.7 liters [1 gal].

#### DCA4 Filter Change Interval

Supplemental coolant additives deplete during normal engine operation. Cummins recommends that the level be maintained by installation of a service coolant filter on the engine at every 10,000-km [6214 mi], 250-hours, or 3-month interval.

#### DCA4 Concentration Test

As noted above, the primary method is to maintain proper DCA4 concentration levels by changing the service coolant filter at every 10,000 km [6214 mi], 250 hours, or 3 months. Fleetguard® DCA4 “dipstick” test kit, Part No. CC2626, or Fleetguard® Monitor C™, Part No. CC2700, **must** be used if testing is deemed necessary due to one of the following reasons:

- Addition of untreated make-up coolant in excess of 5.7 liters [6 qt] between maintenance intervals
- Troubleshooting of cooling system problems in the fleet (such as corrosion or seal leakage)
- An optional program in some fleets to monitor SCA levels to determine if maintenance intervals are acceptable.

**NOTE:** The practice of using a test kit to determine when to add or change the coolant filter is specifically **not** recommended. No other test kit (such as Fleetguard® titration test kit, Part No. 3300846-S or 3825379-S) can be used on Cummins engines with DCA4.

#### DCA4 Unit Maintenance Guide

Fleetguard® Part No.	Cummins Part No.	DCA4 Units
<b>DCA4 Liquid</b>		
DCA 60L	3315459	4*
<b>DCA4 Filter</b>		

(Continued)


Fleetguard® Part No.	Cummins Part No.	DCA4 Units
WF-2070	3318157	2
WF-2071	3315116	4
WF-2072	3318201	6
WF-2073	3315115	8
WF-2074	3316053	12
WF-2077	None	0
*If DCA 60L is used, do <b>not</b> use a coolant filter that contains coolant additives. The combination of liquid and filter coolant additives will result in overconcentration.		

#### DCA4 Maintenance Guide

Maintenance Intervals		
Total Cooling System Capacity	Initial Charge (B)	10,000 km [6000 mi], 250 Hours, or 3 Months
30 to 57 liters [8 to 15 gal]	WF-2074	WF-2070

#### Notes:


- Consult the vehicle equipment manufacturer's maintenance information for the total cooling system capacity.
- After draining and replacing the coolant, install the initial per-charge coolant filter to provide the recommended level of DCA4 concentration.
- Change the coolant filter at regular intervals to protect the cooling system.
- Check the coolant additive concentration regularly. Check the cooling system using Fleetguard® DCA4 **only** with DCA4 coolant test kit, Part No.CC-2626.



#### Cooling System Sealing Additives

Do **not** use sealing additives in the cooling system. The use of sealing additives will

- Build up in coolant low-flow areas
- Clog coolant filters
- Plug radiator and oil cooler
- Possibly damage water pump seal.



#### Cooling System Soluble Oils

Do **not** use soluble oils in the cooling system. The use of soluble oils will

- Allow cylinder liner pitting
- Corrode brass and copper
- Damage heat transfer surfaces
- Damage seals and hoses.

## Drive Belt Tension

### Tension Chart

SAE Belt Size	Belt Tension Gauge Part No.		Belt Tension New		Belt Tension Range Used*	
	Click-type	Burroughs	N	lbf	N	lbf
0.380 in	3822524		620	140	270 to 490	60 to 110
0.440 in	3822524		620	140	270 to 490	60 to 110
1/2 in	3822524	ST-1138	620	140	270 to 490	60 to 110
11/16 in	3822524	ST-1138	620	140	270 to 490	60 to 110
3/4 in	3822524	ST-1138	620	140	270 to 490	60 to 110
7/8 in	3822524	ST-1138	620	140	270 to 490	60 to 110
4 rib	3822524	ST-1138	620	140	270 to 490	60 to 110
5 rib	3822524	ST-1138	670	150	270 to 530	60 to 120
6 rib	3822525	ST-1293	710	160	290 to 580	65 to 130
8 rib	3822525	ST-1293	890	200	360 to 710	80 to 160
10 rib	3822525	3823138	1110	250	440 to 890	100 to 200
12 rib	3822525	3823138	1330	300	530 to 1070	120 to 240
12 rib K section	3822525	3823138	1330	300	890 to 1070	200 to 240

**NOTE:** This chart does not apply to automatic belt tensioners.

\* A belt is considered used if it has been in service for ten minutes or longer.

\* If used belt tension is less than the minimum value, tighten the belt to the maximum used belt value.

## Engine Component Torque Values

### Torque Table

Component	Wrench Size	Torque Value		
		N•m	ft-lb	in-lb
Aftercooler mounting	10 mm	24	18	
Aftercooler water hose clamp	8 mm	5		44
Alternator link (Delco 10-15 SI)	13 mm	24	18	
Alternator link (Delco 20-27 SI)	3/4 in	43	32	
Alternator mtg. bolt 10-15 SI	15 mm	43	32	
Alternator mtg. 27 SI	18 mm	77	57	
Alternator support (upper)	10 mm	24	18	
Belt tensioner flat bracket	Allen 5 mm	24	18	
Belt tensioner mounting	15 mm	43	32	
Crankshaft damper and pulley	15 mm	137	101	
Crossover clamp	5/16 in	5		44
Tee bolt type clamp	11 mm	8		71
Exhaust outlet pipe, v-band clamp	7/16 in	8		71
Fan bracket mounting	10 mm	24	18	
Fan pulley	10 mm	24	18	
Fan pulley	13 mm	43	32	
Fuel filter	75 to 85 mm	Install as specified by filter manufacturer.		
Fuel filter adapter nut	24 mm	32	24	
Lubricating oil filter	75 to 85 mm	3/4 of a turn after contact		
Lubricating oil cooler assembly	10 mm	24	18	
Lubricating oil pan drain plug	17 mm	80	59	

(Continued)

Component	Wrench Size	Torque Value		
		N•m	ft-lb	in-lb
Lubricating oil pan heater plug	27 mm	80	59	
Lubricating oil pressure regulator plug	19 mm	80	59	
Starter mounting	10 mm	43	32	
Thermostat housing	10 mm	24	18	
Water inlet connection	15 mm	43	32	
Water pump mounting	13 mm	24	18	
Rocker lever (valve) cover	15 mm	12		106
Water-in-fuel (WIF) sensor	19 mm	Hand-tighten		

## Sealants

### General Information

Use either the sealants listed below or sealants containing equivalent properties.

Item Description	Sealing Method
1. Pipe plugs	Precoated Teflon™ or pipe sealer
2. Gaskets	No sealant required
3. Cups plugs	Loctite 277 or Cummins sealant, Part Number 3375068
4. O-rings	Lubriplate™ 105
5. Rear camshaft expansion plug	Loctite 277 or Cummins sealant, Part Number 3375068
6. Fuel pump studs	Loctite 242
7. Turbocharger drain (in block)	Loctite 277 or Cummins sealant, Part Number 3375068
8. Dipstick tube (in block)	Loctite 277 or Cummins sealant, Part Number 3375068
9. Wet flywheel housing to block	Three-Bond™ sealant, Part Number 3823494
10. Rear seal (in rear cover)	No sealant required
11. Timing pin housing capscrews	No sealant required
12. Side oil fill	Loctite 277 or Cummins sealant, Part Number 3375068
13. Oil pan at gear housing joint	Three-Bond™ sealant, Part Number 3823494

## Capscrew Markings and Torque Values



### General Information



When replacing capscrews, always use a capscrew of the same measurement and strength as the capscrew being replaced. Using the wrong capscrews can result in engine damage.

Metric capscrews and nuts are identified by the grade number stamped on the head of the capscrew or on the surface of the nuts. U.S. Customary capscrews are identified by radial lines stamped on the head of the capscrew.







The following examples indicate how capscrews are identified:






### NOTES:

1. **Always** use the torque values listed in the following tables when specific torque values are **not** available.
2. Do **not** use the torque values in place of those specified in other sections of this manual.
3. The torque values in the table are based on the use of lubricated threads.
4. When the ft-lb value is less than 10, convert the ft-lb value to in-lb to obtain a better torque with an in-lb torque wrench. Example: 6 ft-lb equals 72 in-lb.

**Capscrew Markings and Torque Values - Metric**

Commercial Steel Class													
8.8					10.9					12.9			
Capscrew Head Markings													
													
Body Size		Torque				Torque				Torque			
Diameter		Cast Iron		Aluminum		Cast Iron		Aluminum		Cast Iron		Aluminum	
mm		N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
6		9	5	7	4	13	10	7	4	14	9	7	4
7		14	9	11	7	18	14	11	7	23	18	11	7
8		23	17	18	14	33	25	18	14	40	29	18	14
10		45	33	30	25	65	50	30	25	70	50	30	25
12		80	60	55	40	115	85	55	40	125	95	55	40
14		125	90	90	65	180	133	90	65	195	145	90	65
16		195	140	140	100	280	200	140	100	290	210	140	100
18		280	200	180	135	390	285	180	135	400	290	180	135
20		400	290	—	—	550	400	—	—	—	—	—	—

## Capscrew Markings and Torque Values - U.S. Customary

SAE Grade Number			5		8			
Capscrew Head Markings								
These are all SAE Grade 5 (3 line)								
								
Capscrew Torque - Grade 5 Capscrew					Capscrew Torque - Grade 8 Capscrew			
Capscrew Body Size	Cast Iron		Aluminum		Cast Iron		Aluminum	
	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb	N•m	ft-lb
1/4 - 20	9	7	8	6	15	11	8	6
1/4 - 28	12	9	9	7	18	13	9	7
5/16 - 18	20	15	16	12	30	22	16	12
5/16 - 24	23	17	19	14	33	24	19	14
3/8 - 16	40	30	25	20	55	40	25	20
3/8 - 24	40	30	35	25	60	45	35	25
7/16 - 14	60	45	45	35	90	65	45	35
7/16 - 20	65	50	55	40	95	70	55	40
1/2 - 13	95	70	75	55	130	95	75	55
1/2 - 20	100	75	80	60	150	110	80	60
9/16 - 12	135	100	110	80	190	140	110	80
9/16 - 18	150	110	115	85	210	155	115	85
5/8 - 11	180	135	150	110	255	190	150	110
5/8 - 18	210	155	160	120	290	215	160	120
3/4 - 10	325	240	255	190	460	340	255	190
3/4 - 16	365	270	285	210	515	380	285	210
7/8 - 9	490	360	380	280	745	550	380	280
7/8 - 14	530	390	420	310	825	610	420	310
1 - 8	720	530	570	420	1100	820	570	420
1 - 14	800	590	650	480	1200	890	650	480



## This image shows a single sheet of white paper with horizontal blue ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## Section W - Warranty

### Section Contents

	Page
California Emission Control System Warranty, Off-Highway .....	W-6
Off-Highway Engines International .....	W-4
Off-Highway Engines United States and Canada .....	W-1

**THIS PAGE LEFT INTENTIONALLY BLANK**

## Off-Highway Engines United States and Canada

### Coverage

#### Products Warranted

This warranty applies to new Engines sold by Cummins and delivered to the first user on or after April 1, 1999, that are used in industrial (off-highway) applications in the United States\* and Canada, except for Engines used in marine, generator drive and certain defense applications, for which different warranty coverage is provided.

#### Base Engine Warranty

This warranty covers any failures of the Engine, under normal use and service, which result from a defect in material or factory workmanship (Warrantable Failures).

Coverage begins with the sale of the Engine by Cummins. Coverage continues for two years or 2,000 hours of operation, whichever occurs first, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first. If the 2,000 hour limit is exceeded during the first year, Coverage continues until the end of the first year.

#### Extended Major Components Warranty

The Extended Major Components Warranty covers Warrantable Failures of the Engine cylinder block, camshaft, crankshaft and connecting rods (Covered Parts).

Bushing and bearing failures are not covered.

This Coverage begins with the expiration of the Base Engine Warranty and ends three years or 10,000 hours of operation from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

#### Consumer Products

The warranty on Consumer Products in the United States is a LIMITED warranty. **CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Any implied warranties applicable to Consumer Products in the United States terminate concurrently with the expiration of the express warranties applicable to the product. In the United States, some states do not allow the exclusion of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the limitations or exclusions herein may not apply to you.

**These warranties are made to all Owners in the chain of distribution, and Coverage continues to all subsequent Owners until the end of the periods of Coverage.**

### Cummins' Responsibilities

#### During The Base Engine Warranty

Cummins will pay for all parts and labor needed to repair the damage to the Engine resulting from a Warrantable Failure.

Cummins will pay for the lubricating oil, antifreeze, filter elements, and other maintenance items that are not reusable due to the Warrantable Failure.

Cummins will pay reasonable costs for mechanics to travel to and from the equipment site, including meals, mileage and lodging, when the repair is performed at the site of the failure.

Cummins will pay reasonable labor costs for Engine removal and reinstallation when necessary to repair a Warrantable Failure.

#### During The Extended Major Components Warranty

Cummins will pay for the repair or, at its option, replacement of the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered part.

### Owner's Responsibilities

#### During The Base Engine Warranty

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items provided during warranty repairs unless such items are not reusable due to the Warrantable Failure.

#### During The Extended Major Components Warranty

Owner is responsible for the cost of all labor needed to repair the Engine, including the labor to remove and reinstall the Engine. When Cummins elects to repair a part instead of replacing it, Owner is not responsible for the labor needed

to repair the part.

Owner is responsible for the cost of all parts required for the repair except for the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during repair of a Warrantable Failure.

### **During The Base Engine and Extended Major Components Warranties**

Owner is responsible for the operation and maintenance of the Engine as specified in the applicable Cummins Operation and Maintenance Manual. Owner is also responsible for providing proof that all recommended maintenance has been performed.

Before the expiration of the applicable warranty, Owner must notify a Cummins distributor, authorized dealer or other repair location approved by Cummins of any Warrantable Failure and make the Engine available for repair by such facility. Locations in the United States and Canada are listed in the Cummins Off Highway Authorized Dealer Directory.

Owner is responsible for communication expenses, meals, lodging and similar costs incurred as a result of a Warrantable Failure.

Owner is responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all applicable taxes, all business costs and other losses resulting from a Warrantable Failure.

### **Limitations**

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolants or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect oil or fuel or by water, dirt or other contaminants in the fuel or oil.

For power units and fire pumps (package units), this warranty applies to accessories, except for clutches and filters, supplied by Cummins which bear the name of another company.

Except for power units and fire pumps, this warranty does not apply to accessories which bear the name of another company. Such non-warranted accessories include, but are not limited to: alternators, starters, fans\*, air conditioning compressors, clutches, filters, transmissions, torque converters, steering pumps, and non-Cummins fan drives, engine compression brakes and air compressors.

Cummins Compusave units are covered by a separate warranty.

Before a claim for excessive oil consumption will be considered, Owner must submit adequate documentation to show that consumption exceeds Cummins published standards.

Failures of belts and hoses supplied by Cummins are not covered beyond the first 500 hours or one year of operation, whichever occurs first.

Parts used to repair a Warrantable Failure may be new Cummins parts, Cummins-approved rebuilt parts, or repaired parts. Cummins is not responsible for failures resulting from the use of parts not approved by Cummins.

A new Cummins or Cummins-approved rebuilt part used to repair a Warrantable Failure assumes the identity of the part it replaced and is entitled to the remaining coverage hereunder.

**CUMMINS DOES NOT COVER WEAR OR WEAROUT OF COVERED PARTS.**

**CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

**THESE WARRANTIES SET FORTH HEREIN ARE THE SOLE WARRANTIES MADE BY CUMMINS IN REGARD TO THESE ENGINES. CUMMINS MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

### **Emission Warranty**

#### **Products Warranted**

This emission warranty applies to new Engines marketed by Cummins that are used in the United States\* in vehicles designed for Industrial off-highway use. This warranty applies to Engines delivered to the ultimate purchaser on or after April 1, 1999 for engines up to 750 horsepower, on or after January 1, 2000 for engines 751 horsepower and over.

## **Coverage**

Cummins warrants to the ultimate purchaser and each subsequent purchaser that the Engine is designed, built and equipped so as to conform at the time of sale by Cummins with all U.S. Federal emission regulations applicable at the time of manufacture and that it is free from defects in workmanship or material which would cause it not to meet these regulations within the longer of the following periods: (A) Five years or 3,000 hours of operation, whichever occurs first, as measured from the date of delivery of the Engine to the ultimate purchaser, or (B) The Base Engine Warranty.

If the vehicle in which the Engine is installed is registered in the state of California, a separate California Emission Warranty also applies.

## **Limitations**

Failures, other than those resulting from defects in materials, or workmanship, are not covered by this warranty.

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolant or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect fuel or by water, dirt or other contaminants in the fuel.

Cummins is not responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all business costs or other losses resulting from a Warrantable Failure.

### **CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

\* Includes American Samoa, the Commonwealth of Northern Mariana Islands, Guam, Puerto Rico, and the U.S. Virgin Islands.

\*\* Alternators, starters, and fans ARE covered for the duration of the base engine warranty on B3.3 engines.

## Off-Highway Engines International

### Coverage

#### PRODUCTS WARRANTED

This warranty applies to new Engines sold by Cummins and delivered to the first user on or after April 1, 1999, that are used in industrial (off-highway) applications anywhere in the world where Cummins-approved service is available, except the United States\* and Canada. Different warranty coverage is provided for Engines used in marine, generator drive and certain defense applications.

#### BASE ENGINE WARRANTY

This warranty covers any failures of the Engine, under normal use and service, which result from a defect in material or factory workmanship (Warrantable Failure).

Coverage begins with the sale of the Engine by Cummins. Coverage continues for two years or 2,000 hours of operation, whichever occurs first, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or when the Engine has been operated for 50 hours, whichever occurs first. If the 2,000 hour limit is exceeded during the first year, coverage continues until the end of the first year.

#### EXTENDED MAJOR COMPONENTS WARRANTY

The Extended Major Components Warranty covers Warrantable Failures of the Engine cylinder block, camshaft, crankshaft and connecting rods (Covered Parts).

Bushing and bearing failures are not covered.

This coverage begins with the expiration of the Base Engine Warranty and ends three years or 10,000 hours of operation, from the date of delivery of the Engine to the first user, or from the date the unit is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

**These warranties are made to all Owners in the chain of distribution, and Coverage continues to all subsequent Owners until the end of the periods of Coverage.**

### Cummins' Responsibilities

#### DURING THE BASE ENGINE WARRANTY

Cummins will pay for all parts and labor needed to repair the damage to the Engine resulting from a Warrantable Failure.

Cummins will pay for the lubricating oil, antifreeze, filter elements, and other maintenance items that are not reusable due to a Warrantable Failure.

Cummins will pay reasonable costs for mechanics to travel to and from the equipment site, including meals, mileage and lodging, when the repair is performed at the site of the failure.

Cummins will pay reasonable labor costs for Engine removal and reinstallation when necessary to repair a Warrantable Failure.

#### DURING THE EXTENDED MAJOR COMPONENTS WARRANTY

Cummins will pay for the repair or, at its option, replacement of the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered part.

### Owner's Responsibilities

#### DURING THE BASE ENGINE WARRANTY

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during warranty repairs unless such items are not reusable due to the Warrantable Failure.

#### DURING THE EXTENDED MAJOR COMPONENTS WARRANTY

Owner is responsible for the cost of all labor needed to repair the Engine, including the labor to remove and reinstall the Engine. When Cummins elects to repair a part instead of replacing it, Owner is not responsible for the labor needed to repair the part.

Owner is responsible for the cost of all parts required for the repair except for the defective Covered Part and any Covered Part damaged by a Warrantable Failure of the defective Covered Part.

Owner is responsible for the cost of lubricating oil, antifreeze, filter elements and other maintenance items replaced during repair of a Warrantable Failure.

## **DURING THE BASE ENGINE AND EXTENDED MAJOR COMPONENTS WARRANTIES**

Owner is responsible for the operation and maintenance of the Engine as specified in the applicable Cummins Operation and Maintenance Manual. Owner is also responsible for providing proof that all recommended maintenance has been performed.

Before the expiration of the applicable warranty, Owner must notify a Cummins distributor, authorized dealer or other repair location approved by Cummins of any Warrantable Failure and make the product available for repair by such facility. Locations are listed in the Cummins International Sales and Service Directory.

Owner is responsible for communication expenses, meals, lodging and similar costs incurred as a result of a Warrantable Failure.

Owner is responsible for non-Engine repairs, "downtime" expenses, cargo damage, fines, all applicable taxes, all business costs and other losses resulting from a Warrantable Failure.

## **Limitations**

Cummins is not responsible for failures or damage resulting from what Cummins determines to be abuse or neglect, including, but not limited to: operation without adequate coolants or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or intake systems; improper storage, starting, warm-up, run-in or shutdown practices; unauthorized modifications of the Engine. Cummins is also not responsible for failures caused by incorrect oil or fuel or by water, dirt or other contaminants in the fuel or oil.

For power units and fire pumps (package units) the warranty applies to accessories, except for clutches and filters supplied by Cummins which bear the name of another company.

Starters, alternators, power steering pumps and non-Cummins air compressors supplied by Cummins on B or C Series Engines that are not supplied as part of a package unit are covered for six months\* from the date of delivery of the Engine to the first user, or the date the Engine is first leased, rented or loaned, or from when the Engine has been operated for 50 hours, whichever occurs first.

Except for the accessories noted previously, Cummins does not warrant accessories which bear the name of another company. Such non-warranted accessories include, but are not limited to: alternators, starters, fans\*, air conditioning compressors, clutches, filters, transmissions, torque converters, steering pumps, non-Cummins fan drives, and air cleaners.

Cummins Compusave units are covered by a separate warranty.

Before a claim for excessive oil consumption will be considered, Owner must submit adequate documentation to show that consumption exceeds Cummins published standards.

Failures of belts and hoses supplied by Cummins are not covered beyond the first 500 hours or one year of operation, whichever occurs first.

Parts used to repair a Warrantable Failure may be new Cummins parts, Cummins-approved rebuilt parts, or repaired parts. Cummins is not responsible for failures resulting from the use of parts not approved by Cummins.

A new Cummins or Cummins-approved rebuilt part used to repair a Warrantable Failure assumes the identity of the part it replaced and is entitled to the remaining coverage hereunder.

**CUMMINS DOES NOT COVER WEAR OR WEAROUT OF COVERED PARTS.**

**CUMMINS IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

**THESE WARRANTIES SET FORTH HEREIN ARE THE SOLE WARRANTIES MADE BY CUMMINS IN REGARD TO THESE ENGINES. CUMMINS MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OR OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

In case of consumer sales, in some countries, the Owner has statutory rights which cannot be affected or limited by the terms of this warranty.

Nothing in this warranty excludes or restricts any contractual rights the Owner may have against third parties.

\* Alternators, starters, and fans ARE covered for the duration of the base engine warranty on B3.3 engines.



## California Emission Control System Warranty, Off-Highway

### Products Warranted

This Emission Control System Warranty applies to off-road diesel engines certified with the California Air Resources Board beginning with the year 1996 for engines up to 750 horsepower, beginning with the year 2000 for 751 horsepower and over, marketed by Cummins, and registered in California for use in industrial off-highway applications.

### Your Warranty Rights and Obligations

The California Air Resources Board and Cummins Engine Company, Inc., are pleased to explain the emission control system warranty on your engine. In California, new off-road diesel engines must be designed, built and equipped to meet the State's stringent anti-smog standards. Cummins must warrant the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel injection system and the air induction system. Also included may be hoses, belts, connectors and other emission-related assemblies.

Where a warrantable condition exists, Cummins will repair your off-road diesel engine at no cost to you including diagnosis, parts and labor.

### Manufacturer's Warranty Coverage

This warranty coverage is provided for 5 years or 3,000 hours of engine operation, whichever first occurs from the date of delivery of the engine to the first user. If any emission-related part on your engine is defective, the part will be repaired or replaced by Cummins.

### Coverage

This emission control system warranty applies only to the following B5.9, QSB, QSC, QS9 and C8.3 emission control parts:

#### Fuel Pump

- Static Timing
- Delivery Valve
- Injection Control Valve Module

#### Intake Manifold

- Charge Air Cooler
- Aftercooler

#### Exhaust Manifold

#### Oxidation Catalyst

#### Electronic Control System

- Control Module
- Boost Pressure Sensor
- Coolant Temperature Sensor
- Fuel Pressure Sensor

#### Injectors

- Calibration
- Needle
- Nozzle
- Spring

#### Turbocharger

- Compressor Wheel
- Turbine Wheel
- Turbine Oil Seal
- Wastegate Valve

### Owner's Warranty Responsibilities

As the off-road diesel engine owner, you are responsible for the performance of the required maintenance listed in your Cummins Operation and Maintenance Manual. Cummins recommends that you retain all receipts covering maintenance on your off-road diesel engine, but Cummins cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your off-road diesel engine to a Cummins dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

As the off-road diesel engine owner, you should also be aware that Cummins may deny you warranty coverage if your off-road diesel engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

Your engine is designed to operate on diesel fuel only. Use of any other fuel may result in your engine no longer operating in compliance with California's emissions requirements.

If you have any questions regarding your warranty rights and responsibilities, you should contact Cummins Customer Assistance Department at 1-800-343-7357 (1-800-DIESELS) or the California Air Resources Board at 9528 Telstar Avenue, El Monte, CA 91731.

Prior to the expiration of the applicable warranty, Owner must give notice of any warranted emission control failure to a Cummins distributor, authorized dealer or other repair location approved by Cummins and deliver the engine to such facility for repair. Repair locations are listed in Cummins United States and Canada Service Directory.

Owner is responsible for incidental costs such as: communication expenses, meals, lodging incurred by Owner or employees of Owner as a result of a warrantable failure.

Owner is responsible for business costs and losses, "downtime" expenses, and cargo damage resulting from a warrantable failure. CUMMINS IS NOT RESPONSIBLE FOR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDE BUT ARE NOT LIMITED TO FINES, THEFT, VANDALISM OR COLLISIONS.

## **Replacement Parts**

Cummins recommends that any service parts used for maintenance, repair or replacement of emission control systems be new, genuine Cummins or Cummins approved rebuilt parts and assemblies, and that the engine be serviced by a Cummins distributor, authorized dealer or the repair location approved by Cummins. The owner may elect to have maintenance, replacement or repair of the emission control parts performed by a facility other than a Cummins distributor, an authorized dealer or a repair location approved by Cummins, and may elect to use parts other than new genuine Cummins or Cummins approved rebuilt parts and assemblies for such maintenance, replacement or repair; however, the cost of such service or parts will not be covered under this emission control system warranty.

## **Cummins Responsibilities**

Repairs and service will be performed by any Cummins distributor, authorized dealer or other repair location approved by Cummins using new, genuine Cummins or Cummins approved rebuilt parts and assemblies. Cummins will repair any of the emission control parts found by Cummins to be defective without charge for parts or labor (including diagnosis which results in determination that there has been a failure of a warranted emission control part).

## **Emergency Repairs**

In the case of an emergency where a Cummins distributor, authorized dealer, or other repair location approved by Cummins is not available, repairs may be performed by any available repair location using any replacement parts. Cummins will reimburse the Owner for expenses (including diagnosis), not to exceed the manufacturer's suggested retail price for all warranted parts replaced and labor charges based on the manufacturer's recommended time allowance for the warranty repair and the geographically appropriate hourly labor rate. A part not being available within 30 days or a repair not being complete within 30 days constitutes an emergency. Replaced parts and paid invoices must be presented at a Cummins authorized repair facility as a condition of reimbursement for emergency repairs not performed by a Cummins distributor, authorized dealer, or other repair location approved by Cummins.

## **Warranty Limitations**

Cummins is not responsible for failures resulting from Owner or operator abuse or neglect, such as: operation without adequate coolant, fuel or lubricants; overfueling; overspeeding; lack of maintenance of lubricating, cooling or air intake systems; improper storage, starting, warm-up, run-in or shutdown practices.

The manufacturer warrants to the ultimate purchaser and each subsequent purchaser that the engine is designed, built, and equipped so as to conform with all applicable regulations adopted by the Air Resources Board, and that it is free from defects in materials and workmanship which cause the failure of a warranted part.

Any warranted part which is not scheduled for replacement as required maintenance, or which is scheduled only for regular inspection to the effect of "repair or replace as necessary" is warranted for the warranty period.

Any warranted part which is scheduled for replacement as required maintenance is warranted for the period of time prior to the first scheduled replacement point for that part.

The owner will not be charged for diagnostic labor which leads to the determination that a warranted part is defective, if the diagnostic work is performed at a warranty station.


The manufacturer is liable for damages to other engine components caused by the failure under warranty of any warranted part.

Cummins is not responsible for failures resulting from improper repair or the use of parts which are not genuine Cummins or Cummins approved parts.

These warranties, together with the express commercial warranties and emission warranty are the sole warranties of Cummins. There are no other warranties, express or implied, or of merchantability or fitness for a particular purpose.

## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.






NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 15, COLUMBUS INDIANA

—POSTAGE WILL BE PAID BY ADDRESSEE—

CUMMINS INC.  
MAIL CODE 41302  
BOX 3005  
COLUMBUS, IN 47202-3005



**Do not use this form to order additional literature. Refer to  
Section L - Service Literature for literature information.**

Literature Survey Form

Bulletin No.: 4021330

We are always open to any suggestions or recommendations that will aid in improving our manuals. Use this postage paid survey form to evaluate this manual. Please check the appropriate response and use the space provided below to list any additional comments:

	Yes	No
Is the needed information easy to locate in the manual?	<input type="checkbox"/>	<input type="checkbox"/>
Is the information easy to read?	<input type="checkbox"/>	<input type="checkbox"/>
Is the information easy to understand?	<input type="checkbox"/>	<input type="checkbox"/>
Does the information sufficiently cover the subject?	<input type="checkbox"/>	<input type="checkbox"/>
Are subjects in the Index specific enough to locate in the manual?	<input type="checkbox"/>	<input type="checkbox"/>
Are the important points sufficiently emphasized?	<input type="checkbox"/>	<input type="checkbox"/>
Are the illustrations easy to understand?	<input type="checkbox"/>	<input type="checkbox"/>
Does the text support the operation being illustrated?	<input type="checkbox"/>	<input type="checkbox"/>
Do you use the Table of Contents and Section Contents?	<input type="checkbox"/>	<input type="checkbox"/>
Do you use the Index?	<input type="checkbox"/>	<input type="checkbox"/>

Please provide comments on any response(s) marked No in this survey and on any suggestions you feel could improve our manuals.

Name:

Company:

Street Address:

City:  State/Province:

Country:  Zip/Postal Code:

Do not use this form to order additional literature. Refer to Section L - Service Literature for literature information.

**Cummins Inc.**

Box 3005  
Columbus, Indiana, U.S.A., 47202

Registered Office

**Cummins Engine Company, Ltd.**

46-50 Coombe Road  
New Malden,  
Surrey KT3 4QL,  
England  
Registration 573951 England

Copyright© 2002  
Cummins Inc.








NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 15, COLUMBUS INDIANA

—POSTAGE WILL BE PAID BY ADDRESSEE—

Cummins Inc.  
Product Registration Dept. (CAC)  
P O Box 3005 M/C 91200  
Columbus, IN 47202-3005



In order to serve you better it is very important that you fill out and return this card **within** 30 days of purchase.

---

Customer Name \_\_\_\_\_

Address \_\_\_\_\_

City / State \_\_\_\_\_

Zip Code \_\_\_\_\_

Home Phone Number (\_\_\_\_)\_\_\_\_\_

Truck Phone / Cell Phone (\_\_\_\_)\_\_\_\_\_

E-mail Address \_\_\_\_\_

Engine Serial Number \_\_\_\_\_

Date Purchased \_\_\_\_/\_\_\_\_/\_\_\_\_ VIN # \_\_\_\_\_

THANK YOU!!

<b>About the Manual</b> .....	i-1	<b>Oil Heaters</b> .....	M-3
General Information .....	i-1	<b>Prelubrication Systems</b> .....	M-3
<b>Acronyms and Abbreviations</b> .....	i-7	<b>Radiators</b> .....	M-3
General Information .....	i-7	<b>Throttle Assemblies</b> .....	M-3
<b>Additional Service Literature</b> .....	L-1	<b>Torque Converters</b> .....	M-3
General Information .....	L-1	<b>Coolant Filter</b> .....	5-1
<b>Air Cleaner Restriction</b> .....	4-1	Clean .....	5-1
Maintenance Check .....	4-1	Install .....	5-2
<b>Air Compressor</b> .....	4-1	Remove .....	5-1
Maintenance Check .....	4-1	<b>Coolant Level</b> .....	3-2
<b>Air Compressor Discharge Lines</b> .....	7-1	Maintenance Check .....	3-2
General Information .....	7-1	<b>Coolant Recommendations and Specifications</b> .....	V-5
Maintenance Check .....	7-1	Cooling System Additives .....	V-8
<b>Air in Fuel</b> .....	A-19	Cooling System Soluble Oils .....	V-10
General Information .....	A-19	Fully Formulated Coolant/Antifreeze.....	V-5
Test .....	A-20	<b>Cooling Fan Belt Tensioner</b> .....	A-7
<b>Air Intake Piping</b> .....	3-2	Inspect for Reuse .....	A-8
Maintenance Check .....	3-2	Install .....	A-8
<b>Air Intake System</b> .....	V-2	Maintenance Check .....	6-1
Specifications .....	V-2	Preparatory Steps.....	A-7
<b>Air Tanks and Reservoirs</b> .....	3-7	Remove .....	A-7
Drain .....	3-7	<b>Cooling System</b> .....	7-3
<b>Alternator</b> .....	A-1	Drain .....	7-3
Install .....	A-2	Fill .....	7-5
Preparatory Steps .....	A-1	Flush .....	7-4
Remove .....	A-1	Specifications .....	V-2
<b>California Emission Control System Warranty, Off-Highway</b> .....	W-6	<b>Crankcase Breather Tube</b> .....	3-6
<b>Capscrew Markings and Torque Values</b> .....	V-13	Maintenance Check .....	3-6
Capscrew Markings and Torque Values - Metric .....	V-14	<b>Cummins/Fleetguard® Specifications</b> .....	V-2
Capscrew Markings and Torque Values - U.S. Customary ....	V-15	General Information .....	V-2
General Information .....	V-13	Fuel Filters .....	V-3
<b>Charge-Air Cooler</b> .....	A-2	Lubricating Oil Filter .....	V-3
Clean .....	A-3	<b>Daily Maintenance Procedures - Overview</b> .....	3-1
General Information .....	A-2	Engine Operation Report .....	3-1
Initial Check .....	A-2	General Information .....	3-1
Install .....	A-4	Unusual Engine Noise .....	3-1
Leak Test .....	A-5	<b>Distributors - International</b> .....	S-18
Maintenance Check .....	4-2	Locations .....	S-18
Pressure Test .....	A-4	<b>Distributors and Branches</b> .....	S-3
Remove .....	A-3	Australia .....	S-12
Temperature Differential Test .....	A-6	Canada .....	S-10
<b>Charge-Air Piping</b> .....	4-2	New Zealand .....	S-14
Maintenance Check .....	4-2	United States .....	S-3
<b>Cold Weather Starting</b> .....	1-5	<b>Division and Regional Offices</b> .....	S-2
General Information .....	1-5	Locations .....	S-2
Using Starting Aids .....	1-5	<b>Drive Belt, Cooling Fan</b> .....	A-6
<b>Component Manufacturers' Addresses</b> .....	M-1	Inspect for Reuse .....	A-7
Air Compressors .....	M-1	Install .....	A-7
Air Cylinders .....	M-1	Remove .....	A-6
Air Heaters.....	M-1	<b>Drive Belt Tension</b> .....	V-11
Air Starting Motors .....	M-1	Tension Chart .....	V-11
Alternators .....	M-1	<b>Drive Belts</b> .....	3-3
Auxiliary Brakes .....	M-1	Maintenance Check .....	3-3
Belts .....	M-1	Cogged Belt .....	3-3
Catalytic Converters.....	M-1	Poly-Vee Belt .....	3-3
Clutches .....	M-1	<b>Electrical System</b> .....	V-2
Coolant Heaters .....	M-1	Batteries (Specific Gravity) .....	V-2
Coolant Level Switches .....	M-1	Specifications .....	V-2
Drive Plates .....	M-1	<b>Emergency and Technical Service</b> .....	S-1
Electric Starting Motors.....	M-2	General Information .....	S-1
Electronic Switches.....	M-2	<b>Engine Component Torque Values</b> .....	V-11
Engine Protection Controls.....	M-2	Torque Table .....	V-11
Fan Clutches.....	M-2	<b>Engine Diagrams</b> .....	E-3
Fans.....	M-2	Engine Views .....	E-3
Fault Lamps .....	M-2	<b>Engine Identification</b> .....	E-1
Filters.....	M-2	Cummins Engine Nomenclature .....	E-2
Flexplates .....	M-2	Industrial Applications .....	E-2
Fuel Coolers .....	M-2	Engine Dataplate .....	E-1
Fuel Pumps .....	M-2	Industrial Applications .....	E-1
Fuel Warmers .....	M-2	Fuel Injection Pump Dataplate .....	E-2
Gauges .....	M-2	<b>Engine Operating Range</b> .....	1-8
General Information .....	M-1	General Information .....	1-8
Governors .....	M-2	<b>Engine Shutdown</b> .....	1-8
Heat Sleeves.....	M-3	General Information .....	1-8
Hydraulic and Power Steering Pumps .....	M-3	<b>Exhaust System</b> .....	V-2
In-Line Connectors.....	M-3	Specifications .....	V-2
		<b>Fan, Cooling</b> .....	3-4

Inspect for Reuse.....	3-4	Maintenance Check .....	3-6
<b>Fan Spacer and Pulley</b> .....	A-9	<b>Lubricating Oil Pressure Regulator (Main Rifle)</b> .....	A-14
Inspect for Reuse .....	A-9	Clean .....	A-15
Install .....	A-10	Install .....	A-15
Preparatory Steps .....	A-9	Preparatory Steps .....	A-14
Remove .....	A-9	Remove .....	A-15
<b>Flow Diagram, Air Intake System</b> .....	D-11	<b>Lubricating Oil Recommendations and Specifications</b> .....	V-3
General Information .....	D-11	General Information .....	V-4
<b>Flow Diagram, Compressed Air System</b> .....	D-13	New Engine Break-in Oils .....	V-3
General Information .....	D-13	<b>Lubricating Oil System</b> .....	V-1
General Information .....	D-13	Specifications .....	V-1
<b>Flow Diagram, Cooling System</b> .....	D-7	<b>Lubricating Oil Thermostat</b> .....	A-15
General Information .....	D-7	Clean .....	A-16
General Information .....	D-7	Install .....	A-16
<b>Flow Diagram, Exhaust System</b> .....	D-12	Preparatory Steps .....	A-15
General Information .....	D-12	Remove .....	A-16
<b>Flow Diagram, Fuel System</b> .....	D-2	<b>Maintenance Guidelines - Overview</b> .....	2-1
General Information .....	D-2	General Information .....	2-1
General Information .....	D-2	<b>Maintenance Procedures - Overview</b> .....	4-1
<b>Flow Diagram, Lubricating Oil System</b> .....	D-3	General Information .....	4-1
General Information .....	D-3	<b>Maintenance Record Form</b> .....	2-3
General Information .....	D-3	Maintenance Data .....	2-3
<b>Fuel Filter Adapter</b> .....	A-10	<b>Maintenance Schedule</b> .....	2-1
Install .....	A-11	General Information .....	2-1
Bosch® .....	A-11	Maximum Oil Drain Intervals .....	2-2
Preparatory Steps .....	A-10	<b>Normal Starting Procedure</b> .....	1-2
Bosch® .....	A-10	General Information .....	1-2
Remove .....	A-10	Jump Starting .....	1-4
Bosch® .....	A-10	<b>Off-Highway Engines International</b> .....	W-4
<b>Fuel Filter (Spin-On Type)</b> .....	5-4	<b>Off-Highway Engines United States and Canada</b> .....	W-1
Clean .....	5-4	<b>Operating Instructions - Overview</b> .....	1-1
Install .....	5-4	General Information .....	1-1
Prime .....	5-5	<b>Operating the Engine</b> .....	1-5
Remove .....	5-4	Ambient Temperature .....	1-7
<b>Fuel Lift Pump</b> .....	A-11	0 to -32°C [32 to -25°F] .....	1-7
Clean .....	A-12	-32 to -54°C [-25 to -65°F] .....	1-7
Install .....	A-12	Cold Weather .....	1-7
Preparatory Steps .....	A-11	Normal .....	1-5
Remove .....	A-11	<b>Overhead Set</b> .....	6-2
<b>Fuel Manifold (Drain)</b> .....	A-12	Adjust .....	6-2
Install .....	A-13	<b>Problem Solving</b> .....	S-1
Preparatory Steps .....	A-12	General Information .....	S-1
Remove .....	A-12	<b>Regional Offices - International</b> .....	S-15
<b>Fuel Recommendations and Specifications</b> .....	V-3	Locations .....	S-15
Fuel Recommendations .....	V-3	<b>Routine Service and Parts</b> .....	S-1
<b>Fuel Shutoff Valve</b> .....	A-13	General Information .....	S-1
Install .....	A-13	<b>Sealants</b> .....	V-12
Preparatory Steps .....	A-13	General Information .....	V-12
Remove .....	A-13	<b>Service Literature Ordering Location</b> .....	L-2
<b>Fuel System</b> .....	V-1	Contact Information .....	L-2
Specifications .....	V-1	<b>Starting Motor</b> .....	A-16
<b>Fuel-Water Separator</b> .....	3-5	Initial Check .....	A-16
Drain .....	3-5	Install .....	A-17
Canister Type .....	3-5	Remove .....	A-17
Spin-on Type .....	3-6	Rotation Check .....	A-18
<b>General Cleaning Instructions</b> .....	i-5	<b>Starting Procedure After Extended Shutdown or Oil</b>	
Glass or Plastic Bead Cleaning .....	i-6	<b>Change</b> .....	1-5
Solvent and Acid Cleaning .....	i-5	General Information .....	1-5
Steam Cleaning .....	i-6	<b>Supplemental Coolant Additive (SCA) and Antifreeze</b>	
<b>General Engine</b> .....	V-1	<b>Concentration</b> .....	5-3
Specifications .....	V-1	Maintenance Check .....	5-3
<b>General Repair Instructions</b> .....	i-5	Antifreeze .....	5-3
General Information .....	i-5	Supplemental Coolant Additive (SCA) .....	5-3
Welding on a Vehicle with an Electronic Controlled Fuel		<b>Symbols</b> .....	i-2
System .....	i-5	General Information .....	i-2
<b>General Safety Instructions</b> .....	i-4	<b>System Diagrams - Overview</b> .....	D-1
Important Safety Notice .....	i-4	General Information .....	D-1
<b>How to Use the Manual</b> .....	i-1	<b>To the Owner and Operator</b> .....	i-1
General Information .....	i-1	General Information .....	i-1
<b>Illustrations</b> .....	i-3	<b>Tool Requirements</b> .....	2-1
General Information .....	i-3	General Information .....	2-1
<b>Lubricating Oil and Filters</b> .....	4-3	<b>Troubleshooting Procedures and Techniques</b> .....	TS-1
Drain .....	4-3	General Information .....	TS-1
Fill .....	4-5	<b>Troubleshooting Symptoms Charts</b> .....	TS-1
Install .....	4-4	Air Compressor Air Pressure Rises Slowly .....	TS-2
Remove .....	4-4	Air Compressor Cycles Frequently .....	TS-3
<b>Lubricating Oil Level</b> .....	3-6	Air Compressor Noise is Excessive .....	TS-4

Air Compressor Pumping Excess Lubricating Oil into the Air System .....	TS-5
Air Compressor Will Not Maintain Adequate Air Pressure (Not Pumping Continuously) .....	TS-6
Air Compressor Will Not Stop Pumping .....	TS-7
Alternator Not Charging or Insufficient Charging .....	TS-8
Alternator Overcharging .....	TS-9
Coolant Contamination .....	TS-10
Coolant Loss – External .....	TS-11
Coolant Temperature Above Normal – Gradual Overheat.....	TS-12
Coolant Temperature is Above Normal – Sudden Over-heat .....	TS-14
Coolant Temperature is Below Normal.....	TS-15
Engine Acceleration or Response Poor .....	TS-16
Engine Difficult to Start or Will Not Start (Exhaust Smoke) .....	TS-18
Engine Difficult to Start or Will Not Start (No Exhaust Smoke) .....	TS-20
Engine Noise Excessive.....	TS-22
Engine Noise Excessive — Combustion Knocks .....	TS-24
Engine Power Output Low.....	TS-25
Engine Runs Rough at Idle.....	TS-28
Engine Runs Rough or Misfires .....	TS-29
Engine Speed Surges at Low or High Idle.....	TS-30
Engine Speed Surges Under Load or in Operating Range ..	TS-31
Engine Starts But Will Not Keep Running .....	TS-32
Engine Vibration Excessive .....	TS-33
Engine Will Not Crank or Cranks Slowly (Air Starter).....	TS-34
Engine Will Not Crank or Cranks Slowly (Electric Starter)....	TS-36
Engine Will Not Reach Rated Speed (RPM) .....	TS-38
Engine Will Not Shut Off.....	TS-40
Exhaust Smoke Excessive Under Load .....	TS-41
Fuel Consumption Excessive .....	TS-42
Fuel in Coolant .....	TS-43
Fuel in the Lubricating Oil.....	TS-44
Fuel or Lubricating Oil Leaking From Exhaust Manifold .....	TS-45
General Information .....	TS-1
Intake Manifold Air Temperature Above Specification.....	TS-46
Intake Manifold Pressure (Boost) is Below Normal.....	TS-48
Lubricating Oil Consumption Excessive.....	TS-49
Lubricating Oil Contaminated .....	TS-50
Lubricating Oil Loss .....	TS-51
Lubricating Oil Pressure High .....	TS-52
Lubricating Oil Pressure Low .....	TS-53
Lubricating Oil Sludge in the Crankcase Excessive .....	TS-55
Smoke, Black — Excessive.....	TS-56
Smoke, White — Excessive.....	TS-57
Turbocharger Leaks Engine Oil or Fuel .....	TS-59
<b>Vibration Damper, Rubber</b> .....	7-6
Inspect .....	7-6