

INDUSTRIAL DIESEL ENGINE

4BG1, 6BG1 MODELS

Revised (10-12)

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.

WORKSHOP MANUAL

ISUZU MOTORS LIMITED

SECTION 1

GENERAL INFORMATION

TABLE OF CONTENTS

ITEM	PAGE
General repair instructions	1- 2
Notes on the format of this manual.....	1- 2
Main data and specifications	1- 6
Tightening torque specifications	1- 8
Angular nut and bolt tightening method.....	1-10
Major parts fixing nuts and bolts	1-12
Identifications	1-23

GENERAL REPAIR INSTRUCTIONS

1. Before performing any service operation with the engine mounted, disconnect the grounding cable from the battery.
This will reduce the chance of cable damage and burning due to short circuiting.
2. Always use the proper tool or tools for the job at hand.
Where specified, use the specially designed tool or tools.
3. Use genuine ISUZU parts referring ISUZU PARTS CATALOG for the engines surely.
4. Never reuse cotter pins, gaskets, O-rings, lock washers, and self locking nuts. Discard them as you remove them. Replace them with new ones.
5. Always keep disassembled parts neatly in groups. This will ensure a smooth reassembly operation.
It is especially important to keep fastening parts separate. These parts vary in hardness and design, depending on their installation position.
6. All parts should be carefully cleaned before inspection or reassembly.
Oil ports and other openings should be cleaned with compressed air to make sure that they are completely free of obstructions.
7. Rotating and sliding part surfaces should be lubricated with oil or grease before reassembly.
8. If necessary, use a sealer on gaskets to prevent leakage.
9. Nut and bolt torque specifications should be carefully followed.
10. Always release the air pressure from any machine-mounted air tank(s) before dismantling the engine or disconnecting pipes and hoses. To not do so is extremely dangerous.
11. Always check and recheck you work. No service operation is complete until you have done this.
12. Information contained in the "Main Data and Specifications" of the Workshop Manual and the Instruction Book may differ. In this case, the information contained in the Instruction Book should be considered applicable.

NOTES ON THE FORMAT OF THIS MANUAL

This Workshop Manual is applicable to the 4BG1, 4BG1T, 6BG1, and 6BG1T family of industrial diesel engines. Unless otherwise specified, these engines have common parts and components as well as data and specifications.

Illustrations used in this Workshop Manual are based on the 6BG1 and 6BG1T engines.

The 4BG1T engine and the 6BG1T engine are turbocharged.

1. Find the applicable section by referring to the Table of Contents at the beginning of the Manual.
2. Common technical data such as general maintenance items, service specifications, and tightening torques are included in the "General Information" section.
3. Each section is divided into sub-sections dealing with disassembly, inspection and repair, and reassembly.
The section ENGINE ASSEMBLY is an exception. This part is divided into three sections to facilitates quick indexing.
4. When the same servicing operation is applicable to several different units, the manual will direct you to the appropriate page.
5. For the sake of brevity, self-explanatory removal and installation procedures are omitted.
More complex procedures are covered in detail.

6. Each service operation section in this Workshop Manual begins with an exploded view of the applicable area. A brief explanation of the notation used follows.

Disassembly Steps - 2

- 1. Water by-pass hose
- 2. Thermostat housing
- 3. Water pump
- ▲ 4. Injection nozzle holder
- 5. Glow plug and glow plug connector
- 6. Cylinder head cover
- ▲ 7. Rocker arm shaft and rocker arm
- 8. Push rod
- ▲ 9. Cylinder head
- 10. Cylinder head gasket
- ▲ 11. Crankshaft damper pulley with dust seal
- 12. Timing gear case cover
- 13. Timing gear cover
- 14. Timing gear oil pipe
- 15. Idler gear "B" and shaft
- ▲ 16. Idler gear "A"
- ▲ 17. Idler gear shaft

Inverted Engine

* Repair kit

Parts marked with an asterisk (*) are included in the repair kit.

Parts within a square frame are to be removed and installed as a single unit.

All parts within an irregularly shaped frame form a single assembly. They are considered a "major component".

Individual parts within the irregularly shaped frame are considered "minor components".

The number tells you the service operation sequence.

Removal of unnumbered parts is unnecessary unless replacement is required.


The "** Repair Kit" indicates that a repair kit is available.

The parts listed under "Reassembly Steps" or "Installation Steps" are in the service operation sequence.

The removal or installation of parts marked with a triangle (▲) is an important operation. Detailed information is given in the text.

1-4 GENERAL INFORMATION

7. Below is a sample of the text of the Workshop Manual.



Valve Guide Installation

1. Lubricate the valve guide outer face with engine oil.
2. Attach the installer to the valve guide.
3. Use a hammer to drive the valve guide into position from the cylinder head upper face.
4. Measure the height of the valve guide upper end from the upper face of the cylinder head.

Valve Guide Installer: 1-85220-001-0

Valve Guide Upper End Height (H)	mm(in)
	14.1 (0.56)

Note:
If the valve guide has been removed, both the valve and the valve guide must be replaced with new ones as a set.
Be absolutely sure to discard the used valves and valve guides.

This is the item shown in the illustration. It is marked with a triangle (▲) on the Major Components page.

Special tools are identified by the tool name and/or number.


















The illustration shows how the special tool is to be used.

Letters and numbers contained in a circle refer to the illustration.

Symbols indicate the type of service operation or step to be performed. A detailed explanation of these symbols follows.

Service data and specifications are given in this table.

8. The following symbols appear throughout this Workshop Manual. They tell you the type of service operation or step to perform.

	... Removal		... Adjustment
	... Installation		... Cleaning
	... Disassembly		... Important Operation Requiring Extra Care
	... Reassembly		... Specified Torque (Tighten)
	... Alignment (Marks)		... Special Tool Use Required or Recommended (Isuzu Tool or Tools)
	... Directional Indication		... Commercially Available Tool Use Required or Recommended
	... Inspection		... Lubrication (Oil)
	... Measurement		... Lubrication (Grease)
	... Sealant Application		

9. Measurement criteria are defined by the terms "standard" and "limit".

A measurement falling within the "standard" range indicates that the applicable part or parts are serviceable.

"Limit" should be thought of as an absolute value.

A measurement which is outside the "limit" indicates that the applicable part or parts must be either repaired or replaced.

10. Components and parts are listed in the singular form throughout the Manual.

11. Directions used in this Manual are as follows:

Front

The cooling fan side of the engine viewed from the flywheel.

Right

The injection pump side of the engine.

Left

The exhaust manifold side of the engine.


Rear

The flywheel side of the engine.

Cylinder numbers are counted from the front of the engine.

The front most cylinder is No. 1 and rear most cylinder is No. 4 or No. 6.

The engine's direction of rotation is counterclockwise viewed from the flywheel.



MAIN DATA AND SPECIFICATIONS

Engine Model		A-4BG1	A-4BG1T
Item			
Engine type		Water cooled, four cycle, vertical in-line overhead valve	
Combustion chamber type		Direct injection	
Cylinder liner type		Dry	
No. of cylinders – bore × stroke	mm (in)	4 – 105 × 125 (4.13 × 4.92)	
Total piston displacement	cm ³ (cid)	4,329 (464)	
Compression ratio		17.0 to 1	
* Engine dimensions	mm (in)	842 × 645 × 775 (33.1 × 25.4 × 30.5)	878 × 702 × 883 (34.6 × 27.6 × 34.8)
Length × width × height			
* Engine weight (Dry)	kg (lb)	325 (716)	361 (796)
Fuel injection order		1-3-4-2	
Specified fuel		Diesel fuel (ASTM D975 No. 2D)	
Injection pump		In-line plunger, Bosch A type	
Governor		Mechanical, RSV type	
Injection nozzle		Multi hole	
Injection starting pressure	kg/cm ² (psi)	150 (2,134)	185 (2,630)
Fuel filter type		Center bolt or cartridge (spin-on)	
Water sedimentor	(If so equipped)	Sediment/water level indicating type	
Compression pressure	kg/cm ² (psi)	31 (441) at 200 rpm at sea level	
(At warm)			
Valve clearances (At cold)	Intake mm (in)	0.40 (0.016)	
	Exhaust mm (in)	0.40 (0.016)	
Lubrication method		Pressurized circulation	
Oil pump		Gear type	
Main oil filter type		Full flow, cartridge (spin-on)	
* Lubricating oil volume	lit. (US gal)	13.2 (3.5)	
Oil cooler		Water cooled integral type	
Cooling method		Pressurized forced circulation	
Coolant volume (engine only)	lit. (US gal)	8.5 (2.25)	
Water pump		Belt driven impeller type	
Thermostat type		Wax pellet type	
* Generator	V-A	24-40	
* Starter	V-KW	24-4.5	
* Turbocharger manufacturer		—	MITSUBISHI
* Turbocharger model		—	TD04H

Note: 1. These specifications are based on the standard engine.

2. Specifications for items marked with an asterisk (*) will vary according to the type of equipment on which the engine is installed.

If you are unable to locate the data applicable to these specifications, please contact Isuzu Motors LTD through your machine supplier.

MAIN DATA AND SPECIFICATIONS

Engine Model		A-6BG1	A-6BG1T
Item			
Engine type		Water cooled, four cycle, vertical in-line overhead valve	
Combustion chamber type		Direct injection	
Cylinder liner type		Dry	
No. of cylinders - bore × stroke	mm (in)	6 - 105.0 × 125.0 (4.13 × 4.92)	
Total piston displacement	cm ³ (cid)	6,494 (396)	
Compression ratio		17.5 to 1	
* Engine dimensions	mm (in)	1122 × 648 × 775	1193 × 739 × 949
Length × width × height		(44.2 × 25.5 × 30.5)	(47.0 × 29.1 × 37.4)
* Engine weight (Dry)	kg (lb)	458 (1009)	489 (1078)
Fuel injection order		1-5-3-6-2-4	
Specified fuel		Diesel fuel (ASTM D975 No. 2D)	
Injection pump		In-line plunger, Bosch AD type	
Governor		Mechanical, RSV type	
Injection nozzle		Multi hole	
Injection starting pressure	kg/cm ² (psi)	185 (2,630)	
Fuel filter type		Cartridge (spin-on)	
Water sedimentor	(If so equipped)	Sedimenter/water level indicating type	
Compression pressure	kg/cm ² (psi)	31 (441) at 200 rpm, at sea level	
Valve clearances (At cold)	Intake	0.40 (0.016)	
	Exhaust	0.40 (0.016)	
Lubrication method		Pressurized circulation	
Oil pump		Gear type	
Main oil filter type		Centerbolt, fullflow or cartridge (spin-on)	
Partial oil filter		Equipped by OEM	
* Lubricating oil volume	lit. (US gal)	21.5 (5.68)	
Oil cooler		Water cooled integral type	
Cooling method		Pressurized forced circulation	
Coolant volume (engine only)	lit. (US gal)	12 (3.2)	
Water pump		Belt driven impeller type	
Thermostat type		Wax pellet type	
* Generator	V-A	24-40	
* Starter	V-KW	24-4.5	
* Turbocharger manufacturer		-	IHI
* Turbocharger model		-	RHE6

Note: 1. These specifications are based on the standard engine.

2. Specifications for items marked with an asterisk (*) will vary according to the type of equipment on which the engine is installed.










If you are unable to locate the data applicable to these specifications, please contact Isuzu Motors LTD through your machine supplier.

TIGHTENING TORQUE SPECIFICATIONS

The tightening torque values given in the table below are applicable to the bolts unless otherwise specified.

STANDARD BOLT

kg·m (lb.ft/N·m)

<div style="text-align: center;">Strength Class</div> <div style="text-align: center;">Bolt Identification</div> <div style="text-align: center;">Bolt Diameter × pitch (mm)</div>	4.8 (4T)	(7T)	8.8		9.8 (9T)
			Refined	Non-Refined	
					
	 No mark	—			
M 6 × 1.0	0.4~0.8 (2.9~5.8/3.9~7.8)		0.5~1.0 (3.6~7.2/4.9~9.8)		—
M 8 × 1.25	0.8~1.8 (5.8~13.0/7.8~17.7)		1.2~2.3 (8.7~16.6/11.8~22.6)		1.7~3.1 (12.3~22.4/16.7~30.4)
M10 × 1.25	2.1~3.5 (15.2~25.3/20.6~34.3)		2.8~4.7 (20.3~34.0/27.5~46.1)		3.8~6.4 (27.5~46.3/37.3~62.8)
M12 × 1.25	5.0~7.5 (36.2~54.2/49.0~73.6)		6.2~9.3 (44.8~67.3/60.8~91.2)		7.7~11.6 (55.7~83.9/75.5~113.8)
M14 × 1.5	7.8~11.7 (56.4~84.6/78.5~114.7)		9.5~14.2 (68.7~102.7/93.2~139.3)		11.6~17.4 (83.9~125.6/113.8~170.6)
M16 × 1.5	10.6~16.0 (76.7~115.7/103.0~156.9)		13.8~20.8 (99.8~150.4/135.3~204.0)		16.3~24.5 (118.9~177.2/159.9~240.3)
M18 × 1.5	15.4~23.0 (111.1~166.4/151.0~225.6)		19.9~29.9 (143.9~216.3/195.2~391.3)		23.4~35.2 (169.3~254.6/229.5~345.2)
M20 × 1.5	21.0~31.6 (151.9~228.6/205.9~307.9)		27.5~41.3 (198.9~298.7/269.7~405.0)		32.3~48.5 (233.6~350.8/316.8~475.6)
M22 × 1.5	25.6~42.2 (185.2~305.2/251.1~413.8)		37.0~55.5 (267.6~401.4/362.9~544.3)		43.3~64.9 (313.2~469.4/424.6~636.5)
M24 × 2.0	36.6~55.0 (264.7~397.8/358.9~539.4)		43.9~72.5 (317.5~523.9/430.5~711.0)		56.5~84.7 (408.7~612.6/554.1~830.6)
*M10 × 1.5	2.0~3.4 (14.5~24.6/19.6~32.4)		2.8~4.6 (20.3~33.3/27.5~45.1)		3.7~6.1 (26.8~44.1/36.3~59.8)
*M12 × 1.5	4.6~7.0 (33.3~50.6/45.1~68.7)		5.8~8.6 (42.0~62.2/56.9~84.3)		7.3~10.9 (52.8~78.8/71.6~106.9)
*M14 × 2.0	7.3~10.9 (52.8~78.8/71.6~106.9)		9.0~13.4 (65.1~96.9/88.3~131.4)		10.9~16.3 (78.8~118.9/106.9~159.9)
*M16 × 2.0	10.2~15.2 (73.8~110.0/100.0~149.1)		13.2~19.8 (95.5~143.2/129.5~194.2)		15.6~23.4 (112.8~169.3/162.8~229.5)




An asterisk (*) indicates that the bolts are used for female threaded parts that are made of soft materials such as casting. Those shown in parentheses in the strength class indicate the classification by the old standard.

TIGHTENING TORQUE SPECIFICATIONS

The tightening torque values given in the table below are applicable to the bolts unless otherwise specified.

FLANGED HEAD BOLT

kg·m (lb.ft/N·m)

<div style="display: inline-block; transform: rotate(-45deg);"> Bolt head marking Nominal size (dia. x pitch) </div>			
M 6 × 1	0.5~0.9 (3.61~6.50/4.6~8.5)	0.6~1.2 (4.33~8.67/5.88~11.76)	—
M 8 × 1.25	1.1~2.0 (7.95~14.46/10.78~19.61)	1.4~2.9 (4.33~8.67/5.88~11.76)	1.9~3.4 (13.74~24.59/18.63~33.34)
M10 × 1.25	2.3~3.9 (17.35~28.20/23.53~38.24)	3.6~6.4 (26.03~44.12/35.30~59.82)	4.3~7.2 (31.10~52.07/42.16~70.60)
*M10 × 1.5	2.3~3.8 (16.63~27.48/22.55~37.26)	3.5~5.8 (25.31~41.95/34.32~56.87)	4.1~6.8 (29.65~49.18/40.20~66.68)
M12 × 1.25	5.6~8.4 (40.50~60.75/54.91~82.37)	7.9~11.9 (57.14~86.07/77.47~116.69)	8.7~13.0 (62.92~94.02/85.31~127.48)
*M12 × 1.75	3.5~9.5 (37.61~56.41/50.99~76.49)	7.3~10.9 (52.80~78.83/71.58~106.89)	8.1~12.2 (58.58~88.24/79.43~119.64)
M14 × 1.5	8.5~12.7 (61.48~91.85/83.35~124.54)	11.7~17.6 (84.62~127.30/114.73~172.59)	12.6~18.9 (91.13~136.70/123.56~185.34)
*M14 × 2	7.6~11.5 (57.14~85.34/77.47~115.71)	11.1~16.6 (80.28~120.06/108.85~162.79)	11.8~17.7 (85.34~128.02/115.71~173.57)
M16 × 1.5	11.8~17.7 (85.34~128.02/115.71~173.57)	17.1~26.5 (125.85~189.50/170.63~256.93)	18.0~27.1 (130.19~196.01/176.52~265.76)
*M16 × 2	11.2~16.7 (81.00~120.79/109.83~163.77)	16.6~24.9 (120.06~180.10/162.79~244.18)	17.2~25.7 (124.40~186.61/168.67~253.01)


A bolt with an asterisk (*) is used for female screws of soft material such as cast iron.




ANGULAR NUT AND BOLT TIGHTENING METHOD




1. Carefully wash the nuts and bolts to remove all oil and grease.




2. Apply a coat of molybdenum disulfide grease to the threads and setting faces of the nuts and bolts.




3. Tighten the nuts and bolts to the specified torque (snug torque) with a torque wrench.




4. Draw a line [A-B] across the center of each bolt.




5. Draw another line (C-D) on the face of each of the parts to be clamped. This line should be an extension of the line [A-B].



6. Draw another line [F-G] on the face of each of the parts to be clamped. This line will be in the direction of the specified angle (Q) across the center [E] of the nut or bolt.



7. Use a socket wrench to tighten each nut or bolt to the point where the line [A-B] is aligned with the line [F-G].



Example: Specified Angle and Tightening Rotation


A	30°	1/12 of a turn
B	60°	1/6 of a turn
C	90°	1/4 of a turn
D	180°	1/2 of a turn
E	360°	One full turn



MAJOR PART FIXING NUTS AND BOLTS

Cylinder Head and Cover


kg·m (lb.ft)



Mos₂ Molybdenum disulfide paste.


Cylinder Body

kg·m (lb.ft)




Oil Pan and Dipstick

kg·m (lb.ft)




Camshaft and Rocker Arm

kg·m (lb.ft)




Crankshaft, Piston, and Flywheel

kg·m (lb.ft)




Thermostat and Thermostat Housing

kg·m (lb·ft)




Intake and Exhaust Manifold

kg·m (lb.ft)




Timing Gear Case and Flywheel Housing

kg·m (lb.ft)




Oil Cooler, Oil Filter, and Oil Pump

kg·m (lb.ft)




Fuel System

kg·m (lb.ft)






Turbocharger

kg·m (lb.ft)



IDENTIFICATIONS



MODEL IDENTIFICATION

Engine Serial Number

The engine number is stamped on the front left hand side of the cylinder body.

INJECTION PUMP IDENTIFICATION

Injection Pump Number

Injection volume should be adjusted after referring to the adjustment data applicable to the injection pump installed.

The injection pump identification number (A) is stamped on the injection pump identification plate.

Note:

Always check the identification number before beginning a service operation.

Applicable service data will vary according to the identification number. Use of the wrong service data will result in reduced engine performance and engine damage.

MEMO

Handwriting practice lines consisting of horizontal dotted lines on a white background.

SECTION 2

MAINTENANCE

TABLE OF CONTENTS

ITEM	PAGE
Lubricating system	2- 2
Fuel system	2- 3
Cooling system	2- 7
Valve clearance adjustment	2- 7
Injection timing	2- 9
Compression pressure measurement.....	2-15
Turbocharger inspection	2-16
Engine repair kit.....	2-17
Recommended lubricants.....	2-19
Engine oil viscosity chart	2-19

Note: Maintenance intervals such as fuel or oil filter changes should be referred to INSTRUCTION BOOK.

LUBRICATING SYSTEM

Main Oil Filter Replacement

Center Bolt Type

Removal

1. Loosen the drain plug to drain the engine oil from the oil filter.
2. Remove the center bolt and the filter body from the filter cover along with the filter element.
3. Discard the used filter element.
4. Wipe the oil filter fitting face clean with a rag.
This will allow the new oil filter to seat properly.

Installation

1. Install the two O-rings A and B and check that they are correctly positioned.
2. Reassemble the filter body with the center bolt.





kg.m (lb.ft)

Center Bolt Torque	4.3-6.3 (31.1-45.6)
--------------------	---------------------

3. Check that the gasket is properly seated. This will prevent oil leakage.

kg.m (lb.ft)

Drain Plug Torque	1.6-2.0 (11.6-14.5)
-------------------	---------------------



Cartridge (Spin-On) Type


Removal

Removal and Installer: Filter Wrench

1. Loosen the used oil filter by turning it counterclockwise with the filter wrench.
2. Discard the used oil filter.

Installation

1. Wipe the oil filter mounting face with a clean rag.
This will allow the new oil filter to seat properly.
2. Lightly oil the O-ring.
3. Turn in the new oil filter until the sealing face is fitted against the O-ring.
4. Use the filter wrench to turn in the oil filter an additional 3/4 of a turn or one turn.
5. Check the engine oil level and replenish to the specified level if required.
6. Start the engine and check for oil leakage from the oil filter.



FUEL SYSTEM

Fuel Filter Replacement

Center Bolt Type



Removal



1. Loosen the drain plug ① to drain the fuel from the fuel filter.
2. Loosen the center bolt ② to remove the filter body ⑤, the spring ⑥, the washer ⑦, the gasket ⑧, and the filter element ⑨.
3. Discard the used element.



Installation



1. Wash the filter body and the other parts immersing them into clean diesel oil.
2. Reassemble the parts in reverse order. Use the new element.
3. Check that the gaskets are properly seated. This will prevent fuel leakage.



Cartridge (Spin-On) Type



Removal

1. Loosen the fuel filter by turning it counterclockwise with the filter wrench or your hand. Discard the used filter.




Filter Wrench

2. Wipe the fuel filter fitting face clean with a rag. This will allow the new fuel filter to seat properly.



Installation

1. Apply a light coat of engine oil to the O-ring.
2. Supply fuel to the new fuel filter.
This will facilitate air bleeding.
3. Turn in the new fuel filter until the filter O-ring is fitted against the sealing face.
4. Use the filter wrench to turn in the fuel filter an additional 2/3 of a turn.




Overflow Valve

- Check the overflow valve for clogging.
Check the ball side for suction leakage

kg/cm²(psi)

Overflow Valve Opening Pressure (Reference)	1.5 (21)
---	----------



Injection Nozzle

Inspection procedure

1. Clamp the injection nozzle holder in a vise.
2. Use a wrench to remove the injection nozzle holder cap.
3. Remove the injection nozzle holder from the vise.





Adjusting Procedure


Injection Starting Pressure Check

1. Attach the injection nozzle holder to the injection nozzle tester.
2. Loosen the adjusting screw ①.
3. Check the injection nozzle starting pressure and the spray condition by operating the injection nozzle tester.
4. Adjust the injection nozzle starting pressure.



Turn the adjusting screw clockwise while operating the injection nozzle tester handle.






kg/cm² (psi)

	4BG1	4BG1T, 6BG1, 6BG1T
Injection Starting Pressure	150 (2134)	185 (2630)

WARNING

TEST FLUID FROM THE NOZZLE TESTER WILL SPRAY OUT UNDER GREAT PRESSURE. IT CAN EASILY PUNCTURE A PERSON'S SKIN. KEEP YOUR HANDS AWAY FROM THE NOZZLE TESTER AT ALL TIMES.




Spray Condition Check (During Injection Nozzle Tester Operation)

1. Tighten the cap nut.
2. Check the injection nozzle starting pressure.
3. Check the injection nozzle spray condition.

Operate the injection nozzle tester hand lever 4 to 6 times a second while looking for abnormal injection nozzle spray conditions.

Refer to the illustration for different spray conditions.



- (1) Good
- (2) Bad (Restrictions in orifice)
- (3) Bad (Dripping)



Feed Pump Strainer

1. Remove the joint bolt.
2. Use a screwdriver to remove the strainer.
3. Wash the strainer in clean diesel fuel.

⚠



Water Separator (Water Sedimentor) (Optional Equipment)



Check the water separator float ① level.

If the float ① has reached level ②, loosen the drain plug ③ (at the bottom side of the water separator) to drain the water.

kg.m (lb.ft)




Drain Plug Torque	0.9–1.5 (6.5–10.8)
-------------------	--------------------



Air Bleeding

1. Loosen the feed pump cap ① on the injection pump.
2. Loosen the fuel filter fuel return eye bolt ②.
3. Operate the feed pump until there are no more bubbles visible in the fuel being discharged from the fuel filter fuel return eye bolt.
4. Retighten the fuel filter fuel return eye bolt.
5. Operate the feed pump several times and check for fuel leakage around the injection pump and the fuel filter.



COOLING SYSTEM

Cooling Fan Drive Belt


Adjustment

1. Check the cooling fan drive belt for cracking and other damage.
2. Check the drive belt tension by exerting a force of 10 kg (22lb) midway between the fan pulley ② and the generator ③.
3. Adjust the belt tension by loosening the alternator mounting bolt and the generator adjusting bolt and pivoting the generator.

Be sure to retighten the bolts after adjusting the belt tension.

mm (in)

Cooling Fan Drive Belt Deflection	8.0–12.0 (0.3–0.5)
-----------------------------------	--------------------



Thermostat

Inspection

Visually inspect the thermostat.

Replace the thermostat if excessive wear or damage is discovered during inspection.


Measure the valve lift.

mm (in)

Amount of Valve Lift at 95°C (203°F)	10.0 (0.39)
--------------------------------------	-------------

°C(°F)


Valve Opening Temperature	80–84 (176–183)
---------------------------	-----------------



VALVE CLEARANCE AND ADJUSTMENT

Note:

The cylinder head bolts were previously tightened with the "Angular Tightening Method". Therefore, it is not necessary to retighten the cylinder head bolts before adjusting the valve clearance.




1. Bring the piston in either the No. 1 cylinder or the No. 6 cylinder to Top Dead Center on the compression stroke by turning the crankshaft until the TDC notched line on the crankshaft pulley is aligned with the timing pointer.

2. Check to see if there is play in the No. 1 intake and exhaust valve rocker arms.

If the No. 1 cylinder intake and exhaust valve rocker arms have play, the No. 1 piston is at TDC on the compression stroke.

If the No. 1 cylinder intake and exhaust valve rocker arms are depressed, the No. 6 piston (No. 4 piston for the 4BG1) is at TDC on the compression stroke.




Adjust the No. 1 or the No. 6 (No. 4 for the 4BG1) cylinder valve clearances while their respective cylinders are at TDC on the compression stroke.

mm (in)

Intake and Exhaust Valve Clearance (cold)	0.40 (0.016)
---	--------------

3. Loosen each valve clearance adjusting screw as shown in the illustration.
4. Insert a 0.40 mm (0.016 in) feeler gauge between the rocker arm and the valve stem end.
5. Turn the valve clearance adjusting screw until a slight drag can be felt on the feeler gauge.
6. Tighten the lock nut securely.



7. Rotate the crankshaft 360°.




Realign the crankshaft pulley TDC notched line with the timing pointer.

8. Adjust the clearances for the remaining valves as shown in the illustration.

kg.m (lb.ft)

Rocker Arm Screw Lock
Nut Torque

2.1-3.1 (15.2-22.4)



Note:

The valve clearance adjustment procedure for the 4BG1 engines is identical to that for the 6BG1 engines. Only the number of cylinders is different.



INJECTION TIMING




Note:

Take care to avoid entry of dust or foreign particles into the pump interior when the timing adjustment is made.

FLANGE MOUNTED INJECTION PUMP INJECTION TIMING CHECKING AND ADJUSTMENT

The flange mounted injection pump is installed behind the timing gear case.



Checking Procedure

1. Align the crankshaft pulley TDC mark with the pointer.

Remove the inspection hole cover at the front of the injection pump on the timing gear case cover.

Check the alignment between the pointer (4) on the injection pump gear nut lock plate and the projection area mark (3) on the injection pump gear case.




If it is in misalignment, recheck with turning the crankshaft pulley one more turn to repeat the foregoing procedure to mark sure that it is in alignment.

Check the alignment of the notched lines (1) and (2).

(These notched lines were aligned at the factory to set the injection pump body and the mounting flange.)


Next, inspect the crankangle position of the injection starting.

2. Reversely turn the crankshaft pulley counterclockwise about 30° crankangle.



3. Disconnect the injection pipe from the No. 1 plunger.

This will allow you to visually check the full injection starting flow at No. 1 plunger.




4. Remove the delivery valve holder (1), the valve seat (2), valve spring (3) the delivery valve (4) from the No. 1 plunger.




5. Reinstall the delivery holder (1) and tighten it to the specified torque.

Do not reinstall the delivery valve spring, the valve seat and the delivery valve.

These parts will be reinstalled later.



6. Hold the fuel control lever at the fully open position.



7. Slowly turn the crankshaft pulley clockwise, at the same time, continue to feed the fuel with pumping the priming pump.

When the fuel stop to flow out from the No. 1 delivery valve holder, stop the pump instantaneously.

This crankangle position is the injection starting of the engine.




8. Observe and make sure that mark (injection starting angle line α°) on the crankshaft pulley is aligning with the pointer.




The timing line shows the injection starting angle of the engine.

Blow out the remaining fuel from the delivery valve holder.

Make sure that there is no fuel being delivered from the priming pump.



015E5002



Note

6BG1 engine has eight timing notch lines punched on the crankshaft damper pulley. 4BG1 engine has eight timing notch lines punched on gear case side, and TDC mark on crank pulley.

These notched lines must be aligned for correct engine timing.

Refer to the illustration.


	Degree	
	6BG1	6BG1T
Injection Timing B.T.D.C	12	12

	Degree	
	4BG1	4BG1T
Injection Timing B.T.D.C	14	12

Note:

Injection pump injection timing will vary among identical engines contact your machine supplier or nearest ISUZU engine service outlet for the specifications applicable to your engine.

These specifications have been set by ISUZU and the OEM manufacturer.



9. Remove the delivery valve holder from the No. 1 plunger.

10. Reinstall the delivery valve internal parts (seat, spring, and valve) to the delivery valve holder.

11. Reinstall the delivery valve holder assembly to the No. 1 plunger and tighten it to the specified torque.

kg.m (lb.ft)

Delivery Valve Holder Torque	4-4.5 (29-33)
------------------------------	---------------

12. Install the No. 1 cylinder injection pipe and tighten it to the specified torque.

kg.m (lb.ft)



Injection Pipe Nut Torque	2.9-3.3 (21-24)
---------------------------	-----------------

Note:

DO NOT OVERTIGHTEN THE INJECTION PUMP BODY.

THE INJECTION PUMP BODY IS MADE OF ALUMINUM. OVERTIGHTENING WILL DISTORT THE INJECTION PUMP BODY SHAPE AND ADVERSELY AFFECT CONTROL RACK OPERATION.

Adjusting Procedure


1. Align the pointer and the specified timing mark on the crank pulley.

2. Perform the operations described on page 2-10, 11, paragraphs 3, 4, 5, 6.

3. Loosen the four injection pump fixing nut.


4. To advance the timing

Pivot the injection pump at the pump driveshaft toward out.


To retard the timing.

Pivot the injection pump at the pump driveshaft toward in. (toward the cylinder block)

Reference; the 1 mm misalignment between the two setting mark lines corresponds to about 2° in crankangle.



5. Do a fine injection pump position adjustment, while continue the pumping operation to feed the fuel, and stop to pivot the injection pump when the fuel stop to flow out from the No. 1 delivery valve holder.
6. Tighten the four injection pump fixing nuts.
7. Once remove the No. 1 delivery valve holder, and reinstall the delivery valve, spring and the valve holder with the specified torque.
8. Install the No. 1 injection pipe and tighten it to the specified torque.



COUPLING DRIVEN INJECTION PUMP TIMING ADJUSTMENT


The coupling driven injection pump is installed at the middle of the cylinder body. It is driven by the injection pump drive shaft.

1. Injection timing is initially adjusted by aligning the notched line 5 on the crankshaft damper pulley with the pointer 6.


Fine adjustment is made by rotating the injection pump drive coupling.

Rotating the injection pump drive coupling counter-clockwise will advance the injection timing.


Rotating the injection pump drive coupling clockwise will retard the injection timing.



2. Loosen the two coupling bolts on the injection pump drive coupling.




3. Perform the operations described on page 2-10, 11 paragraphs 3, 4, 5, 6.



4. Slowly turn the coupling counterclockwise (viewed from the timing gear case).

At the same time, operate the priming pump to feed fuel to the No. 1 injection pump plunger.


Visually check that fuel is being fed (from the top of the delivery valve holder).



5. Continue to operate the priming pump.


Turn the coupling counterclockwise until the fuel stops flowing from the delivery valve holder.

This is the fuel injection starting point at the No. 1 plunger.




6. Blow out the remaining fuel from the delivery valve holder.

7. Check that there is no fuel being delivered from the priming pump.



8. Retighten two coupling bolts.

9. Perform the operations described on page 2-12 paragraphs 9, 10, 11, 12.



COMPRESSION PRESSURE MEASUREMENT

1. Operate the engine to warm-up until the coolant temperature reaches to 75°C (167°F).
2. Remove all of the glow plugs and the injection pipes.
3. Attach a compression gauge to the No. 1 cylinder glow plug installation threads.

Note:

Compression pressure may be measured starting at any cylinder and in no particular cylinder order. However, it is very important that the compression pressure be measured in each cylinder.


Therefore, start at the No.1 cylinder and work back. In this way, you will be sure to measure the compression pressure in each cylinder.



Compression Gauge:



Compression Gauge Adapter: 5-85317-001-0 (JKM-1015)



4. Crank the engine with the starter motor and take the compression gauge reading.


kg/cm² (psi) at 200 rpm at sea level

Standard	Limit
31.0 (441)	26.0 (370)

5. Repeat the procedure (Steps 2 and 3) for the remaining cylinders.


Compression pressure should be approximately the same for each cylinder. A variation exceeding 2.0 kg/cm² (28 psi) is unacceptable.

If the measured value exceeds the specified limit, the related parts must be checked.




TURBOCHARGER INSPECTION

1. Check the air intake duct connections for air leakage.




2. Check the intake manifold connections for air leakage.




3. Check the exhaust duct connections for smoke leakage.

4. Check the turbocharger mounting nuts for looseness.




5. Check the oil feed pipe for oil leakage.




6. Check the oil return pipe joints for oil leakage.

ENGINE REPAIR KIT (FOR NATURALLY ASPIRATED ENGINES)



- | | |
|------------------------------------|--|
| 1. Cylinder head gasket | 17. Gear case to cylinder block gasket |
| 2. Cylinder head cover gasket | 18. Cover to timing gear case gasket |
| 3. Inlet manifold gasket | 19. Relief valve O-ring |
| 4. Exhaust manifold gasket | 20. Cylinder block side plug gasket |
| 5. Thermostat housing gasket | 21. Water drain valve gasket |
| 6. Thermostat gasket | 22. Oil pump hole cover gasket |
| 7. Tappet chamber cover gasket | 23. Water pump gasket |
| 8. Tappet cover fixing bolt gasket | 24. Oil pipe gasket |
| 9. Crankshaft rear end oil seal | 25. Oil pipe gasket |
| 10. Timing gear case oil seal | 26. Fuel pipe joint bolt gasket |
| 11. Valve guide oil seal | 27. Leak off pipe joint bolt gasket |
| 12. Oil pan gasket | 28. Injection nozzle gasket |
| 13. Drain plug gasket | 29. Injection pump oil pipe gasket |
| 14. Oil filter cover gasket | 30. Injection pump oil pipe gasket |
| 15. Oil filter fixing bolt gasket | 31. Cylinder head cover nut gasket |
| 16. Oil cooler gasket | |

ENGINE REPAIR KIT (FOR TURBOCHARGED ENGINES)




- | | |
|--|---|
| 1. Cylinder head gasket | 20. Oil pipe joint gasket |
| 2. Cylinder head cover gasket | 21. Joint bolt gasket |
| 3. Cylinder head cover nut gasket | 22. Oil pipe gasket |
| 4. Tappet chamber cover gasket | 23. Injection pump oil pipe gasket |
| 5. Chamber cover fixing bolt gasket | 24. Injection pump oil pipe gasket |
| 6. Oil pump hole cover gasket | 25. Water pump gasket |
| 7. Oil relief valve gasket | 26. Thermostat housing gasket |
| 8. Water drain valve gasket | 27. Intake manifold gasket |
| 9. Gear case to cylinder block gasket | 28. Inlet pipe manifold gasket |
| 10. Crank pulley to gear case oil seal | 29. Exhaust manifold gasket |
| 11. Gear case cover gasket | 30. Exhaust manifold to turbocharger gasket |
| 12. Crankshaft rear end oil seal | 31. Oil feed pipe gasket |
| 13. Valve guide oil seal | 32. Oil drain pipe gasket |
| 14. Drain plug gasket | 33. Oil drain pipe gasket |
| 15. Oil pan gasket | 34. Overflow fuel pipe gasket |
| 16. Oil pipe gasket | 35. Injection nozzle gasket |
| 17. Oil filter gasket | 36. Injection nozzle leak off pipe gasket |
| 18. Oil filter fixing bolt gasket | 37. Thermostat gasket |
| 19. Oil cooler gasket | |

RECOMMENDED LUBRICANTS

ENGINE TYPE	TYPES OF LUBRICANTS (API)
Without turbocharger	Diesel engine oil CC or CD grade
With turbocharger	Diesel engine oil CD grade

ENGINE OIL VISCOSITY CHART



MEMO

Handwriting practice lines consisting of horizontal dotted lines on a white background.

SECTION 3

**ENGINE ASSEMBLY I
(DISASSEMBLY)**

TABLE OF CONTENTS


ITEM	PAGE
External parts disassembly steps.....	3- 2
Major components.....	3- 7
Rocker arm and rocker arm shaft disassembly steps.....	3-12
Cylinder head disassembly steps.....	3-13
Piston and connecting rod disassembly steps.....	3-14



EXTERNAL PARTS DISASSEMBLY STEPS

(Right-hand side)


MODEL 6BG1T




Disassembly Steps

- | | |
|---|---|
| 1. Cooling fan | 9. Oil pipe; injection pump to cylinder body |
| 2. Not installed | 10. Not installed |
| 3. Intake pipe | 11. Oil pipe; filter to oil cooler |
| 4. Fuel return pipe | ▲ 12. Injection pump with injection pump gear |
| 5. Fuel pipe; fuel filter to injection pump | 13. Fuel filter |
| 6. Fuel pipe; feed pump to filter | 14. Oil filter |
| 7. Injection nozzle and leak off pipe | 15. Glow plug |
| 8. Injection pipe | |

MODEL 4BG1T

**Disassembly Steps**

- | | |
|---|---|
| 1. Cooling fan | 9. Oil pipe; injection pump to cylinder body |
| 2. Not installed | 10. Not installed |
| 3. Intake pipe | 11. Oil pipe; filter to oil cooler |
| 4. Fuel return pipe | ▲ 12. Injection pump with injection pump gear |
| 5. Fuel pipe; fuel filter to injection pump | 13. Fuel filter |
| 6. Fuel pipe; feed pump to filter | 14. Oil filter |
| 7. Injection nozzle and leak off pipe | 15. Glow plug |
| 8. Injection pipe | |



Important Operations

12. Injection Pump with Injection Pump Gear

Use the shipping plugs (or something similar) to seal the injection pump delivery valve ports. This will prevent the entry of foreign material.


Flange Mounted Injection Pump Removal

- 1) Remove the injection pump flange bolts.
- 2) Pull the injection pump with the injection pump drive gear free.

Refer to the illustration.

Coupling Mounted Injection Pump Removal



- 1) Remove the two coupling bolts to disconnect the coupling.
- 2) Remove the injection pump mounting bolts.
- 3) Remove either the injection pump bracket bolts or the injection pump fixing bolts.



Remove of the Air Compressor (if so equipped)

Before the air compressor is removed the injection pump must be unfastened from the mounting bracket to permit the pump to be moved freely on the mounting bracket.

1. Remove the injection pump coupling bolts ②.
2. Remove the injection pump mounting bolts and shift the pump to the rear about 50 mm (2 in).
3. Remove the air compressor mounting bolts ①.
4. Pull out the compressor to the rear about 50 mm (2 in) to pull out the air compressor crankshaft front end spline from the injection pump drive gear.
5. After removal, visually make sure that the crankshaft end spline and the female spline of the injection pump drive gear shaft have fitting marks. Those marks are important for reassembly.






EXTERNAL PARTS DISASSEMBLY STEPS

(Left-hand side)


MODEL 6BG1T



Disassembly Steps


- | | |
|----------------------------|-------------------------|
| 1. Dipstick and guide tube | 7. Gasket |
| 2. Air breather | 8. Starter |
| 3. Turbo adaptor | 9. Fan belt |
| 4. Oil feed pipe | 10. Generator |
| 5. Oil drain pipe | 11. Fan pulley |
| ▲ 6. Turbocharger | 12. Cylinder head cover |

MODEL 4BG1T



Disassembly Steps

- | | |
|----------------------------|-------------------------|
| 1. Dipstick and guide tube | 7. Gasket |
| 2. Air breather | 8. Starter |
| 3. (Not installed) | 9. Fan belt |
| 4. Oil feed pipe | 10. Generator |
| 5. Oil drain pipe | 11. Fan pulley |
| ▲ 6. Turbocharger | 12. Cylinder head cover |




Important Operations

6. Turbocharger

Plug oil ports in turbocharger body immediately after removal of the turbocharger.


MAJOR COMPONENTS - I




Disassembly Steps

- | | |
|--------------------------------|--|
| 1. Rubber hose ; water by-pass | 9. Oil pump driving pinion |
| ▲ 2. Rocker arm shaft assembly | ▲ 10. Starting handle nut |
| 3. Push rod | ▲ 11. Taper bushing |
| ▲ 4. Cylinder head bolt | 12. Crankshaft pulley and dust thrower |
| 5. Cylinder head assembly | 13. Timing gear cover |
| 6. Cylinder head gasket | 14. Oil thrower |
| 7. Water pump assembly | ▲ 15. Flywheel |
| 8. Tappet chamber cover | |


6B series





4B series



6B series



4B series



Important Operations

2. Rocker Arm Shaft

Loosen the rocker arm shaft fixing bolts a little at a time in numerical sequence as specified.

4. Cylinder Head Bolts

Loosen the cylinder head bolts a little at a time in the numerical order shown in the illustration.

Cylinder head bolt wrench: 1-85111-003-0




10. Crankshaft Pulley Nut

Wrench: 54 mm (2.13 in) for 6B series

Wrench: 42 mm (1.65 in) for 4B series


Use an appropriate wrench to remove the crankshaft pulley nut.



11. Taper Bushing (6B series only)

Remover: 9-8521-0122-0


Use the taper bushing remover to remove the crankshaft end taper bushing.



15. Flywheel


Loosen the flywheel bolt a little at a time in the numerical order as specified.

MAJOR COMPONENTS - II



Disassembly Steps

- | | |
|------------------------------|-------------------------------------|
| 1. Oil cooler | 9. Timing gear case |
| 2. Oil pan | 10. Idler gear shaft |
| 3. Oil pump and coupling | ▲ 11. Crankshaft bearing cap |
| 4. Flywheel housing | 12. Crankshaft bearing (lower half) |
| 5. Piston and connecting rod | 13. Thrust bearing |
| ▲ 6. Idler gear | 14. Crankshaft |
| ▲ 7. Camshaft | 15. Crankshaft bearing (upper half) |
| 8. Tappet | 16. Oiling jet |



Important Operations




6. Idler Gear

Measure the following points before disassembly.

mm (in)


	Standard	Limit
Idler Gear End Play	0.128–0.185 (0.005–0.0070)	0.2 (0.008)



mm (in)

	Standard	Limit
Timing Gears Backlash	0.10–0.17 (0.004–0.007)	0.3 (0.012)

Includes the crankshaft gear, the camshaft gear, and the idler gear.




7. Camshaft

Measure the following points before disassembly.

mm (in)

	Standard	Limit
Cam Gear End Play	0.050–0.114 (0.002–0.005)	0.2 (0.008)



11. Crankshaft Bearing Cap


Measure the crankshaft end play at the thrust bearing (center main bearing) before disassembly.

mm (in)

	Standard	Limit
Crankshaft End Play	0.15–0.33 (0.006–0.014)	0.4 (0.016)



ROCKER ARM, AND ROCKER ARM SHAFT DISASSEMBLY STEPS




Disassembly Steps

- | | |
|---------------|---------------------|
| 1. Bracket | 3. Spring |
| 2. Rocker arm | 4. Rocker arm shaft |




CYLINDER HEAD DISASSEMBLY STEPS



Disassembly Steps

1. Exhaust manifold and gasket
2. Intake manifold and gasket
3. Water outlet pipe
4. Thermostat
5. Thermostat housing and gasket
- ▲ 6. Split collar
7. Spring seat (upper) or *Valve rotator
8. Valve spring (if so equipped)
9. Spring seat (lower)
10. Valve
11. Valve stem oil seal



Important Operation

- ## 6. Split collar




Use the valve spring compressor to remove the split collar.

Valve Spring Compressor: 1-85235-006-0




PISTON AND CONNECTING ROD DISASSEMBLY STEPS



Disassembly Steps

- ▲ 1. Piston rings
- ▲ 2. Snap ring
- ▲ 3. Piston pin and connecting rod
- 4. Piston
- 5. Connecting rod bearing




Important Operation

Note:

Remove any carbon deposits from the upper part of the cylinder bore.

This will prevent damage to the piston and the piston rings when they are removed from the cylinder bore.




1. Piston Rings

Use a piston ring remover to remove the piston rings.


Do not attempt to use some other tool. Piston ring stretching will result in reduced piston ring tension.

Piston ring remover:



2, 3. Snap Ring and Piston Pin

- (1) Use a pair of snap ring pliers to remove the snap ring.



- (2) Tap the piston pin out with a hammer and brass bar.

MEMO

SECTION 4

ENGINE ASSEMBLY II (INSPECTION & REPAIR)


TABLE OF CONTENTS

ITEM	PAGE
Cylinder head	4- 2
Valve guide.....	4- 3
Valve spring.....	4- 6
Tappet.....	4- 7
Push rod	4- 8
Rocker arm shaft and rocker arm.....	4- 8
Idler gear and idler gear shaft.....	4- 9
Camshaft	4-10
Cylinder body and liner	4-11
Piston and piston ring.....	4-18
Piston pin.....	4-20
Connecting rod	4-21
Crankshaft.....	4-23
Flywheel and flywheel housing.....	4-30
Timing gear case cover.....	4-31



INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.



CYLINDER HEAD

Cylinder Head Lower Face Warpage

1. Use a straight edge and a feeler gauge to measure the four sides and the two diagonals of the cylinder head lower face.
2. Regrind the cylinder head lower face if the measured values are greater than the specified limit but less than the maximum grinding allowance.

If the measured values exceed the maximum grinding allowance, the cylinder head must be replaced.

Cylinder Head Lower Face Warpage mm (in)

Standard	Limit	Maximum Grinding Allowance
0.05 (0.002) or less	0.2 (0.008)	0.3 (0.012)

Cylinder Head Height (Reference) mm (in)

Standard	Limit
89.95 (3.541)–90.05 (3.545)	89.65 (3.530)

Note:




If the cylinder head lower face is reground, valve depression must be checked.


Water Jacket Water Pressure Test

Use the hydraulic gauge to check the water jacket water pressure.

Apply water pressure to the water jacket at 5 kg/cm² (71.1 psi) for three minutes.

Check the entire cylinder head for water leakage.





VALVE GUIDE

Valve Stem and Valve Guide Clearance

Measuring Method - 1

1. With the valve stem inserted in the valve guide, set the dial indicator needle to "0".
2. Move the valve head from side to side


Note the total dial indicator reading (TIR).

This value is the clearance between the valve stem and the valve guide.

If the measured values exceed the specified limit, the valve and the valve guide must be replaced as a set.

Valve Stem Clearance mm (in)


	Standard	Limit
Intake Side TIR	0.039-0.068 (0.0015-0.0027)	0.20 (0.008)
Exhaust Side TIR	0.064-0.096 (0.0025-0.0038)	0.25 (0.0098)



Measuring Method - II

1. Measure the valve stem outside diameter.
2. Use a caliper calibrator or a telescoping gauge to measure the valve guide inside diameter.

The difference between the valve stem outside diameter and the valve guide inside diameter is equal to the valve stem clearance.




Valve Guide Replacement


Valve Guide Removal

Use a hammer and the valve guide remover to drive out the valve guide from the cylinder head lower face.

Valve Guide Remover: 9-8522-035-0



The height of the valve guide top edge from the cylinder head upper face should be 14.1 mm.



Valve Depression


1. Install the valve ① to the cylinder head ②.
2. Use a depth gauge or a straight edge with steel rule to measure the valve depression from the cylinder head lower surface.

If the measured value exceeds the specified limit, the valve seat insert and/or valve must be replaced.

If the valve is replaced, the valve guide must be also replaced.

mm (in)

	Standard	Limit
Intake and Exhaust Valve Depression	1.0 (0.039)	2.5 (0.098)



Valve Contact Width

1. Inspect the valve contact faces for roughness and unevenness.


Make smooth the valve contact surfaces.

2. Measure the valve contact width.

If the measured value exceeds the specified limit, the valve seat insert must be replaced.

mm (in)

	Standard	Limit
Valve Contact Width	1.5 (0.059)	2.0 (0.078)



Valve Seat Insert Replacement

Valve Seat Insert Removal


1. Arc weld the entire inside circumference ① of the valve seat insert ②.
2. Allow the valve seat insert to cool for a few minutes. This will invite contraction and make removal of the valve seat insert easier.

3. Use a screwdriver ③ to pry the valve seat insert free.

Take care not to damage the cylinder head ④.



4. Carefully remove carbon and other foreign material from the cylinder head insert bore.



Valve Seat Installation

1. Carefully place the attachment ① (having the smaller outside diameter than the valve seat insert) on the valve seat insert ②.


Note:

The smooth side of the attachment must contact the valve seat insert.

2. Use a bench press ③ to slowly apply pressure to the attachment and press the valve seat insert into place. (Amount of pressure needed is more than 2,500 kg)

Note:

Do not apply an excessive amount of pressure with the bench press. Damage to the valve seat insert will result.




Valve Seat Insert Correction

1. Remove the carbon deposits from the valve seat insert surface.
2. Use valve cutters (15°, 30°, or 75° blades) to remove scratches and other rough areas.

This will bring the contact width back to the standard value of 90° (A).

Remove only the scratches and rough areas. Do not cut away too much. Take care not to cut away unblemished areas of the valve seat surfaces.




Angle Location	Standard
Intake Valve Seat Angle (B)	45°
Exhaust Valve Seat Angle (B)	45°

Note:

Use an adjustable valve cutter pilot.

Do not allow the cutter pilot to wobble inside the valve guide.



3. Apply abrasive compound to the valve seat insert surface.



4. Insert the valve into the valve guide.

5. Hand lap the valve and the valve seat with a lapping cup.

This will provide optimum valve and valve seat contact for effective gas sealing.

6. Check that the valve contact width is correct.

7. Check that the valve seat insert surface is in contact with the entire circumference of the valve.



VALVE SPRING

Valve Spring Free Length

Use a vernier caliper to measure the valve spring free length.

If the measured value is less than the specified limit, the valve spring must be replaced.

4BG1 mm (in)


	Standard	Limit
Exhaust and Intake Valve Spring Free Length	49.0 (1.929)	47.0 (1.850)


6BG1; with valve rotator mm (in)

	Color	Standard	Limit
Exhaust	pink	55.0 (2.165)	53.0 (2.087)

6BG1; without valve rotator mm (in)

	Color	Standard	Limit
Exhaust	blue	60.6 (2.39)	68.0 (2.68)






Valve Spring Inclination

Use a surface plate and a square to measure the valve spring inclination.

If the measured value exceeds the specified limit, the valve spring must be replaced.

mm (in)

	Standard	Limit
Valve Spring Inclination	less than 1.3 (0.051)	2.7 (0.106)



Valve Spring Tension

Use a spring tester to measure the valve spring tension.

If the measured value is less than the specified limit, the valve spring must be replaced.

4BG1

kg (lb)

Set Length	Standard	Limit
40 mm (1.57 in)	14.5 (30.9)	13.0 (28.7)

6BG1; with valve rotator


kg (lb)

Set Length	Standard	Limit
40 mm (1.57 in)	14.5 (30.9)	13.0 (28.7)

6BG1; without valve rotator


kg (lb)

Set Length	Standard	Limit
44.5 mm (1.75 in)	14.5 (30.9)	13.0 (28.7)



TAPPET (Cam Follower or Valve Lifter)


Inspect the tappets for excessive wear, damage and any abnormalities.



Use a micrometer to measure the tappet diameter.

mm (in)


	Standard	Limit
Tappet Diameter	27.97-27.98 (1.1020-1.1024)	27.92 (1.1000)



Use a dial indicator to measure the clearance between the tappet and cylinder body tappet travelling bore.

mm (in)

	Standard	Limit
Tappet and Tappet Travelling Bore Clearance	0.020–0.054 (0.001–0.002)	0.1 (0.004)




PUSH ROD

Use a filler gauge to measure the valve push rod run out.

Roll the push rod along a smooth flat surface (illustration).

mm (in)

	Limit
Push Rod Run-Out	0.3 (0.012)




Rocker Arm Correction

Inspect the rocker arm valve stem contact surfaces for ridge ① and scoring ②.


If the surfaces have light ridge or scoring, they may be honed with an oil stone.

If the ridge or scoring is severe, the rocker arm must be replaced.



ROCKER ARM SHAFT AND ROCKER ARM

Inspect all disassembled parts for wear, damage and any abnormalities.




Rocker Arm Shaft Outside Diameter

Use a micrometer to measure the rocker arm outside diameter.

If the measured value is less than the specified limit, the shaft must be replaced.

mm (in)

	Standard	Limit
Rocker Arm Shaft Diameter	18.98–19.00 (0.747–0.749)	18.85 (0.743)



Rocker Arm Shaft and Rocker Arm Clearance


1. Use a vernier caliper to measure the rocker arm bushing inside diameter.

mm (in)

	Standard	Limit
Rocker Arm Bushing Inside Diameter	19.01–19.03 (0.749–0.750)	19.05 (0.751)

2. Measure the rocker arm shaft outside diameter.

Replace either the rocker arm or the rocker arm shaft if the clearance exceeds the specified limit.




mm (in)

	Standard	Limit
Rocker Arm Bushing and Rocker Arm Shaft Clearance	0.01–0.05 (0.0004–0.0020)	0.2 (0.0079)

3. Check that the rocker arm oil port is free of obstructions.

If necessary, use compressed air to clean the rocker arm oil port.




IDLER GEAR AND IDLER GEAR SHAFT

1. Use a micrometer to measure the idler gear shaft outside diameter.

If measured diameter exceeds specified limit, replace the idler gear shaft.

mm (in)


	Standard	Limit
Idler Gear Shaft Outside Diameter	44.945–44.975 (1.769–1.771)	44.9 (1.768)



2. Use a dial indicator to measure the idler gear inside diameter.

mm (in)

	Standard	Limit
Idler Gear and Idler Gear Shaft Clearance	0.025–0.085 (0.001–0.003)	0.2 (0.008)



CAMSHAFT



1. Use the camshaft bearing remover and installer to remove camshaft bearing from the cylinder body.

Camshaft Bearing Remover and Installer: 9-8523-1818-0


2. Measure the clearance between the cam journal and the camshaft bearing.

mm (in)

	Standard	Limit
Cam Journal and Cam Bearing Clearance	0.03–0.09 (0.001–0.004)	0.15 (0.006)



3. Align the camshaft bearing oil holes with the mating oil ports (machined on the cylinder body camshaft bearing fitting bore).




4. Use a micrometer to measure the cam lobe height.

If the cam lobe height is less than the specified limit, the camshaft must be replaced.

mm (in)

	Standard	Limit
Cam Lobe Height (C-D)	7.71 (0.304)	7.21 (0.284)
Cam Journal Diameter	56.0 (2.205)	55.6 (2.189)



5. Place the camshaft on a measuring stand.


Use a dial indicator to measure the camshaft runout.

Note the total indicator reading (TIR).

If the measured run-out exceeds the specified limit, the camshaft must be replaced.

mm (in)

	Limit
Camshaft Run-Out TIR	0.12 (0.005)



CYLINDER BODY AND LINER

Cylinder Liner Bore Measurement


Use a cylinder indicator to measure the cylinder liner bore at measuring position ① in line with the crankshaft ② and across the crankshaft ③.

Measuring Point ① mm (in): 20.0 (0.79) (Maximum Wear Portion)

If the measured value exceeds the specified limit, the cylinder liner must be replaced.

mm (in)


	Standard	Limit
Cylinder Liner Bore Total Indicator Reading	105.021–105.060 (4.1347–4.1362)	105.20 (4.1417)



Note:

The inside of the dry type cylinder liner is chrome plated. It cannot be rebored or honed.

If the inside of the cylinder liner is scored or scorched, the cylinder liner must be replaced.




Cylinder Liner Projection Inspection

1. Hold a straight edge ① along the top edge of the cylinder liner to be measured.
2. Use a feeler gauge ② to measure each cylinder liner projection.

mm (in)

	Standard
Cylinder Liner Projection	0.03–0.10 (0.001–0.004)

The difference in the cylinder liner projection height between any two adjacent cylinders must not exceed 0.03 mm (0.001 in).



Cylinder Liner Replacement

Cylinder Liner Removal


1. Set the cylinder liner remover to the cylinder liner.
2. Check that the remover shaft ankle is firmly gripping the cylinder liner bottom edge.
3. Slowly turn the remover shaft handle counterclockwise to pull the cylinder liner free.

Cylinder Liner Remover: 9-8523-1169-0

Cylinder Liner Remover Ankle: 5-8523-1004-0

Note:

Take care not to damage the cylinder body upper face during the cylinder liner removal procedure.



Cylinder Bore Measurement


Cylinder Liner Grade Selection



The term "grade" refers to the cylinder body inside diameter and the cylinder liner outside diameter combination. Measure the cylinder body inside diameter and select the appropriate cylinder liner grade.

Loose fitting cylinder liners (the liner is too small for the cylinder bore) will adversely affect engine cooling efficiency and may lead to serious engine damage.

Cylinder liners which are too large for the cylinder bore will be difficult to install.





Cylinder Body Inside Diameter Measurement

1. Take measurements at measuring point ① across the positions W-W, X-X, Y-Y, and Z-Z.

Measuring Point ① : 115 mm (4.531 in)

2. Calculate the average value of the four measurements to determine the correct cylinder liner grade.





Cylinder Liner Outside Diameter Measurement

1. Take measurements at measuring point ①, ②, and ③.

Measuring Points mm (in):

- ① 20.0 (0.788)
 - ② 105.0 (4.137)
 - ③ 195.0 (7.683)
2. Calculate the average value of the 6 measurements to determine the correct cylinder liner grade.

mm (in)

Cylinder Liner Fitting Clearance Standard	0.001–0.019 (0.00004–0.0007)
--	---------------------------------

Cylinder Bore and Cylinder Liner Outside Diameter Combinations

(Reference)

4BG1, 6BG1


mm (in)

Grade	Cylinder Bore	Cylinder Liner Outside Diameter
1	107.001–107.010 (4.2126–4.2130)	107.011–107.020 (4.2130–4.2134)
2	107.011–107.020 (4.2130–4.2134)	107.021–107.030 (4.2134–4.2138)
3	107.021–107.030 (4.2134–4.2138)	107.031–107.040 (4.2138–4.2142)



Cylinder Liner Installation

1. Carefully wipe away any foreign material from the cylinder liner inside and outside surfaces and the cylinder bore.
2. Use new kerosene or diesel oil to thoroughly clean the cylinder liner and bore surfaces.
3. Use a clean rag to remove all traces of kerosene or diesel oil from the cylinder liner and bore surfaces.




4. Insert the cylinder liner ① into the cylinder body ② from the top of the cylinder body.
5. Set the cylinder liner installer ③ to the top of the cylinder liner.

Cylinder Liner Installer: 5-8522-1018-0

6. Position the cylinder body so that the installer center ③ is directly beneath the bench press shaft center ④.
7. Check that the cylinder liner is set perpendicular to the cylinder.

Check that the cylinder liner does not wobble.



8. Use the bench press to apply an initial seating force of 500 kg (1,102.5 lb) to the cylinder liner.
9. Use the bench press to apply a final seating force of 2,500 kg (5,512.5 lb) to fully seat the cylinder liner.
10. After installing the cylinder liner, measure the cylinder liner projection.


Refer to "Cylinder Liner Projection Inspection."

Piston Grade Selection

The term "piston grade" refers to the piston diameter and cylinder liner bore combination.

Selection of the proper piston grade will ensure efficient engine operation, free from cylinder liner and piston problems.

Measure the cylinder liner bore after installing the cylinder liner. Then select the appropriate piston grade for the installed cylinder liner.



Cylinder Liner Bore Measurement

1. Locate the two measuring points.

Cylinder Liner Measuring Point ①: 20 mm (0.788 in)

Cylinder Liner Measuring Point ②: 105 mm (4.173 in)

2. Measure the cylinder liner bore at measuring point ① and ② in four different directions (W-W, X-X, Y-Y, and Z-Z).
3. Calculate the average value of the eight measurements.


mm (in)

Cylinder Liner Bore Total Indicator Reading	105.021–105.060 (4.1347–4.1362)
---	------------------------------------

Note:

It is most important that the correct piston grade be used. Failure to select the correct piston grade will result in piston seizure.

Always measure the cylinder bore and select the appropriate piston grade.

**Piston Outside Diameter**

Measure the piston outside diameter at the measuring piston shown in the illustration.

Piston Grade mm (in)

	Ⓐ	Ⓒ
4BG1	104.955–104.974 (4.1321–4.1328)	104.975–104.994 (4.1329–4.1336)
4BG1T	104.945–104.964 (4.1317–4.1324)	104.965–104.984 (4.1325–4.1332)
6BG1	104.955–104.974 (4.1321–4.1328)	104.975–104.994 (4.1329–4.1336)
6BG1T		

Cylinder Liner Bore and Piston Clearance


mm (in)

	4BG1, 6BG1, 6BG1T	4BG1T
Cylinder Liner Bore and Piston Clearance	0.047–0.085 (0.0019–0.0033)	0.057–0.095 (0.0022–0.0037)

Note:

Cylinder liner piston kit clearances are preset. However, the cylinder liner installation procedure may result in slight decreases in cylinder liner bore clearances.

Always measure the cylinder liner bore clearance after installation to be sure that it is correct.




PISTON AND PISTON RING

Piston Ring and Piston Ring Groove Clearance

Use a feeler gauge to measure the clearance between the piston ring and the piston ring groove.

Do this at several points around the piston.

If the clearance between the piston ring and the piston ring groove exceeds the specified limit, the piston ring must be replaced.



Piston Ring and Piston Ring Groove Clearance

4BG1 mm (in)

	Standard	Limit
1st Compression Ring	0.085–0.110 (0.0033–0.0043)	0.20 (0.0079)
2nd Compression Ring	0.030–0.055 (0.0018–0.0022)	0.15 (0.0059)
Oil Ring	0.030–0.070 (0.0018–0.0027)	0.15 (0.0059)

4BG1T mm (in)


	Standard	Limit
1st Compression Ring	0.105–0.130 (0.0041–0.0051)	0.20 (0.0079)
2nd Compression Ring	0.050–0.075 (0.0020–0.0029)	0.15 (0.0059)
Oil Ring	0.030–0.070 (0.0012–0.0027)	0.15 (0.0059)

6BG1 mm (in)

	Standard	Limit
1st Compression Ring	0.105–0.130 (0.0041–0.0051)	0.20 (0.0079)
2nd Compression Ring	0.030–0.065 (0.0012–0.0026)	0.15 (0.0059)
Oil Ring	0.030–0.070 (0.0012–0.0027)	0.15 (0.0059)

6BG1T mm (in)

	Standard	Limit
1st Compression Ring	0.085–0.120 (0.0033–0.0047)	0.20 (0.0079)
2nd Compression Ring	0.050–0.085 (0.0020–0.0033)	0.15 (0.0059)
Oil Ring	0.030–0.070 (0.0012–0.0027)	0.15 (0.0059)



Piston Ring Gap

1. Insert the piston ring horizontally (in the position it would assume if it were installed to the piston) into the cylinder liner.
2. Use an inverted piston to push the piston ring into the cylinder liner until it reaches either measuring point ① or measuring point ②. Cylinder liner diameter is the smallest at these two points.

Do not allow the piston ring to slant to one side or the other. It must be perfectly horizontal.

Cylinder Liner Measuring Point ①: 10mm (0.39 in)

Cylinder Liner Measuring Point ②: 130mm (5.12 in)

3. Use a feeler gauge to measure the piston ring gap.

If the measured value exceeds the specified limit, the piston ring must be replaced.

Piston Ring Gap

4BG1


mm (in)

	Standard	Limit
1st Compression Ring	0.25–0.45 (0.010–0.018)	1.5 (0.059)
2nd Compression Ring	0.35–0.50 (0.014–0.020)	
Oil Ring	0.30–0.50 (0.012–0.020)	

4BG1T, 6BG1, 6BG1T

mm (in)

	Standard	Limit
1st Compression Ring	0.35–0.50 (0.014–0.020)	1.5 (0.059)
2nd Compression Ring	0.35–0.50 (0.014–0.020)	
Oil Ring	0.30–0.50 (0.014–0.020)	



PISTON PIN


Piston Pin Outside Diameter

Use a micrometer to measure the piston pin outside diameter at several points.

If the measured piston pin outside diameter exceeds the specified limit, the piston pin must be replaced.

mm (in)

	Standard	Limit
Piston Pin Outside Diameter	35.000–35.005 (1.3780–1.3781)	34.95 (1.3760)




Piston Pin and Piston Clearance

Use an inside dial indicator to measure the piston pin hole.

mm (in)

Piston Pin Hole Diameter	Standard
4BG1, 4BG1T, 6BG1 6BG1T	35.010–35.018 (1.3783–1.3787)




Piston Pin and Piston Pin Hole Clearance

Determine the clearance between the piston pin and the piston pin hole by calculating the difference between the piston pin hole diameter and the piston pin outside diameter.

mm (in)


	Limit
Piston Pin and Piston Pin Hole Clearance	0.050 (0.002)



If an inside dial indicator is not available, use the following procedure to check the piston pin fit.

1. Use a piston heater to heat the piston to approximately 60°C (140°F).
2. Push strongly against the piston pin with your thumbs.

The piston pin fitting should feel tight.



CONNECTING ROD

Connecting Rod Alignment



Use a connecting rod aligner to measure the parallelism between the connecting rod big end hole and the connecting rod small end hole.


If either the measured parallelism exceeds the specified limit, the connecting rod must be replaced.

Connecting Rod Alignment

(Per Length of 100 mm (3.94 in))

mm (in)

	Standard	Limit
Parallelism	0.05 (0.0002) or less	0.20 (0.0079)



Piston Pin and Connecting Rod Small End Bushing Clearance



Use a caliper calibrator and a micrometer to measure the piston pin and connecting rod small end bushing clearance.

If the clearance between the piston pin and the connecting rod small end bushing exceeds the specified limit, replace either the piston pin or the connecting rod bushing.

mm (in)

	Standard	Limit
Piston Pin and Connecting Rod Small End Bushing Clearance	0.012–0.025 (0.0004–0.0010)	0.05 (0.0020)

Connecting Rod Bushing Replacement


Connecting Rod Bushing Removal



1. Clamp the connecting rod in a vise.



2. Use a brass bar and a bench press or hammer to remove the connecting rod bushing.



Connecting Rod Bushing Installation

Use the connecting rod bushing installer to install the connecting rod bushing.

Connecting Rod Bushing Installer: 9-8523-1369-0
(J-29765)



Note:

The connecting rod bushing oil port must be aligned with the connecting rod oil port.

- Use a piston pin hole grinder ① fitted with a reamer ② or an adjustable pilot reamer to ream the piston pin hole.

mm (in)

	Standard
Connecting Rod Bushing Inside Diameter	35.017–35.025 (1.3786–1.3789)




Connecting Rod Bearing Inspection

- Fit the connecting rod bearing lower half into the connecting rod bearing cap.
- Check the connecting rod bearing lower half tension.
If the tension is insufficient, the bearing must be replaced.
- Tighten the connecting rod and the bearing cap to the specified torque.

kg·m(lb.ft)

	1st step	2nd step
Connecting Rod and Bearing Cap Bolt Tightening Torque	4 (28.9)	60°–90°



- Use an inside dial indicator to measure the connecting rod inside diameter.

mm (in)


Connecting Rod Bearing Nominal Diameter	64 (2.520)
--	------------

CRANKSHAFT

Crankshaft and Bearing Inspection



1. Inspect the crankshaft journal surfaces and the crank pin surfaces for excessive wear and damage.
2. Inspect the oil seal fitting surfaces of the crankshaft front and rear ends for excessive wear and damage.
3. Replace or repair the crankshaft if any excessive wear or damage is discovered.
4. Inspect the crankshaft oil ports for obstructions.
5. Use high pressure air to clean the oil ports if necessary.



Crankshaft Journal and Crankpin Outside Diameter

1. Use a micrometer to measure the crankshaft journal outside diameter across points ① – ① and ② – ②.
2. Use the micrometer to measure the crankshaft journal outside diameter at the two points (③ and ④).
3. Repeat steps 1 and 2 to measure the crankshaft outside diameter.

mm (in)

6B Engines only	Position at	Standard
Crankshaft Journal Diameter	Center Bearing Only	79.905–79.925 (3.1459–3.1467)
	Other Bearings	79.919–79.939 (3.1464–3.1472)

mm (in)

4B Engines only	Position at	Standard
Crankshaft Journal Diameter	All Bearings	79.905–79.925 (3.1459–3.1467)

mm (in)

	Standard
Crankshaft Pin Diameter	63.924–63.944 (2.5167–2.5175)

4. Measure the crankshaft journal outside diameter (and/or the crankpin outside diameter) and the bearing inside diameters to determine the bearing clearance.

Crankshaft Journal and Bearing Clearances

If the bearing clearance exceeds the specified limit, the crankshaft must be reground (except 4BD1T, 6BD1T, 6BG1 and 6BG1T) and/or the bearing must be replaced.

mm (in)


6B Engines Only	Position at	Standard	Limit
Crankshaft Journal and Main Bearing Clearance	Center Bearing Only	0.039–0.098 (0.0015–0.0039)	0.11 (0.0043)
	Other Bearings	0.025–0.084 (0.0010–0.0033)	

mm (in)

4B Engines Only	Position at	Standard	Limit
Crankshaft Journal and Main Bearing Clearance	All Bearings	0.039–0.098 (0.0015–0.0039)	0.11 (0.0043)

mm (in)

	Standard	Limit
Crankpin and Connecting Rod Bearing Clearance	0.03–0.07 (0.0012–0.0028)	0.10 (0.0039)



Crankshaft Journal Bearing Inside Diameter


1. Install the main bearing cap with bearings to the cylinder body with the specified torque and facing the arrow mark on the bearing cap toward front. Place them in order of punched cylinder numbers.
2. Use an inside dial indicator to measure the main bearing diameters.

kg·m(lb.ft)

Main Bearing Cap Torque	23 – 25 (160 – 181)
-------------------------	------------------------

mm (in)

Main Bearing Nominal Diameter	80 (3.149)
-------------------------------	---------------



Crankshaft Run-Out

1. Mount the crankshaft on a set of V-blocks.
2. Set a dial indicator to the center of the crankshaft journal.
3. Gently turn the crankshaft in the normal direction of engine rotation.

Read the dial indicator (TIR) as you turn the crankshaft.


If the measured value exceeds the specified limit, the crankshaft must be replaced.

mm (in)

	Model	Standard	Limit
Crankshaft Run-Out	6B	0.05 (0.002)	0.40 (0.016)
	4B		0.30 (0.012)

If the crankshaft generated a crack after repair, replace the crankshaft.

Crankshaft can not be bench pressed, because it is finished with tufftride method.



Main Bearing and Connecting Rod Bearing Tension

Check to see if the bearing has enough tension, so that good finger pressure is needed to fit the bearing into position.

Crankshaft Regrinding

Note:

Crankshaft for 4BG1, 4BG1T, 6BG1 and 6BG1T can not be reground because it is finished with TUFFTRIDE method.

For the crankshaft on 4BG1, 4BG1T, 6BG1 and 6BG1T, no attempt should be made to grind finish the faces of the journals and crankpins as they are TUFFTRIDED (Special hardening treatment).

Therefore, the undersize bearings are not prepared:

Plastigage Clearance Measurements

This is another method to measure the crankjournal bearing clearance.

Crankshaft Journal Bearing Clearance

1. Clean the cylinder body, the journal bearing fitting portions, the bearing cap, and the inside the outside surfaces of the bearing.
2. Install the new journal bearing to the cylinder body.
3. Carefully place the crankshaft on the bearing.
4. Rotate the crankshaft approximately 30° to seat the bearing.
5. Place the Plastigage (arrow) over the crankshaft journal across the full width of the bearing.

Apply engine oil to the Plastigage to keep it from falling.




6. Install the bearing cap with the bearing.
7. Tighten the bearing cap to the specified torque.

Do not allow the crankshaft to turn during bearing cap installation and tightening.

8. Remove the bearing cap.
9. Compare the width of the plastigage attached to either the crankshaft or the bearing against the scale printed on the plastigage container.

If the measured value exceeds the limit, perform the following additional steps.

- 1) Use a micrometer to measure the crankshaft outside diameter.
- 2) Use an inside dial indicator to measure the bearing inside diameter.
- 3) Replace the crankshaft and/or the bearing if the measured value(s) exceed the limit.



Crankshaft Pin Bearing Clearance

1. Clean the crankshaft, the connecting rod, the bearing cap, and the bearings.
2. Install the bearing to the connecting rod.
Do not allow the crankshaft to move when installing the bearing cap.
3. Hold the connecting rod (with the bearing installed) against the crankshaft pin.
4. Attach the plastigage to the crankshaft pin.
Apply engine oil to the plastigage to keep it from falling.




5. Install the connecting rod bearing cap and tighten it to the specified torque.
Do not allow the connecting rod to move when installing and tightening the bearing cap.



6. Remove the bearing cap.
7. Compare the width of the plastigage attached to either the crankshaft or the bearing against the scale printed on the plastigage container.

If the measured value exceeds the limit, perform the following additional steps.

- 1) Use a micrometer to measure the crankshaft outside diameter.
- 2) Use an inside dial indicator to measure the bearing inside diameter.
- 3) Replace the crankshaft and/or the bearing if the measured value(s) exceed the limit.

**Crankshaft Tufftriding Inspection****Inspection**

Model 4BG1, 4BG1T, 6BG1 and 6BG1T

1. Use an organic cleaner to thoroughly clean the crankshaft. There must be no traces of oil on the surfaces to be inspected.
2. Prepare a 10% solution of ammonium cuprous chloride (dissolved in distilled water).
3. Use a spot glass rod to apply the solution to the surface to be inspected.

Hold the surface to be inspected perfectly horizontal to prevent the solution from running.

Note:

Do not allow the solution to come in contact with the oil ports and their surrounding area.

Judgement

1. Wait for thirty to forty seconds.


If there is no discoloration after thirty or forty seconds, the crankshaft is usable.

If discoloration appears (the surface being tested will become the color of copper), the crankshaft must be replaced.

2. Clean the surface being tested with clean water or steam immediately after completing the test.

Note:

The ammonium cuprous chloride solution is highly corrosive. Because of this, it is imperative that the surfaces being tested be cleaned immediately after completing the test.




Oil Seal Wear Ring Replacement

Removal



Use the oil seal wear ring remover to remove the oil seal wear ring from the crankshaft front end.

Oil Seal Wear Ring Remover: 1-85210-0560



Installation

Use a brass bar and a hammer to drive the oil seal wear ring into place.


Oil Seal Wear Ring Installer: 1-85220-031-0



Crankshaft Gear Inspection

Visually inspect the crankshaft gear.

Replace the crankshaft gear if excessive wear or damage is discovered.




Crankshaft Gear Replacement

Removal



Use the crankshaft gear remover to remove the crankshaft gear.

Crankshaft Gear Remover: 9-8521-0141-0




Installation



Use the crankshaft gear installer to install the crankshaft gear.

Crankshaft Gear Installer: 9-8522-0033-0



FLYWHEEL AND FLYWHEEL HOUSING (REAR OIL SEAL)

Ring Gear Inspection

Inspect the ring gear.

If the ring gear teeth are broken or excessively worn, the ring gear must be replaced.

Ring Gear Replacement

Ring Gear Removal



Strike around the edges of the ring gear with a hammer and chisel to remove it.



Ring Gear Installation

1. Heat the ring gear evenly with a gas-burner to invite thermal expansion.

Do not allow the temperature of the ring gear to exceed 200°C (390°F).



2. Use a hammer to install the ring gear when it is sufficiently heated.



Flywheel Housing Oil Seal Replacement

Removal




Use a pry bar to remove the flywheel housing oil seal.

Installation



Use the oil seal installer to install the flywheel housing oil seal.

Oil Seal Installer: 9-8522-1254-0



TIMING GEAR CASE COVER

Crankshaft Front Oil Seal Replacement

Removal



Use an adapter and a hammer to remove the crankshaft front end oil seal.

Installation



Use the crankshaft front oil seal installer to install the crankshaft front oil seal.

Crankshaft Front Oil Seal Installer: 9-8522-0034-0

SECTION 5

**ENGINE ASSEMBLY III
(REASSEMBLY)**


TABLE OF CONTENTS

ITEM	PAGE
Piston and connecting rod reassembly steps.....	5- 2
Cylinder head reassembly steps	5- 4
Rocker arm and rocker arm shaft reassembly steps.....	5- 8
Major component reassembly steps I.....	5- 9
Major component reassembly steps II.....	5-14
External parts reassembly steps (Left-Hand Side)	5-19
External parts reassembly steps (Right-Hand Side)	5-23
Engine tuning operation	5-26
Engine sectional view	5-28







PISTON AND CONNECTING ROD REASSEMBLY STEPS

MIRROR COMPONENT



Reassembly Steps

- | | |
|------------------------------------|-----------------------------|
| ▲ 1. Piston | ▲ 4. Piston ring |
| ▲ 2. Piston pin and connecting-rod | ▲ 5. Connecting rod bearing |
| ▲ 3. Snap ring | |



PISTON AND CONNECTING ROD

Important Operations

1. Piston

Use a piston heater to heat the pistons to approximately 60°C (140°F).

2. Connecting Rod

- 1) Install the connecting rod to the piston with setting the marks as illustrated.
- 2) Install the piston pin into the piston and the connecting rod bushing.

Refer the description of piston pin in page 4-19.

3. Piston Pin Snap Ring

- 1) Use a pair of snap ring pliers to install the piston pin snap ring.
- 2) Check that the piston moves smoothly on the piston pin.

4. Piston Ring

- 1) Use a piston ring installer to install the three piston rings.

Piston Ring Installer

Install the piston rings in the following order.

- (1) Oil ring
- (2) 2nd compression ring
- (3) 1st compression ring

The marked side of the two compression rings must be facing up.

The undercut side of the second compression ring will be facing down.

As the oil ring has no any facing mark, it may face in either direction.


- 2) Lubricate the piston ring surfaces with engine oil.
- 3) Check that the piston rings rotate smoothly in the piston ring grooves.

5. Connecting Rod Bearing

- 1) Install the connecting rod bearings to the connecting rod large-end and the connecting rod cap.
- 2) Install the bearing cap to the connecting rod with semi-tightening the cap bolts.
- 3) Lubricate the bearing with engine oil.




CYLINDER HEAD REASSEMBLY STEPS



★ : Repair kit

Reassembly Steps

- ▲ 1. Valve stem oil seal
- ▲ 2. Intake and exhaust valves
- 3. Spring seat (Lower)
- ▲ 4. Intake and exhaust valve springs
- 5. Spring seat (Upper) or valve rotator
- ▲ 6. Spring seat split collar
- 7. Thermostat housing and gasket
- 8. Thermostat
- 9. Water outlet pipe
- ▲ 10. Intake manifold and gasket
- ▲ 11. Exhaust manifold and gasket




Important Operations



1. Valve Stem Oil Seal

- 1) Lubricate the oil seals and valve stem sealing areas with engine oil.
- 2) Use a valve stem oil seal installer to install the oil seal.


Valve Stem Oil Seal Installer: 1-85221-005-0



2. Intake and Exhaust Valves


- 1) Place the cylinder head on a flat wooden surface.
- 2) Lubricate valve stems with engine oil.
- 3) Install the valves to the intake or exhaust guides.

Install the valves to their original lapped valve seats.



4. Intake and Exhaust Valve Springs


Install the valve springs with their painted end (the close pitched end) facing down.




6. Spring Seat Split Collar

- 1) Use a spring compressor to push the valve spring into position.
- 2) Install the spring seat split collar.
- 3) Set the spring seat split collar by tapping lightly around the head of the collar with a rubber hammer.

Spring Compressor: 1-85235-006-0





10. Intake Manifold and Gasket

- 1) Install the intake manifold gasket.



The intake manifold gasket must be installed with its unchamfered corner facing up and to the front of the engine.

Refer to the illustration.

- 2) Install the intake manifold.
- 3) Tighten the intake manifold bolts to the specified torque a little at a time in the numerical order shown in the illustration.

kg·m (lb.ft)

Intake Manifold Bolt Torque	4B	1.4-2.4 (10.1-17.4)
	6B	2.1-3.1 (15.2-22.4)



11. Exhaust Manifold and Gasket

- 1) Install the exhaust manifold gasket.

The "TOP" mark must be facing up.

- 2) Install the exhaust manifold.
- 3) Tighten the exhaust manifold bolts to the specified torque a little at a time in the numerical order shown in the illustration.



kg·m (lb.ft)



Exhaust Manifold Bolt Torque	4B	1.6-2.6 (11.6-18.8)
	6B	2.6-3.2 (18.8-23.1)

Note:

4B and 6B engines use a different exhaust manifold gasket.

Refer to the illustration to determine the correct gasket for your engine.






- 4) Install either end of the distance tube to the spot facing (6B series engine only).



ROCKER ARM AND ROCKER ARM SHAFT REASSEMBLY STEPS



Reassembly Steps

- ▲ 1. Rocker arm shaft
- 2. Spring

- 3. Rocker arm
- 4. Bracket



Important Operation




1. Rocker Arm Shaft

The rocker arm shaft must be installed with the oil ports facing up.



MAJOR COMPONENT REASSEMBLY STEPS I




Reassembly Steps

- ▲ 1. Oiling jet (except 6BG1)
- ▲ 2. Crankshaft bearing (upper half)
- ▲ 3. Crankshaft
- ▲ 4. Thrust bearing
- ▲ 5. Crankshaft bearing (lower half) and crankshaft bearing cap
- ▲ 6. Timing gear case
- * 7. Tappet
- ▲ 8. Camshaft

- ▲ 9. Idler gear shaft
- ▲ 10. Idler gear
- ▲ 11. Piston and connecting rod
- ▲ 12. Oil pump and coupling
- ▲ 13. Flywheel housing
- ▲ 14. Oil pan
- ▲ 15. Oil cooler


* The tappet must be installed before the camshaft installation.



Important Operations

1. Oil Jet

Install the oil jets taking care not to damage the oil jet nozzles.



kg-m (lb.ft)

Oil Jet Torque	1.6-2.6 (11.6-18.8)
----------------	---------------------


2. Crankshaft Bearing (Upper Half)

5. Crankshaft Bearing (Lower Half) and Crankshaft Bearing Cap

The Crankshaft Bearing Configuration


		With Oil Groove	Without Oil Groove
Bearing Upper Half	4B	All Upper Halves	—
	6B	All Upper Halves	—
Bearing Lower Half	4B	All Lower Halves Except Center Bearing	Center Bearing Only
	6B	—	All Lower Halves

Take care not to misinstall the bearing halves.



4. Thrust Bearing

Install the thrust bearings with the oil groove side facing the crankshaft sliding face.




5. Camshaft Bearing Cap

- 1) Lubricate the bearing cap bolts with engine oil.
- 2) Install the bearing caps to the crankshaft.

The arrow mark must be pointing to the front of the engine.

- 3) Tighten the bearing cap bolts to the specified torque a little at a time in the numerical order shown in the illustration.




Crankshaft Bearing Cap Bolt Torque

kg·m (lb.ft)

23.0–25.0 (166–181)

- 4) Check that the crankshaft turns smoothly by manually rotating it.




6. Timing Gear Case

- 1) Apply liquid gasket to the timing gear case surfaces contacting the cylinder body.
- 2) Tighten the timing gear case bolts to the specified torque.

kg·m (lb.ft)

Timing Gear Case Bolt Torque

2.1–3.1 (15.2–22.4)



8. Camshaft

- Tighten the thrust plate bolts through the camshaft gear hole.

kg·m (lb.ft)


Thrust Plate Bolt Torque

2.1–3.1 (15.2–22.4)

kg·m (lb.ft)

Camshaft Gear Bolt Torque


14.5–17.5 (105–127)



9. Idler Gear Shaft

- Use the thrust collar fixing bolt as a guide to install the idler gear shaft.

The oil port must be facing the camshaft.



10. Idler Gear

- 1) Install the idler gear.

Set the timing marks [A] and [B] as shown in the illustration.

- 2) Tighten the idler gear bolts seating the thrust collar to the specified torque.





The thrust collar must be installed with the chamfered side facing the front of the engine.

kg·m (lb.ft)

Idle Gear Bolt Torque

4B 4.3–6.3 (31.1–45.6)

6B 4.5–6.5 (32.5–47.0)



11. Piston and Connecting Rod

Position the piston ring gaps as shown in the illustration.

- 1) Set the piston ring gaps as shown in the illustration.
- 2) Lubricate the piston, the piston rings, and the connecting rod bearings with engine oil.
- 3) Position the piston front mark towards the front of the engine.

- 4) Use the piston ring compressor to compress the piston rings.

Piston Ring Compressor: 9-8522-1251-0

- 5) Use a hammer grip to push the piston in until it makes contact with the crankpin.

At the same time, rotate the crankshaft until the crankpin reaches its highest point.

- 6) Set the bearing cap cylinder number marks and the connecting rod cylinder number marks.

The marks must be facing the exhaust manifold.

- 7) Lubricate the connecting rod cap bolt threads and setting faces with Mos grease.

- 8) Use the angular tightening method to tighten the connecting rod cap bolts to the specified torque.


kg·m (lb.ft)

	1st step	2nd step
Connecting Rod Bolt Torque and Angle	4 (28.9)	60°-90°

12. Oil Pump and Coupling




- 1) Lubricate the oil pump with the specified grade of engine oil.



- 2) Install the oil pump with the coupling.
- 3) Tighten the oil pump bolts to the specified torque.

kg·m (lb.ft)

Oil Pump Bolt Torque	4.3–6.3 (31.1–45.6)
----------------------	---------------------



13. Flywheel Housing


- 1) Apply a liquid gasket to the shaded area of the illustration.

- 2) Install the flywheel housing.

Tighten the flywheel housing bolts to the specified torque.

kg·m (lb.ft)

Flywheel Housing Bolt Torque	Outer Bolt	15.0–17.0 (108–123)
	Inner Bolt	2.1–3.1 (15.2–22.4)



14. Oil Pan

- 1) Apply liquid gasket to the area indicated by the arrows in the illustration.


- 2) Install the oil pan gasket

- 3) Install the oil pan.

Tighten the oil pan bolts to the specified torque.

kg·m (lb.ft)

Oil Pan Bolt Torque	2.1–3.1 (15.2–22.4)
---------------------	---------------------



15. Oil Cooler

- 1) Apply liquid gasket to the oil cooler gasket.

- 2) Install the oil cooler gasket to the oil cooler body case.

- 3) Install the oil cooler.

Tighten the oil cooler bolts to the specified torque.

Start from the middle and work out to either side.


Refer to the illustration

kg·m (lb.ft)

Oil Cooler Torque	4B	1.6–2.6 (11.6–18.8)
	6B	1.4–2.4 (10.1–17.4)




MAJOR COMPONENT REASSEMBLY STEPS II



★ : Repair kit

Reassembly Steps

- ▲ 1. Flywheel
- ▲ 2. Injection pump and injection pump gear
- ▲ 3. Oil thrower
- ▲ 4. Timing gear cover
- ▲ 5. Crankshaft pulley and dust thrower
- ▲ 6. Taper bushing
- ▲ 7. Crankshaft pulley nut
- ▲ 8. Oil pump driving pinion
- ▲ 9. Tappet chamber cover
- ▲ 10. Water pump
- ▲ 11. Cylinder head gasket
- ▲ 12. Cylinder head
- ▲ 13. Cylinder head bolt
- ▲ 14. Push rod
- ▲ 15. Rocker arm and rocker arm shaft
- ▲ 16. Rubber hose (Water by-pass)



Important Operations

1. Flywheel



1) Lubricate the flywheel bolt threads.





2) Install the flywheel.

The crankshaft rear end dowel pin and the flywheel dowel hole must be aligned.

3) Tighten the flywheel bolts to the specified torque in the numerical order shown in the illustration.

kg-m (lb.ft)

Flywheel Bolt Torque	4B engine	14.5-17.5 (105-127)
	6B engine	20.1-24.5 (145-177)



2. Injection Pump and Injection Pump Gear Assembly

1) Install the injection pump bracket with the injection pump to the timing gear case.


Dowel the injection pump bracket with the timing gear case.



2) Tighten the injection pump bolts to the specified torque.

kg-m (lb.ft)


Injection Pump Bolt Torque	2.1 - 3.1 (15.2 - 22.4)
----------------------------	-------------------------



3) Align the injection pump gear "C" timing mark with the idler gear "C" timing mark.

Air Compressor Installation (If so equipped)

1. Align the air compressor crankshaft spline end marks and the injection pump drive gear shaft female spline marks.



2. Install the air compressor


3. Tighten the air compressor mounting bolts.



After installing the air compressor, perform Step 3 of "Injection Pump and Injection Pump Gear Assembly" (on the following page).



Refer to injection timing in section MAINTENANCE to check the injection timing for correctness.




7. Crankshaft Pulley Nut

1) Apply MoS2 to the crankshaft pulley nut threads and fitting face.

2) Use the appropriate wrench to tighten the crankshaft pulley nut to the specified torque.

kg·m (lb.ft)

Crankshaft Pulley Nut Torque	4B	39-49 (282-354)
	6B	55-65 (378-470)




9. Tappet Chamber Cover

1) Apply liquid gasket to the tappet chamber cover gasket.

2) Install the tappet chamber cover and tighten the bolts to the specified torque.

kg·m (lb.ft)


Tappet Chamber Cover Bolt Torque	2.1 - 3.1 (15.2 - 22.4)
----------------------------------	-------------------------



Apply sealant to the cylinder body side only.

10. Water Pump

Apply sealant (Belco Bond No. 4) to the water pump gasket before installing the water pump.



11. Cylinder Head Gasket



12. Cylinder Head





13. Cylinder Head Bolt

1) Carefully place the cylinder head gasket on the cylinder body upper surface.

The gasket "TOP" mark must be facing up.

2) Align the cylinder body dowels and the cylinder head dowel holes.

6B series**4B series**

3) Carefully place the cylinder head on the cylinder body.

4) Tighten the cylinder head bolt as follows.

1) As cylinder head bolts have two kinds of length, install them at proper location.

The shorter ones (4B series; 4 bolts, 6B series; 6 bolts) must be used at the injection pump side.

2) Follow the numerical sequence shown in the illustrations.

3) The cylinder head bolt tightening method vary depending on the gasket type to be used.

For laminated steel type gasket.

Apply molybdenum disulfide grease to the cylinder head bolt threads and setting faces.

Use the Angular Tightening Method.

kg·m (lb.ft)

	1st step	2nd step	3rd step
Bolt Torque	7.0 (50.6)	8.5-9.5 (62-69)	90°-120°

15. Rocker Arm and Rocker Arm Shaft



- 1) Check that the rocker arm shaft bracket lower surface oil port is free from obstruction.
- 2) Install the rocker arm shaft with the bracket to the cylinder head.
- 3) Tighten the rocker arm bracket bolts to the specified torque a little at a time in the numerical order shown in the illustration.
- 4) Lubricate the rocker arm and the rocker arm shaft with engine oil.

kg-m (lb.ft)

Rocker Arm Shaft	6B	2.6-3.6 (18.8-26.0)
Bracket Bolt Torque	4B	2.0-3.0 (14.5-21.7)


- 5) Adjust the valve clearance.

Refer to MAINTENANCE for the valve clearance adjustment procedure.







EXTERNAL PARTS REASSEMBLY STEPS (Left-hand side)



Reassembly Steps

- | | |
|---|-----------------------------|
| ▲ 1. Cylinder head cover | ▲ 7. Turbocharger |
| 2. Fan pulley | ▲ 8. Oil drain pipe |
| 3. Generator | ▲ 9. Oil feed pipe |
| ▲ 4. Fan belt | ▲ 10. Turbo adapter |
| ▲ 5. Starter | 11. Air breather |
| ▲ 6. Turbocharger mounting flange gasket. | 12. Dipstick and guide tube |



Important Operations

1. Cylinder Head Cover

- 1) Check that the rocker arms, the rocker arm shafts, and the valve springs are thoroughly lubricated with engine oil.

If required, relubricate these parts.

- 2) Place the cylinder head cover gasket on the cylinder head cover.

Check the head cover gasket for looseness.

- 3) Tighten the cylinder head cover bolts to the specified torque a little at a time in the sequence shown in the illustration.



6B Series kg·m (lb.ft)

Cylinder Head Cover Bolt Torque	0.8 – 1.0 (5.8 – 7.2)
---------------------------------	-----------------------

4B Series kg·m (lb.ft)


Cylinder Head Cover Bolt Torque	0.6 – 1.6 (4.3 – 11.6)
---------------------------------	------------------------



4. Fan Belt

Adjust the fan belt tension.

Refer to MAINTENANCE for the fan belt tension adjustment.




5. Starter



Install the starter to the flywheel housing and tighten the bolts to the specified torque.

kg·m (lb.ft)

Starter Fixing Bolts Torque	7.6 – 9.3 (55 – 67)
-----------------------------	---------------------

6BG1T**6. Turbocharger Mounting Flange Gasket**

Carefully position the gasket with the edged side facing up.


4BG1T**7. Turbocharger (4BG1T and 6BG1T)**

Semitighten the turbocharger mounting nuts.

The nuts will be fully tightened after installation of the oil pipes.

kg·m(lb·ft)

Turbocharger Mounting Nut Torque	6BG1T	4.3–6.3 (31.1–45.6)
	4BG1T	2.2–3.2 (15.9–23.1)

**8. Oil Drain Pipe**

- 1) Remove the exhaust manifold distance tube immediately beneath the turbocharger.

This will make it easier to install the oil drain pipe.

- 2) Install the oil drain pipe and tighten the oil drain pipe flange nuts to the specified torque.


kg·m(lb·ft)

Oil Drain Pipe Torque	2.9 – 4.7 (21.0 – 34.0)
-----------------------	-------------------------



- 3) Reinstall the exhaust manifold distance tube and tighten it to the specified torque.

Exhaust manifold nut torque is shown in the page 5-6.




9. Oil Feed Pipe

- 1) Pre-lubricate the turbocharger with CD grade oil through the oil port shown by the arrow in the illustration.
- 2) Install the oil feed pipe and tighten the pipe flange bolts to the specified torque.

kg·m (lb.ft)

Oil Feed Pipe Flange Bolt Torque	4B	1.2 – 1.6 (8.7 – 11.6)
	6B	2.1 – 3.1 (15.2 – 22.4)




10. Turbo Adaptor (6BG1T Only)

- 1) Use a screw driver to insert the gas sealing ring to the turbocharger exhaust outlet port.
- 2) Tighten the turbo adaptor fixing bolts to the specified torque.

kg·m (lb.ft)


Turbo Adaptor Fixing Bolt Torque	4.3 – 6.3 (31.1 – 45.6)
----------------------------------	-------------------------






EXTERNAL PARTS REASSEMBLY STEPS (Right-hand Side)

MODEL 6BG1T



Reassembly Steps

- | | |
|--|--|
| 1. Glow plug | 8. Fuel filter |
| ▲ 2. Injection nozzle | ▲ 9. Fuel pipe; feed pump to fuel filter |
| ▲ 3. Injection pipe and fuel leak off pipe | ▲ 10. Fuel pipe; fuel filter to injection pump |
| ▲ 4. Oil filter | ▲ 11. Fuel return pipe |
| 5. Oil pipe; filter to cooler | ▲ 12. Intake pipe |
| 6. Not installed | 13. Not installed |
| 7. Oil pipe; injection pump to engine body | 14. Cooling fan |



Important Operation




2. Injection Nozzle

Install the injection nozzles with the injection nozzle gaskets.

Be careful not to damage the nozzle tips.

kg·m (lb.ft)

Injection Nozzle Bolt Torque	1.7 – 2.1 (12.3 – 15.2)
------------------------------	-------------------------



3. Fuel injection Pipe and Fuel Leak Off Pipe

- 1) Install the fuel injection pipes ① and tighten the bolts to the specified torque.

kg·m (lb.ft)


Injection Pipe Torque	2.9 – 3.3 (21.0 – 23.9)
-----------------------	-------------------------

- 2) Carefully position and set the clips ②.

It is very important that each clip be positioned correctly.

An improperly positioned clip will result in objectionable fuel pulsing noise and injection pipe breakage.

- 3) Install the fuel leak off pipes ③.



4. Oil filter

(When the oil filter is being removed in an oil filter assembly with the filter cover.)


- 1) Before the installation, set the special gaskets which are included within the repair kit with the two oil filter mounting bolts.
- 2) Apply a coat of LOCTITE 271 on the bolt threads to seal the oil leak from the crankcase as illustrated.



- 3) Install the oil filter assembly with tightening the bolts securely.

kg·m (lb.ft)

Oil Filter Assembly Mounting Bolt Torque	4B	3.1–5.1 (22.4–36.9)
	6B	4.3–6.3 (31.1–45.6)


**9. Fuel Pipe (Feed Pump to Fuel Filter)****10. Fuel Pipe (Fuel Filter to Injection Pump)****11. Fuel Return Pipe**

Install the fuel pipes and tighten the fuel pipe joint bolts to the specified torque.

Take care not to interchange the check valves and joint bolts.

kg·m (lb.ft)

Fuel Pipe Joint Bolt Torque	1.6 – 1.8 (11.6 – 13.0)
-----------------------------	-------------------------

**12. Intake Pipe**

Install the intake pipe and tighten the intake pipe flange bolts to the specified torque.

kg·m (lb.ft)

Intake Pipe Flange Bolt Torque	2.1 – 3.1 (15.2 – 22.4)
--------------------------------	-------------------------

**Injection Timing Adjustment**

Check that the fuel injection timing is correct.

Refer to "MAINTENANCE" for the injection timing adjustment.


ENGINE TUNING OPERATION

After reassembly, the engine must be tuned. This will ensure that the engine operates at its maximum efficiency.



1. Mount the engine on a test bench.
2. Fill the engine with the specified oil.
3. Connect the cooling pipes and the fuel pipes.

Reference



4. Connect the electrical wiring.
Refer to the wiring diagram.
5. Connect the air intake line to the air cleaner.
6. Connect the exhaust pipe.
7. Manually operate the fuel feed pump to feed fuel to the engine.
8. Bleed the fuel lines of air.
Refer to Page 2-6 of Section 2 MAINTENANCE for the air bleeding procedure.

9. Crank the engine with the starter (non-ignition operation) for about twenty seconds.

This will prelubricate the engine internal components.

10. Start the engine and allow it to run at 750 to 800 rpm for five minutes.



11. Remove the cylinder head cover while the engine is running.



12. Check that the engine oil is continuously circulating from the oil pump to the valve rockers through the cylinder head.

If there is no oil circulation or if the oil circulation is sluggish, stop the engine and make the appropriate repairs or adjustments.

Reinstall the cylinder head cover.



13. Increase the engine speed to 1,500 rpm to do the engine warming-up operation.



14. Check the engine for oil, fuel, coolant, and air intake leakage.



15. Check for abnormal noise and odor.



16. Check for abnormal electrical charging.



17. Check the engine fastening parts for looseness.

18. When the engine coolant temperature reached to 75°C (167°F) or more, increase the engine speed to 2,000 rpm and allow it to run for twenty minutes.

This will give the engine the essential run-in operating time.





19. Adjust the engine operation speed to the specified value.

20. Stop the engine to complete the tuning procedure.

ENGINE SECTIONAL VIEW

For your reference:



Note: This sectional drawing is based on 6BG1 standard engine.


SECTION 6

LUBRICATING SYSTEM

TABLE OF CONTENTS

ITEM	PAGE
General description.....	6- 2
Oil pump.....	6- 3
Main oil filter.....	6- 5
Oil cooler	6- 7

GENERAL DESCRIPTION



This family of engines uses a normal forced circulation lubricating system.


The gear type oil pump is driven by the camshaft oil pump drive.

Either a center bolt type full flow oil filter or a cartridge (spin-on) type oil filter is used.

OIL PUMP



DISASSEMBLY




Disassembly Steps

- | | |
|--------------------|-------------------------|
| 1. Strainer | 4. Driven gear |
| 2. Suction pipe | 5. Drive shaft and gear |
| 3. Cover and dowel | 6. Driven gear shaft |



INSPECTION REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.



Visually inspect the disassembled parts for excessive wear and damage.




Oil Pump Drive Gear

Use a feeler gauge to measure the clearance between the oil pump cover (oil pump case) inside surface and the drive gear.

If the clearance exceeds the specified limit, the drive gear and/or the oil pump cover must be replaced.

mm (in)

	Limit
Oil Pump Cover and Oil Pump Drive Gear Clearance	0.18 (0.0071)




Oil Pump Driven Gear

Use a feeler gauge to measure the clearance between the oil pump case cover inside surface and the driven gear.

If the clearance exceeds the specified limit, the driven gear or the oil pump cover must be replaced.

mm (in)

	Limit
Oil Pump Body and Driven Gear Clearance	0.12 (0.0047)




REASSEMBLY

To assemble, follow the disassembly procedures in reverse order.

MAIN OIL FILTER



DISASSEMBLY



Disassembly Steps

- | | |
|-----------------------|--------------------|
| 1. Drain plug | 5. Element gasket |
| 2. Center bolt | 6. Spring seat |
| 3. O-ring | 7. Coil spring |
| 4. Oil filter element | 8. Oil filter body |

Refer to Page 2-2 of the MAINTENANCE for information on the cartridge type (spin-on type) oil filter.




INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.



REASSEMBLY




Reassembly Steps

1. Oil filter body
2. Coil spring
3. Spring seat
4. Element gasket

- ▲ 5. Oil filter element
6. Cover gasket
- ▲ 7. Center bolt
- ▲ 8. Drain plug


Refer to Page 2-2 of the MAINTENANCE for information on the cartridge type (spin-on type) oil filter.



Important Operation

5. Oil Filter Element

The protruding portion of the oil filter element must be facing the spring.



7. Center Bolt

8. Drain Plug

Install the center bolt and drain plug and tighten them to the specified torque.


kg·m (lb.ft)

Center Bolt Torque	5.3 ± 1 (38.3 \pm 7.2)
Drain Plug Torque	1.8 ± 0.2 (13.0 \pm 1.4)

OIL COOLER



DISASSEMBLY



0K482

Disassembly Steps

- | | |
|-----------------------|-------------------------|
| 1. Oil cooler element | 4. O-ring; plug |
| 2. Element gasket | 5. By-pass valve spring |
| 3. By-pass valve plug | 6. By-pass valve |




INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.




REASSEMBLY



OK482

Reassembly Steps

1. By-pass valve
2. By-pass valve spring
3. O-ring; plug
4. By-pass valve plug
5. Element gasket
- ▲ 6. Oil cooler element



Important Operation

6. Oil Cooler Element

Install the oil cooler element to the oil cooler, and tighten the cooler element fixing nuts to the specified torque.

kg·m (lb.ft)

Oil Cooler Element Fixing Nut Torque	6B	1.4–2.4 (10.1–17.4)
	4B	1.6–2.6 (11.6–18.3)


SECTION 7

COOLING SYSTEM

TABLE OF CONTENTS

ITEM	PAGE
General description	7- 2
Water pump	7- 3
Thermostat	7- 8

GENERAL DESCRIPTION




This family of engines uses a pressurized, forced circulation cooling system with a V-belt driven centrifugal water pump and a wax pellet thermostat with jiggle valve.

WATER PUMP




DISASSEMBLY



Disassembly Steps

1. Pulley
2. Cover
- ▲ 3. Impeller
- ▲ 4. Pulley center
5. Dust thrower
- ▲ 6. Snap ring
- ▲ 7. Spindle, *bearing and spacer
- ▲ 8. Seal unit, washer and seal

* Single bearing is used for model 4BG1 and 4BG1T.




Important Operation

3. Impeller


Use the remover to remove the impeller.

Remover: 9-8521-0097-0




4. Pulley Center

Use a bench press and a suitable rod to remove the pulley center.




6. Snap Ring

Use a pair of snap ring pliers to remove the snap ring.



7. Spindle, Bearing, and Spacer

Use a bench press and a suitable remover to remove the spindle, bearing, and spacer.




8. Seal Unit, Washer and Seal

Use a suitable remover to remove the seal unit, the washer, and the seal.



INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.




Bearing Replacement

Removal:



Use a bench press to remove two bearings and the spacer.




Installation:


Use a bench press to install two bearings and the spacer.



Single bearing is used for 4BD1 and 4BD1T.



Use a micrometer to check the fitness at the three points shown in the illustrations.




mm(in)

Fitness	Shaft to Pulley Center Fitness	0.02–0.06 (0.0008–0.0024)
	Shaft to Impeller Fitness	0.07–0.11 (0.0028–0.0043)
	Pulley Center to Pulley Fitness	0.14 (0.0055) or less



REASSEMBLY




OK483

Reassembly Steps

- | | |
|-----------------------------------|---------------------------------|
| ▲ 1. Spindle, *bearing and spacer | ▲ 5. Seal unit, washer and seal |
| ▲ 2. Snap ring | ▲ 6. Impeller |
| ▲ 3. Dust thrower | ▲ 7. Cover |
| ▲ 4. Pulley center | ▲ 8. Pulley |


* Single bearing is used for 4BG1 and 4BG1T.



Important Operation


1. Spindle, Bearing, and Spacer

Lubricate the bearing with multipurpose grease. Use a bench press to install the spindle, the bearing and the spacer.




2. Snap Ring

Use a pair of snap ring pliers to install the snap ring.




4. Pulley Center

Use a bench press and a bar to install the pulley center.




5. Seal Unit, Washer and Seal

1) Apply a thin coat of liquid gasket to the seal unit outer periphery before installation.



2) Use a bench press and a bar to install the seal unit into the pump body.

7-8 COOLING SYSTEM




6. Impeller

- 1) Use a bench press to install the impeller to the spindle.
- 2) Use a feeler gauge to measure the clearance between the impeller and the pump body.

mm (in)

Clearance between
Impeller and Pump Body

0.3–0.8 (0.0118–0.0315)



8. Pulley

Install the pulley and tighten the pulley bolts to the specified torque.

kg·m (lb.ft)

Pulley Fixing Bolts Torque


2.1 – 3.1 (15.2 – 22.4)

THERMOSTAT



INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.



Visually inspect the thermostat function referring Section 2 MAINTENANCE in page 2-7.

SECTION 8


FUEL SYSTEM

TABLE OF CONTENTS

ITEM	PAGE
General description	8- 2
Fuel filter	8- 3
Injection nozzle.....	8- 4
Injection pump calibration data.....	8- 9

GENERAL DESCRIPTION

This illustration is based on the 6BG1 engines.



The fuel system consists of the fuel tank, the water sedimentor, the fuel filter, the injection pump, and the injection nozzle.


The fuel from the fuel tank passes through the water sedimentor and the fuel filter where water particles and other foreign material are removed from the fuel.

Fuel, fed by the injection pump plunger, is delivered to the injection nozzle in the measured volume at the optimum timing for efficient engine operation.

FUEL FILTER



DISASSEMBLY



Disassembly Steps

- | | |
|----------------------|------------------------|
| 1. Drain plug | 5. Fuel filter element |
| 2. Center bolt | 6. Spring seat |
| 3. Fuel filter body | 7. Spring |
| 4. Body cover gasket | |

Refer to Page 2-3 of the "Maintenance" for information on the cartridge type fuel filter.



INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.




REASSEMBLY

To reassemble the fuel filter, follow the disassembly procedure in the reverse order.

INJECTION NOZZLE




DISASSEMBLY



Disassembly Steps

1. Nozzle holder cap nut
2. Cap nut gasket
3. Nozzle adjusting screw
4. Push rod spring
5. Nozzle holder push rod
6. Retaining nut
- ▲ 7. Injection nozzle
8. Injection pipe connector
9. Connector gasket
10. Nozzle holder body



OK836



Important Operation


7. Nozzle

Remove the nozzle assembly from the nozzle body.
Keep the parts separately to maintain the proper
needle valve to body combination.




INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.




Push Rod Spring

Check the push rod spring for wear, weakness, and corrosion.



Nozzle Holder Push Rod

1. Check the nozzle holder push rod curvature.
2. Check the nozzle holder push rod and needle valve contact surfaces for excessive wear and poor contact.



Injection Nozzle

1. Check the injection nozzle needle valve, the valve seat, and the injection nozzle hole for carbon deposits.

If carbon deposits are present, the injection nozzle and the needle valve must be replaced.

2. Hold the nozzle body vertically.

Pull the needle valve about one-third of the way out of the nozzle body.


Release the needle valve.

Check that the needle valve falls back into the nozzle body as far as the valve seat.

If the needle valve does not fall back into the nozzle body as far as the valve seat, the injection nozzle and the needle valve must be replaced.




REASSEMBLY



OK365

Reassembly Steps

- | | |
|-------------------------------|-----------------------------|
| 1. Nozzle holder body | 6. Nozzle holder push rod |
| 2. Connector gasket | 7. Push rod spring |
| ▲ 3. Injection pipe connector | 8. Nozzle adjusting screw |
| ▲ 4. Injection nozzle | 9. Cap nut gasket |
| ▲ 5. Retaining nut | ▲ 10. Nozzle holder cap nut |




Important Operation

3. Injection Pipe Connector



kg·m (lb.ft)

Nozzle Connector Torque	5.0 – 6.0 (36.2 – 43.4)
-------------------------	-------------------------




4. Injection Nozzle

There must be no oil on the contact surfaces of the injection nozzle and the injection nozzle holder.

Clean these contact surfaces with diesel fuel before installation.




The nozzle dowel pin must be aligned with the dowel hole in the nozzle holder body.



5. Retaining Nut

kg·m (lb.ft)

Nozzle Retaining Nut Torque	6.0 – 8.0 (43.4 – 57.9)
-----------------------------	-------------------------




Injection Starting Pressure Adjustment

The injection nozzle injection starting pressure can be adjusted after the adjusting screw is installed.

Refer to "FUEL SYSTEM" on Page 2-5 of the "MAINTENANCE" Section of this Workshop Manual.

kg/cm² (psi)

	4BG1	4BG1T, 6BG1 6BG1T
Injection Starting Pressure	150 (2134)	185 (2630)




10. Nozzle Holder Cap Nut

kg·m (lb.ft)

Cap Nut Torque	4.0 – 5.0 (28.9 – 36.2)
----------------	-------------------------

INJECTION PUMP CALIBRATION DATA



IDENTIFICATION PLATE AND PRODUCT SERIAL NUMBER

1. Injection pump adjustment and repair should be made by the nearest ZEXEL CORPORATION or ROBERT BOSCH Authorized Service Outlet.
2. When you ask such authorized service outlet the adjustment or repair, the identification Plate and Product Serial Number will give them a necessary clue to get technical data distributed by the manufacturers previously.

Without this data, the Service Outlet will be unable to effectively service your injection pump.

If you are unable to locate the data applicable to your injection pump, please contact ISUZU MOTORS LTD through your machine supplier.

3. Do not remove the Identification Plate and Product Serial Number from the injection pump.

Keep the Identification Plate and Product Serial Number clean at all times. Do not allow it to rust or become illegible.

Note: Examples of test conditions and calibration data are as follows.

TEST CONDITIONS REQUIRED FOR THE FUEL INJECTION AMOUNT ADJUSTMENT

Injection Nozzle		*ZEXEL No.: 105780-0000 Bosch Type No.: DN12SD12T
Injection Nozzle Holder		ZEXEL No.: 105780-2080 Bosch Type No.: EF8511/9
Injection Starting Pressure	kg/cm ² (psi)	175 (2488.5)
Injection Line Dimensions	mm(in.)	
Inside Diameter		2.0 (0.079)
Outside Diameter		6.0 (0.236)
Length		600.0 (23.6)
Transfer Pump Pressure		1.6 (22.75)
Testing Diesel Fuel		ISO4113 or SAE Standard Test Oil (SAEJ967D)
Operating Temperature	°C(°F)	40 - 45 (104 - 113)
Pump Rotation Direction		Clockwise (Viewed from the drive side)

INJ. PUMP CALIBRATION DATA

Ass'y No. 000000-0000

Date : 2

ENGINE MODEL 6BG1T

Company : ISUZU

No. 0-00000-000-0

Injection pump : PES4A
000000-0000Governor : EP/RSV
000000-0000

Timing device :

1. Test Conditions :

Pump rotation : clockwise (viewed from drive side)

Nozzle : 000000-0000
(BOSCH Type No. DN12SD12T)Nozzle holder : 000000-0000
(BOSCH Type No. EF8511/9A)Nozzle opening pressure : 175 kgf/cm²Injection pump pressure : 1.6 kgf/cm²

Injection pipe : Inner Dia. 3 mm Length 600 mm

Test Oil : ISO4113 or SAE Standard (SAE J967d) Oil Temp. : 40⁺⁵ °COverflow valve opening pressure : 1.3 kgf/cm²

2. Injection Timing :

Pre-stroke : No. 1 Plunger 3.6 ± 0.05 mm Note : Adjust with control rod position of mm

Injection order : 1 — 3, 1 — 4, 1 — 2 —
90°±30' 180°±30' 270°±30'

(interval : °± 30')

Plungers are numbered from the Driver side.

Tappet clearance: Bolt adjustment type ; More than 0.3 mm for all cylinders.

Shim adjustment type ; Manually rotate the camshaft 2~3 times and confirm that it rotates smoothly.

4. Injection Quantity :

Adjusting point	Rod Position (mm)	Pump Speed (r.p.m)	Injection Q'ty (cc/1000 strokes)	Max. var bet. cyl (%)	Fixed	Remarks
A	10.3	1,075	88.0 - 91	± 2	Lever	Basic
C	Approx. 7.4	450	8.2 - 10.8	± 14	Rod	
D	-	100	80 - 90	-	Lever	

5. Timing advance specification :


Pump Speed (r.p.m)							
Advance Angle (deg.)							

000000-0000


3. GOVERNOR ADJUSTMENT

Recommended speed droop adjustment screw position :7


(Notches from fully tightened position)



SPEED LEVER ANGLE




STOP LEVER ANGLE



TIMING SETTING

plunger beginning of injection
18°



MEMO

Handwriting practice lines consisting of horizontal dotted lines on a white background.

SECTION 9

TURBOCHARGER

TABLE OF CONTENTS

ITEM	PAGE
General description	9- 2
Turbocharger identification.....	9- 3
Inspection and repair	9- 4

Regarding the details of the turbocharger repair, refer the following workshop manual.

Published by: MITSUBISHI HEAVY INDUSTRIES CO., LTD


Title of the manual: MITSUBISHI TURBOCHARGERS (TD-04H FOR 4BG1T)

Pub No. 99626-92110


Availability of the manual ISUZU MOTORS LIMITED will send the manual upon request through your machine supplier.

GENERAL DESCRIPTION


TD04H



RHE6




TURBOCHARGER IDENTIFICATION




The IHI Turbocharger nameplate gives the date of manufacture and other important information required to identify the unit when service inquiries or part orders are made.

The arrow in the illustration indicates the location of the Turbocharger nameplate.



The turbocharger nameplate has the following information stamped on it. Refer to the illustration at the left.

- (1) Turbo Specification Number, Production Year and Month
- (2) Production Date, Daily Serial Number
- (3) ISUZU Parts Number



- (1) Serial Number
- (2) ISUZU Part Number
- (3) MITSUBISHI Number


INSPECTION AND REPAIR

If excessive wear or damage is discovered during inspection, the appropriate parts must be adjusted, repaired, or replaced. Damage or improper adjustment of the turbocharger will inhibit sufficient air flow to the engine, preventing it from delivering full performance.

If the engine demonstrates a significant drop in performance, check for engine damage or wear. If no significant engine damage or wear can be found, it is likely that the turbocharger is at fault.

When reduced performance is the result of a faulty turbocharger, contact your nearest IHI or Mitsubishi Service Center for the proper repairs.

The following is primarily a description of the particularly important rotor shaft end play, and bearing clearance standard and limit values.




Rotor Shaft Axial Play Measurement

- 1) Install a dial indicator on the turbine housing as illustrated.
- 2) Use the dial indicator to measure the rotor shaft axial play with moving the shaft push and pull. Read the total indicator reading (TIR).

mm (in)

IHI RHE6	Limit
Rotor Shaft Axial Play TIR	0.10 (0.0039)

- 3) If the measured value exceeds the specified limit the shaft must be replaced.



Rotor Shaft Radial Play Measurement

- 1) Turn over the turbocharger with the turbine exhaust inlet flange facing up.
- 2) Install a dial indicator to measure the rotor shaft radial play.
- 3) Use the dial indicator to measure the play. Read the TIR.

mm (in)

IHI RHE6	Limit
Rotor Shaft Radial Play TIR	0.19 (0.0075)

- 4) If the measured value exceeds the specified limit replace the shaft.

SECTION 10


AIR COMPRESSOR

TABLE OF CONTENTS

ITEM	PAGE
General description	10- 2
Disassembly steps.....	10- 3
Inspection and repairs	10- 4
Reassembly steps	10- 6

GENERAL DESCRIPTION

AIR COMPRESSOR SECTIONAL VIEW




Main Data

Piston ring configuration	Two compression rings and one oil ring	
Theoretical air delivery amount	155 cc/rev.	
Cylinder bore × stroke	mm (in)	70 (2.755) × 40 (1.574)
Maximum operating speed	rpm	1650
Crankshaft rotating ratio to engine		0.5
Weight	kg	7.0




DISASSEMBLY STEPS



Disassembly Steps

- | | |
|-----------------------------|--------------------------------|
| 1. Cylinder head and gasket | 5. Bearing cover with oil seal |
| ▲ 2. Cylinder body | 6. Bearing |
| 3. Piston | 7. Connecting rod |
| 4. Crankcase flange | 8. Crankshaft and bearing |



Important Operation

2. Cylinder body

- 1) Remove the cylinder mounting flange bolts.
- 2) Remove the cylinder with tapping out from the crankcase.





INSPECTION AND REPAIR

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.

Cylinder



Measure the uneven wear of the cylinder bore at the piston skirt position

mm (in)

	Limit
Cylinder Bore Uneven Wear	0.2 (0.0079)



Measure the piston and the cylinder bore clearance.

mm (in)

	Standard	Limit
Piston and Cylinder Bore Clearance	0.1–0.3 (0.0040–0.0118)	1.0 (0.040)

Note:

The piston outside diameter must be taken at the piston skirt positions.



Measure the piston ring grooves and the piston ring clearances.

mm (in)

	Standard	Limit
Piston Ring and Piston Ring Groove Clearance	0.02–0.05 (0.0008–0.0020)	0.15 (0.0059)



Measure the piston ring gaps.

mm (in)

	Standard	Limit
Piston Ring Gap	0.1–0.3 (0.0040–0.0118)	1.0 (0.039)



Measure the piston and the piston pin hole clearance.

mm (in)

	Standard	Limit
Piston Pin and Piston Pin Hole Clearance	0.002–0.023 (0.00008–0.00091)	0.0040 (0.00016)



Measure the piston pin and the connecting rod small-end clearance.

mm (in)

	Standard	Limit
Piston Pin and Connecting Rod Small-end Clearance	0.002–0.026 (0.00008–0.00102)	0.1 (0.0039)




Measure the air compressor crank pin and connecting rod large-end clearance.

mm (in)

	Standard	Limit
Crankpin and Connecting Rod Large-end Clearance	0.02–0.06 (0.0008–0.0024)	0.15 (0.0059)




REASSEMBLY STEPS



Reassembly Steps

- ▲ 1. Crankshaft and bearing
- ▲ 2. Connecting rod
- 3. Bearing
- ▲ 4. Bearing cover with oil seal
- 5. Crankcase flange
- 6. Piston
- ▲ 7. Cylinder body
- ▲ 8. Cylinder head and gasket



Important Operation

1. Crankshaft and bearings

- 1) Install the bearings to the crankshaft.
- 2) Insert the crankshaft into the crankcase from the bearing cover side while tapping it gently with a soft hammer.



2. Connecting rod



- 1) Install the connecting rod bearing cap and tighten the cap bolts to the specified torque.

kg·m (lb.ft)




Connecting Rod Cap Bolt Torque	2.5 (18.1)
--------------------------------	------------

4. Bearing cover




- 1) Remove the used O-ring from the bearing case and discard it.
- 2) Lubricate the inner surface of new O-ring with grease.



- 3) Install the O-ring to the bearing cover.
- 4) Install the bearing cover to the crankcase.
Tighten the bearing cover bolts to the specified torque.

kg·m (lb.ft)

Bearing Cover Bolt Torque	1.5 (10.9)
---------------------------	------------




7. Cylinder Body

- 1) Install the cylinder body to the crankcase.
- 2) Tighten the cylinder body bolts to the specified torque.

kg·m (lb.ft)

Cylinder Body Bolt Torque	3 (21.7)
---------------------------	----------



8. Cylinder Head

- 1) Apply a coat of liquid gasket (Grease D) to the lower face of the cylinder head gasket.
- 2) Install the cylinder head to the cylinder body.
Evenly tighten the cylinder head bolt to the specified torque.

kg·m (lb.ft)

Cylinder Head Bolt Torque	5.0 (36.2)
---------------------------	------------

MEMO

Handwriting practice lines consisting of horizontal dotted lines on a white background.

SECTION 11

ENGINE ELECTRICALS

TABLE OF CONTENTS

ITEM	PAGE
Starter identification	11- 2
Starter main data and specifications	11- 3
Starter sectional view.....	11- 4
Starter exploded view	11- 4
Alternator identification	11- 5
Main data and specifications	11- 6
Alternator sectional view.....	11- 7
Alternator exploded view	11- 7


STARTER IDENTIFICATION

The starter identification plate is attached to the starter motor outside yoke. The ISUZU part number, the manufacturer's code number, and other important information are stamped on the plate.

Refer to the identification plate together with the "Main Data and Specifications" Tables and accompanying charts in this Manual when requesting service assistance from a qualified electrical repair shop.


If you are unable to locate the data applicable to your engine, please contact ISUZU MOTORS LIMITED through your machine supplier.

NIKKO IDENTIFICATION PLATE



- A: Isuzu part number
- B: Manufacturer's code number
- C: Rated output
- D: Manufacturer's production mark

HITACHI IDENTIFICATION PLATE




- A: Isuzu part number
- B: Manufacturer's code number
- C: Rated output
- D: Manufacturer's production mark

STARTER

MAIN DATA AND SPECIFICATIONS


Isuzu Part No.		897029-8632	1-81100-1892
Manufacturer's code No. (NIKKO)		0-23000-2101	0-23000-1031
Rated voltage (V)		24	24
Rated output (kW)		3.5	4.5
Rating (Sec)		30	30
Direction of rotation (Viewed from the pinion side)		Clockwise	Clockwise
Clutch type		Roller	Roller
Terminal voltage (No load) (V)		24	24
Minimum current (No load) (A)		Less than 100	90
Starter motor minimum operating speed (No load) (rpm)		More than 4500	More than 4000
Pinion gear			
Modules		3	3
Number of teeth		9	11
Outside diameter mm (in.)		36.2 (1.43)	40.64 (1.60)
Travel distance mm (in.)		1.6 (0.063)	0.82 (0.032)
Yoke outside diameter mm (in.)		114 (4.49)	90 (3.54)
Number of poles		4	4
Magnetic switch (at 20°C [68°F])			
Series coil resistance (Ω)		0.17	0.2
Shunt coil resistance (Ω)		1.54	0.98
Brush length			
Standard mm (in.)		20.0 (0.79)	19.0 (0.75)
Limit mm (in.)		12.0 (0.47)	12.0 (0.47)
Brush spring standard fitting load (kg/lbs.)		4.5 (9.92)	4.5 (9.92)
Commutator			
Outside diameter			
Standard mm (in.)		36.0 (1.42)	36.0 (1.42)
Limit mm (in.)		35.0 (1.38)	35.0 (1.38)
Difference between the largest and smallest diameters (Run-out)			
Standard mm (in.)		0.05 (0.002)	0.015 (0.0006)
Limit mm (in.)		0.4 (0.016)	0.1 (0.004)
Depth of undercut mica			
Standard mm (in.)		0.5-0.8 (0.020-0.031)	0.5-0.8 (0.020-0.031)
Limit mm (in.)		0.2 (0.008)	0.2 (0.008)

STARTER MOTOR SECTIONAL VIEW



NIKKO-0-23000-1031

STARTER MOTOR EXPLODED VIEW



NIKKO-0-23000-1031


ALTERNATOR IDENTIFICATION

The alternator identification plate is attached to the alternator rear bracket. The ISUZU part number, the manufacturer's code number, and other important information are stamped on the plate.

Refer to the identification plate together with the "Main Data and Specifications" Tables and accompanying charts in this Manual when requesting service assistance from a qualified electrical repair shop.


If you are unable to locate the data applicable to your engine, please contact ISUZU MOTORS LIMITED through your machine supplier.

NIKKO IDENTIFICATION PLATE



- A: Isuzu part number
- B: Manufacturer's code number
- C: Rated output
- D: Manufacturer's production mark

HITACHI IDENTIFICATION PLATE




- A: Isuzu part number
- B: Manufacturer's code number
- C: Rated output
- D: Manufacturer's production mark


MAIN DATA AND SPECIFICATIONS

ALTERNATOR

Isuzu Part No.		1-81200-440-2	8-97046-6950
Manufacturer's code No. (NIKKO)		0-33000-6550	0-35000-3871
Rated voltage (V)		24	24
Rated output (A)		30	40
Operating speed (rpm)		1100 – 5000	1500 – 5000
Rated speed (rpm)		5000	5000
Rated output at r.p.m (Amp./Volt/rpm)		4 or more/27/1100 Less than 30/27/5000	10 or more/27/1250 Less than 35/27/5000
No-load output at 0 Amp. (Volt/rpm)		28.5 ± 1/1100 or less	28.5 ± 1/1100 or less
Direction of rotation as viewed from pulley side		Clockwise	Clockwise
Polarity grounded		(—)	(—)
Pulley diameter mm (in.)		80 (3.15)	80 (3.15)
Coil resistance at 20°C			
Rotor coil (Ω)		10.2	10.5
Starter coil [U-V-W] (Ω)		0.5	0.38
Brush length			
Standard mm (in.)		13 (0.51)	—
Limit mm (in.)		4 (0.16)	—
Brush spring standard fitting load (g)		390 ± 10%	—
Slip ring diameter			
Standard mm (in.)		33 (1.30)	—
Limit mm (in.)		32 (1.26)	—
Shaft diameter			
Front mm (in.)		25 (0.991)	25 (0.99)
Rear mm (in.)		15 (0.59)	15 (0.59)
Regulator's applicable			
Isuzu part No.		—	—
Manufacturer's code No.		—	—

ALTERNATOR SECTIONAL VIEW

NIKKO-0-35000-3871

ALTERNATOR EXPLODED VIEW

NIKKO-0-33000-6550

MEMO

Handwriting practice lines consisting of horizontal dotted lines.

SECTION 12

TROUBLESHOOTING

TABLE OF CONTENTS

ITEM	PAGE
Hard starting	12- 2
1) Starter inoperative	12- 2
2) Starter operates but engine does not turn over	12- 3
3) Engine turns over but does not start though fuel is being delivered to the injection pump	12- 4
4) Engine turns over but does not start	12- 5
Unstable low idling	12- 6
Insufficient power	12- 9
Excessive fuel consumption	12-12
Excessive oil consumption	12-14
Overheating	12-15
Whity exhaust smoke	12-17
Darkish exhaust smoke	12-18
Oil pressure does not rise	12-19
Abnormal engine noise	12-21

Note:


Use this section to quickly diagnose and repair engine failures.


Each troubleshooting chart has three headings arranged from left to right

(1) Check point (2) Trouble cause (3) Remedy

HARD STARTING

1) STARTER INOPERATIVE



HARD STARTING**2) STARTER MOTOR OPERATES BUT ENGINE DOES NOT TURN OVER**

HARD STARTING

3) ENGINE TURNS OVER BUT DOES NOT START

FUEL IS BEING DELIVERED TO THE INJECTION PUMP


Checkpoint

Trouble Cause

Remedy

Continued from the previous page

OK



HARD STARTING**4) ENGINE TURNS OVER BUT DOES NOT START**

Checkpoint		Trouble Cause		Remedy
Engine stop mechanism	NG	Defective engine stop mechanism Control wire improperly adjusted (In-line pump)	NG	Replace the engine stop mechanism Adjust the control wire
	NG	Defective fuel cut solenoid valve (VE pump)	NG	Replace the fuel cut solenoid valve

FUEL IS NOT BEING DELIVERED TO THE INJECTION PUMP

Fuel	NG	Fuel tank is empty	NG	Fill the fuel tank
OK				
Fuel piping	NG	Clogged or damaged fuel lines Loose fuel line connections	NG	Repair or replace the fuel lines Retighten the fuel line connections
OK				
Fuel filter	NG	Fuel filter overflow valve does not close	NG	Repair or replace the fuel filter overflow valve
	NG	Clogged fuel filter element	NG	Replace the fuel filter element or the fuel filter cartridge
OK				
Fuel system	NG	Air in the fuel system	NG	Bleed the air from the fuel system

Continued on the next page

UNSTABLE LOW IDLING

Checkpoint		Trouble Cause		Remedy
Low idling system	NG	Low idling improperly adjusted	NG	Adjust the low idling
OK				
Low idling speed control device	NG	Defective low idling speed control device	NG	Repair or replace the low idling speed control device
OK				
Throttle control system	NG	Throttle control system improperly adjusted	NG	Adjust the throttle control system
OK				
Fuel system	NG	Fuel system leakage or blockage	NG	Repair or replace the fuel system
	NG	Air in the fuel system	NG	Bleed the air from the fuel system
	NG	Water particles in the fuel system	NG	Change the fuel
	OK			
Fuel filter	NG	Clogged fuel filter element	NG	Replace the fuel filter element or the fuel filter cartridge

Continued on the next page

UNSTABLE LOW IDLING

Checkpoint

Trouble Cause

Remedy

Continued from the previous page

OK

Injection pump	NG	Defective governor lever operation	NG	Repair or replace the governor lever
	NG	Regulator valve improperly adjusted (VE pump only)	NG	Adjust or replace the regulator valve
	NG	Broken plunger spring	NG	Replace the plunger spring
	NG	Worn plunger	NG	Replace the plunger assembly
	NG	Worn camshaft (In-line pump only)	NG	Replace the camshaft
	NG	Worn roller tappet (In-line pump only)	NG	Replace the roller tappet
	NG	Worn cam disc (VE pump only)	NG	Replace the cam disc

Continued on the next page


UNSTABLE LOW IDLING

Checkpoint

Trouble Cause

Remedy

Continued from the previous page



INSUFFICIENT POWER

Checkpoint		Trouble Cause		Remedy
Air cleaner	NG	Clogged air cleaner element	NG	Clean or replace the air cleaner element
OK				
Fuel	NG	Water particles in the fuel	NG	Replace the fuel
OK				
Fuel filter	NG	Clogged fuel filter element	NG	Replace the fuel filter element or the fuel filter cartridge
OK				
Fuel feed pump	NG	Defective fuel feed pump	NG	Repair or replace the fuel feed pump
OK				
Injection nozzle	NG	Injection nozzle sticking	NG	Replace the injection nozzle
	NG	Injection nozzle injection starting pressure too low Improper spray condition	NG	Adjust or replace the injection nozzle
OK				
Fuel injection pipes	NG	Fuel injection pipes damaged or obstructed	NG	Replace the fuel injection pipes

Continued on the next page

INSUFFICIENT POWER


Checkpoint

Trouble Cause

Remedy

Continued from the previous page

OK



Continued on the next page


INSUFFICIENT POWER

Checkpoint

Trouble Cause

Remedy

Continued from the previous page



EXCESSIVE FUEL CONSUMPTION

Checkpoint		Trouble Cause		Remedy
Fuel system	NG	Fuel leakage	NG	Repair or replace the fuel system related parts
OK				
Air cleaner	NG	Clogged air cleaner element	NG	Clean or replace the air cleaner element
OK				
Low idling speed	NG	Poorly adjusted low idle speed	NG	Adjust the low idle speed
OK				
Injection nozzle	NG	Injection nozzle injection starting pressure too low Improper spray condition	NG	Adjust or replace the injection nozzle
OK				
Fuel injection timing	NG	Fuel injection timing improperly adjusted	NG	Adjust the fuel injection timing
OK				
Injection pump	NG	Defective delivery valve resulting fuel drippage after fuel injection	NG	Replace the delivery valve
OK				
Turbocharger	NG	Air leakage from the turbocharger intake side	NG	Repair the turbocharger intake side

Continued on the next page

EXCESSIVE FUEL CONSUMPTION**Checkpoint****Trouble Cause****Remedy**

Continued from the previous page

OK				
Turbocharger	NG	Defective turbocharger assembly	NG	Replace the turbocharger assembly
OK				
Valve clearance	NG	Valve clearance improperly adjusted	NG	Adjust the valve clearance
OK				
Compression pressure	NG	Blown out cylinder head gasket Worn cylinder liner Piston ring sticking or broken Improper seating between the valve and the valve seat	NG	Replace the related parts
OK				
Valve spring	NG	Valve spring weak or broken	NG	Replace the valve spring

EXCESSIVE OIL CONSUMPTION

Checkpoint		Trouble Cause		Remedy
Engine oil	NG	Engine oil unsuitable Too much engine oil	NG	Replace the engine oil Correct the engine oil volume
OK				
Oil seal and gasket	NG	Oil leakage from the oil seal and/or the gasket	NG	Replace the oil seal and/or the gasket
OK				
Air breather	NG	Clogged air breather	NG	Clean the air breather
OK				
Inlet and exhaust valves Valve seals	NG	Defective valve seals Worn valve stems and valve guides	NG	Replace the valve seals, the valves, and the valve guides
OK				
Piston rings	NG	Piston rings worn, broken or improperly installed	NG	Replace the piston rings or properly install
OK				
Cylinder liners	NG	Cylinder lines scored or worn	NG	Replace the cylinder liners

OVERHEATING

Checkpoint		Trouble Cause		Remedy
Cooling water	NG	Insufficient cooling water	NG	Replenish the cooling water
OK				
Fan belt	NG	Fan belt loose or cracked causing slippage	NG	Replace the fan belt
OK				
Radiator	NG	Defective radiator cap or clogged radiator core	NG	Replace the radiator cap or clean the radiator core
OK				
Water pump	NG	Defective water pump	NG	Repair or replace the water pump
OK				
Cylinder head and cylinder body sealing cap	NG	Defective sealing cap resulting in water leakage	NG	Replace the sealing cap
OK				
Thermostat	NG	Defective thermostat	NG	Replace the thermostat
OK				
Cooling system	NG	Cooling system clogged by foreign material	NG	Clean the foreign material from the cooling system

Continued on the next page

OVERHEATING


Checkpoint

Trouble Cause

Remedy


Continued from the previous page

OK



WHITE EXHAUST SMOKE

Checkpoint		Trouble Cause		Remedy
Fuel	NG	Water particles in the fuel	NG	Replace the fuel
OK				
Fuel injection timing	NG	Delayed fuel injection timing	NG	Adjust the fuel injection timing
OK				
Compression pressure	NG	Blown out cylinder head gasket Worn cylinder liner Piston ring sticking or broken Improper seating between the valve and the valve seat	NG	Replace the related parts
OK				
Turbocharger	NG	Defective turbocharger	NG	Replace the turbocharger
OK				
Inlet and exhaust valves Valve seals	NG	Defective valve seals Worn valves stems and valve guides	NG	Replace the valve seals, the valves, and the valve guides
OK				
Piston rings	NG	Piston rings worn, broken or improperly installed	NG	Replace the piston rings or properly install
OK				
Cylinder liners	NG	Cylinder lines scored or worn	NG	Replace the cylinder liners

DARK EXHAUST SMOKE

OIL PRESSURE DOES NOT RISE

Checkpoint		Trouble Cause		Remedy
Engine oil	NG	Improper viscosity engine oil Too much engine oil	NG	Replace the engine oil Correct the engine oil volume
OK				
Oil pressure gauge or unit Oil pressure indicator light	NG	Defective oil pressure gauge or unit Defective indicator light	NG	Repair or replace the oil pressure gauge or unit Replace the indicator light
OK				
Oil filter	NG	Clogged oil filter element	NG	Replace the oil filter element or the oil filter cartridge
OK				
Relief valve and by-pass valve	NG	Relief valve sticking and/or weak by-pass valve spring	NG	Replace the relief valve and/or the by-pass valve spring
OK				
Oil pump	NG	Clogged oil pump strainer	NG	Clean the oil pump strainer
	NG	Worn oil pump related parts	NG	Replace the oil pump related parts
OK				
Rocker arm shaft	NG	Worn rocker arm bushing	NG	Replace the rocker arm bushing

Continued on the next page


OIL PRESSURE DOES NOT RISE

Checkpoint

Trouble Cause

Remedy

Continued from the previous page



ABNORMAL ENGINE NOISE


1. Engine Knocking

Checkpoint


Trouble Cause

Remedy

Check to see that the engine has been thoroughly warmed up before beginning the troubleshooting procedure.



2. Gas Leakage Noise



Continued on the next page

ABNORMAL ENGINE NOISE

2. Gas Leakage Noise

Checkpoint

Trouble Cause

Remedy

Continued from the previous page

OK	Exhaust manifold	NG	Loosely connected exhaust manifold and/or glow plugs	NG	Tighten the exhaust manifold connections
OK	Cylinder head gasket	NG	Damaged cylinder head gasket	NG	Replace the cylinder head gasket

3. Continuous Noise

OK	Fan belt	NG	Loose fan belt	NG	Readjust the fan belt tension
OK	Cooling fan	NG	Loose cooling fan	NG	Retighten the cooling fan
OK	Water pump bearing	NG	Worn or damaged water pump bearing	NG	Replace the water pump bearing
OK	Alternator or vacuum pump	NG	Defective alternator or vacuum pump	NG	Repair or replace the alternator or the vacuum pump
OK	Valve clearance	NG	Valve clearance improperly adjusted	NG	Adjust the valve clearance

ABNORMAL ENGINE NOISE

4. Slapping Noise

Checkpoint		Trouble Cause		Remedy
Valve clearance	NG	Valve clearance improperly adjusted	NG	Adjust the valve clearance
OK				
Rocker arm	NG	Damaged rocker arm	NG	Replace the rocker arm
OK				
Flywheel	NG	Loose flywheel bolts	NG	Retighten the flywheel bolts
OK				
Crankshaft and thrust bearings	NG	Worn or damaged crankshaft and/or thrust bearings	NG	Replace the crankshaft and/or the thrust bearings
OK				
Crankshaft and connecting rod bearings	NG	Worn or damaged crankshaft and/or connecting rod bearings	NG	Replace the crankshaft and/or the connecting rod bearings
OK				
Connecting rod bushing and piston pin	NG	Worn or damaged connecting rod bushing and piston pin	NG	Replace the connecting rod bushing and/or the piston pin
OK				
Piston and cylinder liner	NG	Worn or damaged piston and cylinder liner Foreign material in the cylinder	NG	Replace the piston and the cylinder liner

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There is no text or other markings on the paper.











SECTION 13








SPECIAL TOOL LIST

TABLE OF CONTENTS

ITEM	PAGE
Special tool list.....	13- 2

SPECIAL TOOL LIST

ITEM NO.	ILLUSTRATION	PART NO.	PARTS NAME	PAGE
1.		1-85111-003-0	Cylinder head bolt wrench	3-8
2.		5-85317-001-0	Compression gauge adaptor	2-15
3.		9-8521-0122-0	Crankshaft taper bushing remover	3-9
4.		1-85235-0060	Valve spring compressor	3-13 5-5
5.		1-85232-001-0 9-85220-035-0	Valve guide remover and installer	4-3
6.		9-8523-1818-0	Camshaft bearing remover and installer	4-10
7.		9-8523-1169-0	Cylinder liner remover	4-12
8.		5-8523-1004-0	Cylinder liner remover ankle	4-12
9.		5-8522-1018-0	Cylinder liner installer	4-15
10.		9-8521-0141-0	Crankshaft gear remover	4-30

ITEM NO.	ILLUSTRATION	PART NO.	PARTS NAME	PAGE
11.		9-8522-0033-0	Crankshaft gear installer	4-30
12.		9-8523-1369-0	Connecting rod bushing installer	4-22
13.		9-8522-1254-0	Crankshaft rear oil seal installer	4-30
14.		9-8522-0034-0	Crankshaft front oil seal installer	4-31
15.		1-85221-005-0	Valve stem oil seal installer	5-5
16.		9-8522-1251-0	Piston ring compressor	5-12
17.		9-8521-0097-0	Water pump impeller remover	7-4
18.		1-85210-056-0	Oil seal wear ring remover	4-29
19.		1-85220-031-0	Oil seal wear ring installer	4-29

MEMO

Handwriting practice lines consisting of 20 horizontal dotted lines.

SECTION 14

CONVERSION TABLE

TABLE OF CONTENTS

ITEM	PAGE
LENGTH	14- 2
AREA	14- 3
VOLUME	14- 3
MASS	14- 5
PRESSURE	14- 6
TORQUE	14- 7
TEMPERATURE	14- 8

LENGTH

MILLIMETERS TO INCHES

mm	in.	mm	in.	mm	in.	mm	in.
1	0.0394	26	1.0236	51	2.0079	76	2.9921
2	0.0787	27	1.0630	52	2.0472	77	3.0315
3	0.1181	28	1.1024	53	2.0866	78	3.0709
4	0.1575	29	1.1417	54	2.1260	79	3.1102
5	0.1969	30	1.1811	55	2.1654	80	3.1496
6	0.2362	31	1.2205	56	2.2047	81	3.1890
7	0.2756	32	1.2598	57	2.2441	82	3.2283
8	0.3150	33	1.2992	58	2.2835	83	3.2677
9	0.3543	34	1.3386	59	2.3228	84	3.3071
10	0.3937	35	1.3780	60	2.3622	85	3.3465
11	0.4331	36	1.4173	61	2.4016	86	3.3858
12	0.4724	37	1.4567	62	2.4409	87	3.4252
13	0.5118	38	1.4961	63	2.4803	88	3.4646
14	0.5512	39	1.5354	64	2.5197	89	3.5039
15	0.5906	40	1.5748	65	2.5591	90	3.5433
16	0.6299	41	1.6142	66	2.5984	91	3.5827
17	0.6693	42	1.6535	67	2.6378	92	3.6220
18	0.7087	43	1.6929	68	2.6772	93	3.6614
19	0.7480	44	1.7323	69	2.7165	94	3.7008
20	0.7874	45	1.7717	70	2.7559	95	3.7402
21	0.8268	46	1.8110	71	2.7953	96	3.7795
22	0.8661	47	1.8504	72	2.8346	97	3.8189
23	0.9055	48	1.8898	73	2.8740	98	3.8583
24	0.9449	49	1.9291	74	2.9134	99	3.8976
25	0.9843	50	1.9685	75	2.9528	100	3.9370

101	3.9764	111	4.3701	121	4.7638	131	5.1575
102	4.0157	112	4.4094	122	4.8031	132	5.1969
103	4.0551	113	4.4488	123	4.8425	133	5.2362
104	4.0945	114	4.4882	124	4.8819	134	5.2756
105	4.1339	115	4.5276	125	4.9213	135	5.3150
106	4.1732	116	4.5669	126	4.9606	136	5.3543
107	4.2126	117	4.6063	127	5.0000	137	5.3937
108	4.2520	118	4.6457	128	5.0394	138	5.4331
109	4.2913	119	4.6850	129	5.0787	139	5.4724

INCHES TO MILLIMETERS

in.	mm	in.	mm
1/64	0.3969	33/64	13.0969
1/32	0.7938	17/32	13.4938
3/64	1.1906	35/64	13.8906
1/16	1.5875	9/16	14.2875
5/64	1.9844	37/64	14.6844
3/32	2.3813	19/32	15.0813
7/64	2.7781	39/64	15.4781
1/8	3.1750	5/8	15.8750
9/64	3.5719	41/64	16.2719
5/32	3.9688	21/32	16.6688
11/64	4.3656	43/64	17.0656
13/64	4.7625	45/64	17.4625
7/32	5.5563	23/32	18.2563
15/64	5.9531	47/64	18.6531
1/4	6.3500	3/4	19.0500
17/64	6.7469	49/64	19.4469
9/32	7.1438	25/32	19.8438
19/64	7.5406	51/64	20.2406
5/16	7.9375	13/16	20.6375
21/64	8.3344	53/64	21.0344
11/32	8.7313	27/32	21.4313
23/64	9.1281	55/64	21.8281
3/8	9.5250	7/8	22.2250
25/64	9.9219	57/64	22.6219
13/32	10.3188	29/32	23.0188
27/64	10.7156	59/64	23.4156
7/16	11.1125	15/16	23.8125
29/64	11.5094	61/64	24.2094
15/32	11.9063	31/32	24.6063
31/64	12.3031	63/64	25.0031
1/2	12.7000	1	25.4000

14-2 CONVERSION TABLE**LENGTH****FEET TO METERS**

ft.	0	1	2	3	4	5	6	7	8	9	ft.
	m	m	m	m	m	m	m	m	m	m	
—	—	0.305	0.610	0.914	1.219	1.524	1.829	2.134	2.438	2.743	—
10	3.048	3.353	3.658	3.962	4.267	4.572	4.877	5.182	5.486	5.791	10
20	6.096	6.401	6.706	7.010	7.315	7.620	7.925	8.230	8.534	8.839	20
30	9.144	9.449	9.754	10.058	10.363	10.668	10.973	11.278	11.582	11.887	30
40	12.192	12.497	12.802	13.106	13.411	13.716	14.021	14.326	14.630	14.935	40
50	15.240	15.545	15.850	16.154	16.459	16.764	17.069	17.374	17.678	17.983	50
60	18.288	18.593	18.898	19.202	19.507	19.812	20.117	20.422	20.726	21.031	60
70	21.336	21.641	21.946	22.250	22.555	22.860	23.165	23.470	23.774	24.079	70
80	24.384	24.689	24.994	25.298	25.603	25.908	26.213	26.518	26.822	27.127	80
90	27.432	27.737	28.042	28.346	28.651	28.956	29.261	29.566	29.870	30.175	90
100	30.480	30.785	31.090	31.394	31.699	32.004	32.309	32.614	32.918	33.223	100

METERS TO FEET

m	0	1	2	3	4	5	6	7	8	9	
	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	
—	—	3.2808	6.5617	9.8425	13.1234	16.4042	19.6850	22.9659	26.2467	29.5276	—
10	32.8084	36.0892	39.3701	42.6509	45.9318	49.2126	52.4934	55.7743	59.0551	62.3360	10
20	65.6168	68.8976	72.1785	75.4593	78.7402	82.0210	85.3018	88.5827	91.8635	95.1444	20
30	98.4252	101.7060	104.9869	108.2677	111.5486	114.8294	118.1102	121.3911	124.6719	127.9528	30
40	131.2336	134.5144	137.7953	141.0761	144.3570	147.6378	150.9186	154.1995	157.4803	160.7612	40
50	164.0420	167.3228	170.6037	173.8845	177.1654	180.4462	183.7270	187.0079	190.2887	193.5696	50
60	196.8504	200.1312	203.4121	206.6929	209.9738	213.2546	216.5354	219.8163	223.0971	226.3780	60
70	229.6588	232.9396	236.2205	239.5013	242.7822	246.0630	249.3438	252.6247	255.9055	259.1864	70
80	262.4672	265.7480	269.0289	272.3097	275.5906	278.8714	282.1522	285.4331	288.7139	291.9948	80
90	295.2756	298.5564	301.8373	305.1181	308.3990	311.6798	314.9606	318.2415	321.5223	324.8032	90
100	328.0840	331.3648	334.6457	337.9265	341.2074	344.4882	347.7690	351.0499	354.3307	357.6116	100

MILES TO KILOMETERS

miles	0	1	2	3	4	5	6	7	8	9	
	km	km	km	km	km	km	km	km	km	km	
—	—	1.609	3.219	4.828	6.437	8.047	9.656	11.265	12.875	14.484	—
10	16.093	17.703	19.312	20.921	22.531	24.140	25.749	27.359	28.968	30.577	10
20	32.187	33.796	35.405	37.015	38.624	40.234	41.843	43.452	45.062	46.671	20
30	48.280	49.890	51.499	53.108	54.718	56.327	57.936	59.546	61.155	62.764	30
40	64.374	65.983	67.592	69.202	70.811	72.420	74.030	75.639	77.248	78.858	40
50	80.467	82.076	83.686	85.295	86.904	88.514	90.123	91.732	93.342	94.951	50
60	96.560	98.170	99.779	101.388	102.998	104.607	106.216	107.826	109.435	111.044	60
70	112.654	114.263	115.872	117.482	119.091	120.701	122.310	123.919	125.529	127.138	70
80	128.747	130.357	131.966	133.575	135.185	136.794	138.403	140.013	141.622	143.231	80
90	144.841	146.450	148.059	149.669	151.278	152.887	154.497	156.106	157.715	159.325	90
100	160.934	162.543	164.153	165.762	167.371	168.981	170.590	172.199	173.809	175.418	100

KILOMETERS TO MILES

km	0	1	2	3	4	5	6	7	8	9	
	miles	miles	miles	miles	miles	miles	miles	miles	miles	miles	
—	—	0.621	1.243	1.864	2.485	3.107	3.728	4.350	4.971	5.592	—
10	6.214	6.835	7.456	8.078	8.699	9.321	9.942	10.563	11.185	11.806	10
20	12.427	13.049	13.670	14.292	14.913	15.534	16.156	16.777	17.398	18.020	20
30	18.641	19.262	19.884	20.505	21.127	21.748	22.369	22.991	23.612	24.233	30
40	24.855	25.476	26.098	26.719	27.340	27.962	28.583	29.204	29.826	30.447	40
50	31.069	31.690	32.311	32.933	33.554	34.175	34.797	35.418	36.039	36.661	50
60	37.282	37.904	38.525	39.146	39.768	40.389	41.010	41.632	42.253	42.875	60
70	43.496	44.117	44.739	45.360	45.981	46.603	47.224	47.845	48.467	49.088	70
80	49.710	50.331	50.952	51.574	52.195	52.816	53.438	54.059	54.681	55.302	80
90	55.923	56.545	57.166	57.787	58.409	59.030	59.652	60.273	60.894	61.516	90
100	62.137	62.758	63.380	64.001	64.622	65.244	65.865	66.487	67.108	67.729	100

AREA

SQUARE INCHES TO SQUARE CENTIMETERS

in ²	0	1	2	3	4	5	6	7	8	9	in ²
	cm ²	cm ²	cm ²	cm ²	cm ²	cm ²	cm ²	cm ²	cm ²	cm ²	
—	—	6.452	12.903	19.355	25.806	32.258	38.710	45.161	51.613	58.064	—
10	64.516	70.968	77.419	83.871	90.322	96.774	103.226	109.677	116.129	122.580	10
20	129.032	135.484	141.935	148.387	154.838	161.290	167.742	174.193	180.645	187.096	20
30	193.548	200.000	206.451	212.903	219.354	225.806	232.258	238.709	245.161	251.612	30
40	258.064	264.516	270.967	277.419	283.870	290.322	296.774	303.225	309.677	316.128	40
50	322.580	329.032	335.483	341.935	348.386	354.838	361.290	367.741	374.193	380.644	50
60	387.096	393.548	399.999	406.451	412.902	419.354	425.806	432.257	438.709	445.160	60
70	451.612	458.064	464.515	470.967	477.418	483.870	490.322	496.773	503.225	509.676	70
80	516.128	522.580	529.031	535.483	541.934	548.386	554.838	561.289	567.741	574.192	80
90	580.644	587.096	593.547	599.999	606.450	612.902	619.354	625.805	632.257	638.708	90
100	645.160	651.612	658.063	664.515	670.966	677.418	683.870	690.321	696.773	703.224	100

SQUARE CENTIMETERS TO SQUARE INCHES

cm ²	0	1	2	3	4	5	6	7	8	9	cm ²
	in ²	in ²	in ²	in ²	in ²	in ²	in ²	in ²	in ²	in ²	
—	—	0.155	0.310	0.465	0.620	0.775	0.930	1.085	1.240	1.395	—
10	1.550	1.705	1.860	2.015	2.170	2.325	2.480	2.635	2.790	2.945	10
20	3.100	3.255	3.410	3.565	3.720	3.875	4.030	4.185	4.340	4.495	20
30	4.650	4.805	4.960	5.115	5.270	5.425	5.580	5.735	5.890	6.045	30
40	6.200	6.355	6.510	6.665	6.820	6.975	7.130	7.285	7.440	7.595	40
50	7.750	7.905	8.060	8.215	8.370	8.525	8.680	8.835	8.990	9.145	50
60	9.300	9.455	9.610	9.765	9.920	10.075	10.230	10.385	10.540	10.695	60
70	10.850	11.005	11.160	11.315	11.470	11.625	11.780	11.935	12.090	12.245	70
80	12.400	12.555	12.710	12.865	13.020	13.175	13.330	13.485	13.640	13.795	80
90	13.950	14.105	14.260	14.415	14.570	14.725	14.880	15.035	15.190	15.345	90
100	15.500	15.655	15.810	15.965	16.120	16.275	16.430	16.585	16.740	16.895	100

VOLUME

CUBIC INCHES TO CUBIC CENTIMETERS

in ³	0	1	2	3	4	5	6	7	8	9	in ³
	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	cm ³ (cc)	
—	—	16.387	32.774	49.161	65.548	81.935	98.322	114.709	131.097	147.484	—
10	163.871	180.258	196.645	213.032	229.419	245.806	262.193	278.580	294.967	311.354	10
20	327.741	344.128	360.515	376.902	393.290	409.677	426.064	442.451	458.838	475.225	20
30	491.612	507.999	524.386	540.773	557.160	573.547	589.934	606.321	622.708	639.095	30
40	655.483	671.870	688.257	704.644	721.031	737.418	753.805	770.192	786.579	802.966	40
50	819.353	835.740	852.127	868.514	884.901	901.289	917.676	934.063	950.450	966.837	50
60	983.224	999.611	1015.998	1032.385	1048.772	1065.159	1081.546	1097.933	1114.320	1130.707	60
70	1147.094	1163.482	1179.869	1196.256	1212.643	1229.030	1245.417	1261.804	1278.191	1294.578	70
80	1310.965	1327.352	1343.739	1360.126	1376.513	1392.900	1409.288	1425.675	1442.062	1458.449	80
90	1474.836	1491.223	1507.610	1523.997	1540.384	1556.771	1573.158	1589.545	1605.932	1622.319	90
100	1638.706	1655.093	1671.481	1687.868	1704.255	1720.642	1737.029	1753.416	1769.803	1786.190	100

CUBIC CENTIMETERS TO CUBIC INCHES

cm ³ (cc)	0	1	2	3	4	5	6	7	8	9	cm ³ (cc)
	in ³	in ³	in ³	in ³	in ³	in ³	in ³	in ³	in ³	in ³	
—	—	0.0610	0.1220	0.1831	0.2441	0.3051	0.3661	0.4272	0.4882	0.5492	—
10	0.6102	0.6713	0.7323	0.7933	0.8543	0.9153	0.9764	1.0374	1.0984	1.1594	10
20	1.2205	1.2815	1.3425	1.4035	1.4646	1.5256	1.5866	1.6476	1.7086	1.7697	20
30	1.8307	1.8917	1.9527	2.0138	2.0748	2.1358	2.1968	2.2579	2.3189	2.3799	30
40	2.4409	2.5019	2.5630	2.6240	2.6850	2.7460	2.8071	2.8681	2.9291	2.9901	40
50	3.0512	3.1122	3.1732	3.2342	3.2952	3.3563	3.4173	3.4783	3.5393	3.6004	50
60	3.6614	3.7224	3.7834	3.8444	3.9055	3.9665	4.0275	4.0885	4.1496	4.2106	60
70	4.2716	4.3326	4.3937	4.4547	4.5157	4.5767	4.6377	4.6988	4.7598	4.8208	70
80	4.8818	4.9429	5.0039	5.0649	5.1259	5.1870	5.2480	5.3090	5.3700	5.4310	80
90	5.4921	5.5531	5.6141	5.6751	5.7362	5.7972	5.8582	5.9192	5.9803	6.0413	90
100	6.1023	6.1633	6.2243	6.2854	6.3464	6.4074	6.4684	6.5295	6.5905	6.6515	100

14-4 CONVERSION TABLE

VOLUME

GALLONS (U.S.) TO LITERS

U.S. gal.	0	1	2	3	4	5	6	7	8	9	U.S.gal.
	liters	liters	liters	liters	liters	liters	liters	liters	liters	liters	
—	—	3.7854	7.5709	11.3563	15.1417	18.9271	22.7126	26.4980	30.2834	34.0688	—
10	37.8543	41.6397	45.4251	49.2106	52.9960	56.7814	60.5668	64.3523	68.1377	71.9231	10
20	75.7085	79.4940	83.2794	87.0648	90.8502	94.6357	98.4211	102.2065	105.9920	109.7774	20
30	113.5628	117.3482	121.1337	124.9191	128.7045	132.4899	136.2754	140.0608	143.8462	147.6317	30
40	151.4171	155.2025	158.9879	162.7734	166.5588	170.3442	174.1296	177.9151	181.7005	185.4859	40
50	189.2714	193.0568	196.8422	200.6276	204.4131	208.1985	211.9839	215.7693	219.5548	223.3402	50
60	227.1256	230.9110	234.6965	238.4819	242.2673	246.0528	249.8382	253.6236	257.4090	261.1945	60
70	264.9799	268.7653	272.5507	276.3362	280.1216	283.9070	287.6925	291.4779	295.2633	299.0487	70
80	302.8342	306.6196	310.4050	314.1904	317.9759	321.7613	325.5467	329.3321	333.1176	336.9030	80
90	340.6884	344.4739	348.2593	352.0447	355.8301	359.6156	363.4010	367.1864	370.9718	374.7573	90
100	378.5427	382.3281	386.1136	389.8990	393.6844	397.4698	401.2553	405.0407	408.8261	412.6115	100

LITERS TO GALLONS (U.S.)

liters	0	1	2	3	4	5	6	7	8	9	liters
	gal.	gal.	gal.	gal.	gal.	gal.	gal.	gal.	gal.	gal.	
—	—	0.2642	0.5283	0.7925	1.0567	1.3209	1.5850	1.8492	2.1134	2.3775	—
10	2.6417	2.9059	3.1701	3.4342	3.6984	3.9626	4.2268	4.4909	4.7551	5.0193	10
20	5.2834	5.5476	5.8118	6.0760	6.3401	6.6043	6.8685	7.1326	7.3968	7.6610	20
30	7.9252	8.1893	8.4535	8.7177	8.9818	9.2460	9.5102	9.7744	10.0385	10.3027	30
40	10.5669	10.8311	11.0952	11.3594	11.6236	11.8877	12.1519	12.4161	12.6803	12.9444	40
50	13.2086	13.4728	13.7369	14.0011	14.2653	14.5295	14.7936	15.0578	15.3220	15.5861	50
60	15.8503	16.1145	16.3787	16.6428	16.9070	17.1712	17.4354	17.6995	17.9637	18.2279	60
70	18.4920	18.7562	19.0204	19.2846	19.5487	19.8129	20.0771	20.3412	20.6054	20.8696	70
80	21.1338	21.3979	21.6621	21.9263	22.1904	22.4546	22.7188	22.9830	23.2471	23.5113	80
90	23.7755	24.0397	24.3038	24.5680	24.8322	25.0963	25.3605	25.6247	25.8889	26.1530	90
100	26.4172	26.6814	26.9455	27.2097	27.4739	27.7381	28.0022	28.2664	28.5306	28.7947	100

GALLONS (IMP.) TO LITERS

Imp gal.	0	1	2	3	4	5	6	7	8	9	Imp gal.
	liters	liters	liters	liters	liters	liters	liters	liters	liters	liters	
—	—	4.5459	9.0918	13.6377	18.1836	22.7295	27.2754	31.8213	36.3672	40.9131	—
10	45.4590	50.0049	54.5508	59.0967	63.6426	68.1885	72.7344	77.2803	81.8262	86.3721	10
20	90.9180	95.4639	100.0098	104.5557	109.1016	113.6475	118.1934	122.7393	127.2852	131.8311	20
30	136.3770	140.9229	145.4688	150.0147	154.5606	159.1065	163.6524	168.1983	172.7442	177.2901	30
40	181.8360	186.3819	190.9278	195.4737	200.0196	204.5655	209.1114	213.6573	218.2032	222.7491	40
50	227.2950	231.8409	236.3868	240.9327	245.4786	250.0245	254.5704	259.1163	263.6622	268.2081	50
60	272.7540	277.2999	281.8458	286.3917	290.9376	295.4835	300.0294	304.5753	309.1212	313.6671	60
70	318.2130	322.7589	327.3048	331.8507	336.3966	340.9425	345.4884	350.0343	354.5802	359.1261	70
80	363.6720	368.2179	372.7638	377.3097	381.8556	386.4015	390.9474	395.4933	400.0392	404.5851	80
90	409.1310	413.6769	418.2228	422.7687	427.3146	431.8605	436.4064	440.9523	445.4982	450.0441	90
100	454.5900	459.1359	463.6818	468.2277	472.7736	477.3195	481.8654	486.4113	490.9572	495.5031	100

LITERS TO GALLONS (IMP.)

liters	0	1	2	3	4	5	6	7	8	9	liters
	gal.	gal.	gal.	gal.	gal.	gal.	gal.	gal.	gal.	gal.	
—	—	0.2200	0.4400	0.6599	0.8799	1.0999	1.3199	1.5399	1.7598	1.9798	—
10	2.1998	2.4198	2.6398	2.8597	3.0797	3.2997	3.5197	3.7397	3.9596	4.1796	10
20	4.3996	4.6196	4.8396	5.0595	5.2795	5.4995	5.7195	5.9395	6.1594	6.3794	20
30	6.5994	6.8194	7.0394	7.2593	7.4793	7.6993	7.9193	8.1393	8.3592	8.5792	30
40	8.7992	9.0192	9.2392	9.4591	9.6791	9.8991	10.1191	10.3391	10.5590	10.7790	40
50	10.9990	11.2190	11.4390	11.6589	11.8789	12.0989	12.3189	12.5389	12.7588	12.9788	50
60	13.1988	13.4188	13.6388	13.8587	14.0787	14.2987	14.5187	14.7387	14.9586	15.1786	60
70	15.3986	15.6186	15.8386	16.0585	16.2785	16.4985	16.7185	16.9385	17.1584	17.3784	70
80	17.5984	17.8184	18.0384	18.2583	18.4783	18.6983	18.9183	19.1383	19.3582	19.5782	80
90	19.7982	20.0182	20.2382	20.4581	20.6781	20.8981	21.1181	21.3381	21.5580	21.7780	90
100	21.9980	22.2180	22.4380	22.6579	22.8779	23.0979	23.3179	23.5379	23.7578	23.9778	100

MASS

POUNDS TO KILOGRAMS

lbs.	0	1	2	3	4	5	6	7	8	9	lbs.
	kg	kg	kg	kg	kg	kg	kg	kg	kg	kg	
—	—	0.454	0.907	1.361	1.814	2.268	2.722	3.175	3.629	4.082	—
10	4.536	4.989	5.443	5.897	6.350	6.804	7.257	7.711	8.165	8.618	10
20	9.072	9.525	9.979	10.433	10.886	11.340	11.793	12.247	12.701	13.154	20
30	13.608	14.061	14.515	14.968	15.422	15.876	16.329	16.783	17.236	17.690	30
40	18.144	18.597	19.051	19.504	19.958	20.412	20.865	21.319	21.772	22.226	40
50	22.680	23.133	23.587	24.040	24.494	24.947	25.401	25.855	26.308	26.762	50
60	27.215	27.669	28.123	28.576	29.030	29.483	29.937	30.391	30.844	31.298	60
70	31.751	32.205	32.658	33.112	33.566	34.019	34.473	34.926	35.380	35.834	70
80	36.287	36.741	37.194	37.648	38.102	38.555	39.009	39.462	39.916	40.370	80
90	40.823	41.277	41.730	42.184	42.637	43.091	43.545	43.998	44.452	44.905	90
100	45.359	45.813	46.266	46.720	47.173	47.627	48.081	48.534	48.988	49.441	100

KILOGRAMS TO POUNDS

kg	0	1	2	3	4	5	6	7	8	9	kg
	lbs.	lbs.	lbs.	lbs.	lbs.	lbs.	lbs.	lbs.	lbs.	lbs.	
—	—	2.205	4.409	6.614	8.818	11.023	13.228	15.432	17.637	19.842	—
10	22.046	24.251	26.455	28.660	30.865	33.069	35.274	37.479	39.683	41.888	10
20	44.092	46.297	48.502	50.706	52.911	55.116	57.320	59.525	61.729	63.934	20
30	66.139	68.343	70.548	72.752	74.957	77.162	79.366	81.571	83.776	85.980	30
40	88.185	90.389	92.594	94.799	97.003	99.208	101.413	103.617	105.822	108.026	40
50	110.231	112.436	114.640	116.845	119.049	121.254	123.459	125.663	127.868	130.073	50
60	132.277	134.482	136.686	138.891	141.096	143.300	145.505	147.710	149.914	152.119	60
70	154.323	156.528	158.733	160.937	163.142	165.347	167.551	169.756	171.960	174.165	70
80	176.370	178.574	180.779	182.983	185.188	187.393	189.597	191.802	194.007	196.211	80
90	198.416	200.620	202.825	205.030	207.234	209.439	211.644	213.848	216.053	218.257	90
100	220.462	222.667	224.871	227.076	229.280	231.485	233.690	235.894	238.099	240.304	100

KILOGRAMS TO NEWTON

kg	0	1	2	3	4	5	6	7	8	9	kg
	N	N	N	N	N	N	N	N	N	N	
—	—	9.81	19.61	29.42	39.23	49.03	58.84	68.65	78.45	88.26	—
10	98.07	107.87	117.68	127.49	137.29	147.10	156.91	166.71	176.52	186.33	10
20	196.13	205.94	215.75	225.55	235.36	245.17	254.97	264.78	274.59	284.39	20
30	294.20	304.01	313.81	323.62	333.43	343.23	353.04	362.85	372.65	382.46	30
40	392.27	402.07	411.88	421.69	431.49	441.30	451.11	460.91	470.72	480.53	40
50	490.34	500.14	509.95	519.76	529.56	539.37	549.18	558.98	568.79	578.60	50
60	588.40	598.21	608.02	617.82	627.63	637.44	647.24	657.05	666.86	676.66	60
70	686.47	696.28	706.08	715.89	725.70	735.50	745.31	755.12	764.92	774.73	70
80	784.54	794.34	804.15	813.96	823.76	833.57	843.38	853.18	862.99	872.80	80
90	882.60	892.41	902.22	912.02	921.83	931.64	941.44	951.25	961.06	970.86	90
100	980.67	990.48	1000.28	1010.09	1019.90	1029.70	1039.51	1049.32	1059.12	1068.93	100

NEWTON TO KILOGRAMS

N	0	10	20	30	40	50	60	70	80	90	N
	kg	kg	kg	kg	kg	kg	kg	kg	kg	kg	
—	—	1.020	2.039	3.059	4.079	5.099	6.118	7.138	8.158	9.177	—
100	10.197	11.217	12.237	13.256	14.276	15.296	16.316	17.335	18.355	19.375	100
200	20.394	21.414	22.434	23.454	24.473	25.493	26.513	27.532	28.552	29.572	200
300	30.592	31.611	32.631	33.651	34.670	35.690	36.710	37.730	38.749	39.769	300
400	40.789	41.809	42.828	43.848	44.868	45.887	46.907	47.927	48.947	49.966	400
500	50.986	52.006	53.025	54.045	55.065	56.085	57.104	58.124	59.144	60.163	500
600	61.183	62.203	63.223	64.242	65.262	66.282	67.302	68.321	69.341	70.361	600
700	71.380	72.400	73.420	74.440	75.459	76.479	77.499	78.518	79.538	80.558	700
800	81.578	82.597	83.617	84.637	85.656	86.676	87.696	88.716	89.735	90.755	800
900	91.775	92.795	93.814	94.834	95.854	96.873	97.893	98.913	99.933	100.952	900
1000	101.972	102.992	104.011	105.031	106.051	107.071	108.090	109.110	110.130	111.149	1000

14-6 CONVERSION TABLE

PRESSURE

POUNDS PER SQUARE INCHES TO KILOGRAMS PER SQUARE CENTIMETERS

lb/in ²	0	1	2	3	4	5	6	7	8	9	lb/in ²
(psi)	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	(psi)
—	—	0.0703	0.1406	0.2109	0.2812	0.3515	0.4218	0.4921	0.5625	0.6328	—
10	0.7031	0.7734	0.8437	0.9140	0.9843	1.0546	1.1249	1.1952	1.2655	1.3358	10
20	1.4061	1.4764	1.5468	1.6171	1.6874	1.7577	1.8280	1.8983	1.9686	2.0389	20
30	2.1092	2.1795	2.2498	2.3201	2.3904	2.4607	2.5311	2.6014	2.6717	2.7420	30
40	2.8123	2.8826	2.9529	3.0232	3.0935	3.1638	3.2341	3.3044	3.3747	3.4450	40
50	3.5154	3.5857	3.6560	3.7263	3.7966	3.8669	3.9372	4.0075	4.0778	4.1481	50
60	4.2184	4.2887	4.3590	4.4293	4.4996	4.5700	4.6403	4.7106	4.7809	4.8512	60
70	4.9215	4.9918	5.0621	5.1324	5.2027	5.2730	5.3433	5.4136	5.4839	5.5543	70
80	5.6246	5.6949	5.7652	5.8355	5.9058	5.9761	6.0464	6.1167	6.1870	6.2573	80
90	6.3276	6.3979	6.4682	6.5386	6.6089	6.6792	6.7495	6.8198	6.8901	6.9604	90
100	7.0307	7.1010	7.1713	7.2416	7.3119	7.3822	7.4525	7.5228	7.5932	7.6635	100

KILOGRAMS PER SQUARE CENTIMETERS TO POUNDS PER SQUARE INCHES

kg/cm ²	0	1	2	3	4	5	6	7	8	9	kg/cm ²
	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	lb/in ² (psi)	
—	—	14.22	28.45	42.67	56.89	71.12	85.34	99.56	113.78	128.01	—
10	142.23	156.45	170.68	184.90	199.12	213.35	227.57	241.79	256.01	270.24	10
20	284.46	298.68	312.91	327.13	341.35	355.58	369.80	384.02	398.24	412.47	20
30	426.69	440.91	455.14	469.36	483.58	497.81	512.03	526.25	540.47	554.70	30
40	568.92	583.14	597.37	611.59	625.81	640.04	654.26	668.48	682.70	696.93	40
50	711.15	725.37	739.60	753.82	768.04	782.27	796.49	810.71	824.93	839.16	50
60	853.38	867.60	881.83	896.05	910.27	924.50	938.72	952.94	967.16	981.39	60
70	995.61	1009.83	1024.06	1038.28	1052.50	1066.73	1080.95	1095.17	1109.39	1123.62	70
80	1137.84	1152.06	1166.29	1180.51	1194.73	1208.96	1223.18	1237.40	1251.62	1265.85	80
90	1280.07	1294.29	1308.52	1322.74	1336.96	1351.19	1365.41	1379.63	1393.85	1408.08	90
100	1422.30	1436.52	1450.75	1464.97	1479.19	1493.42	1507.64	1521.86	1536.08	1550.31	100

KILOGRAMS PER SQUARE CENTIMETERS TO KILO PASCAL

kg/cm ²	0	1	2	3	4	5	6	7	8	9	kg/cm ²
	KPa	KPa	KPa	KPa	KPa	KPa	KPa	KPa	KPa	KPa	
—	—	98.1	196.1	294.2	392.3	490.3	588.4	686.5	784.5	882.6	—
10	980.7	1078.7	1176.8	1274.9	1372.9	1471.0	1569.1	1667.1	1765.2	1863.3	10
20	1961.3	2059.4	2157.5	2255.5	2353.6	2451.7	2549.7	2647.8	2745.9	2843.9	20
30	2942.0	3040.1	3138.1	3236.2	3334.3	3432.3	3530.4	3628.5	3726.5	3824.6	30
40	3922.7	4020.7	4118.8	4216.9	4314.9	4413.0	4511.1	4609.1	4707.2	4805.3	40
50	4903.4	5001.4	5099.5	5197.6	5295.6	5393.7	5491.8	5589.8	5687.9	5786.0	50
60	5884.0	5982.1	6080.2	6178.2	6276.3	6374.4	6472.4	6570.5	6668.6	6766.6	60
70	6864.7	6962.8	7060.8	7158.9	7257.0	7355.0	7453.1	7551.2	7649.2	7747.3	70
80	7845.4	7943.4	8041.5	8139.6	8237.6	8335.7	8433.8	8531.8	8629.9	8728.0	80
90	8826.0	8924.1	9022.2	9120.2	9218.3	9316.4	9414.4	9512.5	9610.6	9708.6	90
100	9806.7	9904.8	10002.8	10100.9	10199.0	10297.0	10395.1	10493.2	10591.2	10689.3	100

KILO PASCAL TO KILOGRAMS PER SQUARE CENTIMETERS

KPa	0	100	200	300	400	500	600	700	800	900	KPa
	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	kg/cm ²	
—	—	1.020	2.039	3.059	4.079	5.099	6.118	7.138	8.158	9.177	—
1000	10.197	11.217	12.237	13.256	14.276	15.296	16.316	17.335	18.355	19.375	1000
2000	20.394	21.414	22.434	23.454	24.473	25.493	26.513	27.532	28.552	29.572	2000
3000	30.592	31.611	32.631	33.651	34.670	35.690	36.710	37.730	38.749	39.769	3000
4000	40.789	41.809	42.828	43.848	44.868	45.887	46.907	47.927	48.947	49.966	4000
5000	50.986	52.006	53.025	54.045	55.065	56.085	57.104	58.124	59.144	60.163	5000
6000	61.183	62.203	63.223	64.242	65.262	66.282	67.302	68.321	69.341	70.361	6000
7000	71.380	72.400	73.420	74.440	75.459	76.479	77.499	78.518	79.538	80.558	7000
8000	81.578	82.597	83.617	84.637	85.656	86.676	87.696	88.716	89.735	90.755	8000
9000	91.775	92.795	93.814	94.834	95.854	96.873	97.893	98.913	99.933	100.952	9000
10000	101.972	102.992	104.011	105.031	106.051	107.071	108.090	109.110	110.130	111.149	10000

TORQUE

FOOT POUNDS TO KILOGRAMMETERS

ft. lbs.	0	1	2	3	4	5	6	7	8	9	ft. lbs.
	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	
—	—	0.138	0.277	0.415	0.553	0.691	0.830	0.968	1.106	1.244	—
10	1.383	1.521	1.659	1.797	1.936	2.074	2.212	2.350	2.489	2.627	10
20	2.765	2.903	3.042	3.180	3.318	3.457	3.595	3.733	3.871	4.010	20
30	4.148	4.286	4.424	4.563	4.701	4.839	4.977	5.116	5.254	5.392	30
40	5.530	5.669	5.807	5.945	6.083	6.222	6.360	6.498	6.636	6.775	40
50	6.913	7.051	7.190	7.328	7.466	7.604	7.743	7.881	8.019	8.157	50
60	8.296	8.434	8.572	8.710	8.849	8.987	9.125	9.263	9.402	9.540	60
70	9.678	9.816	9.955	10.093	10.231	10.370	10.508	10.646	10.784	10.923	70
80	11.061	11.199	11.337	11.476	11.614	11.752	11.890	12.029	12.167	12.305	80
90	12.443	12.582	12.720	12.858	12.996	13.135	13.273	13.411	13.549	13.688	90
100	13.826	13.964	14.103	14.241	14.379	14.517	14.656	14.794	14.932	15.070	100

KILOGRAMMETERS TO FOOT POUNDS

kg-m	0	1	2	3	4	5	6	7	8	9	kg-m
	ft. lbs.	ft. lbs.	ft. lbs.	ft. lbs.	ft. lbs.	ft. lbs.	ft. lbs.	ft. lbs.	ft. lbs.	ft. lbs.	
—	—	7.23	14.47	21.70	28.93	36.17	43.40	50.63	57.86	65.10	—
10	72.33	79.56	86.80	94.03	101.26	108.50	115.73	122.96	130.19	137.43	10
20	144.66	151.89	159.13	166.36	173.59	180.83	188.06	195.29	202.52	209.76	20
30	216.99	224.22	231.46	238.69	245.92	253.16	260.39	267.62	274.85	282.09	30
40	289.32	296.55	303.79	311.02	318.25	325.49	332.72	339.95	347.18	354.42	40
50	361.65	368.88	376.12	383.35	390.58	397.82	405.05	412.28	419.51	426.75	50
60	433.98	441.21	448.45	455.68	462.91	470.15	477.38	484.61	491.84	499.08	60
70	506.31	513.54	520.78	528.01	535.24	542.48	549.71	556.94	564.17	571.41	70
80	578.64	585.87	593.11	600.34	607.57	614.81	622.04	629.27	636.50	643.74	80
90	650.97	658.20	665.44	672.67	679.90	687.14	694.37	701.60	708.83	716.07	90
100	723.30	730.53	737.77	745.00	752.23	759.47	766.70	773.93	781.16	788.40	100

KILOGRAMMETERS TO NEWTONMETERS

kg-m	0	1	2	3	4	5	6	7	8	9	kg-m
	N-m	N-m	N-m	N-m	N-m	N-m	N-m	N-m	N-m	N-m	
—	—	9.81	19.61	29.42	39.23	49.03	58.84	68.65	78.45	88.26	—
10	98.07	107.87	117.68	127.49	137.29	147.10	156.91	166.71	176.52	186.33	10
20	196.13	205.94	215.75	225.55	235.36	245.17	254.97	264.78	274.59	284.39	20
30	294.20	304.01	313.81	323.62	333.43	343.23	353.04	362.85	372.65	382.46	30
40	392.27	402.07	411.88	421.69	431.49	441.30	451.11	460.91	470.72	480.53	40
50	490.34	500.14	509.95	519.76	529.56	539.37	549.18	558.98	568.79	578.60	50
60	588.40	598.21	608.02	617.82	627.63	637.44	647.24	657.05	666.86	676.66	60
70	686.47	696.28	706.08	715.89	725.70	735.50	745.31	755.12	764.92	774.73	70
80	784.54	794.34	804.15	813.96	823.76	833.57	843.38	853.18	862.99	872.80	80
90	882.60	892.41	902.22	912.02	921.83	931.64	941.44	951.25	961.06	970.86	90
100	980.67	990.48	1000.28	1010.09	1019.90	1029.70	1039.51	1049.32	1059.12	1068.93	100

NEWTONMETERS TO KILOGRAMMETERS

N-m	0	10	20	30	40	50	60	70	80	90	N-m
	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	kg-m	
—	—	1.020	2.039	3.059	4.079	5.099	6.118	7.138	8.158	9.177	—
100	10.197	11.217	12.236	13.256	14.276	15.296	16.315	17.335	18.355	19.374	100
200	20.394	21.414	22.433	23.453	24.473	25.493	26.512	27.532	28.552	29.571	200
300	30.591	31.611	32.630	33.650	34.670	35.690	36.709	37.729	38.749	39.768	300
400	40.788	41.808	42.827	43.847	44.867	45.887	46.906	47.926	48.946	49.965	400
500	50.985	52.005	53.024	54.044	55.064	56.084	57.103	58.123	59.143	60.162	500
600	61.182	62.202	63.221	64.241	65.261	66.281	67.300	68.320	69.340	70.359	600
700	71.379	72.399	73.418	74.438	75.458	76.478	77.497	78.517	79.537	80.556	700
800	81.576	82.596	83.615	84.635	85.655	86.675	87.694	88.714	89.734	90.753	800
900	91.773	92.793	93.812	94.832	95.852	96.872	97.891	98.911	99.931	100.950	900
1000	101.970	102.990	104.009	105.029	106.049	107.069	108.088	109.108	110.128	111.147	1000

14-8 CONVERSION TABLE

TEMPERATURE

FAHRENHEIT TO CENTIGRADE

°F	°C	°F	°C	°F	°C	°F	°C	°F	°C	°F	°C	°F	°C	°F	°C
-60	-51.1	-2	-18.9	56	13.3	114	45.6	172	77.8	230	110.0	288	142.2	346	174.4
-58	-50.0	0	-17.8	58	14.4	116	46.7	174	78.9	232	111.1	290	143.3	348	175.6
-56	-48.9	2	-16.7	60	15.6	118	47.8	176	80.0	234	112.2	292	144.4	350	176.7
-54	-47.8	4	-15.6	62	16.7	120	48.9	178	81.1	236	113.3	294	145.6	352	177.8
-52	-46.7	6	-14.4	64	17.8	122	50.0	180	82.2	238	114.4	296	146.7	354	178.9
-50	-45.6	8	-13.3	66	18.9	124	51.1	182	83.3	240	115.6	298	147.8	356	180.0
-48	-44.4	10	-12.2	68	20.0	126	52.2	184	84.4	242	116.7	300	148.9	358	181.1
-46	-43.3	12	-11.1	70	21.1	128	53.3	186	85.6	244	117.8	302	150.0	360	182.2
-44	-42.2	14	-10.0	72	22.2	130	54.4	188	86.7	246	118.9	304	151.1	362	183.3
-42	-41.1	16	-8.9	74	23.3	132	55.6	190	87.8	248	120.0	306	152.2	364	184.4
-40	-40.0	18	-7.8	76	24.4	134	56.7	192	88.9	250	121.1	308	153.3	366	185.6
-38	-38.9	20	-6.7	78	25.6	136	57.8	194	90.0	252	122.2	310	154.4	368	186.7
-36	-37.8	22	-5.6	80	26.7	138	58.9	196	91.1	254	123.3	312	155.6	370	187.8
-34	-36.7	24	-4.4	82	27.8	140	60.0	198	92.2	256	124.4	314	156.7	372	188.9
-32	-35.6	26	-3.3	84	28.9	142	61.1	200	93.3	258	125.6	316	157.8	374	190.0
-30	-34.4	28	-2.2	86	30.0	144	62.2	202	94.4	260	126.7	318	158.9	376	191.1
-28	-33.3	30	-1.1	88	31.1	146	63.3	204	95.6	262	127.8	320	160.0	378	192.2
-26	-32.2	32	0.0	90	32.2	148	64.4	206	96.7	264	128.9	322	161.1	380	193.3
-24	-31.1	34	1.1	92	33.3	150	65.6	208	97.8	266	130.0	324	162.2	382	194.4
-22	-30.0	36	2.2	94	34.4	152	66.7	210	98.9	268	131.1	326	163.3	384	195.6
-20	-28.9	38	3.3	96	35.6	154	67.8	212	100.0	270	132.2	328	164.4	386	196.7
-18	-27.8	40	4.4	98	36.7	156	68.9	214	101.1	272	133.3	330	165.6	388	197.8
-16	-26.7	42	5.6	100	37.8	158	70.0	216	102.2	274	134.4	332	166.7	390	198.9
-14	-25.6	44	6.7	102	38.9	160	71.1	218	103.3	276	135.6	334	167.8	392	200.0
-12	-24.4	46	7.8	104	40.0	162	72.2	220	104.4	278	136.7	336	168.9	400	204.4
-10	-23.3	48	8.9	106	41.1	164	73.3	222	105.6	280	137.8	338	170.0	410	210.0
-8	-22.2	50	10.0	108	42.2	166	74.4	224	106.7	282	138.9	340	171.1	420	215.6
-6	-21.1	52	11.1	110	43.3	168	75.6	226	107.8	284	140.0	342	172.2	430	221.1
-4	-20.0	54	12.2	112	44.4	170	76.7	228	108.9	286	141.1	344	173.3	440	226.7

CENTIGRADE TO FAHRENHEIT

°C	°F	°C	°F	°C	°F	°C	°F	°C	°F	°C	°F	°C	°F	°C	°F
-50	-58.0	-18	-0.4	14	57.2	46	114.8	78	172.4	110	230.0	142	287.6	174	345.2
-49	-56.2	-17	1.4	15	59.0	47	116.6	79	174.2	111	231.8	143	289.4	175	347.0
-48	-54.4	-16	3.2	16	60.8	48	118.4	80	176.0	112	233.6	144	291.2	176	348.8
-47	-52.6	-15	5.0	17	62.6	49	120.2	81	177.8	113	235.4	145	293.0	177	350.6
-46	-50.8	-14	6.8	18	64.4	50	122.0	82	179.6	114	237.2	146	294.8	178	352.4
-45	-49.0	-13	8.6	19	66.2	51	123.8	83	181.4	115	239.0	147	296.6	179	354.2
-44	-47.2	-12	10.4	20	68.0	52	125.6	84	183.2	116	240.8	148	298.4	180	356.0
-43	-45.4	-11	12.2	21	69.8	53	127.4	85	185.0	117	242.6	149	300.2	181	357.8
-42	-43.6	-10	14.0	22	71.6	54	129.2	86	186.8	118	244.4	150	302.0	182	359.6
-41	-41.8	-9	15.8	23	73.4	55	131.0	87	188.6	119	246.2	151	303.8	183	361.4
-40	-40.0	-8	17.6	24	75.2	56	132.8	88	190.4	120	248.0	152	305.6	184	363.2
-39	-38.2	-7	19.4	25	77.0	57	134.6	89	192.2	121	249.8	153	307.4	185	365.0
-38	-36.4	-6	21.2	26	78.8	58	136.4	90	194.0	122	251.6	154	309.2	186	366.8
-37	-34.6	-5	23.0	27	80.6	59	138.2	91	195.8	123	253.4	155	311.0	187	368.6
-36	-32.8	-4	24.8	28	82.4	60	140.0	92	197.6	124	255.2	156	312.8	188	370.4
-35	-31.0	-3	26.6	29	84.2	61	141.8	93	199.4	125	257.0	157	314.6	189	372.2
-34	-29.2	-2	28.4	30	86.0	62	143.6	94	201.2	126	258.8	158	316.4	190	374.0
-33	-27.4	-1	30.2	31	87.8	63	145.4	95	203.0	127	260.6	159	318.2	191	375.8
-32	-25.6	0	32.0	32	89.6	64	147.2	96	204.8	128	262.4	160	320.0	192	377.6
-31	-23.8	1	33.8	33	91.4	65	149.0	97	206.6	129	264.2	161	321.8	193	379.4
-30	-22.0	2	35.6	34	93.2	66	150.8	98	208.4	130	266.0	162	323.6	194	381.2
-29	-20.2	3	37.4	35	95.0	67	152.6	99	210.2	131	267.8	163	325.4	195	383.0
-28	-18.4	4	39.2	36	96.8	68	154.4	100	212.0	132	269.6	164	327.2	196	384.8
-27	-16.6	5	41.0	37	98.6	69	156.2	101	213.8	133	271.4	165	329.0	197	386.6
-26	-14.8	6	42.8	38	100.4	70	158.0	102	215.6	134	273.2	166	330.8	198	388.4
-25	-13.0	7	44.6	39	102.2	71	159.8	103	217.4	135	275.0	167	332.6	199	390.2
-24	-11.2	8	46.4	40	104.0	72	161.6	104	219.2	136	276.8	168	334.4	200	392.0
-23	-9.4	9	48.2	41	105.8	73	163.4	105	221.0	137	278.6	169	336.2	210	410.0
-22	-7.6	10	50.0	42	107.6	74	165.2	106	222.8	138	280.4	170	338.0	220	428.0
-21	-5.8	11	51.8	43	109.4	75	167.0	107	224.6	139	282.2	171	339.8	230	446.0
-20	-4.0	12	53.6	44	111.2	76	168.8	108	226.4	140	284.0	172	341.6	240	464.0
-19	-2.2	13	55.4	45	113.0	77	170.6	109	228.2	141	285.8	173	343.4	250	482.0

Copyright reserved for this manual may not be reproduced or copied, in whole or in part, without the written consent of ISUZU MOTORS LIMITED.

WORKSHOP MANUAL (INDUSTRIAL)

4BG1, 6BG1

(IDE-2280)

Issued by

ISUZU MOTORS LIMITED
ENGINE SALES ENGINEERING DEPT.
6-26-1, Minami-oi, Shinagawa-ku, Tokyo, 140, Japan
TEL 03-5471-1111

First edition Dec., 1995

602-01-200K

ISUZU

IDE-2280