



Operation and Maintenance Manual

C9 Industrial Engine

JSC1-Up (Engine) MBD1-Up (Engine) JLW1-Up (Engine)

Important Safety Information

Most accidents that involve product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards. This person should also have the necessary training, skills and tools to perform these functions properly.

Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.

Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.

Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "DANGER", "WARNING" or "CAUTION". The Safety Alert "WARNING" label is shown below.



The meaning of this safety alert symbol is as follows:

Attention! Become Alert! Your Safety is Involved.

The message that appears under the warning explains the hazard and can be either written or pictorially presented.

Operations that may cause product damage are identified by "NOTICE" labels on the product and in this publication.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are, therefore, not all inclusive. If a tool, procedure, work method or operating technique that is not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that the product will not be damaged or be made unsafe by the operation, lubrication, maintenance or repair procedures that you choose.

The information, specifications, and illustrations in this publication are on the basis of information that was available at the time that the publication was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service that is given to the product. Obtain the complete and most current information before you start any job. Caterpillar dealers have the most current information available.

WARNING

When replacement parts are required for this product Caterpillar recommends using Caterpillar replacement parts or parts with equivalent specifications including, but not limited to, physical dimensions, type, strength and material.

Failure to heed this warning can lead to premature failures, product damage, personal injury or death.

Table of Contents

Foreword 4
Safety Section
Safety Messages 6
General Hazard Information 8
Burn Prevention 10
Fire Prevention and Explosion Prevention 11
Crushing Prevention and Cutting Prevention 13
Mounting and Dismounting 13
Before Starting Engine
Engine Starting
Engine Stopping
Electrical System
Engine Electronics
Product Information Section
General Information
Model Views 18
Product Identification Information
Operation Section
Lifting and Storage
Gauges and Indicators
Features and Controls
Engine Diagnostics
Engine Starting
Engine Operation 41
Engine Stopping
Cold Weather Operation 44
Maintenance Section
Refill Capacities
Maintenance Interval Schedule 51

Warranty Section

Warranty Information	88
Reference Information Section	
Engine Ratings	89
Customer Service	91
Reference Materials	93
Index Section	
Index	97

Foreword

Literature Information

This manual contains safety, operation instructions, lubrication and maintenance information. This manual should be stored in or near the engine area in a literature holder or literature storage area. Read, study and keep it with the literature and engine information.

English is the primary language for all Caterpillar publications. The English used facilitates translation and consistency in electronic media delivery.

Some photographs or illustrations in this manual show details or attachments that may be different from your engine. Guards and covers may have been removed for illustrative purposes. Continuing improvement and advancement of product design may have caused changes to your engine which are not included in this manual. Whenever a question arises regarding your engine, or this manual, please consult with your Caterpillar dealer for the latest available information.

Safety

This safety section lists basic safety precautions. In addition, this section identifies hazardous, warning situations. Read and understand the basic precautions listed in the safety section before operating or performing lubrication, maintenance and repair on this product.

Operation

Operating techniques outlined in this manual are basic. They assist with developing the skills and techniques required to operate the engine more efficiently and economically. Skill and techniques develop as the operator gains knowledge of the engine and its capabilities.

The operation section is a reference for operators. Photographs and illustrations guide the operator through procedures of inspecting, starting, operating and stopping the engine. This section also includes a discussion of electronic diagnostic information.

Maintenance

The maintenance section is a guide to engine care. The illustrated, step-by-step instructions are grouped by fuel consumption, service hours and/or calendar time maintenance intervals. Items in the maintenance schedule are referenced to detailed instructions that follow.

Use fuel consumption or service hours to determine intervals. Calendar intervals shown (daily, annually, etc.) may be used instead of service meter intervals if they provide more convenient schedules and approximate the indicated service meter reading.

Recommended service should be performed at the appropriate intervals as indicated in the Maintenance Interval Schedule. The actual operating environment of the engine also governs the Maintenance Interval Schedule. Therefore, under extremely severe, dusty, wet or freezing cold operating conditions, more frequent lubrication and maintenance than is specified in the Maintenance Interval Schedule may be necessary.

The maintenance schedule items are organized for a preventive maintenance management program. If the preventive maintenance program is followed, a periodic tune-up is not required. The implementation of a preventive maintenance management program should minimize operating costs through cost avoidances resulting from reductions in unscheduled downtime and failures.

Maintenance Intervals

Perform maintenance on items at multiples of the original requirement. Each level and/or individual items in each level should be shifted ahead or back depending upon your specific maintenance practices, operation and application. We recommend that the maintenance schedules be reproduced and displayed near the engine as a convenient reminder. We also recommend that a maintenance record be maintained as part of the engine's permanent record.

See the section in the Operation and Maintenance Manual, "Maintenance Records" for information regarding documents that are generally accepted as proof of maintenance or repair. Your authorized Caterpillar dealer can assist you in adjusting your maintenance schedule to meet the needs of your operating environment.

Overhaul

Major engine overhaul details are not covered in the Operation and Maintenance Manual except for the interval and the maintenance items in that interval. Major repairs are best left to trained personnel or an authorized Caterpillar dealer. Your Caterpillar dealer offers a variety of options regarding overhaul programs. If you experience a major engine failure, there are also numerous after failure overhaul options available from your Caterpillar dealer. Consult with your dealer for information regarding these options.

California Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. **Wash hands after handling.**

Safety Section

i02246834

Safety Messages

SMCS Code: 1000; 7405

There may be several specific safety messages on an engine. The exact location of the hazards and the description of the hazards are reviewed in this section. Please become familiar with all safety messages.

Ensure that all of the safety messages are legible. Clean the safety messages or replace the safety messages if the words cannot be read or if the pictures are not visible. When the safety messages are cleaned, use a cloth, water, and soap. Do not use solvent, gasoline, or other harsh chemicals to clean the safety messages. Solvents, gasoline, or harsh chemicals could loosen the adhesive that secures the safety messages. The safety messages that are loosened could drop off of the engine.

Replace any damaged safety messages or missing safety messages. If a safety message is attached to a part of the engine that is replaced, install a new safety message on the replacement part. Any Caterpillar dealer can provide new safety messages.

Do not work on the engine and do not operate the engine unless the instructions and the warnings in the Operation and Maintenance Manual are understood. Proper care is your responsibility. Failure to follow the instructions or failure to heed the warnings could result in injury or in death.




Illustration 1 g01104158




Illustration 2 g01104164

The following section describes the safety messages that are found on the engine.

(1) Universal Warning




Illustration 3

The universal safety messages are located on each side of the valve covers.

A WARNING

Do not operate or work on this equipment unless you have read and understand the instructions and warnings in the Operation and Maintenance Manuals. Failure to follow the instructions or heed the warnings could result in serious injury or death.

i01377208

General Hazard Information

SMCS Code: 1000; 7405




Illustration 4

g00104545

Attach a "Do Not Operate" warning tag or a similar warning tag to the start switch or to the controls before the engine is serviced or before the engine is repaired. These warning tags (Special Instruction, SEHS7332) are available from your Caterpillar dealer. Attach the warning tags to the engine and to each operator control station. When it is appropriate, disconnect the starting controls.

q01113574

Do not allow unauthorized personnel on the engine, or around the engine when the engine is being serviced.

Engine exhaust contains products of combustion which may be harmful to your health. Always start the engine and operate the engine in a well ventilated area. If the engine is in an enclosed area, vent the engine exhaust to the outside.

Cautiously remove the following parts. To help prevent spraying or splashing of pressurized fluids, hold a rag over the part that is being removed.

- · Filler caps
- Grease fittings
- Pressure taps
- · Breathers
- Drain plugs

Use caution when cover plates are removed. Gradually loosen, but do not remove the last two bolts or nuts that are located at opposite ends of the cover plate or the device. Before removing the last two bolts or nuts, pry the cover loose in order to relieve any spring pressure or other pressure.




Illustration 5 g00702020

- Wear a hard hat, protective glasses, and other protective equipment, as required.
- When work is performed around an engine that is operating, wear protective devices for ears in order to help prevent damage to hearing.
- Do not wear loose clothing or jewelry that can snag on controls or on other parts of the engine.
- Ensure that all protective guards and all covers are secured in place on the engine.
- Never put maintenance fluids into glass containers. Glass containers can break.
- Use all cleaning solutions with care.
- · Report all necessary repairs.

Unless other instructions are provided, perform the maintenance under the following conditions:

- The engine is stopped. Ensure that the engine cannot be started.
- Disconnect the batteries when maintenance is performed or when the electrical system is serviced. Disconnect the battery ground leads. Tape the leads in order to help prevent sparks.
- Do not attempt any repairs that are not understood.
 Use the proper tools. Replace any equipment that is damaged or repair the equipment.

Pressure Air and Water

Pressurized air and/or water can cause debris and/or hot water to be blown out. This could result in personal injury.

When pressure air and/or pressure water is used for cleaning, wear protective clothing, protective shoes, and eye protection. Eye protection includes goggles or a protective face shield.

The maximum air pressure for cleaning purposes must be below 205 kPa (30 psi). The maximum water pressure for cleaning purposes must be below 275 kPa (40 psi).

Fluid Penetration




Illustration 6 g00687600

Always use a board or cardboard when you check for a leak. Leaking fluid that is under pressure can penetrate body tissue. Fluid penetration can cause serious injury and possible death. A pin hole leak can cause severe injury. If fluid is injected into your skin, you must get treatment immediately. Seek treatment from a doctor that is familiar with this type of injury.

Containing Fluid Spillage

Care must be taken in order to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the engine. Prepare to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Tools and Shop Products Guide" for the following items:

- Tools that are suitable for collecting fluids and equipment that is suitable for collecting fluids
- Tools that are suitable for containing fluids and equipment that is suitable for containing fluids

Obey all local regulations for the disposal of liquids.

Asbestos Information




Illustration 7 g00702022

Caterpillar equipment and replacement parts that are shipped from Caterpillar are asbestos free. Caterpillar recommends the use of only genuine Caterpillar replacement parts. Use the following guidelines when you handle any replacement parts that contain asbestos or when you handle asbestos debris.

Use caution. Avoid inhaling dust that might be generated when you handle components that contain asbestos fibers. Inhaling this dust can be hazardous to your health. The components that may contain asbestos fibers are brake pads, brake bands, lining material, clutch plates, and some gaskets. The asbestos that is used in these components is usually bound in a resin or sealed in some way. Normal handling is not hazardous unless airborne dust that contains asbestos is generated.

If dust that may contain asbestos is present, there are several guidelines that should be followed:

- Never use compressed air for cleaning.
- Avoid brushing materials that contain asbestos.
- · Avoid grinding materials that contain asbestos.
- Use a wet method in order to clean up asbestos materials.
- A vacuum cleaner that is equipped with a high efficiency particulate air filter (HEPA) can also be used.
- Use exhaust ventilation on permanent machining jobs.
- Wear an approved respirator if there is no other way to control the dust.

- Comply with applicable rules and regulations for the work place. In the United States, use Occupational Safety and Health Administration (OSHA) requirements. These OSHA requirements can be found in "29 CFR 1910.1001".
- Obey environmental regulations for the disposal of asbestos.
- Stay away from areas that might have asbestos particles in the air.

Dispose of Waste Properly




Illustration 8 g00706404

Improperly disposing of waste can threaten the environment. Potentially harmful fluids should be disposed of according to local regulations.

Always use leakproof containers when you drain fluids. Do not pour waste onto the ground, down a drain, or into any source of water.

i01480768

Burn Prevention

SMCS Code: 1000: 7405

Do not touch any part of an operating engine. Allow the engine to cool before any maintenance is performed on the engine. Relieve all pressure in the air system, in the hydraulic system, in the lubrication system, in the fuel system, or in the cooling system before any lines, fittings or related items are disconnected.

Coolant

When the engine is at operating temperature, the engine coolant is hot. The coolant is also under pressure. The radiator and all lines to the heaters or to the engine contain hot coolant.

Any contact with hot coolant or with steam can cause severe burns. Allow cooling system components to cool before the cooling system is drained.

Check the coolant level after the engine has stopped and the engine has been allowed to cool.

Ensure that the filler cap is cool before removing the filler cap. The filler cap must be cool enough to touch with a bare hand. Remove the filler cap slowly in order to relieve pressure.

Cooling system conditioner contains alkali. Alkali can cause personal injury. Do not allow alkali to contact the skin, the eyes, or the mouth.

Oils

Hot oil and hot lubricating components can cause personal injury. Do not allow hot oil to contact the skin. Also, do not allow hot components to contact the skin.

Batteries

Electrolyte is an acid. Electrolyte can cause personal injury. Do not allow electrolyte to contact the skin or the eyes. Always wear protective glasses for servicing batteries. Wash hands after touching the batteries and connectors. Use of gloves is recommended.

i01372254

a00704000

Fire Prevention and Explosion Prevention

SMCS Code: 1000; 7405




Illustration 9

All fuels, most lubricants, and some coolant mixtures are flammable.

Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire. Fire may cause personal injury and property damage.

A flash fire may result if the covers for the engine crankcase are removed within fifteen minutes after an emergency shutdown.

Determine whether the engine will be operated in an environment that allows combustible gases to be drawn into the air inlet system. These gases could cause the engine to overspeed. Personal injury, property damage, or engine damage could result.

If the application involves the presence of combustible gases, consult your Caterpillar dealer for additional information about suitable protection devices.

Remove all flammable materials such as fuel, oil, and debris from the engine. Do not allow any flammable materials to accumulate on the engine.

Store fuels and lubricants in properly marked containers away from unauthorized persons. Store oily rags and any flammable materials in protective containers. Do not smoke in areas that are used for storing flammable materials.

Do not expose the engine to any flame.

Exhaust shields (if equipped) protect hot exhaust components from oil or fuel spray in case of a line, a tube, or a seal failure. Exhaust shields must be installed correctly.

Do not weld on lines or tanks that contain flammable fluids. Do not flame cut lines or tanks that contain flammable fluid. Clean any such lines or tanks thoroughly with a nonflammable solvent prior to welding or flame cutting.

Wiring must be kept in good condition. All electrical wires must be properly routed and securely attached. Check all electrical wires daily. Repair any wires that are loose or frayed before you operate the engine. Clean all electrical connections and tighten all electrical connections.

Eliminate all wiring that is unattached or unnecessary. Do not use any wires or cables that are smaller than the recommended gauge. Do not bypass any fuses and/or circuit breakers.

Arcing or sparking could cause a fire. Secure connections, recommended wiring, and properly maintained battery cables will help to prevent arcing or sparking.

Inspect all lines and hoses for wear or for deterioration. The hoses must be properly routed. The lines and hoses must have adequate support and secure clamps. Tighten all connections to the recommended torque. Leaks can cause fires.

Oil filters and fuel filters must be properly installed. The filter housings must be tightened to the proper torque.



Illustration 10 g00704059

Use caution when you are refueling an engine. Do not smoke while you are refueling an engine. Do not refuel an engine near open flames or sparks. Always stop the engine before refueling.



Gases from a battery can explode. Keep any open flames or sparks away from the top of a battery. Do not smoke in battery charging areas.

Never check the battery charge by placing a metal object across the terminal posts. Use a voltmeter or a hydrometer.

Improper jumper cable connections can cause an explosion that can result in injury. Refer to the Operation Section of this manual for specific instructions.

Do not charge a frozen battery. This may cause an explosion.

The batteries must be kept clean. The covers (if equipped) must be kept on the cells. Use the recommended cables, connections, and battery box covers when the engine is operated.

Fire Extinguisher

Make sure that a fire extinguisher is available. Be familiar with the operation of the fire extinguisher. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instruction plate.

Ether

Ether is flammable and poisonous.

Use ether in well ventilated areas. Do not smoke while you are replacing an ether cylinder or while you are using an ether spray.

Do not store ether cylinders in living areas or in the engine compartment. Do not store ether cylinders in direct sunlight or in temperatures above 49 °C (120 °F). Keep ether cylinders away from open flames or sparks.

Dispose of used ether cylinders properly. Do not puncture an ether cylinder. Keep ether cylinders away from unauthorized personnel.

Do not spray ether into an engine if the engine is equipped with a thermal starting aid for cold weather starting.

Lines, Tubes and Hoses

Do not bend high pressure lines. Do not strike high pressure lines. Do not install any lines that are bent or damaged.

Repair any lines that are loose or damaged. Leaks can cause fires. Consult your Caterpillar dealer for repair or for replacement parts.

Illustration 11 g00704135

Check lines, tubes and hoses carefully. Do not use your bare hand to check for leaks. Use a board or cardboard to check for leaks. Tighten all connections to the recommended torque.

Replace the parts if any of the following conditions are present:

- End fittings are damaged or leaking.
- Outer coverings are chafed or cut.
- · Wires are exposed.
- Outer coverings are ballooning.
- Flexible part of the hoses are kinked.
- Outer covers have embedded armoring.
- · End fittings are displaced.

Make sure that all clamps, guards, and heat shields are installed correctly. During engine operation, this will help to prevent vibration, rubbing against other parts, and excessive heat.

i01359666

Crushing Prevention and Cutting Prevention

SMCS Code: 1000; 7405

Support the component properly when work beneath the component is performed.

Unless other maintenance instructions are provided, never attempt adjustments while the engine is running.

Stay clear of all rotating parts and of all moving parts. Leave the guards in place until maintenance is performed. After the maintenance is performed, reinstall the guards.

Keep objects away from moving fan blades. The fan blades will throw objects or cut objects.

When objects are struck, wear protective glasses in order to avoid injury to the eyes.

Chips or other debris may fly off objects when objects are struck. Before objects are struck, ensure that no one will be injured by flying debris.

i01372247

Mounting and Dismounting

SMCS Code: 1000; 7405

Inspect the steps, the handholds, and the work area before mounting the engine. Keep these items clean and keep these items in good repair.

Mount the engine and dismount the engine only at locations that have steps and/or handholds. Do not climb on the engine, and do not jump off the engine.

Face the engine in order to mount the engine or dismount the engine. Maintain a three-point contact with the steps and handholds. Use two feet and one hand or use one foot and two hands. Do not use any controls as handholds.

Do not stand on components which cannot support your weight. Use an adequate ladder or use a work platform. Secure the climbing equipment so that the equipment will not move.

Do not carry tools or supplies when you mount the engine or when you dismount the engine. Use a hand line to raise and lower tools or supplies.

i00911989

Before Starting Engine

SMCS Code: 1000

Inspect the engine for potential hazards.

Before starting the engine, ensure that no one is on, underneath, or close to the engine. All protective guards and all protective covers must be installed if the engine must be started in order to perform service procedures. To help prevent an accident that is caused by parts in rotation, work around the parts carefully.

Do not bypass the automatic shutoff circuits. Do not disable the automatic shutoff circuits. The circuits are provided in order to help prevent personal injury. The circuits are also provided in order to help prevent engine damage.

On the initial start-up of a new engine or an engine that has been serviced, prepare to stop the engine if an overspeed condition occurs. This may be accomplished by shutting off the fuel supply to the engine and/or shutting off the air supply to the engine.

See the Service Manual for repairs and for adjustments.

i00910470

i01462046

Engine Starting

SMCS Code: 1000

If a warning tag is attached to the engine start switch or to the controls, do not start the engine or move the controls. Also, do not disengage the parking brakes. Consult with the person that attached the warning tag before the engine is started.

All protective guards and all protective covers must be installed if the engine must be started in order to perform service procedures. To help prevent an accident that is caused by parts in rotation, work around the parts carefully.

Start the engine from the operator's station (cab). Never short across the starting motor terminals or the batteries. This could bypass the engine neutral start system and/or the electrical system could be damaged.

Always start the engine according to the procedure that is described in the Operation and Maintenance Manual, "Engine Starting" topic (Operation Section). Knowing the correct procedure will help to prevent major damage to the engine components. Knowing the procedure will also help to prevent personal injury.

To ensure that the jacket water heater (if equipped) and/or the lube oil heater (if equipped) is working properly, check the water temperature gauge and the oil temperature gauge during the heater operation.

Engine exhaust contains products of combustion that can be harmful to your health. Always start the engine and operate the engine in a well ventilated area. If the engine is started in an enclosed area, vent the engine exhaust to the outside.

Ether

Ether is poisonous and flammable. Do not inhale ether, and do not allow ether to contact the skin. Personal injury could result. Do not smoke while ether cylinders are changed. Use ether in well ventilated areas.

Keep ether cylinders out of the reach of unauthorized persons. Store ether cylinders in authorized storage areas only. Do not store ether cylinders in direct sunlight or at temperatures above 39 °C (102 °F). Discard the ether cylinders in a safe place. Do not puncture the ether cylinders. Do not burn the ether cylinders.

Engine Stopping

SMCS Code: 1000

Stop the engine according to the procedure in the Operation and Maintenance Manual, "Engine Stopping (Operation Section)" in order to avoid overheating of the engine and accelerated wear of the engine components.

Use the Emergency Stop Button (if equipped) ONLY in an emergency situation. Do not use the Emergency Stop Button for normal engine stopping. After an emergency stop, DO NOT start the engine until the problem that caused the emergency stop has been corrected.

Stop the engine if an overspeed condition occurs during the initial start-up of a new engine or an engine that has been overhauled. This may be accomplished by shutting off the fuel supply to the engine and/or shutting off the air supply to the engine.

To stop an electronically controlled engine, cut the power to the engine.

i01489749

Electrical System

SMCS Code: 1000; 1400

Never disconnect any charging unit circuit or battery circuit cable from the battery when the charging unit is operating. A spark can cause the combustible gases that are produced by some batteries to ignite.

To help prevent sparks from igniting combustible gases that are produced by some batteries, the negative "-" jump start cable should be connected last from the external power source to the negative "-" terminal of the starting motor. If the starting motor is not equipped with a negative "-" terminal, connect the jump start cable to the engine block.

Check the electrical wires daily for wires that are loose or frayed. Tighten all loose electrical wires before the engine is started. Repair all frayed electrical wires before the engine is started. See the Operation and Maintenance Manual for specific starting instructions.

g00774088

Grounding Practices




Illustration 12
Typical example
Grounding Stud To Battery Ground




Illustration 13

g00774062

Typical example

Alternate Grounding Stud To Battery Ground

Proper grounding for the engine electrical system is necessary for optimum engine performance and reliability. Improper grounding will result in uncontrolled electrical circuit paths and in unreliable electrical circuit paths.

Uncontrolled electrical circuit paths can result in damage to main bearings, to crankshaft bearing journal surfaces, and to aluminum components.

Engines that are installed without engine-to-frame ground straps can be damaged by electrical discharge.

To ensure that the engine and the engine electrical systems function properly, an engine-to-frame ground strap with a direct path to the battery must be used. This path may be provided by way of a starting motor ground, a starting motor ground to the frame, or a direct engine ground to the frame.

All grounds should be tight and free of corrosion. The engine alternator must be grounded to the negative "-" battery terminal with a wire that is adequate to handle the full charging current of the alternator.

i01563743

Engine Electronics

SMCS Code: 1000; 1400; 1900

WARNING

Tampering with the electronic system installation or the OEM wiring installation can be dangerous and could result in personal injury or death and/or engine damage.

This engine has a comprehensive, programmable Engine Monitoring System. The Engine Control Module (ECM) has the ability to monitor the engine operating conditions. If any of the engine parameters extend outside an allowable range, the ECM will initiate an immediate action.

The following actions are available for engine monitoring control: WARNING, DERATE, and SHUTDOWN. These engine monitoring modes have the ability to limit engine speed and/or the engine power.

Many of the parameters that are monitored by the ECM can be programmed for the engine monitoring functions. The following parameters can be monitored as a part of the Engine Monitoring System:

- Operating Altitude
- Engine Coolant Level
- Engine Coolant Temperature
- · Engine Oil Pressure
- · Engine Speed
- Fuel Temperature
- Intake Manifold Air Temperature
- · System Voltage

The Engine Monitoring package can vary for different engine models and different engine applications. However, the monitoring system and the engine monitoring control will be similar for all engines.

Note: Many of the engine control systems and display modules that are available for Caterpillar Engines will work in unison with the Engine Monitoring System. Together, the two controls will provide the engine monitoring function for the specific engine application. Refer to the Electronic Troubleshooting Manual for more information on the Engine Monitoring System.

Product Information Section

General Information

i02276735

Welding on Engines with Electronic Controls

SMCS Code: 1000

NOTICE

Because the strength of the frame may decrease, some manufacturers do not recommend welding onto a chassis frame or rail. Consult the OEM of the equipment or your Caterpillar dealer regarding welding on a chassis frame or rail.

Proper welding procedures are necessary in order to avoid damage to the engine's ECM, sensors, and associated components. When possible, remove the component from the unit and then weld the component. If removal of the component is not possible, the following procedure must be followed when you weld on a unit that is equipped with a Caterpillar Electronic Engine. The following procedure is considered to be the safest procedure to weld on a component. This procedure should provide a minimum risk of damage to electronic components.

NOTICE

Do not ground the welder to electrical components such as the ECM or sensors. Improper grounding can cause damage to the drive train bearings, hydraulic components, electrical components, and other components.

Clamp the ground cable from the welder to the component that will be welded. Place the clamp as close as possible to the weld. This will help reduce the possibility of damage.

- **1.** Stop the engine. Turn the switched power to the OFF position.
- 2. Disconnect the negative battery cable from the battery. If a battery disconnect switch is provided, open the switch.
- 3. Disconnect the J1/P1 and J2/P2 connectors from the ECM. Move the harness to a position that will not allow the harness to accidentally move back and make contact with any of the ECM pins.




Illustration 14 g01075639

Use the example above. The current flow from the welder to the ground clamp of the welder will not cause damage to any associated components.

- (1) Engine
- (2) Welding electrode
- (3) Keyswitch in the OFF position
- (4) Battery disconnect switch in the open position
- (5) Disconnected battery cables
- (6) Battery
- (7) Electrical/Electronic component
- (8) Minimum distance between the component that is being welded and any electrical/electronic component
- (9) The component that is being welded
- (10) Current path of the welder
- (11) Ground clamp for the welder
- 4. Connect the welding ground cable directly to the part that will be welded. Place the ground cable as close as possible to the weld in order to reduce the possibility of welding current damage to bearings, hydraulic components, electrical components, and ground straps.

Note: If electrical/electronic components are used as a ground for the welder, or electrical/electronic components are located between the welder ground and the weld, current flow from the welder could severely damage the component.


- Protect the wiring harness from welding debris and spatter.
- Use standard welding practices to weld the materials.

Model Views

i01474848

Model View Illustrations

SMCS Code: 1000



g00770182

Illustration 15

Right Side View

- (1) Valve mechanism cover
- (2) Turbocharger
- (3) Engine oil filler cap
- (4) Water temperature regulator housing
- (5) Exhaust manifold
- (6) Water pump
- (7) Flywheel housing
- (8) Engine oil pan
- (9) Engine oil filter
- (10) Vibration damper and crankshaft pulley




Illustration 16 g00774521

Left Side View

- (11) Engine oil filler
- (12) Electronic Control Module (ECM)
- (13) Air compressor
- (14) Oil drain plug

i01477858

Engine Description


SMCS Code: 1000

The Caterpillar C-9 Industrial Engine has the following characteristics:

- · In-Line 6 cylinder
- · Four stroke cycle
- Hydraulically Actuated Electronic Unit Injection (HEUI)
- Turbocharged
- · Air-to-air aftercooled

Engine Specifications

Note: The front end of the engine is opposite the flywheel end of the engine. The left and the right sides of the engine are determined from the flywheel end. The number 1 cylinder is the front cylinder.



Cylinder and valve location

- (A) Exhaust valve
- (B) Inlet valve

Table 1

C-9 Engine Specifications					
Arrangement and Cylinders	In-Line 6 cylinder				
Bore	112.0 mm (4.41 inch)				
Stroke	149.0 mm (5.87 inch)				
Aspiration	ATAAC(1)				
Displacement	8.8 L (537 in ³)				
Firing Order	1-5-3-6-2-4				
Rotation (flywheel end)	Counterclockwise				
Valve Lash (inlet)	0.38 mm (0.015 inch)				
Valve Lash (exhaust)	0.64 mm (0.025 inch)				

(1) Air-to-air aftercooled

Electronic Engine Features

The Caterpillar C-9 Engine is designed for electronic controls. The integral on board computer controls the operation of the engine. Current operating conditions are monitored. The Electronic Control Module (ECM) controls the response of the engine to these conditions and to the demands of the operator. These conditions and operator demands determine the precise control of fuel injection by the ECM. The electronic engine control system provides the following features:

- Engine speed governor
- · Automatic air/fuel ratio control
- Torque rise shaping
- Injection timing control
- System diagnostics

For more information on electronic engine features, refer to the Operation and Maintenance Manual, "Engine Features and Controls" topic (Operation Section).

Additional Features

The following additional features provide increased engine fuel economy and serviceability:

- · Cold starting capability
- Tampering detection
- · Diagnostics

Hydraulic Electronic Unit Injectors

Hydraulically Actuated Electronic Unit Injectors (HEUI) perform the following functions:

- · Pump the fuel.
- · Meter the fuel.
- · Time the fuel injection.

The unit injectors are controlled by the ECM which uses the camshaft position and the engine speed signals from the engine speed/timing sensors and the inlet air pressure sensors. The engine's rated rpm is identified on the Information Plate.

Engine Diagnostics

The engine has built-in diagnostics in order to ensure that all of the components are functioning properly. In the event of a deviation from the programmed limits, the operator will be alerted to the condition by a "DIAGNOSTIC" lamp that is mounted on the dashboard. Under certain conditions, the engine horsepower and the vehicle speed may be limited. A Caterpillar electronic service tool may be used to display the diagnostic code.

There are three types of diagnostic codes: active, logged, and event.

Most of the diagnostic codes are logged and stored in the ECM. For additional information, refer to the Operation and Maintenance Manual, "Engine Diagnostics" topic (Operation Section).

The ECM provides an electronic governor that controls the injector output in order to maintain the desired engine rpm. The functionality of electronic governor is similar to the Caterpillar mechanical governor, but the electronic governor includes additional features.

Engine Cooling and Lubrication

The cooling system consists of the following components:

- Centrifugal pump that is driven by belts
- Water temperature regulator which regulates the engine coolant temperature
- Oil cooler and radiator which incorporates a shunt system

The engine lubricating oil that is supplied is cooled. The engine lubricating oil is also filtered. Bypass valves provide unrestricted flow of lubrication oil to the engine components during the following conditions:

- · High oil viscosity
- Plugged oil cooler or plugged oil filter elements (paper cartridge)

Engine Service Life

Engine efficiency and maximum utilization of engine performance depend on the adherence to proper operation and maintenance recommendations. In addition, use recommended fuels, coolants and lubricants. Use the Operation and Maintenance Manual as a guide for required engine maintenance.

Expected engine life is generally predicted by the average power that is demanded. The average power that is demanded is based on fuel consumption of the engine over a period of time. Reduced hours of operation at full throttle and/or operating at reduced throttle settings result in a lower average power demand. Reduced hours of operation will increase the length of operating time before an engine overhaul is required. For more information, refer to the Operation and Maintenance Manual, "Overhaul Considerations" topic (Maintenance Section).

Aftermarket Products and Caterpillar Engines

NOTICE

In order to maximize fuel system life and prevent premature wear out from abrasive particles in the fuel, a two micron absolute high efficiency fuel filter is required for all Caterpillar Electronic Unit Injectors. Caterpillar High Efficiency Fuel Filters meet these requirements. Consult your Caterpillar dealer for the proper part numbers.

When auxiliary devices, accessories, or consumables (filters, additives, catalysts, etc) which are made by other manufacturers are used on Caterpillar products, the Caterpillar warranty is not affected simply because of such use.

However, failures that result from the installation or use of other manufacturers' devices, accessories, or consumables are NOT Caterpillar defects. Therefore, the defects are NOT covered under the Caterpillar warranty.

Welding and Caterpillar Electronic Engines

NOTICE

Because the strength of the frame may decrease, some manufacturers do not recommend welding onto a chassis frame or rail. Consult the OEM of the equipment or your Caterpillar dealer regarding welding on a chassis frame or rail.

To help avoid damage to the electronic controls, proper welding procedures are necessary. Before welding on an engine that is equipped with an electronic engine, observe the following precautions:

- Turn off the engine. Place the key start switch in the OFF position.
- If the machine has a battery disconnect switch, open the switch. Otherwise, disconnect the negative "-" battery cable from the battery of the vehicle.

NOTICE

Do not ground the welder to electrical components such as the ECM or sensors. Improper grounding can cause damage to the drive train bearings, hydraulic components, electrical components, and other components.

Clamp the ground cable from the welder to the component that will be welded. Place the clamp as close as possible to the weld. This will help reduce the possibility of damage.

- Clamp the ground cable from the welder to the component that will be welded. Place the clamp as close as possible to the weld.
- **4.** Protect wiring harnesses from welding debris and spatter. Use proper welding procedures.

Product Identification Information

i02240570

Plate Locations and Film Locations

SMCS Code: 1000

S/N: JSC1-Up **S/N:** MBD1-Up





Illustration 18 g01129459

(1) Serial Number Plate



Caterpillar engines are identified by serial numbers and by arrangement numbers. These numbers are	Top Engine Limit (TEL) at 100 percent load (If Applicable)					
shown on the engine serial number plate and on the engine information plate. Caterpillar dealers need	Torque Limit					
these numbers in order to determine the components that were included with the engine. This permits	High Idle (If Applicable)					
accurate identification of replacement part numbers.	Low Idle					
Serial Number Plate (1)	Intermediate Speed					
The engine serial number plate is located on the upper right side of the engine block.	Engine Monitoring Mode					
Engine serial number	• "OFF"					
Engine model	"Warning"					
Arrangement number	"Warning/Derate"					
-	"Warning/Derate/Shutdown"					
Information Plate (2)	"Coolant Level Sensor Enable/Disable"					
The engine information plate is located on the valve cover base near the front of the left side of the engine.	"Fuel Pressure Sensor Enable/Disable"					
Engine Serial Number	"Inlet Manifold Air Temperature Sensor Enable/Disable"					
Engine Arrangement Number						
Engine Modification Number	Equipment ID					
The engine identification plate also contains other	Maintenance Indicator					
•	Maintenance IndicatorManual-Hours					
The engine identification plate also contains other						
The engine identification plate also contains other important information about the engine.	Manual-Hours					
The engine identification plate also contains other important information about the engine.	Manual-HoursAuto-Hours					
The engine identification plate also contains other important information about the engine. i02238153 Customer Specified	 Manual-Hours Auto-Hours Manual-Fuel					
The engine identification plate also contains other important information about the engine. i02238153 Customer Specified Parameters SMCS Code: 1000 To record programmed specifications, use the	 Manual-Hours Auto-Hours Manual-Fuel Auto-Fuel					
The engine identification plate also contains other important information about the engine. 102238153 Customer Specified Parameters SMCS Code: 1000 To record programmed specifications, use the following blanks.	 Manual-Hours Auto-Hours Manual-Fuel Auto-Fuel Auxiliary Pressure 					
The engine identification plate also contains other important information about the engine. 102238153 Customer Specified Parameters SMCS Code: 1000 To record programmed specifications, use the following blanks. Customer Passwords	 Manual-Hours Auto-Hours Manual-Fuel Auto-Fuel Auxiliary Pressure High Warning Set Point					
The engine identification plate also contains other important information about the engine. Customer Specified Parameters SMCS Code: 1000 To record programmed specifications, use the following blanks. Customer Passwords • First Password	 Manual-Hours Auto-Hours Manual-Fuel Auto-Fuel Auxiliary Pressure High Warning Set Point					
The engine identification plate also contains other important information about the engine. Customer Specified Parameters SMCS Code: 1000 To record programmed specifications, use the following blanks. Customer Passwords • First Password • Second Password	 Manual-Hours Auto-Hours Manual-Fuel Auto-Fuel Auxiliary Pressure High Warning Set Point					
The engine identification plate also contains other important information about the engine. Customer Specified Parameters SMCS Code: 1000 To record programmed specifications, use the following blanks. Customer Passwords • First Password • Second Password Power Rating (hp at rpm)	 Manual-Hours Auto-Hours Manual-Fuel Auto-Fuel Auxiliary Pressure High Warning Set Point					
The engine identification plate also contains other important information about the engine. Customer Specified Parameters SMCS Code: 1000 To record programmed specifications, use the following blanks. Customer Passwords • First Password • Second Password	 Manual-Hours Auto-Hours Manual-Fuel Auto-Fuel Auxiliary Pressure High Warning Set Point					

Engine Parameters

PTO Engine Speed Ramp Rate _____ rpm/sec

Operation Section

Lifting and Storage

i02108082

Product Lifting

SMCS Code: 1000; 1404; 7002




Illustration 20 g00103219

NOTICE

Never bend the eyebolts and the brackets. Only load the eyebolts and the brackets under tension. Remember that the capacity of an eyebolt is less as the angle between the supporting members and the object becomes less than 90 degrees.

When it is necessary to remove a component at an angle, only use a link bracket that is properly rated for the weight.

Use a hoist to remove heavy components. Use an adjustable lifting beam to lift the engine. All supporting members (chains and cables) should be parallel to each other. The chains and cables should be perpendicular to the top of the object that is being lifted.

Some removals require lifting the fixtures in order to obtain proper balance and safety.

To remove the engine ONLY, use the lifting eyes that are on the engine.

Lifting eyes are designed and installed for the specific engine arrangement. Alterations to the lifting eyes and/or the engine make the lifting eyes and the lifting fixtures obsolete. If alterations are made, ensure that proper lifting devices are provided. Consult your Caterpillar dealer for information regarding fixtures for proper engine lifting.

i02126500

Product Storage

SMCS Code: 1000; 1404; 7002

If the engine will not be started for several weeks, the lubricating oil will drain from the cylinder walls and from the piston rings. Rust can form on the cylinder liner surface. Rust on the cylinder liner surface will cause increased engine wear and a reduction in engine service life.

To help prevent excessive engine wear, use the following guidelines:

- Complete all of the lubrication recommendations that are listed in this Operation and Maintenance Manual, "Maintenance Interval Schedule" (Maintenance Section).
- If freezing temperatures are expected, check the cooling system for adequate protection against freezing. See this Operation and Maintenance Manual, "Refill Capacities and Recommendations" (Maintenance Section).

If an engine is out of operation and if use of the engine is not planned, special precautions should be made. If the engine will be stored for more than one month, a complete protection procedure is recommended.

For more detailed information on engine storage, see Special Instruction, SEHS9031, "Storage Procedure For Caterpillar Products".

Your Caterpillar dealer can assist in preparing the engine for extended storage periods.

Gauges and Indicators

i01465281

Gauges and Indicators

SMCS Code: 1900; 7450

Your engine may not have the same gauges or all of the gauges that are described. For more information about the gauge package, see the literature that is provided by the OEM.

Gauges provide indications of engine performance. Ensure that the gauges are in good working order. Determine the normal operating range by observing the gauges over a period of time.

Noticeable changes in gauge readings indicate potential gauge or engine problems. Problems may also be indicated by gauge readings that change even if the readings are within specifications. Determine the cause of any significant change in the readings. Then, correct any cause of any significant change in the readings. Consult your Caterpillar dealer for assistance.

Caterpillar requires one lamp in addition to the gauge package that is normally provided. The "Diagnostic" lamp is yellow or amber. The "Diagnostic" lamp will communicate the status of the engine's electronic system. The optional red "Warning" lamp is also available. This red "Warning" lamp warns the operator of engine problems.

The following conditions are some examples of the engine problems:

- Low oil pressure
- High coolant temperature
- · Low coolant level
- High inlet air temperature

Engine Oil Pressure - Typical oil pressure for an engine at rated speed with SAE 10W30 or with SAE 15W40 is 240 to 480 kPa (35 to 70 psi).

A lower oil pressure is normal at low idle. If the load is stable and the gauge reading changes, perform the following procedure:

- 1. Remove the load.
- 2. Reduce engine speed to low idle.

3. Check the oil level. Maintain the oil level at the proper amount.

If the gauge continues to fluctuate, consult your Caterpillar dealer.

The diagnostic lamp will turn on if the oil pressure drops below 35 kPa (5 psi) at low idle rpm. The diagnostic code will be logged in the Engine Control Module (ECM).



Engine Oil Temperature - This gauge indicates the engine oil temperature. An oil temperature that is higher than normal indicates a heat problem in the lubrication system and/or the cooling system. This problem can damage the cylinder heads, the cylinder liners, the pistons, and the crankshaft bearings.

Jacket Water Coolant Temperature -Typical temperature range is 88 to 102 °C (190 to 215 °F). The maximum allowable temperature with the pressurized cooling system is 105 °C (220 °F). Higher temperatures may occur under certain conditions. The water temperature reading may vary according to load. The reading should never exceed the boiling point for the pressurized system that is being used.

If the engine is operating above the normal range or steam becomes apparent, perform the following procedure:

- 1. Reduce the load and the engine rpm.
- **2.** Inspect the cooling system for leaks.
- **3.** Determine if the engine must be shut down immediately or if the engine can be cooled by reducing the load.

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

Check the coolant level.



Tachometer – This gauge indicates engine speed. When the throttle control lever is moved to the full throttle position without

load, the engine is running at high idle. The engine is running at the full load rpm when the throttle control lever is at the full throttle position with maximum rated load.

Note: The default high idle rpm and the full load rpm are stamped on the Information Plate.

Ammeter – This gauge indicates the amount of charge or of discharge in the battery charging circuit. Operation of the indicator should be to the right side of "0"(zero).

Service Hour Meter – This gauge indicates the total number of clock hours of engine operation. Hours of operation are logged in the ECM. A service tool is needed to retrieve the hours from the ECM. A Service Hour Meter may be installed on the engine.


Fuel Pressure – This gauge indicates fuel pressure to the electronic unit injectors from the fuel filter. The indicator should indicate the "NORMAL" range. A decrease in fuel pressure usually indicates a plugged fuel filter.

Fuel Level – This gauge indicates the level of fuel in the fuel tank. The fuel level gauge registers the fuel level only when the ignition switch is in the ON position.

i02238470

Engine Monitoring System (EMS)

SMCS Code: 7490



(3) Quad gauge

The Caterpillar Engine Monitoring System (EMS) is an option. The engine parameters are displayed in both digital display and analog. The EMS display is for electronically controlled engines.

The EMS includes three individual gauge units. The units can be installed in various combinations. The main unit must be used if any of the units are used.

For information on installation and troubleshooting, refer to Installation Guide, REHS0871.

EMS Main Unit




Illustration 22

g00595165

- (4) Engine oil pressure
- (5) Engine coolant temperature
- (6) Fuel pressure
- (7) Inlet manifold temperature
- (8) Fuel temperature
- (9) Engine coolant level
- (10) Battery voltage
- (11) Active engine derate
- (12) Auxiliary temperature
- (13) Auxiliary pressure

The Engine Monitoring System provides warning lamps. Refer to Illustration 22. The Engine Monitoring System provides a LCD display for engine parameters. When the scroll switch is depressed, the parameters will scroll on the screen. The EMS displays the real time value for the parameter that is selected. The default is engine speed.

The parameters are abbreviated on the LCD display. Table 2 lists the parameters.

Table 2

Abbreviation	Parameter
Spd	Engine Speed
GA-1	Engine Oil Pressure
GA-2	Coolant Temperature
GA-3	Battery Voltage
GA-4	Fuel Pressure
Boost	Boost Pressure
IAirT	Inlet Air Temperature
FuelT	Fuel Temperature
AccrP	Auxiliary Pressure
AccrT	Auxiliary Temperature
Fuel	Fuel Rate
Hrs	Engine Hours
Load	Percent of Engine Load (speed and derate)

Note: For detailed information on the exact parameters for your engine, refer to the Operation and Maintenance Manual, "Gauges and Indicators".

Quad Gauge Unit




Illustration 23

g00595166

- (14) Engine oil pressure
- (15) Engine coolant temperature
- (16) Battery voltage
- (17) Fuel pressure

The quad gauge unit displays the following information: engine oil pressure, engine coolant temperature, battery voltage, and fuel pressure

Note: The gauge needles may not always return to zero position when the engine is not running.

Note: For detailed information on the exact parameters for your engine, refer to the Operation and Maintenance Manual, "Gauges and Indicators".

Tachometer Unit




Illustration 24

(18) Tachometer

g00788023

The tachometer displays the engine speed (rpm) on an analog gauge.

Note: For detailed information on the exact parameters for your engine, refer to the Operation and Maintenance Manual, "Gauges and Indicators".

Communication Data Link

The EMS provides two pins that are connected to the data link. The data link is available to share data with other modules. The ECM processes engine parameters. The parameters will then be transmitted to the EMS through the data link. The EMS receives the information. The information is then displayed on various gauges.

For additional information, refer to the Troubleshooting Manual, "Cat Data Link Circuit-Test".

Features and Controls

i02238515

Sensors and Electrical Components

SMCS Code: 1900; 7400

Sensor Locations

Illustration 25 shows the typical locations of the sensors for a C-9 Industrial Engine. Specific engines may appear different from the illustration due to differences in applications.




Illustration 25

- (1) Coolant Temperature Sensor
- (2) Injection Actuation Pressure Control Valve(IAPCV)
- (3) Air Inlet Heater Relay
- (4) Turbocharger Outlet Pressure Sensor
- (5) Inlet Air Temperature Sensor
- (6) Timing Calibration Probe
- (7) Engine Service Connector J63
- (8) High Pressure Engine Oil Temperature Sensor
- (9) Primary Engine Speed/Timing Sensor
- (10) Secondary Engine Speed/Timing
- (11) Injection Actuation Pressure Sensor
- (12) Fuel Pressure Sensor
- (13) High Pressure Engine Oil Temperature Sensor
- (14) Engine Oil Pressure Sensor
- (15) ECM connector J2/P2
- (16) ECM connector J1/P1
- (17) Oil Grade Detection Plug
- (18) Atmospheric Pressure Sensor

g00779441

Failure of Sensors

All Sensors

A failure of any of the sensors may be caused by one of the following malfunctions:

- Sensor output is open.
- Sensor output is shorted to "- battery" or "+ battery".
- Measured reading of the sensor is out of the specification.

Programmable Monitoring System (PMS)

The Programmable Monitoring System determines the level of action that is taken by the Engine Control Module (ECM) in response to a condition that can damage the engine. These conditions are identified by the ECM from the signals that are produced from the following sensors.

- Inlet Air Temperature Sensor
- Engine Coolant Temperature Sensor
- · Engine Oil Pressure Sensor
- Engine Speed/Timing Sensors
- Fuel Pressure Sensor
- · Coolant Level Sensor
- · Atmospheric Pressure Sensor

Atmospheric Pressure Sensor

Atmospheric pressure sensor (18) measures barometric pressure. A signal is sent to the ECM.

Table 3

Atmospheric	Pressure Sensor
Operating pressure range	0 to 116 kPa (0 to 16.8 psi)

Turbocharger Outlet Pressure Sensor

Turbocharger outlet pressure sensor (4) provides a signal which corresponds to turbocharger outlet pressure to the ECM. The air/fuel ratio control utilizes the actual engine speed and the turbocharger outlet pressure in order to control the transient smoke level. The ECM can control injection timing and the amount of fuel that is injected. When the throttle is increased and when the engine demands more fuel, the fuel limit is controlled in order to reduce overall smoke levels of the engine exhaust.

Failure of the Turbocharger Outlet Pressure Sensor

The ECM will detect failure of the turbocharger outlet pressure sensor. The operator will be warned of the problem through the diagnostic lamp. The strategies that are related to the boost will be disabled. Engine power will be severely reduced in the event of a failure of the turbocharger outlet pressure sensor. A failure of the turbocharger outlet pressure sensor will not cause a shutdown of the engine.

Coolant Temperature Sensor

Coolant temperature sensor (1) monitors engine coolant temperature. The output of the ECM can indicate a high coolant temperature through a relay or a lamp. The coolant temperature sensor is used by the ECM to determine initiation of the Cold Start Condition.

Table 4

Coolant Temperature Sensor				
Activation temperature for the high coolant temperature fault	107°C (225°F)			
Activation temperature for the very high coolant temperature fault	106°C (223°F)			

Failure of the Coolant Temperature Sensor

The ECM will detect a failure of the coolant temperature sensor. The diagnostic lamp will warn the operator about the status of the coolant temperature sensor. A failure of the coolant temperature sensor will not cause a shutdown of the engine or any horsepower change.

Engine Oil Pressure Sensor

Engine oil pressure sensor (14) is an absolute pressure sensor that measures the engine oil pressure in the main oil gallery. The engine oil pressure sensor detects engine oil pressure for diagnostic purposes. The engine oil pressure sensor sends a signal to the ECM.

Table 5

Engine Oil Pressure Sensor					
Operating pressure range	0 to 690 kPa (0 to 100 psi)				

Low Oil Pressure Warning

The setpoint is dependent upon the engine speed. The fault will be active and logged only if the engine has been running for more than 15 seconds.

Very Low Oil Pressure Warning

The very low oil pressure setpoint is dependent upon the engine speed. If the DERATE mode of the engine monitoring system is selected, the ECM will derate the engine power. The engine horsepower will be limited.

Failure of the Engine Oil Pressure Sensor

The ECM will detect failure of the engine oil pressure sensor. The diagnostic lamp warns the user about the status of the engine oil pressure sensor. The engine oil pressure related strategies will be disabled in the event of a failure of the engine oil pressure sensor. A failure of the engine oil pressure sensor will not cause a shutdown of the engine or any horsepower change.

Engine Oil Temperature Sensor

Engine oil temperature sensor (8) monitors the temperature of the engine oil. The ECM uses the information from the engine oil temperature sensor in order to adjust the timing of the fuel injection and the pressure of the fuel injection.

Table 6

Engine Oil Te	emperature Sensor
Operating temperature range	-40 to 120°C (-40 to 258°F)

Crankshaft Position Sensor and Camshaft Position Sensor

If the ECM does not receive a signal from crankshaft position sensor (10), the "DIAGNOSTIC" lamp will indicate a diagnostic fault code which will be logged in the ECM memory.

If the ECM does not receive a signal from the primary speed/timing sensor, the ECM will read the signal from the secondary speed/timing sensor. The ECM continually checks in order to determine if there is a signal from both sensors. If either sensor fails, the faulty sensor should be replaced.

Intermittent failure of the sensors will cause erratic engine control.

Injection Actuation Pressure Sensor

Injection actuation pressure sensor (2) provides a signal of the injection actuation pressure to the ECM. The ECM modifies the current to the injection actuation pressure control valve (not shown) in order to control the injection actuation pressure. The desired actuation pressure is based on the following engine parameters: quantity of fuel, injection timing, engine speed, and engine operating mode.

Inlet Air Temperature Sensor

Inlet air temperature sensor (5) measures the inlet air temperature. A signal is sent to the Electronic Control Module (ECM). The inlet air temperature sensor is also used by the ECM to determine initiation of the Cold Start Strategy.

Table 7

Inlet Air Ten	nperature Sensor
Operating temperature range	-40 to 120°C (-40 to 258°F)

Throttle Position Sensor

The Throttle Position Sensor (TPS) sends a signal to the ECM. The signal from the TPS is required in order to govern engine speed. The throttle position sensor signal is used by the ECM in order to calculate the desired engine speed. The TPS is calibrated during the initial installation of the engine.

Note: The throttle position sensor is not shown in the illustration.

Failure of the Throttle Position Sensor

An intermittent failure in the TPS causes the engine speed to vary erratically. The ECM will perform the following process:

- The ECM will detect the failure of the TPS.
- The ECM will warn the operator of the failure through the diagnostic lamp.
- The ECM will set the desired engine speed to low idle

Engine Diagnostics

i01463253

Diagnostic Lamp

SMCS Code: 1000; 1900; 1901; 1902; 7451

The "DIAGNOSTIC" lamp is used to indicate the existence of an active fault by flashing codes.

When the ignition switch is first turned on, the "DIAGNOSTIC" lamp will go through the following procedure:

- The "DIAGNOSTIC" lamp will come on and the "DIAGNOSTIC" lamp will remain on for five seconds. This checks the operation of the lamp.
- The "DIAGNOSTIC" lamp will turn off.
- The "DIAGNOSTIC" lamp will come on again and the "DIAGNOSTIC" lamp will flash codes for any active diagnostic codes. Not all diagnostic codes have a unique flash code.
- The "DIAGNOSTIC" lamp will turn off for five seconds.
- The "DIAGNOSTIC" lamp repeats all active diagnostic codes.

A fault diagnostic code will remain active until the problem is repaired. The electronic control module will continue flashing the flash code at five second intervals until the problem is repaired.

i02238548

Diagnostic Flash Code Retrieval

SMCS Code: 1000; 1900; 1901; 1902

"Diagnostic" Lamp

Use the "DIAGNOSTIC" Lamp or Caterpillar Electronic Technician (ET) in order to determine the diagnostic flash code.

Use the following procedure to retrieve the diagnostic codes if the engine is equipped with a "DIAGNOSTIC" lamp:

 Turn the ignition key to the ON position. The engine does not need to be started in order to view codes. The engine does not need to be running while the ignition switch is in the ON position. The "DIAGNOSTIC" lamp blinks on and off at five second intervals.

 When the ignition key is in the ON position, the lamp is checked for proper operation. If there are any active codes except for Code 34, the codes are displayed at this time.

Note: The "DIAGNOSTIC" lamp will illuminate for five seconds. The lamp will stay on if there is an active diagnostic code.

- The Active Diagnostic codes will always be flashed. There is no toggle switch that will shut off the lamp.
- 3. The "DIAGNOSTIC" lamp will flash in order to indicate a two-digit code. The sequence of flashes represents the system diagnostic message. Each digit of the two-digit code is determined by counting the number of flashes. The lamp flashes at a rate of two times per second. The lamp will pause for one second between digits. The lamp will pause for two seconds between codes.

Table 8 indicates the potential effect on the engine performance with active flash codes. Table 8 also forms a list of Electronic diagnostic codes and descriptions.

Table 8

		Effect On Engine Performance				Suggested Action by the Operator		
	Diagnostic Flash Code		Low Power	Reduced Engine Speed	Engine Shut Down	Shut down the Engine ⁽¹⁾	Service ⁽²⁾	Schedule Service for the Engine. ⁽³⁾
15	Open or Short Circuit of Injection Actuation Pressure Sensor		Х			Х		
17	High Injection Actuation Pressure					Х	Х	
18	Open or Short for the Injection Actuation Pressure Control Valve				Х		х	
21	Sensor Supply Voltage Above Normal or Below Normal ⁽⁴⁾		X					X
24	Oil Pressure Sensor Fault (4)							Х
25	Inlet Manifold Air Pressure Sensor Fault ⁽⁵⁾							Х
26	Atmospheric Pressure Sensor Fault ⁽⁴⁾		Х					Х
27	Coolant Temperature Sensor Fault ⁽⁴⁾		Х	Х				Х
28	Check the Adjustments for the Throttle Position Sensor.		Х	Х				Х
34	Loss Of Engine RPM Signal			Х	Х		Х	
35	Event for Engine Overspeed				Х			Х
37	Fuel Pressure Sensor Fault(4)							X
38	Inlet Manifold Air Temperature Sensor Fault ⁽⁴⁾		Х	Х				Х
39	Mechanical Failure of the Injection Actuation Pressure Sensor		Х				х	
42	Check the Calibration of the Timing Sensor.	Х	Х	Х		Х		Х
46	Low Oil Pressure Event				Х	Х	Х	
51	Intermittent Battery Power to the ECM	Х	Х		Х	Х	Х	
52	Personality Module Fault	Х	Х	Х	Х		Х	
56	The following parameters must be checked: Customer and System		Х	Х				Х
59	Incorrect Engine Software	Х	Х	Х				Х
61	Event for High Coolant Temperature		Х		Х	Х	х	
62	Event for Low Coolant Level		Х		Х	Х	Х	
63	Low Fuel Pressure Event		Х	Х		Х	Х	

(continued)

(Table 8, contd)

	Diagnostic Flash Codes for C-9 Industrial Engine							
		Effect On Engine Performance				Suggested Action by the Operator		
	Diagnostic Flash Code		Low Power	Reduced Engine Speed	Engine Shut Down	Shut down the Engine ⁽¹⁾	Service ⁽²⁾	Schedule Service for the Engine. ⁽³⁾
64	Even for High Inlet Manifold Air Temperature		Х		Х			Х
72	Fault of Cylinder 1 or Cylinder 2	Х	Х				Х	
73	Fault of Cylinder 3 or Cylinder 4	Х	Х				Х	
74	Fault of Cylinder 5 or Cylinder 6	Х	Х				Х	

- (1) Shut down the Engine: Operate the engine cautiously. Get immediate service. Severe engine damage may result.
- (2) The operator should go to the nearest location for service.
- (3) The operator should investigate the problem at a convenient time.
- (4) The Diagnostic Flash Codes reduce the effectiveness of the Engine Monitoring feature.
- (5) These Diagnostic Flash Codes may affect the system only under specific environmental conditions such as engine start-up at cold temperatures, etc.

i01463504

i01563981

Fault Logging

SMCS Code: 1000; 1900; 1901; 1902

The system provides the capability of Fault Logging. When the Electronic Control Module (ECM) generates an active diagnostic code, the code will be logged in the memory of the ECM. The codes that have been logged in the memory of the ECM can be retrieved with Caterpillar electronic service tools. The codes that have been logged can be cleared with Caterpillar electronic service tools. The codes that have been logged in the memory of the ECM will be automatically cleared from the memory after 100 hours. The following faults can not be cleared from the memory of the ECM without using a factory password: overspeed, low engine oil pressure, and high engine coolant temperature.

Engine Operation with Active Diagnostic Codes

SMCS Code: 1000; 1900; 1901; 1902

If the diagnostic lamp starts to flash codes during normal engine operation, the system has identified a situation that is not within the specification. Use Caterpillar electronic service tools to check the active diagnostic codes.

Note: If the customer has selected "DERATE" and if there is a low oil pressure condition, the Electronic Control Module (ECM) will limit the engine power until the problem is corrected. If the oil pressure is within the normal range, the engine may be operated at the rated speed and load. However, maintenance should be performed as soon as possible. Refer to Operation and Maintenance Manual, "Diagnostic Flash Code Retrieval" for more information on flash codes.

The active diagnostic code should be investigated. The cause of the problem should be corrected as soon as possible. If the cause of the active diagnostic code is repaired and there is only one active diagnostic code, the diagnostic lamp will turn off.

Operation of the engine and performance of the engine can be limited as a result of the active diagnostic code that is generated. Acceleration rates may be significantly slower. Refer to the Operation and Maintenance Manual for more information on the relationship between these active diagnostic codes and engine performance.

i01456915

Engine Operation with Intermittent Diagnostic Codes

SMCS Code: 1000; 1900; 1901; 1902

If the diagnostic lamp starts to flash codes during normal engine operation and the diagnostic lamp shuts off, an intermittent fault may have occurred. If a fault has occurred, the fault will be logged into the memory of the Electronic Control Module (ECM).

In most cases, it is not necessary to stop the engine because of an intermittent code. However, the operator should retrieve the logged fault codes and the operator should reference the appropriate information in order to identify the nature of the event. The operator should log any observation that could have caused the lamp to light.

- · Low power
- · Limits of the engine speed
- · Excessive smoke, etc

This information can be useful to help troubleshoot the situation. The information can also be used for future reference. For more information on diagnostic codes, refer to the Troubleshooting Guide for this engine. i02239577

Customer Specified Parameters

SMCS Code: 1000; 1900; 1901; 1902

Customer specified parameters that will enhance the fuel efficiency and the operator's convenience can be programmed into the Electronic Control Module (ECM). Some parameters may affect engine operation. This may lead to complaints from the operator about power or about performance. The following engine related parameters may be programmed by the customer by using Caterpillar electronic service tools in order to influence the operation of the engine:

- Customer Passwords
- Power Rating (hp at rpm)
- Rating Selection (A-E)
- PTO Ramp Rate
- Engine Parameters: Low Idle, High Idle, Top Engine Limit, Torque Limit, and Intermediate Speed
- Engine Monitoring Mode
- Equipment ID
- Maintenance Indicator
- Auxiliary Pressure
- Auxiliary Temperature
- · Parameter Lock Out

The customer specified parameters can be changed as often as needed. Password protection is provided so that the customer can change the parameters. The customer can authorize someone else to change the parameters. Ensure that a record of the parameters is kept in the Operation and Maintenance Manual. For detailed instructions on programming the engine for optimum performance and for optimum fuel economy, consult your Caterpillar dealer.

Engine Starting

i01486758

Before Starting Engine

SMCS Code: 1000; 1400; 1450

Perform the required daily maintenance and other periodic maintenance before the engine is started. Inspect the engine compartment. This inspection can help prevent major repairs at a later date. Refer to the Operation and Maintenance Manual, "Maintenance Interval Schedule" for more information.

- For the maximum service life of the engine, make a thorough inspection before the engine is started. Look for the following items: oil leaks, coolant leaks, loose bolts, and trash buildup. Remove trash buildup and arrange for repairs, as needed.
- Inspect the cooling system hoses for cracks and for loose clamps.
- Inspect the alternator and accessory drive belts for cracks, breaks, and other damage.
- Inspect the wiring for loose connections and for worn wires or frayed wires.
- Check the fuel supply. Drain water from the water separator (if equipped). Open the fuel supply valve.

NOTICE

All valves in the fuel return line must be open before and during engine operation to help prevent high fuel pressure. High fuel pressure may cause filter housing failure or other damage.

If the engine has not been started for several weeks, fuel may have drained from the fuel system. Air may have entered the filter housing. Also, when fuel filters have been changed, some air pockets will be trapped in the engine. In these instances, prime the fuel system. Refer to the Operation and Maintenance Manual, "Fuel System - Prime" for more information on priming the fuel system.

WARNING

Engine exhaust contains products of combustion which may be harmful to your health. Always start and operate the engine in a well ventilated area and, if in an enclosed area, vent the exhaust to the outside.

- Do not start the engine or move any of the controls if there is a "DO NOT OPERATE" warning tag or similar warning tag attached to the start switch or to the controls.
- Ensure that the areas around the rotating parts are clear.
- All of the guards must be put in place. Check for damaged guards or for missing guards. Repair any damaged guards. Replace damaged guards and/or missing guards.
- Disconnect any battery chargers that are not protected against the high current drain that is created when the electric starting motor (if equipped) is engaged. Check electrical cables and check the battery for poor connections and for corrosion.
- Reset all of the shutoffs or alarm components.
- Check the engine lubrication oil level. Maintain the oil level between the "ADD" mark and the "FULL" mark on the oil level gauge.
- Check the coolant level. Observe the coolant level in the coolant recovery tank (if equipped). Maintain the coolant level to the "FULL" mark on the coolant recovery tank.
- If the engine is not equipped with a coolant recovery tank maintain the coolant level within 13 mm (0.5 inch) of the bottom of the filler pipe. If the engine is equipped with a sight glass, maintain the coolant level in the sight glass.
- Observe the air cleaner service indicator (if equipped). Service the air cleaner when the yellow diaphragm enters the red zone, or when the red piston locks in the visible position.
- Ensure that any driven equipment has been disengaged. Minimize electrical loads or remove any electrical loads.

i02239598

Starting the Engine

SMCS Code: 1000; 1450

WARNING

Engine exhaust contains products of combustion which may be harmful to your health. Always start and operate the engine in a well ventilated area and, if in an enclosed area, vent the exhaust to the outside.

Initial Inspection

Perform the required daily maintenance and other periodic maintenance before you start the engine. Inspect the engine compartment. This inspection can help prevent major repairs at a later date. Refer to the Operation and Maintenance Manual, "Walk-Around Inspection" topic (Maintenance Section) for more information.

- For the maximum service life of the engine, make a thorough inspection before you start the engine. Look for the following items: oil leaks, coolant leaks, loose bolts, and trash buildup. Remove trash buildup and arrange for repairs, as needed.
- Inspect the cooling system hoses for cracks and for loose clamps.
- Inspect the alternator and accessory drive belts for cracks, breaks, and other damage.
- Inspect the wiring for loose connections and for worn wires or frayed wires.
- Check the fuel supply. Drain water from the water separator (if equipped). Open the fuel supply valve.

NOTICE

All valves in the fuel return line must be open before and during engine operation to help prevent high fuel pressure. High fuel pressure may cause filter housing failure or other damage.

- Do not start the engine or do not move any of the controls if there is a "DO NOT OPERATE" warning tag or similar warning tag attached to the start switch or to the controls.
- Ensure that the areas around the rotating parts are clear.
- All of the guards must be put in place. Check for damaged guards or for missing guards. Repair any damaged guards. Replace damaged guards and/or missing guards.
- Disconnect any battery chargers that are not protected against the high current drain that is created when the electric starting motor (if equipped) is engaged. Check electrical cables and check the battery for poor connections and for corrosion.
- Reset all of the shutoffs or alarm components.
- Check the engine lubrication oil level. Maintain the oil level between the "ADD" mark and the "FULL" mark on the oil level gauge.

- Check the coolant level. Observe the coolant level in the coolant recovery tank (if equipped). Maintain the coolant level to the "FULL" mark on the coolant recovery tank.
- If the engine is not equipped with a coolant recovery tank maintain the coolant level within 13 mm (.5 inch) of the bottom of the filler pipe. If the engine is equipped with a sight glass, maintain the coolant level in the sight glass.
- Observe the air cleaner service indicator (if equipped). Service the air cleaner when the yellow diaphragm enters the red zone, or when the red piston locks in the visible position.
- Ensure that any driven equipment has been disengaged. Remove any electrical loads.

Cold Weather Starting

Starting the engine and operation in cold weather is dependent on the type of fuel that is used, the oil viscosity, and other optional starting aids. For more information, refer to the Operation and Maintenance Manual, "Cold Weather Operation" topic (Operation Section).

Air Inlet Heater

WARNING

DO NOT USE ETHER (starting fluids) unless specifically instructed to do so. If the engine is equipped with an Air Inlet Heater (electrically or fuel ignited manifold heater), DO NOT use ether (starting fluids) at any time. The use could result in engine damage and/or personal injury.

Note: There will be an indicator lamp on the control panel that is marked "AIR INLET HEATER".

For detailed information on the operation of the Air Inlet Heater, refer to Troubleshooting Manual, "Air Inlet Heater Circuit - Test".

Refer to the Owner's Manual of the OEM for your type of controls. Use the following procedure to start the engine.

- Place the transmission in NEUTRAL. Disengage the flywheel clutch in order to allow the engine to start faster. This also reduces the draining of the battery.
- **2.** Turn the ignition switch to the ON position.

The "WARNING and DIAGNOSTIC" lamp (if equipped) will flash while the engine is cranking. The lamp should turn off after proper engine oil pressure is achieved. If the lamp fails to flash, notify your authorized Caterpillar dealer. If the lamp continues to flash, the Electronic Control Module (ECM) has detected a problem in the system. For more information, refer to the Operation and Maintenance Manual, "Diagnostic Flash Code Retrival" (Operation Section).

NOTICE

Do not engage the starting motor when flywheel is turning. Do not start the engine under load.

If the engine fails to start within 30 seconds, release the starter switch or button and wait two minutes to allow the starting motor to cool before attempting to start the engine again.

Push the start button or turn the ignition switch to the START position in order to crank the engine.

Do not push down or hold the throttle down while the engine is cranked. The system will automatically provide the correct amount of fuel that is needed to start the engine.

4. If the engine fails to start within 30 seconds, release the start button, or the ignition switch. Wait for two minutes in order to allow the starting motor to cool before attempting to start the engine again.

Note: The "WARNING and DIAGNOSTIC" lamps (if equipped) may come on after the engine is started. If this occurs, the ECM has detected a problem with the system. For more information, refer to the Operation and Maintenance Manual, "Diagnostic Flash Code Retrival" (Operation Section) .

NOTICE

Oil pressure should rise within 15 seconds after the engine starts. Do not increase engine rpm until the oil pressure gauge indicates normal. If oil pressure is not indicated on the gauge within 15 seconds, DO NOT operate the engine. STOP the engine, investigate and correct the cause.

5. Allow the engine to idle for approximately three minutes. Idle the engine until the water temperature gauge has begun to rise. Check all gauges during the warm-up period.

Note: Oil pressures and fuel pressures should be in the normal range on the instrument panel. Engines that are equipped with "WARNING" lamps do not have an operating range. The "WARNING and DIAGNOSTIC" lamp (if equipped) will flash while the engine is cranking. The lamp should turn off after proper engine oil pressure or fuel pressure is achieved. Do not apply a load to the engine or increase engine rpm until the oil pressure gauge indicates at least normal pressure. Inspect the engine for leaks and/or unusual noises.

After the engine has started, the air inlet heater may continue to operate in a "Continuous" mode and/or in an "Intermittent" mode. The air inlet heater will turn OFF when the sum of the coolant temperature and the air inlet temperature exceeds 35 °C or 127 °F.

If the engine is operated with a low load, the engine will reach normal operating temperature sooner than idling the engine with no load. When the engine is idled in cold weather, increase the engine rpm to approximately 1000 to 1200 rpm. This will warm up the engine more quickly. Do not exceed the recommended rpm in order to increase the speed of the warm-up. Limit unnecessary idle time to ten minutes.

Ether Injection System

WARNING

Personal injury or property damage can result from alcohol or starting fluids.

Alcohol or starting fluids are highly flammable and toxic and if improperly stored could result in injury or property damage.

WARNING

DO NOT USE ETHER (starting fluids) unless specifically instructed to do so. If the engine is equipped with an Air Inlet Heater (electrically or fuel ignited manifold heater), DO NOT use ether (starting fluids) at any time. The use could result in engine damage and/or personal injury.

Starting Problems

An occasional starting problem may be caused by one of the following items:

- · Low battery charge
- · Lack of fuel
- · Problem with the wiring harness

If the engine fuel system has been run dry, fill the fuel tank and prime the fuel system. Refer to the Operation and Maintenance Manual, "Fuel System - Prime" topic (Maintenance Section).

If the other problems are suspected, perform the appropriate procedure in order to start the engine.

Problems with the Wiring Harness




Illustration 26

g00772964

- (1) ECM Connector J2/P2
- (2) ECM Connector J1/P1

Locate the ECM. Two harness connectors are attached to the ECM. One connector is ECM J2/P2 (1) and the other connector is ECM J1/P1. Check the connectors in order to ensure that the connectors are secure. Lightly pull each of the wires in the chassis harness.

- Pull each wire with approximately 4.5 kg (10 lb) of force. The wire should remain in the connector.
- 2. If a wire is loose, push the wire back into the connector. Pull the wire again in order to ensure that the wire is secure.
- Start the engine. If the engine does not start, consult the nearest Caterpillar dealer for assistance.

i02097945

Starting with Jump Start Cables

SMCS Code: 1000; 1401; 1402; 1900

WARNING

Improper jump start cable connections can cause an explosion resulting in personal injury.

Prevent sparks near the batteries. Sparks could cause vapors to explode. Do not allow jump start cable ends to contact each other or the engine.

If the installation is not equipped with a backup battery system, it may be necessary to start the engine from an external electrical source.

Many batteries which are considered unusable are still rechargeable. After jump starting, the alternator may not be able to fully recharge batteries that are severely discharged. The batteries must be charged to the proper voltage with a battery charger. For information on testing and charging, refer to the Special Instruction, SEHS7633, "Battery Test Procedure".

NOTICE

Using a battery source with the same voltage as the electric starting motor. Use ONLY equal voltage for jump starting. The use of higher voltage will damage the electrical system.

Do not reverse the battery cables. The alternator can be damaged. Attach ground cable last and remove first.

When using an external electrical source to start the engine, turn the engine control switch to the "OFF" position. Turn all electrical accessories OFF before attaching the jump start cables.

Ensure that the main power switch is in the OFF position before attaching the jump start cables to the engine being started.

- 1. Turn the start switch on the stalled engine to the OFF position. Turn off all accessories.
- Connect one positive end of the jump start cable to the positive cable terminal of the discharged battery. Connect the other positive end of the jump start cable to the positive cable terminal of the electrical source.

- 3. Connect one negative end of the jump start cable to the negative cable terminal of the electrical source. Connect the other negative end of the jump start cable to the engine block or to the chassis ground. This procedure helps to prevent potential sparks from igniting combustible gases that are produced by some batteries.
- Charge the batteries. The engine will not continue to run after starting if the batteries have not been charged.
- 5. Start the engine.
- Immediately after the stalled engine is started, disconnect the jump start cables in reverse order.

Refer to the Electrical Schematic for your engine. Consult your Caterpillar dealer for more information.

i01646248

After Starting Engine

SMCS Code: 1000

Note: In temperatures from 0 to 60°C (32 to 140°F), the warm-up time is approximately three minutes. In temperatures below 0°C (32°F), additional warm-up time may be required.

Note: Ensure that the self test for the monitoring system (if equipped) is completed before operating the engine under load.

When the engine idles during warm-up, observe the following conditions:

- Check for any fluid or for any air leaks at idle rpm and at one-half full rpm (no load on the engine) before operating the engine under load. This is not possible in some applications.
- Operate the engine at low idle until all systems achieve operating temperatures. Check all gauges during the warm-up period.

Note: Gauge readings should be observed and the data should be recorded frequently while the engine is operating. Comparing the data over time will help to determine normal readings for each gauge. Comparing data over time will also help detect abnormal operating developments. Significant changes in the readings should be investigated.

Engine Operation

i00718869

Engine Operation

SMCS Code: 1000

Proper operation and maintenance are key factors in obtaining the maximum life and economy of the engine. If the directions in the Operation and Maintenance Manual are followed, costs can be minimized and engine service life can be maximized.

The time that is needed for the engine to reach normal operating temperature can be less than the time needed for a walk-around inspection of the engine.

After the engine is started and after the engine reaches normal operating temperature, the engine can be operated at the rated rpm. The engine will reach normal operating temperature faster when the engine is at rated speed. The engine will reach normal operating temperature faster when the engine is at low power demand. This procedure is more effective than idling the engine at no load. The engine should reach operating temperature in a few minutes.

Gauge readings should be observed and the data should be recorded frequently while the engine is operating. Comparing the data over time will help to determine normal readings for each gauge. Comparing data over time will also help detect abnormal operating developments. Significant changes in the readings should be investigated.

Engaging the Driven Equipment

SMCS Code: 1000

- 1. Operate the engine at one-half of the rated rpm, when possible.
- **2.** Engage the driven equipment without a load on the equipment, when possible.

Interrupted starts put excessive stress on the drive train. Interrupted starts also waste fuel. To get the driven equipment in motion, engage the clutch smoothly with no load on the equipment. This method should produce a start that is smooth and easy. The engine rpm should not increase and the clutch should not slip.

- **3.** Ensure that the ranges of the gauges are normal when the engine is operating at one-half of the rated rpm. Ensure that all gauges operate properly.
- **4.** Increase the engine rpm to the rated rpm. Always increase the engine rpm to the rated rpm before the load is applied.
- **5.** Apply the load. Begin operating the engine at low load. Check the gauges and equipment for proper operation. After normal oil pressure is reached and the temperature gauge begins to move, the engine may be operated at full load. Check the gauges and equipment frequently when the engine is operated under load.

Extended operation at low idle or at reduced load may cause increased oil consumption and carbon buildup in the cylinders. This carbon buildup results in a loss of power and/or poor performance.

Engine Stopping

i01428739

Stopping the Engine

SMCS Code: 1000; 7000

NOTICE

Stopping the engine immediately after it has been working under load can result in overheating and accelerated wear of the engine components.

If the engine has been operating at high rpm and/or high loads, run at low idle for at least three minutes to reduce and stabilize internal engine temperature before stopping the engine.

Avoiding hot engine shutdowns will maximize turbocharger shaft and bearing life.

Prior to stopping an engine that is being operated at low loads, operate the engine at low idle for 30 seconds before stopping. If the engine has been operating at highway speeds and/or at high loads. operate the engine at low idle for at least three minutes. This procedure will cause the internal engine temperature to be reduced and stabilized.

Ensure that the engine stopping procedure is understood. Stop the engine according to the shutoff system on the engine or refer to the instructions that are provided by the OEM.

 To stop the engine, turn the ignition key switch to the OFF position.

i02170043

Emergency Stopping

SMCS Code: 1000; 7418

NOTICE

Emergency shutoff controls are for EMERGENCY use ONLY. DO NOT use emergency shutoff devices or controls for normal stopping procedure.

Ensure that any system that provides external support to the engine is secured after the engine is stopped.

NOTICE

Do not start the engine until the problem necessitating the emergency stop has been located and corrected.

Pressing the Emergency Stop Button may cause unburned gas to remain in the air inlet and in the exhaust manifold.

WARNING

Unburned gas in the air inlet and exhaust system may ignite when the engine is started. Personal injury and/or property damage may result.

Before starting an engine that may contain unburned gas, purge the unburned gas from the air inlet and exhaust system. Refer to the topic on purging unburned gas in the "Starting the Engine" section.

Emergency Stop Button



Illustration 27

Typical emergency stop button

g00104303

For the junction box, the emergency stop button is in the OUT position for normal engine operation. For an emergency stop, push the emergency stop button. The button must be reset before the engine can be started.

To reset the button, turn the button clockwise. The spring-loaded button will return to the OUT position.

Manual Stop Procedure

SMCS Code: 1000

Note: Individual applications will have different control systems. Ensure that the shutoff procedures are understood. Use the following general guidelines in order to stop the engine.

- **1.** Remove the load, when possible. Reduce the engine speed (rpm) to low idle.
- 2. Increase the engine speed (rpm) to no more than one-half of the rated rpm. Perform this procedure for three to five minutes in order to cool the engine. Reduce the engine speed (rpm) to low idle.
- **3.** After the cool down period, turn the key switch to the OFF position.

i01465494

After Stopping Engine

SMCS Code: 1000

Note: Before you check the engine oil, do not operate the engine for at least 10 minutes in order to allow the engine oil to return to the oil pan.

- Check the crankcase oil level. Maintain the oil level between the "ADD" mark and the "FULL" mark on the oil level gauge.
- If necessary, perform minor adjustments. Repair any leaks and tighten any loose bolts.
- Note the service hour meter reading. Perform the maintenance that is in the Operation and Maintenance Manual, "Maintenance Interval Schedule".
- Fill the fuel tank in order to help prevent accumulation of moisture in the fuel. Do not overfill the fuel tank.

NOTICE

Only use antifreeze/coolant mixtures recommended in the Coolant Specifications that are in the Operation and Maintenance Manual. Failure to do so can cause engine damage.

- Allow the engine to cool. Check the coolant level.
- If freezing temperatures are expected, check the coolant for proper antifreeze protection. The cooling system must be protected against freezing to the lowest expected outside temperature. Add the proper coolant/water mixture, if necessary.
- Perform all required periodic maintenance on all driven equipment. This maintenance is outlined in the instructions from the OEM.

Cold Weather Operation

i01457051

Radiator Restrictions

SMCS Code: 1353; 1396

Caterpillar discourages the use of airflow restriction devices that are mounted in front of radiators. Airflow restriction can cause the following conditions:

- · High exhaust temperatures
- Power loss
- · Excessive fan usage
- · Reduction in fuel economy

If an airflow restriction device must be used, the device should have a permanent opening directly in line with the fan hub. The device must have a minimum opening dimension of at least 770 cm² (120 in²).

A centered opening that is directly in line with the fan hub is specified in order to prevent an interrupted airflow on the fan blades. Interrupted airflow on the fan blades could cause a fan failure.

Caterpillar recommends a warning device for the inlet manifold temperature and/or the installation of an inlet air temperature gauge. The warning device for the inlet manifold temperature should be set at 75 °C (167 °F). The inlet manifold air temperature should not exceed 75 °C (167 °F). Temperatures that exceed this limit can cause power loss and potential engine damage.

i02237624

Fuel and the Effect from Cold Weather

SMCS Code: 1000; 1250

The following fuels are the grades that are available for Caterpillar engines:

- No. 1
- No. 2
- Blend of No. 1 and No. 2

No. 2 diesel fuel is the most commonly used fuel. Either No. 1 diesel fuel or a blend of No. 1 and No. 2 is best suited for cold weather operation. Quantities of No. 1 diesel fuel are limited. No. 1 diesel fuels are usually available during the months of the winter in the colder climates. During cold weather operation, if No. 1 diesel fuel is not available, use No. 2 diesel fuel, if necessary.

There are three major differences between No. 1 and No. 2 diesel fuel. No. 1 diesel fuel has the following properties:

- · Lower cloud point
- · Lower pour point
- Lower rating of kJ (BTU) per unit volume of fuel

When No. 1 diesel fuel is used, a decrease in power and in fuel efficiency may be noticed. Other operating effects should not be experienced.

The cloud point is the temperature when a cloud of wax crystals begins to form in the fuel. These crystals can cause the fuel filters to plug. The pour point is the temperature when diesel fuel will thicken. The diesel fuel becomes more resistant to flow through fuel pumps and through fuel lines.

Be aware of these values when diesel fuel is purchased. Anticipate the average ambient temperature of the area. Engines that are fueled in one climate may not operate well if the engines are moved to another climate. Problems can result due to changes in temperature.

Before troubleshooting for low power or for poor performance in the winter, check the type of fuel that is being used.

When No. 2 diesel fuel is used the following components provide a means of minimizing problems in cold weather:

- · Starting aids
- Engine oil pan heaters
- · Engine coolant heaters
- · Fuel heaters
- · Fuel line insulation

For more information on cold weather operation, see Special Publication, SEBU5898, "Cold Weather Recommendations".

Fuel Related Components in Cold Weather

SMCS Code: 1000; 1250

Fuel Tanks

Condensation can form in partially filled fuel tanks. Top off the fuel tanks after operating the engine.

Fuel tanks should contain some provision for draining water and sediment from the bottom of the tanks. Some fuel tanks use supply pipes that allow water and sediment to settle below the end of the fuel supply pipe.

Some fuel tanks use supply lines that take fuel directly from the bottom of the tank. If the engine is equipped with this system, regular maintenance of the fuel system filter is important.

Drain the water and sediment from any fuel storage tank at the following intervals:

- · Weekly
- Oil changes
- · Refueling of the fuel tank

This will help prevent water and/or sediment from being pumped from the fuel storage tank and into the engine fuel tank.

Fuel Filters

NOTICE

Do not fill the fuel filters with fuel before installing them. The fuel would not be filtered and could be contaminated. Contaminated fuel will cause accelerated wear to fuel system parts.

NOTICE

In order to maximize fuel system life and prevent premature wear out from abrasive particles in the fuel, a two micron absolute high efficiency fuel filter is required for all Caterpillar Hydraulic Electronic Unit Injectors. Caterpillar High Efficiency Fuel Filters meet these requirements. Consult your Caterpillar dealer for the proper part numbers. These engines are equipped with a primary filter/water separator. The primary filter/water separator must use a 10 micron filter to a 15 micron filter. The filters are becoming more critical as fuel injection pressures increase to 209 MPa (30000 psi) and higher psi. For more information on priming the fuel system, see the Operation and Maintenance Manual, "Fuel System - Prime" topic (Maintenance Section).

Fuel Heaters

Fuel heaters help to prevent fuel filters from plugging in cold weather due to waxing. A fuel heater should be installed in order for the fuel to be heated before the fuel enters the primary fuel filter.

Select a fuel heater that is mechanically simple, yet adequate for the application. The fuel heater should also help to prevent overheating of the fuel. High fuel temperatures reduce engine performance and the availability of engine power. Choose a fuel heater with a large heating surface. The fuel heater should be practical in size. Small heaters can be too hot due to the limited surface area.

Disconnect the fuel heater in warm weather.

Note: Fuel heaters that are controlled by the water temperature regulator or self-regulating fuel heaters should be used with this engine. Fuel heaters that are not controlled by the water temperature regulator can heat the fuel in excess of 65° C (149° F). A loss of engine power can occur if the fuel supply temperature exceeds 37° C (100° F).

Note: Heat exchanger type fuel heaters should have a bypass provision in order to prevent overheating of the fuel in warm weather operation.

For further information on fuel heaters, consult your Caterpillar dealer.

Maintenance Section

Refill Capacities

i02138186

Refill Capacities and Recommendations

SMCS Code: 1348; 1395; 7560

Engine Oil

API Oils

The Engine Oil Licensing and Certification System by the American Petroleum Institute (API) is recognized by Caterpillar. For detailed information about this system, see the latest edition of the "API publication No. 1509". Engine oils that bear the API symbol are authorized by API.




Illustration 28

Typical API symbol

Diesel engine oils CC, CD, CD-2, and CE have not been API authorized classifications since 1 January 1996. Table 9 summarizes the status of the classifications.

Table 9

API Classifications		
Current Obsolete		
CI-4 ⁽¹⁾ CH-4 ⁽¹⁾ , CG-4 ⁽²⁾ , CF-4 ⁽³⁾	CE	
CF (4)	CC, CD	
CF-2 ⁽⁵⁾	CD-2 ⁽⁵⁾	

- (1) API CH-4 and CI-4 oils are acceptable if the requirements of Caterpillar's ECF-1 (Engine Crankcase Fluid specification-1) are met. CH-4 and CI-4 oils that have not met the requirements of Caterpillar's ECF-1 Specification may cause reduced engine life.
- (2) API CG-4 oils are acceptable for all Caterpillar diesel engines. When the API CG-4 oils are used, the oil drain interval should not exceed 75 Percent of the standard oil drain interval for your engine.
- (3) API CF-4 oils are no longer recommended for Caterpillar on-highway diesel engines.
- (4) API CF oils are not recommended for Caterpillar on-highway diesel engines.
- (5) API CF-2 and CD-2 oils are classifications for two-cycle diesel engines. Caterpillar does not sell engines that utilize the CD-2 and the API CF-2 oils.

Cat DEO (Diesel Engine Oil)

Caterpillar Oils have been developed and tested in order to provide the full performance and service life that has been designed and built into Caterpillar Engines. Caterpillar Oils are currently used to fill diesel engines at the factory. These oils are offered by Caterpillar dealers for continued use when the engine oil is changed. Consult your Caterpillar dealer for more information on these oils.

Due to significant variations in the quality and in the performance of commercially available oils, Caterpillar makes the following recommendations:

- Cat DEO (Diesel Engine Oil) (10W-30)
- Cat DEO (Diesel Engine Oil) (15W-40)

Commercial Oils

- API CH-4 oils and API CI-4 oils are acceptable if the requirements of Caterpillar's ECF-1 (Engine Crankcase Fluid specification-1) are met. CH-4 oils and CI-4 oils that have not met the requirements of Caterpillar's ECF-1 Specification may cause reduced engine life.
- API CG-4 oils are acceptable for all Caterpillar diesel engines. When the API CG-4 oils are used, the oil drain interval should not exceed 75 Percent of the standard oil drain interval for your engine.
- API CF-4 oils are no longer recommended.

NOTICE

In selecting oil for any engine application, both the oil viscosity and oil performance classification/specification as specified by the engine manufacturer must be defined and satisfied. Using only one of these parameters will not sufficently define oil for an engine application.

In order to make the proper choice of a commercial oil, refer to the following explanations:

API CI-4 – API CI-4 oils were developed in order to meet the requirements of high performance diesel engines that use cooled Exhaust Gas Recirculation (EGR). API CI-4 oils are acceptable if the requirements of Caterpillar's ECF-1 (Engine Crankcase Fluid specification-1) are met.

API CH-4 – API CH-4 oils were developed in order to protect low emissions diesel engines that use a 0.05 percent level of fuel sulfur. However, API CH-4 oils may be used with higher sulfur fuels. API CH-4 oils are acceptable if the requirements of Caterpillar's ECF-1 (Engine Crankcase Fluid specification-1) are met.

Note: CH-4 oils and Cl-4 oils that have not met the requirements of Caterpillar's ECF-1 Specification may cause reduced engine life.

NOTICE

Failure to follow these oil recommendations can cause shortened engine service life due to deposits and/or excessive wear.

Note: Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information that relates to lubrication for your engine.

Lubricant Viscosity Recommendations

The proper SAE viscosity grade of oil is determined by the minimum ambient temperature during cold engine start-up, and the maximum ambient temperature during engine operation.

Refer to Table 10 (minimum temperature) in order to determine the required oil viscosity for starting a cold engine.

Refer to Table 10 (maximum temperature) in order to select the oil viscosity for engine operation at the highest ambient temperature that is anticipated.

Note: Generally, use the highest oil viscosity that is available to meet the requirement for the temperature at start-up.

If ambient temperature conditions at engine start-up require the use of multigrade SAE 0W oil, SAE 0W-40 viscosity grade is preferred over SAE 0W-20 or SAE 0W-30.

Note: SAE 10W-30 is the preferred viscosity grade for the following diesel engines when the ambient temperature is above -18 °C (0 °F) and below 40 °C (104 °F).

- C7
- C9
- 3116
- 3126

Table 10

Engine Oil Viscosities for Ambient Temperatures ⁽¹⁾			
	Ambient Temperature		
Viscosity Grade	Minimum Maximum		
SAE 0W-20	−40 °C (−40 °F)	10 °C (50 °F)	
SAE 0W-30	−40 °C (−40 °F)	30 °C (86 °F)	
SAE 0W-40	-40 °C (−40 °F)	40 °C (104 °F)	
SAE 5W-30	−30 °C (−22 °F)	30 °C (86 °F)	
SAE 5W-40	−30 °C (−22 °F)	50 °C (122 °F)	
SAE 10W-30 ⁽²⁾	−18 °C (0 °F)	40 °C (104 °F)	
SAE 10W-40	−18 °C (0 °F)	50 °C (122 °F)	
SAE 15W-40	−9.5 °C (15 °F)	50 °C (122 °F)	

- (1) Refer to this publication, "Engine Oil (Recommendations)" for recommendations of diesel engine oil type.
- (2) SAE 10W-30 is the preferred viscosity grade for the 3116, 3126, C7, and C9 diesel engines when the ambient temperature is above -18 °C (0 °F) and below 40 °C (104 °F).

Note: Supplemental heat is recommended below the minimum recommended ambient temperature.

S·O·S Oil Analysis

Caterpillar has developed a tool for maintenance management that evaluates oil degradation and the tool also detects the early signs of wear on internal components. The Caterpillar tool for oil analysis is called S·O·S Oil Analysis and the tool is part of the S·O·S Services program. S·O·S Oil Analysis divides oil analysis into three categories:

- · Wear Analysis
- · Oil condition
- · Additional tests

The wear analysis monitors metal particles, some oil additives, and some contaminants.

Oil condition uses infrared (IR) analysis to evaluate the chemistry of the oil. Infrared analysis is also used to detect certain types of contamination.

Additional tests are used to measure contamination levels from water, fuel, or coolant. Oil viscosity and corrosion protection can be evaluated, as needed.

Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" or contact your local Caterpillar dealer for additional information concerning the S·O·S Oil Analysis program.

Refill Capacities (Engine Oil)

The refill capacities for the engine crankcase reflect the approximate capacity of the crankcase or sump plus standard oil filters. Auxiliary oil filter systems will require additional oil. Refer to the OEM specifications for the capacity of the auxiliary oil filter.

Table 11

C-9 Industrial Engine Approximate Refill Capacities			
Refill Capacity fo Changing the Oi System and the Filter			
	Liters	Quarts	
Oil Sump ⁽¹⁾	31	33	

⁽¹⁾ These values should be inserted by the customer as approximate capacities for the crankcase oil sump which include the standard oil filters that are installed at the factory. Engines with auxiliary oil filters will require additional oil. Refer to the OEM specifications for the capacity of the auxiliary oil

Lubricating Grease

Caterpillar provides a range of moderate greases to extremely high performance greases in order to service the entire line of Caterpillar products that operate throughout the wide variety of climates. From this variety of Caterpillar grease products, you will find at least one of the Caterpillar greases that will meet the performance requirements for any machine or equipment application.

Before selecting a grease product for any application, the performance requirements must be determined. Consult the grease recommendations that are made by the OEM for the equipment when the equipment is operated in the expected conditions. Then, consult with your Caterpillar dealer for a list of greases and the following related characteristics.

- Performance specifications
- · Available sizes of containers
- Part numbers

Always choose a grease that meets the recommendations that are specified by the equipment manufacturer for the application.

If it is necessary to choose a single grease to use for all of the equipment at one site, always choose a grease that meets the requirements of the most demanding application. Products that meet the minimum performance requirements can be expected to produce minimum parts' life. Instead, use the grease that yields the lowest total operating cost. This cost is based on an analysis that includes the costs of parts, labor, and downtime. Also, include the cost of the amount of grease that is actually used.

Note: Consult your supplier in order to determine if the greases are compatible.

If the technician is in doubt, purge the grease!

Note: All Caterpillar brand name greases are compatible with each other.

Note: Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information that relates to lubrication for your engine.

Fuel

Distillate Diesel Fuel

In North America, diesel fuel that is identified as No. 1-D or No. 2-D in "ASTM D975" generally meet the specifications. Caterpillar recommends diesel fuels that are distilled from crude oil. Diesel fuels from other sources could exhibit detrimental properties that are not defined or controlled by this specification.

NOTICE

Operating with fuels that do not meet Caterpillar's recommendations can cause the following effects: starting difficulty, poor combustion, deposits in the fuel injectors, reduced service life of the fuel system, deposits in the combustion chamber, and reduced service life of the engine. **Note:** Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for the Caterpillar Specification for distillate fuel and for additional information that relates to fuel for your engine.

Refill Capacities (Fuel System)

Refer to the Operation and Maintenance Manual that is provided by the OEM for capacities of the fuel system.

Coolant

NOTICE

Do not use a commercial coolant/antifreeze that only meets the ASTM D3306 specification. This type of coolant/antifreeze is made for light duty automotive applications.

The following two coolants are used in Caterpillar diesel engines:

Preferred – Caterpillar Extended Life Coolant (ELC) or a commercial extended life coolant that meets the Caterpillar EC-1 specification

Acceptable – A Caterpillar Diesel Engine Antifreeze/Coolant (DEAC) or a commercial heavy-duty coolant/antifreeze that meets "ASTM D4985", or "ASTM D6210" specifications

Note: Caterpillar DEAC does not require a treatment with an SCA at the initial fill. A commercial heavy-duty coolant/antifreeze that meets "ASTM D4985" or "ASTM D6210" specifications MAY require a treatment with an SCA at the initial fill. These coolants WILL require a treatment with an SCA on a maintenance basis.

Table 12

Service Life Before Flushing and Before Refilling			
Coolant	Service Life(1)(2)		
Cat ELC	965,606 kilometers (600,000 miles)		
Commercial coolant that meets the Caterpillar EC-1 specification	482,803 kilometers (300,000 miles)		
Cat DEAC	321,869 kilometers (200,000 miles)		
Commercial Heavy-Duty Coolant/Antifreeze that meets "ASTM D4985" or "ASTM D6210"	241,402 kilometers (150,000 miles)		

⁽¹⁾

Glycol

Glycol in the coolant helps to provide protection against the following conditions:

- Boiling
- Freezing
- Cavitation of the water pump and cylinder liners

For optimum performance, Caterpillar recommends a 1:1 mixture of a water/glycol solution.

Note: Use a mixture that will provide protection against the lowest ambient temperature.

Note: 100 percent pure glycol will freeze at a temperature of -23 °C (-9 °F).

Refer to tables 13 and 14for additional information.

Most conventional heavy-duty coolant/antifreezes use ethylene glycol. Propylene glycol may also be used. In a 1:1 mixture with water, ethylene and propylene glycol provide similar protection against freezing and boiling. Refer to tables 13 and 14 for additional information.

Table 13

14515 15				
Ethylene Glycol				
Concentration Freeze Boil Protection				
50 Percent	-37 °C (−34 °F)	106 °C (223 °F)		
60 Percent	-51 °C (−60 °F)	111 °C (232 °F)		

⁽²⁾ Refer to the specific engine Operation and Maintenance Manual, "Maintenance Interval Schedule" for the interval for the Cooling System Water Temperature Regulator.

NOTICE

Do not use propylene glycol in concentrations that exceed 50 percent glycol because of propylene glycol's reduced heat transfer capability. Use ethylene glycol in conditions that require additional protection against boiling or freezing.

Table 14

Propylene Glycol		
Concentration Freeze Protection		Boil Protection
50 Percent	-32 °C (−26 °F)	106 °C (223 °F)

To check the concentration of glycol, use the 1U-7298 Coolant/Battery Tester (Degree Celsius) or use the 1U-7297 Coolant/Battery Tester (Degree Fahrenheit). The testers give readings that are immediate and accurate. The testers can be used with ethylene or propylene glycol.

Note: Propylene glycol coolant that is used in Caterpillar Diesel Engine cooling systems must meet "ASTM D6211-98a "Fully-Formulated Propylene Glycol-Based Engine Coolant for Heavy-Duty Engines". When Propylene glycol is used in heavy-duty diesel engines, a regular addition of Supplemental Coolant Additive (SCA) is required for protection against liner cavitation. Consult your Caterpillar dealer for more information.

S·O·S Coolant Analysis

Testing the engine coolant is important to ensure that the engine is protected from internal cavitation and from corrosion. The analysis also tests the ability of the coolant to protect the engine from boiling and from freezing. The S·O·S Coolant Analysis can be done at your Caterpillar dealer. Caterpillar S·O·S Coolant Analysis is the best way to monitor the condition of your coolant and your cooling system. S·O·S Coolant Analysis is a program that is based on periodic samples.

Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information.

Refill Capacity (Coolant System)

The total cooling system capacity will vary depending on the radiator that is provided by the vehicle manufacturer. The table for the capacity of the cooling system is blank. The customer should fill in the table.

Table 15

Approximate Capacity of the Cooling System				
Compartment Liters Quarts				
Total Cooling System ⁽¹⁾				

(1) The total cooling system capacity includes the following components:the engine block, the radiator, and all coolant hoses and lines.

Note: Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information that relates to coolant for your engine.

i02282041	Fuel Tank Water and Sediment - Drain
Maintenance Interval Schedule	Radiator - Clean 83
SMCS Code: 1000; 7500	PM Level 1 - Every 20 800 L (5500 US gal) of
When Required	Fuel or 500 Service Hours or 6 Months
Battery - Replace	Air Compressor Filter - Clean/Replace
Engine Storage Procedure - Check	Engine Oil Sample - Obtain
Daily	Radiator - Clean
Air Tank Moisture and Sediment - Drain	PM Level 2 - Every 83 250 L (22 000 US gal) of Fuel or 2000 Service Hours or 1 Year
Engine Air Cleaner Service Indicator - Inspect 68 Engine Oil Level - Check	Aftercooler Core - Inspect
Fuel System Primary Filter/Water Separator -	Alternator - Inspect
Drain	Engine Valve Lash - Inspect/Adjust
Fuel System Primary Filter (Water Separator) Element - Replace	Engine Valve Rotators - Inspect
Power Take-Off Clutch - Check/Adjust/Lubricate 83	DM 0 Fire at 400 F00 (44 000 H0)
Walk-Around Inspection	PM Level 3 - Every 166 500 L (44 000 US gal) of Fuel or 4000 Service Hours or 2 Years
Initial 20 to 40 Service Hours	Aftercooler Core - Clean/Test 52
Belts - Inspect/Adjust 57	Air Compressor - Inspect 53
Beits - Inspect/Adjust	Belt Tensioner - Inspect
Every Week	Cooling System Coolant (DEAC) - Change 58 Cooling System Coolant Extender (ELC) - Add 61
Battery Charger - Check	Cooling System Water Temperature Regulator - Replace
Initial 500 Service Hours	Crankshaft Vibration Damper - Inspect
Engine Valve Lash - Inspect/Adjust	Engine Mounts - Inspect 69
Every 6000 Service Hours or 6 Years	Every 208 000 L (55 000 US gal) of Fuel or 5000 Service Hours
Cooling System Coolant (ELC) - Change 60	Starting Motor - Inspect84
	Turbocharger - Inspect 85
Every 10 000 Service Hours	Water Pump - Inspect 86
Cylinder Head Grounding Stud - Inspect/Clean/ Tighten 64	Every 340 000 L (90 000 US gal) of Fuel or 10 000 Service Hours
PM Level 1 - Every 10 400 L (2750 US gal) of Fuel or 250 Service Hours or 6 Months	Cylinder Head Grounding Stud - Inspect/Clean/ Tighten 64 Overhaul Considerations
Air Compressor Filter - Clean/Replace 53 Battery Electrolyte Level - Check 56 Cooling System Supplemental Coolant Additive (SCA) - Test/Add 62 Engine Oil Sample - Obtain 70 Engine Oil and Filter - Change 70 Fan Drive Bearing - Lubricate 74 Fuel System Secondary Filter - Replace 77	Overridai Considerations

Aftercooler Core - Clean/Test

SMCS Code: 1064-070; 1064-081

- **1.** Remove the core. Refer to the Service Manual for the procedure.
- Turn the aftercooler core upside-down in order to remove debris.

NOTICE

Do not use a high concentration of caustic cleaner to clean the core. A high concentration of caustic cleaner can attack the internal metals of the core and cause leakage. Only use the recommended concentration of cleaner.

3. Back flush the core with cleaner.

Caterpillar recommends the use of Hydrosolv liquid cleaner. Table 16 lists Hydrosolv liquid cleaners that are available from your Caterpillar dealer.

Table 16

Hydrosolv Liquid Cleaners(1)				
Part Description Size				
1U-5490	Hydrosolv 4165	19 L (5 US gallon)		
174-6854	Hydrosolv 100	19 L (5 US gallon)		

- (1) Use a two to five percent concentration of the cleaner at temperatures up to 93°C (200°F). Refer to Application Guide, NEHS0526 or consult your Caterpillar dealer for more information.
- **4.** Steam clean the core in order to remove any residue. Flush the fins of the aftercooler core. Remove any other trapped debris.
- **5.** Wash the core with hot, soapy water. Rinse the core thoroughly with clean water.

A WARNING

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

Maximum air pressure at the nozzle must be less than 205 kPa (30 psi) for cleaning purposes.

6. Dry the core with compressed air. Direct the air in the reverse direction of the normal flow.

- 7. Inspect the core in order to ensure cleanliness. Pressure test the core. Many shops that service radiators are equipped to perform pressure tests. If necessary, repair the core.
- **8.** Install the core. Refer to the Service Manual for the procedure.

For more information on cleaning the core, consult your Caterpillar dealer.

i01468985

Aftercooler Core - Inspect

SMCS Code: 1064-040

Note: Adjust the frequency of cleaning according to the effects of the operating environment.

Inspect the aftercooler for these items: damaged fins, corrosion, dirt, grease, insects, leaves, oil, and other debris. Clean the aftercooler, if necessary.

For air-to-air aftercoolers, use the same methods that are used for cleaning radiators.

WARNING

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

Maximum air pressure at the nozzle must be less than 205 kPa (30 psi) for cleaning purposes.

Pressurized air is the preferred method for removing loose debris. Direct the air in the opposite direction of the fan's air flow. Hold the nozzle approximately 6 mm (.25 inch) away from the fins. Slowly move the air nozzle in a direction that is parallel with the tubes. This will remove debris that is between the tubes.

Pressurized water may also be used for cleaning. The maximum water pressure for cleaning purposes must be less than 275 kPa (40 psi). Use pressurized water in order to soften mud. Clean the core from both sides.

Use a degreaser and steam for removal of oil and grease. Clean both sides of the core. Wash the core with detergent and hot water. Thoroughly rinse the core with clean water.

After cleaning, start the engine and accelerate the engine to high idle rpm. This will help in the removal of debris and drying of the core. Stop the engine. Use a light bulb behind the core in order to inspect the core for cleanliness. Repeat the cleaning, if necessary.

Inspect the fins for damage. Bent fins may be opened with a "comb".

Note: If parts of the aftercooler system are repaired or replaced, a leak test is highly recommended. The FT1984 Aftercooler Testing Group is used to perform leak tests on the aftercooler. Refer to the Systems Operation/Testing and Adjusting, "Aftercooler - Test" and the Special Instruction, SEHS8622 for the proper testing procedure.

Inspect these items for good condition: welds, mounting brackets, air lines, connections, clamps, and seals. Make repairs, if necessary.

For more detailed information on cleaning and inspection, see Special Publication, SEBD0518, "Know Your Cooling System".

i02113479

Air Compressor - Inspect

SMCS Code: 1803-040

WARNING

Do not disconnect the air line from the air compressor governor without purging the air brake and the auxiliary air systems. Failure to purge the air brake and the auxiliary air systems before removing the air compressor and/or the air lines could cause personal injury.




Illustration 29

g01076630

(1) Pressure relief valve

MARNING

If the air compressor pressure relief valve that is mounted in the air compressor cylinder head is bypassing compressed air, there is a malfunction in the air system, possibly ice blockage. Under these conditions, your engine may have insufficient air for normal brake operation.

Do not operate the engine until the reason for the air bypass is identified and corrected. Failure to heed this warning could lead to property damage, personal injury, or death to the operator or bystanders.

The function of the pressure relief valve is to bypass air when there is a malfunction in the air compressor system.

The pressure relief valve releases air at 1723 kPa (250 psi). Do not stand near the pressure relief valve. Compressed air may be released without warning. All personnel should also stay clear of the air compressor when the engine is operating and the air compressor is exposed.

Refer to the Service Manual or refer to the OEM specifications in order to find information concerning the air compressor. Consult your Caterpillar dealer for assistance.

i01544231

Air Compressor Filter - Clean/Replace (If Equipped)

SMCS Code: 1803-070-FQ; 1803-510-FQ

One of the single most important aspects of preventive maintenance for the air compressor is the induction of clean air. The type of maintenance that is required for the air compressor and the maintenance interval depends on the type of air induction system that is used. Operating conditions (dust, dirt and debris) may require more frequent service.

Refer to the Service Manual for the type of air compressor that is installed on the engine. Follow the maintenance recommendations that are provided by the OEM of the air compressor. Some engines use boost air pressure so the engine air cleaner will require servicing.

Air Tank Moisture and Sediment - Drain (If Equipped)

SMCS Code: 1466-543-M&S

Moisture and sediment in the air starting system can cause the following conditions:

- Freezing
- · Corrosion of internal parts
- · Malfunction of the air starting system

A WARNING

When opening the drain valve, wear protective gloves, a protective face shield, protective clothing, and protective shoes. Pressurized air could cause debris to be blown and result in personal injury.

- Open the drain valve that is on the bottom of the air tank. Allow the moisture and sediment to drain.
- 2. Close the drain valve.
- 3. Check the air supply pressure. The air starting motor requires a minimum of 620 kPa (90 psi) of air pressure to operate properly. The maximum air pressure must not exceed 1550 kPa (225 psi). The normal air pressure will be 758 to 965 kPa (110 to 140 psi).

i00072207

Alternator - Inspect

SMCS Code: 1405-040

Caterpillar recommends a scheduled inspection of the alternator. Inspect the alternator for loose connections and proper battery charging. Inspect the ammeter (if equipped) during engine operation in order to ensure proper battery performance and/or proper performance of the electrical system. Make repairs, as required. Refer to the Service Manual.

Check the alternator and the battery charger for proper operation. If the batteries are properly charged, the ammeter reading should be very near zero. All batteries should be kept charged. The batteries should be kept warm because temperature affects the cranking power. If the battery is too cold, the battery will not crank the engine. The battery will not crank the engine is warm. When the engine is not run for long periods of time or if the engine is run for short periods, the batteries may not fully charge. A battery with a low charge will freeze more easily than a battery with a full charge.

i02153996

Battery - Replace

SMCS Code: 1401-510

A WARNING

Batteries give off combustible gases which can explode. A spark can cause the combustible gases to ignite. This can result in severe personal injury or death.

Ensure proper ventilation for batteries that are in an enclosure. Follow the proper procedures in order to help prevent electrical arcs and/or sparks near batteries. Do not smoke when batteries are serviced.

WARNING

The battery cables or the batteries should not be removed with the battery cover in place. The battery cover should be removed before any servicing is attempted.

Removing the battery cables or the batteries with the cover in place may cause a battery explosion resulting in personal injury.

- **1.** Turn the key start switch to the OFF position. Remove the key and all electrical loads.
- **2.** Turn OFF the battery charger. Disconnect the charger.
- 3. The NEGATIVE "-" cable connects the NEGATIVE "-" battery terminal to the ground plane. Disconnect the cable from the NEGATIVE "-" battery terminal.
- **4.** The POSITIVE "+" cable connects the POSITIVE "+" battery terminal to the starting motor. Disconnect the cable from the POSITIVE "+" battery terminal.

Note: Always recycle a battery. Never discard a battery. Return used batteries to an appropriate recycling facility.

- 5. Remove the used battery.
- 6. Install the new battery.

Note: Before the cables are connected, ensure that the key start switch is OFF.

- Connect the cable from the starting motor to the POSITIVE "+" battery terminal.
- **8.** Connect the cable from the ground plane to the NEGATIVE "-" battery terminal.

i01039758

Battery Charger - Check

SMCS Code: 1401-535

Checking Before Start-Up

Check the battery charger for proper operation. If the batteries are properly charged, the needle of the ammeter will register near "0" (zero).

The battery charger must not produce excessive current during start-up. Alternatively, the charger must be automatically disconnected for start-up. If the engine has an alternator, the charger must be automatically disconnected during start-up and during engine operation.

Charging the Battery

WARNING

Never disconnect any charging unit circuit or battery circuit cable from the battery when the charging unit is operated. A spark can cause an explosion from the flammable vapor mixture of hydrogen and oxygen that is released from the electrolyte through the battery outlets. Injury to personnel can be the result.

Perform the following procedure to charge the battery:

- 1. Ensure that the charger is turned OFF.
- **2.** Adjust the voltage of the charger in order to match the voltage of the battery.

- Connect the POSITIVE "+" lead of the charger to the POSITIVE "+" battery terminal. Connect the NEGATIVE "-" lead of the charger to the NEGATIVE "-" battery terminal.
- 4. Turn ON the battery charger.

Overcharging of Batteries

Overcharging reduces the service life of batteries. Use a battery charger that will not overcharge the battery. DO NOT charge the battery if the meter of the battery charger is in the RED zone.

Overcharging is indicated by the following symptoms:

- The battery is very warm to the touch.
- A strong odor of acid is present.
- The battery emits smoke or a dense vapor (gas).

Perform one of the following procedures if the battery shows symptoms of overcharging:

- Reduce the rate of charging by a significant amount. Complete the charging at the reduced rate.
- Turn OFF the charger.

Table 17 describes the effects of overcharging on different types of batteries.

Table 17

Effects of Overcharging Batteries			
Type of Battery	Effect		
Caterpillar General Service Batteries Caterpillar Premium High Output Batteries	All of the battery cells have a low level of electrolyte.		
	When the plates of the battery are inspected through the filler holes, the plates may appear to be warped. This is caused by an excessive temperature.		
	The battery may not pass a load test.		
Caterpillar Maintenance Free Batteries	The battery may not accept a charging current.		
	The battery may not pass a load test.		

Checking After Stopping

Ensure that the battery charger is connected properly. Observe the meter of the charger. Record the amperage.

i02213936

Battery Electrolyte Level - Check

SMCS Code: 1401-535

When the engine is not run for long periods of time or when the engine is run for short periods, the batteries may not fully recharge. Ensure a full charge in order to help prevent the battery from freezing. If batteries are properly charged, ammeter reading should be very near zero.

WARNING

All lead-acid batteries contain sulfuric acid which can burn the skin and clothing. Always wear a face shield and protective clothing when working on or near batteries.

1. Remove the filler caps. Maintain the electrolyte level to the "FULL" mark on the battery.

If the addition of water is necessary, use distilled water. If distilled water is not available use clean water that is low in minerals. Do not use artificially softened water.

- 2. Check the condition of the electrolyte with the 245-5829 Coolant Battery Tester Refractometer.
- 3. Keep the batteries clean.

Clean the battery case with one of the following cleaning solutions:

- A mixture of 0.1 kg (0.2 lb) of baking soda and 1 L (1 qt) of clean water
- A mixture of 0.1 L (0.11 qt) of ammonia and 1 L (1 qt) of clean water

Thoroughly rinse the battery case with clean water.

Use a fine grade of sandpaper to clean the terminals and the cable clamps. Clean the items until the surfaces are bright or shiny. DO NOT remove material excessively. Excessive removal of material can cause the clamps to not fit properly. Coat the clamps and the terminals with 5N-5561 Silicone Lubricant, petroleum jelly or MPGM.

i01492654

Battery or Battery Cable - Disconnect

SMCS Code: 1402-029

WARNING

The battery cables or the batteries should not be removed with the battery cover in place. The battery cover should be removed before any servicing is attempted.

Removing the battery cables or the batteries with the cover in place may cause a battery explosion resulting in personal injury.

- Turn the start switch to the OFF position. Turn the ignition switch (if equipped) to the OFF position and remove the key and all electrical loads.
- 2. Disconnect the negative battery terminal at the battery that goes to the start switch. Ensure that the cable cannot contact the terminal. When four 12 volt batteries are involved, the negative side of two batteries must be disconnected.
- **3.** Tape the leads in order to help prevent accidental starting.
- Proceed with necessary system repairs. Reverse the steps in order to reconnect all of the cables.

i01555583

Belt Tensioner - Inspect (If Equipped)

SMCS Code: 1358-040




Illustration 30 Belt tensioner g00426964

Inspect the belt tensioner for unusual noise, excessive looseness and/or shaking of the bearings.

If the belt tensioner should require disassembly, refer to the Service Manual for the procedure.

i02169621

Belts - Inspect/Adjust

SMCS Code: 1357-025; 1357-040

Inspection

Belt tension should be checked initially between the first 20 to 40 hours of engine operation.

After the initial check, the belt tension should be checked at every oil change.

To maximize the engine performance, inspect the belts for wear and for cracking. Replace belts that are worn or damaged.

For applications that require multiple drive belts, replace the belts in matched sets. Replacing only one belt of a matched set will cause the new belt to carry more load because the older belt is stretched. The additional load on the new belt could cause the new belt to break.

If the belts are too loose, vibration causes unnecessary wear on the belts and pulleys. Loose belts may slip enough to cause overheating.

If the belts are too tight, unnecessary stresses are placed on the pulley bearings and on the belts. This may shorten the service life of the components.


Remove the belt guard, if equipped. Inspect the condition and adjustment of the alternator belts and accessory drive belts (if equipped).

To check the belt tension, apply 110 N (25 lb ft) of force midway between the pulleys. A correctly adjusted belt will deflect 9 mm (0.35 inch) to 15 mm (0.59 inch).

If the belt does not require replacement or adjustment, install the belt guard. If the belt requires adjustment or replacement, perform the following procedure to adjust the belt tension.

Adjustment

Alternator Belt



(1) Nut

Illustration 31

(2) Adjusting Nut

(3) Bolt

(4) Nut

- **1.** Slightly loosen mounting bolt (3) and nut (4).
- 2. Loosen nut (1).
- **3.** Tighten adjusting bolt (2) and mounting bolts (3) and (4). Tighten bolt (1). Refer to the Specifications Manual, SENR3130, "Torque Specifications".

If new belts are installed, check the belt tension again after 30 minutes of engine operation at the rated rpm.

g00768640

Water Pump Belt




Illustration 32

g00426869

Typical example

Exploded view of the drive assembly for a water pump belt

- (1) Mounting bolt
- (2) Square hole
- (3) Adjusting bolt
- Slightly loosen mounting bolt (1) and adjusting bolt (3).
- 2. Adjust the belt tension with a square drive in square hole (2).
- Tighten adjusting bolt (3) and mounting bolt (1). Refer to the Specifications Manual, SENR3130, "Torque Specifications".
- 4. Install the belt guard, if equipped.

If new belts are installed, check the belt tension after 30 minutes of engine operation at the rated rpm.

i02139869

Cooling System Coolant (DEAC) - Change

SMCS Code: 1350-070; 1395-044

Clean the cooling system and flush the cooling system before the recommended maintenance interval if the following conditions exist:

- · The engine overheats frequently.
- · Foaming is observed.
- The oil has entered the cooling system and the coolant is contaminated.
- The fuel has entered the cooling system and the coolant is contaminated.

NOTICE

Use of commercially available cooling system cleaners may cause damage to cooling system components. Use only cooling system cleaners that are approved for Caterpillar engines.

Note: Inspect the water pump and the water temperature regulator after the cooling system has been drained. This is a good opportunity to replace the water pump, the water temperature regulator and the hoses, if necessary.

Drain

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

- Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap.
- **2.** Open the cooling system drain valve (if equipped). If the cooling system is not equipped with a drain valve, remove one of the drain plugs.

Note: If equipped, be sure to drain the heater and any related supply and return lines.

Allow the coolant to drain.

NOTICE

Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method acceptable by Caterpillar to reclaim the used coolant.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Caterpillar Dealer Service Tool Group:

Outside Illinois: 1-800-542-TOOL Inside Illinois: 1-800-541-TOOL Canada: 1-800-523-TOOL

Flush

 Flush the cooling system with clean water in order to remove any debris. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

- Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add 0.5 L (1 pint) of cleaner per 15 L (4 US gal) of the cooling system capacity. Install the cooling system filler cap.
- Start and run the engine at low idle for a minimum of 30 minutes. The coolant temperature should be at least 82 °C (180 °F).

NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap. Open the drain valve (if equipped) or remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. If equipped, be sure to flush the heater and any related supply and return lines. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

Cooling Systems with Heavy Deposits or Plugging

Note: For the following procedure to be effective, there must be some active flow through the cooling system components.

1. Flush the cooling system with clean water in order to remove any debris.

Note: If equipped, be sure to flush the heater and any related supply and return lines.

 Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

- 3. Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add 0.5 L (1 pint) of cleaner per 3.8 to 7.6 L (1 to 2 US gal) of the cooling system capacity. Install the cooling system filler cap.
- Start and run the engine at low idle for a minimum of 90 minutes. The coolant temperature should be at least 82 °C (180 °F).

NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap. Open the drain valve (if equipped) or remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

Fill

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

 Fill the cooling system with coolant/antifreeze. Refer to the Operation and Maintenance Manual, "Refill Capacitites and Recommendations" topic (Maintenance Section) for more information on cooling system specifications. Do not install the cooling system filler cap.

- Start and run the engine at low idle. Increase the engine rpm to 1500 rpm. Run the engine at high idle for one minute in order to purge the air from the cavities of the engine block. Stop the engine.
- 3. Check the coolant level. Maintain the coolant level within 13 mm (0.5 inch) below the bottom of the pipe for filling. Maintain the coolant level within 13 mm (0.5 inch) to the proper level on the sight glass (if equipped).
- 4. Clean the cooling system filler cap. Inspect the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is damaged, discard the old cooling system filler cap and install a new cooling system filler cap and install a new cooling system filler cap is not damaged, perform a pressure test. A 9S-8140 Pressurizing Pump is used to perform the pressure test. The correct pressure for the cooling system filler cap is stamped on the face of the cooling system filler cap. If the cooling system filler cap does not retain the correct pressure, install a new cooling system filler cap.
- **5.** Start the engine. Inspect the cooling system for leaks and for proper operating temperature.

Cooling System Coolant (ELC) - Change

SMCS Code: 1350-070; 1395-044

Clean the cooling system and flush the cooling system before the recommended maintenance interval if the following conditions exist:

- The engine overheats frequently.
- · Foaming is observed.
- The oil has entered the cooling system and the coolant is contaminated.
- The fuel has entered the cooling system and the coolant is contaminated.

Note: When the cooling system is cleaned, only clean water is needed when the ELC is drained and replaced.

Note: Inspect the water pump and the water temperature regulator after the cooling system has been drained. This is a good opportunity to replace the water pump, the water temperature regulator and the hoses, if necessary.

Drain

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

- Stop the engine and allow the engine to cool.
 Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap.
- 2. Open the cooling system drain valve (if equipped). If the cooling system is not equipped with a drain valve, remove the cooling system drain plugs.

Allow the coolant to drain.

NOTICE

Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method acceptable by Caterpillar to reclaim the used coolant.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Caterpillar Dealer Service Tool Group:

Outside Illinois: 1-800-542-TOOL Inside Illinois: 1-800-541-TOOL Canada: 1-800-523-TOOL

Flush

 Flush the cooling system with clean water in order to remove any debris.

Note: If equipped, be sure to flush the heater and any related supply and return lines.

2. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. For the proper torque, refer to the Specifications Manual, SENR3130, "Torque Specifications".

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

3. Fill the cooling system with clean water. Install the cooling system filler cap.

- Start and run the engine at low idle until the temperature reaches 49 to 66 °C (120 to 150 °F).
- 5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap. Open the drain valve (if equipped) or remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. For the proper torque, refer to the Specifications Manual, SENR3130, "Torque Specifications".

Fill

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

- Fill the cooling system with Extended Life Coolant (ELC). See Special Publication, SEBU6385, "Caterpillar On-highway Diesel Truck Engine Fluids Recommendations" for more information on cooling system specifications. Do not install the cooling system filler cap.
- 2. Start and run the engine at low idle. Increase the engine rpm to high idle. Run the engine at high idle for one minute in order to purge the air from the cavities of the engine block. Stop the engine.
- 3. Check the coolant level. Maintain the coolant level within 13 mm (0.5 inch) below the bottom of the pipe for filling. Maintain the coolant level within 13 mm (0.5 inch) to the proper level on the sight glass (if equipped).
- 4. Clean the cooling system filler cap. Inspect the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is damaged, discard the old cooling system filler cap and install a new cooling system filler cap. If the gasket that is on the cooling system filler cap is not damaged, use a 9S-8140 Pressurizing Pump in order to pressure test the cooling system filler cap. The correct pressure for the cooling system filler cap is stamped on the face of the cooling system filler cap. If the cooling system filler cap does not retain the correct pressure, install a new cooling system filler cap.
- **5.** Start the engine. Inspect the cooling system for leaks and for proper operating temperature.

i02106346

Cooling System Coolant Extender (ELC) - Add

SMCS Code: 1352-045; 1395-081

Caterpillar Extended Life Coolant (ELC) does not require the frequent Supplemental Coolant Additive (SCA) additions which are associated with the present conventional coolants. The Extender only needs to be added once.

Check the cooling system only when the engine is stopped and cool.


- Loosen the cooling system filler cap slowly in order to relieve pressure. Remove the cooling system filler cap.
- **2.** It may be necessary to drain enough coolant from the cooling system in order to add the Extender.
- 3. Add Extender according to the requirements for your engine's cooling system capacity. Refer to the Operation and Maintenance Manual, "Refill Capacities and Recommendations" in the Maintenance Section for more information concerning the Caterpillar ELC Extender additions.
- 4. Clean the cooling system filler cap. Inspect the gaskets on the cooling system filler cap. Replace the cooling system filler cap if the gaskets are damaged. Install the cooling system filler cap.

i01197583

Cooling System Coolant Level - Check

SMCS Code: 1395-082

Check the coolant level when the engine is stopped and cool.



SMCS Code: 1352-045; 1395-081

WARNING

Cooling system coolant additive contains alkali. To help prevent personal injury, avoid contact with the skin and eyes. Do not drink cooling system coolant additive.

Note: Caterpillar recommends an S·O·S coolant analysis (Level 1).

Test the Concentration of the SCA

Coolant/Antifreeze and SCA

NOTICE

Do not exceed the recommended six percent supplemental coolant additive concentration.

Test the concentration of the SCA with the 8T-5296 Coolant Conditioner Test Kit. Follow the instructions that are provided in the kit.

Water and SCA

NOTICE

Do not exceed the recommended eight percent supplemental coolant additive concentration.

Test the concentration of the SCA with the 8T-5296 Coolant Conditioner Test Kit. Use the instructions that follow:

- Fill the syringe to the "1.0 ml" mark with the coolant.
- **2.** Dispense the 1.0 mL coolant sample from the syringe into the empty mixing bottle.
- 3. Add tap water to the mixing bottle in order to bring the level up to the "10 ml" mark. Place the cap on the bottle and shake the bottle.
- **4.** Add 2 to 3 drops of the "NITRITE INDICATOR SOLUTION B" to the mixing bottle. Move the bottle in a circular motion in order to mix the solution.
- **5.** Add 1 drop of "NITRITE TEST SOLUTION A" to the mixing bottle. Move the bottle in a circular motion in order to mix the solution.




Illustration 33

g00285520

Cooling system filler cap

A WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

- Remove the cooling system filler cap slowly in order to relieve pressure.
- 2. Maintain the coolant level within 13 mm (0.5 inch) of the bottom of the filler pipe. If the engine is equipped with a sight glass, maintain the coolant level to the proper level in the sight glass.




Illustration 34

g00103639

Typical filler cap gaskets

- Clean the cooling system filler cap and check the condition of the filler cap gaskets. Replace the cooling system filler cap if the filler cap gaskets are damaged. Reinstall the cooling system filler cap.
- **4.** Inspect the cooling system for leaks.

- 6. Repeat 5 until the solution changes color from red to light gray, green, or blue. Record the number of drops of "NITRITE TEST SOLUTION A" that were required to cause the color change.
- 7. Use Table 18 to interpret the results.

Table 18

Number of Drops	Concentration of SCA	Maintenance Required
Less than 25	Less than the recommended concentration of SCA	Add SCA. Retest the coolant.
25 to 30	The recommended concentration of SCA	None
More than 30	More than the recommended concentration of SCA	Remove the coolant. Replace with water only Retest the coolant.

Add the SCA, If Necessary

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Remove the cooling system filler cap slowly.

Note: Always dispose of fluids according to local regulations.

2. If necessary, drain some coolant in order to allow space for the addition of the SCA.

NOTICE

Excessive supplemental coolant additive concentration can form deposits on the higher temperature surfaces of the cooling system, reducing the engine's heat transfer characteristics. Reduced heat transfer could cause cracking of the cylinder head and other high temperature components.

Excessive supplemental coolant additive concentration could also result in blockage of the heat exchanger, overheating, and/or accelerated wear of the water pump seal.

Do not exceed the recommended amount of supplemental coolant additive concentration.

- 3. Add the proper amount of SCA. The concentration of the SCA depends on the type of coolant that is used. To determine the proper amount, see this Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic.
- **4.** Clean the cooling system filler cap. Install the cooling system filler cap.

i00912898

Cooling System Water Temperature Regulator -Replace

SMCS Code: 1355-510

Replace the water temperature regulator before the water temperature regulator fails. This is a recommended preventive maintenance practice. Replacing the water temperature regulator reduces the chances for unscheduled downtime.

A water temperature regulator that fails in a partially opened position can cause overheating or overcooling of the engine.

A water temperature regulator that fails in the closed position can cause excessive overheating. Excessive overheating could result in cracking of the cylinder head or piston seizure problems.

A water temperature regulator that fails in the open position will cause the engine operating temperature to be too low during partial load operation. Low engine operating temperatures during partial loads could cause an excessive carbon buildup inside the cylinders. This excessive carbon buildup could result in an accelerated wear of the piston rings and wear of the cylinder liner.

NOTICE

Failure to replace your water temperature regulator on a regularly scheduled basis could cause severe engine damage.

Caterpillar engines incorporate a shunt design cooling system and require operating the engine with a water temperature regulator installed.

If the water temperature regulator is installed incorrectly, the engine may overheat, causing cylinder head damage. Ensure that the new water temperature regulator is installed in the original position. Ensure that the water temperature regulator vent hole is open.

Do not use liquid gasket material on the gasket or cylinder head surface.

Refer to the Service Manual for the replacement procedure of the water temperature regulator, or consult your Caterpillar dealer.

Note: If only the water temperature regulators are replaced, drain the coolant from the cooling system to a level that is below the water temperature regulator housing.

i00072369

Crankshaft Vibration Damper - Inspect

SMCS Code: 1205-040

Damage to the crankshaft vibration damper or failure of the crankshaft vibration damper can increase torsional vibrations. This can result in damage to the crankshaft and to other engine components. A deteriorating damper can cause excessive gear train noise at variable points in the speed range.

The damper is mounted to the crankshaft which is located behind the belt guard on the front of the engine.

Removal and Installation

Refer to the Service Manual for the damper removal procedure and for the damper installation procedure.

Visconic Damper

The visconic damper has a weight that is located inside a fluid filled case. The weight moves in the case in order to limit torsional vibration. Inspect the damper for evidence of dents, cracks or leaks of the fluid.

Replace the damper if the damper is dented, cracked or leaking. Refer to the Service Manual or consult your Caterpillar dealer for damper replacement.

i01473487

Cylinder Head Grounding Stud - Inspect/Clean/Tighten

SMCS Code: 7423-040; 7423-070; 7423-079




Illustration 35
Typical example

g00768411

Inspect the OEM harness for good connections and condition.

The electrical grounding stud must have a wire ground to the battery. Tighten the electrical grounding stud at every oil change. Ground wires and straps should be combined at engine grounds. All grounds should be tight and free of corrosion.

- If the connections are corroded, clean the connections with a solution of baking soda and water.
- Keep the electrical grounding stud and the strap clean and coated with MPGM grease or petroleum jelly.

i00174798

Driven Equipment - Check

SMCS Code: 3279-535

Refer to the OEM specifications for more information on the following maintenance recommendations for the driven equipment: Inspection

- Adjustment
- Lubrication
- Other maintenance recommendations

Perform any maintenance for the driven equipment which is recommended by the OEM.

i01646701

Engine - Clean

SMCS Code: 1000-070

A WARNING

Personal injury or death can result from high voltage.

Moisture can create paths of electrical conductivity.

Make sure that the electrical system is OFF. Lock out the starting controls and tag the controls "DO NOT OPERATE".

NOTICE

Accumulated grease and oil on an engine is a fire hazard. Keep the engine clean. Remove debris and fluid spills whenever a significant quantity accumulates on the engine.

Periodic cleaning of the engine is recommended. Steam cleaning the engine will remove accumulated oil and grease. A clean engine provides the following benefits:

- · Easy detection of fluid leaks
- · Maximum heat transfer characteristics
- · Ease of maintenance

Note: Caution must be used in order to prevent electrical components from being damaged by excessive water when you clean the engine. Avoid electrical components such as the alternator, the starter, and the ECM.

i01553486

Engine Air Cleaner Element (Dual Element) - Clean/Replace

SMCS Code: 1054-037; 1054-510

NOTICE

Never run the engine without an air cleaner element installed. Never run the engine with a damaged air cleaner element. Do not use air cleaner elements with damaged pleats, gaskets or seals. Dirt entering the engine causes premature wear and damage to engine components. Air cleaner elements help to prevent airborne debris from entering the air inlet.

NOTICE

Never service the air cleaner element with the engine running since this will allow dirt to enter the engine.

Servicing the Air Cleaner Elements

If the air cleaner element becomes plugged, the air can split the material of the air cleaner element. Unfiltered air will drastically accelerate internal engine wear. Your Caterpillar dealer has the proper air cleaner elements for your application. Consult your Caterpillar dealer for the correct air cleaner element.

- Check the precleaner (if equipped) daily for accumulation of dirt and debris. Remove any dirt and debris, as needed.
- Operating conditions (dust, dirt and debris) may require more frequent service of the air cleaner element.
- The air cleaner element may be cleaned up to six times if the element is properly cleaned and inspected.
- The air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

Replace the dirty paper air cleaner elements with clean air cleaner elements. Before installation, the air cleaner elements should be thoroughly checked for tears and/or holes in the filter material. Inspect the gasket or the seal of the air cleaner element for damage. Maintain a supply of suitable air cleaner elements for replacement purposes.

Dual Element Air Cleaners

The dual element air cleaner contains a primary air cleaner element and a secondary air cleaner element. The primary air cleaner element can be used up to six times if the element is properly cleaned and inspected. The primary air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

The secondary air cleaner element is not serviceable or washable. The secondary air cleaner element should be removed and discarded for every three cleanings of the primary air cleaner element. When the engine is operating in environments that are dusty or dirty, air cleaner elements may require more frequent replacement.




Illustration 36

g00736431

- (1) Cover
- (2) Primary air cleaner element
- (3) Secondary air cleaner element
- (4) Turbocharger air inlet
- 1. Remove the cover. Remove the primary air cleaner element.
- 2. The secondary air cleaner element should be removed and discarded for every three cleanings of the primary air cleaner element.

Note: Refer to "Cleaning the Primary Air Cleaner Elements".

- Cover the turbocharger air inlet with tape in order to keep dirt out.
- **4.** Clean the inside of the air cleaner cover and body with a clean, dry cloth.
- **5.** Remove the tape for the turbocharger air inlet. Install the secondary air cleaner element. Install a primary air cleaner element that is new or cleaned.
- 6. Install the air cleaner cover.
- 7. Reset the air cleaner service indicator.

Cleaning the Primary Air Cleaner Elements

NOTICE

Caterpillar recommends certified air filter cleaning services that are available at Caterpillar dealers. The Caterpillar cleaning process uses proven procedures to assure consistent quality and sufficient filter life.

Observe the following guidelines if you attempt to clean the filter element:

Do not tap or strike the filter element in order to remove dust.

Do not wash the filter element.

Use low pressure compressed air in order to remove the dust from the filter element. Air pressure must not exceed 207 kPa (30 psi). Direct the air flow up the pleats and down the pleats from the inside of the filter element. Take extreme care in order to avoid damage to the pleats.

Do not use air filters with damaged pleats, gaskets, or seals. Dirt entering the engine will cause damage to engine components.

The primary air cleaner element can be used up to six times if the element is properly cleaned and inspected. When the primary air cleaner element is cleaned, check for rips or tears in the filter material. The primary air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

Use clean primary air cleaner elements while dirty elements are being cleaned.

NOTICE

Do not clean the air cleaner elements by bumping or tapping. This could damage the seals. Do not use elements with damaged pleats, gaskets or seals. Damaged elements will allow dirt to pass through. Engine damage could result.

Visually inspect the primary air cleaner elements before cleaning. Inspect the air cleaner elements for damage to the seal, the gaskets, and the outer cover. Discard any damaged air cleaner elements.

There are two common methods that are used to clean primary air cleaner elements:

- · Pressurized air
- Vacuum cleaning

Pressurized Air

Pressurized air can be used to clean primary air cleaner elements that have not been cleaned more than two times. Pressurized air will not remove deposits of carbon and oil. Use filtered, dry air with a maximum pressure of 207 kPa (30 psi).




Illustration 37 g00281692

Note: When the primary air cleaner elements are cleaned, always begin with the clean side (inside) in order to force dirt particles toward the dirty side (outside).

Aim the hose so that the air flows inside the element along the length of the filter in order to help prevent damage to the paper pleats. Do not aim the stream of air directly at the primary air cleaner element. Dirt could be forced further into the pleats.

Note: Refer to "Inspecting the Primary Air Cleaner Elements".

Vacuum Cleaning

Vacuum cleaning is a good method for cleaning primary air cleaner elements which require daily cleaning because of a dry, dusty environment. Cleaning with pressurized air is recommended prior to vacuum cleaning. Vacuum cleaning will not remove deposits of carbon and oil.

Note: Refer to "Inspecting the Primary Air Cleaner Elements".

Inspecting the Primary Air Cleaner Elements




Illustration 38 g00281693

Inspect the clean, dry primary air cleaner element. Use a 60 watt blue light in a dark room or in a similar facility. Place the blue light in the primary air cleaner element. Rotate the primary air cleaner element. Inspect the primary air cleaner element for tears and/or holes. Inspect the primary air cleaner element for light that may show through the filter material. If it is necessary in order to confirm the result, compare the primary air cleaner element to a new primary air cleaner element that has the same part number.

Do not use a primary air cleaner element that has any tears and/or holes in the filter material. Do not use a primary air cleaner element with damaged pleats, gaskets or seals. Discard damaged primary air cleaner elements.

Storing Primary Air Cleaner Elements

If a primary air cleaner element that passes inspection will not be used, the primary air cleaner element can be stored for future use.




Illustration 39 g00281694

Do not use paint, a waterproof cover, or plastic as a protective covering for storage. An airflow restriction may result. To protect against dirt and damage, wrap the primary air cleaner elements in Volatile Corrosion Inhibited (VCI) paper.

Place the primary air cleaner element into a box for storage. For identification, mark the outside of the box and mark the primary air cleaner element. Include the following information:

- · Date of cleaning
- · Number of cleanings

Store the box in a dry location.

i01900118


Engine Air Cleaner Service Indicator - Inspect (If Equipped)

SMCS Code: 7452-040

Some engines may be equipped with a different service indicator.

Some engines are equipped with a differential gauge for inlet air pressure. The differential gauge for inlet air pressure displays the difference in the pressure that is measured before the air cleaner element and the pressure that is measured after the air cleaner element. As the air cleaner element becomes dirty, the pressure differential rises. If your engine is equipped with a different type of service indicator, follow the OEM recommendations in order to service the air cleaner service indicator.

The service indicator may be mounted on the air cleaner housing or in a remote location.



g00103777

Observe the service indicator. The air cleaner element should be cleaned or the air cleaner element should be replaced when one of the following conditions occur:

- The yellow diaphragm enters the red zone.
- · The red piston locks in the visible position.

Test the Service Indicator

Service indicators are important instruments.

- Check for ease of resetting. The service indicator should reset in less than three pushes.
- Check the movement of the yellow core when the engine is accelerated to the engine rated speed.
 The yellow core should latch approximately at the greatest vacuum that is attained.

If the service indicator does not reset easily, or if the yellow core does not latch at the greatest vacuum, the service indicator should be replaced. If the new service indicator will not reset, the hole for the service indicator may be plugged.

The service indicator may need to be replaced frequently in environments that are severely dusty, if necessary. Replace the service indicator annually regardless of the operating conditions. Replace the service indicator when the engine is overhauled, and whenever major engine components are replaced.

Note: When a new service indicator is installed, excessive force may crack the top of the service indicator. Tighten the service indicator to a torque of 2 N·m (18 lb in).

i01724662

Engine Crankcase Breather - Clean

SMCS Code: 1317-070

NOTICE

Perform this maintenance with the engine stopped.

NOTICE

If the crankcase breather is not maintained on a regular basis, it can become plugged. A plugged breather will cause excessive crankcase pressure that may cause crankshaft seal leakage.




Illustration 41

g00768439

- (1) Breather assembly
- (2) Bolt
- (3) Hose clamp
- (4) Hose
- 1. Loosen hose clamp (3) and remove hose (4) from breather assembly (1).
- 2. Remove bolt (2) and the washer. Remove the breather assembly (1) and the seal.
- **3.** Wash the breather element in solvent that is clean and nonflammable. Allow the breather element to dry before installation.
- **4.** Install a breather element that is clean and dry. Install breather assembly (1) and the seal.
- Install bolt (2) and the washer. Refer to Specifications, SENR3130, "Torque Specifications" for the correct torque.
- **6.** Install hose (4) on breather assembly (1). Tighten hose clamp (3). Refer to Specifications, SENR3130, "Torque Specifications" for the correct torques.

i02139969

Engine Mounts - Inspect

SMCS Code: 1152-040

Inspect the engine mounts for deterioration and for proper bolt torque. Engine vibration can be caused by the following conditions:

· Improper mounting of the engine

· Deterioration of the engine mounts

Any engine mount that shows deterioration should be replaced. Refer to the Specifications Manual, SENR3130, "Torque Specifications". Refer to your Caterpillar dealer for more information.

i00623423

Engine Oil Level - Check

SMCS Code: 1348-535-FLV

WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.




Illustration 42

g00110310

(Y) "ADD" mark. (X) "FULL" mark.

NOTICE

Perform this maintenance with the engine stopped.

1. Maintain the oil level between "ADD" mark (Y) and "FULL" mark (X) on oil level gauge (1). Do not fill the crankcase above "FULL" mark (X).

NOTICE

Operating your engine when the oil level is above the "FULL" mark could cause your crankshaft to dip into the oil. The air bubbles created from the crankshaft dipping into the oil reduces the oil's lubricating characteristics and could result in the loss of power.

2. Remove the oil filler cap and add oil, if necessary. Clean the oil filler cap. Install the oil filler cap.

Engine Oil Sample - Obtain

SMCS Code: 1000-008; 1348-554-SM; 7542-554-OC, SM

In addition to a good preventive maintenance program, Caterpillar recommends using S·O·S oil analysis at regularly scheduled intervals in order to monitor the condition of the engine and the maintenance requirements of the engine. S·O·S oil analysis provides infrared analysis, which is required for determining nitration and oxidation levels.

Obtain the Sample and the Analysis

WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

Before you take the oil sample, complete the Label, PEEP5031 for identification of the sample. In order to help obtain the most accurate analysis, provide the following information:

- · Engine model
- · Service hours on the engine
- The number of hours that have accumulated since the last oil change
- The amount of oil that has been added since the last oil change

To ensure that the sample is representative of the oil in the crankcase, obtain a warm, well mixed oil sample.

To avoid contamination of the oil samples, the tools and the supplies that are used for obtaining oil samples must be clean.

Caterpillar recommends using the sampling valve in order to obtain oil samples. The quality and the consistency of the samples are better when the sampling valve is used. The location of the sampling valve allows oil that is flowing under pressure to be obtained during normal engine operation.

The 169-8373 Fluid Sampling Bottle is recommended for use with the sampling valve. The fluid sampling bottle includes the parts that are needed for obtaining oil samples. Instructions are also provided.

NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

If the engine is not equipped with a sampling valve, use the 1U-5718 Vacuum Pump. The pump is designed to accept sampling bottles. Disposable tubing must be attached to the pump for insertion into the sump.

For instructions, see Special Publication, PEHP6001, "How To Take A Good Oil Sample". Consult your Caterpillar dealer for complete information and assistance in establishing an S·O·S program for your engine.

i02282136

Engine Oil and Filter - Change

SMCS Code: 1318-510; 1348-044

Selection of Oil Change Interval

NOTICE

This engine meets EPA Tier 2, Euro Stage II, or MOC Step 2 emission regulations. The standard oil change interval is 250 hours. Oil change intervals of 500 hours are available, provided that operating conditions, recommended multigrade oil types, SOS oil sampling, analysis program, and IR (infrared) are used to determine the acceptable oil change interval. Refer to the "Optimizing Oil Change Intervals", PEDP7035 in order to determine oil changes.

If you select an interval for oil and filter change that is too long, you may damage the engine.

A WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

Caterpillar oil filters are recommended for oil changes. Recommended multigrade oil types are listed in Table 19. Do not use single grade oils.




Illustration 43 g00783061

API Trademark

Commercial oils that are licensed by the American Petroleum Institute (API) bear this trademark. Commercial oils that do not bear this trademark are not licensed and these oils are not recommended. Oils that are not listed in Table19 are not recommended.

Abnormally harsh operating cycles or harsh environments can shorten the service life of the engine oil. Arctic temperatures, corrosive environments, or extremely dusty conditions may require a reduction in engine oil change intervals from the recommendations in Table 19. Poor maintenance of air filters or of fuel filters requires reduced oil change intervals. See your Caterpillar dealer for more information if this product will experience abnormally harsh operating cycles or harsh environments.

Table 19

Oil Change Interval for C-9 Industrial Engine (1)					
	Operating Conditions				
				Severe	
Multigrade Oil Type	Normal ⁽²⁾	High Load Factor above 43 L (11 US gal per hour of fuel)	Fuel Sulfur from 0.3% to 0.5%	Altitude above 1830 m (6000 ft)	
Cat DEO Preferred	250 hr	250 hr	250 hr	250 hr [®]	
API CH-4 11.0 minimum TBN ⁽⁴⁾ Preferred	250 hr	250 hr	250 hr	250 hr ⁽⁶⁾	
API CH-4 TBN ⁽⁴⁾ below 11.0	250 hr	250 hr	250 hr ⁽⁵⁾	250 hr ⁽⁶⁾	
API CG-4	250 hr	250 hr ⁽⁵⁾	250 hr ⁽⁵⁾	250 hr ⁽⁶⁾	

- (1) The standard oil change interval in this engine is 250 hours, if the operating conditions and recommended oil types that are listed in this table are met. Oil change intervals may be increased to 500 hours depending on oil type, quality and operating conditions. To determine if the oil change interval can be extended beyond 250 hours, refer to Special Publication, PEDP7035, "Optimizing Oil Change Intervals".
- (2) Normal conditions include these factors: Fuel sulfur below 0.3%, altitude below 1830 m (6000 ft), and good air filter and fuel filter maintenance. Normal conditions do not include high load factor, harsh operating cycles, or harsh environments.
- (3) High load factors can shorten the service life of your engine oil. Continuous heavy load cycles and very little idle time result in increased fuel consumption and oil contamination. These factors deplete the oil additives more rapidly. If the average fuel consumption of your engine exceed 43 L (11 US gal) per hour, follow the "High Load Factor" recommendations in Table 19. To determine average fuel consumption for your engine, measure average fuel consumption for a period of 50 to 100 hours. If the application of the engine is changed, the average fuel consumption may change.
- (4) For sulfur content above 0.5%, refer to, "Total Base Number (TBN) and Fuel Sulfur Levels for Direct Injection (DI) Diesel Engines" in Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations".
- (5) In order to verify an oil change interval of 500 hours, refer to "Program A" below.
- (6) Use "Program B" below to determine an appropriate interval.

Adjustment of the Oil Change Interval

Note: Your Caterpillar dealer has additional information on these programs.

Program A

· Proceed to Program B.

Change to a preferred oil type in Table 19.

Program B

Optimizing Oil Change Intervals

Begin with a 250 hour oil change interval. The oil change intervals are adjusted by increments. Each interval is adjusted an additional 50 hours. Periodic oil sampling and analysis is done during each interval. The analysis includes oil viscosity and infrared (IR) analysis of the oil. Repeat Program B if you change the application of the engine.

If an oil sample does not pass the analysis, shorten the oil change interval, or change to a preferred multigrade oil type in the listing above.

References

Reference: Form, PEDP7035, "Optimizing Oil

Change Intervals"

Reference: Form, PEDP7036, "S·O·S Fluid Analysis"

Reference: Form, PEDP7076, "Understanding the

S·O·S Oil Analysis Tests"

Drain the Engine Oil

After the engine has been run at the normal operating temperature, stop the engine. Attach a "DO NOT OPERATE" or a similar warning tag to the ignition key switch before the engine is serviced. Catch the oil in a suitable container. Recycle the used oil, or dispose of the used oil properly.

- Remove the oil drain plug in order to allow the oil to drain.
- After the oil has drained, the oil drain plug should be cleaned and installed.

Replace the Oil Filter

NOTICE

Caterpillar oil filters are built to Caterpillar specifications. Use of an oil filter not recommended by Caterpillar could result in severe engine damage to the engine bearings, crankshaft, etc., as a result of the larger waste particles from unfiltered oil entering the engine lubricating system. Only use oil filters recommended by Caterpillar.

1. Remove the oil filter with a 185-3630 Strap Wrench.




Illustration 44

g00588944

Element with debris

2. Cut the oil filter open with a 175-7546 Oil Filter Cutter. Break apart the pleats and inspect the oil filter for metal debris. An excessive amount of metal debris in the oil filter may indicate early wear or a pending failure.

Use a magnet to differentiate between the ferrous metals and the nonferrous metals that are found in the oil filter element. Ferrous metals may indicate wear on the steel and cast iron parts of the engine.

Nonferrous metals may indicate wear on the aluminum parts, brass parts or bronze parts of the engine. Parts that may be affected include the following items: main bearings, rod bearings, turbocharger bearings, and cylinder heads.

Due to normal wear and friction, it is not uncommon to find small amounts of debris in the oil filter. Consult your Caterpillar dealer in order to arrange for a further analysis if an excessive amount of debris is found in the oil filter.



Illustration 45

g00103713

Typical filter mounting base and filter gasket

Clean the sealing surface of the filter mounting base. Ensure that all of the old oil filter gasket is removed. **4.** Apply clean engine oil to the new oil filter gasket.

NOTICE

Do not fill the oil filters with oil before installing them. This oil would not be filtered and could be contaminated. Contaminated oil can cause accelerated wear to engine components.

5. Install the oil filter. Tighten the oil filter until the oil filter gasket contacts the base. Tighten the oil filter by hand according to the instructions that are shown on the oil filter. Do not overtighten the oil filter.

Fill the Engine Crankcase

 Remove the oil filler cap. Fill the crankcase with the proper amount of oil. Refer to the Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic (Maintenance Section) for more information.

NOTICE

If equipped with an auxiliary oil filter or system, extra oil must be added when filling the crankcase. Follow the OEM or filter manufacturer's recommendations. If the extra oil is not added, the engine may starve for oil.

NOTICE

To help prevent crankshaft or bearing damage, crank engine to fill all filters before starting. Do not crank engine for more than 30 seconds.

- Start the engine and run the engine at "LOW IDLE" for two minutes. Perform this procedure in order to ensure that the lubrication system has oil and that the oil filters are filled. Inspect the oil filter for oil leaks.
- **3.** Stop the engine and allow the oil to drain back to the sump for a minimum of ten minutes.
- 4. Remove the oil level gauge in order to check the oil level. Maintain the oil level between the "ADD" and "FULL" marks on the "ENGINE STOPPED" side of the oil level gauge.

i01430860

Engine Storage Procedure - Check

SMCS Code: 1000-535

Caterpillar requires all engines that are stored for more than 3 months to follow storage procedures and start-up procedures. These procedures provide maximum protection to internal engine components. Refer to Special Instruction, SEHS9031, "Storage Procedure For Caterpillar Products" for information on these procedures.

An extension of the oil change interval to 12 months is permitted if you follow the required procedures for storage and start-up. This extension is permitted if the following intervals in the Operation and Maintenance Manual, "Maintenance Interval Schedule" have not been reached:

- · Operating hours
- Fuel consumption

i00869628

Engine Valve Lash - Inspect/Adjust

SMCS Code: 1102-025

The initial valve lash adjustment on new engines, rebuilt engines, or remanufactured engines is recommended at the first scheduled oil change. The adjustment is necessary due to the initial wear of the valve train components and to the seating of the valve train components.

This maintenance is recommended by Caterpillar as part of a lubrication and preventive maintenance schedule in order to help provide maximum engine life.

NOTICE

Only qualified service personnel should perform this maintenance. Refer to the Service Manual or your Caterpillar dealer for the complete valve lash adjustment procedure.

Operation of Caterpillar engines with improper valve adjustments can reduce engine efficiency. This reduced efficiency could result in excessive fuel usage and/or shortened engine component life.

MARNING

Ensure that the engine can not be started while this maintenance is being performed. To help prevent possible injury, do not use the starting motor to turn the flywheel.

Hot engine components can cause burns. Allow additional time for the engine to cool before measuring/adjusting valve lash clearance.

Ensure that the engine is stopped before measuring the valve lash. To obtain an accurate measurement, allow the valves to cool before this maintenance is performed.

Refer to the Service Manual for more information.

i01597115

Engine Valve Rotators - Inspect

SMCS Code: 1109-040

A WARNING

When inspecting the valve rotators, protective glasses or face shield and protective clothing must be worn, to help prevent being burned by hot oil or spray.

Engine valve rotators rotate the valves when the engine runs. This helps to prevent deposits from building up on the valves and the valve seats.

Perform the following steps after the engine valve lash is set, but before the valve covers are installed:

- Start the engine according to Operation and Maintenance Manual, "Engine Starting" (Operation Section) for the procedure.
- 2. Operate the engine at low idle.
- Observe the top surface of each valve rotator. The valve rotators should turn slightly when the valves close.

NOTICE

A valve rotator which does not operate properly will accelerate valve face wear and valve seat wear and shorten valve life. If a damaged rotator is not replaced, valve face guttering could result and cause pieces of the valve to fall into the cylinder. This can cause piston and cylinder head damage.

If a valve fails to rotate, consult your Caterpillar dealer.

i02239650

Fan Drive Bearing - Lubricate

SMCS Code: 1359-086-BD

Some of the fan drives have grease fittings and some of the fan drives do not have grease fittings. If there is no grease fitting, periodic lubrication is not required. The fan drive requires grease only if the fan drive is equipped with a zerk.




Illustration 46

g00746166

Typical location of the grease fitting (if equipped) that is for the fan drive bearing

The pulley is shown with the belt guards that have been removed.

Lubricate the grease fitting that is on the fan drive bearing with Bearing Lubricant or the equivalent.

Inspect the fan drive pulley assembly for wear or for damage. If the shaft is loose, an inspection of the internal components should be performed. Refer to the Service Manual for additional information.

i02113137

Fuel System - Prime

SMCS Code: 1258-548

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over any disconnected fuel system components.

Prime the fuel system in order to fill the fuel filter. Prime the fuel system in order to purge trapped air. The fuel system should be primed under the following conditions:

- · Running out of fuel
- Storage
- · Replacement of the fuel filter

Engines that are Equipped with a Fuel Priming Pump

NOTICE

Do not loosen the fuel lines at the fuel manifold. The fittings may be damaged and/or a loss of priming pressure may occur when the fuel lines are loosened.

 Open the fuel priming pump and operate the fuel priming pump until a strong pressure is felt. This procedure will require considerable strokes. Lock the fuel priming pump.

NOTICE

Do not crank the engine continuously for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking the engine again.

- 2. Promptly start the engine. If the engine runs rough, continue to operate the engine at low idle. Do not raise the engine rpm above an idle, until the engine operates smoothly.
- 3. If the engine does not start, open the fuel priming pump and repeat Steps 1 and 2 in order to start the engine.

Engines that are Not Equipped with a Fuel Priming Pump

If the engine is not equipped with a fuel priming pump, you can use the following procedures to prime the fuel system. These procedures will allow only filtered fuel to enter the fuel system.

Fuel Filter Bases that are Equipped with a Plug

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over any disconnected fuel system components.




Illustration 47

g01076450

- (1) Plug
- (2) Fuel filter
- Remove plug (1) in order to fill fuel filter (2). Ensure that air is able to vent from the fitting of the plug while the fuel filter is being filled. Clean up any spilled fuel immediately. Clean plug (1). Install plug (1).

NOTICE

Do not crank the engine continuously for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking the engine again.

2. Start the engine and operate the engine at low idle. Do not raise the engine speed above an idle, until the engine operates smoothly.

Fuel Filter Bases that are Not Equipped with a Plug

NOTICE

Do not crank the engine continuously for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking the engine again.

- Operate the starting motor. This will fill the fuel filter and the fuel lines with fuel.
- Once the engine starts, operate the engine at low idle. Do not raise the engine speed above an idle, until the engine operates smoothly.

Fuel System Primary Filter/Water Separator - Drain

SMCS Code: 1260-543; 1263-543

MARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.




Illustration 48

g00104007

(1) Element. (2) Bowl. (3) Drain.

Bowl (2) should be monitored daily for signs of water. If water is present, drain the water from the bowl.

- **1.** Open drain (3). The drain is a self-ventilated drain. Catch the draining water in a suitable container. Dispose of the water properly.
- 2. Close drain (3).

NOTICE

The water separator is under suction during normal engine operation. Ensure that the drain valve is tightened securely to help prevent air from entering the fuel system.

i02241591

Fuel System Primary Filter (Water Separator) Element - Replace

SMCS Code: 1260-510-FQ; 1263-510-FQ

Water in the fuel can cause the engine to run rough. Water in the fuel may cause a electronic unit injector to fail. If the fuel has been contaminated with water, the element should be changed before the regularly scheduled interval.

The primary filter/water separator also provides filtration in order to help extend the life of the secondary fuel filter. The element should be changed regularly. If a vacuum gauge is installed, the primary filter/water separator should be changed at 50 to 70 kPa (15 to 20 inches hg).

Replace the Element

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

Note: A 10 to 15 micron absolute high efficiency fuel filter is required for Caterpillar Electronic Unit Injectors. Caterpillar High Efficiency Fuel Filters meet these requirements. Consult your Caterpillar dealer for the proper part number.

1. Close the main fuel supply valve.




Illustration 49

g00104012

- (1) Element. (2) Bowl. (3) Drain.
- 2. Remove element (1) from the element mounting base while bowl (2) is attached.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over any disconnected fuel system components.

NOTICE

Use a suitable container to catch any fuel that might spill. Clean up any spilled fuel immediately.

- Dispose of the fuel in the fuel filter element. Remove bowl (2) from element (1). The bowl is reusable. Do not discard the bowl. Dispose of the used element.
- **4.** Remove the O-ring from the gland of the bowl. Clean the following components:
 - Bowl
 - O-ring
 - · Mounting base

Inspect the O-ring for damage and for deterioration. Replace the O-ring, if necessary.

- 5. Lubricate the O-ring with clean diesel fuel.
- **6.** Install bowl (2) on a new element. Tighten the bowl by hand. Do not use tools in order to tighten the bowl.

NOTICE

The primary filter/water separator may be prefilled with fuel to avoid rough running/stalling of the engine due to air. Do not fill the secondary filter with fuel before installation. The fuel would not be filtered and could be contaminated. Contaminated fuel will cause accelerated wear to fuel system parts.

7. Lubricate the top seal of element (1) with clean diesel fuel. The element may be filled with fuel at this time. Install the new element on the mounting base. Tighten the element by hand.

NOTICE

The water separator is under suction during normal engine operation. Ensure that the vent plug is tightened securely to help prevent air from entering the fuel system.

- **8.** Open the main fuel supply valve.
- **9.** Start the engine and check for leaks. Run the engine for one minute. Stop the engine and check for leaks again.

Detection of leaks is difficult while the engine is running. The primary filter/water separator is under suction. A leak will allow air to enter the fuel. The air in the fuel can cause low power due to aeration of the fuel. If air enters the fuel, check the components for overtightening or under tightening.

i01503750

Fuel System Secondary Filter - Replace

SMCS Code: 1261-510-SE

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over any disconnected fuel system components.

NOTICE

Use a suitable container to catch any fuel that might spill. Clean up any spilled fuel immediately.

- Stop the engine. Turn the ignition switch to the OFF position or disconnect the battery. Refer to the Operation and Maintenance Manual, "Battery or Battery Cable - Disconnect" topic (Maintenance Section) for more information. Shut off the fuel supply valve (if equipped).
- 2. Remove the used fuel filter and discard the used fuel filter.
- **3.** Clean the gasket sealing surface of the fuel filter base. Ensure that all of the old gasket is removed.
- 4. Apply clean diesel fuel to the new fuel filter gasket.

NOTICE

Do not fill the secondary fuel filter with fuel before installing. The fuel would not be filtered and could be contaminated. Contaminated fuel will cause accelerated wear to fuel system parts.

NOTICE

In order to maximize fuel system life and prevent premature wear out from abrasive particles in the fuel, a two micron absolute high efficiency fuel filter is required for all Caterpillar Hydraulic Electronic Unit Injectors. Caterpillar High Efficiency Fuel Filters meet these requirements. Consult your Caterpillar dealer for the proper part numbers.

- 5. Install the new fuel filter. Spin the fuel filter onto the fuel filter base until the gasket contacts the base. Use the rotation index marks on the filters as a guide for proper tightening. Tighten the filter for an additional one turn (360 degrees) by hand. Do not overtighten the filter.
- **6.** Open the fuel supply valve. Prime the fuel system. Refer to the Operation and Maintenance Manual, "Fuel System Prime" topic (Maintenance Section) for more information. Start the engine and inspect the fuel system for leaks.

NOTICE

Do not crank the engine continuously for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking the engine again.

Note: There should be enough residual fuel in the cylinder head in order to start the engine. If the engine stops after starting, do not crank the engine for more than 30 seconds. Then allow the starting motor to cool for two minutes. Repeat this procedure until the engine starts and the engine operates.

i01877350

Fuel Tank Water and Sediment - Drain

SMCS Code: 1273-543-M&S

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Tools and Shop Products Guide" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

Fuel Tank

Fuel quality is critical to the performance and to the service life of the engine. Water in the fuel can cause excessive wear to the fuel system. Condensation occurs during the heating and cooling of fuel. The condensation occurs as the fuel passes through the fuel system and the fuel returns to the fuel tank. This causes water to accumulate in fuel tanks. Draining the fuel tank regularly and obtaining fuel from reliable sources can help to eliminate water in the fuel.

Drain the Water and the Sediment

Fuel tanks should contain some provision for draining water and draining sediment from the bottom of the fuel tanks.

Open the drain valve on the bottom of the fuel tank in order to drain the water and the sediment. Close the drain valve.

Check the fuel daily. Drain the water and sediment from the fuel tank after operating the engine or drain the water and sediment from the fuel tank after the fuel tank has been filled. Allow five to ten minutes before performing this procedure.

Fill the fuel tank after operating the engine in order to drive out moist air. This will help prevent condensation. Do not fill the tank to the top. The fuel expands as the fuel gets warm. The tank may overflow.

Some fuel tanks use supply pipes that allow water and sediment to settle below the end of the fuel supply pipe. Some fuel tanks use supply lines that take fuel directly from the bottom of the tank. If the engine is equipped with this system, regular maintenance of the fuel system filter is important.

Fuel Storage Tanks

Drain the water and the sediment from the fuel storage tank during the following conditions:

- Weekly
- Oil change
- · Refill of the tank

This will help prevent water or sediment from being pumped from the storage tank into the engine fuel tank.

If a bulk storage tank has been refilled or moved recently, allow adequate time for the sediment to settle before filling the engine fuel tank. Internal baffles in the bulk storage tank will also help trap sediment. Filtering fuel that is pumped from the storage tank helps to ensure the quality of the fuel. When possible, water separators should be used.

i02121526

Hoses and Clamps - Inspect/Replace

SMCS Code: 7554-040; 7554-510

Inspect all hoses for leaks that are caused by the following conditions:

- Cracking
- Softness
- Loose clamps

Replace hoses that are cracked or soft. Tighten any loose clamps.

NOTICE

Do not bend or strike high pressure lines. Do not install bent or damaged lines, tubes or hoses. Repair any loose or damaged fuel and oil lines, tubes and hoses. Leaks can cause fires. Inspect all lines, tubes and hoses carefully. Tighten all connections to the recommended torque.

Check for the following conditions:

- End fittings that are damaged or leaking
- · Outer covering that is chafed or cut
- · Exposed wire that is used for reinforcement
- Outer covering that is ballooning locally
- Flexible part of the hose that is kinked or crushed
- · Armoring that is embedded in the outer covering

A constant torque hose clamp can be used in place of any standard hose clamp. Ensure that the constant torque hose clamp is the same size as the standard clamp.

Due to extreme temperature changes, the hose will heat set. Heat setting causes hose clamps to loosen. This can result in leaks. A constant torque hose clamp will help to prevent loose hose clamps.

Each installation application can be different. The differences depend on the following factors:

- · Type of hose
- Type of fitting material
- Anticipated expansion and contraction of the hose
- Anticipated expansion and contraction of the fittings

Replace the Hoses and the Clamps

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

- **1.** Stop the engine. Allow the engine to cool.
- 2. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap.

Note: Drain the coolant into a suitable, clean container. The coolant can be reused.

- **3.** Drain the coolant from the cooling system to a level that is below the hose that is being replaced.
- 4. Remove the hose clamps.
- 5. Disconnect the old hose.
- **6.** Replace the old hose with a new hose.
- 7. Install the hose clamps with a torque wrench.

Note: Refer to the Specifications, SENR3130, "Torque Specifications" in order to locate the proper torques.

- 8. Refill the cooling system.
- Clean the cooling system filler cap. Inspect the cooling system filler cap's gaskets. Replace the cooling system filler cap if the gaskets are damaged. Install the cooling system filler cap.
- Start the engine. Inspect the cooling system for leaks.

Jacket Water Heater - Check

SMCS Code: 1383-535

Jacket water heaters help to improve startability in ambient temperatures that are below 21 °C (70 °F). All installations that require automatic starting should have jacket water heaters.

Check the operation of the jacket water heater. For an ambient temperature of 0 °C (32 °F), the heater should maintain the jacket water temperature at approximately 32 °C (90 °F).

i01452713

Overhaul Considerations

SMCS Code: 7595-043

Reduced hours of operation at full load will result in a lower average power demand. A decreased average power demand should increase both the engine service life and the overhaul interval.

The need for an overhaul is generally indicated by increased fuel consumption and by reduced power.

The following factors are important when a decision is being made on the proper time for an engine overhaul:

- The need for preventive maintenance
- · The quality of the fuel that is being used
- · The operating conditions
- The results of the S·O·S analysis

Oil Consumption as an Overhaul Indicator

Oil consumption, fuel consumption, and maintenance information can be used to estimate the total operating cost for your Caterpillar engine. Oil consumption can also be used to estimate the required capacity of a makeup oil tank that is suitable for the maintenance intervals.

Oil consumption is in proportion to the percentage of the rated engine load. As the percentage of the engine load is increased, the amount of oil that is consumed per hour also increases.

The oil consumption rate (brake specific oil consumption) is measured in grams per kW/h (lb per bhp). The brake specific oil consumption (BSOC) depends on the engine load. Consult your Caterpillar dealer for assistance in determining the typical oil consumption rate for your engine.

When an engine's oil consumption has risen to three times the original oil consumption rate due to normal wear, an engine overhaul should be scheduled. There may be a corresponding increase in blowby and a slight increase in fuel consumption.

Overhaul Options

Before Failure Overhaul

A planned overhaul before failure may be the best value for the following reasons:

- · Costly unplanned downtime can be avoided.
- Many original parts can be reused according to the standards for reusable parts.
- The engine's service life can be extended without the risk of a major catastrophe due to engine failure.
- The best cost/value relationship per hour of extended life can be attained.

After Failure Overhaul

If a major engine failure occurs and the engine must be removed, many options are available. An overhaul should be performed if the engine block or the crankshaft needs to be repaired.

If the engine block is repairable and/or the crankshaft is repairable, the overhaul cost should be between 40 percent and 50 percent of the cost of a new engine with a similar exchange core.

This lower cost can be attributed to three aspects:

- Specially designed Caterpillar engine features
- Caterpillar dealer exchange components
- Caterpillar Inc. remanufactured exchange components

Overhaul Recommendation

To minimize downtime, Caterpillar Inc. recommends a scheduled engine overhaul by your Caterpillar dealer before the engine fails. This will provide you with the best cost/value relationship. **Note:** Overhaul programs vary according to the engine application and according to the dealer that performs the overhaul. Consult your Caterpillar dealer for specific information about the available overhaul programs and about overhaul services for extending the engine life.

If an overhaul is performed without overhaul service from your Caterpillar dealer, be aware of the following maintenance recommendations.

Rebuild or Exchange

Cylinder Head Assembly, Cylinder Packs, Oil Pump, and Fuel Transfer Pump

These components should be inspected according to the instructions that are found in various Caterpillar reusability publications. The Special Publication, SEBF8029 lists the reusability publications that are needed for inspecting the engine parts.

If the parts comply with the established inspection specifications that are expressed in the reusable parts quideline, the parts should be reused.

Parts that are not within the established inspection specifications should be dealt with in one of the following manners:

- · Salvaging
- Repairing
- Replacing

Using out-of-spec parts can result in the following problems:

- · Unscheduled downtime
- Costly repairs
- Damage to other engine parts
- Reduced engine efficiency
- Increased fuel consumption

Reduced engine efficiency and increased fuel consumption translates into higher operating costs. Therefore, Caterpillar Inc. recommends repairing out-of-spec parts or replacing out-of-spec parts.

Inspection and/or Replacement

Crankshaft Bearings, Valve Rotators, and Crankshaft Seals

The following components may not last until the second overhaul.

- Thrust bearings
- Main bearings
- Rod bearings
- · Valve rotators
- · Crankshaft seals

Caterpillar Inc. recommends the installation of new parts at each overhaul period.

Inspect these parts while the engine is disassembled for an overhaul.

Inspect the crankshaft for any of the following conditions:

- Deflection
- · Damage to the journals
- Bearing material that has seized to the journals

Check the journal taper and the profile of the crankshaft journals. Check these components by interpreting the wear patterns on the following components:

- · Rod bearing
- · Main bearings

Inspect the camshaft for damage to the journals and to the lobes.

Note: If the camshaft is removed for any reason, use the magnetic particle inspection process to check for cracks in the camshaft.

Inspect the following components for signs of wear or for signs of scuffing:

- Camshaft bearings
- · Camshaft followers

Caterpillar Inc. recommends replacing the crankshaft vibration damper.

Oil Cooler Core

During an overhaul, Caterpillar Inc. recommends the removal of the oil cooler core. Clean the oil cooler core. Then, pressure test the oil cooler core.

NOTICE

Do not use caustic cleaners to clean the core.

Caustic cleaners can attack the internal metals of the core and cause leakage.

Note: Use this cleaning procedure to clean the oil cooler core.

- 1. Remove the oil cooler core.
- Remove any debris from the oil cooler core. To remove debris from the oil cooler core, turn the oil cooler core onto one end.
- **3.** Flush the oil cooler core internally with cleaner in order to loosen foreign substances. This will also help to remove oil from the oil cooler core.

Note: Caterpillar Inc. recommends the use of Hydrosolv Liquid Cleaners. Table 20 lists the Hydrosolv Liquid Cleaners that are available from your Caterpillar dealer.

Table 20

HydrosolvLiquid Cleaners			
Part Number	Description	Size	
1U-8812		4 L (1 US gallon)	
1U-5490	Hydrosolv4165	19 L (5 US gallon)	
8T-7570		208 L (55 US gallon)	
1U-8804		4 L (1 US gallon)	
1U-5492	Hydrosolv100	19 L (5 US gallon)	
8T-5571		208 L (55 US gallon)	

- **4.** Use steam to clean the oil cooler core. This removes any remaining residue from the cleaner. Flush the fins of the oil cooler core. Remove any other trapped debris.
- Wash the oil cooler core with hot, soapy water. Rinse the oil cooler core thoroughly with clean water.

WARNING

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

Maximum air pressure at the nozzle must be less than 205 kPa (30 psi) for cleaning purposes.

- Dry the oil cooler core with compressed air. Direct the air in the reverse direction of the normal flow.
- 7. Inspect the components in order to ensure cleanliness. The oil cooler core should be pressure tested. Repair the oil cooler core, if necessary. Install the oil cooler core.

For more information about cleaning the cores, consult your Caterpillar dealer.

Obtain Coolant Analysis

The concentration of supplemental coolant additive (SCA) should be checked regularly with test kits or with S·O·S Coolant Analysis (Level 1). Further coolant analysis is recommended when the engine is overhauled.

For example, considerable deposits are found in the water jacket areas on the external cooling system, but the concentrations of coolant additives were carefully maintained. The coolant water probably contained minerals that were deposited on the engine over time.

A coolant analysis can be conducted in order to verify the condition of the water that is being used in the cooling system. A full water analysis can be obtained by consulting your local water utility company or an agricultural agent. Private laboratories are also available for water analysis.

Caterpillar Inc. recommends an S·O·S Coolant Analysis (Level 2).

S-O-S Coolant Analysis (Level 2)

An S·O·S Coolant Analysis (Level 2) is a comprehensive coolant analysis which completely analyzes the coolant and the effects on the cooling system. An S·O·S Coolant Analysis (Level 2) provides the following information:

- Complete S·O·S Coolant Analysis (Level 1)
- · Visual inspection of properties
- Identification of metal corrosion
- · Identification of contaminants
- Identification of built up impurities (corrosion and scale)

S·O·S Coolant Analysis (Level 2) provides a report of the results of both the analysis and the maintenance recommendations.

For more information about coolant analysis, see your Caterpillar dealer.

Power Take-Off Clutch - Check/Adjust/Lubricate

SMCS Code: 3055-036; 3055-086

NOTICE

New power take-offs should have the clutch adjustment checked before being placed into service. The clutch adjustment should be checked again after the first ten hours of operation. New clutch plates have a "wear in" period, and the clutch may require several adjustments until the new plates are "worn in".




Illustration 50

q00781502

- (1) Instruction plate
- (2) Serial number plate

Check the clutch adjustment regularly after "wear in". Heavy-duty applications which have engagements that are frequent and relatively long periods of clutch slippage require more frequent adjustment than light-duty applications. The operating torque should be measured in order to determine if a clutch adjustment is required.

Refer to the OEM information and instruction plate (1) for instructions on lubrication, adjustment, and other recommendations for service. Perform the maintenance that is specified on the instruction plate.

A WARNING

Do not operate the engine with the Instruction Plate cover removed from the clutch. Personal injury may result.

If the clutch is damaged to the point of burst failure, expelled pieces can cause personal injury to anyone in the immediate area. Proper safeguards must be followed to help prevent accidents.

i01604510

Radiator - Clean

SMCS Code: 1353-070

Note: Adjust the frequency of cleaning according to the effects of the operating environment.

Inspect the radiator for these items: damaged fins, corrosion, dirt, grease, insects, leaves, oil, and other debris. Clean the radiator, if necessary.

WARNING

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

Maximum air pressure at the nozzle must be less than 205 kPa (30 psi) for cleaning purposes.

Pressurized air is the preferred method for removing loose debris. Direct the air in the opposite direction of the fan's air flow. Hold the nozzle approximately 6 mm (0.25 inch) away from the fins. Slowly move the air nozzle in a direction that is parallel with the tubes. This will remove debris that is between the tubes.

Pressurized water may also be used for cleaning. The maximum water pressure for cleaning purposes must be less than 275 kPa (40 psi). Use pressurized water in order to soften mud. Clean the core from both sides.

Use a degreaser and steam for removal of oil and grease. Clean both sides of the core. Wash the core with detergent and hot water. Thoroughly rinse the core with clean water.

After cleaning, start the engine and accelerate the engine to high idle rpm. This will help in the removal of debris and drying of the core. Stop the engine. Use a light bulb behind the core in order to inspect the core for cleanliness. Repeat the cleaning, if necessary.

Inspect the fins for damage. Bent fins may be opened with a "comb". Inspect these items for good condition: welds, mounting brackets, air lines, connections, clamps, and seals. Make repairs, if necessary.

For more detailed information on cleaning and inspection, refer to Special Publication, SEBD0518, "Know Your Cooling System".

Severe Service Application - Check

SMCS Code: 1000-535

Severe service is an application of an engine that exceeds current published standards for that engine. Caterpillar maintains standards for the following engine parameters:

- Performance (power range, speed range, and fuel consumption)
- · Fuel quality
- Altitude range
- · Maintenance intervals
- · Oil selection and maintenance
- · Coolant selection and maintenance
- Environmental qualities
- Installation

Refer to the standards for the engine or consult with your Caterpillar dealer in order to determine if the engine is operating within the defined parameters.

Severe service operation can accelerate component wear. Engines that operate under severe conditions may need more frequent maintenance intervals in order to ensure maximum reliability and retention of full service life.

Due to individual applications, it is not possible to identify all of the factors which can contribute to severe service operation. Consult your Caterpillar dealer for the unique maintenance that is necessary for the engine.

The operating environment, improper operating procedures and improper maintenance procedures can be factors which contribute to severe service conditions.

Environmental Factors

Ambient temperatures – The engine may be exposed to extended operation in extremely cold environments or hot environments. Valve components can be damaged by carbon buildup if the engine is frequently started and stopped in very cold temperatures. Extremely hot inlet air reduces engine performance.

Air Quality – The engine may be exposed to extended operation in an environment that is dirty or dusty, unless the equipment is cleaned regularly. Mud, dirt and dust can encase components. Maintenance can be very difficult. The buildup can contain corrosive chemicals.

Buildup – Compounds, elements, corrosive chemicals and salt can damage some components.

Altitude – Problems can arise when the engine is operated at altitudes that are higher than the intended settings for that application. Necessary adjustments should be made.

Improper Operating Procedures

- · Extended operation at low idle
- Frequent hot shutdowns
- Operating at excessive loads
- Operating at excessive speeds
- Operating outside the intended application

Improper Maintenance Procedures

- · Extending the maintenance intervals
- Failure to use recommended fuel, lubricants and coolant/antifreeze

i00651416

Starting Motor - Inspect

SMCS Code: 1451-040; 1453-040

Caterpillar Inc. recommends a scheduled inspection of the starting motor. If the starting motor fails, the engine may not start in an emergency situation.

Check the starting motor for proper operation. Check the electrical connections and clean the electrical connections. Refer to the Service Manual for more information on the checking procedure and for specifications or consult your Caterpillar dealer for assistance.

Turbocharger - Inspect

SMCS Code: 1052-040; 1052

Periodic inspection and cleaning is recommended for the turbocharger compressor housing (inlet side). Any fumes from the crankcase are filtered through the air inlet system. Therefore, by-products from oil and from combustion can collect in the turbocharger compressor housing. Over time, this buildup can contribute to loss of engine power, increased black smoke and overall loss of engine efficiency.

If the turbocharger fails during engine operation, damage to the turbocharger compressor wheel and/or to the engine may occur. Damage to the turbocharger compressor wheel can cause additional damage to the pistons, the valves, and the cylinder head.

NOTICE

Turbocharger bearing failures can cause large quantities of oil to enter the air inlet and exhaust systems. Loss of engine lubricant can result in serious engine damage.

Minor leakage of a turbocharger housing under extended low idle operation should not cause problems as long as a turbocharger bearing failure has not occurred.

When a turbocharger bearing failure is accompanied by a significant engine performance loss (exhaust smoke or engine rpm up at no load), do not continue engine operation until the turbocharger is repaired or replaced.

An inspection of the turbocharger can minimize unscheduled downtime. An inspection of the turbocharger can also reduce the chance for potential damage to other engine parts.

Note: Turbocharger components require precision clearances. The turbocharger cartridge must be balanced due to high rpm. Severe Service Applications can accelerate component wear. Severe Service Applications require more frequent inspections of the cartridge.

Removal and Installation

For options regarding the removal, installation, repair and replacement, consult your Caterpillar dealer. Refer to the Service Manual for this engine for the procedure and specifications.

Cleaning and Inspecting

- Remove the exhaust outlet piping and remove the air inlet piping from the turbocharger. Visually inspect the piping for the presence of oil. Clean the interior of the pipes in order to prevent dirt from entering during reassembly.
- 2. Turn the compressor wheel and the turbine wheel by hand. The assembly should turn freely. Inspect the compressor wheel and the turbine wheel for contact with the turbocharger housing. There should not be any visible signs of contact between the turbine wheel or compressor wheel and the turbocharger housing. If there is any indication of contact between the rotating turbine wheel or the compressor wheel and the turbocharger housing, the turbocharger must be reconditioned.
- 3. Check the compressor wheel for cleanliness. If only the blade side of the wheel is dirty, dirt and/or moisture is passing through the air filtering system. If oil is found only on the back side of the wheel, there is a possibility of a failed turbocharger oil seal.

The presence of oil may be the result of extended engine operation at low idle. The presence of oil may also be the result of a restriction of the line for the inlet air (plugged air filters), which causes the turbocharger to slobber.

- 4. Use a dial indicator to check the end clearance on the shaft. If the measured end play is greater than the Service Manual specifications, the turbocharger should be repaired or replaced. An end play measurement that is less than the minimum Service Manual specifications could indicate carbon buildup on the turbine wheel. The turbocharger should be disassembled for cleaning and for inspection if the measured end play is less than the minimum Service Manual specifications.
- **5.** Inspect the bore of the turbine housing for corrosion.
- **6.** Clean the turbocharger housing with standard shop solvents and a soft bristle brush.
- **7.** Fasten the air inlet piping and the exhaust outlet piping to the turbocharger housing.

Walk-Around Inspection

SMCS Code: 1000-040

Inspect the Engine for Leaks and for Loose Connections

A walk-around inspection should only take a few minutes. When the time is taken to perform these checks, costly repairs and accidents can be avoided.

For maximum engine service life, make a thorough inspection of the engine compartment before starting the engine. Look for items such as oil leaks or coolant leaks, loose bolts, worn belts, loose connections and trash buildup. Make repairs, as needed:

- The guards must be in the proper place. Repair damaged guards or replace missing guards.
- Wipe all caps and plugs before the engine is serviced in order to reduce the chance of system contamination.

NOTICE

For any type of leak (coolant, lube, or fuel) clean up the fluid. If leaking is observed, find the source and correct the leak. If leaking is suspected, check the fluid levels more often than recommended until the leak is found or fixed, or until the suspicion of a leak is proved to be unwarranted.

NOTICE

Accumulated grease and/or oil on an engine or deck is a fire hazard. Remove this debris with steam cleaning or high pressure water.

- Ensure that the cooling lines are properly clamped and that the cooling lines are tight. Check for leaks. Check the condition of all pipes.
- · Inspect the water pumps for coolant leaks.

Note: The water pump seal is lubricated by coolant in the cooling system. It is normal for a small amount of leakage to occur as the engine cools down and the parts contract.

Excessive coolant leakage may indicate the need to replace the water pump seal. For the removal of water pumps and the installation of water pumps and/or seals, refer to the Service Manual for the engine or consult your Caterpillar dealer.

 Inspect the lubrication system for leaks at the front crankshaft seal, the rear crankshaft seal, the oil pan, the oil filters and the valve cover.

- Inspect the fuel system for leaks. Look for loose fuel line clamps or for loose fuel line tie-wraps.
- Inspect the piping for the air inlet system and the elbows for cracks and for loose clamps. Ensure that hoses and tubes are not contacting other hoses, tubes, wiring harnesses, etc.
- Inspect the alternator belt and the accessory drive belts for cracks, breaks or other damage.

Belts for multiple groove pulleys must be replaced as matched sets. If only one belt is replaced, the belt will carry more load than the belts that are not replaced. The older belts are stretched. The additional load on the new belt could cause the belt to break.

- Drain the water and the sediment from fuel tanks on a daily basis in order to ensure that only clean fuel enters the fuel system.
- Inspect the wiring and the wiring harnesses for loose connections and for worn wires or frayed wires.
- Inspect the ground strap for a good connection and for good condition.
- Inspect the ECM to the cylinder head ground strap for a good connection and for good condition.
- Disconnect any battery chargers that are not protected against the current drain of the starting motor. Check the condition and the electrolyte level of the batteries, unless the engine is equipped with a maintenance free battery.
- Check the condition of the gauges. Replace any gauges that are cracked. Replace any gauge that can not be calibrated.

i01057943

Water Pump - Inspect

SMCS Code: 1361-040; 1361

A failed water pump might cause severe engine overheating problems that could result in the following conditions:

- · Cracks in the cylinder head
- A piston seizure
- · Other potential damage to the engine

Visually inspect the water pump for leaks. If any leaking is observed, replace the water pump seal or the water pump assembly. Refer to the Service Manual for the disassembly and assembly procedure.

Note: Refer to the Service Manual or consult your Caterpillar dealer if any repair is needed or any replacement is needed.

Warranty Section

Warranty Information

i01087950

Emissions Warranty Information

SMCS Code: 1000

This engine may be certified to comply with exhaust emission standards and gaseous emission standards that are prescribed by law at the time of manufacture, and this engine may be covered by an Emissions Warranty. A detailed explanation of the Emissions Warranty that is applicable to emissions certified engines is found in Supplement, SEBU6981, "Federal Emissions Control Warranty Information". Consult your authorized Caterpillar dealer to determine if your engine is emissions certified and if your engine is subject to an Emissions Warranty.

Reference Information Section

Engine Ratings

i00727327

Engine Rating Conditions

SMCS Code: 1000

All engine ratings are in compliance with the following standard ambient air conditions of "SAE J1349":

- 99 kPa (29.3 inches of Hg)
- · 30 percent relative humidity
- A temperature of 25 °C (77 °F)

Ratings relate to the standard conditions of "ISO8665", of "ISO3046/1", of "DIN6271", and of "BS5514".

The engine ratings are based on the following fuel specifications:

- Low heat value (LHV) of the fuel of 42 780 kJ/kg (18,390 Btu/lb) at 29 °C (84 °F)
- Gravity (API) of 35 degrees at 15 °C (60 °F)
- Specific gravity of .849 at 15 °C (60 °F)
- Density of 850 kg/m³ (7.085 lb/US gal)

The engine ratings are gross output ratings.

Gross Output Ratings – The total output capability of the engine that is equipped with standard accessories.

Standard accessories include the following components:

- Oil pumps
- · Fuel pumps
- · Water pumps

Subtract the power that is required to drive auxiliary components from the gross output. This will produce the net power that is available for the external load (flywheel).

i00819749

Engine Rating Definitions

SMCS Code: 1000

It is important to know the use of the engine so that the rating will match the operating profile. The proper rating selection is also important so that the customer's perception of price and value is realized.

In selecting a rating for a specific application, the most important consideration is the time that is spent at full throttle. These rating definitions identify the percent of time at full throttle. The definitions also identify the corresponding times below rated rpm.

Note: The examples of the applications are only for reference. For an exact determination of the appropriate rating, follow the OEM specifications or consult your Caterpillar dealer.

A Rating – This rating is used for heavy-duty applications that are operated at rated load and at rated rpm up to 100 percent. This rating is used for engines that operate without interruption of load cycling. Typical applications include the following examples: pipeline pumping and ventilation.

B Rating – This rating is used when power and/or rpm are cyclic. The engine should be run at full load. The engine should not exceed 80 percent of the duty cycle. Typical applications include the following examples: irrigation, operation where normal pump demand is 85 percent of the engine rating, oil pumping/drilling, field mechanical pumping/drilling, and stationary/plant air compressors.

C Rating – This rating is used when power and/or rpm are cyclic. The horsepower and the rpm of the engine can be utilized continuously for one hour. This is followed by one hour of operation at the A rating or below the A rating. The engine should be run at full load. The engine should not exceed 50 percent of the duty cycle. Typical applications include the following examples: agricultural tractors, harvesters and combines, off-highway trucks, fire pumps, blast hole drills, rock curshers, wood chippers with high torque rise, and oil field hoisting.

D Rating – This rating is used when rated power is required for periodic overloads. The maximum horsepower and the rpm of the engine can be utilized continuously for a maximum of 30 minutes. This is followed by one hour of operation at the C rating. The engine should be run at full load. The engine should not exceed 10 percent of the duty cycle. Typical applications include the following examples: offshore cranes, runway snow blowers, water well drills, portable air compressors, and fire pump certification power.

E Rating – This rating is used when rated power is required for a short time for initial starting or for sudden overload. The rating is also used for emergency service when standard power is not available. The horsepower and the rpm of the engine can be utilized continuously for a maximum of 15 minutes. This is followed by one hour of operation at the C rating or by the duration of the emergency. The engine should be run at full load. The engine should not exceed 5 percent of the duty cycle. Typical applications include the following examples: standby centrifugal water pumps, oil field well servicing, crash trucks, portable air compressors, and gas turbine starting motors.

NOTICE

Operating engines above the rating definitions can result in shorter service life before overhaul.

Customer Service

i02097871

Customer Assistance

SMCS Code: 1000

USA and Canada

When a problem arises concerning the operation of an engine or concerning the service of an engine, the problem will normally be managed by the dealer in your area.

Your satisfaction is a primary concern to Caterpillar and to Caterpillar dealers. If you have a problem that has not been handled to your complete satisfaction, follow these steps:

- **1.** Discuss your problem with a manager from the dealership.
- 2. If your problem cannot be resolved at the dealer level without additional assistance, use the phone number that is listed below to talk with a Field Service Coordinator:

1-800-447-4986

The normal hours are from 8:00 to 4:30 Monday through Friday Central Standard Time.

3. If your needs have not been met still, submit the matter in writing to the following address:

Caterpillar Inc.
Manager, Customer Service, Engine Division
Mossville Bldg AC
P.O. Box 610
Mossville, Illinois 61552-0610

Please keep in mind: probably, your problem will ultimately be solved at the dealership, using the dealership's facilities, equipment, and personnel. Therefore, follow the steps in sequence when a problem is experienced.

Outside of the USA and of Canada

If a problem arises outside the USA and outside Canada, and if the problem cannot be resolved at the dealer level, consult the appropriate Caterpillar office. Latin America, Mexico, Carribean Caterpillar Americas Co. 701 Waterford Way, Suite 200 Miami, FL 33126-4670 USA

Phone: 305-476-6800 Fax: 305-476-6801

Europe, Africa, and Middle East Caterpillar Overseas S.A. 76 Route de Frontenex P.O. Box 6000 CH-1211 Geneva 6 Switzerland

Phone: 22-849-4444 Fax: 22-849-4544

Far East Caterpillar Asia Pte. Ltd. 7 Tractor Road Jurong, Singapore 627968 Republic of Singapore Phone: 65-662-8333 Fax: 65-662-8302

China
Caterpillar China Ltd.
37/F., The Lee Gardens
33 Hysan Avenue
Causeway Bay
G.P.O. Box 3069
Hong Kong
Phone: 852-2848-0333

Phone: 852-2848-0333 Fax: 852-2848-0440

Fax: 81-3-5717-1177

Japan Shin Caterpillar Mitsubishi Ltd. SBS Tower 10-1, Yoga 4-Chome Setagaya-Ku, Tokyo 158-8530 Japan Phone: 81-3-5717-1150

Japan Caterpillar Power Systems, Inc. SBS Tower (14th floor) 4-10-1, Yoga Setagaya-Ku, Tokyo 158-0097 Phone: 81-3-5797-4300 Fax: 81-3-5797-4359

Australia and New Zealand Caterpillar of Australia Ltd. 1 Caterpillar Drive Private Mail Bag 4 Tullamarine, Victoria 3043 Australia

Phone: 03-9953-9333 Fax: 03-9335-3366

Ordering Replacement Parts

SMCS Code: 7567

WARNING

When replacement parts are required for this product Caterpillar recommends using Caterpillar replacement parts or parts with equivalent specifications including, but not limited to, physical dimensions, type, strength and material.

Failure to heed this warning can lead to premature failures, product damage, personal injury or death.

Quality Caterpillar replacement parts are available from Caterpillar dealers throughout the world. Caterpillar dealers' parts inventories are up-to-date. The parts stocks include all of the parts that are normally needed to protect your Caterpillar engine investment.

When you order parts, please specify the following information:

- · Part number
- Part name
- Quantity

If there is a question concerning the part number, please provide your dealer with a complete description of the needed item.

When a Caterpillar engine requires maintenance and/or repair, provide the dealer with all the information that is stamped on the Information Plate. This information is described in this Operation and Maintenance Manual (Product Information Section).

Discuss the problem with the dealer. Inform the dealer about the conditions of the problem and the nature of the problem. Inform the dealer about when the problem occurs. This will help the dealer in troubleshooting the problem and solving the problem faster.

Reference Materials

i02140374

Reference Material

SMCS Code: 1000

The following literature can be obtained through any Caterpillar dealer.

Coolants

- Special Publication, SEBD0970, "Coolant and Your Engine"
- Special Publication, PEHP4036, "Data Sheet-Extended Life Coolant"
- Special Publication, SEBD0518, "Know Your Cooling System"
- Special Publication, PEEP5027, "Label ELC Radiator Label"
- Special Publication, PEHP7057, "S·O·S Coolant Analysis"

Fuels

- Special Publication, SENR9620, "Improving Fuel System Durability"
- Special Publication, SEBD0717, "Diesel Fuels and Your Engine"

Lubricants

- Special Publication, PEDP7035, "Optimizing Oil Change Intervals"
- Special Publication, PEHP8038, "Data Sheet -Caterpillar Diesel Engine Oils (DEO) (CH-4, CG-4, CF-4) (North America and Australia)"
- Special Publication, PEHP7041, "Product Data Sheet for Caterpillar Diesel Engine Oils (DEO)" CG-4 engine oils (International markets)
- Special Publication, PEWP3014, "Cat Fluids Selector Dial (International)"
- Special Publication, PEWP9733, "Cat Fluids Selector Dial (North America)"
- Special Publication, NEDG6022, "Data Sheet -Multipurpose Lithium Complex Grease (MPG)"

- Special Publication, PEHP0002, "Data Sheet
 Multipurpose Lithium Complex Grease with Molybdenum (MPGM)"
- Special Publication, PEHP0017, "Data Sheet -Special Purpose Grease (SPG) Bearing Lubricant"
- Special Publication, NEHP5621, "How To Select The Right Grease For Any Job"
- Special Publication, PEHP6001, "How To Take A Good Oil Sample"
- Special Publication, SEBD0640, "Oil and Your Engine"
- Special Publications, PEDP7036, "S·O·S Fluids Analysis Cornerstone"

Miscellaneous

- Service Manual, SENR9595, "C-9 Industrial Engine Service Manual"
- Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations For Lubricants, Diesel Fuel, and Coolants"
- Special Publication, PECP9067, "One Safe Source"
- Special Instruction, SMHS7001, "Assembly of Fan Drive Pulley Assemblies"
- Special Instruction, SEHS7633, "Battery Test Procedure"
- Special Publication, SEBF8062, "Guideline for Reusable Parts - Procedure to Inspect and Clean Air Filters"
- Special Publication, SEBF8029, "Index to Guidelines for Reusable Parts and Salvage Operations"
- Special Publication, PEDP0026, "Power Analysis Report"
- Special Publication, NEHS0526, "Service Technology Application Guide"
- Special Instruction, SEHS9031, "Storage Procedure for Caterpillar Products"
- Specifications, SENR3130, "Torque Specifications Module"
- Special Instruction, SEHS8742, "Using the 8T-8697 Electronic Control Analyzer Programmer (ECAP)"

94
Reference Information Section
Reference Materials

- Special Instruction, SEHS8622, "Using the FT-1984 Air-To-Air Aftercooler Leak Test Group"
- Special Instruction, SEHS7332, "Warning Tag -Danger Do Not Operate"
- Special Instruction, REHS0871, "Electronic Installation Guide".

Additional Reference Material

The "Engine Fluids Data Book" can be obtained from the following locations: local technological society, local library, and local college. If necessary, consult EMA at the following address:

Engine Manufacturers Association Two North LaSalle Street, Suite 2200 Chicago, Illinois, USA 60602 E-mail: ema@enginemanufacturers.org

(312) 827-8700

Facsimile: (312) 827-8737

The "Society of Automotive Engineers (SAE) Specifications" can be found in your SAE handbook. This publication can also be obtained from the following locations: local technological society, local library, and local college. If necessary, consult SAE at the following address:

SAE International 400 Commonwealth Drive Warrendale, PA, USA 15096-0001 Telephone: (724) 776-4841

The "American Petroleum Institute Publication No. 1509" can be obtained from the following locations: local technological society, local library, and local college. If necessary, consult API at the following address:

American Petroleum Institute 1220 L St. N.W. Washington, DC, USA 20005 Telephone: (202) 682-8000

The International Organization for Standardization (ISO) offers information and customer service regarding international standards and standardizing activities. ISO can also supply information on the following subjects that are not controlled by ISO: national standards, regional standards, regulations, certification, and related activities. Consult the member of ISO in your country.

International Organization for Standardization

1, rue de Varembé Case postale 56 CH-1211 Genève 20 Switzerland

Telephone: +41 22 749 01 11 Facsimile: +41 22 733 34 30 E-mail: central@iso.ch Web site: http://www.iso.ch

European classifications are established by the Counseil International Des Machines a Combustion (CIMAC) (International Council on Combustion Engines).

CIMAC Central Secretariat Lyoner Strasse 18 60528 Frankfurt Germany

Telephone: +49 69 6603 1567 Facsimile: +49 69 6603 1566

i00912149

Maintenance Records

SMCS Code: 1000

Caterpillar Inc. recommends the retention of accurate maintenance records. Accurate maintenance records can be used for the following purposes:

- Determine operating costs.
- Establish maintenance schedules for other engines that are operated in the same environment.
- Show compliance with the required maintenance practices and maintenance intervals.

Maintenance records can be used for a variety of other business decisions that are related to engine maintenance.

Maintenance records are a key element of a maintenance program that is well managed. Accurate maintenance records can help your Caterpillar dealer to fine tune the recommended maintenance intervals in order to meet the specific operating situation. This should result in a lower engine operating cost.

Records should be kept for the following items:

Fuel Consumption – A record of fuel consumption is essential in order to determine when the load sensitive components should be inspected or repaired. Fuel consumption also determines overhaul intervals.

Service Hours – A record of service hours is essential to determine when the speed sensitive components should be inspected or repaired.

Documents – These items should be easy to obtain, and these items should be kept in the engine history file. All of the documents should show this information: date, service hours, fuel consumption, unit number, and engine serial number. The following types of documents should be kept as proof of maintenance or repair for warranty:

Keep the following types of documents as proof of maintenance for warranty. Also, keep these types of documents as proof of repair for warranty:

- · Dealer work orders and itemized bills
- Owner's repair costs
- · Owner's receipts
- · Maintenance log

Maintenance Log

SMCS Code: 1000

Table 21

Engine M	Engine Model Customer Identifier				
Serial Nu	ımber		Arrangement Number		
Service Hours	Quantity Of Fuel	Service	ce Item	Date	Authorization

Index

A		Customer Assistance Outside of the USA and of Canada	91
After Starting Engine		USA and Canada	
After Stopping Engine	43	Customer Service	
Aftercooler Core - Clean/Test		Customer Specified Parameters 22,	35
Aftercooler Core - Inspect		Cylinder Head Grounding Stud - Inspect/Clean/	
Air Compressor - Inspect	53	Tighten	64
Air Compressor Filter - Clean/Replace (If			
Equipped)	53		
Air Tank Moisture and Sediment - Drain (If		D	
Equipped)	54		
Alternator - Inspect	54	Diagnostic Flash Code Retrieval "Diagnostic" Lamp	32
		Diagnostic Lamp	
В		Driven Equipment - Check	64
Pottony Bonlano	E /		
Battery - Replace		E	
Checking After Stopping		-	
Checking Before Start-Up		Electrical System	14
Battery Electrolyte Level - Check		Grounding Practices	
Battery or Battery Cable - Disconnect		Emergency Stopping	
Before Starting Engine		Emergency Stop Button	
Belt Tensioner - Inspect (If Equipped)		Emissions Warranty Information	
Belts - Inspect/Adjust		Engaging the Driven Equipment	
Adjustment		Engine - Clean	65
Inspection		Engine Air Cleaner Element (Dual Element) -	•
Burn Prevention		Clean/Replace	65
Batteries		Cleaning the Primary Air Cleaner Elements	
Coolant		Servicing the Air Cleaner Elements	
Oils		Engine Air Cleaner Service Indicator - Inspect (If	00
	• •	Equipped)	68
		Test the Service Indicator	
C		Engine Crankcase Breather - Clean	
		Engine Description	
Cold Weather Operation	44	Aftermarket Products and Caterpillar Engines	
Cooling System Coolant (DEAC) - Change		Electronic Engine Features	
Cooling Systems with Heavy Deposits or	30	Engine Cooling and Lubrication	
Plugging	59	Engine Service Life	
Drain		Engine Specifications	
Fill	59	Welding and Caterpillar Electronic Engines	
Flush		Engine Diagnostics	
Cooling System Coolant (ELC) - Change		Engine Electronics	16
Drain		Engine Monitoring System (EMS)	
Fill		Communication Data Link	
Flush		EMS Main Unit	
Cooling System Coolant Extender (ELC) - Add		Quad Gauge Unit	
Cooling System Coolant Level - Check		Tachometer Unit	
	01	Engine Mounts - Inspect	
Cooling System Supplemental Coolant Additive	62		
(SCA) - Test/Add		Engine Oil and Filter - Change	
Add the SCA, If Necessary		Drain the Engine Oil	
Test the Concentration of the SCA	UZ	Fill the Engine Crankcase	
Cooling System Water Temperature Regulator -	60	Replace the Oil Filter	
Replace		Selection of Oil Change Interval	
Crankshaft Vibration Damper - Inspect		Engine Oil Level - Check	
Removal and Installation		Engine Oil Sample - Obtain	
Visconic Damper		Obtain the Sample and the Analysis	
Crushing Prevention and Cutting Prevention	13	Engine Operation	41

Engine Operation with Active Diagnostic Codes 34 Engine Operation with Intermittent Diagnostic	General Hazard InformationAsbestos Information	. 10
Codes 35	Containing Fluid Spillage	9
Engine Rating Conditions 89	Dispose of Waste Properly	
Engine Rating Definitions 89	Fluid Penetration	
Engine Ratings 89	Pressure Air and Water	
Engine Starting 14, 36	General Information	. 17
Ether 14		
Engine Stopping 14, 42		
Engine Storage Procedure - Check	Н	
Engine Valve Lash - Inspect/Adjust		
Engine Valve Rotators - Inspect	Hoses and Clamps - Inspect/Replace	. 79
•	Replace the Hoses and the Clamps	. 79
F		
Fan Drive Rearing Tubricate 74	ı	
Fan Drive Bearing - Lubricate	Important Cafaty Information	2
Fault Logging	Important Safety Information	2
Fire Drayantian and Explanian Drayantian 11		
Fire Prevention and Explosion Prevention		
Ether	J	
Fire Extinguisher	Landard Water Handard Olanda	
Lines, Tubes and Hoses	Jacket Water Heater - Check	. 80
Foreword		
California Proposition 65 Warning 5		
Literature Information	L	
Maintenance 4	1.60	
Maintenance Intervals	Lifting and Storage	. 23
Operation 4		
Overhaul 4		
Safety 4	M	
Fuel and the Effect from Cold Weather 44		
Fuel Related Components in Cold Weather 45	Maintenance Interval Schedule	
Fuel Filters	Maintenance Log	
Fuel Heaters 45	Maintenance Records	
Fuel Tanks 45	Maintenance Section	
Fuel System - Prime	Manual Stop Procedure	
Engines that are Equipped with a Fuel Priming	Model View Illustrations	
Pump 75	Model Views	
Engines that are Not Equipped with a Fuel Priming	Mounting and Dismounting	. 13
Pump 75		
Fuel System Primary Filter (Water Separator)		
Element - Replace 76	0	
Replace the Element		
Fuel System Primary Filter/Water Separator -	Operation Section	
Drain 76	Ordering Replacement Parts	. 92
Fuel System Secondary Filter - Replace	Overhaul Considerations	
Fuel Tank Water and Sediment - Drain 78	Oil Consumption as an Overhaul Indicator	. 80
Drain the Water and the Sediment	Overhaul Recommendation	. 80
Fuel Storage Tanks 78		
Fuel Tank 78	D.	
	Р	
G	Plate Locations and Film Locations	
	Information Plate (2)	
Gauges and Indicators	Serial Number Plate (1)	
	Power Take-Off Clutch - Check/Adjust/Lubricate	
	Product Identification Information	
	Product Information Section	
	Product Lifting	
	Product Storage	23

R		w	
Radiator - Clean	83	Walk-Around Inspection 8	36
Radiator Restrictions	44	Inspect the Engine for Leaks and for Loose	
Reference Information Section	89	Connections 8	36
Reference Material	93	Warranty Information 8	38
Additional Reference Material		Warranty Section 8	
Coolants	93	Water Pump - Inspect 8	36
Fuels	93	Welding on Engines with Electronic Controls 1	7
Lubricants	93	0 0	
Miscellaneous			
Reference Materials			
Refill Capacities			
Refill Capacities and Recommendations			
Coolant			
Engine Oil			
Fuel			
Lubricating Grease			
S			
Safety Messages	6		
Safety Section			
Sensors and Electrical Components			
Atmospheric Pressure Sensor			
Coolant Temperature Sensor			
Crankshaft Position Sensor and Camshaft Position			
Sensor			
Engine Oil Pressure Sensor			
Engine Oil Temperature Sensor			
Failure of Sensors			
Injection Actuation Pressure Sensor	-		
Inlet Air Temperature Sensor			
Programmable Monitoring System (PMS)			
Sensor Locations			
Throttle Position Sensor			
Turbocharger Outlet Pressure Sensor			
Severe Service Application - Check			
Environmental Factors			
Improper Maintenance Procedures			
Improper Operating Procedures			
Starting Motor - Inspect			
Starting the Engine			
Air Inlet Heater			
Cold Weather Starting			
Ether Injection System			
Initial Inspection			
Problems with the Wiring Harness			
Starting Problems			
Starting with Jump Start Cables			
Stopping the Engine			
Т			
	•		
Table of Contents			
Turbocharger - Inspect			
Cleaning and Inspecting			
Removal and Installation	გ ე		

Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Date:	!		
Product	Information		
Model:			
Product Identifi	ication Number:		
Engine Serial N	Number:		
Transmission S	Serial Number:		
Generator Seri	al Number:		
Attachment Se	rial Numbers:		
Attachment Info	ormation:		
Customer Equi	pment Number:		
Dealer Equipm	ent Number:		
Dealer In	formation		
Name:		Branch:	
Address:			
	Dealer Contact	Phone Number	Hours
Sales:			
Parts:			
Service:			