


Users guide and maintenance manual for the generating sets

Model(s) : G200

Control device: Intellisys



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.

Réf. constructeur : 33501185901

Réf. GPAO : 33501185901NE

Revised (10-12)



Users guide and maintenance manual

All generating sets
General considerations
Safety instructions

Réf. constructeur : MUE-IR A

Réf. GPAO : 33522051901

1. Preamble.....	4
1.1. Introduction	4
1.1.1 General recommendations	4
1.1.2. Structure of the reference material	5
1.2. Pictograms and their meanings.....	5
1.3. Safety instructions and regulations	7
1.3.1 General advice.....	7
1.3.2 Risks related to feed gas (concerns gas sets).....	9
1.3.3 Risks related to exhaust gases and fuels.....	9
1.3.4 Risks related to toxic products	10
1.3.5 Risk of fire, burns and explosion	10
1.3.6 Risks related to electrical networks.....	11
1.3.7 Dangers presented by electric currents (first aid).....	12
1.3.8 Risks related to moving the set	12
1.3.9 Recommendation for the operator and environment.....	13
1.4. Identifying sets.....	14
2. Installation.....	16
2.1. Unloading	16
2.1.1 Safety during unloading	16
2.1.2 Example of material	16
2.1.3 Instructions for unloading	16
2.1.3.1 Slings.....	16
2.1.3.2 Fork lift truck	17
3. Installation of mobile site sets.....	18
3.1 Specific arrangements.....	18
4. Road trailer.....	19
4.1 Trailer linkage	19
4.2 Check before towing.....	20
4.3 Driving.....	20
4.4 Unhitching the trailer.....	20
4.5 Implementation for installation	21
5. Battery maintenance.....	22
6. Fuel and consumables.....	23
6.1 Circuit capacities – Mitsubishi engines	23
6.2 Circuit capacities – John Deere engines.....	24
6.3 Circuit capacities – Volvo engines	25

Attached documents

User manual for the control unit

User and maintenance manual for the engine

User and maintenance manual and spare parts catalogue for the alternator

Wiring diagrams (supplied with the electrical generating set)

Genset parts catalog.

1. PREAMBLE

1.1. Introduction

1.1.1 General recommendations

Thank you for choosing an electrical generating set from our company.

This manual has been designed to help you operate and maintain your electrical generating set correctly.

Read the safety instructions carefully in order to prevent any accident, incident or damage. These instructions must always be followed.

In order to obtain optimum efficiency and the longest possible life for the electrical generating sets, maintenance operations must be carried out according to the periods indicated in the attached preventative maintenance tables.

If the electrical generating set is used under dusty or unfavourable conditions, some of these periods will be shorter.

Ensure that all adjustments and repairs are carried out by personnel who have received the appropriate training. The dealers are suitably qualified and can answer all of your questions. They can also supply you with spare parts and other services.

The left and right sides can be seen from the back of the electrical generating set (the radiator is at the front).

Our electrical generating sets have been designed so that damaged or worn parts can be replaced by new or reconditioned parts thereby reducing the out of action period to a minimum.

For all parts replacement, contact your nearest dealer representing our company who will have the necessary equipment and properly trained and informed staff to carry out maintenance, parts replacement and even total reconditioning of generating sets.

Contact your local dealer for the available repair manuals and to make the necessary arrangements for training personnel in implementation and maintenance.

IMPORTANT

Some user manuals and maintenance manuals for the engines fitted to the electrical generator assemblies include information on the control units and detail the engine starting and stopping procedures.

As the electric generator assemblies are fitted with assembly-specific test and control panels, only the information in the documentation regarding the panels fitted to the assemblies should be taken into consideration.

1.1.2. Structure of the reference material

The reference material delivered with the generating sets enables you to get to know the equipment, operate it and maintain it, both on a daily basis and periodically.

The reference material for the engines and alternators fitted to the sets consists of engine user and maintenance manuals (from the manufacturer) and alternator user and maintenance manuals (from the manufacturer).

The reference material contains:

- the user and maintenance manual, containing among other things:
 - o general recommendations and safety regulations to be adhered to
 - o general recommendations for installing generating sets
 - o tables of capacities (lubricants and coolants) and fuel tanks of different engines that may be fitted to the sets according to their configurations
 - o general reference material for maintaining starter batteries
- user and maintenance manual for the engine fitted to the set
- maintenance manual for the alternator fitted to the set
- user manual for the control panel
- wiring diagrams (these diagrams are delivered with the generating set)

1.2. Pictograms and their meanings



Warning danger



Warning, risk of electric shock



Warning, toxic materials



Warning, pressurised liquids



Warning, high temperature, risk of burns



Publications delivered with the generating set must be referred to



Protective clothing must be worn



Your eyes and ears must be protected



Periodic maintenance must be carried out



Battery level must be checked



Warning, rotating or moving parts (risk of getting caught in the machinery)



Warning, corrosive product



Warning, risk of explosion



Entry prohibited to non-authorised persons



Power



Earth



Lifting point required



Stacking point required



Naked flames and unprotected lights prohibited.
No smoking



Exinction by water prohibited



When on a trailer,
earth the set before
starting it



Emergency cut-out

Application of EU Machine Directive 98/37 of 22 June 1998 in relation to generating sets.

- access restricted to authorised personnel only according to the legislation in force
- live installation: possible automatic start-up.

1.3. Safety instructions and regulations

THESE SAFETY PRECAUTIONS ARE IMPORTANT

If you do not understand or have any questions about any point in this manual, contact your dealer who will explain it to you or give you a demonstration. A list of risks and precautionary measures to take follows. You should also refer to any local and national regulations that apply in accordance with your own jurisdiction.

1.3.1 General advice

- Read and understand the manuals provided with the generating set in full.
- Do not wear loose clothing and do not go near the machines when operating. Note that the fans are not clearly visible when the engine is running.
- Warn all people present to keep well back during operation.
-
- The generating set should always be controlled by an experienced person.
- Always test the generating set from the control panel.
- Follow the maintenance table and its directions.
- Never let anyone else use the generating set without having first given them the necessary instructions.
- Do not run the engine without having refitted the protective covers.
- Engine with turbocharger: never start the engine without fitting the air filter. The rotating compressor wheel in the turbocharger can cause severe physical injury. Foreign objects in the intake duct can cause mechanical damage.
- Engine with air preheating (starter components): never use starter aerosol or similar product as starter assistance.
When it comes into contact with the starter component, an explosion may occur in the inlet manifold and lead to physical injury.
- Never let a child touch the generating set, even when not in use. Avoid using the generating set in the presence of animals (can distress the animal).
- Never start the engine without an air filter or exhaust.
- Always follow current local regulations regarding generating sets and use of fuel (petrol and gas) before using your generating set.
- Never use sea water or any other electrolytic or corrosive product in the coolant circuit.



- Disconnect the battery and pneumatic starter (if there is one) before carrying out any repair, to prevent the engine from starting accidentally. Fit a panel over the controls to prevent any attempt at starting.
- Do not modify the engine.
- Only use the correct techniques for turning the crankshaft to rotate the crankshaft manually. Do not try to rotate the crankshaft by pulling or exerting force on the lever on the fan. This method can cause serious physical or material harm or damage the fan blade (s), leading to premature breakdown of the fan.
- Always use tools in good condition. Check that you have understood how to use them before starting a procedure.
- Only fit original spare parts.
- Use tools that correspond to the work being carried out.
- Clean all traces of oil or coolant with a clean cloth.
- Never use petrol or other flammable substances to clean parts. Use only approved cleaning solvents.
- Do not use a high-pressure cleaner for cleaning the engine and fittings. The radiator, hoses, electrical components etc. could be damaged.
- Avoid accidental contact with parts that reach high temperatures (exhaust manifold, exhaust)
- Engage the parking brake when the generating set on its trailer is installed on the operating site.
- When setting on a slope; check that no-one is behind the trailer.
- Protective eyewear must be worn when handling during maintenance operations. Operators should remove watches, chains, etc.

1.3.2 Risks related to feed gas (concerns gas sets)

WARNING – DANGER

The gas is explosive. It is forbidden to smoke, go near or create sparks when the tank is being filled and near to the generating set.

- Request the user technical notes and LPG or NG safety data sheets from your gas supplier.
-
- Gas installations must be installed, maintained and repaired by recognised specialists.
- Do not attempt to open, unseal or intervene in gas supply pressure relief valves and on the gas line in general.
-
- Gas supply procedures must be carried out in fresh air (outside) in accordance with local regulations, in an area well away from fire, people or animals.

1.3.3 Risks related to exhaust gases and fuels

WARNING - DANGER

generating sets should not be operated in unventilated areas.

- Always follow the local regulations in force regarding generating sets and use of fuel (petrol, diesel and gas) before using your generating set.
- Fuel filling should be carried out when the engine is stopped (except for sets with an automatic filling system)
- Engine exhaust gases are toxic: Do not operate the generating set in non ventilated areas. When installed in a ventilated area, the additional requirements for protection against fire and explosions must be observed.
- If a burnt gas exhaust leaks, the generating set may become more noisy. In order to be sure of its efficiency, you should periodically examine the burnt gas exhaust.
- Pipes must be replaced as soon as their condition requires it.

1.3.4 Risks related to toxic products

WARNING – DANGER

The corrosion inhibitor contains alkali. This substance should not come into contact with the eyes. Avoid any prolonged or repeated contact with skin. It should not be swallowed. In the event of skin contact, wash thoroughly with water and soap. In the event of contact with eyes, rinse immediately with plenty of water for at least 15 minutes. CALL A DOCTOR IMMEDIATELY. KEEP THE PRODUCT OUT OF THE REACH OF CHILDREN.

The anti-rust product is toxic and dangerous if absorbed. Avoid any contact with skin or eyes. Read the instructions on the packaging.

Glycol is a toxic product and dangerous if absorbed. Avoid any contact with skin or eyes. Read the instructions on the packaging.

- Never expose the equipment to liquid splashes or rainfall, and do not place it on wet ground.
- Always use the recommended fuels. Using low quality fuels risks damaging the engine and altering performance
- The battery electrolyte is harmful to skin and especially eyes. If splashes get into eyes, rinse immediately with running water and/or a 10% diluted boric acid solution.
- Wear protective eyewear and strong base resistant gloves for handling the electrolyte .

1.3.5 Risk of fire, burns and explosion

WARNING – DANGER

The engine should not be operated in areas containing explosive products. There is a risk of sparks forming where all electrical and mechanical components are not shielded.

- Beware of creating sparks or flames and do not smoke near batteries as the electrolyte gases are highly flammable (especially when the battery is being filled). Their acid is also harmful to the skin and particularly the eyes.
- Never clean, lubricate or adjust an engine when it is in operation (unless you are qualified to do so, in which case extreme care must be taken to avoid accidents)
- Never make adjustments that you are not familiar with.
- Never cover the generating set with any material while it is working or just after it stops (wait until the engine has cooled)
- Do not touch hot components such as the exhaust pipe and do not put combustible material on them.
- Keep all flammable or explosive products (petrol, oil, cloth, etc.) well away when the set is running.

- Good ventilation is required for your generating set to work properly. Without ventilation, the engine will quickly reach an excessive temperature that could lead to accidents or damage to the equipment and surrounding items.
- Do not take off the radiator cap when the engine is hot and the coolant is pressurised due to risk of burns.
- Depressurise the air, oil and coolant circuits, before removing or disconnecting any unions, ducts or connected components. Be aware of any possible pressure that might be present when disconnecting a device from a pressurised system. Do not look for pressure leaks manually. High pressure oil can cause physical accidents.
- Some preservative oils are flammable. Also, some are dangerous to inhale. Check that ventilation is good. Use a protective mask.
- Hot oil causes burns. Avoid contact with hot oil. Check that the system is no longer pressurised before carrying out any procedures. Never start or run the engine when the oil filling cap is off as oil may be ejected.
- Never start or run the engine when the oil filling cap is off as oil may be ejected.
- Never cover the generating set with a fine layer of oil for anti-rust protection.
- Never fill up the oil or coolant when the generating set is running or when the engine is hot.

1.3.6 Risks related to electrical networks

- The electrical equipment supplied with the generating set complies with standard NF C15.100 or the standards of the relevant countries
 - Read the manufacturer's identification plate carefully. The values for voltage, power, current and frequency are shown. Check that these values match the supply use.
 - Never accidentally touch naked wires or disconnected connections.
 - Never handle a generating set with wet hands or feet.
 - Maintain electrical wires and connections in good condition. Using equipment in poor condition can lead to electrocution and damage to equipment.
-
- Any procedure on the equipment must be carried out voltage free.
 - Electrical connections must be made in accordance with current standards and regulations in the country.
 - Do not use faulty, poorly insulated or provisionally connected wires.
 - Do not invert the positive and negative terminals of batteries when connecting them. Such an inversion can lead to severe damage to the electrical equipment. Follow the wiring diagram supplied by the manufacturer.
 - The generating set should not be connected to any other power sources, such as the public distribution network. In specific cases where there is a reserve connection to existing electrical networks, it must only be carried out by a qualified electrician, who should take the operating differences of the equipment into account, according to whether the public distribution network or generating set is being used.
 - Protection against electric shocks is ensured by an assembly of specific equipment. If this needs to be replaced, it should be by components with identical nominal values and specifications.
 - Due to strict mechanical specifications you should only use flexible resistant rubber sleeved wires, in compliance with CEI 245-4 or equivalent wires.

1.3.7 Dangers presented by electric currents (first aid)

First aid

In the event of an electric shock, cut off the voltage immediately and activate the set's emergency stop. If the voltage has not yet been cut off, move the victim out of contact with the live conductor as quickly as possible. Avoid direct contact both with the live conductor and the victim's body. Use a dry plank of wood, dry clothes or other non-conductive materials to move the victim away. The live wire may be cut with an axe. Take extreme care to avoid the electric arc that results from this.

Begin emergency procedures

Resuscitation

If breathing has stopped, begin artificial respiration at once in the same place the accident took place unless the victim or operator's life could be endangered by this.

In the event of cardiac arrest, carry out cardiac massage.

1.3.8 Risks related to moving the set

- Use lifting units to lift the generating set. Always make sure that the lifting equipment is in good condition and has a sufficient lifting capacity.
- In order to work in complete safety and prevent the components fitted to the top of the engine from being damaged, the engine should be lifted with an adjustable boom. All chains and cables should be parallel to one another and as perpendicular as possible to the top of the set.
- If other equipment fitted to the generating set alters its centre of gravity, special lifting devices may be required to maintain the correct balance for working in total safety.
- Never carry out work on a generating set that is suspended on a lifting device only.

1.3.9 Recommendation for the operator and environment


- Operating personnel should be aware of the safety and operating instructions. These will be regularly updated.
 - Operating should be monitored, directly or indirectly, by someone designated by the operator who is familiar with the installation and dangers and problems regarding products stored and used in the installation.
-
- Manufacturers' notes should be available to technical staff, on site if possible.
 - Written operating instructions must be available for operations that involve dangerous handling procedures and driving installations. In particular, these instructions prescribe:
 - o Operating modes
 - o Frequency of testing for safety devices and devices for handling pollution and other harmful substances generated by the installation
 - o Methods for maintenance, checking and use of adjustment equipment and safety devices.
 - The presence of dangerous or combustible materials on premises where combustion apparatus is sheltered is limited to what is required for the operation.
 - The installations must be operated under the constant supervision of a qualified person. This person should periodically check that the safety devices are working properly and ensure the correct fuel supply to the combustion apparatus.
 - Apart from combustion apparatus, flames in any form are prohibited. This should be displayed in bold on a sign.
 - Residual water, mud and waste spray is prohibited.
 - The fuels to be used should correspond to the ones in the declaration file and the specifications prescribed by the combustion apparatus manufacturer.
 - The fuel is considered as being in the physical state that is introduced into the combustion chamber.
 - Always protect your hands when detecting leaks. Pressurised fluids can enter body tissues and cause severe harm. Risk of blood poisoning.
 - Drain and discard engine oil in a designated container (the fuel distributors can collect your used oil).

1.4. Identifying sets

generating sets and their components are identified by means of identification plates.
The precise rules for identifying each major component (engine, alternator etc.) are set out in each manufacturer's documents contained in this manual.

Examples of identification plates

generating set

PLAQUE CONSTRUCTEUR / MANUFACTURER PLATE GROUPE ELECTROGENE / GENERATING SET																							
		<table border="1"><tr><td>Type</td><td>G200</td></tr><tr><td>Execution</td><td>IV</td></tr><tr><td>Version</td><td></td></tr><tr><td>Masse (Kg)</td><td>2980</td></tr><tr><td>Weight</td><td></td></tr></table>				Type	G200	Execution	IV	Version		Masse (Kg)	2980	Weight									
Type	G200																						
Execution	IV																						
Version																							
Masse (Kg)	2980																						
Weight																							
<table border="1"><thead><tr><th>V</th><th>Hz</th><th>rpm</th><th>Cos Phi</th><th>Phase</th></tr></thead><tbody><tr><td>400/230</td><td>50</td><td>1500</td><td>0.8</td><td>3</td></tr></tbody></table>						V	Hz	rpm	Cos Phi	Phase	400/230	50	1500	0.8	3								
V	Hz	rpm	Cos Phi	Phase																			
400/230	50	1500	0.8	3																			
<table border="1"><thead><tr><th></th><th>PRP</th><th>ESP</th></tr></thead><tbody><tr><td>Kva</td><td>180</td><td>198</td></tr><tr><td>Kw</td><td>144</td><td>158.4</td></tr><tr><td>A</td><td>260</td><td>286</td></tr></tbody></table>			PRP	ESP	Kva	180	198	Kw	144	158.4	A	260	286	<table border="1"><thead><tr><th>Ambiance(°C)</th><th>Alt(m)</th></tr></thead><tbody><tr><td>Ambiant</td><td></td></tr><tr><td>25</td><td>1000</td></tr></tbody></table> <p>PRP: Puissance Principale / Prime Power ESP: Service Secours / Standby Duty</p>				Ambiance(°C)	Alt(m)	Ambiant		25	1000
	PRP	ESP																					
Kva	180	198																					
Kw	144	158.4																					
A	260	286																					
Ambiance(°C)	Alt(m)																						
Ambiant																							
25	1000																						
<table border="1"><tr><td>Année / Year</td><td>2002</td></tr></table>		Année / Year	2002	<table border="1"><tr><td>Numéro de Série / Serial Number</td><td>020002009371</td></tr></table>				Numéro de Série / Serial Number	020002009371														
Année / Year	2002																						
Numéro de Série / Serial Number	020002009371																						
INGERSOLL-RAND Co. Ltd. - Hindley Green Wigan UK																							

CEE 84-536 PUISSANCE ACOUSTIQUE / SOUND POWER	
L_{WA}	98.5
Numéro Homologation M216.6068HF160.	

PRESSION ACOUSTIQUE / SOUND PRESSURE					
dB(A)	1 m			7 m	15 m
	50 HZ	80.5	71	67	
	60 HZ	87	77	73	

020002009371	
INGERSOLL-RAND	
020002009371	
INGERSOLL-RAND	

S/N	020002009371
TYPE	G200
Année / Year	2002

Engines


JOHN DEERE	
Engine Serial Number *CD4045T123456*	
CD4045TF150	Abs. Coeff. X.XX
DEERE & COMPANY MOLINE, ILLINOIS MADE IN FRANCE	

VOLVO PENTA	
ENGINE MODEL	XXXXXXXX
SPEC. NO.	XXXXXX
SERIAL NO.	XXXXXXXXXX
RATED NET POWER without fan kW/hp	XXX/XXX
with fan kW/hp	XXX/XXX
SPEED AT RATED POWER rpm	XXXX
PRELIFT mm/INJ. TIMING	X,X+X,X/XX±X,X°
MADE IN SWEDEN 3826077	

Alternator


ALTERNATEURS PARTNER ALTERNATORS

LSA	44.2S7 C 6/4	Date	01/14
N°	117204 / 9		60 Hz
Min-1/R.P.M.	1800	Protection	IP23
Cos Ø / P.F.	0,8	Cl.ther./Th.class	H
Régulateur/A.V.R.	R438 LS/C	AREP	
Altit. < 1000m	Masse/Weight	440 Kg	
Rlt AV/D.E bearing			
Rlt AR/N.D.E bearing	6309 2RS		
Graisse/Grease	Ecco UNIREX N3		
Valeurs excit/Excit.values		480 V / 40°C	
on charge / full load	17,78 V / 3,84 A		
à vide / at no load	0,95 A		

PUISSANCE / RATING						
Tension Voltage	480	440	415	240	208	240 V
Phase	3	3	3	3	3	1
Conn.						ZZ
Cont.	150	135	130	150	130	78 kVA
Base	120	108	104	120	104	62.4 KW
40°C	180	177	180	361	361	325 A
Secours	155	150	144	165	144	87 kVA
Std by	132	120	115	132	115	69.6 KW
27°C	198	197	200	397	400	363 A



LR 57008



Conforme à C.E.I 34-1(1994). According to I.E.C 34-1(1994).

Made by Leroy Somer - 1 024 93046

2. INSTALLATION

2.1. Unloading

2.1.1 Safety during unloading

In order to unload generating sets from their transport mountings, under optimum conditions of safety and efficiency, you should check that the following points are being followed correctly.

- Suitable lifting vehicles or equipment for the work.
- Slings positioned in the rings provided for this procedure or lifting arms resting fully underneath the frame cross beams.
- Suitable ground to accommodate the load of the set and lifting vehicle, without strain (if not, put down sufficiently strong and stable boards).

Remove the set as close as possible to its place of use or transport, in a clear space with free access.

2.1.2 Example of material

- crane, slings, lifting beam, safety hook, shackles.
- fork lift truck.

2.1.3 Instructions for unloading

2.1.3.1 Slings


- attach the lifting vehicle slings to the rings on the generating set designed for this procedure.
- hang the slings carefully.
- check that the slings are correctly attached and the equipment is solid.
- lift the generating set carefully.
- direct and stabilise the set towards the chosen position.
- carefully set down the equipment while continuing to position it.
- release the slings, then detach and remove the lifting rings.

2.1.3.2 Fork lift truck

- position the arms of the fork lift under the frame, making sure that only the cross beams are resting on the arms.
- lift and handle the equipment carefully.
- set down the generating set in its unloading position.



It is recommended to use a fork lift truck with arms that are longer than the width of the frame



3. INSTALLATION OF MOBILE SITE SETS

3.1 Specific arrangements

An area will be reserved to install the generating set. Its should be flat and strong enough so that the generator does not sink into it. It could be made of concrete or even large planks fitted together.

It should be noted that a generating set that does not rest correctly on its base (frame or trailer) will be subject to vibrations that could cause damage to all the equipment.

The location of the set on site should be chosen for ease of fuel supply and distribution of current to the users.

Access to the set's doors should be available at all times for safety and maintenance reasons. Ventilation of the generating set should not be affected if there are different objects close by. It will cause abnormal heating and reduced power.

Burnt gas evacuation will take place in such a way that there is no reaspiration into the air filter or cooling system.

The generating set's neutral speed must be used to protect people.

Earthing is carried out using a metal post buried deeply in the ground.

These sets are to be covered or protected from bad weather by a suitable construction (see previous sections).

Examples of problems that may be encountered :




Incorrect exhaust and ventilation




Ground too uneven or soft.
Set incorrectly positioned



Reduced access



Fuel filling impossible



Opening cover doors impossible

4. ROAD TRAILER

4.1 Trailer linkage

Before attaching the trailer, check the trailer hook on the tow vehicle; it should fit the trailer ring perfectly.

WARNING – DANGER





Trying to tow a trailer with a non-matching device (bar, wires, cords, etc.) could lead to serious accidents.

Also check:

- no incipient fractures or excessive wear on the hitching system.
- locking system is operating properly

To hitch the trailer, proceed as follows:

- lock the wheels to stop the trailer from moving
- lift up the rear trailer supports and lock them
- release the parking brake
- release the locking levers for the draw bar arms and adjust the ring to the same height as the vehicle hook
- hitch the trailer, remove the locks on each side of the wheels then lift up the front wheel fully using its handle
- connect the electrical circuit of the trailer to that of the tow vehicle
- hook the handbrake safety wire onto the hook on the tow vehicle.



4.2 Check before towing

Before towing carry out the following checks:

- wheel torquing
- lock trailer hook
- tyre pressure
- light signals working
- cover doors closed
- parking brake off
- front wheels and rear supports lifted.
- tightening and fixing the draw bar arms locking levers
- brake test for "road" type trailers
- fitting brake safety cable.

4.3 Driving

- "On-site" type trailer

These trailers are not fitted with a main brake and so cannot brake when operating; the tyres are designed for a speed of 17 mph (27 Km/h). Therefore, it is absolutely forbidden to exceed this speed .

- "Road" type trailer

The driving speed should be adapted to road conditions and the trailer handling.

Driving at sustained speed causes tyres to heat up; therefore it is important to stop from time to time to check them. Excessive heating can lead to a blow out and hence a serious accident. When reversing, do not forget to lock the overrun brake.

NOTE

Particular attention must be paid to wheel torquing on new vehicles. Indeed, during the first few miles, heat build-ups on the wheel hubs and brake drums lead to reduced wheel torquing. It is therefore essential to check the torquing every 6 miles (10 kilometres) until no further loosening is noted.

The torque test should nevertheless be carried out before towing.

4.4 Unhitching the trailer

This operation should be carried out on horizontal, flat, stable ground.

- lock the wheels
- lower the front wheel
- disconnect the road signals wire
- refit the hitch using the wheel to release the hook ring from the tow vehicle,
- release the tow vehicle
- engage the handbrake.

4.5 Implementation for installation

Procedures to be carried out:

- check that the ground is strong enough for the assembly not to sink into it
- using the front wheel, position the set as horizontally as possible
- engage the handbrake.
- lower the rear trailer supports and lock them

5. BATTERY MAINTENANCE

WARNING – DANGER

- install the battery so that it has the correct ventilation
- never place the battery close to a flame or fire
- use only insulated tools
- never use sulphuric acid or acid water to top up the electrolyte level.

PROCEDURE FOR TESTING STARTER BATTERIES

TEST TYPE	PROCEDURE	RESULT	ACTION
1 VISUAL INSPECTION STEP 1	TRAY AND TERMINALS	CHECK THAT THE TRAY IS NOT BROKEN, THAT THERE IS NO ELECTROLYTE LEAK AND CHECK THE CONDITION OF THE TERMINALS (DAMAGED, BLACK)	DAMAGE NOTED → REPLACE THE BATTERY NO DAMAGE → CHECK THE ELECTROLYTE LEVEL
	ELECTROLYTE LEVEL	BELOW THE PRESCRIBED LEVEL	ADD WATER UP TO THE PRESCRIBED LEVEL, CHARGE FOR 4-5 HOURS AT 1/10 OF THE NOMINAL CAPACITY THEN CHECK THE ELECTROLYTE DENSITY (step 2)
		PRESCRIBED LEVEL OK	CHECK THE ELECTROLYTE DENSITY (step 2)
2 ELECTROLYTE DENSITY TEST STEP 2		< 1.22 kg/l OR VARIATION ABOVE 50 g/l BETWEEN CELLS	REPLACE THE BATTERY
		RECHARGE THE BATTERY FULLY	
		> 1.22 kg/l	CARRY OUT QUICK ELECTRICAL PERFORMANCE TESTS (step 3)
3 TEST OF QUICK ELECTRICAL PERFORMANCES STEP 3		CHECK THE BATTERY USING A MIDTRONICS, WEGA OR SIMILAR TYPE OF TESTER	THE TESTER GIVES A POSITIVE RESULT → FIT TO OPERATE THE TESTER GIVES A NEGATIVE RESULT → REPLACE THE BATTERY

6. FUEL AND CONSUMABLES

All specifications (product features) are given in the engine and alternator maintenance manuals attached to this manual.

6.1 Circuit capacities – Mitsubishi engines

Engines CIRCUIT AND TANK CAPACITY	S4L2-SD (series SL)	S4Q2 (series SQ)	S4S (series SS)	
	MODEL	G 16	G 22	G 33
	LUBRICATION (in litres)	5.4	5.5	10
	COOLING (in litres)	4.9	8.1	8.9
	FUEL (in litres)	100	100	100

6.2 Circuit capacities – john Deere engines

Engines CIRCUIT AND TANK CAPACITY	3029TF120	4045TF120	4045HF120	6068TF220	6068HF120 (153kW@1500rpm)	6068HF160 (183kW@1500rpm)
MODEL	G 44	G 66 G 77	G 110	G 130	G 160	G 200
LUBRICATION (in litres)	6	13.5	13.5	21.5	21.5	31.5
COOLING (in litres)	16.1	23.6	20.2	27.3	25.8	25.8
FUEL (in litres)	100	175	200	410	410	410

6.3 Circuit capacities – Volvo engines

ENGINES					
CIRCUIT AND TANK CAPACITY	TWD 740	TAD 740	TAD 1032	TAD 1242	TAD 1631
MODEL	G 220	G 270	G 330	G 440	G 550
LUBRICATION (in litres)	29	29	36	35	64
COOLING (in litres)	41.9	36.9	37.3	44	64
FUEL (in litres)	350	700	700	800	800

User's manual

Ingersoll Rand
Control unit
Intellisys
Level 1
1.06F

Réf. constructeur

Réf. GPAO : 33502013801

SAFETY SYMBOLS



Caution : danger



Caution, refer to the publications supplied with the Genset



Caution : risk of electric shock



Protective clothing required.



Caution : toxic substances



Eye and hearings protection necessary




Caution : pressuried fluids



Periodic maintenance required



Caution : high temperature (risk of burning)



Check battery charge




Caution : rotating or moving parts (risk of entanglement)



Recommended Lifting point



Caution : risk of corrosion



Fork lift stacking point



Caution : risk of explosion




Naked flame and non protected lightning forbidden, no smoking



Authorised personnel only



Do not use water based fire extinguishers



Power



Trailer : link up the earth before starting the generator



Earth




Emergency stop

MACHINERY DIRECTIVE 98/37/CE INSTRUCTION FOR GENERATING SETS

- Access prohibited to unauthorized personnel
- Live installation, potential automatic starting.

PRESENTATION

Key



ENGLISH

Control unit
Generating set programmable control-
ler

Panel light indicator
Lighting for wall mounted or free stan-
ding panel

Emergency Stop
The genset shuts down immediately
and the control unit goes into STOP
mode

MICS AMPG
Device for electrical value display

Potentiometer volts
Adjusts the alternator voltage

Dual frequency switch 50/60 Hz
to select the frequency

Potentiometer switch
to select the voltage

FOREWORD

Control unit upgrade:

The software compatibility is ensured with the old interface boards, meaning it is possible to reprogram, on site, an interface board having a software index 1.01B with a software having an index 1.04D and 1.05E. However, a display defined for software version 1.2 and higher is required to use a software version 1.05E.

Software upgrade 1.04D comprises the following:

- Addition of functions and parameters
- Modification of standard value of certain parameters
- Modification of utilization limits of certain parameters
- Supervision and remote management
- Control/command of engines MTU 2000 and 4000
- Control/command compatible with standards NFPA110 and CSA C282
- Control/command compatible with French standards NF S 61-940 and NF E 37-312
- Control/command for Cummins engines type QST30
- Control/command for Nevada engines
- Generating sets with "multi-voltage" option
- Generating sets with "bi-frequency/bi-voltage" option
- Option 5 module (this module is only used with applications on MTU 2000/4000 engines and CUMMINS engines QST30).

The software version 1.06F used with the CB and CB12 I/O cards extends the functionality and working range of the Intellisys. A summary of the developments and changes incorporated into the new software is shown below. Each development is then described in detail in the subsequent paragraphs.

Compatibility with earlier I/O cards has been provided, and it is therefore possible to reprogram I/O cards originally using software versions 1.01B, 1.04D or 1.05E with version 1.06F, without having to remove the card.

Software version 1.06F includes the following features:

- Command and control of the JDEC electronics used with the John Deere 6081HF engines using the optional module 5.
- Command and control of the EDC III electronics used with Volvo D12 engines using the optional module 5.
- Changing the number of working hours for the generator (clear or preset) by entering a single access code.
- Option 4 of module 4, allowing operation at three different voltages (480V, 208V and 240V), may be fine tuned to reflect the customer's actual usage.
- The "low coolant level" LED of the optional module 6 comes on when either the 'low coolant level' or 'air cooling inadequate' inputs are enabled (only for NFPA110 applications).
- For gas-powered generators, the "low gas pressure" fault condition now has a five-second fixed timer. This timer prevents the engine being switched off by sudden load changes. In practice, the gas pressure has a tendency to drop when the load increases sharply, before returning to its normal value.

Supervision and remote management:

Supervision and remote management is possible using the "wintelys" software on a PC computer under a Windows 95, 98; NT or 2000 environment.

A complete document describing the supervision and remote management features can be obtained from the "products and development" department.

Supervision and remote management are operational on software version 1.01B with a few restrictions as concerns the various data acquisition and display features. In this respect, with software version 1.01B, it will not be possible to:

- Control the generator set from a remote location
- Display the status of the alarm and fault LEDs on the front panel of the display or retro-information concerning the position of the Normal/Backup switch.

In addition, with software version 1.01B, the Intellisys is automatically reset when the generating set is configured from a remote location.

For optimum use of the supervision/remote management function, we recommend that you use software version 1.04D or later.

Module 5:

Module 5 is simply module OPT345 configured as module 5.

This module is programmed specifically for the applications with engines using an integrated control electronics (MTU and Cummins engines).

The selection parameter for this module already exists in software version 1.01B.

However, a line has been added in the INPUTS and OUTPUTS screens to display the logical state of the inputs and outputs of the module according to its programming.



Supervision




Remote management

CONTENTS

Safety symbols	2
Presentation	3
Presentation and technicals characteristics	6
1. Foreword	10
1.1. Precautions	10
1.2. Power connection	10
1.3. Electric connections (control)	10
1.4. Battery preliminary inspection and commissioning	10
1.5. Control unit first power-up	11
1.6. Welcome screens	11
1.7. " Overview " screens	12
2. Operating modes	12
2.1. Stop Mode	12
2.2. Manu Mode	13
2.3. Auto Mode	13
2.4. Test Mode	13
3. Sleep mode and automatic shutdown	14
3.1. Sleep mode	14
3.2. Automatic shutdown	14
3.3. Special case	14
4. Viewing the electrical values	15
4.1. Voltages	15
4.2. Currents	16
4.3. Frequency and hours counter	16
5. Viewing the engine parameters	17
6. Display leds and lamp test	17
7. Screen contrast	18
8. Displaying the alarm and fault messages	18
8.1. Appearance of messages	18
8.2. Removing messages on screen	19
9. Displaying the status messages	19
Appendix - Software version 1.05E or later: "international" language	21
1. Introduction	21
2. Starting up the Intellisys	21
3. modifying display with international language	21
4. Display of electrical values	21
5. Display of mechanical values	22
6. Other symbols	23
7. Alarms and fault codes	24
8. Access to programming and language change functions	26

PRESENTATION AND TECHNICALS CHARACTERISTICS



1. Oil pressure fault/shutdown (red LED on).
2. Water T° fault/shutdown (red LED on).
3. Overcranking fault/shutdown (red LED on).
4. Overspeed fault/shutdown (red LED on).
5. Genset on load or ready to take the load (green LED on).
6. Charge alternator fault/shutdown (red LED on).
7. General alarm/warning (yellow LED flashing).
8. General fault/shutdown (red LED flashing).



Power on after automatic shutdown (with LED).



Button to access the main menu (programming/display)




Button to validate a selection.



Button to exit a selection



Buttons to browse through menus and adjust contrast



Number pad



Button to display the voltages.



Button to display the currents



Button to display the frequency and hours counter



Button to display the engine parameters



Button to select Auto mode (with LED).



Button to select Test mode (with LED).



Button reset a fault.



Button to select Manu mode (with LED).



Button to select Manu mode (with LED).



Button to test the LEDs (except ON button LED).

1 - Features

- Display module (DM)
- Interface board available in 2 versions (CB, CB12) depending on customer optional equipment.
- Option 3 module, option 4 module and option 5 module (OPT 345)
- Block building system enabling multiple combinations.

Note: DM required in all combinations

2 - Display module (Fig. 2)

- LCD screen, 8 lines 21 characters, built-in back-light and keyboard adjustable contrast
- 26 momentary push buttons (two types; 10 and 13 dia.)
- 13 display LEDs (alarms/warnings, faults/shutdowns, status, operating modes)
- UL approved polycarbonate case supplied with cable and connector for connection to the interface board
- Dimensions 192x144x70
- Quick installation using brackets and nuts screws
- IP65 on panel face with seal (not supplied), IP20 inside
- Extremely user friendly man-machine interface: multiple-message screens, diagnostic, genset status, ...

3 - Interface board (Fig. 1)

- CB = Main board
- CB12 = Main board with option 1 and option 2 built in
- Electronics in a sheet steel case (base + lid)
- Dimensions : 435x263x31
- Voltage bus; alternator, mains and DC built into the printed circuit board (see paragraphs 7, 8 and 9)
- 16 bit microcontroller, (Flash, RAM and EEPROM) memories, real-time clock, battery backup for time and date
- Supply from 9 to 33Volts DC and from 6Volts DC, for voltage drop at start-up
- All connections are built into the printed circuit board on both sides with full screen printing




Fig. 1 - CB12 board



Fig. 2 - Display module

4 - Logical/analog I/O

All inputs and outputs are allocated to a specific use (see tables below).

Type	Logical output description	CB	CB12
F	oil pressure	x	x
F	water temperature	x	x
A or F	day tank low fuel level	x	x
F	emergency stop	x	x
A or F	overload or short-circuit	x	x
C	water heater thermostat	x	x
C	external start-up command	x	x
F	radiator low water level	x	x
C	Mains contactor home position	x	x
C	Stand-by contactor home position	x	x
F	external emergency stop	x	x
F	oil temperature		x
F	low oil level		x
A or F	water heater failure		x
A or F	battery charger failure		x
A or F	differential or CIC trip		x
F	differential relay available		x
F	Constant Insulation Check available		x
F	air cooler disconnection		x
F	air cooler low water level		x
A or F	fuel pump 1 disconnection		x
A or F	retention bund		x
C	bulk tank CF80		x
A or F	bulk tank low fuel level		x
C	EJP switch (*)		x
C	EJP start-up (*)		x
C	EJP advanced warning (*)		x

Type	Logical output description	CB	CB12
T	fuel solenoid control	x	x
T	starter 1 control	x	x
T	engine preglow control	x	x
T	water heater control	x	x
T	hooter control (general fault)	x	x
R	Mains contactor control	x	x
R	Stand-by contactor control	x	x
T	air damper control		x
T	starter 2 control		x
R	electro-flaps control		x
T	fuel pump 1 control		x
R	CIC remote contact		x

Type	Analogue input description	CB	CB12
Ω	oil pressure indication	x	x
Ω	water temperature indication	x	x
Ω	day tank low fuel level indication	x	x
Ω	oil temperature indication		x

Type	Specific I/O	CB	CB12
ana.	charge alternator excitation	x	x

Note: Alarm or Fault selection via programming Key:

A=Alarm, F=Fault, ana.=analog, C=Control

T=Transistor, R=Relay, Ω =resistive

* : France only

5 - Option 3, 4 and 5 modules (OPT345)

- Modular case, dimensions : 160x90x58
- Programming specific to each module (dip-switch)
- 8 allocated inputs and 10 programmable outputs on option 3 for remote volt free contacts
- 8 programmable inputs and 10 programmable outputs on option 4 , with 24 preprogrammed options
- Specific programming of some entries

6 - Alternator current input

- 4-wire, unisolated, on current transformer with 5A secondary (not built into the electronics)
- Measurements in true root mean square values
- Measurement range: 60A to 5000A

7 - Alternator voltage input

- 4-wire (3ph + neutral), unisolated, with 12.5A-500Vac built in power bus in 50 and 60Hz
- Measurements in true root mean square values
- Frequency measurement on phase 1 for screen display and engine overspeed sensing

8 - Mains voltage mains 1

- 4-wire (3ph + neutral), unisolated, with 15A-600Vac built in power bus in 50 and 60Hz
- No voltage and frequency measurements

9 - Mains voltage mains 2

- 2-wire (1ph + neutral), unisolated, with 10A-240Vac built in power bus in 50 and 60Hz
- No voltage and frequency measurements

10 - Charge alternator input

- Charge alternator excitation and fault
- Starter hardware fail safe on software failure

11 - Communication

- RS485 serial port with J-Bus protocol (Mod bus RTU)
- 9-pin SUB-D connector
- Monitoring possible in local mode (≤ 1000 meters)
- Remote management possible with 2 modems (> 1000 m)
- Optional monitoring/remote management software

12 - CAN Link

- Link between interface board and option module(s)
- Standard CAN bus version 2.0b, 9-pin SUB-D connector for CC supply to module
- 1 connector on CB and CB1, 2 connectors on CB12

13 - Fuse protection

- Fn, F1, F2, F3, 12.5A-500V fuses for alternator bus
- Mains bus protected by circuit breaker in the ATS
- F5, 10A fuse for the DC bus
- F7, 2.5A delayed action fuse for the interface board
- F6, 1A delayed action fuse for option 3 Module
- F8, 1A delayed action fuse for option 4, 5 Module (CB12 only)

14 - Connections

- Multi-pin (2 to 15 pins) connectors with polarizer
- Number of connectors varies with interface board
- Each connector has a specific use

15 - Programming options

- Multiple programming possibilities
- Access code required to read/program

16 - Options connected to the interface

Option description	CB	CB12
external start-up command	X	X
auto predisposition + external command	X	X
3ph+neutral or 1ph+N mains connection	X	X
battery charger (3 possible ratings)	X	X
water heater (3 poss. depending on supply V)	X	X
hooter	X	X
RS485 for monitoring or remote management	X	X
option 3 module / CAN bus connection	X	X
additional engine kit (9 options) (*)		X
electro-flaps (DC or AC)		X
anti-condensation heater		X
EJP (switch, adv. warning and start-up) French only		X
1ph or 3ph fuel pump (control & power)		X
Air cooler (low level, disconnection)		X
differential protection and MX coil control		X
CIC protection with remote contact and MX coil control		X
bulk tank fuel pump (CF80, low level, retention bund)		X
AMPG with optional RS485		X
option 4 module / CAN bus connection		X
three-alarm (OP,WT,OT) and module 4 kit		X

*)indication and fault/shutdown for oil temperature, low oil level, water heater failure and alarm/warning for, oil pressure, water temperature, oil temperature, air damper control, starter 2 control.

17 - Sorties relais

- Max switching voltage: 250Vac (277Vac for *)
- Mains and Stand-by contactor control outputs: 4.9A, 1500VA breaking capacity at $\cos\phi=0.7$
- Electro-flaps outputs: 500mA & CIC remote contact:1A
- MX coil control output (*): 4.9A (optional relay on baseplate)

18 - Transistor outputs

- Protected against short-circuit
- Output for fuel solenoid/panel lighting: 700mA
- Other outputs: 300mA

19 - Hardware configuration

- C14/C15 connector, auxiliaries voltage selection
- C7 dip-switch, RS485 terminator
- P3 dip-switch, CAN bus terminator
- Dip-switch selection for VDE option

20 - Environment and standards

- Operating temperature: -15°C to +60°C
- Storage temperature: -20°C to +70°C
- Resistance to shocks: IK01, vibration: to CEI68-2-6
- Salt mist resistance : 96 hours according to EN68011-2-11
- Humidity : 95 % of humidity at 45°C.
- EMC :
 - Generic standards EN50081-2 and EN50082-2
 - Emissions EN55011 Class A
 - Immunity EN61000-4.2, EN6100-4.3, EN61000-4.4, EN61000-4.6, EN61000-4.8, ENV50201
- CE mark, UL listed, CSA certified

1. FOREWORD

1.1. Precautions

□ The control unit is connected to various AC voltage sources (alternator, mains, ...).



While the generating set is idle, any work inside the control equipment is strictly forbidden as some parts of the electric and electronic equipment stay live (mains voltage available).

□ If work inside the control panel is required, it must be performed by staff authorised to work live.



When the generating set is running, the fuses marked **Fn**, **F1**, **F2**, **F3** are at a dangerous potential which can lead to electric shock when touched.

These fuses must be replaced when the generating set is in complete shutdown. For any voltage measurement on these four fuses, please use suitable equipment.

□ The generating set can be equipped with a remote start-up (simple contact) or with an automatic starting system [mains failure + ATS (Mains/Stand-by changeover switch)] .



Beware of possible electric shock by contact with any live part, during the generating set start up.

1.2. Power connection

For power connection, make sure that flexible cables of suitable cross section are used to avoid overheating and a major in-line voltage drop. Depending on laying method, ambient temperature and proximity of other cables, the conductor's cross section may vary.

1.3. Electric connections (control)

□ **Generating set with manual start only** (from the control unit keyboard)

No external connection to make.

□ **Generating set with remote (without mains) or automatic (with mains) start-up**

For proper operation, make the connections on the user terminal block as per the diagram below.

☞ For DC signals, we recommend the use of a 5-core (5x1.5mm²) flexible cable between the ATS and the user terminal block.


☞ For AC signals, we recommend the use of a 12-core (12G1.5mm²) flexible cable between the ATS and the user terminal block.

(G means cable with a Green/Yellow conductor)

Note: for a remote start only, a 2x1.5mm² flexible cable is sufficient (see ① overleaf)



The cross sections above are given as a guide as they can vary depending on the current to be drawn, length, temperature and control cable laying method.



- ① External command (mains sensing or client contact)
- ② Output C/B fault auxiliary signal contact
- ③ Mains and Stand-by contactors home position
- ④ Stand-by contactor control
- ⑤ Mains contactor control
- ⑥ 1 or 3 phase water heater

□ If the user does not connect an ATS from our range, it is imperative to observe the board relay characteristics given below and to check that the coils power requirements are within these parameters.

Rated current=5A Rated voltage=250Vac
Maximum breaking capacity under a 0.7 cos φ: 1500VA



Not observing the above characteristics will damage or even destroy the board control relays.

1.4. Battery preliminary inspection and commissioning

The battery must be connected for the control unit to operate and the generating set to start, hence the need to check its connection:

- Red wire, positive polarity (+),
- Black wire, negative polarity (-).


Some generating sets are equipped with a battery isolator enabling the electric circuit to be isolated. Check that it is in the position enabling the operation.



The battery is supplied without electrolyte. Fill the battery with electrolyte at least 20 minutes before any start-up attempt (see maintenance manual).

1.5. Control unit first power-up

If the battery is connected and the electrolyte level correct, control unit powers up automatically and the initialisation screen below appears.



- This screen is visible for eight seconds. All LEDs are lit and will go out after 3 seconds except the **Power** button LED. When initialisation is complete, the **Stop** button LED comes on again.
- If other LEDs are lit or flashing, refer to paragraph 6.

Note: During initialisation, the display module software version appears on screen.

1.6. Welcome screens

□ Screen 1

After the initialisation phase, the screen below appears. The operator is then able to choose in which language he wants the messages to be displayed on the control unit screen. Four languages are available: French, English, Spanish and Portuguese.

LANGUAGE SELECTION	
V: Valid Esc: Exit	
■ International	
o French	
o English	
o Spanish	
o Portugues	

The language selection screen is then displayed. The cursor flashes by default on "international". If no action is taken while the four squares are displayed in the small overlaid window, the Intellisys is automatically positioned on the international language. You then have around 6 seconds to change the language by pressing the → button then the **Enter** or **Exit** button (*).

(*) By pressing the **Enter** button, you store the selected language in memory meaning that the next time you power up the unit, the cursor will automatically go to the previously selected language. In addition, when you press the **Enter** button, the system goes to the next screen for modification of the date and time.

(*) If you press the **Exit** button, the selected language is not stored in memory. The next time the unit is powered up, the cursor will automatically be positioned on the international language.

- By pressing → or ←, the operator places the cursor over the required language. Note : Depending on the cursor position, the text of the two upper lines changes to enable the operator to know where he is.

Press **Exit** to go directly to the " overview " screen (see paragraph 1.7).

There, the language used will be the one where the cursor was positioned.

Example : Cursor positioned over **English**. Pressing **Exit** configures the control unit in English. Any messages will appear be in English.

- If neither **Enter** nor **Exit** is pressed, the " overview " screen (see paragraph 1.7) appears automatically after three minutes. There, the language used will be the one where the cursor was positioned.

Not until the appearance of the " overview " screen will it be possible to start the generating set, however all inputs stay active (example: appearance of a fault).

- Press **Enter** to go to the second welcome screen, in the language where the cursor was before pressing **Enter**.

Note: If the "international" language is selected, refer to the "international language" appendix.

□ Screen 2

Screen 2 will allow the date and time to be modified. This is only required when the clocks change because the internal clock is kept active by a lithium battery while control unit is powered off.

DATE / TIME	
V: Valid Esc: Exit	
■ Day	: 12
o Month	: 01
o Year	: 2000
o Hour	: 16
o Minute	: 30

- The cursor ■ flashes over the o sign of the first line.
- Press → to move the cursor to the next line, except if it flashes next to **Minute**.
- Press ← to move the cursor to the previous line, except if it flashes next to Day.
- By pressing → or ←, the operator places the cursor on the line to be changed.

By following the instructions below, it is possible to change, line after line, the day, month, year, hours and minutes.

- Press **Enter** to take the cursor to the first digit after the : sign. By pressing one of the ten buttons **0** to **9**, the first digit is modified and the cursor is automatically moved to the second digit.

The cursor can be moved to the second digit by pressing → instead of one of the ten digits **0** to **9**. Afterwards, it can be moved back to the first digit by pressing ←.

Note: the year has four digits.

- Press **Enter** again to take the cursor back to o and to validate the entry made.
- When the cursor is positioned over one of the digits, press **Exit** to bring it back to o, without saving the entry made or without changing the previous value if there was no entry.
- Press **Exit** without any entry to go to the " overview " screen (see paragraph 1.7). There, the date and time taken into account will be the ones appearing on the screen before **Exit** was pressed.



When the clocks change, if you press **Exit** without changing the date and time, the generating set alarms, faults and status will not be correctly date and time stamped.

- Press **Exit** after changing one of more parameters (hour, minute,...) to go to the " overview " screen (see paragraph 1.7). There, the time and date taken into account will be those which were modified on screen before **Exit** was pressed.

If neither **Enter** nor **Exit** is pressed, the " overview " screen appears after three minutes. There, the time and date will be those of the previous screen (before going automatically to the " overview " screen).

Note : Not until the appearance of the " overview " screen will it be possible to start the generating set, however all engine protection shut-downs stay active (example: appearance of a fault).

1.7. " Overview " screen

The " overview " screen is the screen which appears systematically by default.

Using the four buttons: **V, A, Hz, Engine**, you can access all " overview " type screens (see paragraphs 4 and 5) which give details on:

- Electrical values and engine parameters
- Generating set alarms and faults
- Status of the generating set and its auxiliaries, date and time

□ Normal operation

Following the language selection screen and/or possible date and time modification screen, the " overview " screen below appears during normal operating conditions.

Fuel Lev(%)	50
E.Speed(RPM)	0
Batt. (Volts)	24.2
ext command=0	16:45
gen stopped	12/01/00

- The first line indicates the fuel level, in %, in the day tank.
- The second line indicates the engine speed in RPM.
- The third line indicates the battery voltage in Volts.
- The fourth and fifth lines indicate the generating set status, the time, date and various other messages (see paragraph 9).

- If the cabling of the fuel level analogue input is faulty or if the sensor itself is faulty, there will be no digital indication on screen. However, the wording **Fuel Lev(%)** will appear (see also paragraph 5). This particular display is used to perform a quick diagnostic on the physical status of the input (sensor and cabling).

- If the fuel level analogue sensor is not available on the day tank, there will be no display on screen (see paragraph 5). This is the case for the Pacific range generating sets where the fuel level is read directly from a mechanical gauge.

Note 1 : Press successively one of the four buttons previously mentioned to modify the screen above (see paragraphs 4 and 5).

Note 2 : the date is given in day/month/year

□ Abnormal operation

During abnormal operating conditions (presence of an alarm or fault, several alarms or faults or a mixture of both), the previous screen is replaced by the following one:

Fuel Lev(%)	10
E.Speed(RPM)	0
Batt. (Volts)	24.2
Alarm Low fuel level	
ext command=0	17:25
gen stopped	12/01/00


- Two extra lines are inserted to display the malfunctions (alarms and/or faults).
- Engine parameters and electric values appear on screen in a shortened form.
- The two lower lines stay unchanged.

The display of the generating set alarms and faults is detailed in paragraph 8.

2. OPERATING MODES

The control unit has four operating modes which can be accessed via the buttons (**Stop, Start, Auto, Auto Test**) on the display module:

- Mode **Stop**
- Mode **Manu**
- Mode **Auto**
- Mode **Test**



2.1. Stop Mode

After powering up (initialization, language selection and/or possible time and date update), the control unit automatically goes into **Stop** mode. The red LED associated with the button comes on and the "overview screen" appears.

Fuel Lev(%)	50
E.Speed(RPM)	0
Batt. (Volts)	24.2
ext command=0	16:45
gen stopped	12/01/00

Example of " overview " screen in **Stop** mode.

- In this operating mode, any event appearance (alarm, fault, external command, ...) is signalled on screen. However, the generating set is stopped and automatic start-up is not possible.

Ph./ph.	U12	396
voltages	U23	390
(Volts)	U31	395
STOP mode selected		

- When the generating set is running and whatever the current mode (**Auto**, **Test**, **Manu**), press the **Stop** button to stop it instantly without any cooling down. A message appears on screen for two seconds to signal that the button has been taken into account (see screen opposite).

Note: if the engine is equipped with a water heater, the latter is not powered in **Stop** mode.

2.2. Manu Mode

- The **Manu** mode provides local control from the keyboard, ie, the operator is wholly in control of the start procedure.
 - This mode may be accessed from the **Stop** or **Auto** modes.
- The generator starts in **Manu** mode after a single press on the **Start** key. Using this function:
- The red LED usually associated with the **Start** key does not flash,
 - The message confirming the selection of **Manu** mode does not appear.

2.3. Auto Mode

Auto mode can be accessed from **Stop**, **Manu** or **Test** mode. Press the **Auto** button to select the mode and to display the left-hand side screen below for two seconds. The red LED associated with the button comes on, then the right-hand screen appears. This screen corresponds to the standby state of the generating set.

Fuel Lev(%)	50
E.Speed(RPM)	0
Batt. (Volts)	24.2
AUTO mode selected	

Fuel Lev(%)	50
E.Speed(RPM)	0
Batt. (Volts)	24.2
ext command=0	16:50
gen stand-by	12/01/00

- From the waiting screen, the generating set start-up is conditioned by:
 - ① Logical status change of the 'external command' input
 - ② Logical status change of the 'EJP advance warning' or 'EJP start-up' inputs (France only)
 - ③ Activation of the clock mode built into (if the mode is programmed).

Example: the right-hand side screen above informs of the logical status of the external start-up command (abbreviation ext **command=0** or ext **command=1**):

- External command = 0, no start-up
- External command = 1, imminent start-up possible
- When one of the three start-up conditions changes from 0 to 1 (for ① and ②) or from inactive to active (for ③), a new message informs the operator, then the generating set enters into an automatic start-up phase.
- When one of the three start-up conditions changes from 1 to 0 (for ① and ②) or from active to inactive (for ③), a new message informs the operator, then the generating set enters into an automatic shutdown phase.
- In **Auto** mode, the ATS toggle is completely automatic.

2.4. Test Mode

Test mode can only be accessed from **Auto** mode. If one of the inputs ; external command, EJP advance warning, EJP start-up, is in logical status 1 or if the clock is active, **Test** mode cannot be selected.

- If the inputs; external command, EJP advance warning, EJP start-up, are in logical status 0 or if the clock is inactive, press **Auto Test** button to select the mode and to bring up the screen below. The red LED associated with the button flashes.

Fuel Lev(%)	50
E.Speed(RPM)	0
Batt. (Volts)	24.2
TEST mode selected	
press Auto Test to confirm	

- Press **Auto Test** button again to confirm the mode, the associated red LED comes on continuously and the generating set then enters into an automatic start-up phase.
- When the red LED flashes (waiting for confirmation), the mode can be changed by selecting **Stop** mode or **Auto** mode.

- If you do not press **Auto Test** to confirm, **Auto** mode is automatically selected after two minutes.
- In **Test** mode, the ATS cannot be toggled, this is a no-load operation. The generating set operating time is indicated on screen by a time displayed in minutes and seconds which counts down automatically. When the delay elapses, the generating set shuts down without cooling and automatically goes into **Auto** mode.

Fuel Level(%)	50
E.Speed(RPM)	0
Batt. (Volts)	24.2
TEST mode	
eng. stops in:	02' 30"

Example of " overview " screen in **Test** mode

There are two minutes and thirty seconds of operation left before the generating set stops and the control unit goes into **Auto** mode.

- During operation, if one of the inputs ; external command, EJP advance warning, EJP start-up, changes logical status (from 0 to 1) or if internal clock is activated, a screen message is displayed to indicate the status change or the clock activation. The **Test** mode timer is bypassed, automatically goes into **Auto** mode, the ATS toggles and you are then back in normal **Auto** mode operation.

3. SLEEP MODE AND AUTOMATIC SHUTDOWN

Is equipped with a sleep mode and an automatic shutdown.

3.1. Sleep mode

Sleep mode is possible when is in **Stop** mode or **Auto** mode with the generating set on stand-by (*). The sleep mode starts automatically after an adjustable time if there is no status change on one of the system logical inputs, no communication with a PC or no keystroke. In this case, the back-light switches off and goes into a minimum consumption mode.

Fuel Lev(%)	50
E.Speed(RPM)	0
Batt. (Volts)	24.2
ext command=0	16:48
gen stopped	12/01/00

Example of a " overview " screen in sleep mode, the various indications stay visible on screen.

(*) Genset stopped with no external command, no EJP start-up and no clock activation.

- If one the system logical inputs changes status (alarm, fault, thermostat, external command, ...), the messages appear and the back-light switches back on.
- On the appearance of an alarm or a fault not generated by the change of state of an entry, the back-lighting does not come on again.

Note : if a low/high battery voltage alarm or fault or a CAN bus fault appears, the back-light will not switch itself back on.

3.2. Automatic shutdown

Automatic shutdown is only possible when is in **Stop** mode. In **Stop** mode, even if the back-light is switched off, the battery discharges slowly (electronics consumption) in cases where the generating set is not equipped with a battery charger.

To avoid the battery from discharging and thus the generating set from not being able to start, will shut down automatically after a delay. After shutdown, the internal clock stays active. The generating set alarm, fault and status event log is kept unchanged.



Following an automatic shutdown, can be powered up again by simply pressing the **Power** button. Initialisation is carried out in the same conditions as with a first power-up.

After powering up via the **Power** button, automatically goes into **Stop** mode and brings up the " overview " screen (see paragraph 1.7) in the language used before the automatic shutdown. This way, the operator does not need to reselect the language and press **Exit** to return to the " overview " screen.

3.3. Special case

- On the appearance of any fault condition whatsoever, the Intellisys automatically sets itself into the **Stop** mode but, at the end of the 'auto cut-off' timer (setting 108 in the Timer menu), the Intellisys remains switched on. This function is particularly useful for those applications fitted with :

- An OPT345 module, programmed for Option 3
- An optional module 6
- The Wintelys supervision and remote management software.

This feature ensures that the signals provided by these modules (free potential contact, remote module 6 control) and the monitoring software will remain available for remote operating.

4. VIEWING THE ELECTRICAL VALUES

4.1. Voltages

You can view the various AC voltages by pressing the **V** button successively. Their values are expressed in true root mean square Volts. Depending on the client's needs (type of electrical installation), several screens are possible:

- 3 phase with neutral (3ph+N)
- 3 phase without neutral (3ph)
- 2 phase (2ph+N)
- 1 phase (1ph+N)

Note: one of the four choices above has been factory programmed as per the client's specification.

☐ 3 phase with neutral (3ph+N)

Ph./ph.	U12	399
voltages	U23	400
(Volts)	U31	398
ext command=1	17:05	
gen running	12/01/00	

- Press **V** to get the three phase-to-phase voltages:
U12 = voltage across phase 1 and phase 2
U23 = voltage across phase 2 and phase 3
U31 = voltage across phase 3 and phase 1

Ph./neutr.	V1	230
voltages	V2	230
(Volts)	V3	230
ext command=1	17:05	
gen running	12/01/00	

- Press **V** again to get the three phase-to-neutral voltages:
V1 = voltage across phase 1 and neutral
V2 = voltage across phase 2 and neutral
V3 = voltage across phase 3 and neutral
- Press **V** again to bring up the first screen and so on...

☐ 3 phase without neutral (3ph)

Ph./ph.	U12	399
voltages	U23	400
(Volts)	U31	398
ext command=1	17:05	
gen running	12/01/00	

- Press **V** to get the three phase-to-phase voltages:
U12 = voltage across phase 1 and phase 2
U23 = voltage across phase 2 and phase 3
U31 = voltage across phase 3 and phase 1
- If you press **V** nothing changes.

☐ 2 phase (2ph+N)

Half	U1n	120
voltage	U2n	122
(Volts)		
ext command=1	17:05	
gen running	12/01/00	

- Press **V** to get the two half voltages:
U1n = voltage across phase 1 and neutral
U2n = voltage across phase 2 and neutral

Phase	U12	242
voltage		
(Volts)		
ext command=1	17:05	
gen running	12/01/00	

- Press **V** again to get the voltage across the two phases:
U12 = voltage across phase 1 and phase 2
- Press **V** again to bring up the first screen and so on ...

☐ 1 phase (1ph+N)

Ph./neutr.	V1	230
voltage		
(Volts)		
ext command=1	17:05	
gen running	12/01/00	

- Press **V** button to get the voltage across phase and neutral:
V1 = voltage across phase 1 and neutral
- If you press **V** again, nothing changes.

4.2. Currents

To view the various AC currents, press the **A** button successively. The values are expressed in true root mean square Amps. Depending on the client's needs (type of electrical installation), several screens are possible:

- 3 phase with neutral (3ph+N)
- 3 phase without neutral (3ph)
- 2 phase (2ph+N)
- 1 phase (1ph+N)

Note: one of the four choices above has been factory programmed as per the client's specification.

□ 3 phase with neutral (3ph+N)

Phase	I1	542
current	I2	543
(Amps)	I3	536
ext command=1 17:10		
gen running 12/01/00		

- Press **A** to get the three phase currents:
I1 = current in phase 1
I2 = current in phase 2
I3 = current in phase 3

Neutral		
current	In	23
(Amps)		
ext command=1 17:10		
gen running 12/01/00		

- Press **A** again to get the neutral current:
In = current in the neutral
- Note : the neutral current is calculated by vector summation of the three phase currents..
- Press **A** again to bring up the first screen and so on ...

□ 3 phase without neutral (3ph)

Phase	I1	542
current	I2	543
(Amps)	I3	536
ext command=1 17:10		
gen running 12/01/00		

- Press **A** to get the three phase currents:
I1 = current in phase 1
I2 = current in phase 2
I3 = current in phase 3
- If you press **A** again, nothing changes.

□ 2 phase (2ph+N)

Phase	I1	246
current	I2	238
(Amps)		
ext command=1 17:10		
gen running 12/01/00		

- Press **A** to get the two phase currents:
I1 = current in phase 1
I2 = current in phase 2
- If you press **A** again, nothing changes.

□ 1 phase (1ph+N)

Phase	I1	95
current		
(Amps)		
ext command=1 17:10		
gen running 12/01/00		

- Press **A** to get the 1 phase current :
I1 = 1 phase current
- If you press **A** again, nothing changes.

4.3. Frequency and hours counter

To view the generating set frequency and number of running hours, press the **Hz** button. Values are expressed in Hertz (Hz) and in hours respectively.

Frequency (Hz)	50.2
No hours	643
No minutes	45
ext command=1 17:10	
gen running 12/01/00	

The minutes are counted from 0 to 59 minutes; on the 60th minute, the number of hours is incremented and the number of minutes goes to 0.

Example of "overview" screen showing frequency and number of generator running hours and minutes.

Note: a maximum of 32767 running hours can be displayed. The display is in whole hours.

5. VIEWING THE ENGINE PARAMETERS

To view the engine parameters, press the **Engine** button successively. Three different screens can be viewed. The values that can be displayed on these three screens are indications only.

❑ **Screen 1** : Press the **Engine** button to get the following screen.

Fuel Lev(%)	65
E.Speed(RPM)	1502
Batt. (Volts)	12.3
ext command=	17:15
gen running	12/01/00

- The first line indicates the fuel level, expressed in %, in the day tank.
- The second line indicates the engine speed expressed in RPM.
- The third line indicates the battery voltage expressed in Volts.

❑ **Screen 2** : Press **Engine** a second time to get the following screen.

Oil Pr.(Bar)	6
Oil T.(°C)	90
WaterT.(°C)	75
ext command=1	17:15
gen running	12/01/00

- The first line indicates the oil pressure expressed in Bar.
- The second line indicates the oil temperature expressed in degrees Celsius (°C).
- The third line indicates the water temperature expressed in degrees Celsius (°C).

❑ **Screen 3** : Press **Engine** a third time to get the following screen.

Oil Pr. (PSI)	90
Oil T.(°F)	194
WaterT. (°F)	167
ext command=1	17:15
gen running	12/01/00

- The first line indicates the oil pressure expressed in PSI (pound per square inch).
- The second line indicates the oil temperature expressed in degrees Fahrenheit (°F).
- The third line indicates the water temperature expressed in degrees Fahrenheit (°F).

• Press **Engine** again to bring up the first screen and so on ...

The first screen is the one which appears by default after the has powered up (see paragraph 1.7) or after pressing **Exit** to exit the display mode.

- If one of the sensors is not declared available (optional sensor and/or factory programming), there will be no display on screen on the line corresponding to the undeclared sensor (see screen 1).
- If the cabling of one the analogue inputs is faulty or if a sensor is faulty, there will be no digital indication on screen on the line of the corresponding sensor (see screen 2).

Oil Pr. (Bar)	6
WaterT. (°C)	75
ext command=1	17:15
gen running	12/01/00

screen 1

Oil Pr. (Bar)	
Oil T.(°C)	90
WaterT.(°C)	75
ext command=	17:15
gen running	12/01/00

screen 2

6. DISPLAY LEDS AND LAMP TEST

On the display module panel face, fifteen LEDs are used to display various generating set status, alarms and faults.

❑ A set of eight LEDs are used to display the following alarms, faults and statuses:



Oil pressure fault/shutdown (red)



Genset ready to take load (green)



Water temperature fault/shutdown (red)



Charge alternator fault/shutdown (red)



Overcranking/Fail to start shutdown (red)



General alarm (yellow)



Overspeed fault/shutdown (red)



General fault (red)

All these LEDs are identified by an ISO symbol. The last two LEDs are flashing lights. The " general fault " LED flashes on appearance of any fault and the " general alarm " LED flashes on appearance of any alarm.

□ Each blue coloured function button (**Stop, Start, Auto, Auto Test**) is associated with a LED. The operation of these four LEDs is described in paragraph 2.

□ The **0** and **1** buttons are each associated with a LED.

□ The **Power** button is associated with a LED. This LED is used to display the powering up (see paragraphs 1.5 and 3.2).

Press the **Lamp Test** button to light all the LEDs for six seconds. This is only possible on the " overview " type screens.

7. SCREEN CONTRAST

On the various " overview " type screens, the contrast of the characters displayed on screen can be adjusted via the ➡ and ⬅ buttons:

- Press ➡ to increase the contrast on screen

- Press ⬅ to reduce the contrast on screen.

Note: The contrast obtained after using the ➡ and ⬅ button is not saved when if powered down. The only way the contrast value, modified by the ➡ and ⬅ buttons, can be saved is via the **Contrast** menu.

• Contrast adjustment is especially useful when is used in severe conditions (-15°C or +60°C).

• When temperature is above +60°C, the screen is very dark. It is therefore necessary to reduce the contrast by pressing ⬅.

• When temperature is below -15°C, the screen is very light. It is therefore necessary to increase the contrast by pressing ➡.

8. DISPLAYING THE ALARM AND FAULT MESSAGES

All alarms and faults are clearly viewed on screen. Two lines are dedicated for their display (see screens below).

8.1. Appearance of messages on screen

As soon as an alarm or fault appears, the electrical values and engine parameters are displayed on screen in a shortened form.

• The first alarm is displayed on screen over the first of the two lines (screen 1).

• The first fault is displayed on screen over the first of the two lines (screen 2).

Ph./ph.	U12	400
voltages	U23	401
(Volts)	U31	398
Alarm Low Fuel Level		
ext command=1	17:30	
gen stopped	12/01/00	

screen 1

Ph./ph.	U12	0
voltages	U23	0
(Volts)	U31	0
Fault Emergency Stop		
ext command=1	17:32	
gen stopped	12/01/00	

screen 2

Ph./ph.	U12	400
voltages	U23	401
(Volts)	U31	398
Alarm Retention Bund		
Alarm Low Fuel Level		
ext command=1	17:35	
gen stopped	12/01/00	

screen 3

As soon as another alarm appears on screen 1, the first alarm message slides down to the second line and the message of the new alarm positions itself on the first line (see screen opposite).

(example : **Alarm Retention Bund**)

Ph./ph.	U12	0
voltages	U23	0
(Volts)	U31	0
Fault Low Fuel Level		
Fault Emergency Stop		
ext command=1	17:38	
gen stopped	12/01/00	

screen 4

As soon as another fault appears on screen 2, the first fault message slides down to the second line and the message of the new fault positions itself on the first line (see screen opposite).

(example : **Fault Low Fuel Level**)

Ph./ph.	U12	0
voltages	U23	0
(Volts)	U31	0
Fault Emergency Stop		
Alarm Low Fuel Level		
ext command=1	17:35	
gen stopped	12/01/00	

screen 5

If an alarm appears on screen 2, the fault message stays on the first line and the alarm message is displayed on the second line (see screen opposite).

(example : **Alarm Low Fuel Level**)

Priority is given to fault messages.

- If a fault appears on screen 3, the message on the second line disappears from the screen, the message on the first line slides down to the second line and the fault message takes the first line.
- If a third fault appears on screen 4, the message on the second line disappears from the screen, the message on the first line slides down to the second line and the third fault message takes the first line.
- If an alarm appears on screen 4, the message relating to that alarm will not appear.
- If a new alarm appears on screen 5, the message relating to that alarm will replace the alarm message on the second line.

8.2. Removing messages on screen

- If all the faults, displayed on screen or not, are no longer active (circuit-breaker pressed in, emergency stop unlocked, logical input inactive, connection restored, ...), press the **Reset** button to reset the last fault present on screen or in other words, the last recorded fault. This way, the previous fault(s) is/are moved forward one line.

The example below shows the screen changes with two faults displayed on screen and one fault not displayed but recorded. In order of appearance, the following faults are:

- Module 3 CAN
- Emergency stop
- Day tank low fuel level

The three faults are considered as no longer active (fuel level above low level, emergency stop unlocked, CAN connection restored on the option 3 module).

Ph./ph.	U12	0
voltages	U23	0
(Volts)	U31	0
Fault Low Fuel Level		
Fault Emergency Stop		
ext command=1	17:45	
gen stopped	12/01/00	

Messages **Fault Low Fuel Level** and **Fault Emergency stop** are then displayed. Press **Reset** to reset the low fuel level fault (the message disappears).

Ph./ph.	U12	0
voltages	U23	0
(Volts)	U31	0
Fault Emergency Stop		
Fault module 3 CAN		
ext command=1	17:46	
gen stopped	12/01/00	

The message **Fault module 3 CAN** then appears on the second line (see screen opposite). Press **Reset** to reset the emergency stop fault (the message disappears).

Ph./ph.	U12	0
voltages	U23	0
(Volts)	U31	0
Fault module 3 CAN		
ext command=1	17:47	
gen stopped	12/01/00	

The message **Fault module 3 CAN** then appears on the second line (see screen opposite). Press **Reset** to reset the emergency stop fault (the message disappears).

Ph./ph.	U12	●
voltages	U23	●
(Volts)	U31	●
ext command=1	17:48	
gen stopped	12/01/00	

There are no more faults but is still in **Stop** mode. As the external command is still available, the operator must select the **Auto** mode for the generating set to restart automatically.

- An alarm message will automatically disappear when the alarm input is no longer in logical status 1.

9. DISPLAYING THE STATUS MESSAGES

All status relating to the operation of the generating set and its auxiliaries are clearly viewed on the two lower lines.

As well as the date and time, the operator will be able to view:

- Operating mode selected (**Stop**, **Manu**, **Auto**, **Test**)
- Water heater control logical status (active or inactive)
- External command logical status (0 or 1)
- built-in mains failure and mains return delays
- Generating set status (genset on stand-by, stopped or running)
- Engine preglow period
- Cranking period (with attempt number and starter number)
- Starter rest period between two starting attempts, with possible indication of engine preglow
- Starter tripping (indicating starter number)
- RPM and Volts stabilising period
- Authorisation to close the Stand-by contactor in **Manu** mode

- ATS toggle delay: Mains→Stand-by and Stand-by→Mains, and closure confirmation of the Mains and Stand-by contactors- Motorised C/B opening and closure
- Engine cooling down time in **Auto** mode
- Operating time in **Test** mode
- Delayed shutdown on water temperature fault or overload/short-circuit fault
- Appearance of commands ; EJP J-1, EJP advance warning, EJP start-up
- Clock activated operation indicating time range number
- Shutdown bypass via switch (complying with French standard NFC 61940))

The three screens below show three examples of status messages displayed over the two last lines.

Fuel Lev(%)	45
E.Speed(RPM)	326
Batt. (Volts)	24.2
starting attempt1 starter1	

Starting period: attempt 1 on starter 1

Fuel Lev(%)	40
E.Speed(RPM)	1502
Batt. (Volts)	24.2
toggle delay stand-by->mains 05"	

S→N toggle: Toggle from Stand-by contactor to Mains contactor in 5 seconds

Fuel Lev(%)	39
E.Speed(RPM)	1502
Batt. (Volts)	24.2
cooling down eng. stops in: 03' 42"	

Engine cooling down: Engine to stop in 3 minutes and 42 seconds in **Auto** mode

APPENDIX - SOFTWARE VERSION 1.05E OR LATER: "INTERNATIONAL" LANGUAGE

1 - Introduction


Software version 1.05E or later used with interface boards CB and CB12 enable you to use the Intellisys in a language which is different from the four standard languages already implemented. This language is based on the use of pictograms. Compatibility is ensured with the old interface boards. This means it is possible to reprogram, on site, an interface board having software index 1.01B or 1.04D with a software having an index 1.05E. However, use of a software version 1.05E requires a display defined for software version 1.2 (see paragraph 2).

2 - Starting up the Intellisys



When the Intellisys is powered up, the initialization screen indicates the display software version. The initialization phase takes no more than 5 seconds.

Note: A display flashed to version 1.2 can be used with no problem with an interface board version 2.01B or 1.04D.



Next, the language selection screen is displayed. The cursor flashes by default on "International". If no action is taken while the four squares are displayed in the small overlaid window, the Intellisys automatically goes to the international language.

You then have around 6 seconds to change the language by pressing the → button then the **Enter** or **Exit** (*) buttons.

(*) By pressing the **Enter** button, the selected language is stored, meaning that the next time the unit is powered up, the cursor will automatically go to the previously selected language. In addition, by pressing the **Enter** button, the system goes to the next screen to modify the date and time.

(*) If you press the **Exit** key, the selected language is not stored in memory. The next time the unit is powered up, the cursor will automatically be positioned on the international language.

3 - Modifying display with international language

When the international language is selected on power up or during use:

- The time and date are no longer displayed on the screen. The time-stamped record of alarms, faults and statuses is however preserved.
- The comfort messages described in paragraph 9 of the user instructions manual, levels 1, 2 or 3, disappear. These messages are displayed on the last two lines of the screen.
- The alarms and/or faults are no longer displayed in plain language on the screen on the two lines located directly above the comfort messages, but are displayed in the form of codes in place of the time and date (see list of codes in paragraph 6).
- When an alarm or fault appears, the size of the electrical and mechanical value displays are not compressed.
- The programming display screens are accessed in the same way, the only difference is that all the screens are systematically in English.

4 - Display of electrical values

To facilitate understanding, the electrical values are not represented by pictograms.

- Press the **V** button to display the line voltages and the single voltages by pressing the button successively.


(Volts)	U12	399
(Volts)	U23	400
(Volts)	U31	398

The notations such as **U12**, **U23**, **U31**, etc. are preserved. For more information concerning the meaning of the notations, refer to the user paragraph 4.1. The Volt is the unit of measurement for the electrical voltages at the alternator terminals (screen display: **Volts**).

- Press the **A** button to display the phase currents and the neutral current by pressing the button successively.


(Amps)	I1	250
(Amps)	I2	264
(Amps)	I3	275

The notations such as **I1**, **I2**, **I3**, **In**, etc. are preserved. For more information concerning the meaning of the notations, refer to the user paragraph 4.2.





The Ampere is the unit if measurement of the currents output by the alternator (screen display: **Amps**).

■ Press the **Hz** key to display the generating set frequency and running hours and minutes.




Hz is the abbreviation for **Hertz**. Symbols 1 and 2 are represented in the table below.

Symbol number	Pictogram	Description
Symbol 1 (sinewave)		frequency of voltage output by alternator
Symbol 2 (hourglass)		number of generating set running hours and minutes

5 - Display of mechanical values

By pressing the Engine button successively, the following is displayed: oil pressure, water temperature, oil temperature, battery voltage, engine speed and fuel remaining in daily tank.



The notations: %, RPM and Volts are preserved. For more information on the meaning of the notations, refer to the user paragraph 5.









The notations: Bars and C° are preserved. For more information on the meaning of the notations, refer to the user paragraph 5.

A third screen can be accessed using the **Engine** button with Anglo-Saxon notations for the oil pressure (PSI), the water temperature (°F) and the oil temperature (°F).

Note: if the oil temperature is not selected (Sensors menu) or if the analog pack has not been selected, the symbol(s) will not appear on the screen.

All the symbols related to the engine parameters are represented in the table below.

Symbol number	Pictogram	Description
Symbol 3 (fuel pump)		Fuel level in daily tank
Symbol 4 (galvanometer)		Engine speed
Symbol 5 (generating set battery)		Battery voltage
Symbol 6 (oil can)		Engine oil pressure
Symbol 7 (thermometer with oil drop)		Engine oil temperature
Symbol 8 (thermometer with cooling fluid level)		Cooling fluid temperature

6 - Other symbols

■ Loss of system voltage (symbol 9)

Loss of the system voltage (or loss of mains) is represented on the screen by a crossed-out transformer. The micro-cutout time-delay (parameter 103 of **Timing** menu) is displayed next to this symbol and decrements automatically from the adjustment setting to 0.



(symbol 3) (%)	50
(symbol 4) (RPM)	0
(symbol 5) (Volts)	24.2
(symbol 9) : 12"	

Example of screen showing system voltage is no longer available. 12 seconds remain prior to startup of the generating set (micro-cutout time delay).

■ Return of system voltage (symbol 10)

Return of the system voltage (or mains voltage) is represented on the screen by a transformer. The mains return time delay (parameter 104 of Timing menu) is displayed next to this symbol and decrements automatically from the adjustment setting to 0.



(Amps) 11	645
(Amps) 12	680
(Amps) 13	653
(symbol 10) : 2" 15"	

Example of screen showing system voltage is again available. Two minutes and fifteen seconds remain prior to automatic switchover from the generating set to the system (mains return time delay).

Note: The two previous symbols can only be displayed provided the type 2 control parameter is at 1 (see user paragraph 2.1.1).

■ Spark plug preheating (symbol 11)

If the generating set is ready to be started on an external command and if the "spark plug preheating" parameter is set to 1 (Factory menu), a symbol representing a solenoid appears on the screen during the spark plug preheating period prior to the first startup and also between two startup attempts.



(symbol 3) (%)	50
(symbol 4) (RPM)	0
(symbol 5) (Volts)	24.2
(symbol 11)	

Example of screen showing that spark plug preheating is in operation; generating set will start in a few seconds.

■ Engine cooling (symbol 12)

When the mains return time delay is completed, the emergency contactor opens, the normal contactor closes and the engine begins its cooling period which is displayed by the symbol shown opposite. The cooling time delay (parameter 10 of timing menu) is displayed next to the symbol and decrements automatically from the adjustment setting to 0.



(Volts) U12	399
(Volts) U23	400
(Volts) U31	398
(symbol 12) : 3" 10"	

Example of screen showing that three minutes and ten seconds remain for cooling of the generating set prior to complete shutdown.

7 - Alarms and fault codes

The alarms and faults are displayed on the right hand side of the two lower lines. As a general rule, a fault or alarm is displayed on the screen as follows:

XX-Y XX is a number between 00 and 99

Y takes two values: 0 to indicate an alarm, 1 to indicate a fault (same method used in **Options** menu).

Special case 1: for a single number, it is possible to display: XX-0 or XX-1. This means that the **Options** menu must be programmed to have one or the other on the screen.

Special case 2: if the alarm or fault are possible at the same time (two different sensors used on engine), the XX numbers are different (example: engine oil pressure fault = 02-1, engine oil pressure alarm = 64-0).

Note: When the word "impossible" appears in the table on the following page, this means that the alarm or fault does not exist (example: generating set emergency stop only managed for fault and not for alarm).

(symbol 3) (%)	50
(symbol 4) (RPM)	0
(symbol 5) (Volts)	24.2
	06-1

Example of screen showing "overload or short-circuit" fault designated 06-1.

(Volts) U12	380
(Volts) U23	382
(Volts) U31	381
	12-0

Example of screen showing "alternator min voltage " alarm designated 12-0.

(símbolos 3) %	50
(símbolos 4) RPM	0
(símbolos 5) Volts	24.2
	00-1
	08-0

Example of screen showing "max. battery voltage" alarm designated 08-0 and "emergency stop" fault designated 00-1.

The alarms and faults are displayed in the same way as for versions 0.01B and 1.04D:

- Up to two codes (max.) displayed on screen
- Fault takes priority over alarm
- Faults are reset in order of appearance

For more details, refer to paragraph 8.

All the alarms and faults which can appear on the Intellisys screen are listed in the table below.a.

Wording	Alarm	Fault	Generated on
Generator set emergency stop	impossible	00-1	CB, CB12
External emergency stop	impossible	01-1	CB, CB12
Engine oil pressure	impossible	02-1	CB, CB12
Engine water temperature	impossible	03-1	CB, CB12
Daily fuel tank level low	04-0	04-1	CB, CB12
Radiator water level low	impossible	05-1	CB, CB12
Alternator overload or short-circuit	06-0	06-1	CB, CB12
Engine overspeed	impossible	07-1	CB, CB12
Min. battery voltage	08-0	08-1	CB, CB12
Max. battery voltage	09-0	09-1	CB, CB12
Lithium battery absent	10-0	impossible	CB, CB12
Generator set no start	impossible	11-1	CB, CB12
Min. alternator voltage	12-0	12-1	CB, CB12
Max. alternator voltage	13-0	13-1	CB, CB12
Min. alternator frequency	14-0	14-1	CB, CB12
Max. alternator frequency	15-0	15-1	CB, CB12
Option 3 module CAN bus	impossible	16-1	CB, CB12
Option 4 module CAN bus	impossible	17-1	CB12
Option 5 module CAN bus	impossible	18-1	CB12
Option 6 module CAN bus	impossible	19-1	CB12
Spare			
RS485 communication	21-1	impossible	CB, CB12
Hardware watchdog	impossible	22-1	CB, CB12
Spare			
Spare			
Normal contactor open (system side)	25-0	impossible	CB, CB12
Emergency contactor open (generating set side)	26-0	impossible	CB, CB12
Oil temperature	impossible	27-1	CB, CB12
Oil level low	impossible	28-1	CB12
No water preheating	29-0	29-1	CB12
Differential trigger	30-0	30-1	CB12
Permanent insulation monitor trigger	31-0	31-1	CB12
Differential relay connection	impossible	32-1	CB12
Permanent insulation monitor connection	impossible	33-1	CB12
Battery charger fault	34-0	34-1	CB12
Air cooler trip	impossible	35-1	CB12
Air cooler low level	impossible	36-1	CB12
Fuel pump 1 trip	37-0	37-1	CB12
Retention tank	38-0	38-1	CB12
Fuel tank low level	39-0	39-1	CB12
Water flow	impossible	40-1	module 3
Fire detection	impossible	41-1	module 3
Oil leak	impossible	42-1	module 3
Fuel leak	impossible	43-1	module 3
Air cooler compartment door open	impossible	44-1	module 3
MCPS door open	impossible	45-1	module 3
Main circuit breaker open	46-0	46-1	module 3
Overload	47-0	impossible	CB12
MTU engine oil pressure	impossible	48-1	module 5
MTU engine HV water temperature	impossible	49-1	module 5
MTU engine overspeed	impossible	50-1	module 5
MTU engine general fault	impossible	51-1	module 5

Wording	Alarm	Fault	Generated on
MTU engine general alarm	52-0	impossible	module 5
QST30 engine overspeed	impossible	53-1	module 5
QST30 engine general fault	impossible	54-1	module 5
QST30 engine general alarm	55-0	impossible	module 5
Engine oil high level	56-0	impossible	module 4
Engine oil high level	impossible	57-1	module 4
Startup battery min. voltage	58-0	impossible	module 4
Startup battery charger	59-0	impossible	module 4
MX coil	impossible	60-1	module 4
Damping valve	impossible	61-1	module 4
Starter air pressure	62-0	impossible	module 4
Magneto-thermal relay	63-0	impossible	module 4
Engine oil pressure	64-0	impossible	module 4
Engine water temperature	65-0	impossible	module 4
Engine oil temperature	66-0	impossible	module 4
Fuel low level (combined in option No. 16)	67-0	impossible	module 4
Fuel high level	68-0	impossible	module 4
Fuel very low level	impossible	69-1	module 4
Fuel very high level	impossible	70-1	module 4
Oil low level	71-0	impossible	module 4
Cylinder head temperature	impossible	72-1	module 4
Thermostat water inlet temperature	impossible	73-1	module 4
No water circulation	impossible	74-1	module 4
Bearing temperature	75-0	impossible	module 4
Bearing temperature	impossible	76-1	module 4
Stator temperature	77-0	impossible	module 4
Stator temperature	impossible	78-1	module 4
Fuel pump 2 trip	79-0	79-1	module 4

(*) Special case: the "engine oil high level" indication is possible as an alarm and as a fault with two different numbers (56-0 and 57-1).

8 - Access to programming and language change functions

The programming/browsing functions are always accessed using the **Menu** button. However, the various menus and parameters are always displayed in English only (when international language is selected).

GENERAL (vers. 1.05E)	
V : Valida	Esc : Exit
Control	o Config
o Alarm/Flt	o Status
o Inputs	o Outputs
o Contrast	o Protect
o GES	

The software version number appears on the first line next to **GENERAL**. All the texts are in English.

By pressing the **Menu** button for at least three seconds, the first screen is displayed to allow you to change the language, and possibly the time and date.

Use and maintenance manual

John Deere Electronically - Controlled POWERTECH 4.5 L & 6.8 L 4045 and 6068 OEM Diesel Engines

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:



WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

Réf. constructeur : OMRG33324

Réf. GPAO : 33522045801 ind1



Danger

Warning about the dangers linked to fuel discharges under high pressure on engines equipped with Denso high pressure common rail (HPCR).

- Watch out for fuel under high pressure throughout the system
- Never dismantle the fuel lines, when the engine is running (lines under high pressure)
- It is better to work on the injection system when the fuel temperature is less than 30°C
- Wait at least 5 minutes after the engine stops before carrying out work on the injection system (check the pressure before doing anything)
- After changing the component, check that there are no fuel leaks. Carry out this test with the engine protection closed (engine bonnet or other protection)
- Do not dismantle and reassemble the injector parts

Introduction

Foreword

READ THIS MANUAL carefully to learn how to operate and service your engine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your engine and should remain with the engine when you sell it.

MEASUREMENTS IN THIS MANUAL are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by standing at the drive or flywheel end (rear) of the engine and facing toward the front of the engine.

WRITE ENGINE SERIAL NUMBERS and option codes in the spaces indicated in the Record Keeping Section. Accurately record all the numbers. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the engine.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

CERTAIN ENGINE ACCESSORIES such as radiator, air cleaner, and instruments are optional equipment on John Deere OEM Engines. These accessories may be provided by the equipment manufacturer instead of

John Deere. This operator's manual applies only to the engine and those options available through the John Deere distribution network.

IMPORTANT: This manual covers only *POWERTECH*[®] electronically controlled 4.5 and 6.8 L OEM engines. These engines were produced starting in the year 2000 at Saran, France and Torreón, Mexico. With the use of electronic fuel systems, these engines meet Tier II emission certification standards. (This is for both the U.S. EPA and European Union Council (EU) standards.) They can be identified by the engine model number with the suffix "275", as in 6068HF275. Engines with the suffix "475" have the 4-valve cylinder head design option introduced in the year 2002. (Engines with mechanical controls which are non-emission certified or Tier I emission certified (U.S. and EU) are covered in a separate operators manual, OMRG25204.)

NOTE: This operators manual covers only engines provided to OEM (Outside Equipment Manufacturers). For engines in Deere machines, refer to the machine operators manual.

OMRGOEM,IFC -19-26APR02-1/1

Engine Owner

John Deere Engine Owner:

Don't wait until you need warranty or other service to meet your local John Deere Engine Distributor or Service Dealer.

Learn who he is and where he is. At your first convenience, go meet him. He'll want to get to know you and to learn what your needs might be.

Aux Utilisateurs De Moteurs John Deere:

N'attendez pas d'être obligé d'avoir recours à votre concessionnaire John Deere ou point de service le plus proche pour vous adresser à lui.

Renseignez-vous dès que possible pour l'identifier et le localiser. À la première occasion, prenez contact avec lui et faites-vous connaître. Il sera lui aussi heureux de faire votre connaissance et de vous proposer ses services le moment venu.

An Den Besitzer Des John Deere Motors:

Warten Sie nicht auf einen evt. Reparaturfall um den nächstgelegenen John Deere Händler kennen zu lernen.

Machen Sie sich bei ihm bekannt und nutzen Sie sein "Service Angebot".

Proprietario Del Motore John Deere:

Non aspetti fino a quando ha bisogno della garanzia o di un altro tipo di assistenza per incontrarsi con il Suo Concessionario che fornisce l'assistenza tecnica.

Impari a conoscere chi è e dove si trova. Alla Sua prima occasione cerchi d'incontrarlo. Egli desidera farsi conoscere e conoscere le Sue necessità.

Propietario De Equipo John Deere:

No espere hasta necesitar servicio de garantía o de otro tipo para conocer a su Distribuidor de Motores John Deere o al Concesionario de Servicio.

Entérese de quién es, y dónde está situado. Cuando tenga un momento, vaya a visitarlo. A él le gustará conocerlo, y saber cuáles podrían ser sus necesidades.

John Deere MotorÄgare:

Vänta inte med att besöka Din John Deere återförsäljare till dess att Du behöver service eller garanti reparation.


Bekanta Dig med var han är och vem han är. Tag första tillfälle att besöka honom. Han vill också träffa Dig för att få veta vad Du behöver och hur han kan hjälpa Dig.

**POWERTECH® 4.5 L Engines With Electronic Fuel Systems (Tier II Emission Certified)
(Two-Valve Cylinder Head Models)**



4045 Engine (Stanadyne DE10 Injection Pump Shown)

RG11931 -UN-06NOV01



4045 Engine

RG11932 -UN-06NOV01

POWERTECH is a trademark of Deere & Company


OUOD002,0000162 -19-26APR02-1/1

**POWERTECH® 6.8 L Engines With Electronic Fuel Systems (Tier II Emission Certified)
(Two-Valve Cylinder Head Models)**



6068 Engine (Bosch VP44 Injection Pump Shown)

RG11933 -JUN-24OCT01



6068 Engine

RG11934 -JUN-24OCT01

POWERTECH is a trademark of Deere & Company


OUOD002,0000163 -19-26APR02-1/1

**POWERTECH® 4.5/6.8 L Engines With Electronic Fuel Systems (Tier II Emission Certified)
(Four-Valve Cylinder Head Models)**



RG12199 -UN-24MAY02

6068HF475 Engine Shown (Level 11 Electronic Fuel System With Denso High Pressure Common Rail)



RG12200 -UN-24MAY02

6068HF475 Shown

POWERTECH is a trademark of Deere & Company

OUOD005,000017F -19-26APR02-1/1

Contents

	Page		Page
Record Keeping		Viewing Active Engine Service Codes (DTC) . .	15-15
PowerTech Medallion	01-1	Viewing Stored Service Codes (DTC) in	
Engine Serial Number Plate	01-1	Engine ECU	15-16
Record Engine Serial Number	01-2	Engine Break-In Service	15-17
Engine Option Codes	01-3	Starting the Engine	15-20
Record Fuel Injection Pump Model Number	01-5	Normal Engine Operation	15-22
		Warming Engine	15-23
Safety	05-1	Cold Weather Operation	15-24
		Using a Booster Battery or Charger	15-26
Fuels, Lubricants, and Coolant		Avoid Excessive Engine Idling	15-27
Diesel Fuel	10-1	Changing Engine Speeds	15-28
Lubricity of Diesel Fuel	10-2	Stopping The Engine	15-29
Filling Fuel Tank	10-2	Auxiliary Gear Drive Limitations	15-30
Bio-Diesel Fuel	10-3	Generator Set (Standby) Applications	15-30
Handling And Storing Bio-Diesel Fuel	10-4		
Diesel Fuel Storage	10-5	Lubrication and Maintenance	
Dieselscan Fuel Analysis	10-5	Observe Service Intervals	20-1
Minimizing the Effect of Cold Weather on		Use Correct Fuels, Lubricants, and Coolant . . .	20-1
Diesel Engines	10-6	Lubrication and Maintenance Service	
Diesel Engine Break-In Oil	10-8	Interval Chart—Standard Industrial Engines . .	20-2
Diesel Engine Oil	10-9	Lubrication and Maintenance Service	
Diesel Engine Oil Service Intervals	10-10	Interval Chart—Generator (Standby)	
Mixing of Lubricants	10-10	Applications	20-4
OILSCAN® and COOLSCAN™	10-10		
Alternative and Synthetic Lubricants	10-11	Lubrication & Maintenance/Daily	
Lubricant Storage	10-11	Daily Prestarting Checks	25-1
Grease	10-12		
Diesel Engine Coolant	10-13	Lubrication & Maintenance/500 Hour/12 Month	
Diesel Engine Coolants, Supplemental		Servicing Fire Extinguisher	30-1
Additive Information	10-14	Checking Engine Mounts	30-1
Testing Diesel Engine Coolant	10-15	Servicing Battery	30-2
Supplemental Coolant Additives	10-16	Manual Belt Tensioner Adjustment	30-4
Operating in Warm Temperature Climates . . .	10-17	Manual Belt Tensioner Adjustment Using	
Disposing of Coolant	10-17	Belt Tension Tool (Alternate Method	
		For Engines Without Auxiliary Drive)	30-5
Engine Operating Guidelines		Changing Engine Oil and Replacing Filter	30-7
Electronic Instrument (Gauge) Panel	15-1	Cleaning Crankcase Vent Tube	30-9
Using Diagnostic Gauge To Access Engine		Checking Air Intake System	30-10
Information	15-7	Replacing Fuel Filter Elements	30-11
Using Touch Switches To Display Information . .	15-9	Checking Belt Tensioner Spring Tension	
Changing Units of Measure (English or		and Belt Wear (Automatic Tensioner)	30-13
Metric)	15-11		
Viewing Engine Configuration Data	15-13		

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2002
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 2001

Page

Page

Checking Engine Electrical Ground	
Connections	30-15
Checking Cooling System.	30-15
Replenishing Supplemental Coolant	
Additives (SCAs) Between Coolant	
Changes	30-16
Testing Diesel Engine Coolant	30-18
Pressure Testing Cooling System.	30-19

Lubrication & Maint./2000 Hour/24 Month

Checking Crankshaft Vibration Damper	
(6-Cylinder Engine Only).	35-1
Flushing Cooling System	35-2
Testing Thermostats Opening Temperature	35-5
Check and Adjust Valve Clearance (All	
Engines Except 4045HF475 And	
6068HF475)	35-8
Check and Adjust Valve Clearance	
(4045HF475 And 6068HF475 Engines).	35-11
Test Glow Plugs for Continuity	
(4045HF475 And 6068HF475 Engines).	35-14

Service as Required

Additional Service Information	40-1
Do Not Modify Fuel System	40-1
Adding Coolant.	40-2
Replacing Single Stage Air Cleaner	40-4
Replacing Axial Seal Air Cleaner Filter	
Element	40-5
Replacing Radial Seal Air Cleaner Filter	
Element	40-7
Replacing Fan and Alternator Belts	40-9
Checking Fuses	40-10
Bleeding the Fuel System (Engines With	
Electronic Fuel Systems And Bosch VP44	
Pump).	40-11
Bleed the Fuel System (Engines with	
Electronic Fuel Systems and Stanadyne DE10	
Pump).	40-13
Bleed the Fuel System (Engines with	
Electronic Fuel Systems and Denso High	
Pressure Common Rail) (4045HF475,	
6068HF475)	40-16

Troubleshooting

General Troubleshooting Information	45-1
Precautions For Welding On Engines	
Equipped With Electronic Engine Control Unit	
(ECU)	45-2
Engine Wiring Layout (Electronic Fuel	
System With Stanadyne DE10 Injection	
Pump).	45-3

Engine Wiring Layout (Electronic Fuel	
System With Bosch VP44 Injection Pump) . . .	45-4
Engine Wiring Layout (Electronic Fuel	
System With Denso High Pressure Common	
Rail)	45-5
Engine Wiring Diagram (Electronic	
Instrument Panel)	45-6
Engine Wiring Diagram (Engines With	
Electronic Instrument Panel)	45-7
Engine Troubleshooting	45-8
Diagnostic Trouble Code Procedure	
(Using Electronic Instrument Panel)	45-16
Displaying Of Diagnostic Trouble Codes	
(DTCs)	45-17
Listing of Diagnostic Trouble Codes (DTCs)	
(Engines With Electronic Fuel	
Systems And Stanadyne DE10 Pump)	45-18
Listing of Diagnostic Trouble Codes (DTCs)	
(Engines With Electronic Fuel	
Systems And Bosch VP44 Pump).	45-20
Listing of Diagnostic Trouble Codes (DTCs)	
(Engines With Electronic Fuel	
Systems And Denso High Pressure Common	
Rail)	45-22
Intermittent Fault Diagnostics (With	
Electronic Controls).	45-24

Storage

Engine Storage Guidelines.	50-1
Preparing Engine for Long Term Storage	50-2
Removing Engine from Long Term Storage	50-3

Specifications

General OEM Engine Specifications.	55-1
Engine Power Ratings And Fuel System	
Specifications	55-3
Engine Crankcase Oil Fill Quantities	55-5
Unified Inch Bolt and Cap Screw Torque	
Values.	55-6
Metric Bolt and Cap Screw Torque Values.	55-7

Lubrication and Maintenance Records

Using Lubrication and Maintenance Records . . .	60-1
Daily (Prestarting) Service	60-1
500 Hour/12 Month Service	60-2
2000 Hour/24 Month Service	60-3
Service as Required.	60-4

Emission System Warranty

U.S. EPA Emission Control Warranty	
Statement	65-1

Continued on next page

Page

Emission Control System Certification Label. . . 65-2

Record Keeping

POWERTECH® Medallion

A medallion is located on the rocker arm cover which identifies each engine as a John Deere POWERTECH® engine.

NOTE: Four-valve head engines also have "16V" or "24V" printed on their medallions. The 4045HF475 has "16V" to denote 16 valves total while 6068HF475 has "24V" to denote 24 valves total.



RG11608 -UN-17OCT01



RG11609 -UN-17OCT01

POWERTECH is a trademark of Deere & Company.

RG, RG34710, 5505 -19-04JUN02-1/1

Engine Serial Number Plate

Each engine has a 13-digit John Deere engine serial number. The first two digits identify the factory that produced the engine:

- "CD" = Saran, France
- "PE" = Torreon, Mexico
- "T0" = Dubuque, Iowa
- "J0" = Rosario, Argentina

The engine's serial number plate (A) is located on the right-hand side of cylinder block behind the fuel filter.

A—Serial Number Plate



RG8007 -UN-15JAN99

13-Digit Engine Serial Number Plate

RG, RG34710, 5506 -19-10NOV01-1/1

Record Engine Serial Number


Record all of the numbers and letters found on your engine serial number plate in the spaces provided below.

This information is very important for repair parts or warranty information.


Engine Serial Number (B)

Engine Model Number (C)

Coefficient of Absorption Value (D)
(Saran Engines Only)



Saran Engine Serial Number Plate



Torreon Engine Serial Number Plate

RG, RG34710, 5507 -19-10NOV01-1/1

Engine Option Codes



A—Engine Base Code

In addition to the serial number plate, OEM engines have an engine option code label affixed to the rocker arm cover. These codes indicate which of the engine options were installed on your engine at the factory. When in need of parts or service, furnish your authorized servicing dealer or engine distributor with these numbers.

The engine option code label includes an engine base code (A). This base code must also be recorded along with the option codes.

The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as a 12-volt, 55-amp alternator.

NOTE: These option codes are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

If an engine is ordered without a particular component, the last two digits of that functional group option code will be 99, 00, or XX. The list on the next page shows only the first two digits of the code numbers. For future reference such as ordering repair parts, it is important to have these code numbers available. To ensure this availability, enter the third and fourth digits shown on your engine option code label in the spaces provided on the following page.

Continued on next page

RG, RG34710, 5508 -19-04JUN02-1/2

NOTE: Your engine option code label may not contain all option codes if an option has been added after the engine left the producing factory.

If option code label is lost or destroyed, consult your servicing dealer or engine distributor selling the engine for a replacement.

An additional option code label may also be delivered with the engine. Place this sticker or tag, for reference, either on this page or in the engine owner's warranty booklet under **OPTION CODES** title.

Option Codes	Description	Option Codes	Description
11_____	Rocker Arm Cover	50_____	Oil Pump
12_____	Oil Fill Inlet	51_____	Cylinder Head With Valves
13_____	Crankshaft Pulley/Damper	52_____	Auxiliary Gear Drive
14_____	Flywheel Housing	53_____	Fuel Heater
15_____	Flywheel	55_____	Shipping Stand
16_____	Fuel Injection Pump	56_____	Paint Option
17_____	Air Inlet	57_____	Coolant Pump Inlet
18_____	Air Cleaner	59_____	Oil Cooler
19_____	Oil Pan	60_____	Add-on Auxiliary Drive Pulley
20_____	Coolant Pump	62_____	Alternator Mounting Bracket
21_____	Thermostat Cover	63_____	Low Pressure Fuel Line
22_____	Thermostat	64_____	Exhaust Elbow
23_____	Fan Drive	65_____	Turbocharger
24_____	Fan Belt	66_____	Temperature Switch
25_____	Fan	67_____	Electronic Sensors (Base Engine)
26_____	Engine Coolant Heater	68_____	Crankshaft Rear Damper
27_____	Radiator	69_____	Engine Serial Number Plate
28_____	Exhaust Manifold	71_____	Engine Oil Bypass Filter
29_____	Ventilator System	72_____	ECU Electronic Software Option
30_____	Starter Motor	74_____	Air Conditioning (Freon) Compressor
31_____	Alternator	75_____	Air Restriction Indicator
32_____	Instrument Panel	76_____	Pressure Switches and Sensors
33_____	Tachometer	77_____	Timing Gear Cover
35_____	Fuel Filters	78_____	Air Compressor
36_____	Front Plate	79_____	Engine Certification
37_____	Fuel Transfer Pump	81_____	Primary Fuel Filter And Water Separator
39_____	Thermostat Housing	83_____	Electronic Software (Vehicle Option)
40_____	Oil Dipstick	84_____	Electrical Wiring Harness
41_____	Belt-Driven Front Auxiliary Drive	86_____	Fan Pulley
43_____	Starting Aid	87_____	Belt Tensioner
44_____	Timing Gear Cover With Gears	88_____	Oil Filter
46_____	Cylinder Block With Liners and Camshaft	95_____	Special Equipment (Factory Installed)
47_____	Crankshaft and Bearings	96_____	Engine Installation Kit
48_____	Connecting Rods and Pistons	97_____	Special Equipment (Field Installed)
49_____	Valve Actuating Mechanism	98_____	Shipping (Engine Hanger Straps)
		99_____	Service Only Items

Engine Base Code

Record Fuel Injection Pump Model Number


Record the fuel injection pump model and serial information found on the serial number plate (A).

Model No. _____ RPM _____

Manufacturer's No. _____

Serial No. _____

A—Serial Number Plate



RG11943 -JUN-06NOV01

Record Injection Pump Serial Number

RG, RG34710, 5511 -19-10NOV01-1/1

Safety

Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-29SEP98-1/1

T81389 -UN-07DEC88

Understand Signal Words

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93-1/1

TS187 -19-30SEP88

Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-03MAR93-1/1

TS201 -UN-23AUG88

Replace Safety Signs

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



DX,SIGNS1 -19-04JUN90-1/1

TS201 -UN-23AUG88

Prevent Bypass Starting

Avoid possible injury or death from engine runaway.

Do not start engine by shorting across starter terminal. Engine will start with PTO engaged if normal circuitry is bypassed.

Start engine only from operator's station with PTO disengaged or in neutral.



RG,RG34710,7508 -19-30JUN97-1/1

RG5419 -UN-28FEB89

Handle Fuel Safely—Avoid Fires

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



DX,FIRE1 -19-03MAR93-1/1


TS202 -UN-23AUG88

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1

Handle Starting Fluid Safely

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.



TS1356 -UN-18MAR92

DX,FIRE3 -19-16APR92-1/1

Handle Fluids Safely—Avoid Fires

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure engine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.




TS227 -UN-23AUG88

DX,FLAME -19-29SEP98-1/1

Service Engines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near engine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



TS228 -UN-23AUG88

DX,LOOSE -19-04JUN90-1/1


Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1

Protect Against Noise

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



TS207 -UN-23AUG88

DX,NOISE -19-03MAR93-1/1

Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1

Stay Clear of Rotating Drivelines

Entanglement in rotating driveline can cause serious injury or death.

Keep master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



TS1644 -UN-22AUG95

DX,PTO -19-12SEP95-1/1

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.



TS218 -UN-23AUG88

DX,SERV -19-17FEB99-1/1

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area



TS220 -UN-23AUG88

DX,AIR -19-17FEB99-1/1


Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



X9811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

Avoid Heating Near Pressurized Fluid Lines

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



TS953 -UN-15MAY90

DX,TORCH -19-03MAR93-1/1

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.


Remove paint before heating:

- Remove paint a minimum of 76 mm (3 in.) from area to be affected by heating.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.




TS220 -UN-23AUG88

DX,PAINT -19-19JUL01-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS281 -UN-23AUG88

DX,RCAP -19-04JUN90-1/1


Avoid Harmful Asbestos Dust

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



TS220 -JUN-23AUG88

DX,DUST -19-15MAR91-1/1

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -JUN-23AUG88

DX,SPARKS -19-03MAR93-1/1

Prevent Acid Burns

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TS203 -UN-23AUG88

DX,POISON -19-21APR93-1/1

Protect Against High Pressure Spray

Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



TS1343 -UN-18MAR92

DX,SPRAY -19-16APR92-1/1

Dispose of Waste Properly


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -UN-26NOV90

DX,DRAIN -19-03MAR93-1/1

Fuels, Lubricants, and Coolant

Diesel Fuel

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended.

Required fuel properties

In all cases, the fuel must meet the following properties:

Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below -20°C (-4°F) or elevations above 1500 m (5000 ft).

Cold Filter Plugging Point (CFPP) below the expected low temperature OR **Cloud Point** at least 5°C (9°F) below the expected low temperature.

Fuel lubricity should pass a minimum load level of 3100 grams as measured by ASTM D6078 or, maximum scar diameter of 0.45 mm as measured by ASTM D6079.

Sulfur content:

- Diesel fuel quality and fuel sulfur content must comply with all existing regulations for the area in which the engine operates.
- Sulfur content less than 0.05% (500 ppm) is preferred.
- If diesel fuel with sulfur content greater than 0.05% (500 ppm) is used, crankcase oil service intervals may be affected. (See recommendation for Diesel Engine Oil.)
- DO NOT use diesel fuel with sulfur content greater than 1.0%.

IMPORTANT: DO NOT mix used engine oil or any other type of lubricating oil with diesel fuel.

OUOD002,0000171 -19-18DEC01-1/1

Lubricity of Diesel Fuel

Diesel fuel must have adequate lubricity to ensure proper operation and durability of fuel injection system components.

Diesel fuels for highway use in the United States and Canada require sulfur content less than 0.05% (500 ppm).

Diesel fuel in the European Union requires sulfur content less than 0.05% (500 ppm).

Experience shows that some low sulfur diesel fuels may have inadequate lubricity and their use may reduce performance in fuel injection systems due to inadequate lubrication of injection pump components. The lower concentration of aromatic compounds in these fuels also adversely affects injection pump seals and may result in leaks.

Use of low lubricity diesel fuels may also cause accelerated wear, injection nozzle erosion or corrosion, engine speed instability, hard starting, low power, and engine smoke.

Fuel lubricity should pass a minimum load level of 3100 gram as measured by the ASTM D6078 or maximum scar diameter of 0.45 mm as measured by ASTM D6079.

ASTM D975 and EN 590 specifications do not require fuels to pass a fuel lubricity test.

If fuel of low or unknown lubricity is used, add John Deere PREMIUM DIESEL FUEL CONDITIONER (or equivalent) at the specified concentration.

OUOD002,0000179 -19-18DEC01-1/1

Filling Fuel Tank



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while filling fuel tank or servicing fuel system.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace it with an original vented cap.

Fill fuel tank at the end of each day's operation to prevent condensation in tank. As moist air cools, condensation may form and freeze during cold weather.



TS202 -UN-23AUG88

RG, RG34710, 7527 -19-30JUN97-1/1

Bio-Diesel Fuel

Consult your local fuel distributor for properties of the bio-diesel fuel available in your area.

Bio-diesel fuels may be used **ONLY** if the bio-diesel fuel properties meet the latest edition of ASTM PS121, DIN 51606 or equivalent specification.

It has been found that bio-diesel fuels may improve lubricity in concentrations up to a 5% blend in petroleum diesel fuel.

When using a blend of bio-diesel fuel, the engine oil level must be checked daily when the air temperature is -10°C (14°F) or lower. If the oil becomes diluted with fuel, shorten oil change intervals accordingly.

IMPORTANT: Raw pressed vegetable oils are NOT acceptable for use for fuel in any concentration in John Deere engines.

These oils do not burn completely, and will cause engine failure by leaving deposits on injectors and in the combustion chamber.

A major environmental benefit of bio-diesel fuel is its ability to biodegrade. This makes proper storage and handling of bio-diesel fuel especially important. Areas of concern include:

- Quality of new fuel
- Water content of the fuel
- Problems due to aging of the fuel

Potential problems resulting from deficiencies in the above areas when using bio-diesel fuel in concentrations above 5% may lead to the following symptoms:

- Power loss and deterioration of performance
- Fuel leakage
- Corrosion of fuel injection equipment
- Coked and/or blocked injector nozzles, resulting in engine misfire
- Filter plugging
- Lacquering and/or seizure of internal components
- Sludge and sediments
- Reduced service life of engine components

RG41183,0000046 -19-18DEC01-1/1

Handling And Storing Bio-Diesel Fuel



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while you fill the fuel tank or service the fuel system.

Fill the fuel tank at the end of each day's operation to prevent water condensation and freezing during cold weather.

Keep all storage tanks as full as practicable to minimize condensation.

Ensure that all fuel tank caps and covers are installed properly to prevent moisture from entering.

Monitor water content of the fuel regularly.

Fuel filter may require more frequent replacement due to premature plugging.

Check engine oil level daily prior to starting engine. A rising oil level may indicate fuel dilution of the engine oil.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace it with an original vented cap.

When fuel is stored for an extended period or if there is a slow turnover of fuel, add a fuel conditioner to stabilize the fuel and prevent water condensation. Contact your fuel supplier for recommendations.

OUOD002,0000176 -19-18DEC01-1/1

Diesel Fuel Storage



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while you fill the fuel tank or service the fuel system.

Fill the fuel tank at the end of each day's operation to prevent water condensation and freezing during cold weather.

IMPORTANT: DO NOT store diesel fuel in galvanized containers. Diesel fuel stored in galvanized containers reacts with zinc coating on container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters, damage injection nozzles and injection pump.

DO NOT use brass-coated containers for fuel storage. Brass is an alloy of copper and zinc.

Store diesel fuel in plastic, aluminum, and steel containers specially coated for diesel fuel storage.

Avoid storing fuel over long periods of time. If fuel is stored for more than a month prior to use, or there is a slow turnover in fuel tank or supply tank, add a fuel conditioner such as John Deere PREMIUM DIESEL FUEL CONDITIONER or equivalent to stabilize the fuel and prevent water condensation. John Deere PREMIUM DIESEL FUEL CONDITIONER is available in winter and summer formulas. Fuel conditioner also reduces fuel gelling and controls wax separation during cold weather.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace with an original vented cap.

RG, RG34710, 7526 -19-18DEC01-1/1

Dieselscan Fuel Analysis

DIESELSCAN™ is a John Deere fuel sampling program to help you monitor the quality of your fuel source. It verifies fuel type, cleanliness, water content, suitability for cold weather operation, and if fuel is within ASTM specifications. Check with your John Deere dealer for availability of DIESELSCAN kits.

DIESELSCAN is a trademark of Deere & Company

DX, FUEL6 -19-06DEC00-1/1

Minimizing the Effect of Cold Weather on Diesel Engines

John Deere diesel engines are designed to operate effectively in cold weather.

However, for effective starting and cold weather operation, a little extra care is necessary. The information below outlines steps that can minimize the effect that cold weather may have on starting and operation of your engine. See your authorized engine distributor or servicing dealer for additional information and local availability of cold weather aids.

Use Grade No. 1-D Fuel

When temperatures fall below 5°C (40°F), Grade No. 1-D fuel is best suited for cold weather operation. Grade No. 1-D fuel has a lower cloud point and a lower pour point.

Cloud point is the temperature at which wax will begin to form in the fuel and this wax causes fuel filters to plug. **Pour point** is the temperature at which fuel begins to thicken and becomes more resistant to flow through fuel pumps and lines.

NOTE: On an average, Grade No. 1-D fuel has a lower BTU (heat content) rating than Grade No. 2-D fuel. When using Grade No. 1-D fuel you may notice a drop in power and fuel efficiency, but should not experience any other engine performance effects. Check the grade of fuel being used before troubleshooting for low power complaints in cold weather operation.

Fuel Heaters

Two options are available with fuel heaters: one location is at the inlet port of the primary fuel filter,

while the other location is at the inlet port of the final fuel filter.

Coolant Heaters

Engine block heaters (coolant) are an available option to aid cold weather starting.

Glow Plugs

Glow plugs are an available option to aid cold weather starting on engines equipped with the 4 valve cylinder head (475 suffix).

Seasonal Viscosity Oil and Proper Coolant Concentration

Use seasonal grade viscosity engine oil based on expected air temperature range between oil changes and a proper concentration of low silicate antifreeze as recommended. (See DIESEL ENGINE OIL and ENGINE COOLANT REQUIREMENTS later in this section).

Diesel Fuel Flow Additive

IMPORTANT: Treat fuel when outside temperature drops below 0°C (32°F). For best results, use with untreated fuel. Follow all recommended instructions on label.

Use John Deere Premium Diesel Fuel Conditioner (Winter) or equivalent to treat fuel during the cold weather season. This winter formulation is a combination diesel fuel conditioner and anti-gel additive.

Continued on next page

RG, RG34710, 7529 -19-16MAY02-1/2

Winterfronts

Use of fabric, cardboard, or solid winterfronts is not recommended with any John Deere engine. Their use can result in excessive engine coolant, oil, and charge air temperatures. This can lead to reduced engine life, loss of power and poor fuel economy. Winterfronts may also put abnormal stress on fan and fan drive components potentially causing premature failures.

If winterfronts are used, they should never totally close off the grill frontal area. Approximately 25% area in the center of the grill should remain open at all times. At no time should the air blockage device be applied directly to the radiator core.

Radiator Shutters

If equipped with a thermostatically controlled radiator shutter system, this system should be regulated in

such a way that the shutters are completely open by the time the coolant reaches 93°C (200°F) to prevent excessive intake manifold temperatures. Manually controlled systems are not recommended.

If air-to-air aftercooling is used, the shutters must be completely open by the time the intake manifold air temperature reaches the maximum allowable temperature out of the charge air cooler.

For more information, see your John Deere engine distributor or servicing dealer.

RG, RG34710, 7529 -19-16MAY02-2/2

Diesel Engine Break-In Oil

New engines are filled at the factory with John Deere ENGINE BREAK-IN OIL. During the break-in period, add John Deere ENGINE BREAK-IN OIL as needed to maintain the specified oil level (order TY22041).

Change the oil and filter after the first 100 hours of operation of a new or rebuilt engine.

After engine overhaul, fill the engine with John Deere ENGINE BREAK-IN OIL.

If John Deere ENGINE BREAK-IN OIL is not available, use a diesel engine oil meeting one of the following during the first 100 hours of operation:

- API Service Classification CD
- API Service Classification CC
- ACEA Specification E1

After the break-in period, use John Deere PLUS-50® or other diesel engine oil as recommended in this manual.

IMPORTANT: Do not use PLUS-50 oil or engine oils meeting any of the following during the first 100 hours of operation of a new or rebuilt engine:

- API CI-4
- ACEA E5
- API CH-4
- ACEA E4
- API CG-4
- ACEA E3
- API CF-4
- ACEA E2

These oils will not allow the engine to break-in properly.

PLUS-50 is a registered trademark of Deere & Company.

OUOD002,0000178 -19-26APR02-1/1

Diesel Engine Oil

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oil is preferred:

- John Deere PLUS-50®

The following oils are also recommended:

- John Deere TORQ-GARD SUPREME®
- Oils meeting ACEA Specification E5

Other oils may be used if they meet one or more of the following:

- API Service Classification CI-4
- API Service Classification CH-4
- ACEA Specification E3
- ACEA Specification E4

Multi-viscosity diesel engine oils are preferred.


Diesel fuel quality and sulfur content must comply with all existing emissions regulations for the area in which the engine operates.

If diesel fuel with sulfur content greater than 0.05% (500 ppm) is used, reduce the oil and filter change interval by 100 hours.

If diesel fuel with sulfur content greater than 0.5% (5000 ppm) is used, reduce the service interval by 50%.

Diesel fuel with sulfur content greater than 1.0% (10,000 ppm) is not recommended.

Extended service intervals may apply when John Deere preferred engine oils are used. Consult your John Deere dealer for more information.



Diesel Engine Oil

TS1668A -UN-14DEC01

PLUS-50 is a registered trademark of Deere & Company.

TORQ-GARD SUPREME is a trademark of Deere & Company

OUOD002,0000172 -19-11JUN02-1/1

Diesel Engine Oil Service Intervals

When John Deere PLUS-50® or ACEA-E4/E5 oil and the specified John Deere filter are used, the service interval for the engine oil and filter is 500 hours.

If other than PLUS-50® or ACEA-E4/E5 oil and the specified John Deere filter are used, the service interval for the engine oil and filter is reduced to 250 hours.

PLUS-50 is a trademark of Deere & Company

OUOD002,0000177 -19-04JUN02-1/1

Mixing of Lubricants

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Consult your John Deere engine distributor or servicing dealer to obtain specific information and recommendations.


DX,LUBMIX -19-18MAR96-1/1

OILSCAN® and COOLSCAN™

OILSCAN®, OILSCAN PLUS®, COOLSCAN™ and, COOLSCAN PLUS™ are John Deere sampling programs to help you monitor machine performance and identify potential problems before they cause serious damage.


Oil and coolant samples should be taken from each system prior to its recommended change interval.

Check with your John Deere engine distributor or servicing dealer for the availability of OILSCAN®, OILSCAN PLUS®, COOLSCAN™ and, COOLSCAN PLUS™ kits.



Sampling Programs

T6828AB -UN-15JUN89



T6829AB -UN-18OCT88

Recommended Change Interval

OILSCAN is a registered trademark of Deere & Company.
COOLSCAN is a trademark of Deere & Company.
OILSCAN PLUS is a registered trademark of Deere & Company.
COOLSCAN PLUS is a trademark of Deere & Company.

OUOD002,0000173 -19-23NOV01-1/1

Alternative and Synthetic Lubricants

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic oils.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-15JUN00-1/1

Lubricant Storage

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-18MAR96-1/1

Grease

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

The following greases are preferred:

- John Deere SD POLYUREA GREASE


The following greases are also recommended:

- John Deere HD MOLY GREASE
- John Deere HD LITHIUM COMPLEX GREASE
- John Deere HD WATER RESISTANT GREASE
- John Deere GREASE-GARD

Other greases may be used if they meet the following:

- NLGI Performance Classification GC-LB

IMPORTANT: Some types of grease thickener are not compatible with others. Consult your grease supplier before mixing different types of grease.



DX,GREA1 -19-24JAN00-1/1

Diesel Engine Coolant

The engine cooling system is filled to provide year-round protection against corrosion and cylinder liner pitting, and winter freeze protection to -37°C (-34°F).

The following engine coolant is preferred for service:

- John Deere COOL-GARD Prediluted Coolant

The following engine coolant is also recommended:

- John Deere COOL-GARD Coolant Concentrate in a 40 to 60% mixture of concentrate with quality water.

Other low silicate ethylene glycol base coolants for heavy-duty engines may be used if they meet one of the following specifications:

- ASTM D5345 (prediluted coolant)
- ASTM D4985 (coolant concentrate) in a 40 to 60% mixture of concentrate with quality water

Coolants meeting these specifications require use of supplemental coolant additives, formulated for heavy-duty diesel engines, for protection against corrosion and cylinder liner erosion and pitting.

A 50% mixture of ethylene glycol engine coolant in water provides freeze protection to -37°C (-34°F). If

protection at lower temperatures is required, consult your John Deere dealer for recommendations.

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol base engine coolant concentrate.

IMPORTANT: Do not use cooling system sealing additives or antifreeze that contains sealing additives.

Coolant Drain Intervals

Drain the factory fill engine coolant, flush the cooling system, and refill with new coolant after the first 3 years or 3000 hours of operation. Subsequent drain intervals are determined by the coolant used for service. At each interval, drain the coolant, flush the cooling system, and refill with new coolant.

When John Deere COOL-GARD is used, the drain interval may be extended to 5 years or 5000 hours of operation, provided that the coolant is tested annually AND additives are replenished, as needed, by adding a supplemental coolant additive.

If COOL-GARD is not used, the drain interval is reduced to 2 years or 2000 hours of operation.

DX,COOL3 -19-05FEB99-1/1

Diesel Engine Coolants, Supplemental Additive Information

Engine coolants are a combination of three chemical components: ethylene glycol (antifreeze), inhibiting coolant additives, and quality water.

Coolant Specifications

Some products, including John Deere COOL-GARD Prediluted Coolant, are fully formulated coolants that contain all three components in their correct concentrations. Do not add an initial charge of supplemental coolant additives to these fully formulated products.

Some coolant concentrates, including John Deere COOL-GARD Coolant Concentrate, contain both ethylene glycol antifreeze and inhibiting coolant additives. Mix these products and quality water, but do not add an initial charge of supplemental coolant additives.

Coolants meeting ASTM D5345 (prediluted coolant) or ASTM D4985 (coolant concentrate) require an initial charge of supplemental coolant additives.

Replenish Coolant Additives

The concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD is used. Follow the recommendations in this manual for the use of supplemental coolant additives.

Why Use Supplemental Coolant Additives?

Operating without proper coolant additives will result in increased corrosion, cylinder liner erosion and pitting, and other damage to the engine and cooling system. A simple mixture of ethylene glycol and water will not give adequate protection.

Use of supplemental coolant additives reduces corrosion, erosion, and pitting. These chemicals reduce the number of vapor bubbles in the coolant and

help form a protective film on cylinder liner surfaces. This film acts as a barrier against the harmful effects of collapsing vapor bubbles.

Avoid Automotive-Type Coolants

Never use automotive-type coolants (such as those meeting ASTM D3306 or ASTM D4656). These coolants do not contain the correct additives to protect heavy-duty diesel engines. They often contain a high concentration of silicates and may damage the engine or cooling system.

Water Quality

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol base engine coolant concentrate. All water used in the cooling system should meet the following minimum specifications for quality:

Chlorides	<40 mg/L
Sulfates	<100 mg/L
Total Dissolved Solids	<340 mg/L
Total Hardness	<170 mg/L
pH	5.5 to 9.0

Freeze Protection

The relative concentrations of ethylene glycol and water in the engine coolant determine its freeze protection limit.

Ethylene Glycol	Freeze Protection Limit
40%	-24°C (-12°F)
50%	-37°C (-34°F)
60%	-52°C (-62°F)

DO NOT use a coolant-water mixture greater than 60% ethylene glycol.

Testing Diesel Engine Coolant

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.

Test the coolant solution at intervals of 12 month or less and whenever excessive coolant is lost through leaks or overheating.


Coolant Test Strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective method to check the freeze point and additive levels of your engine coolant.

Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.

COOLSCAN™ and COOLSCAN PLUS™

For a more thorough evaluation of your coolant, perform a COOLSCAN or COOLSCAN PLUS™ analysis. See your John Deere dealer for information.



Coolant Test Strips

RG7297 -UN-22SEP99



CoolScan Bellows

RG7397 -UN-05DEC97

COOLSCAN is a trademark of Deere & Company
COOLSCAN PLUS is a trademark of Deere & Company.

OUOD002,0000174 -19-18DEC01-1/1

Supplemental Coolant Additives

The concentration of coolant additives is gradually depleted during engine operation. For all recommended coolants, replenish additives between drain intervals by adding a supplemental coolant additive every 12 months or as determined necessary by coolant testing.

John Deere COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

IMPORTANT: Only use coolant additive to replenish the coolant. Do not use additive when the entire system is drained and refilled with John Deere COOL GARD.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.

OUOD006,0000019 -19-11JUN02-1/1

Operating in Warm Temperature Climates

John Deere engines are designed to operate using glycol base engine coolants.

Always use a recommended glycol base engine coolant, even when operating in geographical areas where freeze protection is not required.

IMPORTANT: Water may be used as coolant *in emergency situations only*.

Foaming, hot surface aluminum and iron corrosion, scaling, and cavitation will occur when water is used as the coolant, even when coolant conditioners are added.

Drain cooling system and refill with recommended glycol base engine coolant as soon as possible.

DX,COOL6 -19-18MAR96-1/1


Disposing of Coolant

Improperly disposing of engine coolant can threaten the environment and ecology.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere engine distributor or servicing dealer.



TS1133 -UN-26NOV90

RG,RG34710,7543 -19-30JUN97-1/1

Engine Operating Guidelines

Electronic Instrument (Gauge) Panel


The electronic instrument panel is linked to the John Deere engine control unit (ECU). This allows the operator to monitor engine performance as well as to diagnose any troubles during engine operation.

IMPORTANT: Any time an electric gauge or meter does not register correctly, replace with a new one. Do not attempt to repair it. All gauges are plug-in type.

Following is a brief description of the gauges and controls on the John Deere electronic instrument panel.

NOTE: The instrument panel for your engine may vary from the one shown, depending on the options selected.

- A—Engine Oil Pressure Gauge
- B—Amber “WARNING” Indicator
- C—Red “STOP ENGINE” Indicator
- D—Diagnostic Gauge/Hour Meter
- E—Touch Switch
- F—Touch Switch
- G—Audible Alarm (Optional)
- H—Audible Alarm Override Switch (Optional)
- I—Throttle Control (Optional)
- J—Dimmer Control (Optional)
- K—Engine Preheater Indicator (Optional)
- L—Key Start Switch
- M—Override Shutdown Rocker Switch
- N—High-Low Speed Select Rocker Switch
- O—Bump Speed Enable Rocker Switch (Optional)
- P—Speed Select Rocker Switch
- Q—Fuse Holder (5-Amp Fuse)
- R—Tachometer (Optional)
- S—Power Meter (Percent Load) (Optional)
- T—Voltmeter (Optional)
- U—Engine Coolant Temperature Gauge (Optional)



Electronic Instrument Panel

RG9547 -UN-14AUG00

DPSG,OUOD002,1571 -19-23NOV01-1/1

Electronic Instrument (Gauge) Panel

Engine Oil Pressure Gauge

The engine oil pressure gauge (A) indicates engine oil pressure in pounds per square inch (psi). It is connected to an audible alarm (G) to warn the operator if oil pressure drops below the preset safe operating pressure set for the engine.

Amber “Warning” Indicator

The amber “WARNING” indicator (B) signals an abnormal condition such as low oil pressure, high coolant temperature, low battery voltage, etc. Use the Service Code menu of the diagnostic gauge (D) to identify the trouble.

Red “Stop Engine” Indicator

The red “STOP ENGINE” indicator (C) signals operator to stop engine immediately or as soon as safely possible. A condition exists that could cause damage to engine.

Diagnostic Gauge/Hour Meter

The diagnostic gauge (D) displays diagnostic trouble codes (DTCs) as they occur. Other information on the engine can be accessed using the touch switches (E and F). The hour meter shows the operating hours of the engine. Normally, the gauge will alternately flash from the displayed parameters to the message “SvrcCode”. (See following in this section for operating the diagnostic gauge switches to access engine

information. Also see TROUBLESHOOTING section for a list of diagnostic trouble codes (DTCs) and corresponding engine problems.)

Touch Switches

The touch switches are used to change the display on the window of the diagnostic gauge to access engine performance data. Pressing the DOWN switch (E) or UP switch (F) scrolls through various engine parameters and diagnostic fault codes.

Audible Alarm (Optional)

The audible alarm (G) sounds whenever a low oil pressure or high coolant temperature condition exists.

Audible Alarm Override Switch (Optional)

The audible alarm override switch (H) can be pressed to silence the alarm for approximately 2-1/2 minutes.

Throttle Control (Optional)

The throttle control (I) is used to control engine speed. This control is available as part of the panel only on engines with analog throttle.

Dimmer Control (Optional)

The dimmer control (J) is used to control illumination of the instrument panel gauges.

DPSG.OUOD002,1572 -19-23NOV01-1/1

Electronic Instrument (Gauge) Panel

Engine Preheater Indicator (Optional)

The engine preheater indicator (K) lights up while the engine is being preheated for cold weather starting. When the engine is warmed up, the light goes off, indicating the engine can now be started.

Key Start Switch

The three-position key switch (L) controls the engine electrical system. When the key switch is turned clockwise to "START", the engine will crank. When the engine starts, the key is released and returns to the "ON" (Run) position.

Override Shutdown Rocker Switch

NOTE: This switch may be present, but not active, depending on panel options originally selected.


Pressing the upper half of the override shutdown switch (M) will override an engine shutdown signal. The switch must be pressed within 30 seconds to prevent undesired shutdown of engine.

High-Low Speed Select Rocker Switch

The high-low speed select switch (N) is used to set the engine at operating speeds of slow (turtle) or fast (rabbit). Factory preset idle speeds can then be adjusted using the Bump Enable Switch (O) with the Speed Select Switch (P).

Bump Speed Enable Rocker Switch (Optional)

The bump speed enable switch (O) has a center position which locks the speed select switch (P) to prevent accidental changes in operating speed. To unlock the speed select switch, press and hold either the upper or lower half of the speed enable switch (O).



Electronic Instrument Panel

RG9547 -UN-14AUG00

DPSG,OUOD002,1573 -19-12NOV01-1/1

Electronic Instrument (Gauge) Panel

Speed Select Rocker Switch

The speed select switch (P) is used to bump engine speed up (+) or down (-) in small increments during operation. This switch must be used with the bump speed enable switch (O) in the unlocked position (top or bottom half of button depressed).

How To Select Preset Operating Speeds (Bump Speeds)

First select slow or fast speed option by pressing speed select switch (N) to “turtle” (slow) or “rabbit” (fast). Then you can press either the upper or lower portion of the bump enable switch (O) to unlock the high or low speed setting. The bump enable must be held down as the speed select rocker (P) is used to change the high or low speed setting by pressing (+) to increase speed or (-) to decrease speed.

Once the slow idle speed has been set, the bump enable rocker must be pressed and released three times within two seconds to commit the operating speed to memory. If not done, the engine's new speed will only be effective until the key switch is shut off. Then the high or low operating speed will revert back to the previous setting. The fast idle speed cannot be locked to a new speed in memory. It will revert to the factory preset speed.

Fuse Holder

The fuse holder (Q) contains a 5-amp fuse for power to the instrument panel.

Tachometer (Optional)

The tachometer (R) indicates engine speed in hundreds of revolutions per minute (rpm).

Power (Percent Load) Meter (Optional)

The power meter (S) shows percent of available power being used by the engine.

Voltmeter (Optional)

The voltmeter (T) indicates system battery voltage. The amber “WARNING” light (B) will illuminate when battery voltage is too low for proper operation of the fuel injection system.

Engine Coolant Temperature Gauge (Optional)

The coolant temperature gauge (U) indicates engine coolant temperature in degrees Centigrade or Fahrenheit. It is connected to an audible alarm (G) to warn the operator if coolant temperature rises above the preset safe operating temperature.

Cruise Control (Optional)

Engine ECU's are available with and without the Cruise Control function. The Cruise Control is an Off-Road type that maintains a constant engine RPM under varying load conditions. (By contrast, automotive-type cruise control maintains a constant road speed.)

The Cruise Cancel/Resume function is a one-button Cancel then Resume control. The first time contact is made with Cruise Control active, the Cruise Control will disengage and the engine speed will drop to idle. If the contact is made again within one minute and with the engine speed above 1300 RPM, the Cruise Control will “Resume”. This feature allows the placement of the Cancel/Resume button in a convenient location in the vehicle cab and does not require the use of the normal Cruise controls for momentary interruptions in cruise operation.

The Cancel/Resume function is intended for applications like ag tractors and sprayers that turn around at the end of each row in a field. This allows the operator to use the throttle and/or brake to turn the vehicle around. When ready to resume field operations, the operator brings the engine speed above 1300 RPM and activates the Cancel/Resume function again to resume cruise speed. An internal timer gives the operator one minute to complete the turn around maneuver.

The Cruise Control has the normal functions of:

- Cruise Control power “ON” or “OFF”
- “Set” or “Bump Up” Engine Speed
- “Resume” or “Bump Down” Engine Speed
- Vehicle brake or clutch pedal to disengage Cruise Control.

The “Bump Up” and “Bump Down” speed controls allow the operator to change the set speed. Small engine speed changes can be made by “bumping” the control switch. Holding the “Bump Up” or “Bump Down” switch will result in greater engine RPM changes until the engine reaches either full speed or idle. The Cruise Control cannot operate beyond the normal min-max engine speeds.

NOTE: The Bump Throttle feature cannot be used while operating cruise control.

On 12-volt ECU's, the engine speed can be set from two different locations. The primary location would normally be in the cab of the vehicle and is used to set a constant engine speed while the vehicle is being driven. The secondary cruise control is normally used in a location that provides for engine PTO speed control and is used with the engine in “neutral” or out of gear. Both locations can have the normal “cruise” functions.

See Specifications section under Fuel Systems Specifications for the 1600 option code group which matches your code to find rated speeds and idle speeds for your engine.

AG.OUOD002,1620 -19-12NOV01-2/2


Using Diagnostic Gauge To Access Engine Information

The diagnostic gauge (A) allows the operator to view many readouts of engine functions and diagnostic trouble codes (DTCs). The gauge is linked to the electronic control system and its sensors. This allows the operator to monitor engine functions and to troubleshoot the engine systems when needed.

Press the two touch switches (B) to view the various engine functions in sequence. The displays can be selected as either customary english or metric units.

The following menu of engine parameters can be displayed on the diagnostic gauge window:

- Engine hours
- Engine rpm
- System voltage
- Percent engine load at the current rpm
- Coolant temperature
- Oil pressure
- Fuel economy
- Throttle position
- Current fuel consumption
- Active service (diagnostic) codes
- Stored service (diagnostic) codes from the engine
- Set the units for display
- View the engine configuration parameters
- Accelerator pedal position
- Percentage load at current speed
- Actual engine percent torque
- Engine speed
- Trip distance
- Total vehicle distance
- Engine hours
- Trip fuel
- Total fuel used
- Coolant temperature
- Fuel temperature
- Engine oil temperature
- Engine intercooler temperature
- Fuel deliver pressure
- Engine oil level
- Engine oil pressure



Diagnostic Gauge

A—Diagnostic Gauge
B—Touch Switches
C—Amber and Red Lights

RG10031 -JUN-28OCT99


- Coolant pressure
- Coolant level
- Wheel base vehicle speed
- Fuel rate
- Instant fuel economy check
- Average fuel economy
- Barometric pressure
- Air inlet temperature
- Boost pressure
- Intake manifold temperature
- Air filter differential pressure
- Exhaust gas temperature
- Electrical potential (voltage)
- Battery potential (voltage), switched
- Transmission oil pressure (optional)
- Transmission oil temperature (optional)
- Estimated percent fan speed

NOTE: Engine parameters which can be accessed will vary with the engine application.

The diagnostic gauge includes a two-line by eight-character backlit Liquid Crystal Display (LCD). The top line displays the data label, i.e. "EngHrs" and the bottom line displays the matching unit information, i.e. "1200 Hrs". The diagnostic gauge uses two touch switches (UP and DOWN) for scrolling through the engine parameter list and viewing the menu list. Two lights (C) (amber and red) are used to signal active trouble messages received by the diagnostic gauge.

DPSG.OUOD007,2840 -19-12NOV01-2/2

Using Touch Switches To Display Information



RG9947 -19-09DEC99

Using Touch Switches

Continued on next page

DPSG.OUOD007,2841 -19-21OCT99-1/2

The touch switches on the diagnostic gauge allow quick and easy navigation through the menu to find the information needed. The diagram on the previous page is a typical Main Menu of Engine Parameters. The Main Menu has 14 entries; the first 10 are engine data parameters, and the last four are sub-menu entry points. The following two rules are used for accessing the various items on the menus:

1. To scroll through the parameter list, press **either** the UP or DOWN touch switches.
2. To select or exit a sub-menu, **simultaneously** press the UP and DOWN switches.

Selecting Engine Data Parameters


To read any of the engine parameters, press either UP or DOWN switches (as shown on diagram) until the top line of the display shows the desired information.

Selecting Sub-Menus

Press either the UP or DOWN switches until the top line of the display shows the label of the desired sub-menu. Then press **BOTH** the UP and DOWN switches at the same time. This action will select the sub-menu and the next screen on the display will list the Sub-Menu items. This is also the way to access Diagnostic Trouble Codes (DTCs).

DPSG,OUOD007,2841 -19-21OCT99-2/2

Changing Units Of Measure (English Or Metric)



RG10018 -19-28OCT99

Changing Units Of Measure

The diagnostic gauge can display engine data in either English or Metric units. To toggle between these, the *Units Sub-Menu*, must be selected.


To select the *Units Sub-Menu*, press the UP or DOWN switches until the top line of the display reads "UNITS". Then press BOTH the UP and DOWN switches at the same time to select the *Units Sub-Menu*. The above

diagram shows the steps for selecting the desired units of measure. Two options are available:

1. Press both the switches to retain the current units designation.
2. Press either UP or DOWN switch to toggle the units selection, then press both switches to select the desired unit of measure.

DPSG,OUOD007,2842 -19-21OCT99-1/1

Viewing Engine Configuration Data



RG10019 -19-28OCT99

Viewing Engine Configuration Data

Continued on next page


DPSG,OUOD002,1927 -19-19DEC00-1/2

The diagnostic gauge can display the engine configuration data stored in the Engine Control Unit (ECU). To select the *Engine Configuration Sub-Menu* (see diagram on previous page), press the UP or DOWN switches until the top line of the display reads

“E-Config”. Then press BOTH the UP and DOWN switches at the same time to select the *Engine Configuration Sub-Menu* . The diagnostic gauge will display the engine configuration data as shown in the diagram.

DPSG,OUOD002,1927 -19-19DEC00-2/2

Viewing Active Engine Service Codes (DTC)




Viewing Active Service Codes

The diagnostic gauge continuously monitors all messages broadcast over the Control Area Network (CAN) and displays all Active Service Codes (DTCs) at the time the message is broadcast. The word "SrvcCode" is displayed on the second line. The display will cycle every 5 seconds between the currently displayed parameter and the "SrvcCode" message until the active trouble code clears. To view the active codes, select the *Service Code Sub-Menu* by pressing the UP or DOWN switches until the top line of the display reads "SrvcCode". Then press

BOTH the UP and DOWN switches at the same time to select the Service (DTC) Code Sub-Menu. The diagnostic gauge has the ability to display all Active Service Codes received. The diagram above titled *Service Codes Sub-Menu* shows the process for selecting Active Service Codes and their values.

NOTE: For a list of Service Codes or Diagnostic Trouble Codes (DTCs) and their causes, refer to *TROUBLESHOOTING Section 55*, later in this manual.

Viewing Stored Service Codes (DTC) In The Engine ECU



RG10021 -19-28OCT99

Viewing Stored Service Codes

The diagnostic gauge can request Stored Service Codes (DTCs) from the engine. The Stored Service Codes may be used for diagnostic and service needs. To view the Stored Service Codes, it is necessary to select the *DM2Codes Sub-Menu* by pressing the UP or DOWN switches until the top line of the display

reads "DM2Codes". Then press BOTH the UP and DOWN switches at the same time to select the *DM2Codes Sub-Menu*. The gauge will display the Stored Service Codes according to the menus shown in the diagram.

Engine Break-In Service

The engine is ready for normal operation. However, extra care during the first 100 hours of operation will result in more satisfactory long-term engine performance and life. DO NOT exceed 100 hours of operation with break-in oil.

1. This engine is factory-filled with John Deere ENGINE BREAK-IN OIL. Operate the engine at heavy loads with minimal idling during the break-in period.
2. If the engine has significant operating time at idle, constant speeds, and/or light load usage, or makeup oil is required in the first 100 hour period, a longer break-in period may be required. In these situations, an additional 100 hour break-in period is recommended using a new change of John Deere ENGINE BREAK-IN OIL and a new John Deere oil filter.



RG8009 —UN-06JAN99


Check Engine Oil

Continued on next page

RG, RG34710, 5553 —19-04JUN02-1/4

RG8028A —UN—15JAN99

IMPORTANT: DO NOT add makeup oil until the oil level is **BELOW** the **ADD** mark on dipstick. John Deere **ENGINE BREAK-IN OIL (TY22041)** should be used to make up any oil consumed during the break-in period.



Crosshatch Pattern On Dipstick

A—Crosshatch Pattern On Dipstick

3. Check engine oil level more frequently during engine break-in period. If oil must be added during this period, John Deere **ENGINE BREAK-IN OIL** is preferred. See **ENGINE BREAK-IN OIL**, in **Fuels, Lubricants, and Coolant Section**.

IMPORTANT: DO NOT use **PLUS-50® Engine Oil** during the break-in period of a new engine or engine that has had a major overhaul. **PLUS-50®** oil will not allow a new or overhauled engine to properly wear during this break-in period.

DO NOT fill above the crosshatch pattern (**A**) or the **FULL** mark, whichever is present. Oil levels anywhere within the crosshatch are considered in the acceptable operating range.

Specification

Engine ¹ —Oil Pressure at Full	
Load Rated Speed	345 ± 103 kPa (3.45 ± 1.03 bar) (50 ± 15 psi)
Minimum Oil Pressure at 850 rpm	105 kPa (1.05 bar) (15 psi)
Coolant Temperature Range.....	82°–94°C (180°–202°F)

PLUS-50 is a trademark of Deere & Company.

¹At normal operating temperature of 115°C (240°F) oil sump.

Continued on next page

RG, RG34710, 5553 —19—04JUN02–2/4

4. During the first 20 hours, avoid prolonged periods of engine idling or sustained maximum load operation. If engine will idle longer than 5 minutes, stop engine.
5. Before the first 100 hours (maximum), change engine oil and replace engine oil filter (A). (See CHANGING ENGINE OIL AND REPLACING FILTER in Lubrication and Maintenance/500 Hour/12 Month Section.) Fill crankcase with seasonal viscosity grade oil. (See DIESEL ENGINE OIL, in Fuels, Lubricants, and Coolant Section.)



Engine Oil Filter

A—Engine Oil Filter

NOTE: Some increase in oil consumption may be expected when low viscosity oils are used. Check oil levels more frequently.

If air temperature is below -10°C (14°F), use an engine block heater.


RG11616 -UN-24OCT01

RG, RG34710, 5553 -19-04JUN02-3/4

6. Watch coolant temperature gauge (A) closely. If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop the engine and determine the cause before resuming operation.

NOTE: When the coolant temperature gauge reads approximately 115°C (239°F), the engine will shutdown automatically, if equipped with safety controls.

7. Check poly-vee belt for proper alignment and seating in pulley grooves.



Electronic Instrument Panel

A—Coolant Temperature Gauge

RG11944 -UN-08NOV01

RG, RG34710, 5553 -19-04JUN02-4/4

Starting the Engine


The following instructions apply to the optional controls and instruments available through the John Deere Parts Distribution Network. The controls and instruments for your engine may be different from those shown here; always follow manufacturer's instructions.



CAUTION: Before starting engine in a confined building, install proper outlet exhaust ventilation equipment. Always use safety approved fuel storage and piping.

NOTE: If temperature is below 0°C (32°F), it may be necessary to use cold weather starting aids (See *COLD WEATHER OPERATION*, later in this section).

1. Perform all prestarting checks outlined in Lubrication & Maintenance/Daily Section later in this manual.
2. Open the fuel supply shut-off valve, if equipped.
3. Disengage clutch (if equipped) controlling any engine drivelines.



Use Proper Ventilation

TS220 -JUN-23AUG88

Continued on next page

RG, RG34710, 5557 -19-12NOV01-1/2

NOTE: Hand throttle (A) may have an analog potentiometer for changing engine speeds (See "Changing Engine Speeds" later in this section).

4. Turn the throttle (A) clockwise 1/3 of the way (see illustration). (If not equipped with an analog throttle, move throttle control 1/3 of the distance away from slow idle stop.)


IMPORTANT: Do not operate the starter for more than 30 seconds at a time. To do so may overheat the starter. If the engine does not start the first time, wait at least 2 minutes before trying again. If engine does not start after four attempts, see Troubleshooting Section.

5. Turn the key switch (B) clockwise to crank the engine. When the engine starts, release the key so that it returns to the "ON" position.

IMPORTANT: If the key switch is released before the engine starts, wait until the starter and the engine stop turning before trying again. This will prevent possible damage to the starter and/or flywheel.

IMPORTANT: Should the engine die when operating under load, immediately disengage any driveline clutch to remove load and restart the engine. Overheating of turbocharger parts may occur when oil flow is stopped.

6. Check all gauges for normal engine operation. If operation is not normal, stop the engine and determine the cause.



Electronic Instrument Panel

A—Hand Throttle
B—Key Start Switch
C—Oil Pressure Gauge
D—Coolant Temperature Gauge

RG11936 -UN-06NOV01

RG, RG34710, 5557 -19-12NOV01-2/2

Normal Engine Operation

Observe engine coolant temperature and engine oil pressure. Temperatures and pressures will vary between engines and with changing operating conditions, temperatures, and loads.

Normal engine coolant operating temperature range is 82°—94°C (180°—202°F). If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop engine and determine cause before resuming operation.

Operate the engine under a lighter load and at slower than normal speed for first 15 minutes after start-up. DO NOT run engine at slow idle.

IMPORTANT: Should the engine die while operating under load, immediately

remove load and restart the engine. Overheating of the turbocharger parts may occur when oil flow is stopped.

Stop engine immediately if there are any signs of part failure. Symptoms that may be early signs of engine problems are:

- Sudden drop in oil pressure
- Abnormal coolant temperatures
- Unusual noise or vibration
- Sudden loss of power
- Excessive black exhaust
- Excessive fuel consumption
- Excessive oil consumption
- Fluid leaks

RG, RG34710, 5552 -19-20MAY96-1/1

Warming Engine

The electronically-controlled engines will operate at an accelerated slow idle of 1050 rpm until the engine coolant warms up to 20° C (68° F).

IMPORTANT: To assure proper lubrication, operate engine at or below 1200 rpm with no load for 1–2 minutes. Extend this period 2–4 minutes when operating at temperatures below freezing.


Engines used in generator set applications where the governor is locked at a specified speed may not have a slow idle function. Operate these engines at high idle for 1 to 2 minutes before applying the load. This procedure does not apply to standby generator sets where the engine is loaded immediately upon reaching rated speed.

1. Check oil pressure gauge (A) as soon as engine starts. If gauge needle does not rise above minimum oil pressure specification of 105 kPa (1.05 bar) (15.0 psi) within 5 seconds, stop the engine and determine the cause. Normal engine oil pressure is 345 kPa (3.45 bar) (50 psi) at rated full load speed (1800–2500 rpm) with oil at normal operating temperature of 115°C (240°F).

NOTE: On certain engines, the oil pressure and coolant temperature gauges are replaced by indicator warning lights. The lights must be "OFF" when engine is running.

2. Watch coolant temperature gauge (B). Do not place engine under full load until it is properly warmed up. The normal engine coolant temperature range is 82°–94°C (180°–202°F).

NOTE: It is a good practice to operate the engine under a lighter load and at lower speeds than normal for the first few minutes after start-up.



Electronic Instrument Panel

A—Oil Pressure Gauge
B—Coolant Temperature Gauge

RG9917 –UN–16NOV99

Cold Weather Operation

CAUTION: Ether injector starting fluid is highly flammable. **DO NOT** use starting fluid on engines equipped with air intake heaters or glow plugs.

DO NOT use starting fluid near fire, sparks, or flames. **DO NOT** incinerate or puncture a starting fluid container.

Engines may be equipped with intake air heaters, coolant heaters, fuel heaters, or ether injectors as cold weather starting aids. Later "475" 4-valve cylinder head engines are available with glow plugs as a cold weather starting aid.

Starting aids are required below 32°F (0°C). They will enhance starting performance above these temperatures and may be needed to start applications that have high parasitic loads during cranking and/or start acceleration to idle.

Using correct grade of oil (per engine and machine operator's manual) is critical to achieving adequate cold weather cranking speed.


Other cold weather starting aids are required at temperatures below -22°F (-30°C) or at altitudes above 1500 m (5000 ft).

1. Follow steps 1—4 as listed under STARTING THE ENGINE, earlier in this section, then proceed as follows according to the instrument (gauge) panel on your engine.

2. **275-Series Engines Without Air Intake Heaters:**
Manually activate ether injectors.



Handle Starting Fluid with Care



Cold Weather Starting Guidelines

TS1356 -UN-18MAR92

RG11521 -19-10JAN01

Continued on next page

RG, RG34710, 5050 -19-26APR02-1/2

NOTE: Air intake heaters (275 engines) and glow plugs (475 engines) operate automatically through the ECU. The Engine Preheater Indicator light on these engines, located above the key switch, should always illuminate when the switch is turned ON. In warm weather, the light illuminates briefly as a light check. In cold weather, the light remains on during the automatic operation of the air intake heater or glow plugs. Operating time depends on temperature. Do not crank engine until light turns off.

275-Series Engines with Air Intake Heaters and 475-Series Engines with Glow Plugs: Turn key ON, but DO NOT crank engine until Engine Preheater Indicator light turns off.

3. Follow remaining steps 5—6 as listed under earlier in this section.

Additional information on cold weather operation is available from your authorized servicing dealer.

RG, RG34710, 5050 -19-26APR02-2/2

Using a Booster Battery or Charger

A 12-volt booster battery can be connected in parallel with battery (ies) on the unit to aid in cold weather starting. ALWAYS use heavy duty jumper cables.

CAUTION: Gas given off by battery is explosive. Keep sparks and flames away from battery. Before connecting or disconnecting a battery charger, turn charger off. Make last connection and first disconnection at a point away from battery. Always connect **NEGATIVE (-)** cable last and disconnect this cable first.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

IMPORTANT: Be sure polarity is correct before making connections. Reversed polarity will damage electrical system. Always connect positive to positive and negative to ground. Always use 12-volt booster battery for 12-volt electrical systems and 24-volt booster battery (ies) for 24-volt electrical systems.


1. Connect booster battery or batteries to produce the required system voltage for your engine application.

NOTE: To avoid sparks, **DO NOT** allow the free ends of jumper cables to touch the engine.


2. Connect one end of jumper cable to the **POSITIVE (+)** post of the booster battery.
3. Connect the other end of the jumper cable to the **POSITIVE (+)** post of battery connected to starter.
4. Connect one end of the other jumper cable to the **NEGATIVE (-)** post of the booster battery.
5. ALWAYS complete the hookup by making the last connection of the **NEGATIVE (-)** cable to a good ground on the engine frame and away from the battery (ies).



Exploding Battery



12-Volt System



24-Volt System

A—12-Volt Machine Battery (ies)
 B—12-Volt Booster Battery (ies)
 C—Booster Cable
 D—Cable to Starting Motor

TS204 -JUN-23AUG88

RG4678 -JUN-14DEC88

RG4698 -JUN-14DEC88

Continued on next page

RG, RG34710, 5564 -19-20MAY96-1/2

6. Start the engine. Disconnect jumper cables immediately after engine starts. Disconnect NEGATIVE (–) cable first.

RG, RG34710, 5564 –19–20MAY96–2/2

Avoid Excessive Engine Idling

Prolonged idling may cause the engine coolant temperature to fall below its normal range. This, in turn, causes crankcase oil dilution, due to incomplete fuel combustion, and permits formation of gummy deposits on valves, pistons, and piston rings. It also promotes rapid accumulation of engine sludge and unburned fuel in the exhaust system.

Once an engine is warmed to normal operating temperatures, engine should be idled at slow idle

speed. Slow idle speed for this engine is 850 rpm at factory. If an engine will be idling for more than 5 minutes, stop and restart later.

NOTE: Generator set applications where the governor is locked at a specified speed may not have a slow idle function. These engines will idle at no load governed speed (high idle).

RG, RG34710, 5562 –19–20MAY96–1/1

Changing Engine Speeds

Changing from slow to fast speed using High-Low Speed Select Rocker Switch (A):

- For slow speed, press lower half of switch (indicated by turtle symbol).
- For fast speed, press upper half of switch (indicated by rabbit symbol).

NOTE: To adjust preset fast or slow speeds for High-Low Speed Select Rocker Switch:

1. Select fast (rabbit) or slow (turtle) position on High-Low Speed Select Rocker Switch (A).
2. Press and hold top or bottom half of Bump Speed Enable Rocker Switch (B) while using Speed Select Rocker Switch (C).
3. Use Speed Select Rocker Switch (C) to bump engine speed up (+) or down (-).


NOTE: Once the speed has been set, the Bump Speed Enable Switch (B) must be pressed and released three times within two seconds to commit the new slow or fast speed to memory. If not done, the engine's new slow or fast speed will only be effective until the key switch is shut off. Then the speed will revert to its previous setting.

Changing engine speed using optional analog potentiometer throttle (D):

NOTE: Pushing in on analog potentiometer will immediately take engine to slow idle speed.

1. Set High-Low Speed Select Rocker Switch (A) to low speed position.
2. Turn potentiometer throttle clockwise to increase speed or counterclockwise to decrease speed.

NOTE: Engine Control Unit (ECU) reads the higher of the High-Low Speed Select Rocker Switch or the Analog Throttle(s) Speed Settings. With High-Low switch at low speed, Analog Throttle(s) will control speed higher than low idle setting.



Changing Engine Speed

- A—High-Low Speed Select Rocker Switch
 B—Bump Speed Enable Rocker Switch
 C—Speed Select Rocker Switch
 D—Analog Potentiometer Throttle (Optional)

RG9918 —UN—16NOV99

Stopping The Engine

1. Disengage clutch, if equipped, controlling engine power driveline.

IMPORTANT: Before stopping an engine that has been operating at working load, idle engine at least 2 minutes at 1000—1200 rpm to cool hot engine parts.

Engines in generator set applications where the ECU is locked at a specified speed and no slow idle function is available, run engine for at least 2 minutes at fast idle and no load.

2. Run engine at 1000—1200 rpm for at least 2 minutes to cool.

Panels with High-Low Speed Select Rocker Switch (B) only: Set rpm using Bump Speed Enable Switch (C) with Speed Select Rocker Switch (D).


Panels with optional Analog Throttle (E): Set either High-Low Speed Select Switch (B) or Analog Throttle (E) to low idle, and set desired speed with remaining control.

NOTE: Engine Control Unit (ECU) reads the higher of the High-Low Speed Select Rocker Switch or the Analog Throttle(s) Speed settings.


3. Push in on analog throttle potentiometer handle (if equipped) so that engine goes to slow idle, or set slow speed with High-Low Speed Select Rocker Switch.

4. Turn key switch (A) to “OFF” position to stop the engine. Remove ignition key.

IMPORTANT: Make sure that exhaust stack rain cap (F) is installed when engine is not running. This will prevent water and dirt from entering engine.



Electronic Instrument Panel



Exhaust Stack Rain Cap

- A—Key Switch
- B—High-Low Speed Select Rocker Switch
- C—Bump Speed Enable Switch
- D—Speed Select Rocker Switch
- E—Analog Throttle (Optional)
- F—Exhaust Stack Rain Cap

RG9916 —UN—16NOV99


RG9933 —UN—18NOV99

Auxiliary Gear Drive Limitations

IMPORTANT: When attaching an air compressor, hydraulic pump, or other accessory to be driven by the auxiliary gear drive (A) (engine timing gear train at front of engine), power requirements of the accessory must be limited to values listed below:

- 30 kW (40 hp) Continuous Operation at 2500 rpm
- 37 kW (50 hp) Intermittent Operation at 2500 rpm

A—Auxiliary Gear Drive



Auxiliary Gear Drive

RG7634A -JUN-22JAN99

RG, RG34710, 5555 -19-20MAY96-1/1

Generator Set (Standby) Applications

To assure that your engine will deliver efficient standby operation when needed, start engine and run at rated speed (with 50%—70% load) for 30 minutes every 2 weeks. DO NOT allow engine to run extended period of time with no load.

RG, RG34710, 5556 -19-20MAY96-1/1


Lubrication and Maintenance

Observe Service Intervals

Using hour meter (A) as guide, perform all services at the hourly intervals indicated on following pages. At each scheduled maintenance interval, perform all previous maintenance operations in addition to the ones specified. Keep a record of hourly intervals and services performed using charts provided in Lubrication and Maintenance Records Section.

IMPORTANT: Recommended service intervals are for normal operating conditions. Service **MORE OFTEN** if engine is operated under adverse conditions. Neglecting maintenance can result in failures or permanent damage to the engine.

A—Hour Meter



Electronic Instrument Panel Hour Meter

DPSG,OUOE003,20 -19-12NOV01-1/1

Use Correct Fuels, Lubricants, and Coolant

IMPORTANT: Use only fuels, lubricants, and coolants meeting specifications outlined in Fuels, Lubricants, and Coolant Section when servicing your John Deere Engine.

Consult your John Deere engine distributor, servicing dealer or your nearest John Deere Parts Network for recommended fuels, lubricants, and coolant. Also available are necessary additives for use when operating engines in tropical, arctic, or any other adverse conditions.



DPSG,OUOE003,20 -19-06JAN99-1/1

Lubrication and Maintenance Service Interval Chart—Standard Industrial Engines

NOTE: The service intervals below are for standard industrial engines. See details in Sections which follow these charts.

Item	Lubrication and Maintenance Service Intervals			
	Daily	500 Hour/ 12 Month	2000 Hour/ 24 Month	As Required
Check Engine Oil and Coolant Level	•			
Check Fuel Filter/Water Bowl	•			
Check Air Cleaner Dust Unloader Valve & Restriction Indicator Gauge ^a	•			
Visual Walk Around Inspection	•			
Service Fire Extinguisher		•		
Service Battery		•		
Check Manual Belt Tensioner and Belt Wear		•		
Change Engine Oil And Replace Oil Filter ^{b, c}		•		
Clean Crankcase Vent Tube		•		
Check Air Intake Hoses, Connections, & System		•		
Replace Fuel Filter Elements (Bleed System)		•		
Check Automatic Belt Tensioner and Belt Wear		•		
Check Engine Electrical Ground Connection		•		
Check Cooling System		•		
Coolant Solution Analysis-Add SCAs as required		•		
Pressure Test Cooling System		•		
Check Crankshaft Vibration Damper (6.8 L Engines) ^d			•	
Flush Cooling System ^e			•	
Test Thermostats			•	
Check and Adjust Engine Valve Clearance			•	
Test Glow Plugs (4045HF475, 6068HF475)			•	
Add Coolant				•
Replace Air Cleaner Elements				•
Replace Poly-vee Belt				•

^aReplace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H₂O.

^bDuring engine break-in, change the oil and filter for the first time before 100 hours of operation.

^cIf the recommended engine oils, John Deere PLUS-50® or ACEA-E4/E5, are not used, the oil and filter change interval is reduced to every 250 hours. If diesel fuel with a sulfur content greater than 0.05% is used, the oil and filter change interval is also reduced.

^dReplace crankshaft damper every 4500 hours or 60 months, whichever occurs first.

^eIf John Deere COOL-GARD is used, the flushing interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished as needed by adding a supplemental coolant additive, the flushing interval may be extended to 5000 hours or 60 months, whichever occurs first.

Lubrication and Maintenance

	Lubrication and Maintenance Service Intervals			
Item	Daily	500 Hour/ 12 Month	2000 Hour/ 24 Month	As Required
Check Fuses				•
Bleed Fuel System				•

RG, RG34710, 7559 -19-04JUN02-2/2

Lubrication and Maintenance Service Interval Chart—Generator (Standby) Applications

NOTE: Use service intervals listed below for generator (standby) applications. Match service items below to titles in Lubrication and Maintenance Sections for procedures.

Item	Lubrication and Maintenance Service Intervals			
	Every 2 Weeks	500 Hours or 12 Months	2000 Hours or 24 Months	As Required
Operate Engine at Rated Speed and 50%–70% Load a Minimum of 30 Minutes	•			
Check Engine Oil and Coolant Level	•			
Check Fuel Filter/Water Bowl	•			
Check Air Cleaner Dust Unloader Valve & Restriction Indicator Gauge ^a	•			
Visual Walk Around Inspection	•			
Service Fire Extinguisher	•			
Check Engine Mounts		•		
Service Battery		•		
Clean Crankcase Vent Tube		•		
Check Air Intake Hoses, Connections, & System		•		
Replace Fuel Filter Elements—Bleed Fuel System		•		
Check Belt Tensioner and Belt Wear		•		
Check Engine Electrical Ground Connection		•		
Check Cooling System		•		
Coolant Solution Analysis-Add SCAs as required		•		
Pressure Test Cooling System		•		
Change Engine Oil And Replace Oil Filter ^{b, c}		•		
Check Crankshaft Vibration Damper (6.8 L Engines) ^d		•		
Flush Cooling System		•		
Test Thermostats		•		
Check and Adjust Engine Valve Clearance		•		
Test Glow Plugs (4045HF475, 6068HF475)		•		
Add Coolant				•
Replace Air Cleaner Elements				•
Replace Poly-vee Belt				•
^a Replace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H ₂ O.				
^b During engine break-in, change the oil and filter for the first time before 100 hours of operation.				
^c If the recommended engine oils, John Deere PLUS-50® or ACEA-E4/E5, are not used, the oil and filter change interval is reduced to every 250 hours. If diesel fuel with a sulfur content greater than 0.05% is used, the oil and filter change interval is also reduced.				
^d Replace crankshaft damper every 4500 hours or 60 months, whichever occurs first.				

Continued on next page

RG, RG34710, 7560 -19-04JUN02-1/2

Lubrication and Maintenance

Item	Lubrication and Maintenance Service Intervals			
	Every 2 Weeks	500 Hours or 12 Months	2000 Hours or 24 Months	As Required
Check Fuses				•
Bleed Fuel System				•

RG, RG34710, 7560 –19–04JUN02–2/2

Lubrication & Maintenance/Daily

Daily Prestarting Checks

Do the following **BEFORE STARTING THE ENGINE** for the first time each day:

IMPORTANT: DO NOT add makeup oil until the oil level is **BELOW** the crosshatch marks on the dipstick.

1. Check engine oil level on dipstick. Add as required, using seasonal viscosity grade oil. (See **DIESEL ENGINE OIL** in Fuels, Lubricants, and Coolant Section for oil specifications.)


Depending on application, oil may be added at left (A) or right (B) side oil filler cap and rocker arm cover filler cap (C) locations.

IMPORTANT: DO NOT fill above the top mark on the dipstick. Oil levels anywhere within crosshatch (D) are considered in the acceptable operating range.


A—Left Side Oil Filler Cap
B—Right Side Oil Filler Cap
C—Cover Oil Filler Cap
D—Crosshatch On Dipstick



Left Side Oil Filler Cap




Right Side Oil Filler Cap



Rocker Arm Cover Filler Cap

RG8028B -UN-15JAN99



Crosshatch on Dipstick

Continued on next page

DPSG,OUOE003,20 -19-23MAY02-1/4


CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Only remove filler cap when engine is cold or when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


2. Check the coolant level when engine is cold. Coolant level should be at bottom of filler neck. Fill radiator (A) with proper coolant solution if level is low. (See **ADDING COOLANT** in Service As Required Section.) Check overall cooling system for leaks.

NOTE: Refer to your vehicle's operator's manual for recommendations for non-John Deere supplied accessories.

A—Fill Radiator



High-Pressure Fluids



Fill Radiator

RG4675 -UN-14DEC88

TS281 -UN-23AUG88

Continued on next page

DPSG,OUOE003,20 -19-23MAY02-2/4


NOTE: Engine may be equipped with a water sensor at the fuel filter. In this case, an indicator light will signal the operator that water should be drained from the filter bowl.

3. Check the fuel filters for water or debris. If filter is fitted with a see-through bowl, drain as needed based on a daily visual inspection.

IMPORTANT: Drain water into a suitable container and dispose of properly.


- a. Loosen drain plugs (A) at bottom of fuel filters or bowls, if equipped, two or three turns.
- b. Loosen air bleed plug (B) two full turns on fuel filter mounting and drain water from bottom until fuel starts to drain out.
- c. When fuel starts to drain out, tighten drain plugs securely.

After draining water from the fuel filters, the filters must be primed by bleeding all air from the fuel system. See **BLEEDING FUEL SYSTEM** in Service As Required Section, later in this manual



RG12222 -UN-24MAY02

Drain Final Fuel Filter



RG11955 -UN-05DEC01

Drain Primary Fuel Filter (If Equipped)

A—Drain Plug
B—Air Bleed Plug


Continued on next page

DPSG,OUOE003,20 -19-23MAY02-3/4

4. If the air cleaner has an automatic dust unloader valve (A), squeeze the unloader valve on air cleaner assembly to clear away any dust buildup.

If equipped with air intake restriction indicator gauge (B), check gauge to determine if air cleaner needs to be serviced.

IMPORTANT: Maximum air intake restriction is 6.25 kPa (0.06 bar) (1.0 psi) (25 in. H₂O). A clogged air cleaner element will cause excessive intake restriction and a reduced air supply to the engine.



RG7332A -UN-22JAN99

Dust Unloader Valve and Indicator Gauge

A—Dust Unloader Valve
B—Air Restriction Indicator

5. Make a thorough inspection of the engine compartment. Look for oil or coolant leaks, worn fan and accessory drive belts, loose connections and trash build-up. Remove trash buildup and have repairs made as needed if leaks are found.

NOTE: Wipe all fittings, caps, and plugs before performing any maintenance to reduce the chance of system contamination.

Inspect:

- Radiator for leaks and trash build-up.
- Air intake system hoses and connections for cracks and loose clamps.
- Fan, alternator, and accessory drive belts for cracks, breaks or other damage.
- Coolant pump for coolant leaks.

NOTE: It is normal for a small amount of leakage to occur as the engine cools down and parts contract. Excessive coolant leakage may indicate the need to replace the coolant pump seal. Contact your engine distributor or servicing dealer for repairs.

DPSG,OUOE003,20 -19-23MAY02-4/4

Servicing Fire Extinguisher

A fire extinguisher (A) is available from your authorized servicing dealer or engine distributor.

Read and follow the instructions which are packaged with it. The extinguisher should be inspected at least every 500 hours of engine operation or once a month. Once extinguisher is operated, no matter how long, it must be recharged. Keep record of inspections on the tag which comes with the extinguisher instruction booklet.

A—Fire Extinguisher



Fire Extinguisher

RG, RG34710, 5567 -19-04JUN02-1/1

Checking Engine Mounts

Engine mounting is the responsibility of the vehicle or generator manufacturer. Follow manufacturer's guidelines for mounting specifications.

IMPORTANT: Use only Grade SAE 8 or higher grade of hardware for engine mounting.

1. Check the engine mounting bracket, vibration isolators, and mounting bolts on support frame and engine block for tightness. Tighten as necessary.
2. Inspect overall condition of vibration isolators, if equipped. Replace isolators if rubber has deteriorated or mounts have collapsed, as necessary.

DPSG, RG34710, 111 -19-12NOV01-1/1

Servicing Battery



CAUTION: Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded **NEGATIVE (-)** battery clamp first and replace it last.



Exploding Battery

TS204 -JUN-23AUG88

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

1. On regular batteries, check electrolyte level. Fill each cell to bottom of filler neck with distilled water.

NOTE: Low-maintenance or maintenance-free batteries should require little additional service. However, electrolyte level can be checked by cutting the center section of decal on dash-line, and removing cell plugs. If necessary, add clean, soft water to bring level to bottom of filler neck.

2. Keep batteries clean by wiping them with a damp cloth. Keep all connections clean and tight. Remove any corrosion, and wash terminals with a solution of 1 part baking soda and 4 parts water. Tighten all connections securely.

NOTE: Coat battery terminals and connectors with a mixture of petroleum jelly and baking soda to retard corrosion.

3. Keep battery fully charged, especially during cold weather. If a battery charger is used, turn charger off before connecting charger to battery(ies). Attach **POSITIVE (+)** battery charger lead to **POSITIVE (+)** battery post. Then attach **NEGATIVE (-)** battery charger lead to a good ground.

Continued on next page

RG, RG34710, 5568 -19-20MAY96-1/2

CAUTION: Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10–15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.



Sulfuric Acid

TS203 -JUN-23AUG88

In freezing weather, run engine at least 30 minutes to assure thorough mixing after adding water to battery.

If necessary to replace battery(ies), replacements must meet or exceed the following recommended capacities at -18°C (0°F):

Specification

12 Volt Standard Duty Starter—	
Cold Cranking Amps	640
12 Volt Heavy Duty Starter—Cold	
Cranking Amps	800
24 Volt Standard Duty Starter—	
Cold Cranking Amps	570

Manual Belt Tensioner Adjustment

NOTE: Two types of manual tensioners shown.

NOTE: Inspect belts for cracks, fraying, or stretched-out areas. Replace if necessary.

As a reference check, twist belt in the middle of a 254—305 mm (10—12 in.) span with two fingers. A properly tensioned belt will turn 75—85 degrees. If belt turns more, it needs to be tightened. If belt turns less, it needs to be loosened.

NOTE: If timing gear cover or alternator bracket interfere with installation/centering of belt tension gauge (A), install gauge with face toward engine.

1. Install JDG1341 Belt Tension Gauge (A) on belt, halfway between pulleys as shown. (JDG1341 Belt Tension Gauge available from local John Deere Dealer or Distributor.)
2. Loosen cap screws (B) and (C).
3. Slide alternator or tensioner bracket (D) in slot by hand to remove all excess slack in belt.

IMPORTANT: Do not pry against alternator rear frame.

4. Stretch belt by prying outward on alternator front frame or tensioner bracket. Observing tension gauge, stretch the belt until specified tension is achieved.


Specification

New Belt—Tension..... 470—650 N (105—145 lb-force)
Used Belt—Tension..... 400—580 N (90—130 lb-force)


5. Tighten cap screws (B) and (C).

NOTE: After ten minutes run-in, new belts are considered used. Belt tension must then be rechecked per used belt specifications.

6. Run engine for ten minutes and immediately re-check belt tension per used belt specification above.
7. Reset belt tension as necessary.



Check Belt Tension



Adjust Belt Tension

A—Belt Tension Gauge
B—Cap Screw
C—Cap Screw
D—Tensioner Bracket


Manual Belt Tensioner Adjustment Using Belt Tension Tool (Alternate Method For Engines Without Auxiliary Drive)

NOTE: The JD1520 Belt Tension Tool may not be compatible with all alternators. In that case, use the preceding method for belt tensioning.


NOTE: Inspect belts for cracks, fraying, or stretched-out areas. Replace if necessary.

As a reference check, twist belt in the middle of a 254—305 mm (10—12 in.) span with two fingers. A properly tensioned belt will turn 75—85 degrees. If belt turns more, it needs to be tightened. If belt turns less, it needs to be loosened.

1. Loosen upper (A) and lower (B) alternator bracket cap screws. Lower cap screw must remain tight enough to prevent excessive alternator play but allow alternator to pivot by hand.
2. Insert JDG1520 Belt Tension Tool (C) behind belt (D) and over alternator mounting screw.



Alternator Bracket and Cap Screws



Belt Tension Tool

- A—Upper Alternator Bracket Cap Screw
- B—Lower Alternator Bracket Cap Screw
- C—JDG1520 Belt Tension Tool
- D—Belt

Continued on next page

OUOD002,000016D -19-05JUN02-1/2

3. Place torque wrench (C) on belt tensioning tool (B) at 90° to tool. Pivot alternator (A) until desired torque is achieved according to specification using the following table.


Specification

New Belt—Tension..... 470—650 N (105—145 lb-force)
Used Belt—Tension..... 400—580 N (90—130 lb-force)


JDG1520 Belt Tensioning Tool Torque Table	
Desired Belt Tension N (lb-force)	Applied Torque N•m (lb-ft)
445 (100)	108 (90)
489 (110)	115 (85)
534 (120)	122 (90)
623 (140)	135 (100)

4. While holding tension with torque wrench (B), scribe a reference mark (D) on alternator in line with notch (E) on upper alternator bracket.
5. Continue to hold tension with torque wrench and tighten upper alternator bracket cap screw.
6. Check position of reference mark to see if alternator moved while tightening. If alternator moved, loosen upper alternator bracket cap screw and repeat the tension adjustment procedure.
7. Remove belt tension tool and tighten lower alternator bracket cap screw.

A—Alternator
B—Belt Tensioning Tool
C—Torque Wrench
D—Reference Mark
E—Alternator Upper Bracket Notch



Belt Tension Tool and Torque Wrench



Scribe Reference Mark

OUOD002,000016D -19-05JUN02-2/2

Changing Engine Oil and Replacing Filter

Your engine is equipped with a special oil filter (A).

NOTE: During break-in, change engine oil and filter for the first time before 100 hours maximum of operation.

After break-in, if John Deere PLUS-50® or ACEA-E4/E5 engine oil **and** a John Deere special oil filter are used, the oil and filter change interval is 500 hours or every 12 months, whichever comes first.

NOTE: If the above recommendations are not followed, the recommended oil and filter change interval is every 250 hours/ or 6 months. If diesel fuel with a sulfur content greater than 0.05% (500 ppm) is used, the oil and filter change interval is also reduced.

OILSCAN® or OILSCAN PLUS® is a John Deere sampling program to help you monitor machine performance and identify potential problems before they cause serious damage. OILSCAN® and OILSCAN PLUS® kits are available from your John Deere engine distributor or servicing dealer. Oil samples should be taken prior to the oil change. Refer to instructions provided with kit.

To change engine oil and oil filter:

1. Run engine approximately 5 minutes to warm up oil. Shut engine off.
2. Remove oil pan drain plug (arrow).
3. Drain crankcase oil from engine while warm.

NOTE: Drain plug location may vary, depending on the application.



Special Oil Filter



Oil Pan Drain Plug

A—Oil Filter Element

RG11616 —UN-24OCT01

RG4881 —UN-29NOV88

PLUS-50 is a trademark of Deere & Company.
 OILSCAN is a trademark of Deere & Company.
 OILSCAN PLUS is a trademark of Deere & Company.

Continued on next page

OUOD002,0000168 —19-05JUN02-1/3

4. Turn filter element (A) using a suitable filter wrench to remove. Discard oil filter element.

NOTE: Depending on engine application, oil filter may be located on either side of the engine in a high- or low-mount location.

IMPORTANT: Filtration of oils is critical to proper lubrication. Always change filter regularly. Use filter meeting John Deere performance specifications.

5. Apply clean engine oil to the new filter at the inner (B) and outer (C) seals and to filter threads.
6. Wipe both sealing surfaces of the header (D, E) with a clean rag. Ensure dust seal (F) is in place, replace if damaged.

IMPORTANT: When installing filter element, **HAND TIGHTEN** only. A filter wrench may be used for **REMOVAL ONLY**.

7. Install and tighten oil filter by hand until firmly against dust seal (F). **DO NOT** apply an extra 3/4 to 1-1/4 turn after gasket contact as done with standard filters.
8. Tighten drain plug to specifications.

Specification


Oil Pan Drain Plug With Copper Washer—Torque	70 N•m (52 lb ft)
Oil Pan Drain Plug With O-Ring—Torque	50 N•m (37 lb ft)
Oil Pan Drain Plug With Packing (6068 Engine Code 1961, Steel Oil Pan)—Torque.....	40 N•m (29 lb ft)



Oil Filter And Mounting Header



Oil Filter Seals



Filter And Mounting Header

- A—Oil Filter Element
- B—Inner Seal
- C—Outer Seal
- D—Sealing Surface On Header
- E—Sealing Surface On Header
- F—Dust Seal

Continued on next page

OUOD002,0000168 -19-05JUN02-2/3

RG11616 -UN-24OCT01

RG11617 -UN-24OCT01

RG11618 -UN-24OCT01


9. Fill engine crankcase with correct John Deere engine oil through rocker arm cover opening (A) or either side oil filler (B) depending on engine application. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section for determining correct engine oil.)

To determine the correct oil fill quantity for your engine, see ENGINE CRANKCASE OIL FILL QUANTITIES in the Specifications Section of this manual.


IMPORTANT: Immediately after completing any oil change, crank engine for 30 seconds without permitting engine to start. This will help insure adequate lubrication to engine components before engine starts.

NOTE: Crankcase oil capacity may vary slightly. ALWAYS fill crankcase within crosshatch marks on dipstick. DO NOT overfill.

10. Start engine and run to check for possible leaks.
11. Stop engine and check oil level after 10 minutes. Oil level reading should be within crosshatch of dipstick.



Rocker Arm Cover Oil Filler Opening



Oil Filler At Side Of Engine

A—Rocker Arm Cover Oil Filler Opening
B—Oil Filler At Side Of Engine

RG11619 -UN-24OCT01

RG11942 -UN-24OCT01


OUOD002,0000168 -19-05JUN02-3/3

Cleaning Crankcase Vent Tube

If you operate the engine in dusty conditions, clean the tube at shorter intervals.

1. Remove and clean crankcase vent tube (A).
2. Install the vent tube. Be sure the O-ring fits correctly in the rocker arm cover for elbow adapter. Tighten hose clamp securely.

A—Crankcase Vent Tube



Crankcase Vent Tube

RG8017A -UN-19JUN00

RG, RG34710, 5574 -19-12NOV01-1/1

Checking Air Intake System


IMPORTANT: The air intake system must not leak. Any leak, no matter how small, may result in internal engine damage due to abrasive dirt and dust entering the intake system.

1. Inspect all intake hoses (piping) for cracks. Replace as necessary.
2. Check clamps (A) on piping which connect the air cleaner, engine and, if present, turbocharger. Tighten clamps as necessary. This will help prevent dirt from entering the air intake system through loose connections causing internal engine damage.
3. If engine has a rubber dust unloader valve (B), inspect the valve on bottom of air cleaner for cracks or plugging. Replace as necessary.


IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.

4. Test air restriction indicator (C) for proper operation. Replace indicator as necessary.

IMPORTANT: If not equipped with air restriction indicator, replace air cleaner elements at 500 Hours or 12 Months, whichever occurs first.



Check Clamps



Underloader Valve and Air Restriction Indicator

A—Clamps
B—Dust Unloader Valve
C—Air Restriction Indicator

RG, RG34710, 5575 -19-23NOV01-1/1

Replacing Fuel Filter Elements

Engines may be equipped with either a primary fuel filter (or pre-filter) with water bowl and a final filter, or only a final filter including water bowl. Both filters are replaced at the same 500-hour interval.


CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.


1. Close fuel shut-off valve, if equipped.
2. Thoroughly clean fuel filter assemblies and surrounding areas.
3. Disconnect water sensor wiring (if equipped).
4. Loosen drain plugs (C) and drain fuel into a suitable container.

NOTE: Lifting up on retaining ring (A) as it is rotated helps to get it past raised locators.


5. Firmly grasp the retaining ring (A) and rotate it counterclockwise 1/4 turn. Remove ring with filter element (B).
6. Inspect filter mounting base for cleanliness. Clean as required.



High-Pressure Fluids



Final Fuel Filter



Primary Fuel Filter (or Pre-Filter, If Equipped)

- A—Retaining Ring
- B—Filter Element
- C—Drain Plug
- D—Bleed Plug
- E—Water Bowl

X9811 -UN-23AUG88

RG7721 -UN-15JAN99

RG11954 -UN-05DEC01

Continued on next page

RG, RG34710, 5576 -19-05JUN02-1/2

NOTE: Raised locators on fuel filter canisters must be indexed properly with slots in mounting base for correct installation.

7. Install new filter elements onto mounting bases. Be sure elements are properly indexed and firmly seated on bases. It may be necessary to rotate filters for correct alignment.

If equipped with water separator bowl (E), remove filter element from separator bowl. Drain and clean separator bowl. Dry with compressed air. Install bowl onto new element. Tighten securely.

8. Align keys on filter element with slots in filter base.
9. Install retaining ring onto mounting base making certain dust seal is in place on filter base. Hand tighten ring (about 1/3 turn) until it "snaps" into the detent. DO NOT overtighten retaining ring.

NOTE: The proper installation is indicated when a "click" is heard and a release of the retaining ring is felt.

A plug is provided with the new element for plugging the used element.

10. Reconnect water sensor wiring (if equipped).
11. Open fuel shut-off valve and bleed the fuel system. (See BLEEDING FUEL SYSTEM in Service As Required Section.) Tighten bleed plug (D).

RG, RG34710, 5576 -19-05JUN02-2/2

Checking Belt Tensioner Spring Tension and Belt Wear (Automatic Tensioner)

Belt drive systems equipped with automatic (spring) belt tensioners cannot be adjusted or repaired. The automatic belt tensioner is designed to maintain proper belt tension over the life of the belt. If tensioner spring tension is not within specification, replace tensioner assembly.


RG, RG34710, 5578 -19-05JUN02-1/3

Checking Belt Wear

The belt tensioner is designed to operate within the limit of arm movement provided by the cast stops (A and B) when correct belt length and geometry is used.

Visually inspect cast stops (A and B) on belt tensioner assembly.

If the tensioner stop on swing arm (A) is hitting the fixed stop (B), check mounting brackets (alternator, belt tensioner, idler pulley, etc.) and the belt length. Replace belt as needed (see REPLACING FAN AND ALTERNATOR BELTS in Service As Required Section).



Cast Stops

A—Cast Stops
B—Cast Stop


Continued on next page

RG, RG34710, 5578 -19-05JUN02-2/3

Checking Tensioner Spring Tension


A belt tension gauge will not give an accurate measure of the belt tension when automatic spring tensioner is used. Measure tensioner spring tension using a torque wrench and procedure outlined below:

1. Release tension on belt using a breaker bar and socket on tension arm. Remove belt from pulleys.
2. Release tension on tension arm and remove breaker bar.
3. Put a mark (A) on swing arm of tensioner as shown.
4. Measure 21 mm (0.83 in.) from (A) and put a mark (B) on tensioner mounting base.
5. Install torque wrench (C) so that it is aligned with centers of pulley and tensioner. Rotate the swing arm using a torque wrench until marks (A and B) are aligned.
6. Record torque wrench measurement and compare with specification below. Replace tensioner assembly as required.



Marks on Tensioner

RG7977 -UN-14NOV97



Align Marks


RG8037C -UN-11SEP00

Specification

Spring Tension—Torque 18-22 N•m (13-16 lb-ft)

NOTE: Threads on belt tensioner roller cap screw are **LEFT-HAND** threads

A—Mark On Swing Arm
B—Mark On Tensioner Mounting Base
C—Torque Wrench



Align Torque Wrench With Pulley and Tensioner

RG12065 -UN-28JAN02

RG, RG34710, 5578 -19-05JUN02-3/3

Checking Engine Electrical Ground Connections

Keep all engine ground connections clean and tight to prevent electrical arcing which can damage electronic components.

Also see precautions in Troubleshooting Section when welding on engine or machine.

OUOD002,0000169 -19-23NOV01-1/1

Checking Cooling System




CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Retighten fitting or plug when all the air has been expelled.

1. Visually check entire cooling system for leaks. Tighten all clamps securely.
2. Thoroughly inspect all cooling system hoses for hard, flimsy, or cracked condition. Replace hoses if any of the above conditions are found.



High-Pressure Fluids

TS281 -UN-23AUG88

RG, RG34710, 5580 -19-12NOV01-1/1

Replenishing Supplemental Coolant Additives (SCAs) Between Coolant Changes

IMPORTANT: Do not add supplemental coolant additives when the cooling system is drained and refilled with John Deere COOL-GARD®

NOTE: If system is to be filled with coolant that does not contain SCAs, the coolant must be precharged. Determine the total system capacity and premix with 3% John Deere Coolant Conditioner.


Through time and use, the concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD® is used. The cooling system must be recharged with additional supplemental coolant additives available in the form of liquid coolant conditioner.

Maintaining the correct coolant conditioner concentration (SCAs) and freeze point is essential in your cooling system to protect against rust, liner pitting and corrosion, and freeze-ups due to incorrect coolant dilution.


John Deere LIQUID COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

DO NOT mix one brand of SCA with a different brand.

Test the coolant solution at 500 hours or 12 months of operation using either John Deere coolant test strips or a COOLSCAN® or COOLSCAN PLUS® analysis. If a COOLSCAN® or COOLSCAN PLUS® analysis is not available, recharge the system per instructions printed on label of John Deere Liquid Coolant Conditioner.



Radiator Coolant Check



JTO7298 Coolant/Battery Tester

COOL-GARD is a registered trademark of Deere & Company
COOLSCAN is a registered trademark of Deere & Company
COOLSCAN PLUS is a registered trademark of Deere & Company

Continued on next page

DPSG,OUOD002,1921 -19-23NOV01-1/2

IMPORTANT: ALWAYS maintain coolant at correct level and concentration. DO NOT operate engine without coolant even for a few minutes.

If frequent coolant makeup is required, the glycol concentration should be checked with JTO7298 Coolant/Battery Tester to ensure that the desired freeze point is maintained. Follow manufacturer's instructions provided with Coolant/Battery Tester.

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.

The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

See DIESEL ENGINE COOLANTS AND SUPPLEMENTAL ADDITIVE INFORMATION for proper mixing of coolant ingredients before adding to the cooling system.

DPSG,OUOD002,1921 -19-23NOV01-2/2

Testing Diesel Engine Coolant

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.

Test the coolant solution at intervals of 12 months or less and whenever excessive coolant is lost through leaks or overheating.

Coolant Test Strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective method to check the freeze point and additive levels of your engine coolant.


Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.

COOLSCAN Or COOLSCAN PLUS

For a more thorough evaluation of your coolant, perform a COOLSCAN or COOLSCAN PLUS analysis. See your John Deere dealer for information about COOLSCAN or COOLSCAN PLUS.


OUOD002,0000175 -19-23NOV01-1/1

Pressure Testing Cooling System



Test Radiator Cap

RG6557 -JUN-20JAN93



Test Cooling System

RG6558 -JUN-20JAN93

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

NOTE: These tests apply only to John Deere radiators. For other brands, see manufacturers literature.

Test Radiator Cap

1. Remove radiator cap and attach to D05104ST Tester as shown.
2. Pressurize cap to specification listed. Gauge should hold pressure for 10 seconds at least to pressure listed if cap is acceptable.

If gauge does not hold pressure, replace radiator cap.

Specification

Radiator Cap Holding Pressure (Not Opening For 10 Seconds)-All engines except 6068HF275 with VP44 fuel system on non Gen-Set applications and 6068HF475 on non Gen-Set applications—	Pressure..... 70 kPa (0.7 bar) (10 psi)
Radiator Cap Holding Pressure (Not Opening For 10 Seconds)-6068HF275 with VP44 fuel system on non Gen-Set applications and 6068HF475 on non Gen-Set applications—	Pressure..... 100 kPa (1.0 bar) (15 psi)

3. Remove the cap from gauge, turn it 180°, and retest cap. This will verify that the first measurement was accurate.

Continued on next page

RG, RG34710, 5586 -19-24MAY02-1/2

Test Cooling System

NOTE: Engine should be warmed up to test overall cooling system.

1. Allow engine to cool, then carefully remove radiator cap.
2. Fill radiator with coolant to the normal operating level.

IMPORTANT: DO NOT apply excessive pressure to cooling system, doing so may damage radiator and hoses.

3. Connect gauge and adapter to radiator filler neck. Pressurize cooling system to specification listed for radiator cap.

4. With pressure applied, check all cooling system hose connections, radiator, and overall engine for leaks.

If leakage is detected, correct as necessary and pressure test system again.

If no leakage is detected, but the gauge indicated a drop in pressure, coolant may be leaking internally within the system or at the block-to-head gasket. Have your engine distributor or servicing dealer correct this problem immediately.

RG, RG34710, 5586 -19-24MAY02-2/2

Checking Crankshaft Vibration Damper (6-Cylinder Engine Only)

1. Remove belts (shown removed).
2. Grasp vibration damper with both hands and attempt to turn it in both directions. If rotation is felt, damper is defective and should be replaced.


IMPORTANT: The vibration damper assembly is not repairable and should be replaced every 4500 hours or 60 months, whichever occurs first.

3. Check vibration damper radial runout by positioning a dial indicator (A) so probe contacts damper outer diameter.
4. With engine at operating temperature, rotate crankshaft using either JD281A, JDE81-4, or JDE83 Flywheel Turning Tool.
5. Note dial indicator reading. If runout exceeds specifications given below, replace vibration damper.

Specification


Vibration Damper—Maximum

Radial Runout..... 1.50 mm (0.060 in.)



Grasp Vibration Damper

RG8018 -UN-15JAN99



Check Runout

RG7508 -UN-23NOV97

RG, RG34710, 5585 -19-12NOV01-1/1

Flushing Cooling System



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

NOTE: When John Deere COOL-GARD is used, the drain interval is 3000 hours or 36 months. The drain interval may be extended to 5000 hours or 60 months of operation, **provided that the coolant is tested annually AND additives are replenished, as needed, by adding a supplemental coolant additive (SCA).**

If COOL-GARD is not used, the flushing interval is 2000 hours or 24 months of operation.

Drain old coolant, flush the entire cooling system, test thermostats, and fill with recommended clean coolant.

1. Pressure test entire cooling system and pressure cap if not previously done. (See PRESSURE TESTING COOLING SYSTEM, in the Lubrication and Maintenance/500 Hour/12 Month Section.)
2. Slowly open the engine cooling system filler cap or radiator cap to relieve pressure and allow coolant to drain faster.



High-Pressure Fluids

TS281 -JUN-23AUG88

Continued on next page

RG, RG34710, 5587 -19-29MAY02-1/3

3. All Except 4045HF475 and 6068HF475 Engines:

Open engine block drain valve (A) on left side of engine. Drain all coolant from engine block.

NOTE: On 475 engines, the engine block drain valve is located behind the fuel rail, and is not easily accessible.


4045HF475 and 6068HF475 Engines: Open drain plug (B) or (C) on oil cooler housing. Drain all coolant from engine block.

NOTE: These engines use several different oil filter adapters. Use either drain plug (B) or (C) to drain coolant, whichever is more accessible for the oil filter adapter on your engine.


4. Open radiator drain valve. Drain all coolant from radiator.
5. Remove thermostats at this time, if not previously done. Install cover (without thermostats) using old gasket and tighten cap screws to 47 N•m (35 lb-ft).
6. Close all drain valves after coolant has drained.

CAUTION: Do not run engine longer than 10 minutes. Doing so may cause engine to overheat which may cause burns when radiator water is draining.

7. Fill the cooling system with clean water. Run the engine about 10 minutes to stir up possible rust or sediment.
8. Stop engine, pull off lower radiator hose and remove radiator cap. Immediately drain the water from system before rust and sediment settle.



Engine Block Drain Valve- Except 475 Engines



Engine Block Drain Plug- 475 Engines

A—Engine Block Drain Valve
B—Engine Block Drain Plug
C—Engine Block Drain Plug

Continued on next page

RG, RG34710, 5587 -19-29MAY02-2/3

9. After draining water, close drain valves. Reinstall radiator cap and radiator hose and clamp. Fill the cooling system with clean water and a heavy duty cooling system cleaner such as Fleetguard® RESTORE™ and RESTORE PLUS™. These products may be available from your John Deere dealer. Follow manufacturer's directions on label.
10. After cleaning the cooling system, drain cleaner and fill with water to flush the system. Run the engine about 10 minutes, remove radiator cap and pull off lower radiator hose to drain out flushing water.
11. Close all drain valves on engine and radiator. Reinstall radiator hose and tighten clamps securely. Install thermostats using a new gasket. (See TESTING THERMOSTATS OPENING TEMPERATURE later in this section.)

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Retighten fitting or plug after filling cooling system.

12. Add coolant to radiator until coolant touches bottom of filler neck. (See ADDING COOLANT in Service As Required Section.) Install radiator cap.
13. Run engine until it reaches operating temperature. This mixes the solution uniformly and circulates it through the entire system. The normal engine coolant temperature range is 82°—94°C (180° — 202°F).
14. After running engine, check coolant level and entire cooling system for leaks.

*Fleetguard is a trademark of Cummins Engine Company, Inc.
RESTORE is a trademark of Fleetguard.
RESTORE PLUS is a trademark of Fleetguard.*

RG, RG34710, 5587 -19-29MAY02-3/3

Testing Thermostats Opening Temperature

To Remove Thermostat(s)

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns. DO NOT drain coolant until it has cooled below operating temperature. Always loosen radiator pressure cap or drain valve slowly to relieve pressure.

1. Visually inspect area around thermostat housing for leaks.
2. Remove radiator pressure cap and partially drain cooling system.
3. Remove thermostat cover-to-coolant pump tube (A) and seal.

A—Cover-To-Coolant Pump Tube



High Pressure Fluids



Thermostat Cover-to-Coolant Pump Tube


DPSG, RG34710, 112 -19-23NOV01-1/5

TS281 -UN-23AUG88

RG8115A -UN-15JAN98

4. Remove thermostat cover (B) with gasket.
5. Remove thermostat(s)
6. Remove and discard all gasket material. Clean gasket surfaces.
7. Clean and check cover for cracks or damage.

B—Thermostat Cover



Thermostat Cover

RG7921A -UN-13NOV97

Continued on next page

DPSG, RG34710, 112 -19-23NOV01-2/5

Testing Thermostats Opening Temperature

1. Remove thermostat(s).
2. Visually inspect thermostat(s) for corrosion or damage. If dual thermostats, replace as a matched set as necessary.

CAUTION: DO NOT allow thermostat or thermometer to rest against the side or bottom of container when heating water. Either may rupture if overheated.


3. Suspend thermostat and a thermometer in a container of water.
4. Stir the water as it heats. Observe opening action of thermostat and compare temperatures with the specification given in chart below.

NOTE: Due to varying tolerances of different suppliers, initial opening and full open temperatures may vary slightly from specified temperatures.

THERMOSTAT TEST SPECIFICATIONS

Rating	Initial Opening (Range)	Full Open (Nominal)
71°C (160°F)	69—72°C (156—162°F)	84°C (182°F)
77°C (170°F)	74—78°C (166—172°F)	89°C (192°F)
82°C (180°F)	80—84°C (175—182°F)	94°C (202°F)
89°C (192°F)	86—90°C (187—194°F)	101°C (214°F)
90°C (195°F)	89—93°C (192—199°F)	103°C (218°F)
92°C (197°F)	89—93°C (193—200°F)	105°C (221°F)
96°C (205°F)	94—97°C (201—207°F)	100°C (213°F)
99°C (210°F)	96—100°C (205—212°F)	111°C (232°F)

5. Remove thermostat and observe its closing action as it cools. In ambient air the thermostat should close completely. Closing action should be smooth and slow.
6. Replace any defective thermostat. On a dual thermostat engine, replace both thermostats.



Testing Thermostat Opening Temperature

RG5971 -UN-23NOV97

Continued on next page


DPSG, RG34710, 112 -19-23NOV01-3/5

To Install Thermostats

IMPORTANT: Install manifold gasket so that smaller (round) holes are at lower left and upper right corners of manifold (matching studs A).

1. Clean all gasket material from thermostat cover and housing mounting surfaces.
2. Using guide studs (A) to keep gasket in place, install a new gasket on cylinder head.
3. Install thermostat(s) with jiggle wire facing up in the 12 o'clock position.
4. Using a screwdriver to hold thermostat(s) in place, install thermostat(s) and coolant manifold/thermostat cover.
5. Tighten cover cap screws to 70 N•m (52 lb-ft).
6. Lubricate new O-ring with PT507 Multi-Purpose Grease. Install seal (B) in thermostat cover.

A—Guide Studs
B—Seal



RG7614A -UN-06NOV97

Installing Thermostat Cover



RG7921B -UN-13NOV97

Thermostat Cover Seal

DPSG, RG34710, 112 -19-23NOV01-4/5

7. Install coolant manifold/thermostat cover-to-coolant pump tube (C). Tighten clamps.
8. If not already done, fill cooling system and check for leaks.

IMPORTANT: Air must be expelled from cooling system when filling. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Tighten fitting or plug when all air has been expelled.



RG8115B -UN-15JAN98

Cover-To-Coolant Pump Tube

C—Cover-To-Coolant Pump Tube

DPSG, RG34710, 112 -19-23NOV01-5/5

Check and Adjust Valve Clearance (All Engines Except 4045HF475 And 6068HF475)



CAUTION: To prevent accidental starting of engine while performing valve adjustments, always disconnect **NEGATIVE (—)** battery terminal.

IMPORTANT: Valve clearance **MUST BE** checked and adjusted with engine **COLD**.

1. Remove rocker arm cover and crankcase ventilator tube.

IMPORTANT: Visually inspect contact surfaces of valve tips and rocker arm wear pads. Check all parts for excessive wear, breakage, or cracks. Replace parts that show visible damage.

Rocker arms that exhibit excessive valve clearance should be inspected more thoroughly to identify damaged parts.


2. Remove plastic plugs or cover plate from engine timing/rotation hole (A) and timing pin hole (B).

NOTE: Some engines are equipped with flywheel housings which do not allow use of an engine flywheel rotation tool. These engines may be rotated from front nose of engine, using JDG966 Crankshaft Front/Rear Rotation Adapter.

3. Using JDE83 or JD281A Flywheel Turning Tool, rotate engine flywheel in running direction (clockwise viewed from front) until No. 1 cylinder is at TDC compression stroke. Insert JDG1571 Timing Pin in flywheel.

If No.1 cylinder rocker arms are loose, the engine is at No. 1 TDC compression.

If No. 1 cylinder rocker arms are not loose, rotate engine one full revolution (360°) to No. 1 TDC compression.



Flywheel Housing Timing Holes

A—Timing/Rotation Hole
B—Timing Pin Hole

RG7408 -UN-06AUG96

Continued on next page

DPSG, RG41165, 137 -19-26APR02-1/5

4. With engine lock-pinned at TDC of No. 1 piston's compression stroke, check valve clearance to following specifications. (Use sequence for 4-cylinder or 6-cylinder engines as outlined on next page.)

Specification


Intake Valve Clearance For	
Checking (Rocker Arm-to-Valve	
Tip) (Engine Cold)—Clearance	0.31—0.38 mm
	(0.012—0.015 in.)
Exhaust Valve Clearance For	
Checking (Rocker Arm-to-Valve	
Tip) (Engine Cold)—Clearance	0.41—0.48 mm
	(0.016—0.019 in.)

DPSG,RG41165,137 -19-26APR02-2/5

5. If valves need adjusting, use the appropriate valve clearance adjustment procedure on the next page and adjust to specifications below. Loosen the jam nut (A) on rocker arm adjusting screw. Turn adjusting screw until feeler gauge slips with a slight drag. Hold the adjusting screw from turning with screwdriver and tighten jam nut to specifications. Recheck clearance again after tightening jam nut. Readjust clearance as necessary.

Specification

Intake Valve Clearance For	
Adjusting (Rocker Arm-to-Valve	
Tip) (Engine Cold)—Clearance	0.36 mm (0.014 in.)
Exhaust Valve Clearance For	
Adjusting (Rocker Arm-to-Valve	
Tip) (Engine Cold)—Clearance	0.46 mm (0.018 in.)
Rocker Arm Adjusting Screw Jam	
Nut—Torque	27 N•m (20 lb-ft)



RG7409 -UN-06AUG96

Adjusting Valves

A—Adjusting Screw Jam Nut

6. Replace rocker arm cover and crankcase ventilator tube.

Continued on next page


DPSG,RG41165,137 -19-26APR02-3/5

4-Cylinder Engine:

NOTE: Firing order is 1-3-4-2.

1. Using JDE81-4 Timing Pin, lock No. 1 piston at TDC compression stroke (B).
2. Adjust valve clearance on No. 1 and 3 exhaust valves and No. 1 and 2 intake valves.
3. Turn crankshaft 360°. Lock No. 4 piston at TDC compression stroke (C).
4. Adjust valve clearance on No. 2 and 4 exhaust valves and No. 3 and 4 intake valves.

A—Front of Engine
 B—No. 1 Piston TDC Compression
 C—No. 4 Piston TDC Compression
 E—Exhaust Valve
 I—Intake Valve




RG4776 -UN-31OCT97

DPSG, RG41165, 137 -19-26APR02-4/5

6-Cylinder Engine:

NOTE: Firing order is 1-5-3-6-2-4.

1. Lock No. 1 piston at TDC compression stroke (B).
2. Adjust valve clearance on No. 1, 3 and 5 exhaust valves and No. 1, 2, and 4 intake valves.
3. Turn crankshaft 360°. Lock No. 6 piston at TDC compression stroke (C).
4. Adjust valve clearance on No. 2, 4 and 6 exhaust valves and No. 3, 5, and 6 intake valves.



A—Front of Engine
 B—No. 1 Piston TDC Compression
 C—No. 6 Piston TDC Compression
 E—Exhaust Valve
 I—Intake Valve

RG4777 -UN-31OCT97

DPSG, RG41165, 137 -19-26APR02-5/5

Check and Adjust Valve Clearance (4045HF475 And 6068HF475 Engines)



CAUTION: To prevent accidental starting of engine while performing valve adjustments, always disconnect **NEGATIVE (—)** battery terminal.

IMPORTANT: Valve clearance **MUST BE** checked and adjusted with engine **COLD**.

1. Remove rocker arm cover and crankcase ventilator tube.

IMPORTANT: Visually inspect contact surfaces of valve tips, bridges and rocker arm wear pads. Check all parts for excessive wear, breakage, or cracks. Replace parts that show visible damage.

Rocker arms that exhibit excessive valve clearance should be inspected more thoroughly to identify damaged parts.


2. Remove plastic plugs or cover plate from engine timing/rotation hole (A) and timing pin hole (B).

NOTE: Some engines are equipped with flywheel housings which do not allow use of an engine flywheel rotation tool. These engines with straight nose crankshafts may be rotated from front nose of engine, using JDG966 Crankshaft Front/Rear Rotation Adapter.

3. Using JDE83 or JDE81-1 Flywheel Turning Tool, rotate engine flywheel in running direction (clockwise viewed from front) until No. 1 (front) cylinder is at TDC compression stroke. Insert JDG1571 or JDE81-4 Timing Pin in flywheel.

If No. 1 cylinder rocker arms are loose, the engine is at No. 1 TDC compression.

If No. 1 cylinder rocker arms are not loose, rotate engine one full revolution (360°) to No. 1 TDC compression.



Flywheel Housing Timing Holes

A—Timing/Rotation Hole
B—Timing Pin Hole

4. With engine lock-pinned at TDC of No. 1 piston's compression stroke, check valve clearance to following specifications. (Use sequence for 4-cylinder or 6-cylinder engines as outlined on next page.)

Specification

Intake Valve Clearance Checking
(Rocker Arm-to-Bridge) (Engine Cold)—Clearance 0.31—0.38 mm (0.012—0.015 in.)

Exhaust Valve Clearance
Checking (Rocker Arm-to-Bridge)
(Engine Cold)—Clearance..... 0.41—0.48 mm (0.016—0.019 in.)

OUC1089,0000208 -19-05JUN02-2/5

5. If valves need adjusting, use the appropriate valve clearance adjustment procedure on the next page and adjust to specifications below. Loosen the jam nut (A) on rocker arm adjusting screw. Turn adjusting screw until feeler gauge slips with a slight drag. Hold the adjusting screw from turning with screwdriver and tighten jam nut to specifications. Recheck clearance again after tightening jam nut. Readjust clearance as necessary.

Specification


Intake Valve Clearance
Adjustment (Rocker Arm-to-Bridge) (Engine Cold)—
Clearance 0.36 mm (0.014 in.)

Exhaust Valve Clearance
Adjustment (Rocker Arm-to-Bridge) (Engine Cold)—
Clearance 0.46 mm (0.018 in.)

Rocker Arm Adjusting Screw Jam
Nut—Torque 27 N•m (20 lb-ft)

NOTE: While rocker arm cover is removed, test glow plugs. (See following procedure.)

6. Install rocker arm cover and crankcase ventilator tube.
7. Reconnect battery terminal.



Adjusting Valves

A—Adjusting Screw Jam Nut


Continued on next page

OUC1089,0000208 -19-05JUN02-3/5

4-Cylinder Engine:

NOTE: Firing order is 1-3-4-2.

1. Using JDG1571 or JDE81-4 Timing Pin, lock No. 1 piston at TDC compression stroke (B).
2. Adjust valve clearance on No. 1 and 3 exhaust valves and No. 1 and 2 intake valves.
3. Turn crankshaft 360°. Lock No. 4 piston at TDC compression stroke (C).
4. Adjust valve clearance on No. 2 and 4 exhaust valves and No. 3 and 4 intake valves.



4-Cylinder Valve Adjustment

A—Front of Engine
B—No. 1 Piston TDC Compression
C—No. 4 Piston TDC Compression
E—Exhaust Valve
I—Intake Valve


OUC1089,0000208 -19-05JUN02-4/5

RG12357 -JUN-29MAY02

6-Cylinder Engine:

NOTE: Firing order is 1-5-3-6-2-4.

1. Lock No. 1 piston at TDC compression stroke (B).
2. Adjust valve clearance on No. 1, 3 and 5 exhaust valves and No. 1, 2, and 4 intake valves.
3. Turn crankshaft 360°. Lock No. 6 piston at TDC compression stroke (C).
4. Adjust valve clearance on No. 2, 4 and 6 exhaust valves and No. 3, 5, and 6 intake valves.



6-Cylinder Valve Adjustment

A—Front of Engine
B—No. 1 Piston TDC Compression
C—No. 6 Piston TDC Compression
E—Exhaust Valve
I—Intake Valve

OUC1089,0000208 -19-05JUN02-5/5

RG12170 -JUN-21MAY02

Test Glow Plugs for Continuity (4045HF475 And 6068HF475 Engines)



CAUTION: To prevent accidental starting of engine while performing this test, always disconnect **NEGATIVE (—)** battery terminal.

While checking valve clearance with rocker arm cover removed, check each glow plug for continuity using a multimeter.

Check continuity between glow plug and ground on cylinder head. If resistance is infinite (no current), the glow plug is damaged and must be replaced.

Install new glow plugs and torque to specifications.

Specification

Glow Plug—Torque 12—18 N•m (9—13 lb-ft)


Reinstall rocker arm cover and crankcase ventilator tube.

OUOD006,0000018 —19-05JUN02-1/1

Service as Required

Additional Service Information

This is not a detailed service manual. If you want more detailed service information, use the Publications Information in the back of this manual to order a component technical manual.



Component Technical Manual

RG4624 -UN-15DEC88


RG, RG34710, 5591 -19-23NOV01-1/1

Do Not Modify Fuel System

IMPORTANT: Modification or alteration of the injection pump (arrow), the injection pump timing, or the fuel injectors in ways not recommended by the manufacturer will terminate the warranty obligation to the purchaser.

In addition, tampering with fuel system which alters emission-related equipment on engines may result in fines or other penalties, per EPA regulations or other local emission laws.

Do not attempt to service injection pump or fuel injectors yourself. Special training and special tools are required. (See your authorized servicing dealer or engine distributor.)



Fuel Injection Pump

RG11953 -UN-26NOV01

RG, RG34710, 5592 -19-23NOV01-1/1

Adding Coolant



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Never pour cold liquid into a hot engine, as it may crack cylinder head or block. DO NOT operate engine without coolant for even a few minutes.

John Deere TY15161 Cooling System Sealer may be added to the radiator to stop leaks. DO NOT use any other stop-leak additives in the cooling system.

Air must be expelled from cooling system when coolant is added.

1. Loosen temperature sending unit fitting at rear of cylinder head or plug in side of thermostat housing to allow air to escape when filling system.

IMPORTANT: When adding coolant to the system, use the appropriate coolant solution. (See **ENGINE COOLANT SPECIFICATIONS** in **Fuels, Lubricants, and Coolant Section** for mixing of coolant ingredients before adding to cooling system.)

Do not overfill cooling system. A pressurized system needs space for heat expansion without overflowing at top of radiator.

2. Fill until coolant level touches bottom of radiator filler neck.
3. Tighten plugs and fittings when air has been expelled from system.



High-Pressure Fluids

TS281 -JUN-23AUG88

Service as Required

4. Run engine until it reaches operating temperature.

RG, RG34710, 5593 -19-12NOV01-2/2

Replacing Single Stage Air Cleaner

IMPORTANT: ALWAYS REPLACE air cleaner when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.

NOTE: This procedure applies to John Deere single stage air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.

1. If equipped, loosen body clamp.
2. Loosen clamp around outlet neck (A).
3. Remove air cleaner.
4. Install new filter so that overlap (B) of air cleaner outlet neck and engine intake pipe is to specification below.

Specification

Air Cleaner Neck to Engine
Intake—Overlap..... 38 mm (1.5 in)

5. Tighten neck clamp (A) to specification below.

Specification


Air Cleaner Neck Clamp—Torque..... 6.8 N•m (60 lb-in.)

IMPORTANT: Do NOT overtighten body clamp. Overtightening may cause crushing of air cleaner body. Tighten body clamp only until snug.


6. If equipped, tighten body clamp until snug.

IMPORTANT: Whenever the air cleaner has been serviced or removed, ALWAYS fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

7. If equipped, fully depress air restriction indicator reset button and release to reset indicator.



Single Stage Air Filter



Installation of Single Stage Air Cleaner

A—Outlet Neck Clamp
B—Filter to Engine Overlap

RG11319A -UN-06SEP00

RG11320 -UN-07SEP00

Replacing Axial Seal Air Cleaner Filter Element

IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.


NOTE: This procedure applies to John Deere 2-stage axial seal air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.

1. Remove wing nut and remove canister cover shown in small illustration inset.
2. Remove wing nut (A) and remove primary element (B) from canister.
3. Thoroughly clean all dirt from inside canister.

NOTE: Some engines may have a dust unloader valve (C) on the air cleaner. If equipped, squeeze valve tip to release any trapped dirt particles.


IMPORTANT: Remove secondary (safety) element (E) **ONLY** for replacement. **DO NOT** attempt to clean, wash, or reuse secondary element. Replacement of secondary element is usually necessary **ONLY** when primary element has a hole in it.

4. To replace secondary element, remove retaining nut (D) and secondary element (E). Immediately replace secondary element with new element to prevent dust from entering air intake system.
5. Install new primary element and tighten wing nut securely. Install cover assembly and tighten retaining wing nut securely.




Wing Nut and Primary Element

RG4686 -UN-20DEC88



Dust Unloader Valve

RG4687 -UN-20DEC88



Retaining Nut and Secondary Element

RG11068 -UN-26JUN00

- A—Wing Nut
- B—Primary Element
- C—Dust Unloader Valve
- D—Retaining Nut
- E—Secondary Element

Continued on next page

RG41165,000008A -19-12NOV01-1/2

IMPORTANT: Whenever the air cleaner has been serviced or had cover removed, **ALWAYS** fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

6. If equipped, fully depress air restriction indicator reset button and release to reset indicator.

RG41165,000008A -19-12NOV01-2/2

Replacing Radial Seal Air Cleaner Filter Element

IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.

NOTE: This procedure applies to John Deere 2-stage radial seal air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.

1. Unlatch and remove dust cup/cover (A) of air cleaner.
2. Move end of filter (B) back and forth gently to break seal.
3. Pull filter (B) off outlet tube and out of housing.
4. Thoroughly clean all dirt from inside housing and from outlet bore.

IMPORTANT: Remove secondary (safety) element (C) **ONLY** for replacement. **DO NOT** attempt to clean, wash, or reuse secondary element. Replacement of secondary element is usually necessary **ONLY** when primary element has a hole in it.

5. To replace secondary element (C), pull filter element out gently. Immediately replace secondary element with new element to prevent dust from entering air intake system.
6. Install new primary filter element. Apply pressure by hand at outer rim of filter.


IMPORTANT: Do NOT use latches on cover to force filter into air cleaner. Using cover to force filter will damage cleaner housing.

7. Close housing with dust unloader valve aimed down and latch latches.




Dust Cup/Cover

RG11321A -UN-08SEP00



Primary Filter Element

RG11322A -UN-08SEP00



Secondary Filter Element

RG11327A -UN-08SEP00

A—Dust Cap/Cover
B—Primary Filter Element
C—Secondary Filter Element

Continued on next page

RG41165,000008B -19-06SEP00-1/2

IMPORTANT: Whenever the air cleaner has been serviced or cover has been removed, **ALWAYS** fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

8. If equipped, fully depress air restriction indicator reset button and release to reset indicator.

RG41165,000008B -19-06SEP00-2/2

Replacing Fan and Alternator Belts

Refer to CHECKING BELT TENSIONER SPRING TENSION AND BELT WEAR in Lubrication and Maintenance/500 Hour/12 Month Section for additional information on the belt tensioner.


1. Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary.
2. To replace belt with automatic tensioner, release tension on belt using a breaker bar and socket on tension arm.

To replace belt with manual tensioner, release tension at belt tensioner (See MANUAL BELT TENSIONER ADJUSTMENT in Lubrication and Maintenance/500 Hour/12 Month Section.)


3. Remove poly-vee belt from pulleys and discard belt.
4. Install new belt, making sure belt is correctly seated in all pulley grooves. Refer to belt routing at right for your application.
5. Apply tension to belt with tensioner. Remove socket.
6. Start engine and check belt alignment.

*Measured from crank centerline to fan drive center.


A—Alternator
CSP—Crankshaft Pulley
FC—Freon (A/C) Compressor
FD—Fan Drive
I—Idler Pulley
T—Tensioner
CP—Coolant Pump



290 mm (11.4 in.) Fan Height and Lower*



338 mm (13.3 in.) Fan Height and Higher Without Freon Compressor*



402 mm (15.8 in.) Fan Height With Freon Compressor*

RG11950 -UN-07NOV01

RG11951 -UN-07NOV01

RG11952 -UN-07NOV01


RG, RG34710, 5599 -19-05JUN02-1/1

Checking Fuses

Check the fuse (A) located in the fuse holder on the face of the instrument panel. If defective, replace with a 5-amp fuse.

A separate wiring harness fuse (10 amp) and a main system fuse (20 amp) are shown in the Wiring Diagrams in the Troubleshooting Section.

A—5 Amp Fuse



RG11938 -JUN-06NOV01


RG, RG34710, 5601 -19-12NOV01-1/1

Bleeding the Fuel System (Engines With Electronic Fuel Systems And Bosch VP44 Pump)



CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.



High-Pressure Fluids

X9811 -UN-23AUG88

Whenever the fuel system has been opened up for service (lines disconnected or filters removed), it will be necessary to bleed air from the system.

This fuel system can only be bled by the electronic transfer pump or at the injection nozzles. **BLEEDING SHOULD NOT BE PERFORMED** at any location on the Bosch VP44 injection pump.


Continued on next page

OUOD002,000016A -19-23NOV01-1/3

Bleed Using Electronic Transfer Pump

The bleed is automatically performed by a small orifice (A) inside the final fuel filter base connected to the overflow valve on injection pump. The system allows air to escape continually through the fuel return line (B) when ignition is ON.

1. Ignition ON.
2. Allow 40 seconds for electronic transfer pump to complete priming.
3. If additional system bleeding is required, bleed the circuit by loosening fuel line connections at injection nozzles. See the next procedure, BLEED FUEL SYSTEM AT FUEL INJECTION NOZZLES.



Bleed Fuel System

A—Bleed Orifice in Final Fuel Filter Base
B—Fuel Return Line

OUOD002,000016A -19-23NOV01-2/3

Bleed Fuel System at Fuel Injection Nozzles

IMPORTANT: Always use a backup wrench when loosening or tightening fuel lines at nozzles and/or injection pump to avoid damage.

1. Using **two** open-end wrenches, loosen two fuel line connections at injection nozzles.
2. Crank engine over with starter motor for 15 seconds (but do not start engine) until fuel free from bubbles flows out of loosened connection. Retighten connection to specifications.

Specification

Fuel Injection Nozzle Delivery

Line—Torque..... 27 N•m (20 lb-ft)

3. Repeat procedure for remaining injection nozzles (if necessary) until all air has been removed from fuel system.




Bleed At Fuel Injection Nozzles

OUOD002,000016A -19-23NOV01-3/3

Bleed the Fuel System (Engines with Electronic Fuel Systems and Stanadyne DE10 Pump)

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid hazards by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.



High Pressure Fluids

X9811 -UN-23AUG88

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Any time the fuel system has been opened up for service (lines disconnected or filters removed), it will be necessary to bleed air from the system.

The fuel system may be bled at one of several locations. Choose the best location for your engine/machine application.

OUOD002,000016F -19-23NOV01-1/5

1. Loosen the air bleed vent screw (A) two full turns by hand on fuel filter base.

A—Bleed Vent Screw



Final Fuel Filter Bleed Vent Screw

RG11805 -UN-25OCT01


Continued on next page

OUOD002,000016F -19-23NOV01-2/5

2. Operate fuel supply pump primer lever (B) or primer button on fuel filter base (if equipped).
3. Tighten bleed plug securely, continue operating primer until pumping action is not felt
4. Start engine and check for leaks.

If engine will not start, it may be necessary to bleed air from fuel system at fuel injection pump or injection nozzles as explained next.

B—Primer Lever



Fuel Supply Pump Primer Lever

RG11806 -UN-25OCT01


OUOD002,000016F -19-23NOV01-3/5

At Fuel Injection Pump

1. Loosen fuel return line (A) at fuel injection pump.
2. Operate fuel supply pump primer lever or primer button on fuel filter base (if equipped).
3. As soon as fuel flow is free from air bubbles, tighten fuel return line to specifications. Primer lever is spring-loaded and will return to normal position.

Specification

Fuel Injection Pump Return
Line—Torque 27 N•m (20 lb-ft)



Fuel Injection Pump Return Line

A—Fuel Return Line

RG11807 -UN-25OCT01

Continued on next page

OUOD002,000016F -19-23NOV01-4/5

At Fuel Injection Nozzles

IMPORTANT: Always use a backup wrench when loosening or tightening fuel lines at nozzles and/or injection pump to avoid damage.

1. Using **two** open-end wrenches, loosen two fuel line connections at injection nozzles.
2. Crank engine over with starter motor for 15 seconds (but do not start engine) until fuel free from bubbles flows out of loosened connection. Retighten connection to specifications.

Specification

Fuel Injection Nozzle Delivery

Lines—Torque 27 N•m (20 lb-ft)

3. Repeat procedure for remaining injection nozzles (if necessary) until all air has been removed from fuel system.

If engine still will not start, see your authorized servicing dealer or engine distributor.




Nozzle Fuel Pressure Line

RG11808 -UN-25OCT01

OUOD002,000016F -19-23NOV01-5/5

Bleed the Fuel System (Engines with Electronic Fuel Systems and Denso High Pressure Common Rail) (4045HF475, 6068HF475)

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid hazards by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.



High Pressure Fluids

X9811 -UN-23AUG88

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Any time the fuel system has been opened up for service (lines disconnected or filters removed), it will be necessary to bleed air from the system.

OUOD006,0000015 -19-23MAY02-1/3

NOTE: These are the 4-valve cylinder head 4.5 L and 6.8 L engines with Denso HP3 pumps and High Pressure Common Rail (HPCR) fuel systems.

IMPORTANT: Four valve cylinder head engines are especially sensitive to fuel contamination. Do not crack any fuel lines to bleed the fuel system.

1. Loosen the air bleed vent screw (A) two full turns by hand on fuel filter base.

A—Bleed Vent Screw



Final Fuel Filter Bleed Vent Screw

RG12220 -UN-24MAY02


Continued on next page

OUOD006,0000015 -19-23MAY02-2/3

2. Operate fuel supply pump primer lever (B), or primer button on fuel filter base (if equipped), until fuel flows out of bleed vent screw.
3. Tighten bleed vent screw securely. Continue operating primer until pumping action is not felt.
4. Start engine and check for leaks.

If engine will not start, repeat steps 1-4.

B—Primer Lever



RG12221 -UN-24MAY02

Fuel Supply Pump Primer Lever

OUOD006,0000015 -19-23MAY02-3/3

Troubleshooting

General Troubleshooting Information

Troubleshooting engine problems can be difficult. An engine wiring diagram is provided in this section to help isolate electrical problems on power units using John Deere wiring harness and instrument (gauge) panel.

Wiring diagrams are shown for the electronic instrument panel and harness offered for these engines.

Later in this section is a list of possible engine problems that may be encountered accompanied by possible causes and corrections. The illustrated diagrams and troubleshooting information are of a general nature; final design of the overall system for your engine application may be different. See your engine distributor or servicing dealer if you are in doubt.

A reliable program for troubleshooting engine problems should include the following basic diagnostic thought process:

- Know the engine and all related systems.
- Study the problem thoroughly.
- Relate the symptoms to your knowledge of engine and systems.
- Diagnose the problem starting with the easiest things first.
- Double-check before beginning the disassembly.
- Determine cause and make a thorough repair.
- After making repairs, operate the engine under normal conditions to verify that the problem and cause was corrected.

NOTE: The engines covered in this manual have electronic control systems which send diagnostic trouble codes to signal problems (see DIAGNOSTIC TROUBLE CODE PROCEDURE, later in this section).

RG, RG34710, 5605 -19-12NOV01-1/1


Precautions For Welding On Engines Equipped With Electronic Engine Control Unit (ECU)

IMPORTANT: ALWAYS disconnect Electronic Control Unit (ECU) connectors and engine control system-to-machine ground before welding on engine or machine. High currents or electro-static discharge in electronic components from welding may cause permanent damage.

1. Remove the ground connection for the engine control system-to-machine frame.
2. Disconnect the connectors from the ECU.
3. Connect the welder ground close to the welding point and be sure ECU or other electronic components are not in the ground path.

OUOD002,000016B -19-08OCT01-1/1

Engine Wiring Layout (Electronic Fuel System With Stanadyne DE10 Injection Pump)



RG12201 -UN-24MAY02

A—Coolant Temperature
Sensor Connector
B—Fuel Temperature Sensor
Connector
C—Injection Pump Solenoid
Connector
D—SAE 1939 CAN Connector
E—Crankshaft Position Sensor
Connector
F—ECU Connector


G—Starter Relay Connector
H—Oil Pressure Sensor
Connector
I—Main System Fuse (10 amp)
J—Power and Ground Battery
Connections
K—Fuse Holder
L—Transient Voltage
Protection (TVP) Module
Connector

M—Remote ON/ OFF
Connector
N—CAN Network Diagnostic
Connector
O—Instrument Panel
Connector Harness
P—23-pin Optional Feature
Connector (Extended-
feature ECU only)

Q—21-pin Instrument Panel
Connector
R—Engine Wiring Harness
S—Fuel Heater Connector
T—Manifold Air Temperature
(MAT) Sensor Connector
U—Alternator Ignition
Connector
V—Optional Instrument Panel

OUOD005,0000180 -19-26APR02-1/1

Engine Wiring Layout (Electronic Fuel System With Bosch VP44 Injection Pump)



A—Oil Pressure Sensor
B—Fuel Pump Relay
C—Fuel Pump Relay Fuse
D—Crankshaft Position Sensor
E—Fuel Injection Pump Event Sensor
F—Coolant Temperature Sensor
G—Fuel Injection Pump Connector
H—Alternator Ignition Connector


I—Manifold Air Temperature (MAT) Sensor
J—Fuel Transfer Pump
K—Fuel Heater
L—Fuel Temperature Sensor
M—Network CAN Connector
N—Isochronous Governor Select Connector
O—Transient Voltage Protection (TVP) Module
P—Main System Fuse (20 Amp)

Q—Engine Control Unit (ECU)
R—ECU Connector
S—System Ground (ECU must also be grounded to frame)
T—CAN Network Diagnostic Connector
U—Blink-Code Diagnostic Connector
V—Secondary Analog Throttle Connector

W—Remote ON/OFF Connector
X—Instrument Panel Connector
Y—Optional Instrument Panel
Z—Starter Relay Connections
AA—Power and Ground Battery Connections
BB—Optional Wire Extensions

RG-1139A -UN-05JUN02

Engine Wiring Layout (Electronic Fuel System With Denso High Pressure Common Rail)



A—Engine Coolant Temperature (ECT) Sensor
B—Electronic Injector Connector
C—Manifold Air Temperature (MAT) Sensor

D—(ECU) Connector
E—Optional Instrument Panel
F—Engine Wiring Harness
G—Engine Oil Pressure Sensor Connector


H—Power and Ground Battery Connections
I—Fuel Rail Pressure Sensor
J—Crankshaft Position Sensor

K—Pump Position Sensor
L—Pump Control Valve Solenoid
M—Fuel Temperature Sensor

RG12224 -UN-19JUN02

OUOD005,0000186 -19-12JUN02-1/1

Engine Wiring Diagram (Electronic Instrument Panel)



SE-1 ENGINE START COMPONENTS


SE-2 INSTRUMENT PANEL (CONTINUED NEXT PAGE)

- B1—Analog Throttle or Emulator
- E1—Back Light Regulator (24V) or Plug (12V)
- F1—Fuse (10 Amp) (for harness)
- F2—Fuse (5 Amp) (for instrument panel)
- G1—Alternator
- K1—Starter Relay
- M1—Starter Motor
- N1—Transient Voltage Protector
- N2—Voltage Regulator (for 24V Operation)
- P1—Optional Gauge
- P2—Optional Gauge
- P3—Oil Pressure Gauge
- P4—Coolant Temperature Gauge
- P5—Tachometer Display
- P6—Hourmeter/Diagnostic Meter

- S1—Ignition Key Switch
- S2—Speed Select Switch (Momentary)
- S3—Bump Enable Switch (Momentary)
- S4—High Low Speed Switch
- S5—Override Shutdown Switch (Momentary)
- S6—Dimmer Control or Jumper Plug

- V1—Diode
- X1—Vehicle Harness Connector
- X2—Alternator Harness
- X3—Single Point Ground
- X4—CAN Terminator
- X5—Analog Throttle Connector
- X6—Remote On-Off Plug

Engine Wiring Diagram (Electronic Instrument Panel)—Continued



SE-2 INSTRUMENT PANEL (CONTINUED)

- | | | | |
|---|--|---|------------------------------|
| B1—Analog Throttle or Emulator | N1—Transient Voltage Protector | S1—Ignition Key Switch | V1—Diode |
| E1—Back Light Regulator (24V) or Plug (12V) | N2—Voltage Regulator (for 24V Operation) | S2—Speed Select Switch (Momentary) | X1—Vehicle Harness Connector |
| F1—Fuse (10 Amp) (for harness) | P1—Optional Gauge | S3—Bump Enable Switch (Momentary) | X2—Alternator Harness |
| F2—Fuse (5 Amp) (for instrument panel) | P2—Optional Gauge | S4—High Low Speed Switch | X3—Single Point Ground |
| G1—Alternator | P3—Oil Pressure Gauge | S5—Override Shutdown Switch (Momentary) | X4—CAN Terminator |
| K1—Starter Relay | P4—Coolant Temperature Gauge | S6—Dimmer Control or Jumper Plug | X5—Analog Throttle Connector |
| M1—Starter Motor | P5—Tachometer Display | | X6—Remote On-Off Plug |
| | P6—Hourmeter/Diagnostic Meter | | |

Engine Troubleshooting

Symptom	Problem	Solution
Engine cranks but will not start	Incorrect starting procedure.	Verify correct starting procedure.
	No fuel.	Check fuel in tank.
	Exhaust restricted.	Check and correct exhaust restriction.
	Fuel filter plugged or full of water.	Replace fuel filter or drain water from filter.
	Injection pump not getting fuel or air in fuel system.	Check fuel flow at supply pump or bleed fuel system.
	Faulty injection pump or nozzles.	Consult authorized diesel repair station for repair or replacement.

Continued on next page

RG, RG34710, 5608 -19-05JUN02-1/8

Symptom	Problem	Solution
Engine hard to start or will not start	Engine starting under load.	Disengage PTO.
	Improper starting procedure.	Review starting procedure.
	No fuel.	Check fuel tank.
	Air in fuel line.	Bleed fuel line.
	Cold weather.	Use cold weather starting aids.
	Slow starter speed.	See "Starter Cranks Slowly".
	Crankcase oil too heavy.	Use oil of proper viscosity.
	Improper type of fuel.	Consult fuel supplier; use proper type fuel for operating conditions.
	Water, dirt, or air in fuel system.	Drain, flush, fill, and bleed system.
	Clogged fuel filter.	Replace filter element.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Defective glow plugs (Cold weather starting-4045HF475, 6068HF475)	Test glow plugs (See 2000 hour/24 month maintenance section)
	Electronic fuel system problem (if equipped)	See your John Deere distributor or servicing dealer.
Engine knocks	Low engine oil level.	Add oil to engine crankcase.
	Low coolant temperature.	Remove and check thermostat.
	Engine overheating.	See "Engine Overheats".
	Engine cold	Wrong or defective thermostat. Remove and check thermostat.

Continued on next page

RG, RG34710, 5608 -19-05JUN02-2/8

Symptom	Problem	Solution
Engine runs irregularly or stalls frequently	Low coolant temperature.	Remove and check thermostat.
	Clogged fuel filter.	Replace fuel filter element.
	Water, dirt, or air in fuel system.	Drain, flush, fill, and bleed system.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Electronic fuel system problem	See your John Deere distributor or servicing dealer.
Below normal engine temperature	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check gauge, sender, and connections.

Continued on next page

RG, RG34710, 5608 —19-05JUN02-3/8

Symptom	Problem	Solution
Lack of power	Engine overloaded.	Reduce load.
	Intake air restriction.	Service air cleaner.
	Clogged fuel filter.	Replace filter elements.
	Improper type of fuel.	Use proper fuel.
	Overheated engine.	See "Engine Overheats".
	Below normal engine temperature.	Remove and check thermostat.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Injection pump out of time.	See your authorized servicing dealer or engine distributor.
	Electronic fuel system problem	See your John Deere distributor or servicing dealer.
	Turbocharger not functioning. (Turbocharger engines only.)	See your authorized servicing dealer or engine distributor.
	Leaking exhaust manifold gasket.	See your authorized servicing dealer or engine distributor.
	Defective aneroid control line.	See your authorized servicing dealer or engine distributor.
	Restricted fuel hose.	Clean or replace fuel hose.
Low oil pressure	Low fast idle speed.	See your authorized servicing dealer or engine distributor.
	Low oil level.	Add oil.
	Improper type of oil.	Drain, fill crankcase with oil of proper viscosity and quality.

Continued on next page

RG, RG34710, 5608 -19-05JUN02-4/8

Symptom	Problem	Solution
High oil consumption	Crankcase oil too light.	Use proper viscosity oil.
	Oil leaks.	Check for leaks in lines, gaskets, and drain plug.
	Restricted crankcase vent tube.	Clean vent tube.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
Engine emits white smoke	Improper type of fuel.	Use proper fuel.
	Low engine temperature.	Warm up engine to normal operating temperature.
	Defective thermostat.	Remove and check thermostat.
	Defective injection nozzles.	See your authorized servicing dealer or engine distributor.
	Defective glow plugs (4045HF475, 6068HF475)	Test glow plugs (See 2000 hour/6 month maintenance section)
Engine emits black or gray exhaust smoke	Improper type of fuel.	Use proper fuel.
	Clogged or dirty air cleaner.	Service air cleaner.
	Engine overloaded.	Reduce load.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Electronic fuel system problem	See your authorized servicing dealer or engine distributor.
	Turbocharger not functioning.	See your authorized servicing dealer or engine distributor.

Continued on next page

RG, RG34710, 5608 -19-05JUN02-5/8

Symptom	Problem	Solution
Engine overheats	Engine overloaded.	Reduce load.
	Low coolant level.	Fill radiator to proper level, check radiator and hoses for loose connections or leaks.
	Faulty radiator cap.	Have technician check.
	Stretched poly-vee belt or defective belt tensioner.	Check automatic belt tensioner and check belts for stretching. Replace as required.
	Low engine oil level.	Check oil level. Add oil as required.
	Cooling system needs flushing.	Flush cooling system.
	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check coolant temperature with thermometer and replace, if necessary.
	Incorrect grade of fuel.	Use correct grade of fuel.
	Improper type of fuel.	Use proper type of fuel.
High fuel consumption	Clogged or dirty air cleaner.	Service air cleaner.
	Engine overloaded.	Reduce load.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Electronic fuel system problem	See your authorized servicing dealer or engine distributor.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
	Low engine temperature.	Check thermostat.

Continued on next page

RG, RG34710, 5608 -19-05JUN02-6/8

Symptom	Problem	Solution
Undercharged electrical system	Excessive electrical load from added accessories.	Remove accessories or install higher output alternator.
	Excessive engine idling.	Increase engine rpm when heavy electrical load is used.
	Poor electrical connections on battery, ground strap, starter, or alternator.	Inspect and clean as necessary.
	Defective battery.	Test battery.
	Defective alternator.	Test charging system.
Battery uses too much water	Cracked battery case.	Check for moisture and replace as necessary.
	Defective battery.	Test battery.
	Battery charging rate too high.	Test charging system.
Batteries will not charge	Loose or corroded connections.	Clean and tighten connections.
	Sulfated or worn-out batteries.	See your authorized servicing dealer or engine distributor.
	Stretched poly-vee belt or defective belt tensioner.	Adjust belt tension or replace belts.
Starter will not crank	PTO engaged.	Disengage PTO.
	Loose or corroded connections.	Clean and tighten loose connections.
	Low battery output voltage.	See your authorized servicing dealer or engine distributor.
	Faulty start circuit relay.	See your authorized servicing dealer or engine distributor.
	Blown main system fuse (MDL-25)	Replace fuse.
Starter cranks slowly	Low battery output.	See your authorized servicing dealer or engine distributor.
	Crankcase oil too heavy.	Use proper viscosity oil.
	Loose or corroded connections.	Clean and tighten loose connections.

Continued on next page

RG, RG34710, 5608 -19-05JUN02-7/8

Symptom	Problem	Solution
Starter and hour meter functions; rest of electrical system does not function	Blown fuse on magnetic switch.	Replace fuse.
Entire electrical system does not function	Faulty battery connection.	Clean and tighten connections.
	Sulfated or worn-out batteries.	See your authorized servicing dealer or engine distributor.
	Blown main system fuse.	Replace fuse.

RG, RG34710, 5608 -19-05JUN02-8/8

Diagnostic Trouble Code Procedure (Using Electronic Instrument Panel)

IMPORTANT: Care should be used during diagnostic procedures to avoid damaging the terminals of connectors, sensors, and actuators. Probes should not be poked into or around the terminals or damage will result. Probes should only be touched against the terminals to make measurements.

Diagnosis of the Deere electronic control system should be performed according to the following procedure:

1. Make sure all engine mechanical and other systems not related to the electronic control system are operating properly.


NOTE: Liquid Crystal Display [LCD] will always default to last menu item. If an active Diagnostic Trouble Code (DTC) is present, display will alternately flash from the hour meter reading to DTC(s).

The code number will appear on the first line and the words *SrvcCode* on the second line. Active DTC(s) can be viewed by selecting "SrvcCode" on the menu and pressing both touch switches at the same time. Pressing touch switches (B) and (C) scrolls through various engine parameters and diagnostic trouble codes.

2. Read and record DTC(s) displayed on LCD of diagnostic gauge (A). For procedure to access diagnostic trouble codes, refer to "Using Diagnostic Gauge to Access Engine Information", earlier in this manual.

3. Go to the LISTING OF DIAGNOSTIC TROUBLE CODES (DTCs) later in this section, to interpret to the DTC(s) present.

4. Contact your nearest engine distributor or servicing dealer with a list of DTC(s) so that necessary repairs can be made.



Diagnostic Gauge - Electronic Instrument Panels

- A—LCD Display on Diagnostic Gauge
- B—Touch Switch (DOWN)
- C—Touch Switch (UP)

RG9923 -UN-16NOV99

Displaying Of Diagnostic Trouble Codes (DTCs)

Stored and active diagnostic trouble codes are output on the diagnostic gauge on the instrument panel according to the J1939 standard as a two-part code as shown on the tables on the following pages.

The first part is a two to four-digit Suspect Parameter Number (SPN) followed by a one or two-digit Failure Mode Identifier (FMI) code. In order to determine the exact failure, both parts (SPN and FMI) of the code are needed.

The SPN identifies the system or the component that has the failure; for example SPN 110 indicates a failure in the engine coolant temperature circuit.

The FMI identifies the type of failure that has occurred; for example FMI 3 indicates value above normal. Combining SPN 110 with FMI 3 yields engine coolant temperature input voltage too high, or the equivalent of 2-3 digit fault code 18.

If diagnosing an application that shows DTCs as SPNs and FMIs, using the following list, determine the equivalent 2-3 digit code and have your dealer use the diagnostic procedure in the component technical manual for that 2-3 digit code.

Always contact your servicing dealer for help in correcting diagnostic trouble codes which are displayed for your engine.

DPSG.OUOD002,1591 -19-12NOV01-1/1

Listing of Diagnostic Trouble Codes (DTCs) (Engines With Electronic Fuel Systems And Stanadyne DE10 Pump)

*NOTE: Not all of these codes are used on all OEM
engine applications*

Trouble Codes

Displayed Code SPN	FMI	Definition
28	3	Analog Throttle (B) Input Voltage High
	4	Analog Throttle (B) Input Voltage Low
29	3	Analog Throttle (A) Input Voltage High
	4	Analog Throttle (A) Input Voltage Low
91	3	Multi-state Throttle Input Voltage High
	4	Multi-state Throttle Input Voltage Low
100	1	Engine Oil Pressure Extremely Low
	3	Engine Oil Pressure Input Voltage High
	4	Engine Oil Pressure Input Voltage Low
	18	Engine Oil Pressure Moderately Low
105	3	Manifold Air Temperature Input Voltage High
	4	Manifold Air Temperature Input Voltage Low
	16	Manifold Air Temperature Moderately High
110	0	Engine Coolant Temperature High Most Severe
	3	Engine Coolant Temperature Input Voltage High
	4	Engine Coolant Temperature Input Voltage Low
	15	Engine Coolant Temperature High Least Severe
	16	Engine Coolant Temperature High Moderately Severe
158	17	ECU Power Down Error
174	3	Fuel Temperature Input Voltage High
	4	Fuel Temperature Input Voltage Low
	16	Fuel Temperature Moderately High
190	0	Engine Overspeed Extreme
	16	Engine Overspeed Moderate
620	3	Sensor Supply Voltage High
	4	Sensor Supply Voltage Low
637	2	Crankshaft Position Input Noise
	10	Crankshaft Position Input Pattern Error
970	31	Auxiliary Engine Shutdown Switch Active
971	31	External Engine Derate Switch Active
1076	0	Pump Control Valve Closure Too Long
	1	Pump Control Valve Closure Too Short
	5	Pump Solenoid Circuit Open
	6	Pump Solenoid Circuit Severely Shorted
	7	Pump Control Valve Closure Not Detected
	10	Pump Solenoid Circuit Moderately Shorted
	31	Engine Shutdown Warning
1109	31	Engine Shutdown
1569	31	Fuel Derate
2000	6	Internal ECU Failure

Continued on next page

OUOD002,0000170 -19-12NOV01-1/2

NOTE: *The Diagnostic Gauge on the electronic instrument panel can have communication problems that result in Error Codes being shown on its LCD display window. The following Error Codes all indicate that there is a Diagnostic Gauge communication error with the ECU. Contact your servicing dealer for help in correcting these codes:*

EE—Error	XXXXX—EP
	No Data
ACP—Err	XXXXX—BO
No Addr	No Data
ACP—Err	XXXXX—BR
BUS—EP	No Data

OUOD002,0000170 -19-12NOV01-2/2

Listing of Diagnostic Trouble Codes (DTCs) (Engines With Electronic Fuel Systems And Bosch VP44 Pump)

*NOTE: Not all of these codes are used on all OEM
engine applications*

Trouble Codes

Displayed Code SPN	FMI	Definition
28	3	Analog Throttle (A) No. 3 Voltage High
	4	Analog Throttle (A) No. 3 Voltage Low
29	3	Analog Throttle (B) No. 2 Voltage High
	4	Analog Throttle (B) No. 2 Voltage Low
84	2	Vehicle Speed Mismatch
91	3	Multistate Throttle Input High
	4	Multistate Throttle Input Low
94	1	Fuel Supply Pressure Extremely Low
	3	Fuel Supply Pressure Input Voltage High
	4	Fuel Supply Pressure Input Voltage Low
	18	Fuel Supply Pressure Moderately Low
100	1	Engine Oil Pressure Extremely Low
	3	Engine Oil Pressure Input Voltage High
	4	Engine Oil Pressure Input Voltage Low
	18	Engine Oil Pressure Moderately Low
105	0	Manifold Air Temperature Extremely High
	3	Manifold Air Temperature Input Voltage High
	4	Manifold Air Temperature Input Voltage Low
	16	Manifold Air Temperature Moderately High
107	0	Air Filter Differential Pressure
110	0	Engine Coolant Temperature Extremely High
	3	Engine Coolant Temperature Input Voltage High
	4	Engine Coolant Temperature Input Voltage Low
	15	Engine Coolant Temperature High Least Severe
	16	Engine Coolant Temperature Moderately High
111	1	Engine Coolant Level Low
158	17	ECU Power Down Error
174	0	Fuel Temperature High-Most Severe
	15	Fuel Temperature High-Least Severe
	16	Fuel Temperature High-Moderately Severe
	31	Fuel Temperature Sensor Faulty
189	0	Fuel temperature Sender Faulty
	31	Engine Speed Derate
190	0	Engine Overspeed Extreme
190	16	Engine Overspeed Moderate
620	3	Sensor Supply Voltage High
	4	Sensor Supply Voltage Low
627	4	ECU Unswitched, Power Missing
629	13	ECU Error
629	19	ECU to Pump Communication Error
632	2	Fuel Shutoff Error
	5	Fuel Shutoff Not Functioning

Continued on next page

RG41221,0000130 -19-12NOV01-1/2

Displayed Code	SPN	FMI	Definition
	636	2	Pump Position Sensor Input Noise
		8	Pump Position Sensor Input Missing
		10	Pump Position Sensor Input Pattern Error
	637	2	Crankshaft Position Input Noise
		8	Crankshaft Position Input Missing
		10	Crankshaft Position Input Pattern Error
	729	3	Inlet Air Heater Signal High
		5	Inlet Air Heater Signal Low
	810	2	Calculated Vehicle Speed Input Noise
	898	9	Vehicle Speed Invalid/Missing
	970	2	Auxiliary Engine Shutdown Switch Signal Invalid
		31	Auxiliary Engine Shutdown Switch Active
	971	31	External Engine Derate Switch Active
	1069	2	Tire Size Error
	1076	2	Injection Pump Detected Defect
	1077	7	Attempting to Fuel Without Command
		11	Pump Supply Voltage Out of Range
		12	Pump Self Test Error
		19	Pump Detected Communication Error
		31	Pump Initiated Engine Protection
	1078	7	ECU/Pump Timing Moderately Out of Sync
		11	ECU/Pump Speed Out of Sync
		31	ECU/Pump Timing Extremely Out of Sync
	1079	3	Sensor Supply 1 Voltage High
		4	Sensor Supply 1 Voltage Low
	1080	3	Sensor Supply 2 Voltage High
		4	Sensor Supply 2 Voltage Low
	1109	31	Engine Shutdown Warning
	1110	31	Engine Shutdown
	1485	2	Pump Power Relay Fault
	1569	31	Fuel Derate
	2000	13	Security Violation

NOTE: *The Diagnostic Gauge on the electronic instrument panel can have communication problems that result in Error Codes being shown on its LCD display window. The following Error Codes all indicate that there is a Diagnostic Gauge communication error with the ECU. Contact your servicing dealer for help in correcting these codes:*

EE—Error	XXXXX—EP
	No Data
ACP—Err	XXXXX—BO
No Addr	No Data
ACP—Err	XXXXX—BR
BUS—EP	No Data

Listing of Diagnostic Trouble Codes (DTCs) (Engines With Electronic Fuel Systems And Denso High Pressure Common Rail)

*NOTE: Not all of these codes are used on all OEM
engine applications*

Trouble Codes

Displayed Code SPN	FMI	Definition
28	3	Analog Throttle (B) Input High
	4	Analog Throttle (B) Input Low
29	3	Analog Throttle (A) Input High
	4	Analog Throttle (A) Input Low
91	3	Multi-state Throttle Input High
	4	Multi-state Throttle Input Low
94	3	Fuel Rail Pressure Input Voltage High
	4	Fuel Rail Pressure Input Voltage Low
	10	Fuel Rail Pressure Loss Detected
	13	Fuel Rail Pressure Higher Than Expected
97	17	Fuel Rail Pressure Not Detected
	0	Water In Fuel Continuously Detected
	16	Water In Fuel Detected
100	1	Engine Oil Pressure Extremely Low
	3	Engine Oil Pressure Input Voltage High
	4	Engine Oil Pressure Input Voltage Low
	18	Engine Oil Pressure Moderately Low
105	0	Manifold Air Temperature Extremely High
	3	Manifold Air Temperature Input Voltage High
	4	Manifold Air Temperature Input Voltage Low
	16	Manifold Air Temperature Moderately High
107	0	Air Filter Restriction High
110	0	Engine Coolant Temperature High Most Extreme
	3	Engine Coolant Temperature Input Voltage High
	4	Engine Coolant Temperature Input Voltage Low
	15	Engine Coolant Temperature High Least Severe
	16	Engine Coolant Temperature High Moderately Severe
111	1	Engine Coolant Level Low
158	17	ECU Power Down Error
174	0	Fuel Temperature High Most Severe
	3	Fuel Temperature Input Voltage High
	4	Fuel Temperature Input Voltage Low
	16	Fuel Temperature High Moderately Severe
189	0	Engine Speed Derate
190	0	Engine Overspeed Extreme
611	3	Electronic Injector Wiring Shorted To Power Source
	4	Electronic Injector Wiring Shorted To Ground
620	3	Sensor Supply 1 Voltage High
	4	Sensor Supply 1 Voltage Low
627	1	Electronic Injector Supply Voltage Problem
629	13	ECU Error

Continued on next page

OUOD006,0000016 -19-23MAY02-1/2

Displayed Code

SPN	FMI	Definition
636	2	Pump Position Sensor Input Noise
	8	Pump Position Sensor Input Missing
	10	Pump Position Sensor Input Pattern Error
637	2	Crankshaft Position Input Noise
	7	Crank Position/Pump Position Timing Moderately Out Of Sync
	8	Crankshaft Position Input Missing
	10	Crankshaft Position Input Pattern Error
639	13	CAN Bus Error
651	5	Cylinder #1 Electronic Injector (EI) Circuit Open
	6	Cylinder #1 Electronic Injector (EI) Circuit Shorted
652	5	Cylinder #2 Electronic Injector (EI) Circuit Open
	6	Cylinder #2 Electronic Injector (EI) Circuit Shorted
653	5	Cylinder #3 Electronic Injector (EI) Circuit Open
	6	Cylinder #3 Electronic Injector (EI) Circuit Shorted
654	5	Cylinder #4 Electronic Injector (EI) Circuit Open
	6	Cylinder #4 Electronic Injector (EI) Circuit Shorted
655	5	Cylinder #5 Electronic Injector (EI) Circuit Open
	6	Cylinder #5 Electronic Injector (EI) Circuit Shorted
656	5	Cylinder #6 Electronic Injector (EI) Circuit Open
	6	Cylinder #6 Electronic Injector (EI) Circuit Shorted
970	31	External Engine Shutdown Switch Active
971	31	External Fuel Derate Switch Active
1079	3	Sensor Supply 2 Voltage High
	4	Sensor Supply 2 Voltage Low
1080	3	Fuel Rail Pressure Sensor Supply Voltage High
	4	Fuel Rail Pressure Sensor Supply Voltage Low
1109	31	Engine Protection Shutdown Warning
1110	31	Engine Protection Shutdown
1347	3	Pump Control Valve Current High
	5	Pump Control Valve Current Mismatch
	7	Fuel Rail Pressure Control Error
1568	2	Torque Curve Selection Invalid
1569	31	Fuel Derate

NOTE: *The Diagnostic Gauge on the electronic instrument panel can have communication problems that result in Error Codes being shown on its LCD display window. The following Error Codes all indicate that there is a Diagnostic Gauge communication error with the ECU. Contact your servicing dealer for help in correcting these codes:*

EE—Error	XXXXX—EP
	No Data
ACP—Err	XXXXX—BO
No Addr	No Data
ACP—Err	XXXXX—BR
BUS—EP	No Data

Intermittent Fault Diagnostics (With Electronic Controls)

Intermittent faults are problems that periodically “go away”. A problem such as a terminal that intermittently doesn’t make contact can cause an intermittent fault. Other intermittent may be set only under certain operating conditions such as heavy load, extended idle, etc. When diagnosing intermittent faults, take special note of the condition of wiring and connectors, since a high percentage of intermittent problems originate here. Check for loose, dirty or disconnected connectors. Inspect the wiring routing, looking for possible shorts caused by contact with external parts (for example, rubbing against sharp sheet metal edges). Inspect the connector vicinity, looking for wires that have pulled out of connectors, poorly positioned terminals, damaged connectors and corroded or damaged splices and terminals. Look for broken wires, damaged splices, and wire-to-wire shorts. Use good judgement if component replacement is thought to be required.

NOTE: The engine control unit (ECU) is the component LEAST likely to fail.

Suggestions for diagnosing intermittent faults:

- If the problem is intermittent, try to reproduce the operating conditions that were present when the diagnostic trouble code (DTC) set. When a DTC

sets, the ECU stores a freeze frame of the data parameter values the instant the DTC sets. Observing these values on the diagnostic gauge can help determine the operating conditions when the fault occurred. In addition, the diagnostic gauge includes a function called Snap Shot. The Snap Shot function permits the recording of the data parameter values during a diagnostic session. The Snap Shot mode can be set up so that its recording is “triggered” by the setting of a fault code.

- If a faulty connection or wire is suspected to be the cause of the intermittent problem: clear DTCs, then check the connection or wire by wiggling it while watching the diagnostic gauge to see if the fault resets.

Possible causes of intermittent faults:

- Faulty connection between sensor or actuator harness.
- Faulty contact between terminals in connector.
- Faulty terminal/wire connection.
- Electromagnetic interference (EMI) from an improperly installed 2-way radio, etc., can cause faulty signals to be sent to the ECU.

NOTE: Refer to wiring diagrams earlier in this section as a guide to connection and wiring.

OUOD007,0000036 –19–18OCT01–1/1

Storage

Engine Storage Guidelines

1. John Deere engines can be stored outside for up to three (3) months with no long term preparation IF COVERED BY WATERPROOF COVERING.
2. John Deere engines can be stored in a standard overseas shipping container for up to three (3) months with no long term preparation.
3. John Deere engines can be stored inside, warehoused, for up to six (6) months with no long term preparation.
4. John Deere engines expected to be stored more than six (6) months, long term storage preparation MUST BE taken. (See PREPARING ENGINE FOR LONG TERM STORAGE, later in this section.)

RG, RG34710, 5610 -19-23NOV01-1/1

Preparing Engine for Long Term Storage

The following storage preparations are good for long term engine storage up to one year. After that, the engine should be started, warmed up, and retreated for an extended storage period.

IMPORTANT: Any time your engine will not be used for over six (6) months, the following recommendations for storing it and removing it from storage will help to minimize corrosion and deterioration.

1. Change engine oil and replace filter. Used oil will not give adequate protection. (See CHANGE ENGINE OIL AND FILTER in Lubrication and Maintenance/500 Hour Section.)
2. Service air cleaner. (See REPLACING AIR CLEANER FILTER ELEMENTS in Service As Required Section.)
3. Draining and flushing of cooling system is not necessary if engine is to be stored only for several months. However, for extended storage periods of a year or longer, it is recommended that the cooling system be drained, flushed, and refilled. Refill with appropriate coolant. (See RECOMMENDED ENGINE COOLANT in Fuels, Lubricants, and Coolant Section and ADDING COOLANT in Service As Required Section.)
4. Crank the engine several revolutions with starter (do not allow the engine to start).
5. Remove fan/alternator poly-vee belt, if desired.
6. Remove and clean batteries. Store them in a cool, dry place and keep them fully charged.
7. Disengage the clutch for any driveline.
8. Clean the exterior of the engine with salt-free water and touchup any scratched or chipped painted surfaces with a good quality paint.
9. Coat all exposed (machined) metal surfaces with grease or corrosion inhibitor if not feasible to paint.
10. Seal all openings on engine with plastic bags and tape.
11. Store the engine in a dry protected place. If engine must be stored outside, cover it with a waterproof canvas or other suitable protective material and use a strong waterproof tape.

RG, RG34710, 5612 -19-23NOV01-1/1

Removing Engine from Long Term Storage

Refer to the appropriate section for detailed services listed below or have your authorized servicing dealer or engine distributor perform services that you may not be familiar with.

IMPORTANT: DO NOT operate starter more than 30 seconds at a time. Wait at least 2 minutes for starter to cool before trying again.

1. Remove all protective coverings from engine. Unseal all openings in engine and remove covering from electrical systems.
2. Remove the batteries from storage. Install batteries (fully charged) and connect the terminals.
3. Install fan/alternator poly-vee belt if removed.
4. Fill fuel tank.
5. Perform all appropriate prestarting checks. (See DAILY PRESTARTING CHECKS in Lubrication and Maintenance/Daily Section.)
6. Crank engine for 20 seconds with starter (do not allow the engine to start). Wait 2 minutes and crank engine an additional 20 seconds to assure bearing surfaces are adequately lubricated.
7. Start engine and run at low idle and no load for several minutes. Warm up carefully and check all gauges before placing engine under load.
8. On the first day of operation after storage, check overall engine for leaks and check all gauges for correct operation.

RG, RG34710, 5613 -19-20MAY96-1/1

Specifications

General OEM Engine Specifications

ITEM	4045TF275	4045HF275	4045HF475	6068TF275	6068HF275	6068HF475
Number of Cylinders	4	4	4	6	6	6
Bore	106 mm (4.19 in.)	106 mm (4.19 in.)	106 mm (4.19 in.)	106 mm (4.19 in.)	106 mm (4.19 in.)	106 mm (4.19 in.)
Stroke	127 mm (5.0 in.)	127 mm (5.0 in.)	127 mm (5.0 in.)	127 mm (5.0 in.)	127 mm (5.0 in.)	127 mm (5.0 in.)
Displacement	4.5 L (276 cu in.)	4.5 L (276 cu in.)	4.5 L (276 cu in.)	6.8 L (414 cu in.)	6.8 L (414 cu in.)	6.8 L (414 cu in.)
Compression Ratio	17.0:1	17.0:1	17.0:1	17.0:1	17.0:1	17.0:1
Aspiration	Turbocharged	Turbocharged	Turbocharged	Turbocharged	Turbocharged	Turbocharged
Engine Firing Order	1-3-4-2	1-3-4-2	1-3-4-2	1-5-3-6-2-4	1-5-3-6-2-4	1-5-3-6-2-4
Valves Per Cylinder	1 Intake 1 Exhaust	1 Intake 1 Exhaust	2 Intake 2 Exhaust	1 Intake 1 Exhaust	1 Intake 1 Exhaust	2 Intake 2 Exhaust
Valve Clearance (Cold) Intake (Checking)	0.31-0.38 mm (0.012-0.015 in)	0.31-0.38 mm (0.012-0.015 in)	0.31-0.38 mm (0.012-0.015 in)	0.31-0.38 mm (0.012-0.015 in)	0.31-0.38 mm (0.012-0.015 in)	0.31-0.38 mm (0.012-0.015 in)
Exhaust (Checking)	0.41-0.48 mm (0.016-0.019 in)	0.41-0.48 mm (0.016-0.019 in)	0.41-0.48 mm (0.016-0.019 in)	0.41-0.48 mm (0.016-0.019 in)	0.41-0.48 mm (0.016-0.019 in)	0.41-0.48 mm (0.016-0.019 in)
Intake (Adjusting)	0.36 mm (0.014 in.)	0.36 mm (0.014 in.)	0.36 mm (0.014 in.)	0.36 mm (0.014 in.)	0.36 mm (0.014 in.)	0.36 mm (0.014 in.)
Exhaust (Adjusting)	0.46 mm (0.018 in.)	0.46 mm (0.018 in.)	0.46 mm (0.018 in.)	0.46 mm (0.018 in.)	0.46 mm (0.018 in.)	0.46 mm (0.018 in.)
Max. Crank Pressure	0.5 kPa (2 H ₂ O)	0.5 kPa (2 H ₂ O)	0.5 kPa (2 H ₂ O)	0.5 kPa (2 H ₂ O)	0.5 kPa (2 H ₂ O)	0.5 kPa (2 H ₂ O)
Vibration Damper Maximum Radial Runout	1.50 mm (0.060 in.)	1.50 mm (0.060 in.)	1.50 mm (0.060 in.)	1.50 mm (0.060 in.)	1.50 mm (0.060 in.)	1.50 mm (0.060 in.)
Battery Capacities (CCA) 12-Volt System 24-Volt System	640 570	640 570	640 570	800 570	800 570	800 570
Governor Regulation (Industrial)	7—10 %	7—10 %	7—10 %	7—10 %	7—10 %	7—10 %
Governor Regulation (Generator)	5 %	5%	5%	5%	5 %	5%
Thermostat Start To Open Temperature	82°C (180°F)	82°C (180°F)	82°C (180°F)	82°C (180°F)	82°C (180°F)	82°C (180°F)
Thermostat Fully Open Temperature	94°C (202°F)	94°C (202°F)	94°C (202°F)	94°C (202°F)	94°C (202°F)	94°C (202°F)
Coolant Capacity	8.5 L (9 qt)	8.5 L (9 qt)	8.5 L (9 qt)	11.3 L (12 qt)	11.3 L (12 qt)	11.3 L (12 qt)
Recommended Radiator Pressure Cap	70 kPa (10 psi)	70 kPa (10 psi)	70 kPa (10 psi)	70 kPa (10 psi)	70 kPa (10 psi) ^a	100 kPa (15 psi) ^b

^aPressure cap for 6068HF275 with VP44 fuel system for non gen-set applications is 100 kPa (15 psi)

^bPressure cap for 6068HF475 for gen-set applications is 70 kPa (10 psi)

Continued on next page

RG, RG34710, 5614 -19-26APR02-1/2

Specifications

ITEM	4045TF275	4045HF275	4045HF475	6068TF275	6068HF275	6068HF475
Oil Pressure At Rated Speed, Full Load (\pm 15 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)	345 kPa (50 psi)
Oil Pressure At Low Idle (Minimum)	105 kPa (15 psi)	105 kPa (15 psi)	105 kPa (15 psi)	105 kPa (15 psi)	105 kPa (15 psi)	105 kPa (15 psi)
Length	860 mm (33.9 in.)	860 mm (33.9 in.)	860 mm (33.9 in.)	1116 mm (43.9 in.)	1123 mm (44.2 in.)	1123 mm (44.2 in.)
Width	612 mm (24.1 in.)	612 mm (24.1 in.)	612 mm (24.1 in.)	623 mm (24.5 in.)	623 mm (24.5 in.)	608 mm (23.9 in.)
Height	994 mm (39.1 in.)	994 mm (39.1 in.)	994 mm (39.1 in.)	1012 mm (39.9 in.)	1015 mm (40.0 in.)	1044 mm (41.1 in.)
Weight	451 kg (993 lb)	451 kg (993 lb)	451 kg (993 lb)	587 kg (1290 lb)	587 kg (1290 lb)	587 kg (1290 lb)

RG, RG34710, 5614 -19-26APR02-2/2

Engine Power Ratings¹ And Fuel System Specifications²

Engine Model	Fuel System Option Codes	Electronic Software Option Codes	System Voltage	Power Rating @ Rated Speed Without Fan kW (hp)	Rated Speed (rpm)	Slow Idle (rpm)	Fast Idle (rpm)
4045TF275	161K, 163H	7288	12V	86 (115)	2500	800	2700
	161L, 163L	7289	24V	86 (115)	2500	800	2700
	161K, 163H	7290	12V	82 (110)	2400	800	2600
	161L, 163L	7291	24V	82 (110)	2400	800	2600
	161K, 163H	7292	12V	84 (112)	1800	1150	1870
	161L, 163L	7293	24V	84 (112)	1800	1150	1870
4045HF275	161F, 163G	7262	12V	104 (140) ...	2400	800	2600
	161G, 163K	7263	24V	104 (140) ...	2400	800	2600
	161F, 163G	7264	12V	93 (125)	2400	800	2600
	161G, 163K	7265	24V	93 (125)	2400	800	2600
	161F, 163G	7266	12V	93 (125)	2200	800	2400
	161G, 163K	7267	24V	93 (125)	2200	800	2400
	161F, 163G	7268	12V	86 (115)	2000	800	2100
	161G, 163K	7269	24V	86 (115)	2000	800	2100
	161F, 163G	7270	12V	108 (145) ...	1800	1150	1870
	161G, 163K	7271	24V	108 (145) ...	1800	1150	1870
	161F, 163G	7272	12V	117 (157) ...	1800	1150	1870
	161G, 163K	7273	24V	117 (157) ...	1800	1150	1870
4045HF475 (4-Valve Head)	161V	72AT	12V	129 (173) ...	2400	800	2600
	161V	72AU	12V	119 (160) ...	2200	800	2400
	161V	72AV	12V	143 (192) ...	1800	1400	1870
	161V	72AW	12V	120 (161) ...	1500	1400	1560
6068TF275	161J, 163M	72AA	24V	123 (165) ...	2400	800	2600
	161H, 163F	72AB	12V	101 (135) ...	2200	800	2400
	161J, 163M	72AC	24V	101 (135) ...	2200	800	2400
	161H, 163F	72AD	12V	112 (150) ...	2200	800	2400
	161J, 163M	72AE	24V	112 (150) ...	2200	800	2400
	161H, 163F	72AF	12V	104 (140) ...	2000	800	2100
	161J, 163M	72AG	24V	104 (140) ...	2000	800	2100
	161H, 163F	72AH	12V	123 (165) ...	1800	1150	1870
	161J, 163M	72AJ	24V	123 (165) ...	1800	1150	1870

¹Power ratings are for bare engines without drag effect of cooling fan or accessories like air compressors.

²Engine speeds listed are preset to factory specification. Slow idle speed may be reset depending upon specific vehicle application requirements. Refer to your machine operator's manual for engine speeds that are different from those preset at the factory.

Continued on next page

RG, RG34710, 5616 -19-26APR02-1/2

Specifications

Engine Model	Fuel System Option Codes	Electronic Software Option Codes	System Voltage	Power Rating @ Rated Speed Without Fan kW (hp)	Rated Speed (rpm)	Slow Idle (rpm)	Fast Idle (rpm)
6068TF275	161H, 163F	7294	12V	116 (155)	2500	800	2700
	161J, 163M	7295	24V	116 (155)	2500	800	2700
	161H, 163F	7296	12V	127 (170)	2500	800	2700
	161J, 163M	7297	24V	127 (170)	2500	800	2700
	161H, 163F	7298	12V	123 (165)	2400	800	2600
6068HF275	16YS	7201	12V	168 (225)	2400	850	2600
	16YT	7202	24V	168 (225)	2400	850	2600
	16YS	7203	12V	149 (200)	2400	800	2600
	16YT	7204	24V	149 (200)	2400	850	2600
	16YS	7205	12V	138 (185)	2400	850	2600
	16YT	7206	24V	138 (185)	2400	850	2600
	16YS	7207	12V	149 (200)	2200	800	2400
	16YT	7208	24V	149 (200)	2200	800	2400
	16YS	7274	12V	187 (250)	2400	850	2600
	16YT	7275	24V	187 (250)	2400	850	2600
	16YS	7276	12V	168 (225)	2200	800	2400
	16YT	7277	24V	168 (225)	2200	800	2400
	16YS	7278	12V	157 (210)	2000	800	2100
	16YT	7279	24V	157 (210)	2000	800	2100
	161N, 163E	7280	12V	129 (173)	2000	800	2100
	161Q, 163J	7281	24V	129 (173)	2000	800	2100
	161N, 163E	7282	12V	164 (220)	1800	1150	1870
	161Q, 163J	7283	24V	164 (220)	1800	1150	1870
	16YS	7284	12V	187 (250)	1800	1150	1870
	16YT	7285	24V	187 (250)	1800	1150	1870
	16YS, 162B	7286	12V	210 (282)	1800	1150	1870
	16YT, 162C	7287	24V	210 (282)	1800	1150	1870
6068HF475 (4-Valve Head)	161U	72AP	12V	205 (275)	2400	800	2600
	161U	72AQ	12V	187 (250)	2200	800	2400
	161U	72AR	12V	234 (314)	1800	1400	1870
	161U	72AS	12V	207 (278)	1500	1400	1560

RG, RG34710, 5616 -19-26APR02-2/2

Engine Crankcase Oil Fill Quantities

To determine the option code for the oil fill quantity of your engine, refer to the engine option code label affixed to the rocker arm cover. The first two digits of the code (19) identify the oil pan option group. The last two digits of each code identify the specific oil pan on your engine.


NOTE: Crankcase oil capacity may vary slightly from amount shown. ALWAYS fill crankcase to within crosshatch on dipstick. DO NOT overfill.

The following table lists engine crankcase oil fill quantities:

Engine Model	Oil Pan Option Code(s)	Crankcase Oil Capacity L (qt)
4045TF275	1903	12.5 (13.2)
	1904	13.5 (14.3)
	1923	15.0 (15.8)
4045HF275	1904	13.5 (14.3)
	1923	15.0 (15.8)
	1976	20.5 (21.6)
4045HF475	1923	15.0 (15.8)
	1976	20.5 (21.6)
6068TF275	1907	19.5 (20.6)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1924	24.2 (25.6)
	1944	20.0 (21.1)
	1956	18.0 (19.0)
	1961	31.5 (33.3)
6068HF275	1907	19.5 (20.6)
	1908	19.0 (20.1)
	1909	19.0 (20.1)
	1924	24.2 (25.6)
	1961	31.5 (33.3)
6068HF475	1924	23.7 (25.0)
	1961	31.5 (33.3)

RG, RG34710, 5617 -19-16MAY02-1/1

Unified Inch Bolt and Cap Screw Torque Values



Top, SAE Grade and Head Markings; Bottom, SAE Grade and Nut Markings

Size	Grade 1 (No Mark)		Grade 2 ^a (No Mark)		Grade 5, 5.1 or 5.2		Grade 8 or 8.2	
	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)
1/4	3.8 (2.8)	4.7 (3.5)	6 (4.4)	7.5 (5.5)	9.5 (7)	12 (9)	13.5 (10)	17 (12.5)
5/16	7.7 (5.7)	9.8 (7.2)	12 (9)	15.5 (11.5)	19.5 (14.5)	25 (18.5)	28 (20.5)	35 (26)
3/8	13.5 (10)	17.5 (13)	22 (16)	27.5 (20)	35 (26)	44 (32.5)	49 (36)	63 (46)
7/16	22 (16)	28 (20.5)	35 (26)	44 (32.5)	56 (41)	70 (52)	80 (59)	100 (74)
1/2	34 (25)	42 (31)	53 (39)	67 (49)	85 (63)	110 (80)	120 (88)	155 (115)
9/16	48 (35.5)	60 (45)	76 (56)	95 (70)	125 (92)	155 (115)	175 (130)	220 (165)
5/8	67 (49)	85 (63)	105 (77)	135 (100)	170 (125)	215 (160)	240 (175)	305 (225)
3/4	120 (88)	150 (110)	190 (140)	240 (175)	300 (220)	380 (280)	425 (315)	540 (400)
7/8	190 (140)	240 (175)	190 (140)	240 (175)	490 (360)	615 (455)	690 (510)	870 (640)
1	285 (210)	360 (265)	285 (210)	360 (265)	730 (540)	920 (680)	1030 (760)	1300 (960)
1-1/8	400 (300)	510 (375)	400 (300)	510 (375)	910 (670)	1150 (850)	1450 (1075)	1850 (1350)
1-1/4	570 (420)	725 (535)	570 (420)	725 (535)	1280 (945)	1630 (1200)	2050 (1500)	2600 (1920)
1-3/8	750 (550)	950 (700)	750 (550)	950 (700)	1700 (1250)	2140 (1580)	2700 (2000)	3400 (2500)
1-1/2	990 (730)	1250 (930)	990 (730)	1250 (930)	2250 (1650)	2850 (2100)	3600 (2650)	4550 (3350)

^a Grade 2 applies for hex cap screws (not hex bolts) up to 6 in. (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.

^b "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

^c "Dry" means plain or zinc plated without any lubrication.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.


Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

Metric Bolt and Cap Screw Torque Values



Top, Property Class and Head Markings; Bottom, Property Class and Nut Markings

Size	Class 4.8		Class 8.8 or 9.8		Class 10.9		Class 12.9	
	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)
M6	4.7 (3.5)	6 (4.4)	9 (6.6)	11.5 (8.5)	13 (9.5)	16.5 (12.2)	15.5 (11.5)	19.5 (14.5)
M8	11.5 (8.5)	14.5 (10.7)	22 (16)	28 (20.5)	32 (23.5)	40 (29.5)	37 (27.5)	47 (35)
M10	23 (17)	29 (21)	43 (32)	55 (40)	63 (46)	80 (59)	75 (55)	95 (70)
M12	40 (29.5)	50 (37)	75 (55)	95 (70)	110 (80)	140 (105)	130 (95)	165 (120)
M14	63 (46)	80 (59)	120 (88)	150 (110)	175 (130)	220 (165)	205 (150)	260 (190)
M16	100 (74)	125 (92)	190 (140)	240 (175)	275 (200)	350 (255)	320 (235)	400 (300)
M18	135 (100)	170 (125)	265 (195)	330 (245)	375 (275)	475 (350)	440 (325)	560 (410)
M20	190 (140)	245 (180)	375 (275)	475 (350)	530 (390)	675 (500)	625 (460)	790 (580)
M22	265 (195)	330 (245)	510 (375)	650 (480)	725 (535)	920 (680)	850 (625)	1080 (800)
M24	330 (245)	425 (315)	650 (480)	820 (600)	920 (680)	1150 (850)	1080 (800)	1350 (1000)
M27	490 (360)	625 (460)	950 (700)	1200 (885)	1350 (1000)	1700 (1250)	1580 (1160)	2000 (1475)
M30	660 (490)	850 (625)	1290 (950)	1630 (1200)	1850 (1350)	2300 (1700)	2140 (1580)	2700 (2000)
M33	900 (665)	1150 (850)	1750 (1300)	2200 (1625)	2500 (1850)	3150 (2325)	2900 (2150)	3700 (2730)
M36	1150 (850)	1450 (1075)	2250 (1650)	2850 (2100)	3200 (2350)	4050 (3000)	3750 (2770)	4750 (3500)

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

^b "Dry" means plain or zinc plated without any lubrication.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

TORQ2 -UN-07SEP99

Lubrication and Maintenance Records

Using Lubrication and Maintenance Records

Refer to specific Lubrication and Maintenance Section for detailed service procedures.

1. Keep a record of the number of hours you operate your engine by regular observation of hour meter.
2. Check your record regularly to learn when your engine needs service.
3. DO ALL the services within an interval section. Write the number of hours (from your service records) and the date in the spaces provided. For a

complete listing of all items to be performed and the service intervals required, refer to the quick-reference chart near the front of the Lubrication and Maintenance Section.

IMPORTANT: The service recommendations covered in this manual are for the accessories that are provided by John Deere. Follow manufacturer's service recommendations for servicing engine driven equipment not supplied by Deere.

RG, RG34710, 5620 -19-20MAY96-1/1

Daily (Prestarting) Service

- Check engine oil level.
- Check coolant level.
- Check fuel filters/water bowls.
- Check air cleaner dust unloader valve and air restriction indicator, if equipped.
- Perform visual walkaround inspection.

RG, RG34710, 5621 -19-11JUN02-1/1

500 Hour/12 Month Service

- Change engine oil and filter.¹
- Service fire extinguisher.
- Service battery.
- Check automatic belt tensioner and belt wear.
- Clean crankcase vent tube.
- Check air intake hoses, connections, and system.
- Replace fuel filter element.
- Check automatic belt tensioner and belt wear.
- Check engine electrical ground connection.
- Check cooling system.
- Coolant solution analysis – add SCAs as needed.
- Pressure test cooling system.

Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									

¹Oil and filter change interval is every 250 hours/6 months UNLESS the special oil filter is installed AND John Deere PLUS 50® or ACEA-E4/E5 engine oils are used.

2000 Hour/24 Month Service

- Check crankshaft vibration damper (6-cylinder only).
- Flush cooling system.¹
- Test thermostats.
- Check and adjust valve clearance.
- Test glow plugs (4045HF475, 6068HF475)

Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									

¹If John Deere COOL-GARD is used, the flushing interval may be extended to 3000 hours, or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished as needed by adding a supplemental coolant additive, the flushing interval may be extended to 5000 hours or 60 months, whichever occurs first.

RG, RG34710, 5625 -19-06JUN02-1/1

Service as Required

- Add coolant
- Service air cleaner.
- Replace poly-vee belts.
- Check fuses
- Bleed fuel system

Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									

RG, RG34710, 5627 -19-20MAY96-1/1

Emission System Warranty


U.S. EPA Emissions Control Warranty Statement

Emissions control-related parts and components are warranted by John Deere for five years or 3000 hours of operation, whichever occurs first. John Deere further warrants that the engine covered by this warranty was designed, built, and equipped so as to conform at the time of sale with all U.S. emissions standards at the time of manufacture, and that it is free of defects in materials and workmanship which would cause it not to meet these standards within the period of five years or 3000 hours of operation, whichever occurs first.

Warranties stated in this manual refer only to emissions-related parts and components of your engine. The complete engine warranty, less emissions-related parts and components, is provided separately as the "John Deere New Off-Highway Engine Warranty".

RG, RG34710, 7629 -19-30JUN97-1/1

Emissions Control System Certification Label



RG11947 -JUN-06NOV01

Emissions Label



CAUTION: Statutes providing severe penalties for tampering with emissions controls may apply to the user or dealer.

The emissions warranty described below applies only to those engines marketed by John Deere that have been certified by the United States Environmental Protection Agency (EPA) and/or California Air Resources Board (CARB); and used in the United States and Canada in non-road mobile (self-propelled or portable/transportable¹) equipment. The presence of an emissions label like the one shown signifies that the engine has been certified with the EPA and/or CARB. The EPA and CARB warranties only apply to new

engines having the certification label affixed to the engine and sold as stated above in the geographic areas. The presence of an EU number in the third line of the label signifies that the engine has been certified with the European Union countries per Directive 97/68/EC. The emissions warranty does not apply to the EU countries.

NOTE: The hp/kW rating on the engine emissions certification label specifies the gross engine hp/kW, which is flywheel power without fan. In most applications this will not be the same rating as the advertised vehicle hp/kW rating.

¹Equipment moved at least once every 12 months.

John Deere Service Literature Available

Technical Information

Technical information is available from John Deere. Some of this information is available in electronic as well as printed form. Order from your John Deere dealer or call **1-800-522-7448**. Please have available the model number, serial number, and name of the product.

Available information includes:

- **PARTS CATALOGS** list service parts available for your machine with exploded view illustrations to help you identify the correct parts. It is also useful in assembling and disassembling.
- **OPERATOR'S MANUALS** providing safety, operating, maintenance, and service information. These manuals and safety signs on your machine may also be available in other languages.
- **OPERATOR'S VIDEO TAPES** showing highlights of safety, operating, maintenance, and service information. These tapes may be available in multiple languages and formats.
- **TECHNICAL MANUALS** outlining service information for your machine. Included are specifications, illustrated assembly and disassembly procedures, hydraulic oil flow diagrams, and wiring diagrams. Some products have separate manuals for repair and diagnostic information. Some components, such as engines, are available in separate component technical manuals
- **FUNDAMENTAL MANUALS** detailing basic information regardless of manufacturer:
 - Agricultural Primer series covers technology in farming and ranching, featuring subjects like computers, the Internet, and precision farming.
 - Farm Business Management series examines "real-world" problems and offers practical solutions in the areas of marketing, financing, equipment selection, and compliance.
 - Fundamentals of Services manuals show you how to repair and maintain off-road equipment.
 - Fundamentals of Machine Operation manuals explain machine capacities and adjustments, how to improve machine performance, and how to eliminate unnecessary field operations.



Parts Catalogs

RG9262 –UN-16MAR98



Operator Manuals

RG9260 –UN-16MAR98



Component Technical Manuals

RG9261 –UN-16MAR98



Fundamental Manuals

TS1663 –UN-10OCT97

DPSG, RG41165, 134 –19-10JUL00-1/1

Publications for this Engine

Technical information is available from John Deere in support of our products. Some of this information is available in electronic as well as printed form. Order from your John Deere dealer or call **1-800-522-7448**. Please have available the model number, and name of your engine.

Publications For *POWERTECH* 4.5 And 6.8 L Diesel Engines (English).

Publication Type	Title	Order Number
Operation And Maintenance Manual	<i>POWERTECH</i> 4.5 L and 6.8 L Electronically-Controlled OEM Diesel Engines	OMRG33324
Parts Catalogs	<i>POWERTECH</i> 4.5 L OEM Diesel Engines (4045TF275, 4045HF275, 4045HF475)	PC9080
	<i>POWERTECH</i> 6.8 L OEM Diesel Engines (6068TF275, 6068HF275, 6068HF475)	PC9081
Component Technical Manuals	<i>POWERTECH</i> 4.5 & 6.8 L Diesel Engines—Base Engine	CTM104
	Level 4 Electronic Fuel System With Bosch VP44 Pump	CTM170
	Level 12 Electronic Fuel System With Stanadyne DE10 Pump	CTM331
	Level 11 Electronic Fuel System With Denso High Pressure Common Rail	CTM220
	OEM Engine Accessories	CTM67
	Alternators And Starter Motors	CTM77

DPSG,RG34710,105 -19-26APR02-1/1

Index

Page

Page

A

Acid burns	30-2
Adjust	
Valves, 275 engines	35-8
Valves, 475 engines	35-11
Air cleaner	
Air intake restriction indicator	25-1
Dust unloader valve	25-1
Replace single stage element	40-4
Air intake system, check.	30-10
Alternator belts	40-9
Analysis	
Dieselscan	10-5
Auxiliary gear drive, limitations	15-30

B

Batteries	
Charge/Boost	15-26
Service	30-2
Battery acid burns	30-2
Battery explosion	30-2
Belt tensioner	
Manual tensioner, adjust	30-4
Manual tensioner, adjust with tool	30-5
Belt tensioner, automatic	30-13
Belts, fan and alternator	
Replacing	40-9
Bio-Diesel fuel	10-3
Bleeding fuel system	
DE10 pump.	40-13
High Pressure Common Rail.	40-16
VP44 pump.	40-11
Break-in, engine	15-17

C

Chart, service interval.	20-2, 20-4
Check and adjust	
Valves, 275 engines	35-8
Valves, 475 engines	35-11
Check engine electrical ground.	30-15
Cold weather aids.	10-6, 15-24, 35-14
Coolant	
Adding	40-2
Additional information	10-14
Analysis	10-10
Diesel engine	10-13

Disposing	10-17
Replenishing supplemental additives.	30-16
Supplemental additives	10-16
Testing	10-15, 30-18
Warm temperature climates	10-17
Cooling system	
Adding coolant	40-2
Check	30-15
Flush.	35-2
Pressure test.	30-19
Pressure test radiator cap.	30-19
Crankcase vent tube, clean	30-9
Crankshaft vibration damper.	35-1

D

Damper, checking.	35-1
Diagnostic procedure	45-16
Using diagnostic gauge.	15-7
Diagnostic trouble codes (DTC's)	45-16
Diagnostic Trouble Codes (DTCs)	
Electronic systems and Bosch VP44.	45-20
Electronic systems and Denso High Pressure	
Common Rail.	45-22
Electronic systems and Stanadyne DE10	45-18
Diesel engine oil.	10-9
Diesel fuel	10-1
Storage	10-5
Dieselscan fuel analysis	10-5

E

Emissions	
EPA Statement	65-1
Engine	
Break-in	15-17
Check electrical ground.	30-15
Idling.	15-27
Operation	15-22
Option codes.	01-3
Serial number	01-1
Starting	15-20
Stopping	15-29
Troubleshooting	45-8
Warming	15-23
Engine coolant	
Disposing of	10-17
Engine mounts	
Checking.	30-1

	Page		Page
Engine oil		I	
Break-In	10-8	Idling engine.	15-27
Change.	30-7	Inch torque values	55-6
Diesel	10-9	Instrument panel.	15-1
Engine wiring diagram		Intermittent fault diagnostics	45-24
W/electronic instrument panel.	45-6		
Engine wiring layout		L	
With Bosch VP44 pump	45-4	Listing of DTCs.	45-18, 45-20, 45-22
With Denso High Pressure Common Rail	45-5	Lubricants	
With Stanadyne DE10 pump.	45-3	Mixing	10-10
		Storage.	10-11
F		Lubrication and Maintenance	
Fan belts	40-9	Service Interval Chart	20-2, 20-4
Filter, replace		Lubricity of diesel fuel.	10-2
Oil.	30-7		
Filters, replace		M	
Fuel	30-11	Maintenance interval chart	
Fire extinguisher, service	30-1	Generator (Standby) applications	20-4
Fuel		Standard industrial applications.	20-2
Bio-Diesel	10-3	Manual belt tensioner	30-4
Diesel	10-1	Manual belt tensioner - using belt tension tool . .	30-5
Dieselscan Analysis	10-5	Metric torque values.	55-7
Storage.	10-5	Mixing lubricants.	10-10
Fuel filter		Mounts, engine	
Checking.	25-1	Checking.	30-1
Draining water.	25-1		
Fuel filters		O	
Replace	30-11	Oil	
Fuel injection pump model number.	01-5	Analysis	10-10
Fuel system		Dipstick.	25-1
Bleeding (DE10 pump)	40-13	Fill quantity	55-5
Bleeding (High Pressure Common Rail)	40-16	Filler locations.	25-1
Bleeding (VP44 pump)	40-11	Oil filter, change	30-7
Fuel tank		Operating engine	
Filling	10-2	Break-in	15-17
Fuses, checking	40-10	Cold weather.	10-6, 15-24
		Normal operation	15-22
G		Option codes	01-3
Gauges	15-23		
Generator (Standby) Applications.	20-4	P	
Glow plugs		Poly-vee belts	
Test, 475 engines	35-14	Replace	40-9
Grease			
Extreme pressure and multipurpose	10-12		

	Page		Page
Power ratings	55-3	Thermostat	
Precautions for welding on engines equipped w/ECU	45-2	Install	35-5
		Remove	35-5
		Test opening temperature	35-5
		Torque values	
		Inch.	55-6
		Metric	55-7
		Trouble codes	
		Electronic systems and Bosch VP44	45-20
		Electronic systems and Denso High Pressure Common Rail.	45-22
		Electronic systems and Stanadyne DE10 . . .	45-18
		Troubleshooting	
		General, engine	45-8
R		V	
Radiator cap testing	30-19	Valves	
Radiator shutters	10-6	Clearance, check and adjust	
Recordkeeping		275 engines.	35-8
Engine option codes	01-3	475 engines.	35-11
Engine serial number	01-1	Vibration damper	35-1
Injection pump model number.	01-5		
S		W	
Serial number		Warming engine	15-23
Engine	01-1	Warranty	
Fuel injection pump.	01-5	Emission System	65-2
Service		Winterfronts	10-6
Battery	30-2	Wiring diagrams, engine	
Fire extinguisher	30-1	Engines w/electronic instrument panel	45-6
Intervals	20-2, 20-4	Wiring harness	
Service literature	70-2	With Bosch VP44 pump	45-4
Specifications		With Denso High Pressure Common Rail . . .	45-5
Battery capabilities	30-2	With Stanadyne DE10 pump.	45-3
Belt tensioner	30-13		
Damper.	35-1		
Engine crankcase oil fill	55-5		
Fuel injection pump and power ratings	55-3		
General OEM	55-1		
Standby power units.	15-30		
Starting engine.	15-20		
Stopping engine	15-29		
Storage			
Guidelines.	50-1		
Long term	50-2		
Removing from	50-3		
Storing lubricants	10-11		
Supplemental coolant additives			
Replenishing.	30-16		
T			
Tensioner, belt			
Automatic	30-13		
Manual	30-4		



GENERATOR PARTS LISTS

GENERATOR MODEL G200

SALES OFFICES

Sales Office United Kingdom Facility details

Ingersoll-Rand European Sales Ltd
Swan Lane
Hindley Green
Wigan WN2 4EZ
United Kingdom
Phone +44 (0) 1942 257 171
Fax +44 (0) 1942 523 417

Structure de l'Organisation en France Coordonnées du Site

Ingersoll-Rand Portable Power
Zone du Cène Sourcier
B.P 62
LES CLAYES SOUS BOIS Cedex 78236
FRANCE
Téléphone +33 1 30 07 68 62
Fax +33 1 30 07 68 71

Organisatorische Bekanntmachung im Deutschland Unternehmensdetails

Ingersoll-Rand Gmbh
Gewerbealle 17
Mulheim D-45478
Germany
Telefon +49 208 99 94 400
Fax +49 208 99 94 111

Dirección de la organización en España Dirección

Ingersoll-Rand Iberia, S.L.
C/ Tierra de Barros nº 2
Poligono Industrial de Coslada
28820 Coslada (Madrid)
Spain
Teléfono +34 91 627 74 07
Fax +34 91 627 74 08

Sales Office The Netherlands Facility details

Ingersoll-Rand Benelux N.V.
Produktieweg 10
2382 PB Zoeterwoude-Rijndijk
The Netherlands
Phone +31 (0)71 58 23456
Fax +31 (0)71 58 23400

TABLE OF CONTENTS

G200

ENGINE FUNCTION 6068H.....	5
ENGINE JD 6068H DETAIL.....	6
OIL SUMP DRAIN PUMP ASSEMBLY.....	7
AIR FILTER HEAVY DUTY ASSEMBLY.....	8
AIR FILTER 080350 DETAIL.....	9
AIR HEATER ASSEMBLY.....	10
TRANS. WATER TEMPERATURE-OIL PRESSURE ASSEMBLY.....	11
ENGINE WIRING LOOM 6068H.....	12
OUTPUT CABLES ALTERNATOR ASSEMBLY.....	13
ALTERNATOR LS 462M ASSEMBLY.....	14
ALTERNATOR LS 462M3 SAE 3/11,5 DETAIL.....	15
RADIATOR FITTINGS JD6068H ASSEMBLY.....	16
RADIATOR 030620 DETAIL.....	17
FUEL TANK M214 ASSEMBLY.....	18
FUEL FILLER 050110 DETAIL.....	19
FUEL PREFILTER KIT ASSEMBLY.....	20
EXHAUST MUFFLER M216 ASSEMBLY.....	22
HOT SPOT GUARDS ASSEMBLY.....	23
FRAME M216 JD 6068 ASSEMBLY.....	24
G200 ACCESSORY ASSEMBLY.....	25
M216 MISCELLANEOUS ASSEMBLY.....	26
WBH CANOPY M216 ASSEMBLY BEIGE.....	28
PANEL DOOR M216/413 ASSEMBLY.....	29
EMERGENCY STOP PANEL ASSEMBLY.....	30
R3000 BRACKET ASSEMBLY.....	31
EARTH ROD WITH CABLE CANOPY ASSEMBLY.....	32
INTELISYS™ ASSEMBLY.....	33
INTELLISYSTM PANEL SHEET METAL ASSEMBLY.....	34
INTELLISYSTM OPTION CB12 CARD.....	35
INTELLISYSTM OPTION USING PLATEN.....	36
INTELLISYSTM OPTION TENSION POTENTIOMETER.....	37
INTELLISYSTM OPTION EARTH LEAKAGE RELAY.....	38
INTELLISYSTM PANEL 12VDC ASSEMBLY.....	39
INTELLISYSTM OPTION EMERGENCY STOP.....	40
INTELLISYSTM WIRING LOOM FUNCTION.....	41
TERMINAL BLOCK HOUSING 250<I<=480A ASSEMBLY.....	42
PANEL DOOR M403 ASSEMBLY.....	43
POWER TERMINAL CONNECTIONS 360A ASSEMBLY.....	44
TERMINAL CONNECTION BLOCK ASSEMBLY.....	45
COMPACT CIRCUIT BREAKER 100A<I<630A ACCESSORIES.....	46
RETENTION BUND M216.....	47
3 WAY FUEL VALVE ASSEMBLY.....	49
AIR SHUT OFF VALVE JD 6068H ASSEMBLY.....	50
SPARK ARRESTER INERIS DN100 ASSEMBLY.....	51

SOCKET TYPE 2

SOCKET PANEL EU M216 TYPE 2 ASSEMBLY	52
SOCKETS PANEL T2-T6-T9 M216 ASSEMBLY	53
SOCKETS ASSEMBLY	54


SOCKET TYPE 4

SOCKET PANEL FR M216 TYPE 4 ASSEMBLY.....	55
SOCKETS ASSEMBLY	56


SOCKET TYPE 6

SOCKET PANEL FR M216 TYPE 6 ASSEMBLY.....	57
SOCKETS PANEL T2-T6-T9 M216 ASSEMBLY	58
SOCKETS ASSEMBLY	59
GALVANIZED SKID KIT	60
INTELLISYSTEM OPTION DUAL FREQUENCY.....	61
HOOD UNDERSHEETING M214.....	62
ELECTRONIC REGULATION KIT	63
INTELLISYSTEM OPTION SPEED POTENTIOMETER	64
COOLANT HEATER RESISTANCE 1000W 240V	65
INTELLISYSTEM OPTION WATER PREHEATING	66
INTELLISYSTEM OPTION BATTERY CHARGER 12V/2.5A	67
ROAD TRAILER M216 ASSEMBLY.....	68
EARTH ROD WITH CABLE CANOPY ASSEMBLY.....	69
ROAD TRAILER 130530 DETAIL.....	70
BREAK GEAR 303780 DETAIL.....	72
AXLE 303750 DETAIL	73

01₀₄₂




Item	Part Number	Description	Quantity	Units
F01042		ENGINE FUNCTION 6068H	1.0	UN
010160	85509149	ENGINE JD 6068HF SAE 3/11.5	1.0	UN




30₀₂₈

Item	Part Number	Description	Quantity	Units
F30028		ENGINE JD 6068H DETAIL	1.0	UN
301410	36881696	OIL FILTER	1.0	UN
301740	85400976	FUEL FILTER	1.0	UN
301710	85400851	BELT	1.0	UN
301730	85400893	INJECTOR	6.0	UN
302200	85400927	STARTER	1.0	UN
301720	85400877	CHARGING ALTERNATOR	1.0	UN
301810	85401313	WATER PUMP	1.0	UN
301750	85401099	PRESSURE SWITCH	1.0	UN
301770	85401164	TEMPERATURE SWITCH	1.0	UN
301790	85401206	THERMOSTAT SEAL	1.0	UN
301780	85401180	THERMOSTAT	1.0	UN
301760	85401131	ROCKER COVER GASKET	1.0	UN




04₀₀₁

Item	Part Number	Description	Quantity	Units
F04001	85403442	OIL SUMP DRAIN PUMP ASSEMBLY	1.0	UN
040110	85403426	OIL SUMP PUMP BRACKET	1.0	UN
040120	85403434	MANUAL PUMP	1.0	UN
182320	85409209	SCREW H M12x25	2.0	UN
180340	85409258	PIPE UNION MAL/MAL 3/8G	1.0	UN
181520	85492551	PIPE UNION FEMAL/MAL 1/2G	1.0	UN
180350	85409308	PIPE UNION ELBOW 90° MAL/FEM 3/8G	1.0	UN
181040	85417756	HOSE CLIP D16/27	2.0	UN
180450	85410298	GASKET D14x18	1.0	UN
180380	85409597	FLEXIBLE HOSE D15x23	0.65	ML
180390	85410165	WASHER 12x24	2.0	UN
180360	85409324	NOT FITTED	-	-
180370	85409423	NOT FITTED	-	-




Item	Part Number	Description	Quantity	Units
F08007	85404002	AIR FILTER HEAVY DUTY ASSEMBLY	1.0	UN
080330	85403848	AIR CLEANER CLAMP D330	2.0	UN
080340	85403863	RAIN CAP	1.0	UN
080350	85403921	AIR FILTER HEAVY DUTY	1.0	UN
080160	85404069	AIR FILTER BRACKET JD 4039	1.0	UN
080300	85404101	AIR FILTER BRACKET ALL JD	1.0	UN
180420	85409407	HOSE CLIP D70/90	1.0	UN
180510	85409415	HOSE CLIP D120/140	1.0	UN
183080	85509156	RUBBER HOSE ELBOW D76	1.0	UN
080240	85410108	AIR RESTRICTION INDICATOR	1.0	UN
180520	85409571	NOT FITTED	-	-
080360	85404093	NOT FITTED	-	-
180410	85409589	NOT FITTED	-	-


30₀₁₄




Item	Part Number	Description	Quantity	Units
F30014	85403921	AIR FILTER 080350 DETAIL	1.0	UN
300200	85400737	FILTER CARTRIDGE	1.0	UN
300210	85400786	FILTER CARTRIDGE	1.0	UN
300120	85501229	VACUATOR VALVE	1.0	UN
300230	85501294	DUST CUP	1.0	UN
080340	85403863	RAIN CAP	1.0	UN
181680	85501872	HOSE CLIP D140/160	1.0	UN

08₀₀₈

Item	Part Number	Description	Quantity	Units
F08008	85404291	AIR HEATER ASSEMBLY	1.0	UN
080200	85404267	AIR HEATER RESISTANCE 1200W 12V	1.0	UN
160880	85408177	AIR HEATER WIRING LOOM JD 6068	1.0	UN
160550	85408938	RELAY 12V 180A	1.0	UN
160170	85408896	RELAY 12V 20/30A	1.0	UN


11₀₀₂

Item	Part Number	Description	Quantity	Units
F11002	85404705	TRANS. WATER TEMPERATURE-OIL PRESSURE ASSEMBLY	1.0	UN
110110	85404598	PRESSURE SWITCH 00/10 BAR	1.0	UN
110140	85404606	TEMPERATURE SENSOR 40/120°	1.0	UN
180440	85409134	PIPE UNION REDUCER MAL/FEM 3/8SAE 1/8G	1.0	UN
180260	85409340	PIPE UNION REDUCER MAL/FEM M14x150 1/8NPTF	1.0	UN


16₂₀₄

Item	Part Number	Description	Quantity	Units
F16204	85509339	ENGINE WIRING LOOM 6068H	1.0	UN
168790	85509164	CONNECTOR BRACKET	1.0	UN
160950	85407963	WIRING BRACKET JD 6068	1.0	UN
160580	85407971	STARTING RELAY PROTECTION PANEL	1.0	UN
160960	85408045	ENGINE WIRING LOOM JD 6068	1.0	UN
160270	85408078	COPPER BAR 5x25	1.0	UN
160170	85408896	RELAY 12V 20/30A	2.0	UN
160180	85408912	AUTOMOBILE RELAY BASE	3.0	UN
165120	85410652	INTELLISYSTEM WIRING LOOM 010	1.0	UN
166270	85426971	ELECTRICAL SHAFT BRACKET	1.0	UN
166240	85427268	ELECTRICAL SHAFT D29	3.8	ML
162860	85427276	CLIP D29	7.0	UN
166250	85427029	CLIP D29	1.0	UN


16₀₀₄




Item	Part Number	Description	Quantity	Units
F16004	85407484	OUTPUT CABLES ALTERNATOR ASSEMBLY	1.0	UN
160420	85406742	CABLE OUTLET PLATE	1.0	UN
160500	85406874	FOAM CABLE PROTECTION	2.0	UN

02₀₀₆


Item	Part Number	Description	Quantity	Units
F02006		ALTERNATOR LS 462M ASSEMBLY	1.0	UN
020150	85509172	ALTERNATOR LS 462M	1.0	UN




Item	Part Number	Description	Quantity	Units
F30197		ALTERNATOR LS 462M3 SAE 3/11,5 DETAIL	1.0	UN
320730	85509180	WOUND STATOR ASSEMBLY	1.0	UN
320740	85509198	WOUND ROTOR ASSEMBLY	1.0	UN
320600	85508877	N.D.E BRACKET	1.0	UN
302310	85425916	BEARING LSA 462/471	1.0	UN
319880	85509065	WAVY WASHER	1.0	UN
320610	85508927	WOUND EXCITER FIELD	1.0	UN
320620	85508968	WOUND EXCITER ARMATURE	1.0	UN
302210	85425577	GOVERNOR	1.0	UN
302340	85425940	DRIVE DISC LSA 462	1.0	UN
302380	85426179	DIODE BRIDGE	1.0	UN
302090	85402444	SURGE SUPPRESSOR	1.0	UN
320630	85509016	O RING	1.0	UN



Item	Part Number	Description	Quantity	Units
F03041	85509354	RADIATOR FITTINGS JD6068H ASSEMBLY	1.0	UN
030180	85403251	RADIATOR BRACKET ENGINE JD 6068	2.0	UN
030620	85503605	RADIATOR JD 6068H WITH HOSE KIT	1.0	UN
030190	85509206	RADIATOR BRACKET JD 6CYL	1.0	UN
080370	85404135	AIR INLET PIPE JD 6068H	1.0	UN
080380	85404143	AIR HOSE BRACKET JD 6068H	1.0	UN
130110	85405017	ANTI-VIBRATION MOUNT D40 Th28	4.0	UN
180490	85409456	HOSE CLAMP D60	1.0	UN
181530	85427110	PIPE UNION FEMAL/MAL 1/4G	1.0	UN
180370	85409423	HOSE CLIP D20/32	2.0	UN
181540	85492163	GASKET D6x10	1.0	UN
181490	85416444	FLEXIBLE HOSE D12x19	0.75	ML
180380	85409597	NOT FITTED	-	-
130100	85405009	NOT FITTED	-	-




Item	Part Number	Description	Quantity	Units
F30082	85503605	RADIATOR 030620 DETAIL	1.0	UN
300970	85426013	RADIATOR BOTTOM HOSE	1.0	UN
300980	85426047	RADIATOR TOP HOSE	1.0	UN
180630	85426393	RUBBER HOSE D50	2.0	UN
300990	85502623	RADIATOR CHARGE AIR HOSE	1.0	UN
080370	85404135	AIR INLET PIPE JD 6068H	1.0	UN
301010	85500619	WATER RADIATOR	1.0	UN
301020	85500684	AIR RADIATOR	1.0	UN
181730	85500536	PLUG RADIATOR	1.0	UN
180300	85409399	HOSE CLIP D60/80	2.0	UN
181430	85412922	HOSE CLIP D50/70	2.0	UN
180620	85426385	T BOLT CLAMP D60/63	6.0	UN
301030	85500783	LEFT FAN PROTECTION	1.0	UN
301040	85500908	RIGHT FAN PROTECTION	1.0	UN
301050	85502532	RADIATOR TOP TRAVERSE	1.0	UN
300720	85502573	RADIATOR BOTTOM TRAVERSE	1.0	UN
300340	85509214	PLENUM 26"	1.0	UN
301070	85501070	RADIATOR RIGHT UPRIGHT	1.0	UN
301080	85501153	RADIATOR LEFT UPRIGHT	1.0	UN
300730	85502649	2 WAY VALVE	1.0	UN
180450	85410298	GASKET D14x18	1.0	UN
180100	85409316	PLUG 1/2G	1.0	UN




05₀₀₅

Item	Part Number	Description	Quantity	Units
F05005	85403533	FUEL TANK M214 ASSEMBLY	1.0	UN
050170	85403475	FUEL SUCCION PIPE L240 D8 3/8G	2.0	UN
050110	85403517	FUEL FILLING FUNNEL BASE TANK	1.0	UN
181750	85503035	PLUG TANK	1.0	UN
050120	85403509	LEVEL SENSOR ADAPTER	1.0	UN
110100	85404572	LEVEL SENSOR	1.0	UN
180130	85409068	SQARE FLANGE GASKET	1.0	UN
180140	85409076	ROUND FLANGE GASKET	1.0	UN
180360	85409324	PIPE UNION REDUCER MAL/FEM 1/2 3/8G	2.0	UN
180150	85409514	SPRING CLAMP D13/15	4.0	UN
680100	85410090	NOT FITTED	-	-


30₀₁₉

Item	Part Number	Description	Quantity	Units
F30019	85403517	FUEL FILLER 050110 DETAIL	1.0	UN
181750	85509222	PLUG TANK	1.0	UN
050420	85431120	FUEL FILTER	1.0	UN


05₀₀₄




Item	Part Number	Description	Quantity	Units
F05004	85403558	FUEL PREFILTER KIT ASSEMBLY	1.0	UN
050160	85403483	FUEL FILTER BRACKET	1.0	UN
050150	85403525	FUEL FILTER SEPARATOR	1.0	UN
180240	85409274	BANJO CONNECTOR MALE D08	2.0	UN
180250	85409282	BANJO SCREW M14X150 L26	2.0	UN
180150	85409514	SPRING CLAMP D13/15	4.0	UN
180270	85409522	GASKET D14x20	4.0	UN
181480	85416436	FLEXIBLE HOSE D8x14	2.2	ML




Item	Part Number	Description	Quantity	Units
F07004	85403830	ELECTRIC STARTER ISOLATED ASSEMBLY	1.0	UN
070100	85403699	BATTERY FIXING BRACKET	1.0	UN
070170	85403707	BATTERY ISOLATOR BRACKET	1.0	UN
070120	85403723	BATTERY ISOLATOR SWITCH	1.0	UN
070180	85403731	STARTING BATTERY 12V 100Ah 450A	1.0	UN
070160	85403806	BATTERY SUPPORT BRACKET M214/216	1.0	UN
160430	85406387	BATTERY CABLE (+) 50mm2 L700 RED	1.0	UN
160600	85406395	BATTERY CABLE (-) 50mm2 L700 BLACK	1.0	UN
160610	85408136	BATTERY CABLE (+) 50mm2 L700 RED	1.0	UN
165410	85502235	COWL	2.0	UN



Item	Part Number	Description	Quantity	Units
F09010	85404358	EXHAUST MUFFLER M216 ASSEMBLY	1.0	UN
090200	85404366	29dB MUFFLER	1.0	UN
090150	85503597	EXHAUST PIPE D114 JD	1.0	UN
181910	85509230	HOSE CLAMP D115	2.0	UN
180500	85409449	NOT FITTED	-	-


09₀₁₁

Item	Part Number	Description	Quantity	Units
F09011	85404473	HOT SPOT GUARDS ASSEMBLY	1.0	UN
130360	85405025	HOT SPOT GUARD BRACKET JD 6068	1.0	UN
130370	85405033	HOT SPOT GUARD JD 6068	1.0	UN
130380	85405157	HOT SPOT GUARD JD 6068	1.0	UN
130390	85405165	HOT SPOT GUARD JD 6068	1.0	UN


13₀₇₃

Item	Part Number	Description	Quantity	Units
F13073	85509362	FRAME M216 JD 6068 ASSEMBLY	1.0	UN
130410	85404895	FRAME TANK 410L M216	1.0	UN
130420	85401883	ANTI-VIBRATION MOUNT 330daN 3.5mm	4.0	UN
130250	85509248	ENGINE SUPPORT JD 4045/6068 LEFT SIDE	1.0	UN
130260	85509255	ENGINE SUPPORT JD 4045/6068 RIGHT SIDE	1.0	UN
180110	85409050	SPACER Th10 D80	2.0	UN


18₀₅₁



Item	Part Number	Description	Quantity	Units
F18051	85509370	G200 ACCESSORY ASSEMBLY	1.0	UN
050420	85431120	FUEL FILTER	1.0	UN
090300	85422772	MUFFLER EXTENSION D114	1.0	UN
090220	85404341	EXHAUST RAIN FLAP D114	1.0	UN
144560	85509263	WBH LATCH KEY	1.0	UN
181910	85509230	HOSE CLAMP D115	1.0	UN
181600	85428019	RECTANGULAR STICKER 450x600	2.0	UN
181900	85500213	ROUND STICKER D385	2.0	UN
184940	85509289	RECTANGULAR STICKER 1100x325	2.0	UN




Item	Part Number	Description	Quantity	Units
F13014	85404945	M216 MISCELLANEOUS ASSEMBLY	1.0	UN
140890	85405942	RADIATOR PANEL M216 JD 6068H	1.0	UN
160890	85406460	GROUND WIRES 16mm2	4.0	UN
160110	85406940	NOT FITTED	-	-




Item	Part Number	Description	Quantity	Units
F14047	85405637	WBH CANOPY M216 ASSEMBLY BEIGE	1.0	UN
130430	85491892	LIFTING EYE D61	1.0	UN
140730	85405660	CANOPY SIDE PANEL LOWER LEFT M216	1.0	UN
140710	85509297	SUPPORT ARCH M216	1.0	UN
140700	85405561	AIR DEFLECTOR M216 FRONT	1.0	UN
140720	85405652	CANOPY SIDE PANEL LOWER RIGHT M216	1.0	UN
140740	85405678	CENTER UPRIGHT DOOR M216 SEPARATOR	2.0	UN
140750	85405702	FRONT HOOD CLOSURE PANEL M216	1.0	UN
140760	85405769	AIR INLET LOUVER M216	1.0	UN
140770	85405868	CANOPY REAR RIGHT UPRIGHT M216	1.0	UN
140780	85405876	CANOPY REAR LEFT UPRIGHT M216	1.0	UN
140790	85405884	AIR DEFLECTOR M216 REAR	1.0	UN
140800	85405892	AIR DEFLECTOR M216 REAR	1.0	UN
140810	85405900	SOUNDPROOF PANELS BATCH M216	1.0	UN
140820	85405918	CANOPY FRONT RIGHT UPRIGHT M216	1.0	UN
140830	85405926	CANOPY FRONT LEFT UPRIGHT M216	1.0	UN
140840	85405934	CANOPY REAR TOP PANEL M216	1.0	UN
140850	85410215	AIR INLET LOUVER M216	1.0	UN
140310	85406098	CANOPY TOP ISOLATION BRACKET M223/214/216	5.0	UN
140860	85406114	CANOPY TOP M216	1.0	UN
140340	85406155	DOOR HINGE	8.0	UN
140350	85406189	ANTI-VIBRATION MOUNT 140daN 15mm	4.0	UN
144270	85509305	CANOPY DOOR LOCK KEY LOCK	4.0	UN
140360	85406205	PLUG D100	1.0	UN
140870	85406213	PLUG D6.9	8.0	UN
140170	85492460	STRIKER PLATE M400 CANOPY DOOR	4.0	UN
144550	85509313	CANOPY DOOR M216	4.0	UN
160900	85406437	CONTROL PANEL HOUSING M403	1.0	UN
160910	85406445	REAR PANEL M403 CONTROL PANEL HOUSING	1.0	UN
160920	85407138	RACK CLOSURE PANEL	1.0	UN
160370	85407302	TERMINAL CONNECTIONS CLOSURE PANEL M216	1.0	UN
160930	85407369	CONTROL PANEL HOUSING INTELLISYSTM M216/413	1.0	UN

14₀₀₄




Item	Part Number	Description	Quantity	Units
F14004	85406288	PANEL DOOR M216/413 ASSEMBLY	1.0	UN
140900	85405462	DOOR STOP	1.0	UN
140330	85406148	CANOPY DOOR LOCK KEY LOCK	1.0	UN
140340	85406155	DOOR HINGE	2.0	UN
140350	85406189	ANTI-VIBRATION MOUNT 140daN 15mm	1.0	UN
140910	85406262	STRIKER PLATE M403 CANOPY MICS/MCPS DOOR	1.0	UN
140920	85406296	CONTROL PANEL DOOR M216	1.0	UN
180530	85409498	CLIP-ON BRACKET	2.0	UN
141370	85405454	NOT FITTED	-	-

16₀₁₅





Item	Part Number	Description	Quantity	Units
F16015	85407187	EMERGENCY STOP PANEL ASSEMBLY	1.0	UN
161080	85406726	SOCKET BRACKET CLOSURE PANEL	1.0	UN
161070	85407294	EMERGENCY STOP PANEL	1.0	UN


16₂₁₆



Item	Part Number	Description	Quantity	Units
F16216	85427862	R3000 BRACKET ASSEMBLY	1.0	UN
168330	85427177	RUBBER GROMMET SUPPORT	2.0	UN
163330	85427193	INTELLISYSTM RACK BRACKET	2.0	UN
160520	85408391	RUBBER GROMMET D47	4.0	UN


16₀₀₆

Item	Part Number	Description	Quantity	Units
F16006	85407906	EARTH ROD WITH CABLE CANOPY ASSEMBLY	1.0	UN
160140	85408227	NEUTRAL/EARTH SYSTEM CABLE 25mm ² L10000 Gr/Ye	1.0	UN
160150	85408334	EARTH ROD L1000	1.0	UN
180120	85409191	CLIP-ON BRACKET	2.0	UN




Item	Part Number	Description	Quantity	Units
F16200	85509396	INTELISYS™ ASSEMBLY	1.0	UN
168200	85411569	INTELLISYS™ OPTION CB CARD	1.0	UN
168220	85411619	INTELLISYS™ OPTION USING PLATEN	1.0	UN
168230	85412286	INTELLISYS™ OPTION ELECTRIC PACK 12V	1.0	UN
168240	85412260	INTELLISYS™ OPTION EARTH LEAKAGE RELAY	1.0	UN
168190	85412013	INTELLISYS™ PANEL ASSEMBLY	1.0	UN
168180	85412005	INTELLISYS™ PANEL SHEET METAL ASSEMBLY	1.0	UN
168250	85411676	INTELLISYS™ OPTION EMERGENCY STOP	1.0	UN


Parts numbers listed are the only parts used in this model

30 041

Item	Part Number	Description	Quantity	Units
F30041	85412005	INTELLISYSTEM PANEL SHEET METAL ASSEMBLY	1.0	UN
302880	85504108	RIGHT HOUSING	1.0	UN
302890	85504116	LEFT HOUSING	1.0	UN
302900	85504124	ROTOR	2.0	UN
302910	85504132	SLAM SHUT DOOR LATCH	2.0	UN
302920	85504140	ORDER THE 302890	2.0	UN
302930	85504157	RING	2.0	UN
302940	85504165	SCREW M6X16	2.0	UN
302950	85504173	STOP	2.0	UN
302960	85504181	DOOR	1.0	UN
303160	85504298	INTELLISYSTEM HOUSING	1.0	UN


30₀₄₅

Item	Part Number	Description	Quantity	Units
F30045	85411569	INTELLISYSTEM OPTION CB12 CARD	1.0	UN
166390	85504058	RUBBER GROMMET	1.0	UN
166430	85402592	INTELLISYSTEM CARD CB12	1.0	UN
166370	85504033	INTELLISYSTEM WIRING LOOM C35S	1.0	UN
166440	85426112	FUSE CYLINDRICAL 12A	4.0	UN
166470	85426120	FUSE CYLINDRICAL 10A	1.0	UN
166450	85426138	FUSE CYLINDRICAL 1A	2.0	UN
166460	85426146	FUSE CYLINDRICAL 2,5A	1.0	UN
303240	85505154	CR2032 CELL	1.0	UN




30₀₅₁


Item	Part Number	Description	Quantity	Units
F30051	85411619	INTELLISYSTEM OPTION USING PLATEN	1.0	UN
166030	85408854	STOP	4.0	UN
303120	85504256	WIRING LOOM SUPPORT	0.21	ML
303170	85504306	USING TERMINAL	1.0	UN

30₀₅₂

Item	Part Number	Description	Quantity	Units
F30052	85412286	INTELLISYSTEM OPTION TENSION POTENTIOMETER	1.0	UN
302980	85504207	CLAMP D4.7	1.0	UN
303050	85504215	LOCK AXE SYSTEM	1.0	UN
166520	85504009	INTELLISYSTEM WIRING LOOM C106 L560	1.0	UN
303130	85504264	POTENTIOMETER 1kOHMS	1.0	UN




Item	Part Number	Description	Quantity	Units
F30053	85412260	INTELLISYSTEM OPTION EARTH LEAKAGE RELAY	1.0	UN
303090	85504249	FLASK	1.0	UN
164080	85413482	FUSE CYLINDRICAL 5A	2.0	UN
166500	85503985	INTELLISYSTEM WIRING LOOM C39 L2000	1.0	UN
303140	85504272	EARTH LEAKAGE RELAY 12V	1.0	UN
303110	85423473	TORE	1.0	UN
303080	85504231	FUSE HOUSING	2.0	UN
168410	85508570	NOT FITTED	-	-




30₀₄₂

Item	Part Number	Description	Quantity	Units
F30042	85412013	INTELLISYSTEM PANEL 12VDC ASSEMBLY	1.0	UN
302990	85426781	EMERGENCY STOP SWITCH	1.0	UN
302970	85504199	GROUND WIRES 10mm2	1.0	UN
166350	85504017	INTELLISYSTEM WIRING LOOM C3 L810	1.0	UN
166360	85504025	INTELLISYSTEM WIRING LOOM C11 L460	1.0	UN
303060	85504983	INTELLISYSTEM PLASTIC PLATE	1.0	UN
166380	85504041	EARTHING INTELLISYSTEM WIRING LOOM	1.0	UN
166400	85412021	INTELLISYSTEM DISPLAY	1.0	UN
303000	85402519	LAMP 12V	1.0	UN
303010	85503522	PANEL LIGHT CYLINDRIC D22	1.0	UN
303020	85426773	EMERGENCY STOP BUTTON	1.0	UN

30₀₅₅




Item	Part Number	Description	Quantity	Units
F30055	85411676	INTELLISYSTEM OPTION EMERGENCY STOP	1.0	UN
166490	85503977	INTELLISYSTEM WIRING LOOM C11 L2000	1.0	UN




Item	Part Number	Description	Quantity	Units
F16103	85509388	INTELLISYSTM WIRING LOOM FUNCTION	1.0	UN
166480	85411221	INTELLISYSTM WIRING LOOM 037/041	1.0	UN
166630	85410546	INTELLISYSTM WIRING LOOM 001	1.0	UN
166790	85509321	INTELLISYSTM WIRING LOOM 106	1.0	UN
166770	85410520	INTELLISYSTM WIRING LOOM 006	1.0	UN
166810	85411452	INTELLISYSTM WIRING LOOM 119	1.0	UN
166820	85411460	INTELLISYSTM WIRING LOOM 120	1.0	UN


EDITION: MAY2002



Item	Part Number	Description	Quantity	Units
F16045	85419851	TERMINAL BLOCK HOUSING 250<I<=480A ASSEMBLY	1.0	UN
161390	85424067	GLAND NUT PLATE TERMINAL CONNECTION M204/205	1.0	UN
161900	85417111	CABLE OUTPUT RUBBER SCREEN	1.0	UN
161910	85423739	WIRE BIB OUTPUT BRACKET M403	1.0	UN
161940	85417822	PANEL ANGLE BAR	1.0	UN
162090	85423796	CIRCUIT BREAKER BRACKET M403	1.0	UN
162140	85424414	CIRCUIT BREAKER PROTECTION PANEL	1.0	UN
162160	85424620	ISOLATION PANEL MCPS 250A	0.0	UN
162160	85424612	ISOLATION PANEL MCPS 250A	1.0	UN
161840	85423937	CABLE FIXING BRACKET MCPS M403	1.0	UN
161920	85423945	CABLE FIXING BRACKET MCPS M403	1.0	UN
181590	85496446	WING NUT M12	2.0	UN
162200	85418051	CIRCUIT BREAKER PROTECTION PLATE	1.0	UN


16₀₅₄

Item	Part Number	Description	Quantity	Units
F16054	85420081	PANEL DOOR M403 ASSEMBLY	1.0	UN
140660	85406130	DOOR HINGE	3.0	UN
162130	85422731	TERMINAL CONNECTION DOOR M403	0.0	UN
162180	85422756	TERMINAL CONNECTION DOOR M403	1.0	UN
160760	85407708	HINGE FIXING PLATE M214	3.0	UN
180460	85409225	1/4 TURN SCREW D9	2.0	UN
180470	85409233	CAPTIVE NUT FOR 1/4 TURN BOLT	2.0	UN
180480	85409241	WASHER FOR 1/4 TURN FASTENER	2.0	UN




Item	Part Number	Description	Quantity	Units
F16066	85427086	POWER TERMINAL CONNECTIONS 360A ASSEMBLY	1.0	UN
161410	85417319	EARTHING CABLE D8xD10 25mm2 L2500 Gr/Ye	1.0	UN
161420	85406601	EARTHING CABLE D8xD10 25mm2 L1800 Gr/Ye	1.0	UN
161460	85417335	POWER CABLE SINGLE CORE 100mm2 L1800	4.0	UN
161480	85416915	COPPER BAR 10x30	4.0	UN
161550	85416899	COPPER BAR 5x25	1.0	UN
161950	85417368	NEUTRAL/EARTH SYSTEM CABLE 25mm2 L800 Gr/Ye	1.0	UN
160770	85408342	INSULATION PIN	3.0	UN
160520	85408391	RUBBER GROMMET D47	5.0	UN
162410	85424679	CURRENT TRANSFORMER 400/5	3.0	UN
162430	85417905	COMPACT CIRCUIT BREAKER 4x400A	1.0	UN
162470	85415479	GLAND NUT PG29	4.0	UN
165190	85413284	GLAND NUT PG29	4.0	UN
162610	85422442	RUBBER GROMMET D79	1.0	UN
161690	85406981	NOT FITTED	-	-
163280	85407070	NOT FITTED	-	-

16₀₇₆




Item	Part Number	Description	Quantity	Units
F16076	85418176	TERMINAL CONNECTION BLOCK ASSEMBLY	1.0	UN
161850	85417061	COPPER BAR 10x50	4.0	UN
161860	85416972	COPPER BAR 10x30	1.0	UN
161870	85416980	COPPER BAR 10x30	1.0	UN
161880	85416998	COPPER BAR 10x30	1.0	UN
161890	85417004	COPPER BAR 10x30	1.0	UN
161930	85418077	PHASE ISOLATOR M403	4.0	UN
162360	85413706	INSULATION PIN	4.0	UN
162370	85421675	INSULATION PIN	4.0	UN
162390	85423598	CABLE CLAMP 120/240mm2	4.0	UN


16₀₃₆

Item	Part Number	Description	Quantity	Units
F16036		COMPACT CIRCUIT BREAKER 100A<I<630A ACCESSORIES	1.0	UN
162450	85408573	CIRCUIT BREAKER SHUNT RELEASE COIL 200/280VAC	1.0	UN

Part number listed is the only part used in this model




Item	Part Number	Description	Quantity	Units
F99004		RETENTION BUND M216	1.0	UN
130405	85404861	RETENTION BUND M216	1.0	UN
140690	85405553	NOT FITTED	-	-
130400	85404846	NOT FITTED	-	-




3 WAY FUEL VALVE OPTION 992370

Item	Part Number	Description	Quantity	Units
F05006	85403574	3 WAY FUEL VALVE ASSEMBLY	1.0	UN
050180	85403566	3 WAY FUEL VALVE BRACKET ALL JD	1.0	UN
050570	85426963	3 WAY FUEL VALVE LEVER 3/8G	1.0	UN
180170	85507861	PIPE UNION REDUCER MAL/FEM 3/8G D8	6.0	UN
180560	85409266	PIPE UNION REDUCER MAL/MAL D8 D8	4.0	UN
180180	85426377	PIPE UNION ELBOW MAL/MAL D8	4.0	UN
180190	85409290	PIPE UNION FEM/FEM D8	2.0	UN
180200	85409332	HOSE CLAMP D36	4.0	UN
180150	85409464	SPRING CLAMP D13/15	12.0	UN
183090	85409514	3 WAY FUEL VALVE	2.0	UN
181480	85416436	FLEXIBLE HOSE D8x14	6.0	ML
050130	85403491	NOT FITTED	-	-
680100	85410090	NOT FITTED	-	-
180220	85409530	NOT FITTED	-	-



EXPLOSIVE ATMOSPHERE OPTION 992380


Item	Part Number	Description	Quantity	Units
F08017	85410348	AIR SHUT OFF VALVE JD 6068H ASSEMBLY	1.0	UN
080510	85426294	ENGINE AIR INLET PIPE D50	1.0	UN
080520	85426302	ENGINE AIR INLET PIPE D50	1.0	UN
080420	85410249	AIR SHUT OFF VALVE D51	1.0	UN
160160	85408367	RELAY 12V/24V 75A	1.0	UN
160170	85408896	RELAY 12V 20/30A	1.0	UN
160180	85408912	AUTOMOBILE RELAY BASE	1.0	UN
180620	85426385	T BOLT CLAMP D60/63	1.0	UN
180630	85426393	RUBBER HOSE D50	1.0	UN

09₀₁₃

EXPLOSIVE ATMOSPHERE OPTION
992380

Item	Part Number	Description	Quantity	Units
F09013	85404556	SPARK ARRESTER INERIS DN100 ASSEMBLY	2.0	UN
090160	85404325	INERIS SPARK ARRESTER DN100	1.0	UN
181910	85509230	HOSE CLAMP D115	1.0	UN
180500	85409381	NOT FITTED	-	-


16₁₃₈



SOCKET OPTION
992390

Item	Part Number	Description	Quantity	Units
F16138	85506913	SOCKET PANEL EU M216 TYPE 2 ASSEMBLY		
162880	85406429	COPPER BAR 5x25	1.0	UN
166200	85499440	ELECTRICAL SHAFT D36	1.5	ML
160770	85408342	INSULATION PIN	2.0	UN
167720	85408607	POWER CONNECTION BLOCK	1.0	UN
164360	85408680	GLAND NUT PG36	2.0	UN
166900	85499689	PIPE UNION ELBOW 90° PG36	2.0	UN


16₁₂₁



SOCKET OPTION
992390


Item	Part Number	Description	Quantity	Units
F16121	85505774	SOCKETS PANEL T2-T6-T9 M216 ASSEMBLY	1.0	UN
166660	85427334	SOCKETS PANEL EC M223/214/223	1.0	UN
167540	85407765	REAR PANEL M223/216 CONTROL PANEL HOUSING	1.0	UN
167550	85407773	GLAND NUT PLATE CONTROL PANEL M223/216	1.0	UN
167560	85407781	REAR PANEL M216 CONTROL PANEL HOUSING	1.0	UN
167590	85505832	SOCKETS BRACKET PANEL	1.0	UN

16₁₂₆



SOCKET OPTION
992390


Item	Part Number	Description	Quantity	Units
F16126	85505881	SOCKETS ASSEMBLY	1.0	UN
167750	85408748	COMPACT CIRCUIT BREAKER 1x10A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
167760	85413169	COMPACT CIRCUIT BREAKER 1x15A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
166180	85501542	SOCKETS ADAPTATION PLATE	2.0	UN
167650	85506020	MOULDED CASE CIRCUIT BREAKER 4x32A	1.0	UN
167660	85506038	MOULDED CASE CIRCUIT BREAKER 4x63A	1.0	UN
164060	85408284	CIRCUIT BREAKER SUPPORT PLATE 12 MODULES	1.0	UN
167670	85408300	SOCKET GERMAN 230V 16A 2S+G	1.0	UN
167690	85408326	EC SOCKET 400V 32A 3S+N+G	1.0	UN
167700	85506046	EC SOCKET 400V 63A 3S+N+G	1.0	UN
165340	85408771	DIFFERENTIAL SWITCH 4P 25A 30mA	1.0	UN
167800	85506103	SOCKET EC 230V 16A 2S+G	1.0	UN



SOCKET OPTION
992390

Item	Part Number	Description	Quantity	Units
F16143	85507051	SOCKET PANEL FR M216 TYPE 4 ASSEMBLY	1.0	UN
162880	85406429	COPPER BAR 5x25	1.0	UN
166660	85427334	SOCKETS PANEL EC M223/214/223	1.0	UN
167540	85407765	REAR PANEL M223/216 CONTROL PANEL HOUSING	1.0	UN
167550	85407773	GLAND NUT PLATE CONTROL PANEL M223/216	1.0	UN
167560	85407781	REAR PANEL M216 CONTROL PANEL HOUSING	1.0	UN
167620	85505972	SOCKETS BRACKET PANEL	1.0	UN
166200	85499440	ELECTRICAL SHAFT D36	1.5	ML
160770	85408342	INSULATION PIN	2.0	UN
167720	85408607	POWER CONNECTION BLOCK	1.0	UN
164360	85408680	GLAND NUT PG36	2.0	UN
166900	85499689	PIPE UNION ELBOW 90° PG36	2.0	UN


16₁₃₁



SOCKET OPTION
992390

Item	Part Number	Description	Quantity	Units
F16131	85505964	SOCKETS ASSEMBLY		
167750	85408748	COMPACT CIRCUIT BREAKER 1x10A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
167760	85413169	COMPACT CIRCUIT BREAKER 1x15A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
167650	85506020	MOULDED CASE CIRCUIT BREAKER 4x32A	1.0	UN
164060	85408284	CIRCUIT BREAKER SUPPORT PLATE 12 MODULES	1.0	UN
167670	85408300	SOCKET GERMAN 230V 16A 2S+G	1.0	UN
167680	85408318	EC SOCKET 400V 16A 3S+N+G	1.0	UN
167690	85408326	EC SOCKET 400V 32A 3S+N+G	1.0	UN
165340	85408771	DIFFERENTIAL SWITCH 4P 25A 30mA	1.0	UN
167800	85506103	SOCKET EC 230V 16A 2S+G	1.0	UN
167820	85506434	MOULDED CASE CIRCUIT BREAKER 4x16A	1.0	UN


16₁₄₉



SOCKET OPTION
992390

Item	Part Number	Description	Quantity	Units
F16149	85507259	SOCKET PANEL FR M216 TYPE 6 ASSEMBLY		
162880	85406429	COPPER BAR 5x25	1.0	UN
166200	85499440	ELECTRICAL SHAFT D36	1.5	ML
160770	85408342	INSULATION PIN	2.0	UN
167720	85408607	POWER CONNECTION BLOCK	1.0	UN
164360	85408680	GLAND NUT PG36	2.0	UN
166900	85499689	PIPE UNION ELBOW 90° PG36	2.0	UN


16₁₂₁



SOCKET OPTION
992390

Item	Part Number	Description	Quantity	Units
F16121	85505774	SOCKETS PANEL T2-T6-T9 M216 ASSEMBLY	1.0	UN
166660	85427334	SOCKETS PANEL EC M223/214/223	1.0	UN
167540	85407765	REAR PANEL M223/216 CONTROL PANEL HOUSING	1.0	UN
167550	85407773	GLAND NUT PLATE CONTROL PANEL M223/216	1.0	UN
167560	85407781	REAR PANEL M216 CONTROL PANEL HOUSING	1.0	UN
167590	85505832	SOCKETS BRACKET PANEL	1.0	UN


16₁₂₈



SOCKET OPTION
992390


Item	Part Number	Description	Quantity	Units
F16128	85505915	SOCKETS ASSEMBLY	1.0	UN
167760	85413169	COMPACT CIRCUIT BREAKER 1x15A	2.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	2.0	UN
167650	85506020	MOULDED CASE CIRCUIT BREAKER 4x32A	1.0	UN
167660	85506038	MOULDED CASE CIRCUIT BREAKER 4x63A	1.0	UN
164060	85408284	CIRCUIT BREAKER SUPPORT PLATE 12 MODULES	1.0	UN
167690	85408326	EC SOCKET 400V 32A 3S+N+G	1.0	UN
167700	85506046	EC SOCKET 400V 63A 3S+N+G	1.0	UN
165340	85408771	DIFFERENTIAL SWITCH 4P 25A 30mA	1.0	UN
167810	85506111	SOCKET EC 110V 16A 2S+G	2.0	UN

13₀₆₆



SIMPLIFIED RETENTION TANK OPTION
992400

Item	Part Number	Description	Quantity	Units
F13066		GALVANIZED SKID KIT	1.0	UN
140690	85405553	HOOD UNDERSHEETING M216	1.0	UN
130400	85404846	NOT FITTED	-	-




DUAL FREQUENCY OPTION

992410


Item	Part Number	Description	Quantity	Units
F30075	85506723	INTELLISYSTM OPTION DUAL FREQUENCY	1.0	UN
304390	85506673	BUTTON	1.0	UN
304400	85506681	POTENTIOMETER 200kOHMS	1.0	UN
167460	85506566	INTELLISYSTM WIRING LOOM 124	1.0	UN
167470	85506574	INTELLISYSTM WIRING LOOM 125	1.0	UN
304410	85506699	POTENTIOMETER SUPPORT	1.0	UN
304420	85506707	KEY BUTTON	1.0	UN
304430	85506582	KEY SWITCH HOUSING	1.0	UN
304440	85506715	NO SWITCH	1.0	UN

14₀₃₄



SINGLE BASE PLATE OPTION
992420

Item	Part Number	Description	Quantity	Units
F14034		HOOD UNDERSHEETING M214	1.0	UN
130400	85404846	RETENTION BUND M216	1.0	UN




ELECTRONIC REGULATION OPTION

992430


Item	Part Number	Description	Quantity	Units
F06002	54602925	ELECTRONIC REGULATION KIT	1.0	UN
060100	85403616	ELECTRONIC ACTUATOR	1.0	UN
060130	85426260	SPEED ELECTRONIC GOVERNOR 12VCC	1.0	UN
060120	85403632	MAGNETIC SPEED SENSOR L75 3/4UNF	1.0	UN
161090	85407328	ELECTRONIC REGULATOR HOUSING BRACKET	1.0	UN
166780	85411445	INTELLISYSTEM WIRING LOOM 105	1.0	UN
160980	85407237	ELECTRONIC REGULATION HOUSING	1.0	UN
160990	85407245	HOUSING ELECTRONIC REGULATION	1.0	UN
161000	85407336	ELECTRONIC REGULATOR BRACKET	1.0	UN
161010	85408375	TERMINAL BLOCK 1x2.5mm2 GREY	3.0	UN
161020	85408706	STOP	1.0	UN
161030	85408789	TERMINAL BLOCK 1x4mm2 Gr/Ye	1.0	UN
160170	85408896	RELAY 12V 20/30A	1.0	UN
160180	85408912	AUTOMOBILE RELAY BASE	1.0	UN
160300	85408920	MOULDED CASE CIRCUIT BREAKER 1x16A	1.0	UN
161040	85410116	PLASTIC COVER TERMINAL BLOCK	1.0	UN

30₀₄₇



ELECTRONIC REGULATION OPTION
992430

Item	Part Number	Description	Quantity	Units
F30047	85412161	INTELLISYSTM OPTION SPEED POTENTIOMETER	1.0	UN
302980	85504207	CLAMP D4.7	1.0	UN
303050	85504215	LOCK AXE SYSTEM	1.0	UN
166510	85503993	INTELLISYSTM WIRING LOOM C105 L540	1.0	UN
303070	85504223	POTENTIOMETER 4.7kOHMS	1.0	UN




AUTO START OPTION

992440


Item	Part Number	Description	Quantity	Units
F16165				
030130	85401081	COOLANT HEATER RESISTANCE 1000W 240V	1.0	UN
110120	85404655	TEMPERATURE SWITCH 35/45°	1.0	UN
162460	85408581	AUXILARY CONTACT	1.0	UN
166670	85411155	INTELLISYSTM WIRING LOOM 035	1.0	UN
166650	85410827	INTELLISYSTM WIRING LOOM 013	1.0	UN
166870	85426898	INTELLISYSTM WIRING LOOM 016	1.0	UN
166720	85411486	INTELLISYSTM WIRING LOOM 121	1.0	UN

30₀₇₈



AUTO START OPTION
992440


Item	Part Number	Description	Quantity	Units
F30078	85412179	INTELLISYSTM OPTION WATER PREHEATING	1.0	UN
167410	85506517	INTELLISYSTM WIRING LOOM 031/33/34	1.0	UN
167420	85506525	INTELLISYSTM WIRING LOOM 100	1.0	UN
167430	85506533	INTELLISYSTM WIRING LOOM 027	1.0	UN
304360	85506640	SURGE SUPRESSOR BLOCK	1.0	UN
304370	85506657	RELAY	1.0	UN



AUTO START OPTION
992440

Item	Part Number	Description	Quantity	Units
F30079	85412054	INTELLISYSTM OPTION BATTERY CHARGER 12V/2.5A	1.0	UN
304380	85507622	CHARGER	1.0	UN
167440	85506541	INTELLISYSTM WIRING LOOM 022/024	1.0	UN
167450	85506558	INTELLISYSTM WIRING LOOM 009	1.0	UN



13₀₁₇



ROAD TRAILER OPTION 992450

Item	Part Number	Description	Quantity	Units
F13017	85405314	ROAD TRAILER M216 ASSEMBLY	1.0	UN
130460	85405249	TOWING BALL D50	1.0	UN
130490	85405223	TOWING EYE 76x42	1.0	UN
130470	85405231	TOWING EYE DIN 40	1.0	UN
130530	85405306	ROAD TRAILER M216	1.0	UN
130520	85405363	SPARE WHEEL M216 ROAD TRAILER ASSEMBLY	2.0	UN


16₀₀₆



ROAD TRAILER OPTION
992450

Item	Part Number	Description	Quantity	Units
F16006	85407906	EARTH ROD WITH CABLE CANOPY ASSEMBLY	1.0	UN
160140	85408227	NEUTRAL/EARTH SYSTEM CABLE 25mm2 L10000 Gr/Ye	1.0	UN
160150	85408334	EARTH ROD L1000	1.0	UN
180120	85409191	CLIP-ON BRACKET	2.0	UN

30₀₆₃




ROAD TRAILER OPTION

992450

Item	Part Number	Description	Quantity	Units
F30063	85405306	ROAD TRAILER 130530 DETAIL	1.0	UN
303690	85504769	RIGHT SPECIAL SIDE MEMBER	1.0	UN
303700	85504777	LEFT SPECIAL SIDE MEMBER	1.0	UN
303710	85504785	SOLDERED PROCESSING FRAME	1.0	UN
303720	85504793	FRONT CROSS MEMBER	1.0	UN
303730	85504801	LIGHTS CROSS MEMBER	1.0	UN
303470	85504546	TRIANGLE SUPPORT	2.0	UN
303480	85504553	RIGHT FRONT BOUNDING	1.0	UN
303490	85504561	LEFT FRONT BOUNDING	1.0	UN
303500	85504579	RIGHT REAR BOUNDING	1.0	UN
303510	85504587	LEFT REAR BOUNDING	1.0	UN
303520	85504595	RIGHT MUDGUARD FIXATION	1.0	UN
303530	85504603	LEFT MUDGUARD FIXATION	1.0	UN
303540	85504611	FIXING CLIP WHITE LITE	2.0	UN
303400	85504470	STANDARD GALVANIZED CYCLIST-GUARD	2.0	UN
303670	85504744	REINFORCEMENT OF LEFT TANDEM MUDGUARD	1.0	UN
303680	85504751	REINFORCEMENT OF RIGHT TANDEM MUDGUARD	1.0	UN
303740	85504819	SOCKET SUPPORT	1.0	UN
303750	85504827	FRONT AXLE	1.0	UN
303760	85504835	REAR AXLE	1.0	UN

Item	Part Number	Description	Quantity	Units
303770	85504843	POLE	1.0	UN
303590	85504660	INTERMEDIARY ARMS	1.0	UN
303780	85504850	BREAK GEAR	1.0	UN
303610	85504686	GALVANIZED MUDGUARD	2.0	UN
303620	85504694	JOCKEY WHEEL SUPPORT	1.0	UN
303630	85504702	SQUARE JOCKEY WHEEL	1.0	UN
303790	85504868	COMPLETE WHEEL	4.0	UN
303800	85504876	WHITE SQARE LIGHT WITH REFLECTOR	2.0	UN
303810	85504884	SHUTTLE LAMP	2.0	UN
303370	85504447	TRIANGULAR REFLECTOR	2.0	UN
303390	85504462	ROUND STICKY REFLECTOR ORANGE	4.0	UN
303410	85504488	ECIM PRODUCER PLATE	1.0	UN
303820	85504892	ELECTRIC BEAM	1.0	UN
303360	85504439	RIGHT REAR LIGHT	1.0	UN
303350	85504421	LEFT REAR LIGHT	1.0	UN
303830	85504900	ELECTRIC BEAM OF TRAILER TOWING BAR	1.0	UN

30₀₇₁




ROAD TRAILER OPTION

992450

Item	Part Number	Description	Quantity	Units
F30071	85504850	BREAK GEAR 303780 DETAIL	1.0	UN
304150	85505378	BELLOW	1.0	UN
304160	85505386	TRACTION TUBE	1.0	UN
304170	85505394	SHOCK ABSORBER	1.0	UN
304180	85505402	CONNECTING ROD	1.0	UN
304040	85505261	BREAK DOWN CABLE	1.0	UN
304190	85505410	COMPENSATOR	1.0	UN
304200	85505428	HANDBRAKE LEVER	1.0	UN
304210	85505436	FRICTION COLLAR	1.0	UN
304220	85505444	TRANSMISSION CABLE	1.0	UN
304140	85505360	LEVER AND AXLE	1.0	UN

30 074



ROAD TRAILER OPTION
992450

Item	Part Number	Description	Quantity	Units
F30074	85504827	AXLE 303750 DETAIL	1.0	UN
303950	85505170	HUB CAP	1.0	UN
304300	85505535	BEARING KIT	1.0	UN
303980	85505204	BOLTS KIT	1.0	UN
303990	85505212	NUTS KIT	1.0	UN
304280	85505519	BRAKE KIT	1.0	UN
304290	85505527	ADJUSTMENT KIT	1.0	UN
304250	85505477	BRAKE CABLE 1,40m KIT	1.0	UN
304260	85505485	BRAKE CABLE 1,60m KIT	1.0	UN

Users guide and maintenance manual

Leroy Somer Alternators LSA 46.2 / 47.1

Réf. constructeur : 2981 GB - 4.33/a
- 04.00

Réf. GPAO : 33522035901

LSA 46.2 / 47.1 ALTERNATORS

This manual concerns the alternator which you have just purchased.

The latest addition to a whole new generation of alternators, this range benefits from the experience of the world's leading manufacturer, using advanced technology and incorporating strict quality control.

We wish to draw your attention to the contents of this maintenance manual. By following certain important points during installation, use and servicing of your alternator, you can look forward to many years of trouble-free operation.

SAFETY MEASURES

Before using your machine for the first time, it is important to read the whole of this installation and maintenance manual.

All necessary operations and work on this machine must be performed by a qualified technician.

Our technical support service will be pleased to provide any additional information you may require.

The various operations described in this manual are accompanied by recommendations or symbols to alert the user to potential risks of accidents. It is vital that you understand and take notice of the following warning symbols.

WARNING

Warning symbol for an operation which may damage or destroy the machine or surrounding equipment.



Warning symbol for general danger to personnel.




Warning symbol for electrical danger to personnel.

Note : LEROY-SOMER reserves the right to modify the characteristics of its products at any time in order to incorporate the latest technological developments. The information contained in this document may therefore be changed without notice.

WARNING SYMBOLS

A set of self-adhesive stickers depicting the various warning symbols is included with this maintenance manual. They should be positioned as shown in the drawing below once the machine has been fully installed.



Copyright 2000 : MOTEURS LEROY-SOMER

This document is the property of :
MOTEURS LEROY-SOMER

It may not be reproduced in any form without prior authorization.

All brands and models have been registered and patents applied for.

LSA 46.2 / 47.1 ALTERNATORS

CONTENTS

1 - RECEIPT	4	4 - SERVICING - MAINTENANCE	15
Standards and safety measures		Safety measures	
Inspection		Regular maintenance	
Identification		Checks after start-up	
Storage		Cooling circuit	
		Bearings	
2 - TECHNICAL CHARACTERISTICS	5	Electrical servicing	
Electrical characteristics		Mechanical servicing	
Options		Fault detection	
Mechanical characteristics		Mechanical defects	
Options		Electrical faults	
Excitation system		Checking the winding	
R448 AVR characteristics		Checking the diode bridge	
R 448 power supply connection		Checking the windings and rotating diodes	
Frequency compared with voltage		using separate excitation	
LAM characteristics		Dismantling, reassembly	
Typical effects of the LAM		Tools required	
R 448 AVR options		Screw tightening torque	
		Access to diodes	
3 - INSTALLATION	8	Access to connections and the regulation system	
Assembly		Replacing the NDE bearing on	
Handling		single-bearing machines	
Coupling		Replacing the DE bearing on	
Location		two-bearing machines	
Inspection prior to first use		Complete dismantling	
Electrical checks		Reassembling the bearings	
Mechanical checks		Reassembling the rotor	
Terminal connection diagrams		Installation and maintenance of the PMG	
Terminal connection : LSA 46.2/47.1 - 12-wire		Mechanical characteristics	
Terminal connection : LSA 46.2/47.1 - 6-wire		Electrical connection	
Option connection diagram		Table of characteristics	
Connection checks		Average values for LSA 46.2	
Electrical checks on the AVR		Average values for LSA 47.1	
Commissioning			
Settings		5 - SPARE PARTS	23
R 448 settings		Technical support service	
Max. excitation setting		Accessories	
Special type of use		Space heater for use when stopped	
		Stator thermistor temperature probes (PTC)	
		Connection accessories	
		Exploded views, parts list	
		Single bearing	
		Two-bearing	

LSA 46.2 / 47.1**ALTERNATORS****RECEIPT****1 - RECEIPT****1.1 - Standards and safety measures**

Our alternators comply with most international standards and are compatible with :

- the recommendations of the

International Electrotechnical Commission

IEC 34-1, (EN 60034).

- the recommendations of the

International Standards Organisation ISO 8528.

- the European Community directive 89/336/EEC on Electromagnetic Compatibility (EMC).

- the European Community directives

73/23/EEC and 93/68/EEC (Low Voltage Directive).

They are CE marked with regard to the LVD (Low Voltage Directive) in their role as a machine component. A declaration of incorporation can be supplied on request.

Before using your generator for the first time, read carefully the contents of this installation and maintenance manual, supplied with the machine. All operations performed on the generator should be undertaken by qualified personnel with specialist training in the commissioning, servicing and maintenance of electrical and mechanical machinery. This maintenance manual should be retained for the whole of the machine's life and be handed over with the contractual file. The various operations described in this manual are accompanied by recommendations or symbols to alert the user to potential risks of accidents. It is vital that you understand and take notice of the different warning symbols.

1.2 - Inspection

On receipt of your alternator, check that it has not suffered any damage in transit. If there are obvious signs of damage, contact the carrier (you may be able to claim on their insurance) and after a visual check, turn the machine by hand to detect any malfunction.

1.3 - Identification

The alternator is identified by means of a nameplate fixed on the frame (see drawing).

Make sure that the nameplate on the machine conforms to your order.

The machine name is defined according to various criteria, for example : LSA 46.2 M6 C6/4 -

• LSA : name used in the PARTNER range

M : Marine

C : Cogeneration

T : Telecommunications.

• 46.2 : machine type

• M5 : model

• C : excitation system

(C : AREP / J : SHUNT or PMG / E : COMPOUND)

• 6/4 : winding number / number of poles.

1.3.1 - Nameplate



So that you can identify your machine quickly and accurately, we suggest you fill in its specifications on the nameplate below.

1.4 - Storage

Prior to commissioning, machines should be stored :

- Away from humidity : in conditions of relative humidity of more than 90%, the machine insulation can drop very rapidly, to just above zero at around 100%; monitor the state of the anti-rust protection on unpainted parts. For storage over an extended period, the machine can be placed in a sealed enclosure (heatshrink plastic for example) with dehydrating sachets inside, away from significant and frequent variations in temperature to avoid the risk of condensation during storage.

- If the area is affected by vibration, try to reduce the effect of these vibrations by placing the generator on a damper support (rubber disc or similar) and turn the rotor a fraction of a turn once a fortnight to avoid marking the bearing rings.

LEROY-SOMER		ALTERNATEURS PARTNER ALTERNATORS																																		
LSA	<input type="text"/>	Date	<input type="text"/>																																	
N	<input type="text"/>	Hz	<input type="text"/>																																	
Min-1/R.P.M.	<input type="text"/>	Protection	<input type="text"/>																																	
Cos Ø / P.F.	<input type="text"/>	Cl. ther. / Th.class	<input type="text"/>																																	
Régulateur/A.V.R.	<input type="text"/>																																			
Altitude	<input type="text"/>	Masse / Weight	<input type="text"/>																																	
Rlt AV/D.E bearing	<input type="text"/>																																			
Rlt AR/N.D.E bearing	<input type="text"/>																																			
Graisse / Grease	<input type="text"/>																																			
Valeurs excit / Excit. values	<input type="text"/>																																			
en charge / full load	<input type="text"/>																																			
à vide / at no load	<input type="text"/>																																			
<table border="1"> <thead> <tr> <th colspan="3">PUISSANCE / RATING</th> </tr> </thead> <tbody> <tr> <td>Tension</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>Voltage</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>Connex.</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>Continue</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>Continuous</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>40 C</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>Secours</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>Std by</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td>27 C</td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> <tr> <td colspan="3">(*) Tension maxi. / maximum voltage</td> </tr> </tbody> </table>				PUISSANCE / RATING			Tension	<input type="text"/>	<input type="text"/>	Voltage	<input type="text"/>	<input type="text"/>	Connex.	<input type="text"/>	<input type="text"/>	Continue	<input type="text"/>	<input type="text"/>	Continuous	<input type="text"/>	<input type="text"/>	40 C	<input type="text"/>	<input type="text"/>	Secours	<input type="text"/>	<input type="text"/>	Std by	<input type="text"/>	<input type="text"/>	27 C	<input type="text"/>	<input type="text"/>	(*) Tension maxi. / maximum voltage		
PUISSANCE / RATING																																				
Tension	<input type="text"/>	<input type="text"/>																																		
Voltage	<input type="text"/>	<input type="text"/>																																		
Connex.	<input type="text"/>	<input type="text"/>																																		
Continue	<input type="text"/>	<input type="text"/>																																		
Continuous	<input type="text"/>	<input type="text"/>																																		
40 C	<input type="text"/>	<input type="text"/>																																		
Secours	<input type="text"/>	<input type="text"/>																																		
Std by	<input type="text"/>	<input type="text"/>																																		
27 C	<input type="text"/>	<input type="text"/>																																		
(*) Tension maxi. / maximum voltage																																				
<div>  <input type="text" value="LR 0021"/>  </div>																																				
Conforme à C.E.I 34-1(1994). According to I.E.C 34-1(1994).																																				

Made by Leroy Somer - 1 024 647 Y

LSA 46.2 / 47.1


ALTERNATORS

TECHNICAL CHARACTERISTICS

2 - TECHNICAL CHARACTERISTICS

2.1 - Electrical characteristics

LSA 46.2/47.1 alternators are machines without sliprings or revolving field brushes, wound as « 2/3 pitch»; 6 or 12-wire, with class H insulation and a field excitation system available in either AREP or "PMG" version (see diagrams).



Interference suppression conforms to standard EN 55011, group 1, class B.

2.1.1 - Options

- Stator temperature detection probes
- Space heaters

2.2 - Mechanical characteristics

- Steel frame
- Cast iron end shields
- Ball bearings greased for life
- Mounting arrangement

MD 35 :

single bearing with standard feet and SAE flanges/coupling discs.

B 34 :

two-bearing with SAE flange and standard cylindrical shaft extension.

- Drip-proof machine, self-cooled
- Degree of protection : IP 21

2.2.1 - Options

- IP 23,
- Air inlet filter,
- Greasable ball bearings,
- IP 44,
- Bearing probes,
- PT 100 stators.


LSA 46.2 / 47.1

ALTERNATORS

TECHNICAL CHARACTERISTICS

2.3 - Excitation system

For both the AREP & PMG excitation systems, the alternator voltage regulator is the R 448.



With **AREP** excitation, the electronic AVR is powered by two auxiliary windings which are independent of the voltage detection circuit. The first winding (X1, X2) has a voltage proportional to that of the alternator (Shunt characteristic), the second (Z1, Z2) has a voltage in proportion with the stator current (compound characteristic : Booster effect). The power supply voltage is rectified and filtered before being used by the AVR monitoring transistor. As a result the machine has a short-circuit current capacity of 3 IN for 10 s, and good immunity to distortions generated by the load.

With **PMG** excitation, a permanent magnet generator (PMG) is added to the alternator. This is fitted at the rear of the machine and connected to the AVR. The PMG supplies the AVR with voltage which is independent of the main alternator winding. As a result the machine has a short-circuit current capacity of 3 IN for 10 s, and good immunity to distortions generated by the load.

The AVR monitors and corrects the alternator output voltage by adjusting the excitation current.

2.3.1 - R448 AVR characteristics

- shunt power supply : max 140V - 50/60 Hz
- rated overload current : 10A - 10s
- electronic protection (overload, voltage detection opening short-circuit): excitation overload current for 10 s then return to approximately 1A

The alternator must be stopped (or the power switched off, see section 3.5.3.) in order to reset the protection.

- Fuse :

- F1 on X1,X2.

- voltage detection : 5 VA isolated via transformer

0-110 V terminals = 95 to 140 V

0-220 V terminals = 170 to 260 V

0-380 V terminals = 340 to 520 V

- voltage regulation $\pm 0.5\%$

- normal or rapid response time via strap ST2

- voltage adjustment via potentiometer P2

other voltages via adapter transformer

- current detection : (parallel operation) :

C.T. 2.5 VA cl1, secondary 1A (Option)


- quadrature droop adjustment via potentiometer P1

- underspeed protection (U/f) and LAM : frequency threshold

adjustable via potentiometer P4


- max. excitation current adjustment via P5 : 4 to 10A

- 50/60 Hz selection via strap ST3.



2.3.2 - R 448 power supply connection

AREP excitation




LSA 46.2 / 47.1


ALTERNATORS

TECHNICAL CHARACTERISTICS

PMG excitation



2.3.3 - Frequency compared with voltage (without LAM)



2.3.4 - LAM characteristics



The LAM system is integrated in the regulator, as standard it is active (ST5 with bridge). It can be deactivated by removing the ST5 bridge.

- Role of the "LAM" (Load Adjustment Module) :

On application of a load, the rotation speed of the generator set decreases. When it passes below the preset frequency threshold, the LAM causes the voltage to drop by approximately 15% and consequently the amount of active load applied is reduced by approximately 25%, until the speed reaches its rated value again.

Hence the LAM can be used either to reduce the speed variation (frequency) and its duration for a given applied load, or to increase the applied load possible for one speed variation (turbo-charged engine).

To avoid voltage oscillations, the trip threshold for the LAM function should be set approximately 2 Hz below the lowest frequency in steady state.



Typical effects of the "LAM" with a diesel engine -

— with LAM · · · without LAM (U/F only)

2.3.5 - R 448 AVR options

- Current transformer for parallel operation

of...../1 A -2.5 VA CL 1 (See the diagram included with this manual).

- Remote voltage adjustment potentiometer :

470 Ω , 3 W min. : adjustment range $\pm 5\%$ (range limited by internal voltage potentiometer P2). Remove ST4 to connect the potentiometer. (A 1 k Ω potentiometer can also be used to extend the adjustment range by $\pm 10\%$)

- **R 731 module** : detection of 3-phase voltage 200 to 500V, compatible with parallel operation. Cut ST1 to connect the module; set the voltage via the module potentiometer.

- **R 726 module** : regulation system changed to "4-function" (See the maintenance manual and connection diagram).

- PF regulation (2F)

- equalization of voltages before paralleling (3 F).

- possibility of coupling alternators, already running in parallel, to the mains (4F).

R 726 module connected in place of ST4.

LSA 46.2 / 47.1

ALTERNATORS

INSTALLATION

3 - INSTALLATION


3.1 - Assembly



All mechanical handling operations must be undertaken using approved equipment.
Whilst being handled, the machine should remain horizontal.

3.1.1 - Handling

The generously-sized lifting rings are for handling the alternator alone. They must not be used to lift the genset. Use a lifting system which respects the positioning of the rings.



3.1.2 - Coupling

3.1.2.1 - single bearing alternator

Before coupling the two machines, check that both are compatible by :

- undertaking a torsional analysis of the transmission
- checking the dimensions of the flywheel and its housing, the flange, coupling discs and the offset of the alternator

WARNING

When coupling the alternator to the prime mover, the holes of the coupling discs should be aligned with the flywheel holes by rotating the primary pulley on the thermal engine.

Do not use the alternator fan to turn the rotor.

Tighten the coupling disc screws to the recommended torque (see section 4.6.2.) and check that there is lateral play on the crankshaft.

3.1.2.2 - two-bearing alternator

- Semi-flexible coupling

Careful alignment of the machines is recommended, checking that the concentricity and parallelism of both parts of the coupling does not exceed 0.1 mm.

WARNING

This alternator has been balanced with a 1/2 key.

3.1.3 - Location

Ensure that the ambient temperature in the room where the alternator is placed cannot exceed 40°C for standard power ratings (for temperatures > 40°C, apply a derating coefficient). Fresh air, free from damp and dust, must be able to circulate freely around the air intake grilles on the opposite side from the coupling. It is essential to prevent not only the recycling of hot air from the machine or engine, but also exhaust fumes.

3.2 - Inspection prior to first use

3.2.1 - Electrical checks



Under no circumstances should an alternator, new or otherwise, be operated if the isolation is less than 1 megohm for the stator and 100,000 ohms for the other windings.

There are three possible methods for restoring these minimum values.

- Dry out the machine for 24 hours in a drying oven at a temperature of 110 °C (without the AVR)
- Blow hot air into the air intake, having made sure that the machine is rotating with the exciter field disconnected.
- Run in short-circuit mode (disconnect the AVR) :
 - Short-circuit the three output power terminals using connections capable of supporting the rated current (try not to exceed 6 A/mm²)
 - Insert a clamp ammeter to monitor the current passing through the short-circuit connections.
 - Connect a 24 Volt battery in series with a rheostat of approximately 10 ohms (50 W) to the exciter field terminals, respecting the polarity.
 - Open fully all the alternator openings.
 - run the alternator at its rated speed, and adjust the exciter field current using the rheostat to obtain the rated output current in the short-circuit connections.

Note : Prolonged standstill : In order to avoid these problems, we recommend the use of space heaters, as well as turning over the machine from time to time. Space heaters are only really effective if they are working continuously while the machine is stopped.

3.2.2 - Mechanical checks

Before starting the machine for the first time, check that :

- all fixing bolts and screws are tight
 - cooling air is drawn in freely
 - the protective louvers and housing are correctly positioned
 - the standard direction of rotation is clockwise as seen from the shaft end (phase rotation in order 1 - 2 - 3).
- For anti-clockwise rotation, swap 2 and 3.
- the winding connection corresponds to the site operating voltage (see section 3.3)

LSA 46.2 / 47.1

ALTERNATORS

INSTALLATION

3.3 - Terminal connection diagrams













To modify the connections, change the position of the terminal links or shunts. The winding code is specified on the nameplate.




3.3.1 - Terminal connection : LSA 46.2/47.1 - 12-wire

The connection accessories are detailed in section 5.3.3.

Any intervention on the alternator terminals during reconnection or checks should be performed with the machine stopped.

Connection codes	Voltage L.L			Factory connection	
(A) 3-phase 	Winding	50 Hz	60 Hz	LSA 46.2/47.1 - 12-WIRE	
	6	190 - 208	190 - 240		
	7	220	-		
	8	-	190 - 208		
	 R 448 voltage detection : 0 => (T3) / 220 V => (T2)				
(D) 3-phase 	Winding	50 Hz	60 Hz	LSA 46.2/47.1 - 12-WIRE	
	6	380 - 415	380 - 480		
	7	440	-		
	8	-	380 - 416		
	 R 448 voltage detection : 0 => (T3) / 380 V => (T2)				
	9		600		
	Winding 9 : R 448 voltage detection + transformer (See specific diagram)				
(FF) 1 phase 	Winding	50 Hz	60 Hz	LSA 46.2 - 12-WIRE (*)	
	6	220 - 240	220 - 240		
	7	240 - 254	-		
	8	-	220 - 240		
	 R 448 voltage detection : 0 => (T10) / 220 V => (T1)				
	Voltage LM = 1/2 voltage LL				
(F) 1 phase or 3-phase 	Winding	50 Hz	60 Hz	LSA 46.2/47.1 - 12-WIRE (*)	
	6	220 - 240	220 - 240		
	7	240 - 254	-		
	8	-	220 - 240		
	 R 448 voltage detection : 0 => (T3) / 220 V => (T2)				
	Operating phases L2 (V), L3 (W) single phase				
	Voltage LM = 1/2 voltage LL				


In case of reconnection, ensure that AVR voltage detection is correct !

LSA 46.2 / 47.1

ALTERNATORS

INSTALLATION

3.3.2 - Terminal connection :

LSA 46.2/47.1 - 6-wire

Connection codes		Voltage L.L			Factory connection	
(D) 3-phase 	L1(U)	Winding	50 Hz	60 Hz	LSA 46.2 - 6-WIRE 	
		7S	440	-		
		8S	-	380 - 416		
		R 448 voltage detection : 0 => (T3) / 380 V => (T2)				
		9S		600		
		Winding 9 : R 448 voltage detection + transformer (See specific diagram)				
(F) 1 phase or 3-phase 	L1(U)	Winding	50 Hz	60 Hz	LSA 46.2 - 6-WIRE 	
		7S	240 - 254	-		
		8S	-	220 - 240		
		R 448 voltage detection : 0 => (T3) / 220 V => (T2) Operating phases : L2 (V), L3 (W) single phase			NDE (*)	
Connection codes		Voltage L.L			Factory connection	
(D) 3-phase 	L1(U)	Winding	50 Hz	60 Hz	LSA 47.1 - 6-WIRE 	
		6S	380 - 415	380 - 480		
		7S	440	-		
		8S	-	380 - 416		
		R 448 voltage detection : 0 => (T3) / 380 V => (T2)				
		NDE				
(F) 1 phase or 3-phase 	L1(U)	Winding	50 Hz	60 Hz	LSA 47.1 - 6-WIRE 	
		6S	220 - 240	220 - 277		
		7S	240 - 254	-		
		8S	-	220 - 240		
		R 448 voltage detection : 0 => (T3) / 220 V => (T2) Operating phases : L2 (V), L3 (W) single phase			NDE (*)	
In case of reconnection, ensure that the AVR voltage detection is correct !						


(*) The factory can supply a set of flexible shunts and special connection links as an option for making these connections. The standard alternator is fitted with 3 starting ranges, 6 connection links and one neutral link.

LSA 46.2 / 47.1

ALTERNATORS

INSTALLATION

3.3.3 - Option connection diagram




3.3.4 - Connection checks



Electrical installations must comply with the current legislation in the country of use.

Check that :

- the residual circuit-breaker conforms to legislation on protection of personnel, in force in the country of use, and has been correctly installed on the alternator power output as close as possible to the alternator. (In this case, disconnect the wire of the interference suppression module linking the neutral).
- Any protective devices in place have not been tripped.
- If there is an external AVR , the connections between the alternator and the cubicle are made in accordance with the connection diagram.
- There is no short-circuit between phase or phase-neutral between the alternator output terminals and the generator set control cabinet (part of the circuit not protected by circuit-breakers or cubicle relays).
- The machine should be connected with the busbar separating the terminals as shown in the terminal connection diagram.



3.3.5 - Electrical checks on the AVR

- Check that all connections have been made properly as shown in the attached connection diagram.

- Check that the frequency selection strap "ST3" is on the correct frequency setting.
- Check whether strap ST4 or the remote adjustment potentiometer have been connected.
- Optional operating modes
 - Strap ST1 : cut to connect the R 731 3-phase detection module.
 - Strap ST2 : cut for rapid response time
 - Strap ST5 : cut to suppress the LAM function.

LSA 46.2 / 47.1

ALTERNATORS

INSTALLATION

3.4 - Commissioning



The machine can only be started up and used if the installation has been set up in accordance with the regulations and instructions defined in this manual.

The machine is tested and set at the factory. When first used with no load, make sure that the drive speed is correct and stable (see the nameplate). With the greaseable ball bearings option, we recommend greasing the bearings at the time of commissioning (see 4.2.3).

On application of the load, the machine should achieve its rated speed and voltage; however, in the event of abnormal operation, the machine setting can be altered (follow the adjustment procedure in section 3.5). If the machine still operates incorrectly, the cause of the malfunction must be located (see section 4.4).

3.5 - Settings



The various adjustments during tests must be made by a qualified engineer.

WARNING

Take care that the drive speed specified on the nameplate is reached before commencing adjustment

1500 min⁻¹ / 50Hz or 1800 min⁻¹ / 60 Hz.

Do not try to set the voltage if the frequency or speed is not correct (risk of irreparable rotor damage).



After operational testing, replace all access panels or covers.

The AVR should be used to make any adjustments to the machine.

3.5.1 - R 448 settings



a) Initial potentiometer settings (see table below)
- Remote voltage adjustment potentiometer : centre (strap ST4 removed).

Action	Factory setting	Pot.
Voltage minimum fully anti-clockwise	400V - 50 Hz (Input 0 - 380 V)	
Stability	Not set (centre position)	
Threshold/LAM or U/F Underspeed protection and "LAM" trip threshold Maximum frequency fully anti-clockwise	If ST3 = 50 Hz (factory) = 48 Hz If ST3 = 60 Hz (factory) = 58 Hz	
Voltage quadrature droop (// operation with C.T.) - 0 quadrature droop fully anti-clockwise.	Not set (fully anti- clockwise)	
Excitation ceiling Limit of excitation and short-circuit current, minimum fully anti-clockwise	10 A maximum	

LSA 46.2 / 47.1

ALTERNATORS

INSTALLATION

Adjustments in standalone operation

b) Install a D.C. analogue voltmeter (needle dial) cal. 100V on terminals E+, E- and an A.C. voltmeter cal 300 - 500 or 1000V on the alternator output terminals.

c) Make sure that strap ST3 is positioned on the desired frequency (50 or 60 Hz).

d) Voltage potentiometer P2 at minimum, fully anti-clockwise.

e) Turn the V/Hz potentiometer P4 fully clockwise.

f) Stability potentiometer P3 to approximately 1/3 anti-clockwise turn.

g) Start the engine and set its speed to a frequency of 48 Hz for 50 Hz, or 58 for 60 Hz.

h) Set the output voltage to the desired value using P2.

- Rated voltage UN for solo operation (eg. 400 V)

- Or UN + 2 to 4% for parallel operation with C.T. (eg. 410 V)
If the voltage oscillates, use P3 to make adjustments (try both directions) observing the voltage between E+ and E- (approx. 10V D.C.). The best response times are obtained at the limit of the instability. If no stable position can be obtained, try cutting or replacing strap ST2 (normal/fast).

i) Check LAM operation : ST5 closed.

j) Turn potentiometer P4 slowly anti-clockwise until there is a significant voltage drop (approximately 15%)

k) Vary the frequency (speed) around 48 or 58 Hz according to the operating frequency, and check the change in voltage from that observed previously (approximately 15%).

l) Readjust the speed of the unit to its rated no-load value.

Adjustments in parallel operation

WARNING

Before any intervention on the alternator, make sure that the speed droop is identical for all engines.

m) Preset for parallel operation (with C.T. connected to S1, S2 on connector J2)

- Potentiometer P1 (quadrature droop) in centre position. Apply the rated load ($\cos \varnothing = 0.8$ inductive).

The voltage should drop by 2 to 3%. If it increases, swap the 2 incoming wires from the C.T. secondary.

n) The no-load voltages should be identical for all the alternators intended to run in parallel.

- Couple the machines in parallel.

- By adjusting the speed, try to obtain 0 KW power exchange.

- By altering the voltage setting P2 or Rhe on one of the

machines, try to cancel (or minimise) the current circulating between the machines.


From now on, do not touch the voltage settings.

o) Apply the available load (the setting is only correct if a reactive load is available)

- By altering the speed, equalise the KW (or divide the rated power of the units proportionally)

- By altering the quadrature droop potentiometer P1, equalise or divide the currents.

3.5.2 - Max. excitation setting (excitation ceiling)



Adjustment of the current limit

via potentiometer P5 (fuse rating : 8A-10 seconds).

The maximum factory setting corresponds to that of the excitation current required to obtain a 3-phase short-circuit current of approximately 3 IN at 50 Hz for industrial power, unless otherwise specified(*).

A static method can be used to reduce this value or adapt the Isc to the actual max. operating power (derated machine), which is safer for the alternator and the installation.

Disconnect power supply wires X1,X2 and Z1,Z2 and the voltage reference (0-110V-220V-380V) on the alternator. Connect the mains power supply (200-240V) as indicated (X1,X2). Install a 10A D.C. ammeter in series with the exciter field. Turn P5 fully anti-clockwise and activate the power supply. If there is no output current from the AVR, turn potentiometer P2 (voltage) clockwise until the ammeter indicates a stable current. Switch the power supply off, then on again, turn P5 clockwise until the required max. current is obtained (no more than 10 A).

LSA 46.2 / 47.1

ALTERNATORS

INSTALLATION

Checking the internal protection :

Open switch (D): the excitation current should increase to its preset ceiling, remain at that level for ≥ 10 seconds and then drop to < 1 A.

To reset, switch off the power supply by opening switch (A).


Note : After setting the excitation ceiling as described, adjust the voltage again

(see section 3.5.2.) via P2.

(*) : In some countries it is a legal requirement to have a short-circuit current, so as to offer discriminating protection.

3.5.3 - Special type of use


- Field weakening



The exciter is switched off by disconnecting the AVR power supply (1 wire on each auxiliary winding) – contact rating 16 A - 250V A.C.

Connection is identical for resetting the AVR internal protection

- Field forcing



Applications	B volts	Time t
Guaranteed voltage build-up	12 (1A)	1 - 2 s
Parallel operation, de-energized	12 (1A)	1 - 2 s
Parallel operation, at standstill	24 (2A)	5 - 10 s
Frequency starting	48 (4A)	5 - 10 s
Sustained voltage on overload	48 (4A)	5 - 10 s

LSA 46.2 / 47.1**ALTERNATORS****SERVICING - MAINTENANCE****4 - SERVICING - MAINTENANCE****4.1 - Safety measures**

Servicing or troubleshooting must be carried out strictly in accordance with instructions so as to avoid the risk of accidents and to maintain the machine in its original condition.



All such operations performed on the alternator should be undertaken by personnel trained in the commissioning, servicing and maintenance of electrical and mechanical components.

Before any intervention on the machine, ensure that it cannot be started by a manual or automatic system and that you understand how the operating system works.

4.2 - Regular maintenance**4.2.1 - Checks after start-up**

After approximately 20 hours of operation, check that all fixing screws on the machine are still tight, plus the general condition of the machine and the various electrical connections in the installation.

4.2.2 - Cooling circuit

It is advisable to check that circulation of air is not reduced by partial blocking of the air intake and outlet grilles : mud, fibre, grease, etc.

4.2.3 - Bearings

The bearings are greasable (option). It is advisable to lubricate the machine during operation. Time intervals and quantity of grease are given in the table below.

DE bearing - LSA 46.2	6316 C3
Quantity of grease	33 g
Lubrication interval	4000 H

NDE bearing - LSA 46.2/ 47.1	6315 C3
Quantity of grease	30 g
Lubrication interval	4500 H

DE bearing - LSA 47.1	6318 C3
Quantity of grease	41 g
Lubrication interval	3500 H

Lubrication intervals are given for a grease of grade
LITHIUM - standard - NLGI 3.

The factory lubrication is performed with grease :
SHELL - ALVANIA G3.

Before using another grease, check for compatibility with the original one. Monitor the temperature rise in the bearings, which should not exceed 50°C above the ambient temperature. Should this value be exceeded, the machine must be stopped and checks carried out.

4.2.4 - Electrical servicing

Cleaning product for the windings

WARNING

Do not use : trichlorethylene, perchlorethylene, trichloroethane or any alkaline products.

Certain strictly defined pure volatile degreasing products can be used, such as :

- Normal petrol (without additives)
- Toluene (slightly toxic); inflammable
- Benzene (or benzine, toxic); inflammable
- Cyclohexane (non toxic); inflammable

Cleaning of the stator, rotor, exciter and diode bridge

The insulating components and the impregnation system are not at risk of damage from solvents (see the above list of authorised products).

Avoid letting the cleaning product run into the slots. Apply the product with a brush, sponging frequently to avoid accumulation in the housing. Dry the winding with a dry cloth. Let any traces evaporate before reassembling the machine.

4.2.5 - Mechanical servicing**WARNING**

Cleaning the machine using water or a high-pressure washer is strictly prohibited.

Any problems arising from such treatment are not covered by our warranty.

Degreasing : Use a brush and detergent (suitable for paintwork).

Dusting : Use an air gun.

If filters have been added to the machine after manufacture and do not have thermal protection, the service personnel should clean the air filters periodically and systematically, as often as is necessary (every day in very dusty atmospheres). Cleaning can be performed using water for dry dust or in a bath containing soap or detergent in the case of greasy dust. Petrol or chlorethylene can also be used.

After cleaning the alternator, it is essential to check the winding insulation (see sections 3.2. and 4.8.).

LSA 46.2 / 47.1

ALTERNATORS

SERVICING - MAINTENANCE

4.3 - Fault detection

If, when commissioned, the alternator does not work normally, the source of the malfunction must be identified.

To do this, check that :

- the protective devices are fitted correctly
- the connections comply with diagrams in the manuals supplied with the machine

- the speed of the unit is correct (see section 1.3).

Repeat the operations defined in section 3.

4.4 - Mechanical defects

Fault		Action
Bearing	Excessive overheating of one or both bearings (bearing temperature 50°C above the ambient temperature) (With or without abnormal bearing noise)	<ul style="list-style-type: none"> - If the bearing has turned blue or if the grease has turned black, change the bearing. - Bearing not fully locked (abnormal play in the bearing cage). - End shields incorrectly aligned.
Abnormal temperature	Excessive overheating of alternator frame (more than 40° C above the ambient temperature)	<ul style="list-style-type: none"> - Airflow (inlet-outlet) partially clogged or hot air is being recycled from the alternator or engine - Alternator operating at too high a voltage (> 105% of Un on load) - Alternator overloaded
Vibrations	Too much vibration	<ul style="list-style-type: none"> - Misalignment (coupling) - Defective mounting or play in coupling - Rotor balancing fault (Engine - Alternator)
	Excessive vibration and humming noise coming from the machine	<ul style="list-style-type: none"> - Phase imbalance - Stator short-circuit
Abnormal noise	Alternator damaged by a significant impact, followed by humming and vibration	<ul style="list-style-type: none"> - System short-circuit - Mis-parallelism <p>Possible consequences</p> <ul style="list-style-type: none"> - Broken or damaged coupling - Broken or bent shaft end. - Shifting and short-circuit of main field - Fan fractured or coming loose on shaft - Irreparable damage to rotating diodes or AVR.

LSA 46.2 / 47.1

ALTERNATORS

SERVICING - MAINTENANCE

4.5 - Electrical faults

Fault	Action	Effect	Check/Cause
No voltage at no load on start-up	Connect a new battery of 4 to 12 volts to terminals E- and E+, respecting the polarity, for 2 to 3 seconds	The alternator builds up and its voltage is still correct when the battery is removed.	- Lack of residual magnetism
		The alternator builds up but its voltage does not reach the rated value when the battery is removed.	- Check the connection of the voltage reference to the AVR - Faulty diode - Armature short-circuit
		The alternator builds up but its voltage disappears when the battery is removed	- Faulty AVR - Field windings open circuit (check winding) - Main field winding open circuit (check the resistance)
Voltage too low	Check the drive speed	Correct speed	Check the AVR connections (possible AVR failure) - Field windings short-circuited - Rotating diodes burnt out - Main field winding short-circuited - Check the resistance
		Speed too low	Increase the drive speed. (Do not touch the AVR voltage pot. (P2) before running at the correct speed.)
Voltage too high	Adjust AVR voltage potentiometer	Adjustment ineffective	Faulty AVR
Voltage oscillations	Adjust AVR stability potentiometer	If no effect : try normal / fast recovery modes (ST2)	- Check the speed : possibility of cyclic irregularity - Loose connections - Faulty AVR - Speed too low when on load (or LAM set too high)
Voltage correct at no load and too low when on load	Run at no load and check the voltage between E+ et E- on the AVR	Voltage between E+ and E- (DC) AREP / PMG < 10V	- Check the speed (or LAM set too high)
		Voltage between E+ and E- AREP / PMG > 15V	- Faulty rotating diodes - Short-circuit in the main field. Check the resistance- Faulty exciter armature. Check the resistance.
Voltage disappears during operation	Check the AVR, the surge suppressor, the rotating diodes, and replace any defective components	The voltage does not return to the rated value.	- Exciter winding open circuit - Faulty exciter armature - Faulty AVR - Main field open circuit or short-circuited

4.5.1 - Checking the winding

You can check the winding insulation by performing a high voltage test. In this case, you must disconnect all AVR wires.

WARNING

Damage caused to the AVR in such conditions is not covered by our warranty.


LSA 46.2 / 47.1

ALTERNATORS





SERVICING - MAINTENANCE

4.5.2 - Checking the diode bridge

DIODE BRIDGE



A diode in good working order must allow the current to flow from the anode to the cathode only.



4.5.3 - Checking the windings and rotating diodes using separate excitation




During this procedure, make sure that the alternator is disconnected from any external load and inspect the terminal box to check that the connections are fully tightened.

- 1) Stop the unit, disconnect and isolate the AVR wires.
- 2) There are two ways of creating an assembly with separate excitation.

Assembly A : Connect a 12 V battery in series with a rheostat of approximately 50 ohms - 300 W and a diode on both exciter field wires (5+) and (6-).

ASSEMBLY A



Assembly B : Connect a "Variac" variable power supply and a diode bridge on both exciter field wires (5+) and (6-).


Both these systems should have characteristics which are compatible with the machine field excitation power (see the nameplate).

3) Run the unit at its rated speed.

4) Gradually increase the exciter field current by adjusting the rheostat or the variac and measure the output voltages on L1 - L2 - L3, checking the excitation voltage and current at no load and on load (see the machine nameplate or ask for the factory test report).

When the output voltage is at its rated value and balanced within < 1 % for the rated excitation level, the machine is in good working order. The fault therefore comes from the AVR or its associated wiring (ie. sensing, auxiliary windings).


ASSEMBLY B



LSA 46.2 / 47.1**ALTERNATORS****SERVICING - MAINTENANCE****4.6 - Dismantling, reassembly
(see sections 5.4.1. & 5.4.2.)****WARNING**

During the warranty period, this operation should only be carried out in an approved LEROY-SOMER workshop or in our factory, otherwise the warranty may be invalidated.

Whilst being handled, the machine should remain horizontal (rotor not locked when moved).

**4.6.1 - Tools required**

To fully dismantle the machine, we recommend using the tools listed below :

- 1 ratchet spanner + extension,
- 1 torque wrench,
- 1 set of flat spanners : 8 mm, 10 mm, 18 mm,
- 1 socket set : 8, 10, 13, 16, 18, 21, 24, 30 mm
- 1 socket with male ferrule : 5 mm,
- 1 puller.

4.6.2 - Screw tightening torque

IDENTIFICATION	Screw Ø	Torque N.m
Exciter screw	M 6	10
Star diode bridge	M 6	10
Diode nut	M 6	4
Flange / Frame screw (46.2 S, M)	M 14	80
Flange / Frame screw (46.2 L, VL)	M 14	190
Flange / Frame screw (47.1)	M 16	190
NDE bracket / frame screw	M 12	50
Discs / Sleeve screw	M 16	230
Earth screw	M 10	20
Grille screws	M 6	5
Cover screws	M 6	5
Terminal block nut	M 12	35

4.6.3 - Access to diodes

- Open the air inlet louvre (51)
- Disconnect the diodes.
- Check the diodes using an ohmmeter or a battery lamp (see section 4-5)

If the diodes are faulty


- Remove the surge suppressor (347).
- Remove the 6 "H" mounting nuts for the diode bridges on the support.
- Change the crescents, respecting the polarity.

4.6.4 - Access to connections and the regulation system

Access directly by removing the box lid (48) or the AVR access door (466).

4.6.5 - Replacing the NDE bearing on single bearing machines

- Remove the box lid (48) and the NDE panel (365) and remove the 2 screws from the part (122).
- Disconnect the stator outputs (T1 to T12).
- Disconnect the auxiliary winding wires with AREP (X1,X2,Z1,Z2).
- Disconnect the exciter wires (5+,6-).
- Remove the air inlet louvre (51)
- Remove the 2 bearing thrust screws (78).
- Remove all 4 screws (37).
- Remove the bearing (36).
- Remove the ball bearing (70) using a puller with a central screw (see drawing below).



- Check the condition of the "O" ring seal (349) and, if necessary, change it.
- Fit the new bearing, after heating it by induction to approximately 80°C.

WARNING

When dismantling the machine, always change the bearings.

LSA 46.2 / 47.1

ALTERNATORS

SERVICING - MAINTENANCE

4.6.6 - Replacing the DE bearing on two-bearing machines


- Remove the screws (31) and (62).
- Remove the shield (30).
- Remove the circlips (284).
- Remove the ball bearing (60) using a puller with a central screw.
- Fit the new bearing, after heating it by induction to approximately 80°C.

WARNING

When dismantling the machine, always change the bearings.

4.6.7 - Complete dismantling

- Remove the DE shield (30) as described in section 4.6.6.
- Support the DE rotor (4) with a strap or a support constructed as shown in the drawing below.



- Remove the NDE shield bearing cover.
- Tap the shaft end lightly on the opposite side from the coupling using a small mallet.
- Pull the strap in order to move the rotor and ensure its weight is evenly supported.
- Remove the NDE shield following the instructions in section 4.6.5.

4.6.8 - Reassembling the end shields

- Place the "O" ring seal (349) and the preloading wavy washer (79) in the bearing seat (36).
- Position shields (30) and (36) on the stator (1).
- Tighten screws (31) and (37).
- Reconnect all the exciter wires, auxiliary windings, stator, etc.
- Fit the 2 support screws (122).
- Fit the air inlet louvre (51)
- Replace the cover.


4.6.9 - Reassembling the rotor

On single bearing machines :

- Mount the rotor (4) in the stator (1) (see drawing below)
- Check that the machine is correctly assembled and that all screws are tightened.

On two-bearing machines :


- Mount the rotor (4) in the stator (1).
- Position shield (30) on the stator (1).
- Tighten screws (31).
- Mount the inner bearing retainer (68) using the screws (62).



- Mount the circlips (284)
- Check that the machine is correctly assembled and that all screws are tightened.

4.6.10 - Dismantling and reassembly of the filters

- Remove the grille (417) then take out the filter (418) .
- Change the filter, if necessary, please refer to section 4.2.5 for cleaning the filter. To replace follow instructions in reverse order.



LSA 46.2 / 47.1

ALTERNATORS

SERVICING - MAINTENANCE

WARNING

When removal of the rotor involves changing parts or rewinding, the rotor must be rebalanced.



After operational testing, replace all access panels or covers.

4.7 - Installation and maintenance of the PMG

In LSA 46.2 / 47.1, the PMG reference is : PMG 2.

4.7.1 - Mechanical characteristics

The components are :

- an adaptation shaft (to position the rotor on the alternator shaft).
 - an M16 tie rod and nut for assembling the rotor on the shaft.
 - a rotor with 16 magnets.
 - A housing + wound stator + plastic connection sleeve assembly + plastic ferrules.
 - the housing cover (4 CBLXS M5 screws).
 - 4 HM6 screws (mounting housing on the NDE shield).
- If mounting in kit form, follow the instructions below.

- 1 - Remove the PMG cover [297] and the seal (71) on the alternator NDE shield.
- 2 - Mount the PMG housing assembly [290] on the shield using the 4 HM6 screws.
- 3 - Put adhesive on the tie rod [295] and screw it fully into the tapped hole in the alternator shaft extension.
- 4 - Mount the magnetised rotor on the adaptation shaft, then using 2 M10 threaded rods screwed into the rotor slide the assembly onto the tie rod.
- 5 - Once the rotor is in position, remove the 2 M10 rods.
- 6 - Fit the cable gland washer [296].
- 7 - Tighten the assembly with the M16 nut.
- 8 - Close the PMG with the cover [297].
- 9 - Remove the plastic plug on the NDE panel and fit the plastic sleeve and its ferrule.
- 10 - Connect the PMG to the AVR (section 4.7.2.).

4.7.2 - Electrical connection

- Connect the 3 PMG wires (14/15/16), the 2 exciter wires (5/6) and the 2 previously mentioned voltage detection wires (2/3) in accordance with the connection diagram (see section 2.3.2).

Mounting the PMG on an AREP machine

- Connect the 3 PMG wires (14/15/16), to terminals X1,X2,Z2

on the AVR. The 4 auxiliary winding wires X1.X2.Z1.Z2 should be isolated using the domino fitting supplied with the kit. Both exciter field wires (5/6) and the voltage sensing wires (2/3) remain in place.

Electrical characteristics of the PMG 2


Stator phase/phase resistance 20°C : 2.1 Ω

No-load A.C. voltage between phases at 1500 rpm : 125 V.

ATTENTION

With the PMG, check that strap ST9 has been disconnected.

4.7.3 - Exploded view of the PMG



LSA 46.2 / 47.1

ALTERNATORS

SERVICING - MAINTENANCE

4.8 - Table of characteristics

Table of average values

Alternator - 4 poles - 50 Hz - Standard winding No. 6.
(400V for the excitation values)

The voltage and current values are given for no-load operation and operation at rated load with separate field excitation. All values are given at $\pm 10\%$ and may be changed without prior notification (for exact values, consult the test report).

4.8.1 - Average values for LSA 46.2

Resistances at 20°C (Ω)

LSA 46.2	Stator L/N	Rotor	Field	Armature
M3	0.022	0.23	8.8	0.035
M5	0.0182	0.24	8.8	0.035
L6	0.0148	0.264	8.8	0.035
L9	0.012	0.295	8.8	0.035
VL12	0.0085	0.343	10	0.037

Resistance of AREP auxiliary windings at 20°C (Ω)

LSA 46.2	Auxil wdg : X1, X2	Auxil wdg : Z1, Z2
M3	0.24	0.4
M5	0.215	0.36
L6	0.185	0.36
L9	0.19	0.32
VL12	0.17	0.32

Field excitation current i exc (A)

Symbols : "i exc": excitation current of the exciter field.

LSA 46.2	No load	At rated load
M3	1.1	4
M5	1.1	3.8
L6	1.1	4.1
L9	1.2	4
VL12	1.1	3.5

For 60 Hz machines, the "i exc" values are approximately 5 to 10 % lower.

4.8.2 - Average values for LSA 47.1

Resistances at 20°C (Ω)

LSA 47.1	Stator L/N	Rotor	Field	Armature
M4	0.0108	0.8	10.2	0.13
M6	0.0081	0.9	10.2	0.13
L9	0.006	1.04	10.2	0.13
L10	0.0053	1.1	10.2	0.13
L11	0.0053	1.1	10.2	0.13
VL 12	0.0028	1.13	10.2	0.13

Resistance of AREP auxiliary windings at 20°C (Ω)

LSA 47.1	Auxil wdg : X1, X2	Auxil wdg : Z1, Z2
M4	0.23	0.405
M6	0.21	0.335
L9	0.175	0.34
L10	0.173	0.29
L11	0.173	0.29
VL 12	0.18	0.325

Field excitation current i exc (A)

Symbols : "i exc": excitation current of the exciter field.

LSA 47.1	No load	At rated load
M4	0.9	3.8
M6	0.9	3.5
L9	0.9	3.2
L10	0.9	3.4
L11	0.9	3.7
VL 12	0.9	3.45

For 60 Hz machines, the "i exc" values are approximately 5 to 10 % lower.

4.8.3 - Voltage of auxiliary windings at no load

LSA 46.2	Auxil wdg : X1, X2	Auxil wdg : Z1, Z2
50 Hz	70 V	10 V
60 Hz	85 V	12 V

LSA 47.1	Auxil wdg : X1, X2	Auxil wdg : Z1, Z2
50 Hz	70 V	5 V
60 Hz	85 V	6 V

LSA 46.2 / 47.1 ALTERNATORS

5 - SPARE PARTS

5.1 - First maintenance parts

Emergency repair kits are available as an option.
They contain the following items :

Ref.	Description	Qty	LSA 46.2	Part ref
	Emergency kit	1		
198	AVR	1	R 448	ESC 220 CV019
343	Diode bridge assembly	1	LSA 471. 9. 07 LSA 471.9 / 0.08	ADE 461 EQ 004
347	Surge suppressor	1	LSA 461.9.01	CII 111 PM 005
	AVR fuse	2	250 V - 10 A	PEL 010 FG 008
	Other spare parts			
60	DE bearing	1	6316 2RS/C3	RLT 080 TS030
70	NDE bearing	1	6315 2RS/C3	RLT 075 TS030

Ref.	Description	Qty	LSA 47.1	Part ref
	Emergency kit	1		
198	AVR	1	R 448	ESC 220 CV019
343	Diode bridge assembly	1	LSA 471. 9. 07 LSA 471.90.08	ADE 471 EQ 007
347	Surge suppressor	1	LSA 461.9.01	CII 111 PM 005
	AVR fuse	2	250 V - 10 A	PEL 010 FG 008
	Other spare parts			
60	DE bearing	1	6318 2RS/C3	RLT 090 TS030
70	NDE bearing	1	6315 2RS/C3	RLT 075 TS030

5.2 - Technical support service

Our technical support service will be pleased to provide any additional information you may require.

When ordering spare parts, you should indicate the complete machine type, its serial number and the information given on the nameplate.

Address your enquiry to your usual contact.

Part numbers should be identified from the exploded views and their description from the parts list.

Our extensive network of service centres can dispatch the necessary parts without delay.

To ensure correct operation and the safety of our machines, we recommend the use of original manufacturer spare parts. In the event of failure to comply with this advice, the manufacturer cannot be held responsible for any damage.

5.3 - Accessories

5.3.1 - Space heater for use when stopped

The space heater must start up as soon as the alternator stops. It is installed at the rear of the machine. Its standard power is 250W with 220V or 250W with 110V on request.



Warning : the power supply is present when the machine has stopped.

5.3.2 - Stator thermistor temperature probes (PTC)

These are thermistor triplets with a positive temperature coefficient installed in the stator winding (1 per phase). There can be a maximum of 2 triplets in the windings (at 2 levels : warning and trip) and 1 or 2 thermistors in the shields.

These probes must be linked to appropriate detection relays (supplied optionally)

Cold resistance of thermistor probes:

100 to 250 Ω per probe.

5.3.3 - Connection accessories

- 6-wire machines

Requirements for coupling (F) :

- 3 flexible shunts

- 12-wire machines

Requirements for coupling (A) :

- 6 links

- 1 link for the neutral

Requirements for coupling (F.F) :

- 4 flexible shunts

- 2 flexible shunts

- 1 link for the central point

- 1 additional starting range

- 1 additional terminal

Requirements for coupling (F) :

- 3 flexible shunts

- 1 link for the central point


LSA 46.2 / 47.1

ALTERNATORS

SPARE PARTS

5.4 - Exploded view, parts list

5.4.1 - Single bearing




Ref.	Qty	Description	Ref.	Qty	Description
1	1	Stator assembly	124	1	Terminal block with terminals
4	1	Rotor assembly	177	2	AVR support bracket
15	1	Turbine	198	1	Voltage regulator (AVR)
18	1	Balancing disc	290	1	PMG housing
21	1	Lifting ring	291	1	Adaptation shaft
28	1	Earth terminal	292	1	Magnetic rotor
30	1	DE shield	293	1	Stator
31	6 or 4	Fixing screw	294	2	Fixing screw
33	1	Fan guard	295	1	Tie rod
34	2	Fixing screw	296	1	Cable gland washer + nut
36	1	Exciter end shield	297	1	End plate
37	4	Fixing screw	320	1	Coupling sleeve
41	1	Cover front panel	321	1	Sleeve key
48	1	Cover top panel	322	3	Coupling disc
49	-	Cover screws	323	6	Fixing screw
51	1	Air intake louvre	325	-	Spacer shim
53	1	Plug	343	1	Diode bridge assembly
70	1	NDE bearing	347	1	Protection varistor (+ PCB)
71	1	Outer bearing retainer	349	1	"O" ring
78	1	Inner bearing retainer	364	1	AVR support
79	1	Preloading wavy washer	365	1	Cover rear panel
90	1	Exciter field	367	2	Side panel
91	4	Fixing screw	371	4	Damper
100	1	Exciter armature	416	1	Filter
107	1	Crescent support	417	1	Filter support
120	1	Terminal support	466	2	AVR inspection door
122	1	Console support			

LSA 46.2 / 47.1

ALTERNATORS

SPARE PARTS


5.4.2 - Two-bearing



Ref.	Qty	Description	Ref.	Qty	Description
1	1	Stator assembly	100	1	Exciter armature
4	1	Rotor assembly	107	1	Crescent support
15	1	Turbine	120	1	Terminal support
18	1	Balancing disc	122	1	Console support
21	1	Lifting ring	124	1	Terminal block with terminals
22	1	Shaft extension key	177	2	AVR support bracket
28	1	Earth terminal	198	1	Voltage regulator (AVR)
30	1	DE shield	284	1	Circlips
31	6 or 4	Fixing screw	290	1	PMG housing
33	1	Fan guard	291	1	Adaptation shaft
34	2	Fixing screw	292	1	Magnetic rotor
36	1	Exciter end shield	293	1	Stator
37	4	Fixing screw	294	2	Fixing screw
41	1	Cover front panel	295	1	Tie rod
48	1	Cover top panel	296	1	Cable gland washer + nut
49	-	Cover screws	297	1	End plate
51	1	Air intake louvre	343	1	Direct diode crescent
53	1	Plug	347	1	Protection varistor (+ PCB)
60	1	DE bearing	349	1	"O" ring
62	3 or 4	Fixing screw	364	1	AVR support
68	1	Inner bearing retainer	365	1	Cover rear panel
70	1	NDE bearing	367	2	Side panel
71	1	Outer bearing retainer	371	4	Damper
79	1	Preloading wavy washer	416	1	Filter
90	1	Exciter field	417	1	Filter support
91	4	Fixing screw	466	2	AVR inspection door

LEROY-SOMER	INSTALLATION AND MAINTENANCE	Ref. 2981 GB - 4.33/a - 04.00
LSA 46.2 / 47.1 ALTERNATORS SPARE PARTS		

LEROY-SOMER	INSTALLATION AND MAINTENANCE	Ref. 2981 GB - 4.33/a - 04.00
LSA 46.2 / 47.1 ALTERNATORS SPARE PARTS		



MOTEURS LEROY-SOMER 16015 ANGOULÊME CEDEX - FRANCE