


Users guide and maintenance manual for the generating sets

Model(s) : G44

Control device: M150



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.

Réf. constructeur : 33501170701

Réf. GPAO : 33501170701NE

Revised (10-12)



Users guide and maintenance manual

All generating sets
General considerations
Safety instructions

Réf. constructeur : MUE-IR A

Réf. GPAO : 33522051901

1. Preamble.....	4
1.1. Introduction	4
1.1.1 General recommendations	4
1.1.2. Structure of the reference material	5
1.2. Pictograms and their meanings.....	5
1.3. Safety instructions and regulations	7
1.3.1 General advice.....	7
1.3.2 Risks related to feed gas (concerns gas sets).....	9
1.3.3 Risks related to exhaust gases and fuels.....	9
1.3.4 Risks related to toxic products	10
1.3.5 Risk of fire, burns and explosion	10
1.3.6 Risks related to electrical networks.....	11
1.3.7 Dangers presented by electric currents (first aid).....	12
1.3.8 Risks related to moving the set	12
1.3.9 Recommendation for the operator and environment.....	13
1.4. Identifying sets.....	14
2. Installation.....	16
2.1. Unloading	16
2.1.1 Safety during unloading	16
2.1.2 Example of material	16
2.1.3 Instructions for unloading	16
2.1.3.1 Slings.....	16
2.1.3.2 Fork lift truck	17
3. Installation of mobile site sets.....	18
3.1 Specific arrangements.....	18
4. Road trailer.....	19
4.1 Trailer linkage	19
4.2 Check before towing.....	20
4.3 Driving.....	20
4.4 Unhitching the trailer.....	20
4.5 Implementation for installation	21
5. Battery maintenance.....	22
6. Fuel and consumables.....	23
6.1 Circuit capacities – Mitsubishi engines	23
6.2 Circuit capacities – John Deere engines.....	24
6.3 Circuit capacities – Volvo engines	25

Attached documents

User manual for the control unit

User and maintenance manual for the engine

User and maintenance manual and spare parts catalogue for the alternator

Wiring diagrams (supplied with the electrical generating set)

Genset parts catalog.

1. PREAMBLE

1.1. Introduction

1.1.1 General recommendations

Thank you for choosing an electrical generating set from our company.

This manual has been designed to help you operate and maintain your electrical generating set correctly.

Read the safety instructions carefully in order to prevent any accident, incident or damage. These instructions must always be followed.

In order to obtain optimum efficiency and the longest possible life for the electrical generating sets, maintenance operations must be carried out according to the periods indicated in the attached preventative maintenance tables.

If the electrical generating set is used under dusty or unfavourable conditions, some of these periods will be shorter.

Ensure that all adjustments and repairs are carried out by personnel who have received the appropriate training. The dealers are suitably qualified and can answer all of your questions. They can also supply you with spare parts and other services.

The left and right sides can be seen from the back of the electrical generating set (the radiator is at the front).

Our electrical generating sets have been designed so that damaged or worn parts can be replaced by new or reconditioned parts thereby reducing the out of action period to a minimum.

For all parts replacement, contact your nearest dealer representing our company who will have the necessary equipment and properly trained and informed staff to carry out maintenance, parts replacement and even total reconditioning of generating sets.

Contact your local dealer for the available repair manuals and to make the necessary arrangements for training personnel in implementation and maintenance.

IMPORTANT

Some user manuals and maintenance manuals for the engines fitted to the electrical generator assemblies include information on the control units and detail the engine starting and stopping procedures.

As the electric generator assemblies are fitted with assembly-specific test and control panels, only the information in the documentation regarding the panels fitted to the assemblies should be taken into consideration.

1.1.2. Structure of the reference material

The reference material delivered with the generating sets enables you to get to know the equipment, operate it and maintain it, both on a daily basis and periodically.

The reference material for the engines and alternators fitted to the sets consists of engine user and maintenance manuals (from the manufacturer) and alternator user and maintenance manuals (from the manufacturer).

The reference material contains:

- the user and maintenance manual, containing among other things:
 - o general recommendations and safety regulations to be adhered to
 - o general recommendations for installing generating sets
 - o tables of capacities (lubricants and coolants) and fuel tanks of different engines that may be fitted to the sets according to their configurations
 - o general reference material for maintaining starter batteries
- user and maintenance manual for the engine fitted to the set
- maintenance manual for the alternator fitted to the set
- user manual for the control panel
- wiring diagrams (these diagrams are delivered with the generating set)

1.2. Pictograms and their meanings



Warning danger



Warning, risk of electric shock



Warning, toxic materials



Warning, pressurised liquids



Warning, high temperature, risk of burns



Publications delivered with the generating set must be referred to



Protective clothing must be worn



Your eyes and ears must be protected



Periodic maintenance must be carried out



Battery level must be checked



Warning, rotating or moving parts (risk of getting caught in the machinery)



Warning, corrosive product



Warning, risk of explosion



Entry prohibited to non-authorised persons



Power



Earth



Lifting point required



Stacking point required



Naked flames and unprotected lights prohibited.
No smoking



Exinction by water prohibited



When on a trailer, earth the set before starting it



Emergency cut-out

Application of EU Machine Directive 98/37 of 22 June 1998 in relation to generating sets.

- access restricted to authorised personnel only according to the legislation in force
- live installation: possible automatic start-up.

1.3. Safety instructions and regulations

THESE SAFETY PRECAUTIONS ARE IMPORTANT

If you do not understand or have any questions about any point in this manual, contact your dealer who will explain it to you or give you a demonstration. A list of risks and precautionary measures to take follows. You should also refer to any local and national regulations that apply in accordance with your own jurisdiction.

1.3.1 General advice

- Read and understand the manuals provided with the generating set in full.
 - Do not wear loose clothing and do not go near the machines when operating. Note that the fans are not clearly visible when the engine is running.
 - Warn all people present to keep well back during operation.
-
- The generating set should always be controlled by an experienced person.
 - Always test the generating set from the control panel.
 - Follow the maintenance table and its directions.
 - Never let anyone else use the generating set without having first given them the necessary instructions.
 - Do not run the engine without having refitted the protective covers.
 - Engine with turbocharger: never start the engine without fitting the air filter. The rotating compressor wheel in the turbocharger can cause severe physical injury. Foreign objects in the intake duct can cause mechanical damage.
 - Engine with air preheating (starter components): never use starter aerosol or similar product as starter assistance.
When it comes into contact with the starter component, an explosion may occur in the inlet manifold and lead to physical injury.
 - Never let a child touch the generating set, even when not in use. Avoid using the generating set in the presence of animals (can distress the animal).
 - Never start the engine without an air filter or exhaust.
 - Always follow current local regulations regarding generating sets and use of fuel (petrol and gas) before using your generating set.
 - Never use sea water or any other electrolytic or corrosive product in the coolant circuit.



- Disconnect the battery and pneumatic starter (if there is one) before carrying out any repair, to prevent the engine from starting accidentally. Fit a panel over the controls to prevent any attempt at starting.
- Do not modify the engine.
- Only use the correct techniques for turning the crankshaft to rotate the crankshaft manually. Do not try to rotate the crankshaft by pulling or exerting force on the lever on the fan. This method can cause serious physical or material harm or damage the fan blade (s), leading to premature breakdown of the fan.
- Always use tools in good condition. Check that you have understood how to use them before starting a procedure.
- Only fit original spare parts.
- Use tools that correspond to the work being carried out.
- Clean all traces of oil or coolant with a clean cloth.
- Never use petrol or other flammable substances to clean parts. Use only approved cleaning solvents.
- Do not use a high-pressure cleaner for cleaning the engine and fittings. The radiator, hoses, electrical components etc. could be damaged.
- Avoid accidental contact with parts that reach high temperatures (exhaust manifold, exhaust)
- Engage the parking brake when the generating set on its trailer is installed on the operating site.
- When setting on a slope; check that no-one is behind the trailer.
- Protective eyewear must be worn when handling during maintenance operations. Operators should remove watches, chains, etc.

1.3.2 Risks related to feed gas (concerns gas sets)

WARNING – DANGER

The gas is explosive. It is forbidden to smoke, go near or create sparks when the tank is being filled and near to the generating set.

- Request the user technical notes and LPG or NG safety data sheets from your gas supplier.
-
- Gas installations must be installed, maintained and repaired by recognised specialists.
- Do not attempt to open, unseal or intervene in gas supply pressure relief valves and on the gas line in general.
-
- Gas supply procedures must be carried out in fresh air (outside) in accordance with local regulations, in an area well away from fire, people or animals.

1.3.3 Risks related to exhaust gases and fuels

WARNING - DANGER

generating sets should not be operated in unventilated areas.

- Always follow the local regulations in force regarding generating sets and use of fuel (petrol, diesel and gas) before using your generating set.
- Fuel filling should be carried out when the engine is stopped (except for sets with an automatic filling system)
- Engine exhaust gases are toxic: Do not operate the generating set in non ventilated areas. When installed in a ventilated area, the additional requirements for protection against fire and explosions must be observed.
- If a burnt gas exhaust leaks, the generating set may become more noisy. In order to be sure of its efficiency, you should periodically examine the burnt gas exhaust.
- Pipes must be replaced as soon as their condition requires it.

1.3.4 Risks related to toxic products

WARNING – DANGER

The corrosion inhibitor contains alkali. This substance should not come into contact with the eyes. Avoid any prolonged or repeated contact with skin. It should not be swallowed. In the event of skin contact, wash thoroughly with water and soap. In the event of contact with eyes, rinse immediately with plenty of water for at least 15 minutes. CALL A DOCTOR IMMEDIATELY. KEEP THE PRODUCT OUT OF THE REACH OF CHILDREN.

The anti-rust product is toxic and dangerous if absorbed. Avoid any contact with skin or eyes. Read the instructions on the packaging.

Glycol is a toxic product and dangerous if absorbed. Avoid any contact with skin or eyes. Read the instructions on the packaging.

- Never expose the equipment to liquid splashes or rainfall, and do not place it on wet ground.
- Always use the recommended fuels. Using low quality fuels risks damaging the engine and altering performance
- The battery electrolyte is harmful to skin and especially eyes. If splashes get into eyes, rinse immediately with running water and/or a 10% diluted boric acid solution.
- Wear protective eyewear and strong base resistant gloves for handling the electrolyte .

1.3.5 Risk of fire, burns and explosion

WARNING – DANGER

The engine should not be operated in areas containing explosive products. There is a risk of sparks forming where all electrical and mechanical components are not shielded.

- Beware of creating sparks or flames and do not smoke near batteries as the electrolyte gases are highly flammable (especially when the battery is being filled). Their acid is also harmful to the skin and particularly the eyes.
- Never clean, lubricate or adjust an engine when it is in operation (unless you are qualified to do so, in which case extreme care must be taken to avoid accidents)
- Never make adjustments that you are not familiar with.
- Never cover the generating set with any material while it is working or just after it stops (wait until the engine has cooled)
- Do not touch hot components such as the exhaust pipe and do not put combustible material on them.
- Keep all flammable or explosive products (petrol, oil, cloth, etc.) well away when the set is running.

- Good ventilation is required for your generating set to work properly. Without ventilation, the engine will quickly reach an excessive temperature that could lead to accidents or damage to the equipment and surrounding items.
- Do not take off the radiator cap when the engine is hot and the coolant is pressurised due to risk of burns.
- Depressurise the air, oil and coolant circuits, before removing or disconnecting any unions, ducts or connected components. Be aware of any possible pressure that might be present when disconnecting a device from a pressurised system. Do not look for pressure leaks manually. High pressure oil can cause physical accidents.
- Some preservative oils are flammable. Also, some are dangerous to inhale. Check that ventilation is good. Use a protective mask.
- Hot oil causes burns. Avoid contact with hot oil. Check that the system is no longer pressurised before carrying out any procedures. Never start or run the engine when the oil filling cap is off as oil may be ejected.
- Never start or run the engine when the oil filling cap is off as oil may be ejected.
- Never cover the generating set with a fine layer of oil for anti-rust protection.
- Never fill up the oil or coolant when the generating set is running or when the engine is hot.

1.3.6 Risks related to electrical networks

- The electrical equipment supplied with the generating set complies with standard NF C15.100 or the standards of the relevant countries
 - Read the manufacturer's identification plate carefully. The values for voltage, power, current and frequency are shown. Check that these values match the supply use.
 - Never accidentally touch naked wires or disconnected connections.
 - Never handle a generating set with wet hands or feet.
 - Maintain electrical wires and connections in good condition. Using equipment in poor condition can lead to electrocution and damage to equipment.
-
- Any procedure on the equipment must be carried out voltage free.
 - Electrical connections must be made in accordance with current standards and regulations in the country.
 - Do not use faulty, poorly insulated or provisionally connected wires.
 - Do not invert the positive and negative terminals of batteries when connecting them. Such an inversion can lead to severe damage to the electrical equipment. Follow the wiring diagram supplied by the manufacturer.
 - The generating set should not be connected to any other power sources, such as the public distribution network. In specific cases where there is a reserve connection to existing electrical networks, it must only be carried out by a qualified electrician, who should take the operating differences of the equipment into account, according to whether the public distribution network or generating set is being used.
 - Protection against electric shocks is ensured by an assembly of specific equipment. If this needs to be replaced, it should be by components with identical nominal values and specifications.
 - Due to strict mechanical specifications you should only use flexible resistant rubber sleeved wires, in compliance with CEI 245-4 or equivalent wires.

1.3.7 Dangers presented by electric currents (first aid)

First aid

In the event of an electric shock, cut off the voltage immediately and activate the set's emergency stop. If the voltage has not yet been cut off, move the victim out of contact with the live conductor as quickly as possible. Avoid direct contact both with the live conductor and the victim's body. Use a dry plank of wood, dry clothes or other non-conductive materials to move the victim away. The live wire may be cut with an axe. Take extreme care to avoid the electric arc that results from this.

Begin emergency procedures

Resuscitation

If breathing has stopped, begin artificial respiration at once in the same place the accident took place unless the victim or operator's life could be endangered by this.

In the event of cardiac arrest, carry out cardiac massage.

1.3.8 Risks related to moving the set

- Use lifting units to lift the generating set. Always make sure that the lifting equipment is in good condition and has a sufficient lifting capacity.
- In order to work in complete safety and prevent the components fitted to the top of the engine from being damaged, the engine should be lifted with an adjustable boom. All chains and cables should be parallel to one another and as perpendicular as possible to the top of the set.
- If other equipment fitted to the generating set alters its centre of gravity, special lifting devices may be required to maintain the correct balance for working in total safety.
- Never carry out work on a generating set that is suspended on a lifting device only.

1.3.9 Recommendation for the operator and environment


- Operating personnel should be aware of the safety and operating instructions. These will be regularly updated.
- Operating should be monitored, directly or indirectly, by someone designated by the operator who is familiar with the installation and dangers and problems regarding products stored and used in the installation.
-
- Manufacturers' notes should be available to technical staff, on site if possible.
- Written operating instructions must be available for operations that involve dangerous handling procedures and driving installations. In particular, these instructions prescribe:
 - o Operating modes
 - o Frequency of testing for safety devices and devices for handling pollution and other harmful substances generated by the installation
 - o Methods for maintenance, checking and use of adjustment equipment and safety devices.
- The presence of dangerous or combustible materials on premises where combustion apparatus is sheltered is limited to what is required for the operation.
- The installations must be operated under the constant supervision of a qualified person. This person should periodically check that the safety devices are working properly and ensure the correct fuel supply to the combustion apparatus.
- Apart from combustion apparatus, flames in any form are prohibited. This should be displayed in bold on a sign.
- Residual water, mud and waste spray is prohibited.
- The fuels to be used should correspond to the ones in the declaration file and the specifications prescribed by the combustion apparatus manufacturer.
- The fuel is considered as being in the physical state that is introduced into the combustion chamber.
- Always protect your hands when detecting leaks. Pressurised fluids can enter body tissues and cause severe harm. Risk of blood poisoning.
- Drain and discard engine oil in a designated container (the fuel distributors can collect your used oil).

1.4. Identifying sets

generating sets and their components are identified by means of identification plates.
The precise rules for identifying each major component (engine, alternator etc.) are set out in each manufacturer's documents contained in this manual.

Examples of identification plates

generating set

PLAQUE CONSTRUCTEUR / MANUFACTURER PLATE GROUPE ELECTROGENE / GENERATING SET																							
		<table border="1"><tr><td>Type</td><td>G200</td></tr><tr><td>Execution</td><td>IV</td></tr><tr><td>Version</td><td></td></tr><tr><td>Masse (Kg)</td><td>2980</td></tr><tr><td>Weight</td><td></td></tr></table>				Type	G200	Execution	IV	Version		Masse (Kg)	2980	Weight									
Type	G200																						
Execution	IV																						
Version																							
Masse (Kg)	2980																						
Weight																							
<table border="1"><thead><tr><th>V</th><th>Hz</th><th>rpm</th><th>Cos Phi</th><th>Phase</th></tr></thead><tbody><tr><td>400/230</td><td>50</td><td>1500</td><td>0.8</td><td>3</td></tr></tbody></table>						V	Hz	rpm	Cos Phi	Phase	400/230	50	1500	0.8	3								
V	Hz	rpm	Cos Phi	Phase																			
400/230	50	1500	0.8	3																			
<table border="1"><thead><tr><th></th><th>PRP</th><th>ESP</th></tr></thead><tbody><tr><td>Kva</td><td>180</td><td>198</td></tr><tr><td>Kw</td><td>144</td><td>158.4</td></tr><tr><td>A</td><td>260</td><td>286</td></tr></tbody></table>			PRP	ESP	Kva	180	198	Kw	144	158.4	A	260	286	<table border="1"><thead><tr><th>Ambiance(°C)</th><th>Alt(m)</th></tr></thead><tbody><tr><td>Ambiant</td><td></td></tr><tr><td>25</td><td>1000</td></tr></tbody></table> <p>PRP: Puissance Principale / Prime Power ESP: Service Secours / Standby Duty</p>				Ambiance(°C)	Alt(m)	Ambiant		25	1000
	PRP	ESP																					
Kva	180	198																					
Kw	144	158.4																					
A	260	286																					
Ambiance(°C)	Alt(m)																						
Ambiant																							
25	1000																						
<table border="1"><tr><td>Année / Year</td><td>2002</td></tr></table>		Année / Year	2002	<table border="1"><tr><td>Numéro de Série / Serial Number</td><td>020002009371</td></tr></table>				Numéro de Série / Serial Number	020002009371														
Année / Year	2002																						
Numéro de Série / Serial Number	020002009371																						
INGERSOLL-RAND Co. Ltd. - Hindley Green Wigan UK																							

CEE 84-536 PUISSANCE ACOUSTIQUE / SOUND POWER	
L_{WA}	98.5
Numéro Homologation M216.6068HF160.	

PRESSION ACOUSTIQUE / SOUND PRESSURE					
dB(A)	1 m			7 m	15 m
	50 HZ	80.5	71	67	
	60 HZ	87	77	73	

020002009371	
INGERSOLL-RAND	
020002009371	
INGERSOLL-RAND	


S/N	020002009371
TYPE	G200
Année / Year	2002

Engines

JOHN DEERE	
Engine Serial Number *CD4045T123456*	
CD4045TF150	Abs. Coeff. X.XX
DEERE & COMPANY MOLINE, ILLINOIS MADE IN FRANCE	



VOLVO PENTA	
ENGINE MODEL	XXXXXXXX
SPEC. NO.	XXXXXX
SERIAL NO.	XXXXXXXXXX
RATED NET POWER without fan kW/hp	XXX/XXX
with fan kW/hp	XXX/XXX
SPEED AT RATED POWER rpm	XXXX
PRELIFT mm/INJ. TIMING	X,X+X,X/XX±X,X°
MADE IN SWEDEN 3826077	



Alternator


ALTERNATEURS PARTNER ALTERNATORS

LSA 44.2S7 C 6/4 **Date** 01/14
N° 117204 / 9 60 Hz
Min-1/R.P.M. 1800 **Protection** IP23
Cos Ø / P.F. 0,8 **Cl.ther./Th.class** H
Régulateur/A.V.R. R438 LS/C AREP
Altitude < 1000m **Masse/Weight** 440 Kg
Rlt AV/D.E bearing
Rlt AR/N.D.E bearing 6309 2RS
Graisse/Grease Esso UNIREX N3
Valeurs excit/Excit.values 480 V / 40°C
on charge / full load 17,78 V / 3,84 A
à vide / at no load 0,95 A

PUISSANCE / RATING

Tension Voltage	480	440	415	240	208	240	V
Phase	3	3	3	3	3	1	
Conn.							
Cont.	150	135	130	150	130	78	kVA
Base	120	108	104	120	104	62.4	KW
40°C	180	177	180	361	361	325	A
Secours	155	150	144	165	144	87	kVA
Std by	132	120	115	132	115	69.6	KW
27°C	198	197	200	397	400	363	A


LR 57008


Conforme à C.E.I 34-1(1994). According to I.E.C 34-1(1994).

Made by Leroy Somer - 1 024 93046

2. INSTALLATION

2.1. Unloading

2.1.1 Safety during unloading

In order to unload generating sets from their transport mountings, under optimum conditions of safety and efficiency, you should check that the following points are being followed correctly.

- Suitable lifting vehicles or equipment for the work.
- Slings positioned in the rings provided for this procedure or lifting arms resting fully underneath the frame cross beams.
- Suitable ground to accommodate the load of the set and lifting vehicle, without strain (if not, put down sufficiently strong and stable boards).

Remove the set as close as possible to its place of use or transport, in a clear space with free access.

2.1.2 Example of material

- crane, slings, lifting beam, safety hook, shackles.
- fork lift truck.

2.1.3 Instructions for unloading

2.1.3.1 Slings


- attach the lifting vehicle slings to the rings on the generating set designed for this procedure.
- hang the slings carefully.
- check that the slings are correctly attached and the equipment is solid.
- lift the generating set carefully.
- direct and stabilise the set towards the chosen position.
- carefully set down the equipment while continuing to position it.
- release the slings, then detach and remove the lifting rings.

2.1.3.2 Fork lift truck

- position the arms of the fork lift under the frame, making sure that only the cross beams are resting on the arms.
- lift and handle the equipment carefully.
- set down the generating set in its unloading position.



It is recommended to use a fork lift truck with arms that are longer than the width of the frame



3. INSTALLATION OF MOBILE SITE SETS

3.1 Specific arrangements

An area will be reserved to install the generating set. It should be flat and strong enough so that the generator does not sink into it. It could be made of concrete or even large planks fitted together.

It should be noted that a generating set that does not rest correctly on its base (frame or trailer) will be subject to vibrations that could cause damage to all the equipment.

The location of the set on site should be chosen for ease of fuel supply and distribution of current to the users.

Access to the set's doors should be available at all times for safety and maintenance reasons. Ventilation of the generating set should not be affected if there are different objects close by. It will cause abnormal heating and reduced power.

Burnt gas evacuation will take place in such a way that there is no reaspiration into the air filter or cooling system.

The generating set's neutral speed must be used to protect people.

Earthing is carried out using a metal post buried deeply in the ground.

These sets are to be covered or protected from bad weather by a suitable construction (see previous sections).

Examples of problems that may be encountered :




Incorrect exhaust and ventilation




Ground too uneven or soft.
Set incorrectly positioned



Reduced access



Fuel filling impossible



Opening cover doors impossible

4. ROAD TRAILER

4.1 Trailer linkage

Before attaching the trailer, check the trailer hook on the tow vehicle; it should fit the trailer ring perfectly.

WARNING – DANGER





Trying to tow a trailer with a non-matching device (bar, wires, cords, etc.) could lead to serious accidents.

Also check:

- no incipient fractures or excessive wear on the hitching system.
- locking system is operating properly

To hitch the trailer, proceed as follows:

- lock the wheels to stop the trailer from moving
- lift up the rear trailer supports and lock them
- release the parking brake
- release the locking levers for the draw bar arms and adjust the ring to the same height as the vehicle hook
- hitch the trailer, remove the locks on each side of the wheels then lift up the front wheel fully using its handle
- connect the electrical circuit of the trailer to that of the tow vehicle
- hook the handbrake safety wire onto the hook on the tow vehicle.



4.2 Check before towing

Before towing carry out the following checks:

- wheel torquing
- lock trailer hook
- tyre pressure
- light signals working
- cover doors closed
- parking brake off
- front wheels and rear supports lifted.
- tightening and fixing the draw bar arms locking levers
- brake test for "road" type trailers
- fitting brake safety cable.

4.3 Driving

- "On-site" type trailer

These trailers are not fitted with a main brake and so cannot brake when operating; the tyres are designed for a speed of 17 mph (27 Km/h). Therefore, it is absolutely forbidden to exceed this speed .

- "Road" type trailer

The driving speed should be adapted to road conditions and the trailer handling.

Driving at sustained speed causes tyres to heat up; therefore it is important to stop from time to time to check them. Excessive heating can lead to a blow out and hence a serious accident. When reversing, do not forget to lock the overrun brake.

NOTE

Particular attention must be paid to wheel torquing on new vehicles. Indeed, during the first few miles, heat build-ups on the wheel hubs and brake drums lead to reduced wheel torquing. It is therefore essential to check the torquing every 6 miles (10 kilometres) until no further loosening is noted.

The torque test should nevertheless be carried out before towing.

4.4 Unhitching the trailer

This operation should be carried out on horizontal, flat, stable ground.

- lock the wheels
- lower the front wheel
- disconnect the road signals wire
- refit the hitch using the wheel to release the hook ring from the tow vehicle,
- release the tow vehicle
- engage the handbrake.

4.5 Implementation for installation

Procedures to be carried out:

- check that the ground is strong enough for the assembly not to sink into it
- using the front wheel, position the set as horizontally as possible
- engage the handbrake.
- lower the rear trailer supports and lock them

5. BATTERY MAINTENANCE

WARNING – DANGER

- install the battery so that it has the correct ventilation
- never place the battery close to a flame or fire
- use only insulated tools
- never use sulphuric acid or acid water to top up the electrolyte level.

PROCEDURE FOR TESTING STARTER BATTERIES

TEST TYPE	PROCEDURE	RESULT	ACTION
1 VISUAL INSPECTION STEP 1	TRAY AND TERMINALS	CHECK THAT THE TRAY IS NOT BROKEN, THAT THERE IS NO ELECTROLYTE LEAK AND CHECK THE CONDITION OF THE TERMINALS (DAMAGED, BLACK)	DAMAGE NOTED → REPLACE THE BATTERY NO DAMAGE → CHECK THE ELECTROLYTE LEVEL
	ELECTROLYTE LEVEL	BELOW THE PRESCRIBED LEVEL	ADD WATER UP TO THE PRESCRIBED LEVEL, CHARGE FOR 4-5 HOURS AT 1/10 OF THE NOMINAL CAPACITY THEN CHECK THE ELECTROLYTE DENSITY (step 2)
		PRESCRIBED LEVEL OK	CHECK THE ELECTROLYTE DENSITY (step 2)
2 ELECTROLYTE DENSITY TEST STEP 2		< 1.22 kg/l OR VARIATION ABOVE 50 g/l BETWEEN CELLS	REPLACE THE BATTERY
		RECHARGE THE BATTERY FULLY	
		> 1.22 kg/l	CARRY OUT QUICK ELECTRICAL PERFORMANCE TESTS (step 3)
3 TEST OF QUICK ELECTRICAL PERFORMANCES STEP 3		CHECK THE BATTERY USING A MIDTRONICS, WEGA OR SIMILAR TYPE OF TESTER	
		THE TESTER GIVES A POSITIVE RESULT	FIT TO OPERATE
		THE TESTER GIVES A NEGATIVE RESULT	REPLACE THE BATTERY

6. FUEL AND CONSUMABLES

All specifications (product features) are given in the engine and alternator maintenance manuals attached to this manual.

6.1 Circuit capacities – Mitsubishi engines

Engines CIRCUIT AND TANK CAPACITY	S4L2-SD (series SL)	S4Q2 (series SQ)	S4S (series SS)	
	MODEL	G 16	G 22	G 33
	LUBRICATION (in litres)	5.4	5.5	10
	COOLING (in litres)	4.9	8.1	8.9
	FUEL (in litres)	100	100	100

6.2 Circuit capacities – john Deere engines

Engines CIRCUIT AND TANK CAPACITY	3029TF120	4045TF120	4045HF120	6068TF220	6068HF120 (153kW@1500rpm)	6068HF160 (183kW@1500rpm)
MODEL	G 44	G 66 G 77	G 110	G 130	G 160	G 200
LUBRICATION (in litres)	6	13.5	13.5	21.5	21.5	31.5
COOLING (in litres)	16.1	23.6	20.2	27.3	25.8	25.8
FUEL (in litres)	100	175	200	410	410	410

6.3 Circuit capacities – Volvo engines

ENGINES					
CIRCUIT AND TANK CAPACITY	TWD 740	TAD 740	TAD 1032	TAD 1242	TAD 1631
MODEL	G 220	G 270	G 330	G 440	G 550
LUBRICATION (in litres)	29	29	36	35	64
COOLING (in litres)	41.9	36.9	37.3	44	64
FUEL (in litres)	350	700	700	800	800

Instructions for use

M 50
M150
A50
X200
INS / ATS

Réf. constructeur :

Réf. GPAO : 33502013301

SAFETY SYMBOLS



Caution : danger



Caution, refer to the publications supplied with the Genset



Caution : risk of electric shock




Protective clothing required.



Caution : toxic substances



Eye and hearings protection necessary




Caution : pressuried fluids




Periodic maintenance required



Caution : high temperature (risk of burning)



Check battery charge




Caution : rotating or moving parts (risk of entanglement)



Recommended Lifting point



Caution : risk of corrosion



Fork lift stacking point



Caution : risk of explosion




Naked flame and non protected lightning forbidden, no smoking



Authorised personnel only



Do not use water based fire extinguishers




Power



Trailer : link up the earth before starting the generator



Earth




Emergency stop


MACHINERY DIRECTIVE 98/37/EC INSTRUCTION FOR GENERATING SETS

- Access prohibited to unauthorized personnel
- Live installation, potential automatic starting.


A50




INS/ATS




X200



M50














M150



A – DESCRIPTION

The manual control panels and the automatic control boxes are equipped with various switchgear and standard indicators. The following figures define the functions of the different switchgear.

- 1  M50 - STARTING AND STOPPING KEY:
M150
- 2  - OIL PRESSURE WARNING LIGHT (M50-M150):
- 3  - COOLING SYSTEM WARNING LIGHT (M50-M150):
- 4  - VOLTAGE AND CHARGING ALTERNATOR EXCITATION WARNING LIGHT (M50-M150):
- 5  - «OVERCHARGE» WARNING LIGHT (M150):
- 6  - WARNING LIGHTS TEST (M150-A50-X200):
- 7  - EMERGENCY STOP PUSH BUTTON:
- 8  - HOURMETER (M50-M150):
- 9  - CIRCUIT BREAKER (M50 - M150):
- 10  - RACK LIGHTING (A50-M150):
- 11  - AMMETER (M50-M150):

The key has 4 positions :

⊗ : Position of the key when the generator set is not running. It also allows it to be stopped and the clearing of faults.

⊖ : In this position, the electrical circuit of the generator set is energised (the fuel solenoid valve is energised). The battery charge warning light is on. The battery indicators and voltmeter are energised and indicate the state of the different organs under control.

⊕ : Certain engines are equipped with cold weather starting aids. The key held on this position for 5 to 20 seconds is necessary before starting.

⊙ : In this position, the starter is activated ; it turns the motor at a speed allowing starting.

Normally off during running of the generator set, this warning light comes on in the case of an abnormal drop in oil pressure. It indicates an operating incident like lack of oil, a fault with the lubricating system, etc. This fault stops the generating set instantly.

⚠ (The warning light can come on furtively during starting of the generator set.)

Normally off during running of the generator set, this warning light comes on in case of an abnormal rise in engine temperature. It indicates an operating incident like disturbance of airflow, etc. This fault stops the generator set instantly.

Normally off, this warning light comes on in case of a charging incident with the battery(ies) during running of the generator set. For generator sets equipped with a charging alternator, it highlights a fault in the system. This fault does not stop the generator set. During starting of the generator set, this warning light goes off as soon as the alternator has reached an excitation speed of 400 rpm..

Normally off, this warning light comes on when the circuit breaker has disconnected on an overcharge or a short circuit, so freeing the generator from its charge. When this fault arises, it is necessary to limit the charge on disconnecting some appliances or by eliminating the short circuit then re-closing the circuit breaker.

⚠ Trip time user adjustable.

By activating the push button, the warning lights which are normally off light up and signal that they are functioning (except for the battery charge light). The warning light test is always active on the A50 and is active only on position : « ⊕ » of the X200 operating selection switch. « ⊖ » of the M50 and M150 starting and stopping switch.

To be pressed in the event of an accident or incident, it instantly stops the running of the generator set and should be unlocked when put back into service.

⚠ : Type push/pull or push/turn

It totals the number of generator set running hours as soon as the starting key is in the « ⊖ » position.

It interrupts output to the installations in the case of a short circuit or an overcharge or manual activation. In the «ON» position, the power circuit is closed and the generator can supply the installations.


This lights up (if no fault present) :

-the front of box A50 when the operating selection switch is in the auto position and if the order to start is present.

-The front of console M150, when the key is on « ⊖ ».

It indicates the intensity in amps on a phase.

It indicates the power in Volts supplied by the generator set.



- VOLTMETER (A50-M150):




- OPERATING SELECTION SWITCH (A50):

It allows selection of the operating mode :


-STOP : manual operation from the console M50

-AUTO : automatic operation on external order or lack of mains supply.



- GENERAL FAULT WARNING LIGHT (A50):

Normally off, this light comes on in case of a fault immobilising the generator set.




- FUSE (M150):

It protects the remote control circuit against eventual short circuits.




- FREQUENCY METER (M150):

It indicates the frequency in Hertz of the electrical current supplied by the generator set.




- AMMETER SWITCH (M150):

Its different positions allow reading of the amperage of the current produced by each phase.




- VOLTMETER SWITCH (M150):

Its different positions allow reading of the voltage on the voltmeter between each phase or between phase and neutral.



- DIFFERENTIAL:

It ensures the safety of people (adjustment 30 mA instantaneous). The neutral rating of the installation should be TT Rating (an adjustment becomes necessary if an adjustable differential relay is used on option).




- OPTIONAL WARNING LIGHTS (M150):

These warning lights, normally off, are available for different optional functions.




- FAILED TO START WARNING LIGHT (X200):

Normally off, this light comes on, in the case of an operational fault of the generator set.



- GENERATOR FAULT WARNING LIGHT (X200):

Normally off, this warning light comes on in case of the presence of an operating fault with the generator.




- OPERATING SELECTION SWITCH (X200):

The switch has 3 positions :

⏏ : In this position, the generator set will not start in the event of a mains power cut. The preheating resistance is still energised.


TEST : This operating mode is used for maintenance of the generator set (see manual starting switch).

⏻ : In this operating mode, the generator set is ready to start in the event of a mains power cut and/or an external order. Starting is regulated by a time delay to avoid starting on micro mains power cuts.



B – USE

After having carried out the initial putting into service, and the preventive maintenance operation(s), proceed with starting as follows :



I – M50 AND M150


A) STARTING

- Check that there is no danger of output to installations. I.E. : bare cables in contact, personnel carrying out work on electrical equipment connected to the generator, etc.
- Check that battery voltage is good and that the fuel level is sufficient.
- M50 : Open the circuit breaker in order not to have output to installations.
- M150 : Relieve the equipment without opening the circuit breaker (manual opening of the circuit breaker provokes a fault).
- Turn the switch key clockwise to position « ⏏ ».
- Check that the presence of voltage warning light and excitation of the charging alternator is on.
- Keep turning the key to position « ⏻ » (engine equipped with a starting aid). Remain in this position for 5 to 20 seconds depending on ambient temperature. The lower the temperature, the longer the preheating time (some engines are not equipped with preheating).
- Turn the key to position « ⏻ » and release it as soon as the engine starts ; it automatically returns to the « ⏏ » position.


- Let the generator set run empty for several minutes depending on the ambient temperature.
- M50 : Close the circuit breaker.
- From this moment the generator set is outputting to the installations.

B) NORMAL OPERATION

- During operation of the generator set, carry out a regular inspection to ensure there are no anomalies.
- Do not overload the generator set, its power is indicated on the manufacturer's plate. Any overloading could provoke an incident in the short term.

 Operating empty or on low charge is not advised. In case of doubt, consult our after sales service or our agents.

C) NORMAL STOPPING



- M50 : Open the circuit breaker and let it run empty for 3 minutes.
- M150 : Relieve the installation (manual opening of the circuit breaker provokes immediate stopping of the engine, with indication from the overcharging warning light) and let it run empty for 3 minutes.*
- Stop the generator set by turning the key to the «» position.

D) EMERGENCY STOPPING

- Press the emergency stop push button in the event of an accident or incident. The engine will stop instantly.


 Do not forget to unlock the emergency stop push button when putting back in service.


E) CLEARING FAULTS

- Note the signalled fault and turn the starter switch to «».
- Make repairs and start up in «» mode to check for correct operation.

II – A50 (connected to M50)

A) AUTOMATIC START «AUTO»

- Check that battery charge state is good and that the level of fuel is sufficient.
- Place the starting and stopping switch of the M50 in the «» position.
- Close the M50 circuit breaker.

-  If the circuit breaker closes during operation of the generator set, a general fault will be signalled after 30 seconds (stopping of generator).
- Place the operating selection switch in the «**AUTO**» (A50) position.
- In this position, the generator set is ready to start on shutting down of mains (single phase detection) or on external order. (clock, automaton, etc...).
- Check that the panel light warning light is on with the A50.

B) NORMAL STOPPING «STOP»

This position allows stopping of the generator set and the operation of the INS/ATS system and returning to mains supply.
N.B. : the switch on the mains side will only close if mains power is present again.

C) EMERGENCY STOPPING

- Press the emergency stop push button in the event of an accident or incident. The engine will stop instantly.


 Do not forget to unlock the emergency stop push button when putting back in service.



D) RESTARTING AFTER STOPPING FOR A FAULT

- Note the fault and turn the operating selection switch to «**STOP**».
- Make repairs and start with the starting key of the M50.
- Then replace the operating selection switch to «**AUTO**» (A50).

III – X200 (connected to the M150).

A) AUTOMATIC STARTING «»

- Check that battery charge state is good and that the level of fuel is sufficient.
- Place the starting and stopping switch of the M150 in the «» position.
- Close the M150 circuit breaker.

-  If the circuit breaker closes during operation of the generator set, a general fault will be signalled immediately.
- Place the operation selection switch in the «» position.
- In this position, the generator set is ready to start on shutting down of mains (mains detection) (three phase optional) or on external order. (clock, automaton, etc...).
- On starting check that the presence of mains voltage warning light is on with the M150.

B) OPERATION IN TEST MODE «TEST»

This mode of operation is used for simulating a lack of mains or an external order.

- Place the operating switch in the «**TEST**» position.
- The generator set will start automatically after the preheating plug has had time to operate. (If the preheating plug has been configured on the automatics board).

C) STOP «»



This position allows stopping of the generator set and the operation of the ins/ats system and to return to mains supply.
N.B. : the switch on the «mains» side will only close if mains supply is present again.

D) EMERGENCY STOPPING

- Press the emergency stop push button in the event of an accident or incident. The engine will stop instantly.

 Do not forget to unlock the emergency stop push button when putting back in service.

E) RESTARTING AFTER STOPPING FOR A FAULT

- Note the fault and turn the operating selection switch to «».
- Make repairs and start with the starting key of the M150.
- Then replace the operating selection switch to «».

V – REVERSER OF NORMAL/EMERGENCY SOURCES INS/ATS :

The reverser of normal / emergency sources allows the installation to be supplied by the generator set as soon as mains supply disappears. The synoptic allows the display of the presence of mains and generator voltage as well as mains generator output.

Coupled with the M2/3, it allows also, during a mains breakdown, to select a priority generator (see 5).

1 – Presence of generator voltage warning light (White) :

This warning light, when it is on, signals the operation and the presence of voltage from the generator set, which is ready to supply to the installations.

2 – Presence of mains voltage warning light (White) :

This warning light, when it is on, signals the presence of mains voltage.

3 – Generator output warning light (green) :

This warning light, when it is on, signals the closed position of the emergency contactor, therefore output is possible to the installations.

4 – Mains output warning light (green) :

This warning light, when it is on, signals the closed position of the normal contactor, therefore output is possible from the mains to the installation.


5 – Key switch :

This switch allows the selection of 2 modes :

- In the position «priority generator», to force the operation and the output of the generator set to the installations, and that, despite the return of the presence of mains voltage.

i.e. : This manoeuvre is used in the case of frequent and inopportune mains power cuts.


- In the «O» position the output is cut and the operation of the generating set is stopped as soon as mains voltage is restored.




C) M50 WIRING DIAGRAM

I – POWER

SINGLE PHASE – TNS RATING SINGLE PHASE – TT RATING




THREE PHASE – TNS RATING THREE PHASE – TT RATING




MARK	DESCRIPTION	REFERENCE
209	CIRCUIT BREAKER 2 X 20A	31613020703
	CIRCUIT BREAKER 2 X 25A	31613020704
	CIRCUIT BREAKER 2 X 32A	31613020705
	CIRCUIT BREAKER 2 X 40A	31613020706
	CIRCUIT BREAKER 2 X 50A	31613020707
	CIRCUIT BREAKER 2 X 63A	31613020708
	CIRCUIT BREAKER 2 X 80A	31613020709
	CIRCUIT BREAKER 2 X 100A	31613020710
208	INTER-DIF 2 x 25A - 30mA	31613043001
	INTER-DIF 2 x 25A - 300mA	31613061601
	INTER-DIF 2 x 40A - 30mA	31613043101
	INTER-DIF 2 x 40A - 300mA	31613021701
	INTER-DIF 2 x 63A - 30mA	31613043201
	INTER-DIF 2 x 63A - 300mA	31613061801
	INTER-DIF 2 x 100A - 30mA	31613043302
	INTER-DIF 2 x 100A - 300mA	31613061901

MARK	DESCRIPTION	REFERENCE
209	CIRCUIT BREAKER 4 X 10A	31613020711
	CIRCUIT BREAKER 4 X 16A	31613020712
	CIRCUIT BREAKER 4 X 20A	31613020713
	CIRCUIT BREAKER 4 X 25A	31613020714
	CIRCUIT BREAKER 4 X 32A	31613020715
	CIRCUIT BREAKER 4 X 40A	31613020716
	CIRCUIT BREAKER 4 X 50A	31613020717
	CIRCUIT BREAKER 4 X 63A	31613020718
	CIRCUIT BREAKER 4 X 80A	31613020719
	CIRCUIT BREAKER 4 X 100A	31613020720
208	CIRCUIT BREAKER 4 X 125A	31613020721
	INTER-DIF 4 x 25A - 30mA	31613043401
	INTER-DIF 4 x 25A - 300mA	31613062001
	INTER-DIF 4 x 40A - 30mA	31613043501
	INTER-DIF 4 x 40A - 300mA	31613062101
	INTER-DIF 4 x 63A - 30mA	31613043601
	INTER-DIF 4 x 63A - 300mA	31613062201
	INTER-DIF 4 x 100A - 30mA	
	INTER-DIF 4 x 100A - 300mA	31613043701
	INTER-DIF 4 x 125A - 30mA	
	INTER-DIF 4 x 125A - 300mA	31613050701

II - AUTOMATICS



III – TERMINAL BLOCK A50 CABINET



IV - NOMENCLATURE

MARK	DESCRIPTION	Qty	REFERENCE
RDO	RELAY BOARD 12VCC	1	3163044701
MO	SAFETY CARD 12VCC	1	3163003801
3S7	STARTING SWITCH	1	30702001301NE
3KA8	RELAYS 12VCC / 30A AUTOMOBILE TYPE	1	3163014401
	RELAY SOCKET	1	3163055901
3P15	HOURLMETER 12VCC	1	3163042801
3S6	EMERGENCY STOP BUTTON	1	3163042701
3S19	LIGHTS TEST BUTTON	1	3163042901
3F10	CUT-OUT 5 X 20 – MOUNTED ON PANEL	1	3163004001
	FUSE CARTRIDGE 5X20 - 5A	1	3163004101
C1	MALE CONNECTOR – 15 WAY	1	3163060101
C2	FEMALE CONNECTOR – 9 WAY	1	3163057201
C2	MALE CONNECTOR – 9 WAY	1	3163057301
C3	FEMALE CONNECTOR – 2 WAY	1	163048501
C3	MALE CONNECTOR – 2 WAY	1	3163048601

V - WIRING


CIRCUIT		COLOUR
POWER	NEUTRAL	LIGHT BLUE
	PHASE 1	BROWN
	PHASE 2	BLACK
	PHASE 3	BLACK
ALTERNATING REMOTE CONTROL	NEUTRAL	LIGHT BLUE
	PHASE 1	BROWN
	PHASE 2	BLACK
	PHASE 3	BLACK
INSULATED ALTERNATING REMOTE CONTROL		BLACK
CIRCUITS NOT CUT-OFF BY BREAKING DEVICE		COLOUR IDENTICAL TO DOWNSTREAM CIRCUIT OF THE SWITCH + PREVENTION LABEL
DIRECT REMOTE CONTROL	MINUS	BLUE
	PLUS	RED
EXCITATION OF CHARGING ALTERNATOR		RED
TRANSMITTER SIGNAL		BLUE
INTENSIVE CIRCUIT		ORANGE

D) WIRING DIAGRAM M150-A50-X200-INS/ATS

SCHEMA ELECTRIQUE
ELECTRICAL DRAWING
ESQUEMA ELECTRICO
ESQUEMA ELECTRICO

M150

<=125A
















B	EVOLUTION...02/10G-02/11F-11/02B-26/01C-26/02C-26/02G44C-26/04C-25/05C-26/06C-26/06G44C-26/08C-26/09C-26/09G44C	14/04/03	BG	14/04/03	BG
A	FIRST ISSUE	19-09-02	BERGOT Gilles	19-11-02	BERGOT Gilles
IND.	DESIGNATION DE LA MODIFICATION	DATE	VISA	DATE	VISA
		DESSINE		VERIFIE	
MATIERE :				FORMAT : 4	
REVETEMENT :				ECHELLE : 1	
TOLERANCE : JS13/Js13 sauf Indication Particulière				FOLIO :	
DESIGNATION : ELECTRICAL DRAWING PEDESTRAL M150 <= 125A INGERSOLL-RAND				MASSE (Vide/Plein) kg	
33513001701					
12 bis, rue de la Villeneuve 29272 BREST - Tel : 02.98.41.41.41 - Telex : 940757F - Telecopie : 02.98.41.63.07 CE PLAN EST LA PROPRIETE DE LA SOCIETE ; IL NE PEUT ETRE REPRODUIT , UTILISE OU COMMUNIQUE SANS SON AUTORISATION					


E


11


EE


00 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
A	SHEET		REVIEW	DESIGNATION															M150			SHEET	REVIEW	DESIGNATION															A																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				
	00-GARDE	B		FRONT-PAGE																				JD-3029	B	ENGINE. WIRING. JOHN-DEERE.3029															✕																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																		
B	01/01	B	NEUTRAL SYSTEM. TRI/TETRA. <=125A															✕																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																									</


	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19						
A																					A					
B																					B					
C	<p>4P - TT + INTER DIFFERENTIEL 4P - TT + INTER DIFFERENCIAL 4P - TT + INTER DIFERENCIAL 4P - TT + INTER DIFERENCIAL</p>				<p>4P - TT + VIGI</p>				<p>4P - TT - RELAIS DIFFERENTIEL 4P - TT - DIFFERENCIAL RELAY 4P - TT - RELE DIFERENCIAL 4P - TT - RELE DE NEUTRO</p>				<p>3P - TNC - RESTRICTED</p>				<p>3P -TNC UNRESTRICTED</p>				C					
D																					D					
E	<p>Terre NFC 15-100</p> <p>UTILISATION</p> <p>4P -TTEDF - LOCATION</p>				<p>EDF</p> <p>Terre-EDF</p> <p>UTILISATION</p>				<p>3P - TNS - TRI SANS NEUTRE 3P - TNS - WHITHOUT NEUTRAL 3P - TNS - TRIFASICO SIN NEUTRO 3P - TNS - TRIFASE SEM NEUTRO</p>				<p>3P TRI SANS NEUTRE TT -RELAIS DIFFERENTIEL 3P WITHOUT NEUTRAL TT - DIFFERENCIAL RELAY 3P - TT - RELE DIFERENCIAL 3P - TT - RELE DIFERENCIAL</p>				<p>3P - ITSN</p>				E					
<table><tr><td>DESIGNATION : NEUTRAL.SYSTEM..3P/4P REGIME.DE.NEUTRE..3P/4P</td><td>REGIME.DE.NEUTRO..3P/4P REGIME.DE.NEUTRO..3P/4P</td><td><= 125A</td><td>DATE. 18/09/02</td><td>IND. B</td><td>SHEET 01/01</td></tr></table>																					DESIGNATION : NEUTRAL.SYSTEM..3P/4P REGIME.DE.NEUTRE..3P/4P	REGIME.DE.NEUTRO..3P/4P REGIME.DE.NEUTRO..3P/4P	<= 125A	DATE. 18/09/02	IND. B	SHEET 01/01
DESIGNATION : NEUTRAL.SYSTEM..3P/4P REGIME.DE.NEUTRE..3P/4P	REGIME.DE.NEUTRO..3P/4P REGIME.DE.NEUTRO..3P/4P	<= 125A	DATE. 18/09/02	IND. B	SHEET 01/01																					














A

B

C

D

E

1A

E

C


E

NOMENCLATURE
LEGEND
NOMENCLATURA
NOMENCLATURA

REPERE	REFERENCE
ITEM	REFERENCE
SENAL	REFERENCIA
SINAL	REFERENCIA


F01	FAISCEAU-TELYS-001
F06	FAISCEAU-TELYS-006
F138	FAISCEAU-TELYS-138
F139	FAISCEAU-TELYS-139
F140-M150	FAISCEAU-M150-140
2Q18	NE-MCPS-EL...
02T16.17.18	NE-MCPS-EL...
02E08	DOLD IK9270.11/010
02KM08	(LC1K09004P7-230Vac) + TEL LA4KA1U
F28-M150	FAISCEAU-M150-028

Bl : Bleu/Blue/Azul
Br : Brun/Brown/Marron/Castanho
Nr : Noir/Black/Negro/Petro
V/J : Vert-Jaune/green-yellow/verde-amarillo/verde-amarelo





E


E





REPERE	REFERENCE
ITEM	REFERENCE
SENAL	REFERENCIA
SINAL	REFERENCIA
F01	FAISCEAU-TELYS-001
F06	FAISCEAU-TELYS-006
F138	FAISCEAU-TELYS-138
F139	FAISCEAU-TELYS-139
F140-M150	FAISCEAU-M150-140
2Q18	NE-MCPS-EL...
02T16.17.18	NE-MCPS-EL...
02E08	DOLD IK9270.11/010
02KM08	(LC1K09004P7-230Vac) + TEL L4KA1U
F28-M150	FAISCEAU-M150-028























ARRIVEE ALTERNATEUR
FROM GENERATOR
ENTRADA ALTERNADOR
ENTRADA ALTERNADOR


N1 R1 S1 T1

02Q18

16mm²

Protection
différentielle
fixe ou réglable
Earth leakage


N2 R2 S2 T2




DESIGNATION : G66-->G160
EUROPEAN CONFIGURATION EXEPT FRANCE SOCKETS CONFIGURATION

TYPE 2

DATE. 14/04/03	IND. C	SHEET 26/02
-------------------	-----------	----------------






DESIGNATION : G16--->G160
PLASTRON DE PRISES POUR GROUPES FRANCE


TYPE 4


DATE.
14/04/03


IND.
C





SHEET
26/04

















D	AJOUT DIODE ROUE LIBRE SUR KM1	28/03/02	CALVEZ G.		
C	AJOUT CONTACT SUR Q1-MODIFICATION NUMEROTATION BORNIER	05/03/02	CALVEZ G.		
B	MISE EN CONFORMITE NUMEROS	22/05/01	BERGOT Gilles		
A	CREATION DOCUMENT	30/11/98	BERGOT.G		
IND.	DESIGNATION DE LA MODIFICATION	DATE	VISA	DATE	VISA
		DESSINE		VERIFIE	
MATIERE :				FORMAT :	
REVETEMENT :				ECHELLE :	
TOLERANCE :				FOLIO : 1/2	
DESIGNATION : NOTICE RACCORDEMENT - FOLIO1 COFFRET POMPE FUEL SIMPLE- 1 ou 4m3/h				MASSE (Vide/Plein) k	
		3-35-03-0037-01-D			
12 bis, rue de la Villeneuve 29272 BREST - Tel : 02.98.41.41.41 - Telex : 940757F - Telecopie : 02.98.41.63.0 CE PLAN EST LA PROPRIETE DE LA SOCIETE ; IL NE PEUT ETRE REPRODUIT , UTILISE OU COMMUNIQUE SANS SON AUTORISATION					



MODIFICATION		CONTROL PANEL NUMBER	
	A	JD 3029	
SHEET		ENGINE WIRING JOHN DEERE 3029 BASE	
JD 3029		CABLAGE MOTEUR JOHN DEERE 3029 BASE	





Use and maintenance manual

John - Deere POWERTECH 2.9L 3029 OEM Diesel Engines

Réf. constructeur : OMRG27897

Réf. GPAO : 33522042901

Introduction

FOREWORD

THIS MANUAL CONTAINS INFORMATION to operate and service the following engines:

Saran-built (France) Emission Non-Certified Engines:

- CD3029DF120
- CD3029DF121
- CD3029DF122
- CD3029DF123
- CD3029DF124
- CD3029DF160
- CD3029DF161
- CD3029DF162
- CD3029DF163
- CD3029DF164
- CD3029DF165
- CD3029TF120
- CD3029TF121
- CD3029TF123
- CD3029TF160
- CD3029TF161
- CD3029TF162
- CD3029TF163

Saran-built (France) Emission Certified Engines:

- CD3029DF150
- CD3029DF151
- CD3029DF152
- CD3029DF180
- CD3029TF150
- CD3029TF152
- CD3029TF180

Torreon-built (Mexico) Emission Non-Certified Engines:

- PE3029DF120
- PE3029TF120

Torreon-built (Mexico) Emission Certified Engines:

- PE3029DF150
- PE3029TF150

IMPORTANT: This manual replaces two Operation and Maintenance Manuals, OMRG27897 (30JAN98) and OMRG24311 (30AUG96) (Cancelled).

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS IN THIS MANUAL are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

WRITE ENGINE SERIAL NUMBERS and option codes in the spaces indicated in the Record Keeping Section. Accurately record all the numbers. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the engine.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

CERTAIN ENGINE ACCESSORIES such as radiator, air cleaner, and instruments are optional equipment on John Deere OEM Engines. These accessories may be provided by the equipment manufacturer instead of John Deere. This operator's manual applies only to the engine and those options available through the John Deere distribution network.

CALIFORNIA PROPOSITION 65 WARNING
Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

ENGINE OWNER

John Deere Engine Owner:

Don't wait until you need warranty or other service to meet your local John Deere Engine Distributor or Service Dealer.

Learn who he is and where he is. At your first convenience, go meet him. He'll want to get to know you and to learn what your needs might be.

Aux Utilisateurs De Moteurs John Deere:

N'attendez pas d'être obligé d'avoir recours à votre concessionnaire John Deere ou point de service le plus proche pour vous adresser à lui.

Renseignez-vous dès que possible pour l'identifier et le localiser. À la première occasion, prenez contact avec lui et faites-vous connaître. Il sera lui aussi heureux de faire votre connaissance et de vous proposer ses services le moment venu.

An Den Besitzer Des John Deere Motors:

Warten Sie nicht auf einen evt. Reparaturfall um den nächstgelegenen John Deere Händler kennen zu lernen.

Machen Sie sich bei ihm bekannt und nutzen Sie sein "Service Angebot".

Proprietario Del Motore John Deere:

Non aspetti fino a quando ha bisogno della garanzia o di un altro tipo di assistenza per incontrarsi con il Suo Concessionario che fornisce l'assistenza tecnica.

Impari a conoscere chi è e dove si trova. Alla Sua prima occasione cerchi d'incontrarlo. Egli desidera farsi conoscere e conoscere le Sue necessità.

Propietario De Equipo John Deere:

No espere hasta necesitar servicio de garantía o de otro tipo para conocer a su Distribuidor de Motores John Deere o al Concesionario de Servicio.

Entérese de quién es, y dónde está situado. Cuando tenga un momento, vaya a visitarlo. A él le gustará conocerlo, y saber cuáles podrían ser sus necesidades.

John Deere MotorÄgare:

Vänta inte med att besöka Din John Deere återförsäljare till dess att Du behöver service eller garanti reparation.

Bekanta Dig med var han är och vem han är. Tag första tillfälle att besöka honom. Han vill också träffa Dig för att få veta vad Du behöver och hur han kan hjälpa Dig.

IDENTIFICATION VIEWS



3029D Right Front View

RG9173 -UN-29NOV00



3029D Left Front View

RG9172 -UN-29NOV00

RG, RG34710, 4501 -19-30JAN98-1/2



3029T Right Front View

RG9175 -UN-29NOV00



3029T Left Front View

RG9174 -UN-29NOV00

RG, RG34710, 4501 -19-30JAN98-2/2

Contents

	Page		Page
Record Keeping		Idling Engine	15-17
Engine Serial Number Plate	01-1	Stopping the Engine	15-18
Record Engine Serial Number	01-1	Using a Booster Battery or Charger	15-20
Engine Option Codes	01-2		
Record Fuel Injection Pump Model Number	01-4	Lubrication and Maintenance	
		Observe Service Intervals.	20-1
Safety	05-1	Use Correct Fuels, Lubricants, and Coolant . . .	20-2
		Lubrication and Maintenance Service	
Fuels, Lubricants, and Coolant		Interval - Prime Power Engines.	20-3
Diesel Fuel	10-1	Lubrication and Maintenance Service	
Lubricity of Diesel Fuel	10-1	Interval - Standby Power.	20-5
Diesel Fuel Storage	10-2		
DIESELSCAN Fuel Analysis.	10-2	Lubrication & Maintenance/Daily	
Minimizing the Effect of Cold Weather on		Daily Prestarting Checks	25-1
Diesel Engines	10-3		
Diesel Engine Break-In Oil	10-4	Lubrication and Maintenance/250 Hour	
Diesel Engine Oil	10-5	Servicing Fire Extinguisher	30-1
Extended Diesel Engine Oil Service Interval. . .	10-6	Lubricating PTO Clutch Shaft Bearings	30-1
Mixing of Lubricants	10-6	Servicing Battery	30-2
OILSCAN and COOLSCAN	10-7	Handling Batteries Safely	30-3
Alternative and Synthetic Lubricants.	10-7	Changing Engine Oil and Replacing Oil Filter. . .	30-4
Lubricant Storage	10-8	Checking Fan and Alternator V-Belt Tension . .	30-7
Grease	10-8	Checking PTO Clutch Adjustment.	30-9
Diesel Engine Coolant	10-9	Checking Engine Mounts (Generator Sets). . .	30-10
Diesel Engine Coolants, Supplemental			
Additive Information	10-10	Lubrication & Maintenance/500 Hour	
Testing Diesel Engine Coolant	10-11	Adjusting Engine Valve Clearance (New or	
Replenishing Supplemental Coolant		Rebuilt Engines)	35-1
Additives Between Coolant Changes	10-12		
Operating in Warm Temperature Climates . . .	10-13	Lubrication & Maintenance/500Hour/12 Month	
Disposing of Coolant	10-13	Lubricating PTO Clutch Internal Levers and	
		Linkage.	40-1
Engine Operating Guidelines		Cleaning Crankcase Vent Tube	40-1
Instrument (Gauge) Panels.	15-1	Checking Air Intake System	40-2
Normal Engine Operation	15-7	Replacing Fuel Filter Element.	40-3
Break-In Service.	15-8	Checking Cooling System.	40-5
Auxiliary Gear Drive Limitations	15-12	Testing Diesel Engine Coolant	40-6
Generator Sets (Standby) Applications.	15-12	Replenishing Supplemental Coolant	
Starting the Engine.	15-12	Additives (SCAs) Between Coolant	
Cold Weather Operation.	15-15	Changes	40-7
Warming Engine.	15-16	Pressurue Testing Cooling System.	40-9
Changing Engine Speed-Standard			
(Mechanical) Governor	15-17		

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2001
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 1998

Lubrication&Maintenance/1500 Hour/24 Month

Checking and Adjusting Engine Valve Clearance	45-1
Adjusting Variable Speed on Generator Set Engines.	45-4
Flushing and Refilling Cooling System	45-5
Testing Thermostat Opening Temperature	45-8

Service As Required

Additional Service Information	50-1
Do Not Modify Fuel System	50-1
Adding Coolant.	50-2
Bleeding the Fuel System.	50-3
Replacing Air Cleaner Filter Elements	50-5
Inspecting Primary Filter Element.	50-7
Cleaning Primary Filter Element.	50-7
Element Storage.	50-8
Replace Fan and Alternator Belts.	50-8
Power Take-Off (PTO) Clutch.	50-9
Checking Fuses	50-9

Troubleshooting

General Troubleshooting Information	55-1
North American Wiring Diagram	55-2
Engine Troubleshooting	55-4
Electrical Troubleshooting.	55-12
Lubrication Troubleshooting	55-14
Cooling System Troubleshooting	55-16
Air Intake Troubleshooting	55-18

Storage

Engine Storage Guidelines.	60-1
Use AR41785 Engine Storage Kit.	60-1
Preparing Engine for Long Term Storage	60-2
Removing Engine from Long Term Storage	60-3

Specifications

General OEM Engine Specifications.	65-1
Fuel Injection Pump Specifications-Emission Certified Engines.	65-2
Fuel Injection Pump Specifications-Emission Non-Certified Engines.	65-3
Engine Crankcase Oil Fill Quantities	65-5
Unified Inch Bolt and Cap Screw Torque Values.	65-8
Metric Bolt and Cap Screw Torque Values.	65-9

Lubrication and Maintenance Records

Using Lubrication and Maintenance Records . . .	70-1
Daily (Prestarting) Service	70-1
Service, 50 Hour/Every 2 Weeks	70-2
Service, 500 Hours.	70-3

Service, 500 Hour/12 Month.	70-3
Service, 1500 Hour/24 Month.	70-4
Service as Required.	70-5

Emission System Warranty

Emissions Control System Certification Label. . .	75-1
U.S. Emissions Control Warranty Statement. . .	75-2

Record Keeping


ENGINE SERIAL NUMBER PLATE

Each engine has a 13-digit John Deere engine serial number. The first two digits identify the factory that produced the engine:

- “CD” indicates the engine was built in Saran, France
- “PE” indicates the engine was built in Torreon, Mexico

Your engine’s serial number plate (A) is located on the right-hand side of cylinder block near the starter motor.

A—Serial Number Plate



Engine Serial Number Plate Location

RG, RG34710, 5002 -19-30JAN98-1/1

RECORD ENGINE SERIAL NUMBER

Record all of the numbers and letters found on your engine serial number plate in the spaces provided below.

This information is very important for repair parts or warranty information.


Engine Serial Number (A)

Engine Application Data (B)

Coefficient of Absorption Value (For Smoke Emissions) (C)
(Saran-Built Engines Only)

NOTE: Emission-certified engines have application data (B) ending in “150s” or “180s”, while emission non-certified engines have application data (B) ending in “120s” or “160s”.

A—Serial Number
B—Application Data
C—Coefficient of Absorption Value




Saran Serial Number Plate



Torreon Serial Number Plate

RG, RG34710, 5003 -19-30JAN98-1/1

ENGINE OPTION CODES



Option Code Label

A—Base Code

OEM engines have an engine option code label affixed to the rocker arm cover. These codes indicate which of the engine options were installed on your engine at the factory. When in need of parts or service, furnish your authorized servicing dealer or engine distributor with these numbers.

The engine option code label includes an engine base code (A). This base code must also be recorded along with the option codes. At times it will be necessary to furnish this base code to differentiate two identical option codes for the same engine model.

The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as a 12-volt, 55-amp alternator.

If an engine is ordered without a particular component, the last two digits of that functional group option code will be 99, 00, or XX. The following list shows only the first two digits of the code numbers. For future reference such as ordering repair parts, it is important to have these code numbers available. To ensure this availability, enter the third and fourth digits shown on your engine option code label in the spaces provided on the following page.

An additional option code label may also be delivered (in a plastic bag attached to the engine or inserted in the machine documentation). It is recommended to place this label either on this page of the operators manual or in the Engine Owner's Warranty booklet under Option Codes.

The machine manufacturer may have placed the label in a specific accessible area (inside the enclosure or close to a maintenance area).

Your engine option code label may not contain all option codes if an option has been added after the engine left the producing factory.

If option code label is lost or destroyed, consult your servicing dealer or engine distributor selling the engine for a replacement.

Record your engine Base Code (A) in the spaces provided on next page for easy reference.

Engine Serial Number: _____ Engine Base Code: _____

Option Codes	Description	Option Codes	Description
11_____	Rocker Arm Cover	37_____	Fuel Transfer Pump
12_____	Oil Filter Inlet	40_____	Oil Dipstick
13_____	Crankshaft Pulley	41_____	Front Auxiliary Drive
14_____	Flywheel Housing	43_____	Starting Aid
15_____	Flywheel	44_____	Timing Gear Cover With Gears
16_____	Fuel Injection Pump	46_____	Cylinder Block and Liners
17_____	Air Inlet	47_____	Crankshaft and Bearings
18_____	Air Cleaner	48_____	Connecting Rods and Pistons
19_____	Oil Pan	49_____	Valve Actuating Mechanisms
20_____	Coolant Pump	50_____	Oil Pump
21_____	Thermostat Cover	51_____	Cylinder Head With Valves
22_____	Thermostat	52_____	Auxiliary Drive Adapters
23_____	Fan Drive	55_____	Shipping Stand
24_____	Fan Belt	56_____	Paint Option
25_____	Fan	59_____	Oil Cooler and Filter
26_____	Engine Coolant Heater	62_____	Alternator Mounting
27_____	Radiator	64_____	Exhaust Elbow
28_____	Exhaust Manifold	65_____	Turbocharger
29_____	Ventilator System	66_____	Temperature Sensor/Switch
30_____	Starter Motor	69_____	Engine Serial Number Plate
31_____	Alternator	75_____	Air Restriction Indicator
32_____	Instrument Panel	76_____	Oil Pressure Sensor/Switch
35_____	Fuel Filter	95_____	Special Equipment (Factory Installed)
36_____	Front Plate	97_____	Special Equipment (Field Installed Kits)
		98_____	Shipping

NOTE: These option codes are based on the latest information available at the time of publication.

The right is reserved to make changes at any time without notice.

**RECORD FUEL INJECTION PUMP MODEL
NUMBER**


Record the fuel injection pump model and serial
information found on the serial number plate (A).

Model No. _____ RPM _____

Manufacturer's No. _____

Serial No. _____

A—Serial Number Plate



Injection Pump Serial Number Plate

RG, RG34710, 5005 -19-30JAN98-1/1

Safety

RECOGNIZE SAFETY INFORMATION

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-29SEP98-1/1

TS1389 -UN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93-1/1

TS187 -19-30SEP88

FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-03MAR93-1/1

TS201 -UN-23AUG88

REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



DX,SIGNS1 -19-04JUN90-1/1

TS201 -UN-23AUG88

PREVENT BYPASS STARTING

Avoid possible injury or death from engine runaway.

Do not start engine by shorting across starter terminal. Engine will start with PTO engaged if normal circuitry is bypassed.

Start engine only from operator's station with PTO disengaged or in neutral.



Prevent Bypass Starting

OUOD013,0000001 -19-28NOV00-1/1

RG5419 -UN-28FEB89

HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



DX,FIRE1 -19-03MAR93-1/1


TS202 -UN-23AUG88

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1

HANDLE STARTING FLUID SAFELY

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.



TS1356 -UN-18MAR92

DX,FIRE3 -19-16APR92-1/1

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.




TS227 -UN-23AUG88

DX,FLAME -19-29SEP98-1/1

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



TS228 -UN-23AUG88

DX,LOOSE -19-04JUN90-1/1


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1

PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



TS207 -UN-23AUG88

DX,NOISE -19-03MAR93-1/1

HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1

STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



TS1644 -UN-22AUG95

DX,PTO -19-12SEP95-1/1

PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.



TS218 -UN-23AUG88

DX,SERV -19-17FEB99-1/1

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area



TS220 -UN-23AUG88

DX,AIR -19-17FEB99-1/1


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



X9811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.




TS953 -UN-15MAY90

DX,TORCH -19-03MAR93-1/1

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



TS226 -UN-23AUG88

DX,LIFT -19-04JUN90-1/1

REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.


Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 76 mm (3 in.) from area to be affected by heating.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do all work in an area that is ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.




TS220 -UN-23AUG88

DX,PAINT -19-22OCT99-1/1

SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS281 -UN-23AUG88

DX,RCAP -19-04JUN90-1/1


AVOID HARMFUL ASBESTOS DUST

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



TS220 -JN-23AUG88

DX,DUST -19-15MAR91-1/1

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -JN-23AUG88

DX,SPARKS -19-03MAR93-1/1

PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.




TS203 -UN-23AUG88

DX,POISON -19-21APR93-1/1

PROTECT AGAINST HIGH PRESSURE SPRAY

Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



TS1343 -UN-18MAR92

DX,SPRAY -19-16APR92-1/1

USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



TS779 -JN-08NOV89

DX,REPAIR -19-17FEB99-1/1

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -JN-26NOV90

DX,DRAIN -19-03MAR93-1/1

Fuels, Lubricants, and Coolant

DIESEL FUEL

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended.

In all cases, the fuel shall meet the following properties:

Cetane number of 40 minimum. Cetane number greater than 50 is preferred, especially for temperatures below -20°C (-4°F) or elevations above 1500 m (5000 ft).

Cold Filter Plugging Point (CFPP) below the expected low temperature OR **Cloud Point** at least 5°C (9°F) below the expected low temperature.

Fuel lubricity should pass a minimum of 3100 gram load level as measured by the BOCLE scuffing test.

Sulfur content:

- Sulfur content should not exceed 0.5%. Sulfur content less than 0.05% is preferred.
- If diesel fuel with sulfur content greater than 0.5% sulfur content is used, reduce the service interval for engine oil and filter by 50%.
- DO NOT use diesel fuel with sulfur content greater than 1.0%.

Bio-diesel fuels may be used ONLY if the fuel properties meet DIN 51606 or equivalent specification.

DO NOT mix used engine oil or any other type of lubricant with diesel fuel.

DX,FUEL1 -19-24JAN00-1/1

LUBRICITY OF DIESEL FUEL

Diesel fuel must have adequate lubricity to ensure proper operation and durability of fuel injection system components.

Diesel fuels for highway use in the United States and Canada require sulfur content less than 0.05%.

Diesel fuel in the European Union requires sulfur content less than 0.05%.

Experience shows that some low sulfur diesel fuels may have inadequate lubricity and their use may reduce performance in fuel injection systems due to inadequate lubrication of injection pump components. The lower concentration of aromatic compounds in these fuels also adversely affects injection pump seals and may result in leaks.

Use of low lubricity diesel fuels may also cause accelerated wear, injection nozzle erosion or corrosion, engine speed instability, hard starting, low power, and engine smoke.

Fuel lubricity should pass a minimum of 3100 gram load level as measured by the BOCLE scuffing test.

ASTM D975 and EN 590 specifications do not require fuels to pass a fuel lubricity test.

If fuel of low or unknown lubricity is used, add John Deere PREMIUM DIESEL FUEL CONDITIONER (or equivalent) at the specified concentration.

DX,FUEL5 -19-24JAN00-1/1

DIESEL FUEL STORAGE

Proper fuel storage is critically important. Use clean storage and transfer tanks. Periodically drain water and sediment from bottom of tank. Store fuel in a convenient place away from buildings.

IMPORTANT: DO NOT store diesel fuel in galvanized containers. Diesel fuel stored in galvanized containers reacts with zinc coating on container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters, damage injection nozzles and injection pump.

DO NOT use brass-coated containers for fuel storage. Brass is an alloy of copper and zinc.

Store diesel fuel in plastic, aluminum, and steel containers specially coated for diesel fuel storage.

Avoid storing fuel over long periods of time. If fuel is stored for more than a month prior to use, or there is a slow turnover in fuel tank or supply tank, add a fuel conditioner such as John Deere PREMIUM DIESEL FUEL CONDITIONER or equivalent to stabilize the fuel and prevent water condensation. John Deere PREMIUM DIESEL FUEL CONDITIONER is available in winter and summer formulas. Fuel conditioner also reduces fuel gelling and controls wax separation during cold weather.

Consult your John Deere engine distributor or servicing dealer for recommendations and local availability. Always follow manufacturer's directions on label.

RG, RG34710, 5027 -19-30JAN98-1/1

DIESELSCAN FUEL ANALYSIS

DIESELSCAN™ is a John Deere fuel sampling program to help you monitor the quality of your fuel source. It verifies fuel type, cleanliness, water content, suitability for cold weather operation, and if fuel is within ASTM specifications. Check with your John Deere dealer for availability of DIESELSCAN kits.

DIESELSCAN is a trademark of Deere & Company

DX, FUEL6 -19-06DEC00-1/1

MINIMIZING THE EFFECT OF COLD WEATHER ON DIESEL ENGINES

John Deere diesel engines are designed to operate effectively in cold weather.

However, for effective starting and cold weather operation, a little extra care is necessary. The information below outlines steps that can minimize the effect that cold weather may have on starting and operation of your engine. See your authorized engine distributor or servicing dealer for additional information and local availability of cold weather aids.

Use Grade No. 1-D Fuel

When temperatures fall below 5°C (40°F), Grade No. 1-D fuel is best suited for cold weather operation. Grade No. 1-D fuel has a lower cloud point and a lower pour point.

Cloud point is the temperature at which wax will begin to form in the fuel and this wax causes fuel filters to plug. **Pour point** is the temperature at which fuel begins to thicken and become more resistant to flow through fuel pumps and lines.

NOTE: On an average, Grade No. 1-D fuel has a lower BTU (heat content) rating than Grade No. 2-D fuel. When using Grade No. 1-D fuel you may notice a drop in power and fuel efficiency, but should not experience any other engine performance effects. Check the grade of fuel being used before troubleshooting for low power complaints in cold weather operation.

Seasonal Viscosity Oil and Proper Coolant Concentration

Use seasonal grade viscosity engine oil based on expected air temperature range between oil changes

and a proper concentration of low silicate antifreeze as recommended. (See DIESEL ENGINE OIL and ENGINE COOLANT REQUIREMENTS later in this section).

Diesel Fuel Flow Additive

IMPORTANT: Treat fuel when outside temperature drops below 0°C (32°F). For best results, use with untreated fuel. Follow all recommended instructions on label.

Use John Deere Premium Diesel Fuel Conditioner (Winter) or equivalent to treat fuel during the cold weather season. This winter formulation is a combination diesel fuel conditioner and anti-gel additive.

Coolant Heaters

Engine block heaters (coolant) are an available option to aid cold weather starting.

Intake Air Heaters

An electric air heater option consisting of a 12-volt, 700-watt (24-volt, 480-watt) heating element installed in the cylinder head is available.

Ether Injectors

John Deere solenoid-powered ether aid kits deliver ether to intake manifold by depressing a button. Ether should be injected in short bursts only, from immediately after cranking until when the engine starts and runs.

Continued on next page

RG, RG34710, 5029 -19-30JAN98-1/2

IMPORTANT: If too much ether is injected it can prevent proper cranking and cause engine damage.

Winterfronts

Use of fabric, cardboard, or solid winterfronts is not recommended with any John Deere engine. Their use can result in excessive engine coolant, oil, and charge air temperatures. This can lead to reduced engine life, loss of power and poor fuel economy. Winterfronts may also put abnormal stress on fan and fan drive components potentially causing premature failures.

If winterfronts are used, they should never totally close off the grill frontal area. Approximately 25% area in the center of the grill should remain open at all times. At no time should the air blockage device be applied directly to the radiator core.

Radiator Shutters

If equipped with a thermostatically controlled radiator shutter system, this system should be regulated in such a way that the shutters are completely open by the time the coolant reaches 93°C (200°F) to prevent excessive intake manifold temperatures. Manually controlled systems are not recommended.

If air-to-air aftercooling is used, the shutters must be completely open by the time the intake manifold air temperature reaches the maximum allowable temperature out of the charge air cooler.

For more information, see your John Deere engine distributor or servicing dealer.

RG, RG34710, 5029 -19-30JAN98-2/2

DIESEL ENGINE BREAK-IN OIL

New engines are filled at the factory with John Deere ENGINE BREAK-IN OIL. During the break-in period, add John Deere ENGINE BREAK-IN OIL as needed to maintain the specified oil level.

Change the oil and filter after the first 100 hours of operation of a new or rebuilt engine.

After engine overhaul, fill the engine with John Deere ENGINE BREAK-IN OIL.

If John Deere ENGINE BREAK-IN OIL is not available, use a diesel engine oil meeting one of the following during the first 100 hours of operation:

- API Service Classification CE

- ACEA Specification E1

After the break-in period, use John Deere PLUS-50® or other diesel engine oil as recommended in this manual.

IMPORTANT: Do not use PLUS-50 oil or engine oils meeting API CH-4, API CG4, API CF4, ACEA E3, or ACEA E2 performance levels during the first 100 hours of operation of a new or rebuilt engine. These oils will not allow the engine to break-in properly.

PLUS-50 is a registered trademark of Deere & Company.

DX, ENOIL4 -19-24JAN00-1/1

DIESEL ENGINE OIL

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oil is preferred:

- **John Deere PLUS-50®**

The following oil is also recommended:


- **John Deere TORQ-GARD SUPREME®**

Other oils may be used if they meet one or more of the following:

- API Service Classification CH-4
- API Service Classification CG-4
- API Service Classification CF-4
- ACEA Specification E3
- ACEA Specification E2

Multi-viscosity diesel engine oils are preferred.

If diesel fuel with sulfur content greater than 0.5% is used, reduce the service interval by 50%.



PLUS-50 is a registered trademark of Deere & Company.

TORQ-GARD SUPREME is a registered trademark of Deere & Company

CD,ENOil -19-24JAN00-1/1

MIXING OF LUBRICANTS

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Consult your John Deere dealer to obtain specific information and recommendations.


DX,LUBMIX -19-18MAR96-1/1

OILSCAN® AND COOLSCAN®


OILSCAN® and COOLSCAN® are John Deere sampling programs to help you monitor machine performance and identify potential problems before they cause serious damage.

Oil and coolant samples should be taken from each system prior to its recommended change interval.

Check with your John Deere dealer for the availability of OILSCAN® and COOLSCAN® kits.



T6828AB -JUN-15JUN89



T6829AB -JUN-18OCT88

*OILSCAN is a registered trademark of Deere & Company.
COOLSCAN is a registered trademark of Deere & Company*

DX,OILSCAN -19-16APR92-1/1

ALTERNATIVE AND SYNTHETIC LUBRICANTS

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic oils.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-15JUN00-1/1

LUBRICANT STORAGE

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-18MAR96-1/1

GREASE

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

The following greases are preferred:

- John Deere SD POLYUREA GREASE


The following greases are also recommended:

- John Deere HD MOLY GREASE
- John Deere HD LITHIUM COMPLEX GREASE
- John Deere HD WATER RESISTANT GREASE
- John Deere GREASE-GARD

Other greases may be used if they meet the following:

- NLGI Performance Classification GC-LB

IMPORTANT: Some types of grease thickener are not compatible with others. Consult your grease supplier before mixing different types of grease.



DX,GREAI -19-24JAN00-1/1

DIESEL ENGINE COOLANT

The engine cooling system is filled to provide year-round protection against corrosion and cylinder liner pitting, and winter freeze protection to -37°C (-34°F).

The following engine coolant is preferred for service:

- John Deere COOL-GARD Prediluted Coolant

The following engine coolant is also recommended:

- John Deere COOL-GARD Coolant Concentrate in a 40 to 60% mixture of concentrate with quality water.

Other low silicate ethylene glycol base coolants for heavy-duty engines may be used if they meet one of the following specifications:

- ASTM D5345 (prediluted coolant)
- ASTM D4985 (coolant concentrate) in a 40 to 60% mixture of concentrate with quality water

Coolants meeting these specifications require use of supplemental coolant additives, formulated for heavy-duty diesel engines, for protection against corrosion and cylinder liner erosion and pitting.

A 50% mixture of ethylene glycol engine coolant in water provides freeze protection to -37°C (-34°F). If

protection at lower temperatures is required, consult your John Deere dealer for recommendations.

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol base engine coolant concentrate.

IMPORTANT: Do not use cooling system sealing additives or antifreeze that contains sealing additives.

Coolant Drain Intervals

Drain the factory fill engine coolant, flush the cooling system, and refill with new coolant after the first 3 years or 3000 hours of operation. Subsequent drain intervals are determined by the coolant used for service. At each interval, drain the coolant, flush the cooling system, and refill with new coolant.

When John Deere COOL-GARD is used, the drain interval may be extended to 5 years or 5000 hours of operation, provided that the coolant is tested annually AND additives are replenished, as needed, by adding a supplemental coolant additive.

If COOL-GARD is not used, the drain interval is reduced to 2 years or 2000 hours of operation.

DX.COOL3 -19-05FEB99-1/1

DIESEL ENGINE COOLANTS, SUPPLEMENTAL ADDITIVE INFORMATION

Engine coolants are a combination of three chemical components: ethylene glycol (antifreeze), inhibiting coolant additives, and quality water.

Coolant Specifications

Some products, including John Deere COOL-GARD Prediluted Coolant, are fully formulated coolants that contain all three components in their correct concentrations. Do not add an initial charge of supplemental coolant additives to these fully formulated products.

Some coolant concentrates, including John Deere COOL-GARD Coolant Concentrate, contain both ethylene glycol antifreeze and inhibiting coolant additives. Mix these products and quality water, but do not add an initial charge of supplemental coolant additives.

Coolants meeting ASTM D5345 (prediluted coolant) or ASTM D4985 (coolant concentrate) require an initial charge of supplemental coolant additives.

Replenish Coolant Additives

The concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD is used. Follow the recommendations in this manual for the use of supplemental coolant additives.

Why Use Supplemental Coolant Additives?

Operating without proper coolant additives will result in increased corrosion, cylinder liner erosion and pitting, and other damage to the engine and cooling system. A simple mixture of ethylene glycol and water will not give adequate protection.

Use of supplemental coolant additives reduces corrosion, erosion, and pitting. These chemicals reduce the number of vapor bubbles in the coolant and

help form a protective film on cylinder liner surfaces. This film acts as a barrier against the harmful effects of collapsing vapor bubbles.

Avoid Automotive-Type Coolants

Never use automotive-type coolants (such as those meeting ASTM D3306 or ASTM D4656). These coolants do not contain the correct additives to protect heavy-duty diesel engines. They often contain a high concentration of silicates and may damage the engine or cooling system.

Water Quality

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol base engine coolant concentrate. All water used in the cooling system should meet the following minimum specifications for quality:

Chlorides	<40 mg/L
Sulfates	<100 mg/L
Total Dissolved Solids	<340 mg/L
Total Hardness	<170 mg/L
pH	5.5 to 9.0

Freeze Protection

The relative concentrations of ethylene glycol and water in the engine coolant determine its freeze protection limit.

Ethylene Glycol	Freeze Protection Limit
40%	-24°C (-12°F)
50%	-37°C (-34°F)
60%	-52°C (-62°F)

DO NOT use a coolant-water mixture greater than 60% ethylene glycol.

TESTING DIESEL ENGINE COOLANT

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.


Test the coolant solution at intervals of 12 months or less and whenever excessive coolant is lost through leaks or overheating.

DX.COOL9 -19-17FEB99-1/3

Coolant Test Strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective method to check the freeze point and additive levels of your engine coolant.

Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.



Coolant Test Strips

RG7297 -UN-22SEP99

DX.COOL9 -19-17FEB99-2/3

COOLSCAN

For a more thorough evaluation of your coolant, perform a COOLSCAN analysis. See your John Deere dealer for information about COOLSCAN.




COOLSCAN Sampling

RG7397 -UN-05DEC97


DX.COOL9 -19-17FEB99-3/3

REPLENISHING SUPPLEMENTAL COOLANT ADDITIVES (SCAs) BETWEEN COOLANT CHANGES



Sampling of Coolant

RG6241 -UN-08DEC97



Testing of Coolant for Glycol Concentration

RG6262 -UN-05DEC97

IMPORTANT: Do not add supplemental coolant additives when the cooling system is drained and refilled with John Deere COOL-GARD®.

Through time and use, the concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD® is used. The cooling system must be recharged with additional supplemental coolant additives available in the form of liquid coolant conditioner.

Maintaining the correct coolant conditioner concentration (SCAs) and freeze point is essential in your cooling system to protect against rust, liner pitting and corrosion, and freeze-ups due to incorrect coolant dilution.

John Deere COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

Test the coolant solution at 600 hours or 12 months of operation using either John Deere coolant test strips or

a COOLSCAN® analysis. If a COOLSCAN® analysis is not available, recharge system per instructions printed on label of John Deere Liquid Coolant Conditioner.

IMPORTANT: ALWAYS maintain coolant at correct level and concentration. DO NOT operate engine without coolant for even a few minutes.

If frequent coolant makeup is required, the glycol concentration should be checked with JT07298 Coolant/Battery Tester to assure that the desired freeze point is maintained. Follow manufacturer's instructions provided with Coolant/Battery Tester.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

COOL-GARD is a registered trademark of Deere & Company
COOLSCAN is a registered trademark of Deere & Company

Continued on next page

RG, RG34710, 5041 -19-30JAN98-1/2

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.

See ENGINE COOLANT SPECIFICATIONS earlier in this section for proper mixing of coolant ingredients before adding to the cooling system.

RG, RG34710, 5041 -19-30JAN98-2/2

OPERATING IN WARM TEMPERATURE CLIMATES

John Deere engines are designed to operate using glycol base engine coolants.

Always use a recommended glycol base engine coolant, even when operating in geographical areas where freeze protection is not required.

IMPORTANT: Water may be used as coolant *in emergency situations only*.

Foaming, hot surface aluminum and iron corrosion, scaling, and cavitation will occur when water is used as the coolant, even when coolant conditioners are added.

Drain cooling system and refill with recommended glycol base engine coolant as soon as possible.

DX, COOL6 -19-18MAR96-1/1


DISPOSING OF COOLANT

Improperly disposing of engine coolant can threaten the environment and ecology.

Used leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere engine distributor or servicing dealer.



Recycle Waste

TS1133 -UN-26NOV90

OUOD002,000002B -19-24JAN01-1/1

Engine Operating Guidelines

INSTRUMENT (GAUGE) PANELS

IMPORTANT: Any time an electric gauge or meter does not register correctly, replace it with a new one. Do not attempt to repair it.

All controls and gauges are optional equipment for John Deere OEM Engines. They may be provided by the equipment manufacturer instead of John Deere. The following information applies only to those controls and gauges provided by John Deere.

Continued on next page

OUOD002,0000028 -19-18JAN01-1/6

Instrument (Gauge) Panel (North American)

Following is a brief description of the components on the John Deere instrument (gauge) panel:

A—Oil Pressure Gauge - Indicates engine oil pressure.

B—Coolant Temperature Gauge - Indicates the engine coolant temperature.

C—Key Switch - The four position key switch controls the electrical system.

D—Tachometer (optional) - Indicates engine speed in revolutions per minute (rpm).


E—Reset (Safety) Switch - Overrides safety shutdown switch when depressed and held in during engine start-up. Hold button in until engine oil pressure is at a safe operating level.

F—Fuse Holder - Contains 14 amp fuse.

G—Ammeter - Indicates charging current within electrical system.

H—Hour Meter (optional) - Indicates the operating hours of the engine while key switch is in the "ON" position. The hour meter should be used as a guide for scheduling periodic service.

I—Hand Throttle (optional) - Controls engine speed.



North American Instrument Panel

- A—Oil Pressure Gauge
- B—Coolant Temperature Gauge
- C—Key Switch
- D—Tachometer
- E—Reset (Safety) Switch
- F—Fuse Holder
- G—Ammeter
- H—Hour Meter
- I—Hand Throttle

RG11527 -UN-01DEC00

Continued on next page

OUOD002,0000028 -19-18JAN01-2/6

AEZ Instrument (Gauge) Panel (Except North America)

A—Oil Pressure Gauge - The oil pressure gauge indicates engine oil pressure.

B—Coolant Temperature Gauge - The coolant temperature gauge indicates the engine coolant temperature.

C—Engine Control Light - The engine control light indicates that the engine protection is activated.


D—Oil Pressure Light - The oil pressure light illuminates when the key switch is turned to the CONTROL position. The light will remain on until the engine is started and the specified oil pressure is reached. If oil pressure is lost during engine operation, the light will illuminate and protection circuitry will stop the engine. The oil pressure light will remain on, indicating that the engine was stopped due to a low oil pressure condition.

E—Alternator Light - The alternator light illuminates when the key is turned to the CONTROL position. The light will remain on until the engine is started. After the engine is running, if the alternator stops charging, the light will illuminate and protection circuitry will stop the engine. The alternator light will remain on indicating the engine was stopped due to the alternator not charging.

F—Coolant Temperature Light - The coolant temperature light illuminates only if the engine has overheated. After the engine is running, if the engine overheats, the light will illuminate and protection circuitry will stop the engine. The coolant temperature light will remain on indicating the engine was stopped due to the engine overheating.

G—Fuel Level Light - The fuel level light illuminates only if the engine has stopped due to fuel tank being empty. After the engine is running, if the engine runs out of fuel, the light will illuminate. The fuel level light will remain on indicating the engine was stopped due to the fuel tank being empty.

H—Key Switch - The key switch controls the electrical system.



AEZ Instrument Panel

- A—Oil Pressure Gauge
- B—Coolant Temperature Gauge
- C—Engine Control Light
- D—Oil Pressure Light
- E—Alternator Light
- F—Coolant Temperature Light
- G—Fuel Level Light
- H—Key Switch
- I—Hour Meter
- J—Tachometer

RG11590 -JUN-08DEC00

I—Hour Meter - Indicates the operating hours of the engine while key switch is in the “ON” position. The hour meter should be used as a guide for scheduling periodic service.

J—Tachometer - Indicates engine speed in revolutions per minute (rpm).

Continued on next page

QUOD002,0000028 -19-18JAN01-4/6

VDO Instrument (Gauge) Panel (Except North America)

A—Oil Pressure Gauge - The oil pressure gauge indicates engine oil pressure.

B—Coolant Temperature Gauge - The coolant temperature gauge indicates coolant temperature.

C—Tachometer - The tachometer indicates engine speed in hundreds of revolutions per minute (rpm).


The engine control system consists of the following:

D—Engine Control Light - The engine control light illuminates after the engine has started and oil pressure is up to specification. The light indicates that the engine protection circuitry is activated.

E—Preheater Light - The preheater light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. When the key switch is held in position II, the engine preheater is energized and the preheater light illuminates.

F—Fuel Level Light - The fuel level light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the engine runs out of fuel, the light will illuminate. The fuel level light will remain on indicating the engine was stopped due to the fuel tank being empty.

G—Battery Light - The battery light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the alternator stops charging, the light will illuminate and protection circuitry will stop the engine. The battery light will remain on indicating the engine was stopped due to the alternator not charging.



- A—Oil Pressure Gauge
- B—Coolant Temperature Gauge
- C—Tachometer
- D—Engine Control Light
- E—Preheater Light
- F—Fuel Level Light
- G—Battery Light
- H—Oil Pressure Light
- I—Coolant Temperature Light
- J—Key/Start Switch
- K—Hour Meter

Continued on next page

OUOD002,0000028 -19-18JAN01-5/6

H—Oil Pressure Light - The oil pressure light illuminates when the key switch is turned to the bulb test position (position I). The light will remain on until the engine is started and the specified oil pressure is reached. If oil pressure is lost during engine operation, the light will illuminate and protection circuitry will stop the engine. The oil pressure light will remain on, indicating that the engine was stopped due to a low oil pressure condition.

I—Coolant Temperature Light - The coolant temperature light illuminates when the key is turned to the bulb test position (position I). It should go off after approximately five seconds. After the engine is running, if the engine overheats, the light will illuminate and protection circuitry will stop the engine. The coolant temperature light will remain on indicating the engine was stopped due to the engine overheating.

Other components on the instrument panel:

J—Key/Start Switch - The four-position key start switch controls the electrical system.

K—Hour Meter - The hour meter is an integral part of the tachometer. It shows the accumulated hours of engine service. The hour meter operates when the engine is running and accumulated hours are displayed in hours and tenths of hours.

OUOD002,0000028 -19-18JAN01-6/6

NORMAL ENGINE OPERATION

Observe engine coolant temperature and engine oil pressure. Temperatures and pressures will vary between engines and with changing operating conditions, temperatures, and loads.

Normal engine coolant operating temperature range is 82°–94°C (180°–202°F). If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop engine and determine cause before resuming operation.

Operate the engine under a lighter load and at slower than normal speed for first 15 minutes after start-up. DO NOT run engine at slow idle.

IMPORTANT: Should the engine die while operating under load, immediately


remove load and restart the engine. Overheating of the turbocharger parts may occur when oil flow is stopped.

Stop engine immediately if there are any signs of part failure. Symptoms that may be early signs of engine problems are:


- Sudden drop in oil pressure
- Abnormal coolant temperatures
- Unusual noise or vibration
- Sudden loss of power
- Excessive black exhaust
- Excessive fuel consumption
- Excessive oil consumption
- Fluid leaks

RG, RG34710, 5045 –19–30JAN98–1/1

BREAK-IN SERVICE



Check Engine Oil Level



A—Full Mark

B—Crosshatch

The engine is ready for normal operation. However, extra care during the first 100 hours of operation will result in more satisfactory long-term engine performance and life. DO NOT exceed 100 hours of operation with break-in oil.

1. This engine is factory-filled with a special break-in oil. Operate the engine at heavy loads with minimal idling during the break-in period.
2. If the engine has significant operating time at idle, constant speeds, and/or light load usage, or make-up oil is required in the first 100 hour period, a longer break-in period may be required. In these situations, an additional 100 hour break-in period is recommended using a new change of John Deere Engine Break-In Oil and new John Deere oil filter.

IMPORTANT: Do not add makeup oil until the level is **BELOW** the ADD mark or lower

arrow on dipstick. If make-up oil is required during the break-in period, an additional 100 hour break-in period is required. John Deere Engine Break-In Oil (TY22041) should be used to make up any oil consumed during the break-in period.

DO NOT fill above the top of the mark (A) or crosshatch pattern (B), whichever is present. Oil levels anywhere within arrows or crosshatch are considered in the acceptable operating range.

3. Check engine oil level more frequently. If oil must be added, John Deere Engine Break-In Oil is preferred. See ENGINE BREAK-IN OIL, in Fuels, Lubricants, and Coolant Section.

Continued on next page

RG, RG34710, 5046 -19-30JAN98-1/2

IMPORTANT: DO NOT use PLUS-50® Engine Oil or engine oils meeting API CG4, API CF4, ACEA E3, ACEA E2 or CCMC D5 performance levels during the first 100 hours of operation of a new or rebuilt engine. These oils will not allow a new or rebuilt engine to break-in properly.


4. During the first 20 hours, avoid prolonged periods of engine idling or sustained maximum load operation. Vary the engine speed throughout this period. If engine will idle longer than 5 minutes, stop engine.

Specification

Engine ¹ —Oil Pressure at Full Load Rated Speed.....	345 ± 103 kPa (3.45 ± 1.03 bar) (50 ± 15 psi)
Minimum Oil Pressure at Rated Speed.....	275 (2.75 bar) (40 psi)
Minimum Oil Pressure at 850 rpm.....	105 kPa (1.05 bar) (15 psi)
Coolant Temperature Range.....	82°—94°C (180°—202°F)


¹At normal operating temperature of 115 °C (240 °F) sump.

BREAK-IN SERVICE—CONTINUED



RG11529 -UN-01DEC00

Engine Mounted Oil Filter




RG11530 -UN-01DEC00

Engine Mounted Oil Filter

5. After the first 100 hours maximum of operation, drain engine oil and change engine oil filter (A). (See CHANGING ENGINE OIL AND REPLACING OIL FILTER in Lubrication and Maintenance Section.) Fill crankcase with seasonal viscosity grade oil. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section.)

A—Oil Filter



RG11549 -UN-06DEC00

3029 Engines with Remote Oil Filter

Continued on next page

CD,OUOD002,000001C -19-01DEC00-1/2




North American Instrument Panel

RG11531 -UN-01DEC00



AEZ Instrument Panel (Except North America)

RG11591 -UN-08DEC00



RG11587

VDO Instrument Panel (Except North America)

RG11587 -UN-07DEC00

A—Coolant Temperature Gauge

NOTE: If the engine has significant operating time at idle, constant speeds, and/or light load usage, or makeup oil is required in the first 100 hour period, a longer break-in period may be required. In these situations, an additional 100 hour break-in period is recommended using a new change of John Deere Engine Break-In Oil and new John Deere oil filter.

6. Watch coolant temperature gauge (A) closely. If coolant temperature rises above 112°C (234°F), reduce load on engine. Unless temperature drops quickly, stop the engine and determine the cause before resuming operation.

NOTE: When the coolant temperature gauge reads approximately 115°C (239°F), the engine will shutdown automatically, if equipped with safety controls.

7. The tension on newly installed belts should be checked daily for the first few days of operation because of the initial stretching. Also, check belts for proper seating in pulley grooves.

AUXILIARY GEAR DRIVE LIMITATIONS

IMPORTANT: When attaching an air compressor, hydraulic pump, or other accessory to be driven by the auxiliary gear drive (engine timing gear train at front of engine), power requirements of the accessory must be limited to values listed below:

Power Levels For Right-Hand Auxiliary Gear Drive:

- 16 kW (22 hp) Continuous Operation¹
- 28 kW (37.5 hp) Intermittent Operation¹



Auxiliary Gear Drive

CD30354 -UN-03FEB93

¹At 2400 engine rpm.

RG, RG34710, 5047 -19-30JAN98-1/1

GENERATOR SET (STANDBY) APPLICATIONS

To assure that your engine will deliver efficient standby operation when needed, start engine and run at rated speed (with 50%—70% load) for 30 minutes every 2 weeks. DO NOT allow engine to run extended period of time with no load.

RG, RG34710, 5048 -19-30JAN98-1/1

STARTING THE ENGINE

The following instructions apply to the optional controls and instruments available through the John Deere Parts Distribution Network. The controls and instruments for your engine may be different from those shown here; always follow manufacturer's instructions.


Continued on next page

RG, RG34710, 5049 -19-30JAN98-1/4

CAUTION: Before starting engine in a confined building, install proper outlet exhaust ventilation equipment. Always use safety approved fuel storage and piping.

NOTE: If temperature is below 0 °C (32 °F), it may be necessary to use cold weather starting aids (See *COLD WEATHER OPERATION*, later in this section).

1. Perform all prestarting checks outlined in Lubrication & Maintenance/Daily Section later in this manual.
2. Open the fuel supply shut-off valve, if equipped.




Avoid Toxic Fumes

TS220 -UN-23AUG88

RG, RG34710, 5049 -19-30JAN98-2/4

3. If equipped with PTO clutch, pull lever (arrow) rearward (away from engine) to disengage PTO clutch.



PTO Clutch Lever

RG5602 -UN-16JUN00

Continued on next page

RG, RG34710, 5049 -19-30JAN98-3/4

4. Pull hand throttle (A) 1/3 of the way out. Turn the handle in either direction to lock it in place.
5. If equipped, depress and hold reset button (B) while starting.

IMPORTANT: Do not operate the starter for more than 30 seconds at a time. To do so may overheat the starter. If the engine does not start the first time, wait at least 2 minutes before trying again. If engine does not start after four attempts, see Troubleshooting Section.

6. Turn the key switch (C) clockwise to crank the engine. When the engine starts, release the key so that it returns to the "ON" position.


IMPORTANT: If the key switch is released before the engine starts, wait until the starter and the engine stop turning before trying again. This will prevent possible damage to the starter and/or flywheel.

7. After the engine starts, continue to hold the reset button in until the oil pressure gauge (D) reads at least 105 kPa (1.05 bar) (15 psi). The safety controls will not allow the engine to run at a lower oil pressure unless the reset button is held in.

IMPORTANT: Should the engine die while operating under load, immediately disengage PTO clutch and restart the engine. Overheating of turbocharger parts may occur when oil flow is stopped.

8. Check all gauges for normal engine operation. If operation is not normal, stop the engine and determine the cause.

A—Hand Throttle
B—Reset Button
C—Key Switch
D—Oil Pressure Gauge




RG11532 -UN-01DEC00

North American Instrument Panel



RG11592 -UN-17JAN01

AEZ Instrument Panel (Except North America)



RG11588

VDO Instrument Panel (Except North America)

RG11588 -UN-08DEC00

COLD WEATHER OPERATION

CAUTION: Ether injector starting fluid is highly flammable. **DO NOT** use starting fluid on engines equipped with air intake heaters.

DO NOT use starting fluid near fire, sparks, or flames. **DO NOT** incinerate or puncture a starting fluid container.

Engines may be equipped with intake air heaters, coolant heaters, or ether injectors as a cold weather starting aid.

Starting aids are required below 32°F (0°C). They will enhance starting performance above these temperatures and may be needed to start applications that have high parasitic loads during cranking and/or start acceleration to idle.

Using correct grade of oil (per engine and machine operator's manual) is critical to achieving adequate cold weather cranking speed.


Other cold weather starting aids are required at temperatures below -22°F (-30°C) or at altitudes above 1500 m (5000 ft).

1. Follow steps 1—4 as listed under "STARTING THE ENGINE", then proceed as follows according to the instrument (control) panel on your engine.
2. Switch on the air intake heater for 30 seconds or activate ether injector by following suppliers instructions.
3. Follow remaining steps 5—8 as listed under "STARTING THE ENGINE" earlier in this section.

Additional information on cold weather operation is available from your authorized servicing dealer.



Handle Starting Fluid with Care



Cold Weather Starting Guidelines

TS1356 -UN-18MAR92

RG11521 -19-10JAN01

RG, RG34710, 5050 -19-30JAN98-1/1

WARMING ENGINE

IMPORTANT: To assure proper lubrication, operate engine at or below 1200 rpm with no load for 1–2 minutes. Extend this period 2–4 minutes when operating at temperatures below freezing.

Engines used in generator set applications where the governor is locked at a specified speed may not have a slow idle function. Operate these engines at high idle for 1 to 2 minutes before applying the load. This procedure does not apply to standby generator sets where the engine is loaded immediately upon reaching rated speed.

1. Check oil pressure gauge (A) as soon as engine starts. If gauge needle does not rise above minimum oil pressure specification of 105 kPa (1.05 bar) (15.0 psi) within 5 seconds, stop the engine and determine the cause. Normal engine oil pressure is 345 ± 103 kPa ($3.45 \text{ bar} \pm 1.03 \text{ bar}$) (50 ± 15 psi) at rated full load speed (1800–2500 rpm) with oil at normal operating temperature of 105°C (221°F).
2. Watch coolant temperature gauge (B). Do not place engine under full load until it is properly warmed up. The normal engine coolant temperature range is 82°–94°C (180°–202°F).

NOTE: It is a good practice to operate the engine under a lighter load and at lower speeds than normal for the first few minutes after start-up.


A—Oil Pressure Gauge

B—Coolant Temperature Gauge




North American Instrument Panel

RG11533 –UN-01DEC00



AEZ Instrument Panel (Except North America)

RG11593 –UN-08DEC00



VDO Instrument Panel (Except North America)

RG10613 –UN-21OCT99

CHANGING ENGINE SPEED-STANDARD (MECHANICAL) GOVERNOR

NOTE: Throttle levers are usually supplied by OEM manufacturer. Consult supplier literature to familiarize yourself with throttle lever used on your engine.

To increase engine speed, turn throttle handle (A) to the horizontal position and pull out until desired engine speed is obtained. Turn the handle in either direction to lock throttle position. The handle is pushed inward to decrease engine speed.

A—Throttle Handle



RG11534 -JUN-01DEC00

Throttle Handle on North American Instrument Panel

RG, RG34710, 5052 -19-30JAN98-1/1

IDLING ENGINE

Avoid excessive engine idling. Prolonged idling may cause the engine coolant temperature to fall below its normal range. This, in turn, causes crankcase oil dilution, due to incomplete fuel combustion, and permits formation of gummy deposits on valves, pistons, and piston rings. It also promotes rapid accumulation of engine sludge and unburned fuel in the exhaust system.

Once an engine is warmed to normal operating temperatures, engine should be idled at slow idle


speed. Slow idle speed for this engine is 850 rpm at factory. If an engine will be idling for more than 5 minutes, stop and restart later.

NOTE: Generator set applications where the governor is locked at a specified speed may not have a slow idle function. These engines will idle at no load governed speed (high idle).

RG, RG34710, 5053 -19-30JAN98-1/1

STOPPING THE ENGINE

1. Pull PTO clutch lever (arrow) rearward (away from engine) to disengage clutch, if equipped.



PTO Clutch Lever

RG5602 -UN-16JUN00

Continued on next page

RG, RG34710, 5054 -19-30JAN98-1/2

2. Move the throttle handle (A) to slow idle on standard (mechanical) governor engines.

IMPORTANT: Before stopping an engine that has been operating at working load, idle engine at least 2 minutes at 1000–1200 rpm to cool hot engine parts.

Engines in generator set applications, where the governor is locked at a specified speed and no slow idle function is available, run engine for at least 2 minutes at fast idle and no load.

3. Turn key switch to “OFF” position. Remove ignition key.

IMPORTANT: Make sure that exhaust stack cap (rain cap) is installed when engine is not running. This will prevent water and dirt from entering engine.

A—Throttle Handle



RG11534 -UN-01DEC00

Throttle Handle on North American Instrument Panel



RG10616 -UN-16JUN00

Rain Cap

RG, RG34710, 5054 -19-30JAN98-2/2

USING A BOOSTER BATTERY OR CHARGER

CAUTION: Gas given off by battery is explosive. Keep sparks and flames away from battery. Before connecting or disconnecting a battery charger, turn charger off. Make last connection and first disconnection at a point away from battery. Always connect **NEGATIVE (-)** cable last and disconnect this cable first.

IMPORTANT: Be sure polarity is correct before making connections. Reversed polarity will damage electrical system. Always connect positive to positive and negative to ground. Always use 12-volt booster battery for 12-volt electrical systems and 24-volt booster battery(ies) for 24-volt electrical systems.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

A 12-volt booster battery can be connected in parallel with battery(ies) on the unit to aid in cold weather starting. **ALWAYS** use heavy duty jumper cables.


1. Connect booster battery or batteries to produce the required system voltage for your engine application.

NOTE: To avoid sparks, **DO NOT** allow the free ends of jumper cables to touch the engine.


2. Connect one end of jumper cable to the **POSITIVE (+)** post of the booster battery.
3. Connect the other end of the jumper cable to the **POSITIVE (+)** post of battery connected to starter.
4. Connect one end of the other jumper cable to the **NEGATIVE (-)** post of the booster battery.
5. **ALWAYS** complete the hook-up by making the last connection of the **NEGATIVE (-)** cable to a good ground on the engine frame and away from the battery(ies).



Exploding Battery



12-Volt System



24-Volt System

A—12-Volt Machine Battery (ies)
 B—12-Volt Booster Battery (ies)
 C—Booster Cable
 D—Cable to Starting Motor

TS204 -JUN-23AUG88

RG4678 -JUN-14DEC88

RG4698 -JUN-14DEC88

Continued on next page

RG, RG34710, 4060 -19-01JAN96-1/2

6. Start the engine. Disconnect jumper cables immediately after engine starts. Always disconnect NEGATIVE (–) cable first.

RG, RG34710, 4060 –19–01JAN96–2/2

Lubrication and Maintenance

OBSERVE SERVICE INTERVALS



North American Instrument Panel Hour Meter

RG11589 -JUN-08DEC00


Using hour meter (A) as a guide, perform all services at the hourly intervals indicated on following pages. At each scheduled maintenance interval, perform all previous maintenance operations in addition to the ones specified. Keep a record of hourly intervals and services performed using charts provided in Lubrication and Maintenance Records Section.

IMPORTANT: Recommended service intervals are for normal operating conditions. Service **MORE OFTEN** if engine is operated under adverse conditions. Neglecting maintenance can result in failures or permanent damage to the engine.



AEZ Instrument Panel Hour Meter

RG11594 -JUN-08DEC00



VDO Instrument Panel Hour Meter

RG10618 -JUN-21OCT99

A—Hour Meter

RG, RG34710, 5056 -19-30JAN98-1/1

USE CORRECT FUELS, LUBRICANTS, AND COOLANT

IMPORTANT: Use only fuels, lubricants, and coolants meeting specifications outlined in Fuels, Lubricants, and Coolant Section when servicing your John Deere Engine.

Consult your John Deere Servicing Distributor or your nearest John Deere Parts Network for recommended fuels, lubricants, and coolant. Also available are necessary additives for use when operating engines in tropical, arctic, or any other adverse conditions.



John Deere Parts

TS100 -JUN-23AUG88

RG, RG34710, 5057 -19-30JAN98-1/1

LUBRICATION AND MAINTENANCE SERVICE INTERVAL CHART—PRIME POWER ENGINES

Item	Lubrication and Maintenance Service Intervals					
	Daily	250 Hour or 6 Month	500 Hour	500 Hour or 12 Month	1500 Hour or 24 Month	As Required
Check Engine Oil and Coolant Level	•					
Lubricate PTO Release Bearing	•					
Check Air Cleaner Dust Unloader Valve & Restriction Indicator ^a	•					
Visual Walk Around Inspection	•					
Check Fuel Filter	•					
Service Fire Extinguisher		•				
Lubricate PTO Clutch Shaft Bearing		•				
Service Battery		•				
Check Fan and Alternator Belt Tension		•				
Check PTO Clutch Adjustment		•				
Check Engine Mounts		•				
Initial Valve Clearance Adjustment ^c			•			
Check Engine Ground Connection				•		
Change Engine Oil and Filter ^b				•		
Clean Crankcase Vent Tube				•		
Check Air Intake Hoses, Connections, and System				•		
Replace Fuel Filter Element				•		
Check Cooling System				•		
Coolant Solution Analysis-Add SCAs as needed				•		
Pressure Test Cooling System				•		
Check and Adjust Valve Clearance					•	
Flush and Refill Cooling System ^d					•	
Test Thermostats					•	
Add Coolant						•

^aReplace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H₂O.

^bChange the oil and filter for the first time after 100 hours maximum of operation, then every 500 hours thereafter.

^cHave your authorized servicing dealer or engine distributor adjust valve clearance after the first 500 hours of operation. Then, have the valve clearance adjusted at 1500 Hour/24 Month intervals thereafter.

^dIf John Deere COOL-GARD is used, the flushing and refilling interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished by adding supplemental coolant additives (SCAs), the flushing and refilling interval may be extended to 5000 hours or 60 months, whichever occurs first.

Continued on next page

CD, RG34710, 5058 -19-30JAN98-1/2

	Lubrication and Maintenance Service Intervals					
Item	Daily	250 Hour or 6 Month	500 Hour	500 Hour or 12 Month	1500 Hour or 24 Month	As Required
Bleed Fuel System						•
Replace Air Cleaner Elements						•
Replace Belts						•
Inspect PTO Clutch						•
Check Fuses						•

CD, RG34710, 5058 -19-30JAN98-2/2

LUBRICANT AND MAINTENANCE SERVICE INTERVAL CHART—GENERATOR (STANDBY) APPLICATIONS

NOTE: The service intervals in the Lubrication and Maintenance Sections that follow reflect standard engines. Use service intervals listed below for generator (standby) applications. Match service items below to titles in Lubrication and Maintenance Sections for procedures.

Item	Lubrication and Maintenance Service Intervals					
	Every 2 Weeks	250 Hours or 6 Month	500 Hour	500 Hour or 12 Months	1500 Hour or 24 Months	As Required
Operate Engine at Rated Speed and 50%-70% Load a Minimum of 30 Minutes	•					
Check Engine Oil and Coolant Level	•					
Check Fuel Filter	•					
Lubricate PTO Release Bearings	•					
Check Air Cleaner Dust Unloader Valve & Restriction Indicator Gauge ^a	•					
Visual Walkaround Inspection	•					
Service Fire Extinguisher		•				
Lubricate PTO Clutch Shaft Bearings		•				
Service Battery		•				
Check Fan and Alternator Belt Tension		•				
Check PTO Clutch Adjustment		•				
Check Engine Mounts		•				
Initial Valve Clearance Adjustment ^c			•			
Check Engine Ground Connection				•		
Clean Crankcase Vent Tube				•		
Check Air Intake Hoses, Connections & System				•		
Replace Fuel Filter Element				•		
Check Cooling System				•		
Change Engine Oil and Replace Oil Filter ^b				•		

^aReplace primary air cleaner element when restriction indicator shows a vacuum of 625 mm (25 in.) H2O.

^bChange the oil for the first time before 100 hours maximum of (break-in) operation, then every 500 hours thereafter.

^cHave your authorized servicing dealer or engine distributor adjust valve clearance after the first 500 hours of operation. Then, have the valve clearance adjusted at 1500 Hour/24 Month intervals thereafter.

Continued on next page

CD,OUOD002,0000022 -19-06DEC00-1/2

Lubrication and Maintenance

Item	Lubrication and Maintenance Service Intervals					
	Every 2 Weeks	250 Hours or 6 Month	500 Hour	500 Hour or 12 Months	1500 Hour or 24 Months	As Required
Pressure Test Cooling System				•		
Check and Adjust Valve Clearance					•	
Adjust Variable Speed					•	
Flush and Refill Cooling System ^d					•	
Test Thermostats					•	
Add Coolant						•
Bleed Fuel System						•
Replace Air Cleaner Elements						•
Replace Belts						•
Check Fuses						•
^d If John Deere COOL-GARD is used, the flushing and refilling interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used and the coolant is tested annually AND additives are replenished by adding supplemental coolant additives, the flushing and refilling interval may be extended to 5000 hours or 60 months, whichever occurs first.						

CD,OUOD002,0000022 -19-06DEC00-2/2

Lubrication & Maintenance

DAILY PRESTARTING CHECKS

Do the following **BEFORE STARTING THE ENGINE** for the first time each day:

Check Engine Oil Level


IMPORTANT: There is no need to add makeup oil until the oil level is **BELOW** the add mark.

DO NOT fill above the top mark on the dipstick. Oil levels anywhere within arrows (C) or crosshatch (D), whichever is present, are considered in the acceptable operating range.

1. Check engine oil level on dipstick (A). Oil level on dipstick should be within arrows (C) or crosshatch (D). Add oil at filler cap (B) as required, using seasonal viscosity grade oil. (See **DIESEL ENGINE OIL** in Fuels, Lubricants, and Coolant Section for oil specifications.)


Some engines may have the oil filler cap on rocker arm cover, while others will have the filler cap on the timing gear cover.

A—Dipstick
B—Oil Filler Cap
C—Arrows
D—Crosshatch



3029D Engines


RG11536 -UN-01DEC00



3029T Engines


RG11537 -UN-01DEC00

RG11595 -UN-08DEC00



Correct Oil Level Within Arrows

RG11538 -UN-01DEC00



Correct Oil Level Within Crosshatch

Continued on next page

RG, RG34710, 5059 -19-30JAN98-1/5

Check Coolant Level




CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Only remove filler cap when engine is cold or when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


1. Check the coolant level when engine is cold. Coolant level should be at bottom of filler neck. Fill radiator (A) with proper coolant solution if level is low. (See **ADDING COOLANT** in Service As Required Section.) Check overall cooling system for leaks.

Refer to your vehicle's operator's manual for recommendations for non-John Deere supplied accessories.

A—Radiator



Beware of Hot Fluids Under Pressure



Coolant Level in Radiator

RG4675 -UN-14DEC88

TS281 -UN-23AUG88


Continued on next page

RG, RG34710, 5059 -19-30JAN98-2/5

Lubricate PTO Bearing

1. Apply one shot of John Deere Multi-Purpose Lubricant or equivalent at PTO release bearing grease fitting (A). DO NOT over lubricate.

A—Grease Fitting



PTO Release Bearing

Continued on next page

RG, RG34710, 5059 -19-30JAN98-3/5

Check Air Cleaner

IMPORTANT: Maximum air intake restriction is 3.5 kPa (0.03 bar) (0.5 psi) (14 in.) H₂O. A clogged air cleaner element will cause excessive intake restriction and a reduced air supply to the engine.

1. Squeeze dust unloader valve (A) on air cleaner assembly to remove dust deposits. If clogged, remove and clean the dust unloader valve. Replace if damaged.

IMPORTANT: Do not operate engine without the dust unloader valve.

If equipped with air intake restriction indicator gauge (B), check gauge. Service air cleaner when indicator is red.

Inspect Engine Compartment

1. Make a thorough inspection of the engine compartment. Look for oil or coolant leaks, worn fan and accessory drive belts, loose connections and trash build-up. Remove trash build-up and have repairs made as needed if leaks are found.

NOTE: Wipe all fittings, caps, and plugs before performing any maintenance to reduce the chance of system contamination.


Inspect:

- Radiator for leaks and trash build-up.
- Air intake system hoses and connections for cracks and loose clamps.
- Fan, alternator, and accessory drive belts for cracks, breaks or other damage.
- Water pump for coolant leaks.

NOTE: It is normal for a small amount of leakage to occur as the engine cools down and parts contract. Excessive coolant leakage may indicate the need to replace the water pump seal. Contact your engine distributor or servicing dealer for repairs.



European Air Cleaner



North American Air Cleaner

A—Dust Unloader Valve
B—Restriction Indicator Gauge

Checking Fuel Filter

Check the fuel filter daily for water or debris and drain as necessary.


IMPORTANT: Drain water into a suitable container and dispose of properly.

1. Loosen drain plug (B) at bottom of fuel filter two or three turns.
2. Loosen air bleed plug (A) two full turns on fuel filter base and drain water from bottom until fuel starts to drain out.
3. When fuel starts to drain out, hand tighten drain plug.


After draining water from the fuel filter, the filter must be primed by bleeding all air from the fuel system.

4. Operate primer lever (C) of the fuel supply pump until fuel flow is free from air bubbles.
5. Tighten bleed plug (A) securely by hand. Continue operating hand primer until pumping action is not felt. When finished, pull hand primer outward (away from engine) as far as it will go.

If the fuel system needs further bleeding of air, see BLEED FUEL SYSTEM in Service As Required Section, later in this manual.



Draining the Fuel Filter



Fuel Supply Pump Primer Lever

A—Bleed Plug
B—Drain Plug
C—Primer Lever

RG, RG34710, 5059 -19-30JAN98-5/5

Lubrication and Maintenance

SERVICING FIRE EXTINGUISHER

A fire extinguisher (A) is available from your authorized servicing dealer or engine distributor.

Read and follow the instructions which are packaged with it. The extinguisher should be inspected at least every 250 hours of engine operation or once a month. Once extinguisher is operated, no matter how long, it must be recharged. Keep record of inspections on the tag which comes with the extinguisher instruction booklet.

A—Fire Extinguisher



Service Fire Extinguisher

RW4918 -UN-15DEC88


RG, RG34710, 5062 -19-30JAN98-1/1

LUBRICATING PTO CLUTCH SHAFT BEARINGS

Apply one or two shots of John Deere Multipurpose Lubricant or equivalent at clutch drive shaft bearing fitting (B) and pilot bearing fittings (D). DO NOT over-lubricate to avoid getting oil on clutch facings.

NOTE: Location of pilot bearing fitting will depend on application. Only one fitting will be used.

- A—Release Bearing Grease Fitting
- B—Drive Shaft Bearing Fitting
- C—Lever Cross Shaft Fittings
- D—Pilot Bearing Fitting



Lubricate PTO Clutch

RG, RG34710, 5061 -19-30JAN98-1/1

SERVICING BATTERY



CAUTION: Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded **NEGATIVE (-)** battery clamp first and replace it last.



Exploding Battery

TS204 -JUN-23AUG88

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

1. On regular batteries, check electrolyte level. Fill each cell to bottom of filler neck with distilled water.

NOTE: *Low-maintenance or maintenance-free batteries should require little additional service. However, electrolyte level can be checked by cutting the center section of decal on dash-line, and removing cell plugs. If necessary, add clean, soft water to bring level to bottom of filler neck.*

2. Keep batteries clean by wiping them with a damp cloth. Keep all connections clean and tight. Remove any corrosion, and wash terminals with a solution of 1 part baking soda and 4 parts water. Tighten all connections securely.

NOTE: *Coat battery terminals and connectors with a mixture of petroleum jelly and baking soda to retard corrosion.*

3. Keep battery fully charged, especially during cold weather. If a battery charger is used, turn charger off before connecting charger to battery(ies). Attach **POSITIVE (+)** battery charger lead to **POSITIVE (+)** battery post. Then attach **NEGATIVE (-)** battery charger lead to a good ground.

HANDLING BATTERIES SAFELY



CAUTION: Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (-) battery clamp first and replace it last.



CAUTION: Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.


If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**



Exploding Battery



Sulfuric Acid

TS204 -JUN-23AUG88

TS203 -JUN-23AUG88

CHANGING ENGINE OIL AND REPLACING OIL FILTER

NOTE: Change engine oil and filter for the first time after 100 hours maximum of operation, then every 500 hours thereafter.

OILSCAN is a John Deere sampling program to help you monitor machine performance and identify potential problems before they cause serious damage. OILSCAN kits are available from your John Deere dealer. Oil samples should be taken prior to the oil change. Refer to instructions provided with kit.

1. Run engine approximately 5 minutes to warm up oil. Shut engine off.
2. Remove oil pan drain plug (arrow).

NOTE: Drain plug location may vary, depending on the application.

3. Drain crankcase oil from engine while warm.



Oil Pan Drain Plug


CD, RG34710, 5064 -19-30JAN98-1/1

4. Remove and discard oil filter (A) using a suitable filter wrench.

NOTE: Depending on engine application, oil filter may be either vertical or horizontal on either engine model.


5. Remove oil filter packing and clean filter mounting pad.

A—Oil Filter




RG11529 -UN-01DEC00

Engine Mounted Oil Filter



RG11530 -UN-01DEC00

Engine Mounted Oil Filter



RG11549 -UN-06DEC00

Engines W/Remote Oil Filter

OUOD002,0000023 -19-07DEC00-1/1

6. Oil new packing and install new filter element. Hand tighten element according to values printed on filter element. If values are not provided, tighten element approximately 3/4—1-1/4 turn after packing contacts filter housing. **DO NOT** overtighten filter element.

7. Install oil pan drain plug with a new seal when equipped and tighten using the following specifications.

Conical Plug	55 N•m (41 lb-ft)
Cylindrical Plug W/Copper Washer	70 N•m (52 lb-ft)
Cylindrical Plug W/O-Ring	50 N•m (37 lb-ft)

8. Fill engine crankcase with correct John Deere engine oil through timing gear cover opening (A) or rocker arm cover opening (B), depending on engine application. (See DIESEL ENGINE OIL in Fuels, Lubricants, and Coolant Section for determining correct engine oil.)


NOTE: Crankcase oil capacity may vary slightly. *ALWAYS* fill crankcase to top arrow or within crosshatch on dipstick, whichever is present. This should be checked after engine has run and oil has drained back into crankcase. **DO NOT** overfill.

To determine the correct oil fill quantity for your engine, see ENGINE CRANKCASE OIL FILL QUANTITIES in the Specifications Section.

IMPORTANT: Immediately after completing any oil change, crank engine for 30 seconds without permitting engine to start. This will help insure adequate lubrication to engine components before engine starts.


9. Start engine and run to check for possible leaks.

10. Stop engine and check oil level after 10 minutes. Oil level reading should be between arrows (C) or within crosshatch (D) of dipstick.



RG11541 -UN-01DEC00


Timing Gear Cover Oil Fill



RG11596 -UN-08DEC00


Rocker Arm Cover Oil Fill

RG11537 -UN-01DEC00



Correct Oil Level Within Arrows

RG11538 -UN-01DEC00



Correct Oil Level Within Crosshatch

A—Timing Gear Cover Opening
B—Rocker Arm Cover Opening
C—Arrows
D—Crosshatch

CHECKING FAN AND ALTERNATOR V-BELT TENSION

Low belt tension causes slippage resulting in excessive cover wear, burn spots, overheating, or "slip and grab", causing belt breakage.

High belt tension causes belt heating and excessive stretch, as well as damage to drive components such as pulleys and shafts. V-belts should ride on the sides of standard pulleys not on the bottom of the groove.

RG, RG34710, 5065 -19-30JAN98-1/3

Standard V-belt tension can be checked with JDG529 Tension Gauge (bold arrow) or equivalent gauge. (Gauge is available from a John Deere Dealer or Distributor)


NOTE: On engines with dual belts, check tension of front belt only.

1. Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary.
2. Using JDG529 Belt Tension Gauge, or belt tension tester (A) and straightedge (B), check tension of warm belts:
 - a. When using JDG529 Belt Tension Gauge, measure belt tension and compare with specifications on next page.
 - b. Belt deflection when using belt tension tester (A) with straightedge (B), with force applied halfway between pulleys.


Specification

Standard V-Belt with 89 N (20 lb)
force—Deflection 19 mm (3/4 in.)

A—Tension Tester
B—Straightedge



Checking Belt Tension with Tension Gauge



Checking Belt Tension with Straightedge


Continued on next page

RG, RG34710, 5065 -19-30JAN98-2/3

3. If adjustment is necessary, loosen alternator bracket cap screw (C) and nut (D) on mounting bolt. Pull alternator frame outward until belts are correctly tensioned.

IMPORTANT: Do not pry against the alternator rear frame. Do not tighten or loosen belts while they are hot.

4. Tighten alternator bracket cap screw and nut firmly.
5. After a new or used belt has run for 10 minutes, recheck belt tension.



Alternator Mounting Brackets

C—Cap Screw
D—Nut

RG7329 —UN-01DEC00

STANDARD V-BELTS

	New Belt Tension	Used Belt Tension ^a
Single Belt	578—623 N (130—140 lb force)	378—423 N (85—95 lb force)
Dual Belts	423—463 N (95—104 lb force)	378—423 N (85—95 lb force)

^aBelts are considered used after 10 minutes of operation.

RG, RG34710, 5065 —19-30JAN98-3/3


CHECKING PTO CLUTCH ADJUSTMENT

CAUTION: Never attempt to service the PTO while it is in operation. Loose clothing could get caught in moving parts; keep clothing tight against body. Use extreme care when working around the PTO.


1. Measure clutch engagement force at handle grip using a spring scale. The engagement force should be 267–311 N (60–70 lb force).

IMPORTANT: Improper adjustments of the PTO clutch may shorten clutch life. Make sure adjustments are made properly.

2. If adjustments are needed, disengage clutch and stop engine. Remove cover plate from clutch housing (shown removed).
3. Remove adjusting lock (A).
4. Turn adjusting ring (B) to adjust clutch engagement pressure.
5. Measure engagement force at clutch handle with spring scale.
6. Install lock screw and adjusting lock in clutch body splines when specified engagement pressure is achieved.
7. Tighten screw securely.
8. Recheck clutch engagement force with spring scale. Install cover plate. Disengage clutch.



Rotating Driveline



PTO Clutch Adjustment

A—Adjusting Lock
B—Adjusting Ring

TS198 –JUN-23AUG88

R27550 –JUN-14DEC88

RG, RG34710, 4068 –19-01JAN96-1/1


CHECKING ENGINE MOUNTS (GENERATOR SETS)

Engine mounting is the responsibility of the generator manufacturer. Follow manufacturer's guidelines for mounting specifications.

IMPORTANT: Use only Grade SAE 8 or higher grade of hardware for engine mounting.

1. Check the engine mounting brackets (A), vibration isolators, and mounting bolts on support frame and engine block for tightness. Tighten as necessary to recommended torque of generator manufacturer.

2. Inspect overall condition of vibration isolators, if equipped. Replace isolators if rubber has deteriorated or mounts have collapsed, as necessary.



Engine Mounting

A—Engine Mounting Brackets


DPSG,OUOD002,1578 -19-21JUN00-1/1

Lubrication & Maintenance

ADJUSTING ENGINE VALVE CLEARANCE (NEW OR REBUILT ENGINES)

Adjust engine valve clearance after the first 500 hours on new or rebuilt engines. (See CHECKING AND ADJUSTING ENGINE VALVE CLEARANCE in Lubrication and Maintenance Section or have your authorized servicing dealer or engine distributor adjust the valve clearance.)

IMPORTANT: Have valves adjusted after the first 500 hours of operation on new or rebuilt engines. Then, adjust valves at 1500 hour/24 month intervals thereafter.



T81224 -UN-07NOV88

Adjusting Valve Clearance

RG, RG34710, 5077 -19-30JAN98-1/1

Lubrication & Maintenance

LUBRICATING PTO CLUTCH INTERNAL LEVERS AND LINKAGE


CAUTION: Never attempt to service the PTO while it is in operation. Loose clothing could get caught in moving parts; keep clothing tight against body. Use extreme care when working around the PTO.

1. Remove the PTO housing cover and apply one shot of John Deere Multipurpose Lubricant or equivalent (See FUELS, LUBRICANTS, and COOLANT Section) to the pivot points (A) of each clutch linkage.
2. Apply one shot of John Deere Multipurpose Lubricant or equivalent to the two PTO release lever shaft fittings (B).

A—Pivot Points
B—Fittings



Use Extreme Care When Working Around the PTO



Lubrication Internal Parts of PTO Clutch

TS198 -JUN-23AUG88

RG6641 -JUN-18FEB93


RG, RG34710, 5068 -19-30JAN98-1/1

CLEANING CRANKCASE VENT TUBE

If you operate the engine in dusty conditions, clean the tube at shorter intervals.

1. Remove and clean crankcase vent tube (A).
2. Install the vent tube. Be sure the tube is not pinched and O-ring fits correctly in the rocker arm cover for elbow adapter. Tighten hose clamp securely.

A—Vent Tube



Crankcase Vent Tube

RG6005 -JUN-27JAN92

RG, RG34710, 5069 -19-30JAN98-1/1

CHECKING AIR INTAKE SYSTEM

IMPORTANT: The air intake system must not leak. Any leak, no matter how small, may result in engine failure due to abrasive dirt and dust entering the intake system.

1. Inspect all intake hoses (piping) for cracks. Replace as necessary.
2. Check clamps (A) on piping which connect the air cleaner, engine, and, if present, turbocharger. Tighten clamps as necessary. This will help prevent dirt from entering the air intake system through loose connections causing internal engine damage.
3. If engine has a rubber dust unloader valve (B), inspect the valve on bottom of air cleaner for cracks or plugging. Replace as necessary.


IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator is red or shows a vacuum of at least 3.5 kPa (14 in.) H₂O, is torn, or visibly dirty.

4. Test air restriction indicator (C) for proper operation. Replace indicator as necessary.


IMPORTANT: If not equipped with air restriction indicator, replace air cleaner elements at 500 Hours or 12 Months, whichever occurs first.

5. Remove and inspect primary air cleaner element. Service as necessary. (See INSPECTING PRIMARY FILTER ELEMENT and REPLACING AIR CLEANER ELEMENTS in Service As Required Section.)


A—Clamps
B—Unloader Valve
C—Restriction Indicator



Air Cleaner Clamps



North American Air Cleaner



European Air Cleaner

REPLACING FUEL FILTER ELEMENT


CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.


1. Close fuel shut-off valve at tank, if equipped.
2. Thoroughly clean fuel filter assembly and surrounding area.
3. Loosen filter drain plug (C) and air bleed plug (D). Drain fuel into a suitable container. Dispose of fuel in an environmentally safe manner.

NOTE: *Lifting up on retaining ring as it is rotated helps to get it past raised locators.*

4. Firmly grasp the retaining ring (A), lift up and rotate it clockwise 1/4 turn. Remove ring with filter element (B).
5. Save retaining ring and (if equipped) water separator bowl for reuse.
6. Remove red plug from new filter and install into removed filter to protect the environment from leaking fuel.
7. Inspect filter mounting base for cleanliness. Clean as required.



Beware of High-Pressure Fluids



Fuel Filter

- A—Retaining Ring
- B—Filter Element
- C—Filter Drain Plug
- D—Air Bleed Plug


X9811 -UN-23AUG88

RG11543 -UN-01DEC00

8. Inspect condition of dust seal (C). Replace if necessary. Install dust seal as shown.

NOTE: Proper installation is indicated when a "click" is heard and a release of pressure on the ring is felt.

9. Align keys on filter element with slots in filter base, then tighten retaining ring counterclockwise 1/4 turn until it "snaps" into the detent. DO NOT overtighten.
10. If equipped with water separator, remove water separator bowl from removed filter element. Drain and clean separator bowl. Dry with compressed air. Install water separator bowl onto new element. Tighten securely.
11. Leave fuel shut-off valve open and bleed the fuel system. (See BLEED FUEL SYSTEM in Service As Required Section.) Tighten bleed plug.



Fuel Filter Dust Seal Installation

A—Correct Installation
B—Incorrect Installation
C—Seal

RG9187 —JUN-01DEC00

RG, RG34710, 5071 —19-30JAN98-2/2

CHECKING COOLING SYSTEM



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head to allow air to escape when filling system. Retighten fitting when all the air has been expelled.

1. Check entire cooling system for leaks. Tighten all clamps securely.
2. Thoroughly inspect all cooling system hoses. Replace hoses when hardened, softened, or cracked.
3. If coolant must be added, use mixture as recommended in Fuels, Lubricants and Coolant section.



Beware of Pressurized Fluids

TS281 -JUN-23AUG88

RG, RG34710, 5073 -19-30JAN98-1/1

TESTING DIESEL ENGINE COOLANT

Maintaining adequate concentrations of glycol and inhibiting additives in the coolant is critical to protect the engine and cooling system against freezing, corrosion, and cylinder liner erosion and pitting.

Test the coolant solution at intervals of 12 months or less and whenever excessive coolant is lost through leaks or overheating.

Coolant Test Strips

Coolant test strips are available from your John Deere dealer. These test strips provide a simple, effective method to check the freeze point and additive levels of your engine coolant.

Compare the results to the supplemental coolant additive (SCA) chart to determine the amount of inhibiting additives in your coolant and whether more John Deere COOLANT CONDITIONER should be added.

COOLSCAN

For a more thorough evaluation of your coolant, perform a COOLSCAN analysis. See your John Deere dealer for information about COOLSCAN.

DX,COOL9 -19-17FEB99-1/1

REPLENISHING SUPPLEMENTAL COOLANT ADDITIVES (SCAs) BETWEEN COOLANT CHANGES

IMPORTANT: Do not add supplemental coolant additives when the cooling system is drained and refilled with John Deere COOL-GARD®

NOTE: If system is to be filled with coolant that does not contain SCAs, the coolant must be precharged. Determine the total system capacity and premix with 3% John Deere Coolant Conditioner.


Through time and use, the concentration of coolant additives is gradually depleted during engine operation. Periodic replenishment of inhibitors is required, even when John Deere COOL-GARD® is used. The cooling system must be recharged with additional supplemental coolant additives available in the form of liquid coolant conditioner.

Maintaining the correct coolant conditioner concentration (SCAs) and freeze point is essential in your cooling system to protect against rust, liner pitting and corrosion, and freeze-ups due to incorrect coolant dilution.


John Deere LIQUID COOLANT CONDITIONER is recommended as a supplemental coolant additive in John Deere engines.

DO NOT mix one brand of SCA with a different brand.

Test the coolant solution at 500 hours or 12 months of operation using either John Deere coolant test strips or a COOLSCAN® analysis. If a COOLSCAN® analysis is not available, recharge the system per instructions printed on label of John Deere Liquid Coolant Conditioner.



Radiator Coolant Check



JTO7298 Coolant/Battery Tester

COOL-GARD is a registered trademark of Deere & Company
COOLSCAN is a registered trademark of Deere & Company

Continued on next page

DPSG,OUOD002,1921 -19-12DEC00-1/2

IMPORTANT: ALWAYS maintain coolant at correct level and concentration. DO NOT operate engine without coolant even for a few minutes.

If frequent coolant makeup is required, the glycol concentration should be checked with JTO7298 Coolant/Battery Tester to ensure that the desired freeze point is maintained. Follow manufacturer's instructions provided with Coolant/Battery Tester.

Add the manufacturer's recommended concentration of supplemental coolant additive. DO NOT add more than the recommended amount.


The use of non-recommended supplemental coolant additives may result in additive drop-out and gelation of the coolant.

If other coolants are used, consult the coolant supplier and follow the manufacturer's recommendation for use of supplemental coolant additives.

See DIESEL ENGINE COOLANTS AND SUPPLEMENTAL ADDITIVE INFORMATION for proper mixing of coolant ingredients before adding to the cooling system.


DPSG,OUOD002,1921 -19-12DEC00-2/2

PRESSURE TESTING COOLING SYSTEM



Pressure Testing Radiator Cap

RG6657 -JUN-20JAN93



Pressure Testing Cooling System

RG6658 -JUN-20JAN93

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

Test Radiator Cap

1. Remove radiator cap and attach to D05104ST Tester as shown.
2. Pressurize cap to 70 kPa (0.7 bar) (10 psi)¹. Gauge should hold pressure for 10 seconds within the normal range if cap is acceptable.

If gauge does not hold pressure, replace radiator cap.

3. Remove the cap from gauge, turn it 180°, and retest cap. This will verify that the first measurement was accurate.

Test Cooling System

NOTE: Engine should be warmed up to test overall cooling system.

1. Allow engine to cool, then carefully remove radiator cap.
2. Fill radiator with coolant to the normal operating level.

IMPORTANT: DO NOT apply excessive pressure to cooling system, doing so may damage radiator and hoses.

3. Connect gauge and adapter to radiator filler neck. Pressurize cooling system to 70 kPa (0.7 bar) (10 psi)¹.
4. With pressure applied, check all cooling system hose connections, radiator, and overall engine for leaks.

If leakage is detected, correct as necessary and pressure test system again.

If no leakage is detected, but the gauge indicated a drop in pressure, coolant may be leaking internally within the system or at the block-to-head gasket. Have your servicing dealer or distributor correct this problem immediately.

¹Test pressures recommended are for all Deere OEM cooling systems. On specific vehicle applications, test cooling system and pressure cap according to the recommended pressure for that vehicle.

CHECKING AND ADJUSTING ENGINE VALVE CLEARANCE

NOTE: Adjust engine valve clearance after the first 500 hours of engine operation and then at the normal 1500 Hour/24 Month interval thereafter.

If desired, have your authorized servicing dealer or engine distributor adjust the engine valve clearance.



CAUTION: To prevent accidental starting of engine while performing valve adjustments, always disconnect **NEGATIVE (-)** battery terminal.


IMPORTANT: Engine valve clearance **MUST BE** checked and adjusted with engine **COLD**.

1. Remove rocker arm cover and crankcase ventilator tube.

IMPORTANT: Visually inspect contact surfaces of wear caps and rocker arm wear pads. Check all parts for excessive wear, breakage, or cracks. Replace parts that show visible damage.

Rocker arms that exhibit excessive valve clearance should be inspected more thoroughly to identify damaged parts.

2. Remove plastic plugs or cover plate from flywheel housing timing holes (A).



Flywheel Housing Timing Holes

A—Timing Holes

Continued on next page

RG, RG34710, 5067 -19-30JAN98-1/3

3. Using JDE83 Engine Rotation Tool and JDE81-4 Timing Pin, rotate engine in running direction (clockwise viewed from front) until Number 1 (front) cylinder is at Top Dead Center (TDC) Compression stroke. Insert timing pin in flywheel.

If Number 1 cylinder rocker arms are loose, the engine is at Number 1 "TDC-Compression".

If Number 1 cylinder rocker arms are not loose, rotate engine one full revolution (360°) to Number 1 "TDC-Compression".


NOTE: Firing order is 1-2-3.

4. With engine lock-pinned at "TDC" of Number 1 piston's compression stroke (B), check valve clearance using a feeler gauge on Number 1 and 2 exhaust valves and Number 1 and 3 intake valves.


Specification

Intake Valve Clearance Checking (Rocker Arm-to-Valve Tip) (Engine Cold)—Specification—	
Clearance	0.31—0.38 mm (0.012—0.015 in.)
Exhaust Valve Clearance Checking (Rocker Arm-to-Valve Tip) (Engine Cold)—	
Specification—Clearance	0.41—0.48 mm (0.016—0.019 in.)

5. Rotate flywheel 360 degrees and lock Number 1 piston at "TDC" exhaust stroke (C).
6. Check valve clearance on Number 3 exhaust valve and Number 2 intake valve.
7. If valves need adjusting, use following valve clearance adjustment procedure and specifications. Loosen the locknut on rocker arm adjusting screw. Turn adjusting screw until feeler gauge slips with a slight drag. Hold the adjusting screw from turning with screwdriver and tighten locknut to specifications. Recheck clearance again after tightening locknut. Readjust clearance as necessary.



Checking Valve Clearance



Valve Adjusting Order

A—Front of Engine
B—Number 1 Piston at TDC Compression Stroke
C—Number 1 Piston at TDC Exhaust Stroke
E—Exhaust Valve
I—Intake Valve

Specification

Intake Valve Clearance
Adjustment (Rocker Arm-to-Valve
Tip) (Engine Cold)—
Specification—Clearance 0.36 mm (0.014 in.)
Exhaust Valve Clearance
Adjustment (Rocker Arm-to-Valve
Tip) (Engine Cold)—
Specification—Clearance 0.46 mm (0.018 in.)
Rocker Arm Adjusting Screw Jam
Nut—Specification—Torque 27 N•m (20 lb-ft)

8. Replace rocker arm cover and crankcase vent tube.

RG, RG34710, 5067 -19-30JAN98-3/3


ADJUSTING VARIABLE SPEED (DROOP) ON GENERATOR SET ENGINES (STANADYNE INJECTION PUMPS ONLY)



CAUTION: Statutes providing severe penalties for tampering with emissions controls may apply at the user's location.


1. Warm engine to normal operating temperature.
2. If necessary, disconnect throttle linkage or cable.
3. Run engine at fast idle. Check and adjust fast idle speed when necessary.
4. Apply full load.
5. Check power. Adjust with knob or screw (A) if needed.
6. Remove load.
7. Check and adjust fast idle if knob or screw (A) has been turned.
8. Repeat procedure until both the engine power and fast idle speed are correct.
9. Connect throttle linkage if previously removed.

A—Screw



Droop Adjusting Knob

T86735 -UN-23FEB89



Droop Adjusting Screw

RG8418 -UN-01DEC00

RG, RG34710, 5076 -19-30JAN98-1/1

FLUSHING AND REFILLING COOLING SYSTEM



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

NOTE: Drain the initial factory fill engine coolant after the first 1500 hours or 24 months of operation. Subsequent drain intervals are determined by the coolant used for service.

When John Deere COOL-GARD® is used, the drain interval is 3000 hours or 36 months. The drain interval may be extended to 5000 hours or 60 months of operation **provided that the coolant is tested annually AND additives are replenished as needed, by adding a supplemental cooling additive (SCA).**

If COOL-GARD® is not used, the drain interval is reduced to 1500 hours or 24 months of operation.

Drain old coolant, remove thermostat, flush the entire cooling system, install thermostat, and fill with recommended clean coolant. For correct coolant mixture, refer to Fuels, Lubricants and Coolant section.

Perform these procedures as follows:

1. Pressure test entire cooling system and pressure cap if not previously done. (See PRESSURE TESTING COOLING SYSTEM, earlier in this section.)
2. Slowly open the engine cooling system filler cap or radiator cap to relieve pressure and allow coolant to drain faster.



Beware of High Pressure Fluids

TS281 -JUN-23AUG88

3. Open engine block drain valve or plug (A) on left side of engine. Drain all coolant from engine block.
4. Open radiator drain valve. Drain all coolant from radiator.
5. Remove thermostat at this time, if not previously done. Install cover (B) (without thermostat) and tighten cap screws to specification.


Specification

Capscrews—Torque..... 47 N•m (35 lb ft)

6. Test thermostat opening temperature. (See TEST THERMOSTAT OPENING TEMPERATURE following in this Section.)
7. Close all drain valves after coolant has drained.


CAUTION: Do not run engine longer than 5 minutes (at low idle) with water as coolant. Doing so may cause engine to overheat which may cause burns when water is draining.

8. Fill the cooling system with clean water. Run the engine about 5 minutes at low idle to stir up possible rust or sediment.
9. Stop engine, pull off lower radiator hose and remove radiator cap to immediately drain the water from the system before rust and sediment settle.
10. After draining water, close drain valves. Install radiator cap, radiator hose and clamp. Fill the cooling system with clean water and a heavy duty cooling system cleaner such as FLEETGUARD® RESTORE™ or RESTORE PLUS™. Follow manufacturer's directions on label.



RG7315 -UN-01DEC00

Engine Block Drain Valve



RG11597 -UN-08DEC00

Thermostat Housing

A—Plug
B—Cover

FLEETGUARD is a trademark of Cummins Engine Company, Inc.
RESTORE is a trademark of Fleetguard Inc.
RESTORE PLUS is a trademark of Fleetguard Inc.

Continued on next page

RG, RG34710, 5079 -19-30JAN98-2/3

11. After cleaning the cooling system, drain cleaner and fill with water to flush the system. Run the engine about 5 minutes, remove radiator cap and pull off lower radiator hose, immediately draining out flushing water.

IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head to allow air to escape when filling system. Retighten fitting when all the air has been expelled.

12. Close all drain valves on engine and radiator. Install lower radiator hose and tighten clamp.


NOTE: Install thermostat with jiggle wire (A) at top position.

13. Install thermostat and cover using a new gasket. Tighten cap screws to specification.

Specification

Capscrews—Torque 47 N•m (35 lb ft)

14. Add coolant to radiator until coolant touches bottom of filler neck¹. (See ADDING COOLANT in Service As Required Section.)
15. Run engine until it reaches operating temperature. This mixes the solution uniformly and circulates it through the entire system. The normal engine coolant temperature range is 82°–94°C (180°–202°F).
16. After running engine, check coolant level and entire cooling system for leaks.



Jiggle Wire

A—Jiggle Wire

RG11605 -JUN-24JAN01

¹Cooling system capacity for the Saran-sourced 3029 L engine factory generator set package is 12 L (11.5 qt). Refer to OEM manufacturer for capacities of cooling systems not supplied by John Deere.

TESTING THERMOSTAT OPENING TEMPERATURE

1. Remove thermostat.
2. Visually inspect thermostat for corrosion or damage.

CAUTION: DO NOT allow thermostat or thermometer to rest against the side or bottom of container when heating water. Either may rupture if overheated.


3. Suspend thermostat and a thermometer in a container of water.
4. Stir the water as it heats. Observe opening action of thermostat and compare temperatures with specification given in chart below.

NOTE: Due to varying tolerances of different suppliers, initial opening and full open temperatures may vary slightly from specified temperatures.

THERMOSTAT TEST SPECIFICATIONS

Rating	Initial Opening (Range)	Full Open (Nominal)
82°C (180°F)	80-84°C (175-182°F)	94°C (202°F)

5. Remove thermostat and observe its closing action as it cools. In ambient air the thermostat should close completely. Closing action should be smooth and slow.
6. Replace thermostat if opening temperature is not within specification.



Testing Thermostats


RG5971 -UN-23NOV97

RG, RG34710, 5083 -19-30JAN98-1/1

Service As Required

ADDITIONAL SERVICE INFORMATION

This is not a detailed service manual. If you want more detailed service information, see John Deere Service Literature Available later in this manual to order the Component Technical Manuals for "Repair" and "Operation and Diagnosis".



John Deere Service Manuals


RG, RG34710, 5080 -19-30JAN98-1/1

DO NOT MODIFY FUEL SYSTEM

IMPORTANT: Modification or alteration of the injection pump, the injection pump timing, or the fuel injectors in ways not recommended by the manufacturer will terminate the warranty obligation to the purchaser.

In addition, tampering with fuel system which alters emission-related equipment on engines may result in fines or other penalties, per EPA regulations or other local emission laws.

Do not attempt to service injection pump or fuel injectors yourself. Special training and special tools are required. (See your authorized servicing dealer or engine distributor.)



Fuel Injection Pump

RG, RG34710, 5081 -19-30JAN98-1/1

ADDING COOLANT



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Never pour cold liquid into a hot engine, as it may crack cylinder head or block. NEVER operate engine without coolant.

John Deere TY15161 Cooling System Sealer may be added to the radiator to stop leaks on a temporary or emergency basis only. DO NOT use any other stop-leak additives in the cooling system. Leaks should be permanently repaired as quickly as possible.


Air must be expelled from cooling system when coolant is added.

1. Loosen temperature sending unit fitting (A) at rear of cylinder head to allow air to escape when filling system.


IMPORTANT: When adding coolant to the system, use the appropriate coolant solution. (See **ENGINE COOLANT SPECIFICATIONS** in Fuels, Lubricants, and Coolant Section for mixing of coolant ingredients before adding to cooling system.)

Do not overfill cooling system. A pressurized system needs space for heat expansion without overflowing at top of radiator.

2. Fill until coolant level touches bottom of radiator filler neck.
3. Tighten fitting when air has been expelled from system.



High Pressure Fluids



Sending Unit Fitting

A—Sending Unit Fitting

TS281 -JUN-23AUG88


RG11607 -JUN-25JAN01

BLEEDING THE FUEL SYSTEM



CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.




Keep Skin Away from High Pressure Fluids

X9811 -UN-23AUG88

Whenever the fuel system has been opened up for service (lines disconnected or filters removed), it will be necessary to bleed air from the system.


1. Loosen the air bleed vent screw (A) two full turns.
2. On mechanical supply pumps, operate supply pump primer lever (B) until fuel flow is free from air bubbles.
3. On electric supply pumps, turn key switch to "ON" position until fuel flow is free from air bubbles.
4. Tighten bleed plug securely by hand. Continue operating hand primer until pumping action is not felt. When finished, pull hand primer outward (away from engine) as far as it will go.
5. Start engine and check for leaks.

If engine will not start, it may be necessary to bleed air from fuel system at fuel injection pump or injection nozzles as explained next.



Fuel Filter Air Bleed Vent Screw

RG11544 -UN-01DEC00



Fuel Supply Pump Primer Lever

RG11545 -UN-01DEC00

A—Vent Screw
B—Primer Lever


At Fuel Injection Pump

1. Slightly loosen fuel supply line connector (A) at injection pump.
2. On mechanical supply pumps, operate fuel supply pump primer lever until fuel, without air bubbles, flows from fuel line connection.
3. On electric supply pumps, turn key switch to "ON" position until fuel, without air bubbles, flows from fuel line connection.
4. Tighten fuel supply line connector to specification.

Specification

Connector—Torque 16 N•m (12 lb ft)

5. Leave hand primer in the outward position away from cylinder block.



RG7316 -UN-01DEC00

Fuel Supply Line Connector at Injection Pump

A—Connector

RG, RG34710, 5084 -19-30JAN98-2/3

At Fuel Injection Nozzles

1. Move the speed control lever to half throttle position. On engines equipped with electronic fuel shut-off solenoid, energize solenoid.
2. Using two open-end wrenches, loosen fuel line connection at injection nozzle.
3. Crank engine over with starting motor, (but do not start engine), until fuel free from air bubbles flows out of loosened connection. Tighten connection to specification.

Specification

Connection—Torque..... 27 N•m (20 lb ft)

4. Repeat procedure for remaining injection nozzles (if necessary) until all air has been removed from fuel system.

If engine still will not start, see your authorized servicing dealer or engine distributor.



T92924 -UN-01NOV88

Bleeding Fuel System at Injection Nozzle

RG, RG34710, 5084 -19-30JAN98-3/3

REPLACING AIR CLEANER FILTER ELEMENTS

IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of at least 3.5 kPa (14 in.) of H₂O, is torn, or visibly dirty.

NOTE: This procedure applies to John Deere air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.

North American Air Cleaners


1. Remove wing nut and remove canister cover shown in small illustration inset.
2. Remove wing nut (A) and remove primary element (B) from canister.
3. Thoroughly clean all dirt from inside canister.

NOTE: Some engines may have a dust unloader valve (C) on the air cleaner. If equipped, squeeze valve tip to release any trapped dirt particles.


IMPORTANT: Remove secondary (safety) element (E) **ONLY** for replacement. **DO NOT** attempt to clean, wash, or reuse secondary element. Replacement of secondary element is usually necessary **ONLY** when primary element has a hole in it.

4. To replace secondary element, remove retaining nut (D) and secondary element (E). Immediately replace secondary element with new element to prevent dust from entering air intake system.


5. Install new primary element and tighten wing nut securely. Install cover assembly and tighten retaining wing nut securely.



Air Cleaner Primary Element (North American)



Dust Unloader Valve



Air Cleaner Secondary Element

- A—Wing Nut
- B—Primary Element
- C—Unloader Valve
- D—Retaining Nut
- E—Secondary Element

Continued on next page

DPSG,OUOD002,1580 -19-21JUN00-1/2


IMPORTANT: Whenever the air cleaner has been serviced or had cover removed, **ALWAYS** fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.

6. If equipped, fully depress air restriction indicator reset button and release to reset indicator.

On European Sourced Air Cleaner Kits:

Clean filter element when air restriction indicator (A) is red. Replace filter element every 6 cleanings or once every 12 months.

1. Remove cover (B).
2. Remove filter element (C).
3. Thoroughly clean all dirt from inside filter housing.
4. Squeeze dust unloader valve (D) to remove dust deposits. If clogged, remove and clean the dust unloader valve. Replace if damaged.
5. Clean filter element using compressed air.
6. Reinstall the filter element and cover.
7. Depress air restriction indicator (A) button and release to reset indicator.



Air Cleaner Components (European Sourced)

- A—Restriction Indicator
- B—Cover
- C—Filter Element
- D—Dust Unloader Valve


INSPECTING PRIMARY FILTER ELEMENT

Inspect filter to determine if it is practical to clean or for damage after cleaning filter.

1. Hold a bright light (A) inside element and check carefully for holes. Discard any element which shows the smallest hole or rupture.
2. Be sure outer screen (B) is not dented. Vibration would quickly wear a hole in filter.
3. Be sure filter gasket (C) is in good condition. If gasket is damaged or missing, replace element.

IMPORTANT: Air cleaner MUST BE DRY before storing in plastic bag.

If the filter is to be stored for later use, place it in a plastic bag to protect it from dust and damage.



Inspecting Primary Air Filter Element

A—Light
B—Outer Screen
C—Gasket

RG, RG34710, 3598 -19-30AUG96-1/1

CLEANING PRIMARY FILTER ELEMENT

IMPORTANT: Always replace secondary (safety) filter elements. DO NOT attempt to clean them.

Do not blow air from outside portion of filter with air nozzle. Wear safety glasses and remove bystanders.

1. Gently pat sides of element with palm of hand to loosen dirt. DO NOT tap element against a hard surface.

Continued on next page

RG, RG34710, 3598 -19-30AUG96-1/2



CAUTION: Only a special air cleaning gun (A) should be used. Concentrated air pressure from an ordinary air nozzle may severely damage filter element. Do not exceed 210 kPa (2.1 bar) (30 psi) when cleaning filter element.

2. Insert the cleaning gun into element, hold air nozzle about 25.4 mm (1.0 in.) from perforated metal retainer. Force air through filter from inside to outside and move air gun up and down pleats to remove as much dirt as possible.
3. Repeat steps 1 and 2 to remove additional dirt.
4. Inspect element for damage after cleaning. Replace element if any damage is found.



RG11065 -UN-26JUN00

Cleaning Primary Element

A—Air Cleaning Gun

RG, RG34710, 3599 -19-30AUG96-2/2

ELEMENT STORAGE

IMPORTANT: Air cleaner element **MUST BE DRY** before storing in plastic bag.

Seal element in a plastic bag and store in shipping container to protect against dust and damage.

RG, RG34710, 3601 -19-30AUG96-1/1

REPLACE FAN AND ALTERNATOR BELTS

Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary. (See CHECKING FAN AND ALTERNATOR V-BELT TENSION in Lubrication and Maintenance Section.)

RG, RG34710, 5086 -19-30JAN98-1/1

POWER TAKE-OFF (PTO) CLUTCH

CAUTION: Entanglement in rotating driveline can cause serious injury or death. Keep shield on PTO drive shaft (A) between the clutch housing and the engine driven equipment at all times during engine operation. Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments.


Proper performance of the power take-off unit will be related to the care it is given. Lubricate it periodically and keep the clutch properly adjusted. (See LUBRICATION AND MAINTENANCE Section.)

If the power take-off does not work properly after adjustment and lubrication, contact your authorized servicing dealer or engine distributor.

A—PTO Driveshaft



Beware of Rotating Drivelines



PTO Drive Shaft

RG, RG34710, 5087 -19-30JAN98-1/1

TS198 -UN-23AUG88

RG4693 -UN-14DEC88

CHECKING FUSES

The following instructions apply to engines equipped with a John Deere instrument panel.

On North American Instrument Panels:

1. Check the fuse (A) and replace as necessary with an equivalent 14-amp fuse.



North American Instrument Panel

RG11548 -UN-01DEC00

Continued on next page

OUOD013,0000003 -19-28NOV00-1/3


On AEZ Instrument Panels (Except North America):

1. Remove the four cap screws (B) holding the instrument panel board.
2. Open fuse holder (C).
3. Replace as necessary with an equivalent 16-amp fuse (D).

IMPORTANT: Always replace a blown fuse with a fuse of the same amperage.

4. Reinstall the instrument panel board.

B—Cap Screws
C—Fuse Holder
D—16-Amp Fuse




AEZ Instrument Panel (Except North America)

RG8149 -UN-01DEC00

OUOD013,0000003 -19-28NOV00-2/3

On VDO Instrument Panels (Except North America):

5. The fuse is located on the electronic control card inside the panel's rear access cover. Remove cover and check fuse. If defective, replace with a 10 amp fuse. There is a spare fuse available on the card in the "SPARE" terminal.



VDO Instrument Panel (Except North America)

RG10606A -UN-19JUN00

OUOD013,0000003 -19-28NOV00-3/3

Troubleshooting

GENERAL TROUBLESHOOTING INFORMATION

Troubleshooting engine problems can be difficult. An engine wiring diagram is provided in this section to help isolate electrical problems on power units using John Deere wiring harness and instrument (gauge) panel.


Later in this section is a list of possible engine problems that may be encountered accompanied by possible causes and corrections. The illustrated diagrams and troubleshooting information are of a general nature, final design of the overall system for your engine application may be different. See your engine distributor or servicing dealer if you are in doubt.

A reliable program for troubleshooting engine problems should include the following basic diagnostic thought process:

- Know the engine and all related systems.
- Study the problem thoroughly.
- Relate the symptoms to your knowledge of engine and systems.
- Diagnose the problem starting with the easiest things first.
- Double-check before beginning the disassembly.
- Determine cause and make a thorough repair.
- After making repairs, operate the engine under normal conditions to verify that the problem and cause were corrected.

RG, RG34710, 5089 -19-30JAN98-1/1

NORTH AMERICAN WIRING DIAGRAM



North American Wiring Diagram

Continued on next page

RG, RG34710, 5091 -19-30JAN98-1/2

A1—Speed Control Unit	H2—Oil Pressure Indicator Lamp	P6—Ammeter	Y2—Fuel Shut-Off Solenoid
B1—Magnetic Speed Sensor	K1—Starter Relay	R1—Resistor (48 ohm)	BLK—Black
B2—Coolant Temperature Sensor	M1—Starter Motor	S1—Key Switch	BLU—Blue
B3—Oil Pressure Sensor	P1—Coolant Temperature Gauge	S2—Magnetic Safety Switch— North American , Auto Override Module— European (Saran)	BRN—Brown
F1—Starting Circuit Fuse (14 Amp)	P2—Oil Pressure Gauge	W1—Ground on K1 Starter Relay Mounting Stud	DK BLU—Dark Blue
F3—Fuse (Early Models) ¹	P3—Crankcase Oil Level Switch/Gauge	Y1—Starter Solenoid	GRN—Green
G1—Battery	P4—Tachometer ¹		ORG—Orange
G2—Alternator	P5—Hourmeter ²		PUR—Purple
H1—Coolant Temperature Indicator Light			RED—Red
			YEL—Yellow

¹P4 tachometer has a built-in hourmeter. On some earlier engines, a separate hourmeter (P5) and fuse (F3) are used.

²P4 tachometer has a built-in hourmeter. On some engines, a separate hourmeter (P5) and fuse (F3) are used.

RG, RG34710, 5091 -19-30JAN98-2/2

ENGINE TROUBLESHOOTING

Symptom	Problem	Solution
Engine Will Not Crank	Weak battery	Replace battery.
	Corroded or loose battery connections	Clean battery terminals and connections.
	Defective main switch or start safety switch	Repair switch as required.
	Starter solenoid defective	Replace solenoid.
	Starter defective	Replace starter.
Engine cranks but will not start	Incorrect starting procedure.	Verify correct starting procedure.
	No fuel.	Check fuel in tank and manual shut-off valve.
	Exhaust restricted.	Check and correct exhaust restriction.
	Fuel filter plugged or full of water.	Replace fuel filter or drain water from filter.
	Injection pump not getting fuel or air in fuel system.	Check fuel flow at supply pump or bleed fuel system.
	Faulty injection pump or nozzles.	Consult authorized diesel repair station for repair or replacement.

Continued on next page

RG, RG34710, 5092 -19-30JAN98-1/8

Symptom	Problem	Solution
Engine hard to start or will not start	Engine starting under load.	Disengage PTO.
	Improper starting procedure.	Review starting procedure.
	No fuel.	Check fuel tank.
	Air in fuel line.	Bleed fuel line.
	Cold weather.	Use cold weather starting aids.
	Slow starter speed.	See "Starter Cranks Slowly".
	Crankcase oil too heavy.	Use oil of proper viscosity.
	Improper type of fuel.	Consult fuel supplier; use proper type fuel for operating conditions.
	Water, dirt, or air in fuel system.	Drain, flush, fill, and bleed system.
	Clogged fuel filter.	Replace filter element.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Injection pump shut-off not reset.	Turn key switch to "OFF" then to "ON".
	Poor fuel quality	Drain fuel and replace with quality fuel of the proper grade.
	Slow cranking speed	Check for problem in the charging/starting system.
Engine knocks	Low engine oil level.	Add oil to engine crankcase.
	Injection pump out of time.	See your authorized servicing dealer or engine distributor.
	Low coolant temperature.	Remove and check thermostat.
	Engine overheating.	See "Engine Overheats".

Continued on next page

RG, RG34710, 5092 -19-30JAN98-2/8

Symptom	Problem	Solution
Engine runs irregularly or stalls frequently	Low coolant temperature.	Remove and check thermostat.
	Clogged fuel filter.	Replace fuel filter element.
	Water, dirt, or air in fuel system.	Drain, flush, fill, and bleed system.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
Below normal engine temperature	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check gauge, sender, and connections.
Continued on next page		RG, RG34710, 5092 -19-30JAN98-3/8

Symptom	Problem	Solution
Lack of power	Engine overloaded.	Reduce load.
	Intake air restriction.	Service air cleaner.
	Clogged fuel filter.	Replace filter elements.
	Improper type of fuel.	Use proper fuel.
	Poor fuel quality	Drain fuel and replace with quality fuel of the proper grade.
	Overheated engine.	See "Engine Overheats".
	Below normal engine temperature.	Remove and check thermostat.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Injection pump out of time.	See your authorized servicing dealer or engine distributor.
	Turbocharger not functioning. (Turbocharged engines only.)	See your authorized servicing dealer or engine distributor.
	Leaking exhaust manifold gasket.	See your authorized servicing dealer or engine distributor.
	Defective aneroid control line.	See your authorized servicing dealer or engine distributor.
	Restricted fuel hose.	Clean or replace fuel hose.
Engine idles poorly	Low fast idle speed.	See your authorized servicing dealer or engine distributor.
	Poor fuel quality	Drain fuel and replace with quality fuel of the proper grade.
	Engine out of time	See your authorized servicing dealer or engine distributor.
	Air leak on suction side of air intake system.	Check hose and pipe connections for tightness; repair as required.

Continued on next page

RG, RG34710, 5092 -19-30JAN98-4/8

Symptom	Problem	Solution
Low oil pressure	Low oil level.	Add oil.
	Improper type of oil.	Drain, fill crankcase with oil of proper viscosity and quality.
High oil consumption	Crankcase oil too light.	Use proper viscosity oil.
	Oil leaks.	Check for leaks in lines, gaskets, and drain plug.
	Restricted crankcase vent tube.	Clean vent tube.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
Engine emits white exhaust smoke	Improper type of fuel.	Use proper fuel.
	Low engine temperature.	Warm up engine to normal operating temperature.
	Defective thermostat.	Remove and check thermostat.
	Defective injection nozzles.	See your authorized servicing dealer or engine distributor.
	Engine out of time (retarded).	See your authorized servicing dealer or engine distributor.
	Coolant entering combustion chamber (failed cylinder head gasket or cracked cylinder head)	Repair or replace as required. See your John Deere engine distributor or servicing dealer.
	Engine compression too low	Determine cause of low compression and repair as required. See your John Deere engine distributor or servicing dealer.

Continued on next page

RG, RG34710, 5092 -19-30JAN98-5/8

Symptom	Problem	Solution
Engine emits black or gray exhaust smoke	Improper type of fuel.	Use proper fuel.
	Clogged or dirty air cleaner.	Service air cleaner.
	Engine overloaded.	Reduce load.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.
	Turbocharger not functioning.	See your authorized servicing dealer or engine distributor.
	Engine burning oil	See LUBRICATION SYSTEM TROUBLESHOOTING, later in this section.
	Defective muffler/exhaust piping (causing back-pressure)	Replace muffler or defective piping.
Engine Overheats	Engine overloaded.	Reduce load.
	Low coolant level.	Fill radiator to proper level, check radiator and hoses for loose connections or leaks.
	Faulty radiator cap.	Have technician check.
	Loose or defective fan belts.	Adjust belt tension. Replace as required.
	Low engine oil level.	Check oil level. Add oil as required.
	Cooling system needs flushing.	Flush cooling system.
	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check coolant temperature with thermometer and replace, if necessary.
	Incorrect grade of fuel.	Use correct grade of fuel.

Continued on next page

RG, RG34710, 5092 -19-30JAN98-6/8

Symptom	Problem	Solution
High fuel consumption	Improper type of fuel.	Use proper type of fuel.
	Clogged or dirty air cleaner.	Service air cleaner.
	Engine overloaded.	Reduce load.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
	Low engine temperature.	Check thermostat.
	Compression too low.	Determine cause of low compression and repair as needed.
Fuel in Oil	Cracked cylinder head	Locate crack, repair/replace components as required. See your John Deere engine distributor or servicing dealer.

Continued on next page

RG, RG34710, 5092 -19-30JAN98-7/8

Symptom	Problem	Solution
Abnormal Engine Noise	Worn main or connecting rod bearings	Determine bearing clearance. See your John Deere engine distributor or servicing dealer.
	Excessive crankshaft end play	Check crankshaft end play. See your John Deere engine distributor or servicing dealer.
	Loose main bearing caps	Check bearing clearance; replace bearings and bearing cap screws as required. See your John Deere engine distributor or servicing dealer.
	Worn connecting rod bushings and piston pins	Inspect piston pins and bushings. See your John Deere engine distributor or servicing dealer.
	Scored pistons	Inspect pistons. See your John Deere engine distributor or servicing dealer.
	Worn timing gears or excess backlash	Check timing gear back lash. See your John Deere engine distributor or servicing dealer.
	Excessive valve clearance	Check and adjust valve clearance. See your John Deere engine distributor or servicing dealer.
	Worn camshaft lobes	Inspect camshaft. See your John Deere engine distributor or servicing dealer.
	Worn rocker arm shaft(s)	Inspect rocker arm shafts. See your John Deere engine distributor or servicing dealer.
	Insufficient engine lubrication	See LUBRICATION SYSTEM TROUBLESHOOTING, later in this section.
	Turbocharger noise	See AIR INTAKE SYSTEM TROUBLESHOOTING, later in this section.

ELECTRICAL TROUBLESHOOTING

Symptom	Problem	Solution
Undercharged system	Excessive electrical load from added accessories.	Remove accessories or install higher output alternator.
	Excessive engine idling.	Increase engine rpm when heavy electrical load is used.
	Poor electrical connections on battery, ground strap, starter, or alternator.	Inspect, clean and tighten as necessary.
	Defective battery.	Test battery.
	Defective alternator.	Test charging system.
Battery used too much water	Cracked battery case.	Check for moisture and replace as necessary.
	Defective battery.	Test battery.
	Battery charging rate too high.	Test charging system.
Batteries will not charge	Loose or corroded connections.	Clean and tighten connections.
	Sulfated or worn-out batteries.	See your authorized servicing dealer or engine distributor.
	Loose or defective alternator belt.	Adjust belt tension or replace belts.
Starter will not crank	PTO engaged.	Disengage PTO.
	Loose or corroded connections.	Clean and tighten loose connections.
	Low battery output voltage.	See your authorized servicing dealer or engine distributor.
	Faulty start circuit relay.	See your authorized servicing dealer or engine distributor.
	Blown fuse.	Replace fuse.

Continued on next page

RG, RG34710, 5093 -19-30JAN98-1/2

Symptom	Problem	Solution
Starter cranks slowly	Low battery output.	See your authorized servicing dealer or engine distributor.
	Crankcase oil too heavy.	Use proper viscosity oil.
	Loose or corroded connections.	Clean and tighten loose connections.
Entire electrical system does not function	Faulty battery connection.	Clean and tighten connections.
	Sulfated or worn-out batteries.	See your authorized servicing dealer or engine distributor.
	Blown fuse.	Replace fuse.

RG, RG34710, 5093 -19-30JAN98-2/2

LUBRICATION SYSTEM TROUBLESHOOTING

Symptom	Problem	Solution
Low Oil Pressure	Low crankcase oil level	Fill crankcase to proper oil level.
	Clogged oil cooler or filter	Remove and inspect oil cooler. See your John Deere engine distributor or servicing dealer.
	Excessive oil temperature	Remove and inspect oil cooler. See your John Deere engine distributor or servicing dealer.
	Defective oil pump	Remove and inspect oil pump. See your John Deere engine distributor or servicing dealer.
	Incorrect oil	Drain crankcase and refill with correct oil.
	Oil pressure regulating valve failure	Remove and inspect oil pressure regulating valve. See your John Deere engine distributor or servicing dealer.
	Clogged oil pump screen or cracked pick-up tube	Remove oil pan and clean screen/replace pick-up tube.
High Oil Pressure	Excessive main or connecting rod bearing clearance	Determine bearing clearance. See your John Deere engine distributor or servicing dealer.
	Improper oil classification	Drain crankcase and refill with correct oil.
	Oil pressure regulating valve failure	Remove and inspect oil pressure regulating valve. See your John Deere engine distributor or servicing dealer.
	Stuck or damaged filter bypass valve	Remove and inspect filter bypass valve. See your John Deere engine distributor or servicing dealer.
	Stuck or damaged oil cooler bypass valve	Remove and inspect oil cooler bypass valve. See your John Deere engine distributor or servicing dealer.

Continued on next page

RG, RG34710, 7600 -19-30JUN97-1/3

Symptom	Problem	Solution
Excessive Oil Consumption	Too low viscosity crankcase oil	Drain crankcase and refill with correct viscosity oil.
	Crankcase oil level too high	Drain oil until oil level is correct.
	External oil leak(s)	Determine source of oil leak(s) and repair as required.
	Oil control rings worn or broken	Replace piston rings. See your John Deere engine distributor or servicing dealer.
	Scored cylinder liners or pistons	Remove and inspect cylinders and liners; replace as required. See your John Deere engine distributor or servicing dealer.
	Worn valve guides or stems	Inspect and measure valve stems and valve guides; repair as required. See your John Deere engine distributor or servicing dealer.
	Excessive oil pressure	See High Oil Pressure.
	Piston ring grooves excessively worn	Remove and inspect pistons. See your John Deere engine distributor or servicing dealer.
	Piston rings sticking in ring grooves	Remove and inspect pistons. See your John Deere engine distributor or servicing dealer.
	Insufficient piston ring tension	Remove and inspect pistons. See your John Deere engine distributor or servicing dealer.
	Piston ring gaps not staggered	Remove and inspect pistons. See your John Deere engine distributor or servicing dealer.
	Front and/or rear crankshaft oil seal faulty	Replace oil seals. See your John Deere engine distributor or servicing dealer.

Continued on next page

RG, RG34710, 7600 -19-30JUN97-2/3

Symptom	Problem	Solution
		See LOW PRESSURE SYSTEM-FUEL PRESSURE LOW TROUBLESHOOTING earlier in this section.
Fuel in Oil		See FUEL IN OIL TROUBLESHOOTING earlier in this section.
Coolant in Oil		See COOLING SYSTEM TROUBLESHOOTING later in this section.

RG, RG34710, 7600 -19-30JUN97-3/3

COOLING SYSTEM TROUBLESHOOTING

Symptom	Problem	Solution
Engine Overheats	Lack of coolant in cooling system	Fill cooling system to proper level.
	Radiator core dirty	Clean radiator as required.
	Engine overloaded	Reduce engine load.
	Too low crankcase oil level	Fill crankcase to proper oil level.
	Loose or defective fan belt	Replace fan belt as required. Check belt tensioner. (See Lubrication and Maintenance Section.)
	Defective thermostat	Test thermostat opening temperature; replace thermostat as required.
	Damaged cylinder head gasket	Replace cylinder head gasket. See your John Deere engine distributor or servicing dealer.
	Defective coolant pump	Replace coolant pump. See your John Deere engine distributor or servicing dealer.
	Defective radiator cap	Replace radiator cap as required.

Continued on next page

RG, RG34710, 7601 -19-30JUN97-1/2

Symptom	Problem	Solution
Coolant in Oil	Cylinder head gasket defective	Replace cylinder head gasket. See your John Deere engine distributor or servicing dealer.
	Cylinder head or block cracked	Locate crack, repair/replace components as required.
	Cylinder liner seals leaking	Remove and inspect cylinder liners. See your John Deere engine distributor or servicing dealer.
	Leaking oil cooler	Pressure test oil cooler; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Defective oil cooler O-rings	Remove and inspect oil cooler O-rings; replace as required. See your John Deere engine distributor or servicing dealer.
	Faulty coolant pump seal; weep hole plugged; coolant leaking through bearing	Replace coolant pump seals. See your John Deere engine distributor or servicing dealer.
Coolant Temperature Below Normal	Defective thermostat(s)	Test thermostats; replace thermostats as required.

RG, RG34710, 7601 -19-30JUN97-2/2

AIR INTAKE SYSTEM TROUBLESHOOTING

If turbocharger requires replacement, determine what caused the failure of the defective unit, and correct the condition. This will prevent an immediate repeat failure of the replacement unit.

NOTE: Turbochargers are equipped on 3029T engines only.

Symptom	Problem	Solution
Hard to Start or Will Not Start		See ENGINE TROUBLESHOOTING earlier in this section.
Engine Misfiring or Runs Irregularly		See ENGINE TROUBLESHOOTING earlier in this section.
Black or Grey Exhaust Smoke		See ENGINE TROUBLESHOOTING earlier in this section.
Lack of Engine Power		See ENGINE TROUBLESHOOTING earlier in this section.
Turbocharger "Screams"	Air leak in intake manifold.	Check intake manifold gasket and manifold; repair as required. See your John Deere engine distributor or servicing dealer.
Turbocharger Noise or Vibration <i>NOTE: Do not confuse the whine heard during run down with noise which indicates a bearing failure.</i>	Bearings not lubricated (insufficient oil pressure)	Determine cause of lack of lubrication; repair as required. See your John Deere engine distributor or servicing dealer.
	Air leak in engine intake or exhaust manifold	Check intake and exhaust manifold gaskets and manifolds; repair as required. See your John Deere engine distributor or servicing dealer.
	Improper clearance between turbine wheel and turbine housing	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Broken blades (or other wheel failures)	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.

Continued on next page

RG, RG34710, 7602 -19-30JUN97-1/3

Symptom	Problem	Solution
Oil on Turbocharger Compressor Wheel or in Compressor Housing (Oil Being Pushed or Pulled Through Center Housing)	Excessive crankcase pressure.	Determine cause of excessive crankcase pressure; repair as required. See your John Deere engine distributor or servicing dealer.
	Air intake restriction	Determine cause of intake restriction; repair as required. See your John Deere engine distributor or servicing dealer.
	Drain tube restriction	Determine cause of drain tube restriction; repair as required. See your John Deere engine distributor or servicing dealer.
Oil in Intake Manifold or Dripping from Turbocharger Housing	Excessive crankcase pressure	Determine cause of excessive crankcase pressure; repair as required. See your John Deere engine distributor or servicing dealer.
	Air intake restriction	Determine cause of intake restriction; repair as required. See your John Deere engine distributor or servicing dealer.
	Drain tube restriction	Determine cause of drain tube restriction; repair as required. See your John Deere engine distributor or servicing dealer.
	Damaged or worn housing bearings	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Imbalance of rotating assembly	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Damage to turbine or compressor wheel or blade	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Dirt or carbon build-up on wheel or blade	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.

Continued on next page

RG, RG34710, 7602 -19-30JUN97-2/3

Symptom	Problem	Solution
Turbocharger Turbine Wheel Drag	Bearing wear	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Oil starvation or insufficient lubrication	Determine cause of lack of lubrication; repair as required. See your John Deere engine distributor or servicing dealer.
	Shaft seals worn	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Carbon build-up behind turbine wheel caused by coked oil or combustion deposits	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Dirt build-up behind compressor wheel caused by air intake leaks.	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.
	Bearing seizure or dirty, worn bearings	Inspect turbocharger; repair/replace as required. See your John Deere engine distributor or servicing dealer.

RG, RG34710, 7602 -19-30JUN97-3/3

Storage

ENGINE STORAGE GUIDELINES

1. John Deere engines can be stored outside for up to three (3) months with no long term preparation IF COVERED BY WATERPROOF COVERING.
2. John Deere engines can be stored in a standard overseas shipping container for up to three (3) months with no long term preparation.
3. John Deere engines can be stored inside, warehoused, for up to six (6) months with no long term preparation.
4. John Deere engines expected to be stored more than six (6) months, long term storage preparation MUST BE taken. (See PREPARING ENGINE FOR LONG TERM STORAGE, later in this section.)
5. For John Deere engines not yet installed in machines, run a line from a container of AR41937 Nucle Oil to the fuel transfer pump intake, and another line from the fuel return manifold to the tank, so that Nucle Oil is circulated through the injection system during cranking.

RG, RG34710, 5094 -19-30JAN98-1/1

USE AR41785 ENGINE STORAGE KIT

IMPORTANT: Inhibitors can easily change to gas.
Seal or tape each opening immediately
after adding inhibitor.

See your John Deere servicing dealer or engine distributor for an AR41785 Engine Storage Kit. Closely follow instructions provided with this kit.



T85452 -UN-06DEC88

AR41785 Engine Storage Kit

RG, RG34710, 5095 -19-30JAN98-1/1

PREPARING ENGINE FOR LONG TERM STORAGE

The following storage preparations are good for long term engine storage up to one year. After that, the engine should be started, warmed up, and retreated for an extended storage period.

IMPORTANT: Any time your engine will not be used for over six (6) months, the following recommendations for storing it and removing it from storage will help to minimize corrosion and deterioration. Use the AR41785 Engine Storage Kit. Follow recommended service procedure included with storage kit.

1. Change engine oil and replace filter. Used oil will not give adequate protection. (See CHANGING ENGINE OIL AND FILTER in Lubrication and Maintenance Section.)
2. Service air cleaner. (See REPLACING AIR CLEANER FILTER ELEMENT in Service As Required Section.)
3. Draining and flushing of cooling system is not necessary if engine is to be stored only for several months. However, for extended storage periods of a year or longer, it is recommended that the cooling system be drained, flushed, and refilled. Refill with appropriate coolant. (See RECOMMENDED ENGINE COOLANT in Fuels, Lubricants, and Coolant Section and ADDING COOLANT in Service As Required Section.)
4. Drain fuel tank and add 30 ml (1 oz) of inhibitor to the fuel tank for each 15 L (4 U.S. gal) of tank capacity. Completely drain fuel filter and close fuel valve, if equipped.
5. Add 30 ml (1 oz) of inhibitor to the engine crankcase for each 0.95 L (1 qt) of crankcase oil.
6. Disconnect air intake piping from the manifold. Pour 90 ml (3 oz) of inhibitor into intake system and reconnect the piping.
7. Crank the engine several revolutions with starter (do not allow the engine to start).
8. Remove fan/alternator belt, if desired.
9. Remove and clean batteries. Store them in a cool, dry place and keep them fully charged.
10. Disengage the PTO clutch.
11. Clean the exterior of the engine with salt-free water and touchup any scratched or chipped painted surfaces with a good quality paint.
12. Coat all exposed (machined) metal surfaces with grease or corrosion inhibitor if not feasible to paint.
13. Seal all openings on engine with plastic bags and tape supplied in storage kit. Follow instructions supplied in kit.
14. Store the engine in a dry protected place. If engine must be stored outside, cover it with a waterproof canvas or other suitable protective material and use a strong waterproof tape.

RG, RG34710, 5096 -19-30JAN98-1/1

REMOVING ENGINE FROM LONG TERM STORAGE

Refer to the appropriate section for detailed services listed below or have your authorized servicing dealer or engine distributor perform services that you may not be familiar with.

IMPORTANT: DO NOT operate starter more than 30 seconds at a time. Wait at least 2 minutes for starter to cool before trying again.

1. Remove all protective coverings from engine. Unseal all openings in engine and remove covering from electrical systems.
2. Remove the batteries from storage. Install batteries (fully charged) and connect the terminals.
3. Install fan/alternator belt if removed.
4. Fill fuel tank.
5. Perform all appropriate prestarting checks. (See DAILY PRESTARTING CHECKS in Lubrication and Maintenance Section.)
6. Crank engine for 20 seconds with starter (do not allow the engine to start). Wait 2 minutes and crank engine an additional 20 seconds to assure bearing surfaces are adequately lubricated.
7. Start engine and run at low idle and no load for several minutes. Warm up carefully and check all gauges before placing engine under load.
8. On the first day of operation after storage, check overall engine for leaks and check all gauges for correct operation.

RG, RG34710, 5097 -19-30JAN98-1/1

Specifications

GENERAL OEM ENGINE SPECIFICATIONS

ITEM	3029DF120	3029DF150	3029DF160	3029DF180	3029TF120	3029TF150	3029TF160	3029TF180
Number of Cylinders	3	3	3	3	3	3	3	3
Fuel	Diesel	Diesel	Diesel	Diesel	Diesel	Diesel	Diesel	Diesel
Bore	106.5 mm (4.19 in.)	106.5 mm (4.19 in.)	106.5 mm (4.19 in.)	106.5 mm (4.19 in.)	106.5 mm (4.19 in.)	106.5 mm (4.19 in.)	106.5 mm (4.19 in.)	106.5 mm (4.19 in.)
Stroke	110 mm (4.33 in.)	110 mm (4.33 in.)	110 mm (4.33 in.)	110 mm (4.33 in.)	110 mm (4.33 in.)	110 mm (4.33 in.)	110 mm (4.33 in.)	110 mm (4.33 in.)
Displacement	2.9 L (179 cu in.)	2.9 L (179 cu in.)	2.9 L (179 cu in.)	2.9 L (179 cu in.)	2.9 L (179 cu in.)	2.9 L (179 cu in.)	2.9 L (179 cu in.)	2.9 L (179 cu in.)
Compression Ratio	17.8:1	17.8:1	17.8:1	17.8:1	17.8:1	17.8:1	17.8:1	17.8:1
Physical Dimensions:								
Width	519 mm (20.4 in.)	519 mm (20.4 in.)	528 mm (20.8 in.)	528 mm (20.8 in.)	519 mm (20.4 in.)	519 mm (20.4 in.)	528 mm (20.8 in.)	528 mm (20.8 in.)
Height	819 mm (32.2 in.)	819 mm (32.2 in.)	819 mm (32.2 in.)	819 mm (32.2 in.)	928 mm (36.5 in.)	928 mm (36.5 in.)	928 mm (36.5 in.)	928 mm (36.5 in.)
Length	716 mm (28.2 in.)	716 mm (28.2 in.)	716 mm (28.2 in.)	716 mm (28.2 in.)	716 mm (28.2 in.)	716 mm (28.2 in.)	716 mm (28.2 in.)	716 mm (28.2 in.)
Basic Dry Weight	316 kg (696 lb)	316 kg (696 lb)	317 kg (698 lb)	317 kg (698 lb)	328 kg (722 lb)	328 kg (722 lb)	329 kg (724 lb)	329 kg (724 lb)

NOTE: Engine models listed above with numbers ending in "120" and "160" are emission non-certified. Engines with model numbers ending in "150" and "180" are emission certified, as explained later in this manual.

RG, RG34710, 5098 -19-30JAN98-1/1

FUEL INJECTION PUMP SPECIFICATIONS¹—EMISSION CERTIFIED ENGINES

ENGINE MODEL	OPTION CODES	FUEL INJECTION PUMP PART NUMBER	POWER RATING @ RATED SPEED ^a kW (hp)	RATED SPEED ^b (rpm)	SLOW IDLE (rpm)	FAST IDLE ^c (rpm)
CD3029DF150	16DP	RE502217	43 (58)	2500	850	2700
	16EG	RE501983	43 (58)	2500	850	2700
	16EQ	RE502509	43 (58)	2500	1700	2700
	16HW	RE501259	36 (48)	2500	850	2700
	16PN	RE502217	43 (58)	2500	850	2700
CD3029DF151	16DZ	RE501258	43 (58)	2500	850	2700
CD3029DF152	16KZ	RE502217	43 (58)	2500	850	2700
CD3029DF180	16DR	RE502217	43 (58)	2500	850	2700
	16EH	RE501983	43 (58)	2500	850	2700
	16NP	RE502217	43 (58)	2500	850	2700
CD3029TF150	16DE	RE502218	59 (79)	2500	850	2700
	16DF	RE502238	52 (70)	2500	850	2700
CD3029TF152	16EA	RE501218	59 (79)	2500	850	2700
CD3029TF180	16DG	RE502218	59 (79)	2500	850	2700
	16DH	RE502238	52 (70)	2500	850	2700
	16EL	RE501985	59 (79)	2500	850	2700
	16EM	RE501986	52 (70)	2500	850	2700
PE3029DF150	16DP	RE502217	43 (58)	2500	850	2700
	16EG	RE501983	43 (58)	2500	850	2700
	16EQ	RE502182	43 (58)	2500	850	2700
	16HW	RE501259	36 (49)	2500	850	2700
	16PH	RE501259	36 (49)	2500	850	2700
PE3029TF150	16DE	RE502218	59 (79)	2500	850	2700
	16DF	RE502238	52 (69)	2500	850	2700
	16EJ	RE501985	59 (79)	2500	850	2700
	16EK	RE502986	52 (69)	2500	850	2700
	16TR	RE506877	48 (64)	1800	—	1890
	16TS	RE506878	48 (64)	1800	—	1890

^aPower ratings are for a bare engine without the drag effect of accessories like fans, transmission, and auxiliary drives.

^bGenerator set engines (3-5% governor) usually run at 1500 rpm (50 Hz) or 1800 (60 Hz) when operating under load depending on cycles of AC current.

^cFor engines with standard governor, fast idle is 7-10% above rated speed. For engines with generator set governors, fast idle is 3-5% above rated speed.

¹Engine speeds listed are preset to factory specification. Slow idle speed may be reset depending upon specific vehicle application requirements. Refer to your machine operator's manual for engine speeds that are different from those preset at the factory.

FUEL INJECTION PUMP SPECIFICATIONS¹—EMISSION NON-CERTIFIED ENGINES

ENGINE MODEL	OPTION CODES	FUEL INJECTION PUMP PART NUMBER	POWER RATING @ RATED SPEED ^a kW (hp)	RATED SPEED ^b (rpm)	SLOW IDLE (rpm)	FAST IDLE ^c (rpm)
CD3029DF120	1602	RE53785	43 (58)	2500	850	2700
	1603	RE53786	35 (47)	1800	—	1890
	1641	RE53787	31 (41)	1500	—	1560
	1642	RE67271	43 (58)	2500	850	2700
	1644	RE41939	34 (46)	1800	—	1890
	1648	RE64242	30 (40)	1500	—	1560
	1650	RE41938	43 (58)	2500	850	2700
	1655	RE53785	43 (58)	2500	850	2700
CD3029DF121	1602	RE53785	43 (58)	2500	800	2700
	1650	RE41938	43 (58)	2500	800	2700
CD3029DF122	1603	RE53786	35 (47)	1800	—	1890
	1641	RE53787	31 (41)	1500	—	1560
	1644	RE41939	34 (46)	1800	—	1890
	1648	RE64272	30 (40)	1500	—	1560
CD3029DF123	16BS	RE53785	43 (58)	2500	800	2700
CD3029DF124	1641	RE53787	31 (41)	1500	—	1560
CD3029DF160	1602	RE53785	43 (58)	2500	850	2700
	1632	RE51940	37 (50)	2200	850	2400
	1643	RE67271	43 (58)	2500	850	2700
	1650	RE41938	43 (58)	2500	850	2700
CD3029DF162	16YG	RE51940	37 (50)	2200	800	2400
CD3029DF163	1654	RE63523	41 (55)	2400	800	2600
CD3029DF164	16DV	RE53785	43 (58)	2500	850	2700
CD3029DF165	16TH	RE53785	43 (48)	2500	850	2700
CD3029TF120	1602	RE53783	59 (79)	2500	800	2700
	1632	RE58903	59 (79)	2500	800	2700
	1640	RE53958	59 (79)	2500	800	2700
CD3029TF121	1602	RE53783	59 (79)	2500	800	2700
	1632	RE58903	59 (79)	2500	800	2700

^aPower ratings are for a bare engine without the drag effect of accessories like fans, transmission, and auxiliary drives.

^bGenerator set engines (3-5% governor) usually run at 1500 rpm (50 Hz) or 1800 (60 Hz) when operating under load depending on cycles of AC current.

^cFor engines with standard governor, fast idle is 7-10% above rated speed. For engines with generator set governors, fast idle is 3-5% above rated speed.

¹Engine speeds listed are preset to factory specification. Slow idle speed may be reset depending upon specific vehicle application requirements. Refer to your machine operator's manual for engine speeds that are different from those preset at the factory.

Continued on next page


OUOD002,000002A -19-18JAN01-1/2

Specifications

	1640	RE53958	59 (79)	2500	800	2700
CD3029TF123	16BT	RE53783	59 (79)	2500	800	2700
CD3029TF160	1602	RE53783	59 (79)	2500	800	2700
	1632	RE58903	59 (79)	2500	800	2700
	1633	RE51979	46 (62)	2200	800	2400
	1634	RE53783	59 (79)	2500	800	2700
	1640	RE53958	59 (79)	2500	800	2700
CD3029TF161	16EV	RE53958	59 (79)	2500	800	2700
CD3029TF162	1633	RE51979	46 (62)	2200	800	2700
CD3029TF163	1602	RE53783	59 (79)	2500	800	2700
PE3029DF120	1602	RE53785	43 (58)	2500	850	2700
	1603	RE53786	35 (47)	1800	—	1890
	1641	RE64241	43 (58)	2500	850	2700
	1642	RE67271	43 (58)	2500	850	2700
	1644	RE41939	35 (47)	1800	—	1890
	1648	RE64242	31 (41)	1500	—	1560
	1650	RE41938	43 (58)	2500	850	2700
	1655	RE53785	43 (58)	2500	850	2700
PE3029TF120	16TT	RE506879	42 (56)	1500	—	1560
	16TU	RE506880	42 (56)	1500	—	1560
	1602	RE53783	59 (79)	2500	850	2700
	1632	RE58903	59 (79)	2500	850	2700
	1640	RE53958	59 (79)	2500	850	2700

OUOD002,000002A -19-18JAN01-2/2

ENGINE CRANKCASE OIL FILL QUANTITIES



Option Code Label (3029TF150 Shown)

A—Dipstick Tube Option (used to determine crankcase oil fill quantity)

To determine the option code for the oil fill quantity of your engine, refer to the engine option code label affixed to the rocker arm cover (shown above). The first two digits of the code (40) (see A) identify the dipstick tube group. The last two digits of the code identify the specific dipstick and tube assembly on your engine.

Listed on next page are engine crankcase oil fill quantities:

Continued on next page

RG, RG34710, 5100 -19-30JAN98-1/3

Specifications

Engine Model	Dipstick Tube Option Code(s)	Crankcase Oil Capacity
CD3029DF120	4002, 4003, 4004, 4005 4006	6.0 L (6.5 qt) 8.0 L (8.5 qt)
CD3029DF121	4004, 4005	6.0 L (6.5 qt)
CD3029DF122	4004	6.0 L (6.5 qt)
CD3029DF123	4004	6.0 L (6.5 qt)
CD3029DF124	4004	6.0 L (6.5 qt)
CD3029DF150	4004, 4005, 4024 4022	6.0 L (6.5 qt) 7.0 L (7.5 qt)
CD3029DF151	4004	6.0 L (6.5 qt)
CD3029DF152	4004	6.0 L (6.5 qt)
CD3029DF160	4024 4022 4033	6.0 L (6.5 qt) 7.0 L (7.5 qt) 8.0 L (8.5 qt)
CD3029DF161	4024	6.0 L (6.5 qt)
CD3029DF162	4006	8.0 L (8.5 qt)
CD3029DF163	4024	6.0 L (6.5 qt)
CD3029DF164	4033	8.0 L (8.5 qt)
CD3029DF165	4024	6.0 L (6.5 qt)
CD3029DF180	4022 4033	7.0 L (7.5 qt) 8.0 L (8.5 qt)
CD3029TF120	4006, 4025 4023 4024	8.0 L (8.5 qt) 9.0 L (9.5 qt) 6.0 L (6.5 qt)
CD3029TF121	4006, 4024	8.0 L (8.5 qt)
CD3029TF123	4006	8.0 L (8.5 qt)
CD3029TF150	4006, 4025 4023 4024	8.0 L (8.5 qt) 9.0 L (9.5 qt) 6.0 L (6.5 qt)
CD3029TF152	4006	8.0 L (8.5 qt)
CD3029TF160	4024 4026 4033	6.0 L (6.5 qt) 8.5 L (9.0 qt) 8.0 L (8.5 qt)
CD3029TF161	4024	6.0 L (6.5 qt)
CD3029TF162	4006 4026	8.0 L (8.5 qt) 8.5 L (9.0 qt)

Continued on next page

RG, RG34710, 5100 -19-30JAN98-2/3

Specifications


Engine Model	Dipstick Tube Option Code(s)	Crankcase Oil Capacity
CD3029TF163	4024	6.0 L (6.5 qt)
CD3029TF180	4023	9.0 L (9.5 qt)
	4024	6.0 L (6.5 qt)
	4026	8.5 L (9.0 qt)
	4033	8.0 L (8.5 qt)
PE3029DF120	4004, 4005	6.0 L (6.5 qt)
	4006	8.0 L (8.5 qt)
	4022	7.0 L (7.5 qt)
PE3029DF150	4004	6.0 L (6.5 qt)
PE3029TF120	4025	8.0 L (8.5 qt)
PE3029TF150	4006, 4025	8.0 L (8.5 qt)
	4023	9.0 L (9.5 qt)

Crankcase oil capacity may vary slightly from amount shown. ALWAYS fill crankcase to full mark or within

crosshatch, or between arrows on dipstick, whichever is present. DO NOT overfill.

RG, RG34710, 5100 -19-30JAN98-3/3

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES



Top, SAE Grade and Head Markings; Bottom, SAE Grade and Nut Markings

Size	Grade 1 (No Mark)		Grade 2 ^a (No Mark)		Grade 5, 5.1 or 5.2		Grade 8 or 8.2	
	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)	Lubricated ^b N•m(lb-ft)	Dry ^c N•m(lb-ft)
1/4	3.8 (2.8)	4.7 (3.5)	6 (4.4)	7.5 (5.5)	9.5 (7)	12 (9)	13.5 (10)	17 (12.5)
5/16	7.7 (5.7)	9.8 (7.2)	12 (9)	15.5 (11.5)	19.5 (14.5)	25 (18.5)	28 (20.5)	35 (26)
3/8	13.5 (10)	17.5 (13)	22 (16)	27.5 (20)	35 (26)	44 (32.5)	49 (36)	63 (46)
7/16	22 (16)	28 (20.5)	35 (26)	44 (32.5)	56 (41)	70 (52)	80 (59)	100 (74)
1/2	34 (25)	42 (31)	53 (39)	67 (49)	85 (63)	110 (80)	120 (88)	155 (115)
9/16	48 (35.5)	60 (45)	76 (56)	95 (70)	125 (92)	155 (115)	175 (130)	220 (165)
5/8	67 (49)	85 (63)	105 (77)	135 (100)	170 (125)	215 (160)	240 (175)	305 (225)
3/4	120 (88)	150 (110)	190 (140)	240 (175)	300 (220)	380 (280)	425 (315)	540 (400)
7/8	190 (140)	240 (175)	190 (140)	240 (175)	490 (360)	615 (455)	690 (510)	870 (640)
1	285 (210)	360 (265)	285 (210)	360 (265)	730 (540)	920 (680)	1030 (760)	1300 (960)
1-1/8	400 (300)	510 (375)	400 (300)	510 (375)	910 (670)	1150 (850)	1450 (1075)	1850 (1350)
1-1/4	570 (420)	725 (535)	570 (420)	725 (535)	1280 (945)	1630 (1200)	2050 (1500)	2600 (1920)
1-3/8	750 (550)	950 (700)	750 (550)	950 (700)	1700 (1250)	2140 (1580)	2700 (2000)	3400 (2500)
1-1/2	990 (730)	1250 (930)	990 (730)	1250 (930)	2250 (1650)	2850 (2100)	3600 (2650)	4550 (3350)

^a Grade 2 applies for hex cap screws (not hex bolts) up to 6 in. (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.

^b "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

^c "Dry" means plain or zinc plated without any lubrication.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.


Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

METRIC BOLT AND CAP SCREW TORQUE VALUES



Top, Property Class and Head Markings; Bottom, Property Class and Nut Markings

Size	Class 4.8		Class 8.8 or 9.8		Class 10.9		Class 12.9	
	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)	Lubricated ^a N•m(lb-ft)	Dry ^b N•m(lb-ft)
M6	4.7 (3.5)	6 (4.4)	9 (6.6)	11.5 (8.5)	13 (9.5)	16.5 (12.2)	15.5 (11.5)	19.5 (14.5)
M8	11.5 (8.5)	14.5 (10.7)	22 (16)	28 (20.5)	32 (23.5)	40 (29.5)	37 (27.5)	47 (35)
M10	23 (17)	29 (21)	43 (32)	55 (40)	63 (46)	80 (59)	75 (55)	95 (70)
M12	40 (29.5)	50 (37)	75 (55)	95 (70)	110 (80)	140 (105)	130 (95)	165 (120)
M14	63 (46)	80 (59)	120 (88)	150 (110)	175 (130)	220 (165)	205 (150)	260 (190)
M16	100 (74)	125 (92)	190 (140)	240 (175)	275 (200)	350 (255)	320 (235)	400 (300)
M18	135 (100)	170 (125)	265 (195)	330 (245)	375 (275)	475 (350)	440 (325)	560 (410)
M20	190 (140)	245 (180)	375 (275)	475 (350)	530 (390)	675 (500)	625 (460)	790 (580)
M22	265 (195)	330 (245)	510 (375)	650 (480)	725 (535)	920 (680)	850 (625)	1080 (800)
M24	330 (245)	425 (315)	650 (480)	820 (600)	920 (680)	1150 (850)	1080 (800)	1350 (1000)
M27	490 (360)	625 (460)	950 (700)	1200 (885)	1350 (1000)	1700 (1250)	1580 (1160)	2000 (1475)
M30	660 (490)	850 (625)	1290 (950)	1630 (1200)	1850 (1350)	2300 (1700)	2140 (1580)	2700 (2000)
M33	900 (665)	1150 (850)	1750 (1300)	2200 (1625)	2500 (1850)	3150 (2325)	2900 (2150)	3700 (2730)
M36	1150 (850)	1450 (1075)	2250 (1650)	2850 (2100)	3200 (2350)	4050 (3000)	3750 (2770)	4750 (3500)

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

^b "Dry" means plain or zinc plated without any lubrication.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

TORQ2 -UN-07SEP99

Lubrication and Maintenance Records

USING LUBRICATION AND MAINTENANCE RECORDS

Refer to specific Lubrication and Maintenance Section for detailed service procedures.

1. Keep a record of the number of hours you operate your engine by regular observation of hour meter.
2. Check your record regularly to learn when your engine needs service.
3. DO ALL the services within an interval section. Write the number of hours (from your service records) and the date in the spaces provided. For a complete listing of all items to be performed and the service intervals required, refer to the quick-reference chart near the front of the Lubrication and Maintenance Section.

IMPORTANT: The service recommendations covered in this manual are for the accessories that are provided by John Deere. Follow manufacturer's service recommendations for servicing engine driven equipment not supplied by Deere.

RG, RG34710, 5103 -19-30JAN98-1/1

DAILY (PRESTARTING) SERVICE

Check engine oil level.

Check coolant level.

Lubricate PTO release bearing.

Check air cleaner dust unloader valve and air restriction indicator, if equipped.

Visual walkaround inspection.

Check fuel filter.

RG, RG34710, 5104 -19-30JAN98-1/1

250 HOUR/6 MONTH SERVICE

Check engine mounts.

Lubricate PTO clutch shaft bearings.

Service fire extinguisher.

Service battery.

Change engine oil and filter.

Check fan and alternator belt tension.

Check PTO clutch adjustment.

Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									

RG, RG34710, 5105 -19-30JAN98-1/1

500 HOUR SERVICEInitial valve clearance adjustment.¹

Hours									
Date									

¹Have your authorized servicing dealer or engine distributor adjust valve clearance after the first 500 hours of operation. Thereafter, have the valve clearance adjusted at 1500 Hour/24 Month intervals.

RG, RG34710, 5107 -19-30JAN98-1/1

500 HOUR/12 MONTH SERVICE

Lubricate PTO clutch internal levers and linkage.

Coolant solution analysis - add SCAs as needed.

Clean crankcase vent tube.

Check air intake hoses, connections, and system.

Pressure test cooling system.

Replace air cleaner element.

Check cooling system.

Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									

RG, RG34710, 5108 -19-30JAN98-1/1

1500 HOUR/24 MONTH SERVICE

Check and adjust engine valve clearance.

Test thermostat opening temperature.

Adjust variable speed on generator set engines.

Flush and refill cooling system.¹

Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									

¹If John Deere COOL-GARD is used, the flushing interval may be extended to 3000 hours or 36 months. If John Deere COOL-GARD is used, and the coolant is tested annually AND additives are replenished by adding supplemental coolant additives (SCA's), the flushing interval may be extended to 5000 hours or 60 months, whichever occurs first.

RG, RG34710, 5109 -19-30JAN98-1/1

SERVICE AS REQUIRED

Replace air cleaner elements.

Replace belts.

Bleed fuel system.

Add coolant.

Check fuses.

Inspect PTO clutch.

Hours									
Date									
Hours									
Date									
Hours									
Date									
Hours									
Date									

RG, RG34710, 5110 -19-30JAN98-1/1

Emission System Warranty


EMISSIONS CONTROL SYSTEM CERTIFICATION LABEL



CAUTION: Statutes providing severe penalties for tampering with emissions controls may apply at the user's location.

The emissions warranty described below applies only to those engines marketed by John Deere that have been certified by the United States Environmental Protection Agency (EPA) and/or California Air Resources Board (CARB); and used in the United States and Canada in non-road mobile (self-propelled or portable/transportable¹) equipment. The presence of an emissions label like the one shown signifies that the engine has been certified with the EPA and/or CARB. The EPA and CARB warranties only apply to new engines having the certification label affixed to the engine and sold as stated above in the geographic areas. The presence of an EU number in the third line of the label signifies that the engine has been certified with the European Union countries per Directive 97/68/EC. The emissions warranty does not apply to the EU countries.

NOTE: The hp/kW rating on the engine emissions certification label specifies the gross engine hp/kW, which is flywheel power without fan. In most applications this will not be the same rating as the advertised vehicle hp/kW rating.



Emissions Label

¹Equipment moved at least once every 12 months.

U.S. Emissions Control Warranty Statement (*United States Only*)

Emissions control-related parts and components are warranted by John Deere for five years or 3000 hours of operation, whichever occurs first. John Deere further warrants that the engine covered by this warranty was designed, built, and equipped so as to conform at the time of sale with all U.S. emissions standards at the time of manufacture, and that it is free of defects in materials and workmanship which would cause it not to meet these standards within the period of five years or 3000 hours of operation, whichever occurs first.

Warranties stated in this manual refer only to emissions-related parts and components of your engine. The complete engine warranty, less emissions-related parts and components, is provided separately as the "John Deere New Off-Highway Engine Warranty".

RG, RG34710, 5112 -19-30JAN98-1/1

John Deere Service Literature Available

TECHNICAL INFORMATION

Technical information is available from John Deere. Some of this information is available in electronic as well as printed form. Order from your John Deere dealer or call **1-800-522-7448**. Please have available the model number, serial number, and name of the product.

Available information includes:

- **PARTS CATALOGS** list service parts available for your machine with exploded view illustrations to help you identify the correct parts. It is also useful in assembling and disassembling.
- **OPERATOR'S MANUALS** providing safety, operating, maintenance, and service information. These manuals and safety signs on your machine may also be available in other languages.
- **OPERATOR'S VIDEO TAPES** showing highlights of safety, operating, maintenance, and service information. These tapes may be available in multiple languages and formats.
- **TECHNICAL MANUALS** outlining service information for your machine. Included are specifications, illustrated assembly and disassembly procedures, hydraulic oil flow diagrams, and wiring diagrams. Some products have separate manuals for repair and diagnostic information. Some components, such as engines, are available in separate component technical manuals
- **FUNDAMENTAL MANUALS** detailing basic information regardless of manufacturer:
 - Agricultural Primer series covers technology in farming and ranching, featuring subjects like computers, the Internet, and precision farming.
 - Farm Business Management series examines "real-world" problems and offers practical solutions in the areas of marketing, financing, equipment selection, and compliance.
 - Fundamentals of Services manuals show you how to repair and maintain off-road equipment.
 - Fundamentals of Machine Operation manuals explain machine capacities and adjustments, how to improve machine performance, and how to eliminate unnecessary field operations.



TS189 -UN-17JAN89



TS191 -UN-02DEC88



TS224 -UN-17JAN89



TS1663 -UN-10OCT97

PUBLICATIONS FOR THIS ENGINE

Technical information is available from John Deere in support of our products. Some of this information is available in electronic as well as printed form. Order from your John Deere dealer or call **1-800-522-7448**. Please have available the model number and serial number, and name of your John Deere engine.

Title		Order Number
POWERTECH 2.9 L OEM Engines		
Operation and Maintenance Manual (English)		OMRG27897
Parts Catalog (Emission Certified Engines)		PC3213
Parts Catalog (Emission Non-Certified Engines)		PC3202
Component Technical Manual (All 2.9 L Engines)		
	Repair, Operation and Diagnostics	CTM125
OEM Engine Accessories		CTM67
Alternators and Starter Motors		CTM77

OUOD013,0000005 -19-28NOV00-1/1

Index

Page

Page

A

Air cleaner	
Cleaning element	50-7
Element storage	50-8
Inspect element.	50-7
Air filter, replace	50-5
Air filter, service	50-7
Air intake system	
Troubleshooting	55-18
Air intake system, check.	40-2
Alternator belt.	30-7
Ammeter.	15-1
Auxiliary gear drive, limitations	15-12

B

Batteries, Service	30-2
Belts, fan and alternator	
Checking tension	30-7
Replacing	30-7, 50-8
Bleeding fuel system	50-3
Break-in engine oil	10-4
Break-in, engine	15-8

C

Chart, service interval, prime power	20-3
Chart, service interval, standby power	20-5
Checking fuses.	50-9
Clutch adjustment.	30-9
Cold weather aids.	10-3, 15-15
Coolant	
Adding	50-2
Additional information	10-10
Additives	10-12
Diesel engine	10-9
Disposing	10-13
Replenishing supplemental additives.	40-7
Supplemental additives (SCAs).	10-12
Testing	10-11, 40-6
Warm temperature climates	10-13
Coolant temperature gauge	15-1
Cooling system	
Adding coolant	50-2
Check	40-5
Flush and refill	45-5
Pressure test.	40-9
Pressure test radiator cap.	40-9

Troubleshooting	55-16
Crankcase vent tube, clean	40-1

D

Diesel engine oil.	10-5
Diesel fuel	10-1
Storage.	10-2

E

Electrical system diagram (North American)	55-2
Electrical system troubleshooting	55-12
Emissions	
EPA statement	75-2
Warranty label.	75-1
Engine	
Add coolant.	50-2
Break-in	15-8
Idling.	15-17
Operation	15-7
Starting	15-12
Stopping	15-18
Storage kit	60-1
Troubleshooting	55-1
Warming	15-16
Engine electrical system	
Troubleshooting	55-12
Wiring diagram (North American)	55-2
Engine oil	
Break-In	10-4
Change	30-4
Diesel	10-5
Oil filter change.	30-4
Engine speed, changing.	15-17
Droop	45-4
Extended diesel engine oil service intervals	10-6

F

Fan belts	30-7
Filter, replace	
Air.	50-5
Fuel	40-3
Oil.	30-4
Filters, air, service	50-7
Fire extinguisher, service	30-1

[illegible]

Page

Fuel injection pump-emission non-certified engines	65-3
General OEM	65-1
Torque values, metric	70-1
Standby power units	15-12
Starting engine	15-12
Stopping engine	15-18
Storage	
Air cleaner element	50-8
Fuel	10-2
Storing lubricants	10-8
Supplemental coolant additives	
Replenishing	40-7
Supplemental coolant additives (SCAs)	10-12

T

Tachometer	15-1
Temperature gauge (coolant)	15-1
Thermostat, test opening temperature	45-8
Torque values	
Inch.	65-8
Metric	65-9, 70-1
Troubleshooting	
Air intake	55-18
Cooling	55-16
Electrical	55-12
General	55-1
Lubrication	55-14
Turbocharger	55-18

W

Warming engine	15-16
Warranty	
Emission system	75-1
EPA emissions statement	75-2
Winterfronts	10-3
Wiring diagram	
North American	55-2

POWERTECH **2.9 L Diesel Engines**

OMRG27897 (13FEB01)



GENERATOR PARTS LISTS

GENERATOR MODEL G44

SALES OFFICES

Sales Office United Kingdom Facility details

Ingersoll-Rand European Sales Ltd
Swan Lane
Hindley Green
Wigan WN2 4EZ
United Kingdom
Phone +44 (0) 1942 257 171
Fax +44 (0) 1942 523 417

Structure de l'Organisation en France Coordonnées du Site

Ingersoll-Rand Portable Power
Zone du Cène Sourcier
B.P 62
LES CLAYES SOUS BOIS Cedex 78236
FRANCE
Téléphone +33 1 30 07 68 62
Fax +33 1 30 07 68 71

Organisatorische Bekanntmachung im Deutschland Unternehmensdetails

Ingersoll-Rand Gmbh
Gewerbealle 17
Mulheim D-45478
Germany
Telefon +49 208 99 94 400
Fax +49 208 99 94 111

Dirección de la organización en España Dirección

Ingersoll-Rand Iberia, S.L.
C/ Tierra de Barros nº 2
Poligono Industrial de Coslada
28820 Coslada (Madrid)
Spain
Teléfono +34 91 627 74 07
Fax +34 91 627 74 08

Sales Office The Netherlands Facility details

Ingersoll-Rand Benelux N.V.
Produktieweg 10
2382 PB Zoeterwoude-Rijndijk
The Netherlands
Phone +31 (0)71 58 23456
Fax +31 (0)71 58 23400

TABLE OF CONTENTS

G44

ENGINE FUNCTION 3029T	4
ENGINE JD 3029T DETAIL	5
AIR FILTER HEAVY DUTY ASSEMBLY	6
AIR FILTER 080880 DETAIL	7
SUMP DRAIN PUMP ASSEMBLY	8
ENGINE WIRING LOOM JD3029D/T	9
AIR HEATER ASSEMBLY	10
OUTPUT CABLES ALTERNATOR ASSEMBLY	11
ALTERNATOR LS 432S ASSEMBLY	12
ALTERNATOR LS 432S3 SAE 3/11,5 DETAIL	13
RADIATOR FITTINGS JD3029T ASSEMBLY	14
RADIATOR 030850 DETAILS	15
FUEL PREFILTER KIT ASSEMBLY	16
FUEL TANK M107 ASSEMBLY	17
ELECTRIC STARTER ISOLATED ASSEMBLY	18
EXHAUST FITTING KIT M107 ASSEMBLY	19
HOT SPOT GUARDS ASSEMBLY	20
FRAME JD 3029 ASSEMBLY	21
G44-2 ACCESSORY ASSEMBLY	22
FRAME SKID M107 ASSEMBLY	23
CANOPY M107 ASSEMBLY BEIGE	25
EARTH ROD WITH CABLE CANOPY ASSEMBLY	26
CIRCUIT BREAKER 25A<I<63A ACCESSORIES	27
HOUSING M150 ASSEMBLY	28
M150 CONTROL PANEL ASSEMBLY	29
CHASSIS INSTRUMENT PANEL M150 63A 4P TT ASSEMBLY	31
CONNECTIONS M107 ASSEMBLY	32
HI05 CONNECTION BLOCK M107 ASSEMBLY	33

3 WAY FUEL VALVE OPTION


3 WAY FUEL VALVE ASSEMBLY	35
---------------------------------	----

ELECTRONIC REGULATION OPTION


ELECTRONIC REGULATION KIT	36
---------------------------------	----

SOCKET OPTION


SOCKET PANEL FR M107 TYPE 4 ASSEMBLY	37
SOCKETS ASSEMBLY	38
SOCKET PANEL EU M107 TYPE 1 ASSEMBLY	39
SOCKETS ASSEMBLY	40
SOCKET PANEL FR M107 TYPE 5 ASSEMBLY	41
SOCKETS ASSEMBLY	42

01 031

Item	Part Number	Description	Quantity	Units
F01031		ENGINE FUNCTION 3029T	1.0	UN
010290	85620847	ENGINE JD 3029TF SAE 3/11.5	1.0	UN




Item	Part Number	Description	Quantity	Units
F30198		ENGINE JD 3029T DETAIL	1.0	UN
320790	85620516	OIL FILTER	1.0	UN
320800	85620508	FUEL FILTER	1.0	UN
320810	85621357	BELT	1.0	UN
301730	85400893	INJECTOR	3.0	UN
302200	85400927	STARTER	1.0	UN
320820	85621365	CHARGING ALTERNATOR	1.0	UN
320830	85621381	WTER PUMP	1.0	UN
301750	85401099	PRESSURE SWITCH	1.0	UN
302540	85401172	TEMPERATURE SWITCH	1.0	UN
320840	85621373	THERMOSTAT SEAL	1.0	UN
301780	85401180	THERMOSTAT	1.0	UN
302560	85402717	ROCKER COVER GASKET	1.0	UN


08₀₄₀

Item	Part Number	Description	Quantity	Units
F08040	85620938	AIR FILTER HEAVY DUTY ASSEMBLY	1.0	UN
080810	85412815	RAIN CAP	1.0	UN
080880	85413441	AIR FILTER HEAVY DUTY	1.0	UN
080890	85412898	CLAMP D102	1.0	UN
080980	85620920	AIR FILTER BRACKET JD 3029	1.0	UN
080990	85620946	HOSE FILTER BRACKET	1.0	UN
180300	85409399	HOSE CLIP D60/80	1.0	UN
180420	85409407	HOSE CLIP D70/90	2.0	UN
184960	85621308	RUBBER HOSE ELBOW D60	1.0	UN
080240	85410108	AIR RESTRICTION INDICATOR	1.0	UN


30₀₁₆




Item	Part Number	Description	Quantity	Units
F30016		AIR FILTER 080880 DETAIL	1.0	UN
300270	85400679	FILTER CARTRIDGE	1.0	UN
300280	85400703	FILTER CARTRIDGE	1.0	UN
300170	85501252	VACUATOR VALVE	1.0	UN
300300	85501336	DUST CUP	1.0	UN
080810	85412815	RAIN CAP	1.0	UN
180300	85409399	HOSE CLIP D60/80	1.0	UN



Item	Part Number	Description	Quantity	Units
F18041	85621316	SUMP DRAIN PUMP ASSEMBLY	1.0	UN
040110	85403426	OIL SUMP PUMP BRACKET	1.0	UN
040120	85403434	MANUAL PUMP	1.0	UN
181340	85415719	PIPE UNION REDUCER MAL/MAL 3/8G D12	1.0	UN
183350	85621241	PIPE UNION FEMAL/MAL 1/2G	1.0	UN
181420	85412914	HOSE CLIP D12/22	2.0	UN
180450	85410298	GASKET D14x18	1.0	UN
181490	85416444	FLEXIBLE HOSE D12x19	1.0	ML
040250	85620896	OIL SUMP DRAIN PUMP BRACKET JD 3029	1.0	UN
180150	85409514	SPRING CLAMP D13/15	4.0	UN
182750	85490860	FLEXIBLE HOSE D7,5	0.7	ML
182750	85490860	FLEXIBLE HOSE D7,5	0.7	ML




Item	Part Number	Description	Quantity	Units
F16173	85621217	ENGINE WIRING LOOM JD3029D/T	1.0	UN
160580	85407971	STARTING RELAY PROTECTION PANEL	1.0	UN
168850	85621209	ENGINE WIRING LOOM JD 3029	1.0	UN
160270	85408078	COPPER BAR 5x25	1.0	UN
165170	85621225	WIRING BRACKET JD 3029	1.0	UN
160170	85408896	RELAY 12V 20/30A	2.0	UN
160180	85408912	AUTOMOBILE RELAY BASE	2.0	UN


08₀₀₂

Item	Part Number	Description	Quantity	Units
F08002	85404275	AIR HEATER ASSEMBLY	1.0	UN
080110	85404259	AIR HEATER RESISTANCE 700W 12V	1.0	UN
160460	85407252	PREHEATER RELAY BRACKET	1.0	UN
160470	85407260	STARTING RELAY PROTECTION PANEL	1.0	UN
160480	85408151	AIR HEATER WIRING LOOM JD 4039	1.0	UN
160490	85408888	RELAY 12V 70A WITH BRAKET	1.0	UN
160170	85408896	RELAY 12V 20/30A	1.0	UN


16₁₀₅




Item	Part Number	Description	Quantity	Units
F16105	85501427	OUTPUT CABLES ALTERNATOR ASSEMBLY	1.0	UN
166310	85501435	CABLE OUTLET PLATE	1.0	UN
166320	85501443	CABLE OUTLET PLATE	1.0	UN
166330	85501450	REGULATION ACCESS PLATE LSA432	1.0	UN
164360	85408680	GLAND NUT SCREW PG36	1.0	UN
166210	85499697	PIPE UNION ELBOW 45° PG36	1.0	UN

02₀₀₁


Item	Part Number	Description	Quantity	Units
F02001		ALTERNATOR LS 432S ASSEMBLY	1.0	UN
020100	85403046	ALTERNATOR LS 432S	1.0	UN

30₀₃₈


Item	Part Number	Description	Quantity	Units
F30038		ALTERNATOR LS 432S3 SAE 3/11,5 DETAIL	1.0	UN
320480	85508695	WOUND STATOR ASSEMBLY	1.0	UN
320130	85509099	WOUND ROTOR ASSEMBLY	1.0	UN
320490	85508703	N.D.E BRACKET	1.0	UN
302290	85425890	BEARING LSA 432	1.0	UN
319860	85509040	WAVY WASHER	1.0	UN
320500	85508711	WOUND EXCITER FIELD	1.0	UN
309790	85508737	WOUND EXITER ARMATURE	1.0	UN
302240	85402451	GOVERNOR	1.0	UN
302320	85425924	DRIVE DISC LSA 432	1.0	UN
302230	85425593	DIODE BRIDGE ASSEMBLY	1.0	UN
302220	85425585	SURGE SUPPRESSOR LSA 432/442	1.0	UN
320510	85508729	O RING	1.0	UN




Item	Part Number	Description	Quantity	Units
F03002	85620888	RADIATOR FITTINGS JD3029T ASSEMBLY	1.0	UN
030840	85620854	RADIATOR BRACKET ENGINE JD 3029	1.0	UN
030850	85620862	RADIATOR JD 3029	1.0	UN
030860	85620870	PLENUM	1.0	UN
130110	85405017	ANTI-VIBRATION MOUNT D40 Th28	1.0	UN
132130	85621027	ANTI-VIBRATION MOUNT 50daN 5.9mm	2.0	UN
132140	85621043	RADIATOR GUARD JD 3029	1.0	UN
132150	85621050	RADIATOR GUARD JD 3029	1.0	UN
181690	85500544	HOSE CLIP D40/60	4.0	UN
184990	85621258	CLAMP D44	1.0	UN
185000	85621282	RUBBER HOSE ELBOW D48	1.0	UN
185010	85621290	RUBBER HOSE ELBOW D40	1.0	UN

30₁₉₉


Item	Part Number	Description	Quantity	Units
F30199		RADIATOR 030850 DETAILS	1.0	UN
320850	85621399	RADIATOR PLUG	1.0	UN




Item	Part Number	Description	Quantity	Units
F05026	85414902	FUEL PREFILTER KIT ASSEMBLY	1.0	UN
050150	85403525	FUEL FILTER SEPARATOR	1.0	UN
050390	85425361	FUEL FILTER SEPARATOR/3 WAY FUEL VALVE BRACKET	1.0	UN
184950	85621266	SPRING CLAMP D8.9/9.3	2.0	UN
180770	85416428	FLEXIBLE HOSE D5.5	2.0	ML
181350	85415727	BANJO CONNECTOR MALE D06	2.0	UN
180250	85409282	BANJO SCREW M14X150 L26	2.0	UN
180270	85409522	GASKET D14x20	4.0	UN
680100	85410090	NOT FITTED	-	-

05₀₄₈


Item	Part Number	Description	Quantity	Units
F05048	85620904	FUEL TANK M107 ASSEMBLY	1.0	UN
050100	85403467	FUEL SUCCION PIPE L215 D8 3/8G	2.0	UN
050110	85403517	FUEL FILLING FUNNEL BASE TANK	1.0	UN
181750	85503035	PLUG TANK	1.0	UN
110250	85413714	BASE TANK FUEL GAUGE	1.0	UN




Item	Part Number	Description	Quantity	Units
F07034	85620912	ELECTRIC STARTER ISOLATED ASSEMBLY	1.0	UN
070100	85403699	BATTERY FIXING BRACKET	1.0	UN
070170	85403707	BATTERY ISOLATOR BRACKET	1.0	UN
070310	85415891	BATTERY SUPPORT BRACKET M107	1.0	UN
070110	85403715	STARTING BATTERY 12V 70Ah 400A	1.0	UN
070120	85403723	BATTERY ISOLATOR SWITCH	1.0	UN
168810	85621159	BATTERY CABLE(+) 35mm2 L1400 RED	1.0	UN
162660	85412633	BATTERY CABLE(-) 35mm2 L1200 BLACK	1.0	UN
168820	85621167	BATTERY CABLE (+) 50mm2 L500 RED	1.0	UN
165410	85502235	COWL	2.0	UN

09₀₄₈

Item	Part Number	Description	Quantity	Units
F09048	85620987	EXHAUST FITTING KIT M107 ASSEMBLY	1.0	UN
090710	85620953	23dB MUFFLER	1.0	UN
180280	85409357	HOSE CLAMP D65	1.0	UN
183360	85621274	HOSE CLAMP D62.5	1.0	UN
161070	85407294	EMERGENCY STOP PANEL	1.0	UN
090720	85620979	EXHAUST PIPE D60 JD	1.0	UN


09₀₄₉

Item	Part Number	Description	Quantity	Units
F09049	85621001	HOT SPOT GUARDS ASSEMBLY	1.0	UN
132070	85621035	FIXING BRACKET	1.0	UN
132080	85621068	HOT SPOT GUARD JD 3029T	1.0	UN
132090	85621076	HOT SPOT GUARD JD 3029T	1.0	UN
132110	85621118	FIXING BRACKET	1.0	UN
132120	85621126	RIGIDIFICATION BRACKET	1.0	UN
132100	85621084	HOT SPOT GUARD JD 3029T	1.0	UN




13₀₇₇

Item	Part Number	Description	Quantity	Units
F13077	85621019	FRAME JD 3029 ASSEMBLY	1.0	UN
131280	85412849	FRAME TANK 100L	1.0	UN
130150	85401032	ANTI-VIBRATION MOUNT 600daN 8mm	4.0	UN
131410	85416345	ENGINE TRAVERSE MI S3L2/S4L2	1.0	UN
132050	85621092	ENGINE SUPPORT JD 3029 LEFT SIDE	1.0	UN
132060	85621100	ENGINE SUPPORT JD 3029 RIGHT SIDE	1.0	UN
184970	85621340	WASHER 15x80	2.0	UN




Item	Part Number	Description	Quantity	Units
F18052	85621324	G44-2 ACCESSORY ASSEMBLY	1.0	UN
050420	85431120	FUEL FILTER	1.0	UN
144560	85509263	WBH LATCH KEY	1.0	UN
181640	85500197	ROUND STICKER D215	1.0	UN
181650	85500221	RECTANGULAR STICKER 550x110	1.0	UN
182080	85503902	RECTANGULAR STICKER 250x300	2.0	UN
184980	85621332	RECTANGULAR STICKER 1100x325	2.0	UN

13₀₄₁





Item	Part Number	Description	Quantity	Units
F13041	85414159	FRAME SKID M107 ASSEMBLY	1.0	UN
131320	85412864	SKID BASE M107	1.0	UN

14₀₄₀




Item	Part Number	Description	Quantity	Units
F14040	85509958	CANOPY M107 ASSEMBLY BEIGE	1.0	UN
131150	85492700	LIFTING EYE D61	1.0	UN
140150	85412856	FRAME M107	1.0	UN
141910	85415347	M107 CANOPY HEAD PANEL	1.0	UN
141930	85415339	M107 CANOPY LEFT REAR PANEL	1.0	UN
141940	85415321	M107 CANOPY RIGHT REAR PANEL	1.0	UN
141950	85415370	CANOPY SIDE PANEL M107	2.0	UN
141980	85412484	SIDE SUPPORT ARCH UPRIGHTS M107	2.0	UN
141990	85412492	TRANSVERSE ARCH SUPPORT M107	1.0	UN
142000	85413516	STRIKER PLATE M107 CANOPY DOOR	2.0	UN
142010	85413524	REAR AIR INTAKE LOUVER M107 CANOPY	1.0	UN
142020	85413151	AIR DEFLECTOR M107 CENTRAL REAR	1.0	UN
142050	85412617	FRAME FIXING BRACKET M107	1.0	UN
142070	85413888	SOUNDPROOF PANELS BATCH M107	1.0	UN
142090	85415313	M107 CANOPY REAR PANEL	1.0	UN
141880	85509818	M107 CANOPY RIGHT HEAD PANEL	1.0	UN
141890	85509826	M107 CANOPY LEFT HEAD PANEL	1.0	UN
144430	85509560	RADIATOR BLACK PANEL M107	1.0	UN
144440	85509578	RADIATOR BLACK PANEL M107	1.0	UN
144450	85509586	RADIATOR PANEL M107 JD 3039D	1.0	UN
144610	85621134	CANOPY TOP M107	1.0	UN
140660	85406130	DOOR HINGE	4.0	UN
144270	85509305	CANOPY DOOR LOCK KEY LOCK	2.0	UN
142110	85416477	GAS FILLED DAMPER 70kg ROD D10	2.0	UN
142120	85416501	SECURITY WINDOW M107	1.0	UN
142130	85412831	DOOR HINGE	2.0	UN
140380	85406221	SLAM SHUT DOOR LATCH	1.0	UN
140390	85406239	SLAM SHUT LATCH HANDLE	1.0	UN
140400	85406247	SLAM SHUT FASTENER	1.0	UN
144620	85621142	FLAP D160	1.0	UN
144420	85509859	CANOPY DOOR M107 LEFT BEIGE	1.0	UN
144410	85509842	CANOPY DOOR M107 RIGHT BEIGE	1.0	UN
162670	85416287	REAR PANEL M107	1.0	UN
162670	85509917	REAR PANEL M107	1.0	UN
168800	85621183	WIRE BIB OUTPUT BRACKET M107	1.0	UN
168730	85621191	CABLE OUTPUT RUBBER SCREEN	1.0	UN
181450	85413722	LINEAR SEAL	8.3	ML
181460	85413730	LINEAR SEAL	1.25	ML

16₀₀₆




Item	Part Number	Description	Quantity	Units
F16006	85407906	EARTH ROD WITH CABLE CANOPY ASSEMBLY	1.0	UN
160140	85408227	NEUTRAL/EARTH SYSTEM CABLE 25mm ² L10000 Gr/Ye	1.0	UN
160150	85408334	EARTH ROD L1000	1.0	UN
180120	85409191	CLIP-ON BRACKET	2.0	UN


16₀₃₄

Item	Part Number	Description	Quantity	Units
F16034		CIRCUIT BREAKER 25A<I<63A ACCESSORIES	1.0	UN
165340	85408771	DIFFERENTIAL SWITCH 4P 25A 30mA	1.0	UN

Part number listed are the only parts used on this model.




Item	Part Number	Description	Quantity	Units
F16082	85415180	HOUSING M150 ASSEMBLY	1.0	UN
163160	85416121	GLAND NUT PLATE M50/M150	1.0	UN
163300	85416238	CONTROL PANEL BRACKET M150	1.0	UN
163310	85413136	DASHBOARD HOOD SUPERIOR M150	1.0	UN
163320	85413144	DASHBOARD HOOD INFERIOR M150	1.0	UN
167200	85505550	SHAFT ADAPTATOR	1.0	UN
167190	85505543	GROUND WIRES 16mm2	2.0	UN
164520	85415388	RUBBER GROMMET D22	4.0	UN
164960	85415396	RUBBER GROMMET D18	2.0	UN
167210	85505568	TE ELECTRICAL SHAFT	1.0	UN
167220	85505576	ELECTRICAL SHAFT D16	0.44	ML
167230	85505584	ELECTRICAL SHAFT D13	0.98	ML
167240	85505592	ELECTRIC PIPE UNION PG16	1.0	UN
165930	85408664	GLAND NUT SCREW PG16	1.0	UN
166260	85501575	PIPE UNION PG36	1.0	UN
164360	85408680	GLAND NUT SCREW PG36	1.0	UN
166200	85499440	ELECTRICAL SHAFT D36	1.0	UN




Item	Part Number	Description	Quantity	Units
F16084	85414985	M150 CONTROL PANEL ASSEMBLY	1.0	0
070210	85412948	KEY SELECTOR SWITCH	1.0	UN
070220	85413268	SWITCH NUT	1.0	UN
070230	85412872	KEY SWITCH	1.0	UN
164070	85416519	VOLTMETER 0/500V	1.0	UN
164080	85413482	FUSE CYLINDRICAL 5A	1.0	UN
164110	85413490	FUSE CYLINDRICAL 6A	3.0	UN
164300	85402527	PGS CARD 12/24V	1.0	UN
164430	85412591	BOUTON ARRET URGENCE	1.0	UN
164440	85412971	HOUR METER	1.0	UN
164450	85412609	PUSH BUTTON D12	1.0	UN
164500	85402477	AMMETER WITH NEEDLE 72x72	1.0	UN
164580	85412955	VOLTMETER SWITCH 7 POSITIONS D22	1.0	UN
164600	85402576	RD2 CARD 12VCC	1.0	UN
164610	85412930	AMMETER SWITCH 4 POSITIONS D22	1.0	UN
164640	85415503	FUSE HOUSING	1.0	UN
164650	85416527	WARNING LIGHT CYLINDRIC D22	1.0	UN
164680	85508638	AUXILARY CONTACT	2.0	UN
164950	85413508	CYLINDRICAL FUSE NEUTRAL	1.0	UN
303000	85402519	LAMP 12V	1.0	UN
166040	85490472	FUSE HOUSING	1.0	UN
660110	85500379	MOULDED CASE CIRCUIT BREAKER 1x6A	1.0	UN
167320	85505683	PLASTIC COVER TERMINAL BLOCK	1.0	UN
167330	85505691	TERMINAL CONNECTION	2.0	UN

166030	85408854	STOP	7.0	UN
181560	85505634	PLASTIC PLATE L260xh140	1.0	UN
181570	85413797	PLASTIC PLATE L260xh140	1.0	UN
167310	85505659	AMPEREMETRE INDICATOR PLATE	1.0	UN


16₁₈₁




Item	Part Number	Description	Quantity	Units
F16181	85621407	CHASSIS INSTRUMENT PANEL M150 63A 4P TT ASSEMBLY	1.0	UN
164120	85408417	CURRENT TRANSFORMER 60/5	3.0	UN
164200	85408474	MOULDED CASE CIRCUIT BREAKER 4x63A	1.0	UN
164330	85408649	GLAND NUT PG36	1.0	UN
164360	85408680	GLAND NUT SCREW PG36	1.0	UN
164670	85413250	AMMETER SCALE 60/5A	1.0	UN
167300	85505675	PLASTIC COVER TERMINAL BLOCK BLUE	1.0	UN
165990	85426229	TERMINAL BLOCK 1x16mm2 Gr/Ye	1.0	UN
167250	85505642	BLUE TERMINAL CONNECTION	1.0	UN
167270	85505618	TERMINAL BLOCK	1.0	UN



Item	Part Number	Description	Quantity	Units
F16007	85414829	CONNECTIONS M107 ASSEMBLY	1.0	UN
163090	85416030	CABLE FIXING BRACKET MCPS M202/203	1.0	UN
165500	85415982	WIRE BIB OUTPUT BRACKET M202	1.0	UN
165510	85412534	CABLE OUTPUT RUBBER SCREEN	1.0	UN
165530	85415933	TERMINAL BRACKET	1.0	UN
140660	85406130	DOOR HINGE	4.0	UN
140350	85406189	ANTI-VIBRATION MOUNT 140daN 15mm	1.0	UN
140380	85406221	SLAM SHUT DOOR LATCH	1.0	UN
140390	85406239	SLAM SHUT LATCH HANDLE	1.0	UN
140400	85406247	SLAM SHUT FASTENER	1.0	UN
165690	85415537	TERMINAL CONNECTION DOOR M107	1.0	UN
160720	85407682	STRIKER PLATE M214 CANOPY MCPS DOOR	1.0	UN
160750	85407690	SPACER FOR DOOR M214	2.0	UN
160760	85407708	HINGE FIXING PLATE M214	2.0	UN
165700	85416048	CONNECTIONS BLOCK BRACKET M107	1.0	UN
165710	85415545	TERMINAL CONNECTION PERSPEX DOOR M107	1.0	UN
164550	85412559	POWER CONNECTION BLOCK	1.0	UN
180460	85409225	1/4 TURN SCREW D9	2.0	UN
180470	85409233	CAPTIVE NUT FOR 1/4 TURN BOLT	2.0	UN
180480	85409241	WASHER FOR 1/4 TURN FASTENER	2.0	UN
181580	85410140	WING NUT M8	2.0	UN


16₁₇₅

Item	Part Number	Description	Quantity	Units
F16175	85621175	HI05 CONNECTION BLOCK M107 ASSEMBLY	1.0	UN
165790	85499150	GLAND NUT PLATE TERMINAL CONNECTION M107	1.0	UN
166200	85499440	ELECTRICAL SHAFT D36	1.0	UN
168830	85621233	PLUG ELECTRIC D36	1.0	UN
164360	85408680	GLAND NUT SCREW PG36	1.0	UN
166260	85501575	PIPE UNION PG36	1.0	UN
166900	85499689	PIPE UNION ELBOW 90° PG36	1.0	UN



3 WAY FUEL VALVE OPTION
992460


Item	Part Number	Description	Quantity	Units
F05030	85415198	3 WAY FUEL VALVE ASSEMBLY	1.0	UN
050570	85507861	3 WAY FUEL VALVE LEVER 3/8G	1.0	UN
182090	85429926	SCREW H M12x25	4.0	UN
184950	85621266	SPRING CLAMP D8.9/9.3	10.0	UN
180770	85416428	FLEXIBLE HOSE D5.5	3.0	ML
182150	85430213	WASHER 8X18	8.0	UN
180390	85410165	WASHER 12x24	4.0	UN
182100	85430452	PIPE UNION REDUCER MAL/FEM 3/8G D6	6.0	UN
182110	85430460	PIPE UNION MAL/MAL D6	2.0	UN
182120	85430478	PIPE UNION ELBOW MAL/MAL D6	6.0	UN
182130	85430486	PIPE UNION FEM/FEM D6	2.0	UN
180200	85409464	HOSE CLAMP D36	4.0	UN
183090	85505006	3 WAY FUEL VALVE	2.0	UN



ELECTRONIC REGULATION OPTION

992470

Item	Part Number	Description	Quantity	Units
F06023		ELECTRONIC REGULATION KIT	1.0	UN
060100	85403616	ELECTRONIC ACTUATOR	1.0	UN
060130	85426260	SPEED ELECTRONIC GOVERNOR 12VCC	1.0	UN
060120	85403632	MAGNETIC SPEED SENSOR L75 3/4UNF	1.0	UN
168840	85621506	ELECTRONIC REGULATOR HOUSING BRACKET	1.0	UN
160980	85407237	ELECTRONIC REGULATION HOUSING	1.0	UN
160990	85407245	HOUSING ELECTRONIC REGULATION	1.0	UN
161000	85407336	ELECTRONIC REGULATOR BRACKET	1.0	UN
161010	85408375	TERMINAL BLOCK 1x2.5mm2 GREY	3.0	UN
161020	85408706	STOP	1.0	UN
161030	85408789	TERMINAL BLOCK 1x4mm2 Gr/Ye	1.0	UN
160170	85408896	RELAY 12V 20/30A	1.0	UN
160180	85408912	AUTOMOBILE RELAY BASE	1.0	UN
160300	85408920	MOULDED CASE CIRCUIT BREAKER 1x16A	1.0	UN
161040	85410116	PLASTIC COVER TERMINAL BLOCK	1.0	UN




SOCKET OPTION

992480

SOCKET TYPE 4

Item	Part Number	Description	Quantity	Units
F16139	85506939	SOCKET PANEL FR M107 TYPE 4 ASSEMBLY	1.0	UN
167600	85505840	SOCKET PANEL M107	1.0	UN
167610	85505857	ELECTRIC PANEL HOUSING COVER M107	1.0	UN
166200	85499440	ELECTRICAL SHAFT D36	0.7	ML
167710	85506053	PLUG ELECTRIC D9	1.0	UN
167070	85506061	GLAND NUT SCREW PG9	1.0	UN
164360	85408680	GLAND NUT SCREW PG36	2.0	UN
166900	85499689	PIPE UNION ELBOW 90° PG36	1.0	UN
166210	85499697	PIPE UNION ELBOW 45° PG36	1.0	UN

16₁₃₁




SOCKET OPTION

992480

SOCKET TYPE 4

Item	Part Number	Description	Quantity	Units
F16131	85505964	SOCKETS ASSEMBLY	1.0	UN
167750	85408748	COMPACT CIRCUIT BREAKER 1x10A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
167760	85413169	COMPACT CIRCUIT BREAKER 1x15A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
167650	85506020	MOULDED CASE CIRCUIT BREAKER 4x32A	1.0	UN
164060	85408284	CIRCUIT BREAKER SUPPORT PLATE 12 MODULES	1.0	UN
167670	85408300	SOCKET GERMAN 230V 16A 2S+G	1.0	UN
167680	85408318	EC SOCKET 400V 16A 3S+N+G	1.0	UN
167690	85408326	EC SOCKET 400V 32A 3S+N+G	1.0	UN
165340	85408771	DIFFERENTIAL SWITCH 4P 25A 30mA	1.0	UN
167800	85506103	SOCKET EC 230V 16A 2S+G	1.0	UN
167820	85506434	MOULDED CASE CIRCUIT BREAKER 4x16A	1.0	UN




SOCKET OPTION

992480

SOCKET TYPE 1

Item	Part Number	Description	Quantity	Units
F16134	85506798	SOCKET PANEL EU M107 TYPE 1 ASSEMBLY	1.0	UN
167600	85505840	SOCKET PANEL M107	1.0	UN
167610	85505857	ELECTRIC PANEL HOUSING COVER M107	1.0	UN
166200	85499440	ELECTRICAL SHAFT D36	0.7	ML
167710	85506053	PLUG ELECTRIC D9	1.0	UN
167070	85506061	GLAND NUT SCREW PG9	1.0	UN
164360	85408680	GLAND NUT SCREW PG36	2.0	UN
166900	85499689	PIPE UNION ELBOW 90° PG36	1.0	UN
166210	85499697	PIPE UNION ELBOW 45° PG36	1.0	UN

16₁₂₅




SOCKET OPTION

992480

SOCKET TYPE 1

Item	Part Number	Description	Quantity	Units
F16125	85505873	SOCKETS ASSEMBLY	1.0	UN
167750	85408748	COMPACT CIRCUIT BREAKER 1x10A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
167760	85413169	COMPACT CIRCUIT BREAKER 1x15A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
166180	85501542	SOCKETS ADAPTATION PLATE	2.0	UN
167650	85506020	MOULDED CASE CIRCUIT BREAKER 4x32A	1.0	UN
164060	85408284	CIRCUIT BREAKER SUPPORT PLATE 12 MODULES	1.0	UN
167670	85408300	SOCKET GERMAN 230V 16A 2S+G	1.0	UN
167680	85408318	EC SOCKET 400V 16A 3S+N+G	1.0	UN
167690	85408326	EC SOCKET 400V 32A 3S+N+G	1.0	UN
165340	85408771	DIFFERENTIAL SWITCH 4P 25A 30mA	1.0	UN
167800	85506103	SOCKET EC 230V 16A 2S+G	1.0	UN
167820	85506434	MOULDED CASE CIRCUIT BREAKER 4x16A	1.0	UN




SOCKET OPTION

992480

SOCKET TYPE 5

Item	Part Number	Description	Quantity	Units
F16146	85507135	SOCKET PANEL FR M107 TYPE 5 ASSEMBLY	1.0	UN
167600	85505840	SOCKET PANEL M107	1.0	UN
167610	85505857	ELECTRIC PANEL HOUSING COVER M107	1.0	UN
166800	85499283	ELECTRICAL SHAFT D10	1.5	ML
166200	85499440	ELECTRICAL SHAFT D36	0.7	ML
161010	85408375	TERMINAL BLOCK 1x2.5mm2 GREY	2.0	UN
167070	85506061	GLAND NUT SCREW PG9	2.0	UN
164360	85408680	GLAND NUT SCREW PG36	2.0	UN
161020	85408706	STOP	2.0	UN
167730	85413466	PLASTIC COVER TERMINAL BLOCK	1.0	UN
167790	85499663	PIPE UNION PG9	1.0	UN
166900	85499689	PIPE UNION ELBOW 90° PG36	1.0	UN
166910	85500494	PIPE UNION ELBOW 90° PG9	1.0	UN
166210	85499697	PIPE UNION ELBOW 45° PG36	1.0	UN
167780	85506095	NOT FITTED	-	-
166260	85501575	NOT FITTED	-	-

16₁₂₇



SOCKET OPTION

992480

SOCKET TYPE 5

Item	Part Number	Description	Quantity	Units
F16127	85505907	SOCKETS ASSEMBLY	1.0	UN
167760	85413169	COMPACT CIRCUIT BREAKER 1x15A	1.0	UN
167770	85408763	CIRCUIT BREAKER PROTECTION	1.0	UN
167650	85506020	MOULDED CASE CIRCUIT BREAKER 4x32A	1.0	UN
164060	85408284	CIRCUIT BREAKER SUPPORT PLATE 12 MODULES	1.0	UN
167680	85408318	EC SOCKET 400V 16A 3S+N+G	1.0	UN
167690	85408326	EC SOCKET 400V 32A 3S+N+G	1.0	UN
165340	85408771	DIFFERENTIAL SWITCH 4P 25A 30mA	1.0	UN
167810	85506111	SOCKET EC 110V 16A 2S+G	2.0	UN
167820	85506434	MOULDED CASE CIRCUIT BREAKER 4x16A	1.0	UN

Use and maintenance manual

Leroy Somer Alternators LSA 43.2/44.2 - 4 - Pole

Réf. constructeur :
3434 GB - 4.33/a - 03.01

Réf. GPAO : 33522016401 ind1

LSA 43.2/44.2 - 4-POLE ALTERNATORS

This manual concerns the alternator which you have just purchased.

The latest addition to a whole new generation of alternators, this range benefits from the experience of the world's leading manufacturer, using advanced technology and incorporating strict quality control.

We wish to draw your attention to the contents of this maintenance manual. By following certain important points during installation, use and servicing of your alternator, you can look forward to many years of trouble-free operation.

SAFETY MEASURES

Before using your machine for the first time, it is important to read the whole of this installation and maintenance manual.

All necessary operations and interventions on this machine must be performed by a qualified technician.

Our technical support service will be pleased to provide any additional information you may require.

The various operations described in this manual are accompanied by recommendations or symbols to alert the user to potential risk of accident. It is vital that you understand and take notice of the different warning symbols used.

CAUTION

Warning symbol for an operation capable of damaging or destroying the machine or surrounding equipment.



Warning symbol for general danger to personnel.




Warning symbol for electrical danger to personnel.

Note: LEROY-SOMER reserves the right to modify the characteristics of its products at any time in order to incorporate the latest technological developments. The information contained in this document may therefore be changed without notice.

WARNING SYMBOLS

A set of self-adhesive stickers depicting the various warning symbols is included with this maintenance manual. They should be positioned as shown in the drawing below once the machine has been fully installed.



Copyright 2001: MOTEURS LEROY-SOMER

This document is the property of:

MOTEURS LEROY-SOMER

It may not be reproduced in any form without prior authorization.

All brands and models have been registered and patents applied for.

LSA 43.2/44.2 - 4-POLE ALTERNATORS

CONTENTS

1 - RECEIPT

1.1 - Standards and safety measures	4
1.2 - Inspection	4
1.3 - Identification	4
1.4 - Storage	4

2 - TECHNICAL CHARACTERISTICS

2.1 - Electrical characteristics	5
2.2 - Mechanical characteristics	5
2.3 - SHUNT excitation system	6
2.4 - AREP excitation system	7
2.5 - PMG excitation system	9

3 - INSTALLATION - COMMISSIONING

3.1 - Assembly	10
3.2 - Inspection prior to first use	10
3.3 - Terminal connection diagrams	11
3.4 - Commissioning	13
3.5 - Settings	13

4 - SERVICING - MAINTENANCE

4.1 - Safety measures	16
4.2 - Regular maintenance	16
4.3 - Fault detection	16
4.4 - Mechanical defects	17
4.5 - Electrical faults	17
4.6 - Dismantling, reassembly	19
4.7 - Installation and maintenance of the PMG ...	20
4.8 - Table of characteristics	21

5 - SPARE PARTS

5.1 - First maintenance parts	23
5.2 - Bearing designations	23
5.3 - Technical support service	23
5.4 - Exploded view, parts list	24

LSA 43.2/44.2 - 4-POLE ALTERNATORS

RECEIPT

1 - RECEIPT

1.1 - Standards and safety measures

Our alternators comply with most international standards and are compatible with:

- the recommendations of the

International Electrotechnical Commission

IEC 34-1, (EN 60034)

- the recommendations of the

International Standards Organisation ISO 8528

- the European Community directive 89/336/EEC on Electromagnetic Compatibility (EMC)

- the European Community directives

73/23/EEC and 93/68/EEC (Low Voltage Directive)

They are CE marked with regard to the LVD (Low Voltage Directive) in their role as a machine component. A declaration of incorporation can be supplied on request.

Before using your generator for the first time, read carefully the contents of this installation and maintenance manual, supplied with the machine. All operations performed on the generator should be undertaken by qualified personnel trained in the commissioning, servicing and maintenance of electrical and mechanical components. This maintenance manual should be retained for the whole of the machine's life and be handed over with the contractual file.

The various operations described in this manual are accompanied by recommendations or symbols to alert the user to potential risks of accidents. It is vital that you understand and take notice of the different warning symbols used.

1.2 - Inspection

On receipt of your alternator, check that it has not suffered any damage in transit. If there are obvious signs of knocks, contact the transporter (you may be able to claim on their insurance) and after a visual check, turn the machine by hand to detect any malfunction.

1.3 - Identification

The alternator is identified by means of a nameplate glued to the frame.

Make sure that the nameplate on the machine conforms to your order.

The machine name is defined according to various criteria (see below).

Example of description: **LSA 43.2 M4 J6/4**

• LSA: Name used in the PARTNER range

• M: Marine

• C: Cogeneration

• T: Telecommunications

• 43.2: Machine type

• M4: Model

• J: Excitation system (C: AREP/J: SHUNT or PMG/
E: COMPOUND)

• 6/4: Winding number/number of poles

Nameplate

So that you can identify your machine quickly and accurately, we suggest you fill in its specifications on the nameplate below.

1.4 - Storage

Prior to commissioning, machines should not be stored in humid conditions: at relative humidity levels greater than 90%, the machine insulation can drop very rapidly, to just above zero at around 100%. The state of the anti-rust protection on unpainted parts should be monitored.

For storage over an extended period, the machine can be placed in a sealed enclosure (heatshrink plastic for example) with dehydrating sachets inside, away from significant and frequent variations in temperature to avoid the risk of condensation during storage.

If the area is affected by vibration, try to reduce the effect of these vibrations by placing the generator on a damper support (rubber disc or similar) and turn the rotor a fraction of a turn once a fortnight to avoid marking the bearing rings.

LEROY-SOMER		ALTERNATEURS PARTNER ALTERNATORS	
LSA	Date		
N	Hz		
Min-1/R.P.M.	Protection		
Cos Ø / P.F.	Cl. ther. / Th. class		
Régulateur/A.V.R.			
Altitude	Masse / Weight		
Rlt AV/D.E bearing			
Rlt AR/N.D.E bearing			
Graisse / Grease			
Valeurs excit / Excit. values			
en charge / full load			
à vide / at no load			
		PUISSANCE / RATING Tension Voltage <input type="text"/> <input type="text"/> <input type="text"/> V Voltage <input type="text"/> <input type="text"/> <input type="text"/> Ph. Connex. <input type="text"/> <input type="text"/> <input type="text"/> Continue <input type="text"/> <input type="text"/> <input type="text"/> kVA Continuous <input type="text"/> <input type="text"/> <input type="text"/> kW 40 C <input type="text"/> <input type="text"/> <input type="text"/> A Secours <input type="text"/> <input type="text"/> <input type="text"/> kVA Std by <input type="text"/> <input type="text"/> <input type="text"/> kW 27 C <input type="text"/> <input type="text"/> <input type="text"/> A	
LR 0021		Conforme à C.E.I 34-1(1994). According to I.E.C 34-1(1994).	

Made by Leroy Somer - 1 024 930/b

LSA 43.2/44.2 - 4-POLE ALTERNATORS

TECHNICAL CHARACTERISTICS

2 - TECHNICAL CHARACTERISTICS

2.1 - Electrical characteristics

PARTNER LSA 43.2/44.2 alternators are machines without sliprings or revolving field brushes, wound as "2/3 pitch", 12-wire; the insulation is class H and the field excitation system is available in either "SHUNT", "AREP" or "PMG" versions (see sections 2.3, 2.4, 2.5). Interference suppression conforms to standard EN 55011, group 1, class B.

2.1.1 - Options

- Stator temperature detection probes
- Space heaters


2.2 - Mechanical characteristics

- Steel frame
- End shields in cast iron
- Protected ball bearings, greased for life
- Mounting arrangements
- MD 35 STANDARD: Single-bearing with standard feet and SAE flanges/coupling discs
- B 34 STANDARD: standard feet with SAE flange and standard cylindrical shaft extension
- Drip-proof machine, self-cooled
- Degree of protection: IP 23


2.2.1 - Options

- Protection against harsh environments
 - Air inlet filter, air outlet labyrinth seals
- Alternators fitted with air inlet filters should be derated by 5% (power)
- To prevent excessive temperature rise caused by clogged filters, it is advisable to fit the stator winding with thermal sensors (PTC or PT100)


2.1.2 - SHUNT system with R 230 AVR



2.1.3 - AREP system with R 438 AVR



2.1.4 - PMG system with R 438 AVR



LSA 43.2/44.2 - 4-POLE ALTERNATORS

TECHNICAL CHARACTERISTICS


2.3 - SHUNT excitation system

The alternator with Shunt excitation is self-excited with an **R 230** voltage regulator. The regulator monitors the exciter excitation current as a function of the alternator output voltage. Very simple in design, the alternator with shunt excitation has no sustaining short-circuit capacity.




2.3.1 - R 230 AVR

- Voltage regulation: around $\pm 0.5\%$.
- Voltage sensing range 85 to 139 V (50/60 Hz)
- Rapid response time (500 ms) for a transient voltage variation amplitude of $\pm 20\%$
- Voltage setting **P1**
- Stability setting **P2**
- Power supply protected by 8 A fuse, slow-blow action (tolerates 10 A for 10 s)
- Frequency: 50 Hz with **ST3** jumper - 60 Hz without ST3 jumper
- Factory-set underspeed protection **P3**.



2.3.2 - R 230 AVR options

Potentiometer for remote voltage adjustment, 1000 Ω / 0.5 W min: adjustment range $\pm 5\%$.
Remove the **ST4** jumper.




2.3.3 - R 231 AVR for dedicated single-phase

With an M or M1 dedicated single-phase winding, the alternator works with an R 231 voltage regulator. The R 231 is an R 230 with a specific excitation ceiling setting for the dedicated single-phase alternator. See the R 230 for connections, setting up and troubleshooting.

2.3.4 - Additional functions with the R 448

As an option, the LSA 43.2/44.2 SHUNT alternator can work with the R 448 AVR in order to obtain the following functions:

- Parallel operation between alternators with C.T.
- Parallel operation with the mains with C.T. and R 726 module
- 3-phase sensing (R 731 module)
- LAM function integrated in the R 448 AVR



The AVR and its modules need to be mounted outside the terminal box.

In this case, the R 448 AVR replaces the R 230.


For settings and maintenance, see section 4.5 of this manual (the R 448 functions are identical to those for the R 438, & 2.4).

LSA 43.2/44.2 - 4-POLE ALTERNATORS

TECHNICAL CHARACTERISTICS

2.4 - AREP excitation system

With AREP excitation, the **R 438** electronic AVR is powered by two auxiliary windings which are independent of the voltage sensing circuit. The first winding has a voltage in proportion to that of the alternator (shunt characteristic), the second has a voltage in proportion to the stator current (compound characteristic: booster effect). The power supply voltage is rectified and filtered before being used by the AVR monitoring transistor. This principle ensures that regulation is not affected by distortions generated by the load.




2.4.1 - R 438 AVR

- Short-circuit current = 3 IN for 10 seconds
- Standard power supply; 2 auxiliary wdgs
- Shunt power supply; max. 48 V - 50/60 Hz
- Rated overload current: 8 A - 10 s
- Electronic protection (overload, short-circuit on opening of voltage sensing circuit): excitation overload current for 10 seconds then return to approximately 1A

CAUTION

The alternator must be stopped (or the power switched off) in order to reset the protection.

- Fuses:
 - F1 on the input of auxiliary windings X1, X2
- Voltage sensing: 5 VA isolated via transformer:
 - 0-110 V terminals = 95 to 140 V
 - 0-220 V terminals = 170 to 260 V
 - 0-380 V terminals = 340 to 520 V
- Voltage regulation $\pm 0.5\%$
- Normal or rapid response time via the **ST2** jumper
- Voltage adjustment via potentiometer **P2**
(Other voltages via adapter transformer)
- Current sensing (parallel operation): C.T. 2.5 VA c1, secondary 1A (optional)
- Quadrature droop adjustment via potentiometer **P1**
- Underspeed protection (U/f) and LAM: frequency threshold adjustable via potentiometer **P4**
- Max. excitation current adjustment via **P5**: 4.5 to 8 A
- 50/60 Hz selection via the **ST3** jumper



LSA 43.2/44.2 - 4-POLE ALTERNATORS

TECHNICAL CHARACTERISTICS

2.4.2 - LAM characteristics



The LAM system is integrated in the R 438 AVR as standard.
Role of the "LAM" (Load Adjustment Module):

On application of a load, the rotation speed of the generator set decreases. When it passes below the preset frequency threshold, the "LAM" causes the voltage to drop by approximately 15% and consequently the amount of active load applied is reduced by approximately 25%, until the speed reaches its rated value again.

Hence the "LAM" can be used either to reduce the speed variation (frequency) and its duration for a given applied load, or to increase the applied load possible for the same speed variation (turbo-charged engines).

To avoid voltage oscillations, the trip threshold for the "LAM" function should be set approximately 2 Hz below the lowest frequency in steady state.

- LAM: action eliminated by cutting the ST5 jumper



Typical effects of the "LAM" with a diesel engine -
— with LAM · · · without LAM (U/F only)

2.4.3 - R 438 AVR options


- **Current transformer** for parallel operation.
- **Remote voltage adjustment potentiometer**: 470 Ω , 0.5 W min: adjustment range $\pm 5\%$ (range limited by internal voltage potentiometer **P2**). Remove ST4 to connect the potentiometer. (A 1 k Ω potentiometer can also be used to extend the adjustment range)
- **R 731 external module**: sensing of 3-phase voltage 200 to 500 V, compatible with parallel operation. Disconnect ST1 to connect the module; set the voltage via the module potentiometer. (The R 730 module is not compatible with parallel operation.)
- **R 726 module**: 3 functions (mounted externally)
 - P.F. regulation (2F) and voltage sensing circuit before paralleling (3 F).
 - C.T. of/1A. 5 VA CL 1. (See the diagram included with this manual.)

LSA 43.2/44.2 - 4-POLE ALTERNATORS

TECHNICAL CHARACTERISTICS

2.5 - PMG excitation system

This excitation system consists of a SHUNT alternator and a "PMG" (permanent magnet generator). This is fitted at the rear of the machine and connected to the LS R 438 AVR. The PMG supplies the AVR with constant voltage which is independent of the main alternator winding. As a result the machine has a short-circuit current capacity and good immunity to distortions generated by the load. The AVR monitors and corrects the alternator output voltage by adjusting the excitation current.



2.5.1 - R 438 AVR

- Short-circuit current = 3 IN for 10 seconds
- Standard power supply: PMG
- Rated overload current: 8 A - 10 s
- Electronic protection (overload, short-circuit on opening of voltage sensing circuit): excitation overload current for 10 seconds then return to approximately 1A

CAUTION

The alternator must be stopped (or the power switched off) in order to reset the protection.

- Fuses:
 - F1 on X1, X2
- Voltage sensing: 5 VA isolated via transformer:
 - 0-110 V terminals = 95 to 140 V
 - 0-220 V terminals = 170 to 260 V
 - 0-380 V terminals = 340 to 520 V
- Voltage regulation $\pm 1\%$
- Normal or rapid response time via **ST2** jumper
- Voltage adjustment via potentiometer **P2**
- Other voltages via adapter transformer
- Current sensing (parallel operation): C.T. 2.5 VA cl1, secondary 1 A (optional)
- Quadrature droop adjustment via potentiometer **P1**
- Underspeed protection (U/f) and LAM: frequency threshold adjustable via potentiometer **P4**
- Max. excitation current adjustment via **P5**: 4.5 to 8 A
- 50/60 Hz selection via the **ST3** jumper

2.5.2 - R438 AVR options


- See section 2.4.2.

2.5.3 - LAM characteristics

- See section 2.4.3.

CAUTION

The ST9 jumper must be disconnected for operation using the PMG system.



LSA 43.2/44.2 - 4-POLE ALTERNATORS INSTALLATION

3 - INSTALLATION

3.1 - Assembly




All mechanical handling operations must be undertaken using approved equipment.

Whilst being handled, the machine should remain horizontal.

3.1.1 - Handling

The generously-sized lifting rings are for handling the alternator alone. They must not be used to lift the genset. Choose a lifting system which respects the positioning of the rings.



3.1.2 - Coupling

3.1.2.1 - Single-bearing alternator

Before coupling the two machines, check that both are compatible by:

- undertaking a torsional analysis of the transmission on both units
- checking the dimensions of the flywheel and its housing, the flange, coupling discs and offset

CAUTION

When coupling the alternator to the prime mover, the holes of the coupling discs should be aligned with the flywheel holes by cranking the engine.

Do not use the alternator fan to turn the rotor.

Tighten the coupling disc screws to the recommended torque (see section 4.6.2) and check that there is lateral play on the crankshaft.

3.1.2.2 - Two-bearing alternator

- Semi-flexible coupling

Careful alignment of the machines is recommended, checking that the concentricity and parallelism of both parts of the coupling does not exceed 0.1 mm.

CAUTION

This alternator has been balanced with a half-key.

3.1.3 - Location

Ensure that the ambient temperature in the room where the alternator is placed cannot exceed 40 °C for standard power ratings (for temperatures > 40 °C, apply a derating coefficient). Fresh air, free from damp and dust, must be able to circulate freely around the air intake grilles on the opposite side from the coupling. It is essential to prevent not only the recycling of hot air from the machine or engine, but also exhaust fumes.

3.2 - Inspection prior to first use

3.2.1 - Electrical checks



Under no circumstances should an alternator, new or otherwise, be operated if the insulation is less than 1 megohm for the stator and 100,000 ohms for the other windings.

There are three possible methods for restoring the above minimum values.

- a) Dry out the machine for 24 hours in a drying oven at a temperature of approximately 110 °C (without the AVR).
- b) Blow hot air into the air inlet, having made sure that the machine is rotating with the exciter field disconnected.
- c) Run in short-circuit mode (disconnect the AVR):

- Short-circuit the three output terminals (power) using connections capable of supporting the rated current (try not to exceed 6 A/mm²)

- Insert a clamp ammeter to monitor the current passing through the short-circuit connections

- Connect a 48 Volt battery in series with a rheostat of approximately 10 ohms (50 W) to the exciter field terminals, respecting the polarity

- Open all the alternator openings fully

- Run the alternator at its rated speed, and adjust the exciter field current using the rheostat to obtain the rated output current in the short-circuit connections

Note: Prolonged standstill: In order to avoid these problems, we recommend the use of space heaters, as well as turning over the machine from time to time. Space heaters are only really effective if they are working continuously while the machine is stopped.

LSA 43.2/44.2 - 4-POLE ALTERNATORS INSTALLATION

3.2.2 - Mechanical checks

Before starting the machine for the first time, check that:

- the fixing bolts on the feet are tight
- the cooling air is drawn in freely
- the protective grilles and housing are correctly in place
- the standard direction of rotation is clockwise as seen from the shaft end (phase rotation in order 1-2-3). For anti-clockwise rotation, swap 2 and 3.
- the winding connection corresponds to the site operating voltage (see section 3.3)

3.3 - Terminal connection diagrams

To modify the connection, change the position of the terminal cables. The winding code is specified on the nameplate.



Any intervention on the alternator terminals during reconnection or checks should be performed with the machine stopped.

Connection codes	L.L voltage			Factory connection
(A) 3 phases 	Winding	50 Hz	60 Hz	
	6	190 - 208	190 - 240	
	7	220 - 230	-	
	8	-	190 - 208	
(D) 3 phases 	Winding	50 Hz	60 Hz	
	6	380 - 415	380 - 480	
	7	440 - 460	-	
	8	-	380 - 416	
(FF) 1 phase 	Winding	50 Hz	60 Hz	
	6	220 - 240	220 - 240	
	7	250 - 260	-	
	8	200	220 - 240	
(F) 1 phase ou 3 phases 	Winding	50 Hz	60 Hz	
	6	220 - 240	220 - 240	
	7	250 - 260	-	
	8	200	220 - 240	

LM voltage = 1/2 LL voltage

LM voltage = 1/2 LL voltage

LSA 43.2/44.2 - 4-POLE ALTERNATORS INSTALLATION


Connection codes			L.L voltage			Factory connection																																																														
<div><div><div>B</div></div><div>1 phase or 3 phases</div><div><div>L1(V)</div><div>L3(W)</div><div>L2(V)</div></div></div>	Winding	50 Hz	60 Hz	<div><div>L3(W)</div><div>L2(V)</div><div>L1(U)</div></div> <div>AR</div>																																																																
	6	110 - 120	120																																																																	
	7	120 - 130	-																																																																	
	8	-	110 - 120																																																																	
	R 230 voltage sensing: 0 => (T8) / 110 V => (T11) R 438 LS voltage sensing: 0 => (T3) / 110 V => (T2)																																																																			
<div><div><div>G</div></div><div>1 PH</div><div>Connection not recommended</div><div><div>M</div><div>L</div><div>L</div></div></div>	Winding	50 Hz	60 Hz	<div><div>M</div><div>L</div><div>L</div></div> <div>AR</div>																																																																
	6	220 - 240	220 - 240																																																																	
	7	250 - 260	-																																																																	
	8	200	220 - 240																																																																	
	R 230 voltage sensing: 0 => (T8) / 110 V => (T11) R 438 LS voltage sensing: 0 => (T3) / 220 V => (T2)																																																																			
LM voltage = 1/2 LL voltage																																																																				
SINGLE-PHASE 4-WIRE - type M or M1 DEDICATED WINDING																																																																				
<div><div>SERIAL CONNECTION</div><div><div>L</div><div>M</div><div>L</div></div></div>						<div><div>PARALLEL CONNECTION (Not possible with LSA 44.2)</div><div><div>L</div><div>M</div><div>L</div></div></div>																																																														
<table><tr><th colspan="2">Voltage 50/60 Hz</th><th></th><th colspan="3">Output</th></tr><tr><th>L - L</th><th>L - M</th><th>Link</th><th>L</th><th>L</th><th>M</th></tr><tr><td>220</td><td>110</td><td></td><td></td><td></td><td></td></tr><tr><td>230</td><td>115</td><td>T2 - T3</td><td>T1</td><td>T4</td><td>T2 - T3</td></tr><tr><td>240</td><td>120</td><td></td><td></td><td></td><td></td></tr></table>						Voltage 50/60 Hz			Output			L - L	L - M	Link	L	L	M	220	110					230	115	T2 - T3	T1	T4	T2 - T3	240	120					<table><tr><th colspan="2">Voltage 50/60 Hz</th><th></th><th colspan="3">Output</th></tr><tr><th>L - L</th><th>L - M</th><th>Link</th><th>L</th><th>L</th><th>M</th></tr><tr><td>110</td><td>-</td><td></td><td></td><td></td><td></td></tr><tr><td>115</td><td>-</td><td>T1 - T3 T2 - T4</td><td>T1-T3</td><td>T2 - T4</td><td>-</td></tr><tr><td>120</td><td>-</td><td></td><td></td><td></td><td></td></tr></table>			Voltage 50/60 Hz			Output			L - L	L - M	Link	L	L	M	110	-					115	-	T1 - T3 T2 - T4	T1-T3	T2 - T4	-	120	-				
Voltage 50/60 Hz			Output																																																																	
L - L	L - M	Link	L	L	M																																																															
220	110																																																																			
230	115	T2 - T3	T1	T4	T2 - T3																																																															
240	120																																																																			
Voltage 50/60 Hz			Output																																																																	
L - L	L - M	Link	L	L	M																																																															
110	-																																																																			
115	-	T1 - T3 T2 - T4	T1-T3	T2 - T4	-																																																															
120	-																																																																			
R 230 voltage sensing: 0 => (T1) / 110 V => (T2)						R 230 voltage sensing: 0 => (T1) / 110 V => (T2)																																																														

3.3.1 - Exciter field connection

Series connection (shunt excitation)	Parallel connection (AREP or PMG excitation)

LSA 43.2/44.2 - 4-POLE ALTERNATORS INSTALLATION

3.3.2 - Option connection diagram




3.3.3 - Connection checks



Electrical installations must comply with the current legislation in force in the country of use.

Check that:

- The residual circuit-breaker complies with legislation on protection of personnel in force in the country of use, and has been correctly installed on the alternator power output as close as possible to the alternator. (In this case, disconnect the blue wire of the R 791 interference suppression module linking the neutral)
- Any protective devices in place have not tripped
- If there is an external AVR, the connections between the alternator and the cubicle are made in accordance with the connection diagram
- There is no short-circuit between phase or phase-neutral between the alternator output terminals and the generator set control cabinet (part of the circuit not protected by circuit-breakers or cubicle relays)
- The machine has been connected with the busbar separating the terminals as shown in the terminal connection diagram



3.3.4 - Electrical checks on the AVR

- Check that all connections have been made properly as shown in the attached wiring diagram.
- Check that the "ST3" frequency selection jumper is on the correct frequency setting
- Check whether the ST4 jumper or the remote adjustment potentiometer have been connected
- Optional operating modes (LS R 438)
 - ST1 jumper: disconnected to connect the R 731 3-phase sensing module
 - ST2 jumper: cut for rapid response time
 - ST5 jumper: cut to suppress the function

3.4 - Commissioning



The machine can only be started up and used if the installation is in accordance with the regulations and instructions defined in this manual.

The machine is tested and set at the factory. When first used with no load, make sure that the drive speed is correct and stable (see the nameplate). On application of the load, the machine should achieve its rated speed and voltage; however, in the event of abnormal operation, the machine setting can be altered (follow the adjustment procedure: see section 3.5). If the machine still operates incorrectly, the cause of the malfunction must be located (see section 4.4).

3.5 - Setting up



The various adjustments during tests must be made by a qualified engineer. Take care that the drive speed specified on the nameplate is reached before commencing adjustment. After operational testing, replace all access panels or covers.

The AVR is used to make any adjustments to the machine.

3.5.1 - R 230 adjustments (shunt system)



LSA 43.2/44.2 - 4-POLE ALTERNATORS INSTALLATION


Initial potentiometer settings

- **P1** potentiometer (AVR voltage adjustment): fully anti-clockwise.
- Remote voltage adjustment potentiometer: centre position. Run the alternator at its rated speed. If the voltage does not increase, the magnetic circuit should be remagnetized (see section 4.5)
- Turn the AVR voltage adjustment potentiometer **P1** slowly until the output voltage rated value is obtained
- Adjust the stability setting using **P2**
- Sealed potentiometer **P3** is factory set at 48 Hz for 50 Hz and 57.5 Hz for 60 Hz

3.5.2 - LS R 438 adjustments (AREP or PMG system)

CAUTION

Before any intervention on the AVR, make sure that the **ST9** jumper is closed with AREP excitation and disconnected with PMG excitation.



a) Initial potentiometer settings (see table below)

- Remote voltage adjustment potentiometer: centre (ST4 jumper removed).

Action	Factory setting	Pot.
Voltage minimum fully anti-clockwise	400V - 50 Hz (Input 0 - 380 V)	
Stability	Not set (centre position)	
Threshold/LAM or U/F Threshold for underspeed protection and Max. frequency "LAM" tripping, fully anti-clockwise	If ST3 = 50 Hz (factory) = 48 Hz If ST3 = 60 Hz (factory) = 58 Hz	
Voltage quadrature droop (Parallel operation with C.T.) - 0 quadrature droop fully anti-clockwise.	Not set (fully anti-clockwise)	
Excitation ceiling Limiting of excitation current and short-circuit current, minimum fully anti-clockwise	10 A maximum	

b) Install a D.C. analogue voltmeter (needle dial) cal. 50 V on terminals E+, E- and an A.C. voltmeter cal 300, 500 or 1000 V on the alternator output terminals.

c) Make sure that the **ST3** jumper is positioned on the desired frequency (50 or 60 Hz).

d) Voltage potentiometer **P2** at minimum, fully anti-clockwise.

e) Turn the V/Hz potentiometer **P4** fully clockwise.

f) Stability potentiometer **P3** to around 1/3 of the anti-clockwise limit.

g) Start the engine and set its speed to a frequency of 48 Hz for 50 Hz, or 58 for 60 Hz.

h) Set the output voltage to the desired value using **P2**.

- rated voltage UN for solo operation (eg. 400 V)
 - or UN + 2 to 4% for parallel operation with C.T. (eg. 410 V -)
- If the voltage oscillates, use P3 to make adjustments (try both directions) observing the voltage between E+ and E- (approx. 10 V D.C.). The best response times are obtained at the limit of the instability. If no stable position can be obtained, try disconnecting or replacing the ST2 jumper (normal/rapid).

i) Check LAM operation: **ST5** closed

j) Turn potentiometer **P4** slowly anti-clockwise until there is a significant voltage drop (approximately 15%)

k) Vary the frequency (speed) around 48 or 58 Hz according to the operating frequency, and check the change in voltage from that observed previously (~ 15%).

l) Readjust the speed of the unit to its rated no-load value.

Adjustments in parallel operation

Before any intervention on the alternator, make sure that the speed droop is identical for all engines.

m) Preset for parallel operation (with C.T. connected to S1, S2 on connector J2)

Potentiometer P1 (quadrature droop) in centre position.

Apply the rated load (P.F. = 0.8 inductive).

The voltage should drop by 2 to 3%. If it increases, swap the 2 incoming wires of the C.T. secondary.

n) The no-load voltages should be identical for all the alternators intended to run in parallel.

- Couple the machines in parallel
- By adjusting the **speed**, try to obtain **0 kW** power exchange
- By altering the voltage setting P2 or Rhe on one of the machines, try to cancel (or minimize) the **current** circulating between the machines


From now on, do not touch the voltage settings.

o) Apply the available load (the setting is only correct if a **reactive** load is available).

- By altering the **speed**, match the **kW** (or divide the rated power of the units proportionally)
- By altering the quadrature droop potentiometer **P1**, match or divide the **currents**

LSA 43.2/44.2 - 4-POLE ALTERNATORS INSTALLATION

3.5.3 - Max. excitation setting (excitation ceiling)



Static adjustment of the current limit, potentiometer P5 (factory setting: 7.5 A, fuse rating: 8 A - 10 seconds). The factory setting corresponds to that of the excitation current required to obtain a 3-phase short-circuit current of approximately $3 I_N$ at 50 Hz for industrial power, unless otherwise specified (*).

A static method can be used to reduce this value or adapt the I_{sc} to the actual operating power (derated machine), which is safer for the alternator and the installation. Disconnect power supply wires X1, X2 and Z1, Z2, and the voltage reference (0-110 V-220V-380 V) on the alternator.

Connect the mains power supply (200-240 V) as indicated (X1, X2): 48 V). Install a 10A D.C. ammeter in series with the exciter field. Turn P5 fully anti-clockwise and activate the power supply. If there is no output current from the AVR, turn potentiometer P2 (voltage) clockwise until the ammeter indicates a stable current. Switch the power supply off, then on again, turn P5 clockwise until the required max. current is obtained (no more than 8 A).

Checking the internal protection:

Open switch (D): the excitation current should increase to its preset ceiling, remain at that level for ≥ 10 seconds and then drop to < 1 A.


To reset, switch off the power supply by opening switch (A).

Note: After setting the excitation ceiling as described, adjust the voltage again (see section 3.5.2)

(*) In some countries it is a legal requirement to have a short-circuit current of $3 I_N$, so as to offer selective protection.

3.5.4 - Special type of use


- Field weakening



The exciter is switched off by disconnecting the AVR power supply (1 wire on each auxiliary winding) - contact rating 10 A - 250 V A.C.

Connection is identical for resetting the AVR internal protection.

- Field forcing



Applications	B volts	Time t
Guaranteed voltage build-up	6 (1 A)	1 - 2 s
Parallel operation, de-energized	6 (1 A)	1 - 2 s
Parallel operation, at standstill	12 (2 A)	5 - 10 s
Frequency starting	24 (4 A)	5 - 10 s
Sustained voltage on overload	24 (4 A)	5 - 10 s

LSA 43.2/44.2 - 4-POLE ALTERNATORS SERVICING / MAINTENANCE

4 - SERVICING / MAINTENANCE

4.1 - Safety measures



Servicing or troubleshooting must be carried out strictly in accordance with instructions so as to avoid the risk of accidents and to maintain the machine in its original state.



All such operations performed on the alternator should be undertaken by personnel trained in the commissioning, servicing and maintenance of electrical and mechanical components.

Before any intervention on the machine, ensure that it cannot be started by a manual or automatic system and that you have understood the operating principles of the system.

4.2 - Regular maintenance

4.2.1 - Checks after start-up

After approximately 20 hours of operation, check that all fixing screws on the machine are still tight, plus the general state of the machine and the various electrical connections in the installation.

4.2.2 - Cooling circuit

It is advisable to check that circulation of air is not reduced by partial blocking of the air intake and outlet grilles: mud, fibre, grease, etc.

4.2.3 - Bearings

The bearings are permanently greased: approximate life of the grease (depending on use) = 20,000 hours or 3 years. Monitor the temperature rise in the bearings, which must not exceed 60 °C above the ambient temperature. Should this value be exceeded, the machine must be stopped and checks carried out.

4.2.4 - Electrical servicing

Cleaning product for the windings

CAUTION

Do not use: trichlorethylene, perchlorethylene, trichloroethane or any alkaline products.

Certain strictly defined pure volatile degreasing agents can be used, such as:

- Normal petrol (without additives); inflammable
- Toluene (slightly toxic); inflammable
- Benzene (or benzine, toxic); inflammable

- Cyclohexane (non toxic); inflammable

Cleaning of the stator, rotor, exciter and diode bridge

The insulating components and the impregnation system are not at risk of damage from solvents (see the list of authorized products).

Avoid letting the cleaning product run into the slots. Apply the product with a brush, sponging frequently to avoid accumulation in the housing. Dry the winding with a dry cloth. Let any traces evaporate before reassembling the machine.

4.2.5 - Mechanical servicing

CAUTION

Cleaning the machine using a water spray or a high-pressure washer is strictly prohibited.

Any problems arising from such treatment are not covered by our warranty.

The machine should be cleaned with a degreasing agent, applied using a brush. Check that the degreasing agent will not affect the paint.

Compressed air should be used to remove any dust.

If filters have been added to the machine after manufacture and do not have thermal protection, the service personnel should clean the air filters periodically and systematically, as often as necessary (every day in very dusty atmospheres).

Cleaning can be performed using water for dry dust or in a bath containing soap or detergent in the case of greasy dust. Petrol or chloroethylene can also be used.

After cleaning the alternator, it is essential to check the winding insulation (see sections 3.2 and 4.8).

4.3 - Fault detection

If, when commissioned, the alternator does not work normally, the source of the malfunction must be identified.

To do this, check that:

- the protective devices are fitted correctly
 - the connections comply with the diagrams in the manuals supplied with the machine
 - the speed of the unit is correct (see section 1.3)
- Repeat the operations defined in section 3

LSA 43.2/44.2 - 4-POLE ALTERNATORS SERVICING / MAINTENANCE

4.4 - Mechanical defects

Fault		Action
Bearing	Excessive overheating of one or both bearings (temperature > 80 °C on the bearing retainers with or without abnormal noise)	<ul style="list-style-type: none"> - If the bearing has turned blue or if the grease has turned black, change the bearing. - Bearing not properly seated. - End shields misaligned (flanges not properly fitted).
Temperature abnormal	Excessive overheating of alternator frame (more than 40° C above the ambient temperature)	<ul style="list-style-type: none"> - Air flow (intake-outlet) partially clogged or hot air is being recycled from the alternator or engine - Alternator operating at too high a voltage (> 105% of Un on load) - Alternator overloaded
Vibration	Excessive vibration	<ul style="list-style-type: none"> - Misalignment (coupling) - Defective mounting or play in coupling - Rotor balancing fault
	Excessive vibration and humming noise coming from the machine	<ul style="list-style-type: none"> - Alternator operating in single-phase mode (single-phase load or faulty contactor or installation fault) - Stator short-circuit
Abnormal noise	Alternator damaged by a significant impact, followed by humming and vibration	<ul style="list-style-type: none"> - System short-circuit - Mis-paralleling <p>Possible consequences</p> <ul style="list-style-type: none"> - Broken or damaged coupling - Broken or bent shaft end - Shifting and short-circuit of main field - Fan fractured or coming loose on shaft - Irreparable damage to rotating diodes or AVR

4.5 - Electrical faults

Fault	Action	Effect	Check/Cause
No voltage at no load on start-up	Connect between E- and E+ a new battery of 4 to 12 volts, respecting the AVR polarities, for 2 to 3 seconds	The alternator builds up and its voltage is still correct when the battery is removed.	- Lack of residual magnetism
		The alternator builds up but its voltage does not reach the rated value when the battery is removed.	- Check the connection of the voltage reference to the AVR - Faulty diodes - Armature short-circuit
		The alternator builds up but its voltage disappears when the battery is removed	- Faulty AVR - Field windings disconnected - Main field winding open circuit. Check the resistance
Voltage too low	Check the drive speed	Correct speed	Check the AVR connections (AVR may be faulty) - Field windings short-circuited - Rotating diodes burnt out - Main field winding short-circuited - Check the resistance
		Speed too low	Increase the drive speed (Do not touch the AVR voltage pot. (P2) before running at the correct speed.)
Voltage too high	Adjust AVR voltage potentiometer	Adjustment ineffective	Faulty AVR
Voltage oscillations	Adjust AVR stability potentiometer	If no effect: try normal/rapid recovery modes (ST2)	- Check the speed: possibility of cyclic irregularity - Loose connections - Faulty AVR - Speed too low when on load (or LAM set too high)
Voltage correct at no load and too low when on load (*)	Run at no load and check the voltage between E+ and E- on the AVR	Voltage between E+ and E-SHUNT < 20 V - AREP/PMG < 10 V	- Check the speed (or LAM set too high)
		Voltage between E+ and E-SHUNT > 30 V - AREP/PMG > 15 V	- Faulty rotating diodes - Short-circuit in the main field. Check the resistance - Faulty exciter armature
(*) Caution: For single-phase operation, check that the sensing wires coming from the AVR are correctly connected to the operating terminals			
Voltage disappears during operation (**)	Check the AVR, the surge suppressor, the rotating diodes, and replace any defective components	The voltage does not return to the rated value	- Exciter winding open circuit - Faulty exciter armature - Faulty AVR - Main field open circuit or short-circuited
(**) Caution: Internal protection may be activated (overload, open circuit, short-circuit)			

LSA 43.2/44.2 - 4-POLE ALTERNATORS

SERVICING / MAINTENANCE

4.5.1 - Checking the winding

You can check the winding insulation by performing a high voltage test. In this case, you must disconnect all AVR wires.


CAUTION

Damage caused to the AVR in such conditions is not covered by our warranty.

4.5.2 - Checking the diode bridge

LSA 43.2 / 44.2 Diode bridge

Anode  Cathode



A diode in good working condition allows the current to flow in only one direction, from anode to cathode.

4.5.3 - Checking the windings and rotating diodes using separate excitation




During this procedure, make sure that the alternator is disconnected from any external load and inspect the terminal box to check that the connections are fully tightened.

- 1) Stop the unit, disconnect and isolate the AVR wires.
- 2) There are two ways of creating an assembly with separate excitation.

Assembly A: Connect a 12 V battery in series with a rheostat of approximately 50 ohms - 300 W and a diode on both exciter field wires (5+) and (6-).

ASSEMBLY A



Assembly B: Connect a "Variac" variable power supply and a diode bridge on both exciter field wires (5+) and (6-).


Both these systems should have characteristics which are compatible with the field excitation power of the machine (see the nameplate).

3) Run the unit at its rated speed.

4) Gradually increase the exciter field supply current by adjusting the rheostat or the Variac and measure the output voltages on L1 - L2 - L3, checking the excitation voltage at no load and at full load (see machine nameplate or ask for the factory test report).

When the output voltage is at its rated value and balanced within 1% for the rated excitation level, the machine is in good working order. The fault therefore comes from the AVR or its associated wiring (ie. sensing, auxiliary windings).

ASSEMBLY B




LSA 43.2/44.2 - 4-POLE ALTERNATORS

SERVICING / MAINTENANCE

4.6 - Dismantling, reassembly (see sections 5.5.1/5.5.2)



During the warranty period, this operation should only be carried out in an LEROY-SOMER approved workshop or in our factory, otherwise the warranty may be invalidated. Whilst being handled, the machine should remain horizontal (rotor not locked when moved).



4.6.1 - Tools required

To fully dismantle the machine, we recommend using the tools listed below:

- 1 ratchet spanner + extension
- 1 torque wrench
- 1 set of flat spanners: 7 mm, 8 mm, 10 mm, 12 mm
- 1 socket set: 8 mm, 10 mm, 13 mm, 16 mm, 18 mm, 21 mm, 22 mm, 24 mm
- 1 size 5 Allen key (eg. Facom: ET5)
- 1 size 6 Allen key (eg. Facom: ET6)
- 1 size 10 Allen key (eg. Facom: ET6)
- 1 size 12 Allen key (eg. Facom: ET6)
- 1 T20 and T30 TORX bit
- 1 puller (eg. Facom: U35)
- 1 puller (eg. Facom: U32/350).

4.6.2 - Screw tightening torque

IDENTIFICATION	screw Ø	Torque N.m
Field terminal block screw	M4	4 N.m
Field screw	M6	10 N.m
Diode bridge/RP	M6	5 N.m
Diode nut	M5	4 N.m
43.2 tie rod	M12	57 Nm
44.2 tie rod	M14	90 Nm
Earth screw	M8	26 Nm
43.2 disc/shaft screw	M12	110 Nm
44.2 disc/shaft screw	M14	180 Nm
44.2 turbine screw	M6	5 Nm
Grille screws	M6	5 Nm
Cover screws	M6	5 Nm
Terminal block nut	M10	20 Nm

4.6.3 - Access to connections and the regulation system

The terminals are accessed directly by removing the terminal box lid [48].

To access the AVR adjustment potentiometers, the side plate [367] should be removed.

4.6.4 - Accessing, checking and replacing diodes

4.6.4.1 - Dismantling

- Remove the air intake grille [51]
- Remove the surge suppressor [347]
- Disconnect the 6 diodes using an ohmmeter or a battery lamp (see section 4.5.2)

4.6.4.2 - Reassembly

- Replace the bridges, respecting the polarity (see section 4.5.1)
- Replace the surge suppressor [347]
- Refit the air intake grille [51]
- Replace the terminal box lid [48]

4.6.5 - Replacing the NDE bearing on single-bearing machines

4.6.5.1 - Dismantling

- Remove the terminal box lid [48]
- Remove the air intake grille [51]
- Unscrew the fixing clamps on the power output cables, remove the connector from the exciter and the R 791 module.
- Remove the 4 nuts on the tie rods
- Remove the NDE shield [36] using a puller: eg. U.32 - 350 (FACOM)
- Remove the ball bearing [70] using a screw puller



4.6.5.2 - Reassembly

- Heat the inner slipring of a new bearing by induction or in a drying oven at 80 °C (do not use an oil-bath) and fit it to the machine.

- Place the preloading wavy washer [79] in the shield and fit a new O ring seal [349].



Refit the NDE shield and pass the bundle of wires between the top bars of the shield.

- Refit the fixing clamps on the cables, the R 791 module and the exciter connector.

LSA 43.2/44.2 - 4-POLE ALTERNATORS

SERVICING / MAINTENANCE

- Refit the air intake grille [51].
- Replace the terminal box lid [48].



4.6.6 - Replacing the bearings on two-bearing machines

4.6.6.1 - Dismantling

- Uncouple the alternator from the prime mover.
- Remove the 8 assembly screws.
- Remove the DE shield [30].
- Remove the NDE shield (see section 4.6.5.1)
- Remove both ball bearings [60] and [70] using a puller with a central screw.

4.6.6.2 - Reassembly

- Heat the new bearings by induction or in a drying oven at 80 °C (do not use an oil-bath) and fit them to the machine.
- Check that both the preloading wavy washer [79] and the new O ring seal [349] have been fitted on the NDE shield [36]. Refit the NDE shield and pass the bundle of wires between the top bars of the shield.
- Refit the DE shield [30] and tighten the 4 fixing screws.
- Check that the machine assembly is correctly mounted and that all screws are tightened.

4.6.7 - Accessing the main field and stator


4.6.7.1 - Dismantling

- Follow the procedure for dismantling the bearings (see sections 4.6.5.1 and 4.6.6.1)
- Remove the coupling disc (single-bearing machine) or the DE end shield (two-bearing machine) and insert a tube of the corresponding diameter on the shaft end or a support made according to the following diagram.
 - Rest the rotor on one of its poles, then slide it out. Use the tube as a lever arm to assist dismantling.
 - After extraction of the rotor, be careful not to damage the fan. If the fan is dismantled, it is essential that it is replaced for the 43.2.

NOTE: If intervention is required on the main field (rewinding, replacement of components), the rotor assembly must be rebalanced.

4.6.7.2 - Reassembling the main field

- Follow the dismantling procedure in reverse order. Take care not to knock the windings when refitting the rotor in the stator.
- If the fan is being replaced on the 43.2, assemble the parts as shown in the following diagram. Fit a tube and a threaded screw. On the 44.2 the fan is fixed by screws on the hub.



Follow the procedure for reassembling the bearings (see sections 4.6.5.2 and 4.6.6.2).



After operational testing, replace all access panels or covers.

4.7 - Installation and maintenance of the PMG

For the LSA 43.2 and LSA 44.2, the PMG reference is PMG 1.

4.7.1 - Mechanical characteristics

The components are:

- An adaptation shaft (to position the rotor on the shaft extension)
- A tie rod and nut for assembling the rotor on the shaft
- A rotor with 16 magnets
- An assembly consisting of: housing + wound stator + plastic connection sheath + plastic ferrules
- The housing closure cover (4 CBLXS M5 screws)

LSA 43.2/44.2 - 4-POLE ALTERNATORS

SERVICING / MAINTENANCE

- 4 HM6 screws (for fixing the housing to the NDE shield)

If mounting in kit form, follow the following instructions (see section 5.4):

1 - Remove the PMG cover [297] and the alternator NDE shield seal.

2 - Mount the PMG housing assembly [290] on the shield using the 4 HM6 screws.

3 - Put a coating of anti-vibration adhesive on the tie rod [295] and fix it on the alternator shaft extension.

4 - Mount the magnetized rotor on the adaptation shaft, then using 2 threaded rods screwed into the rotor, slide the assembly onto the tie rod.

5 - Install the cable gland washer [296].

6 - Tighten the assembly with the M10 nut.

7 - Close the PMG with the cover [297].

8 - Pierce the cover (Ø 21 hole) and insert the plastic sheath and its ferrule.

9 - Connect the PMG to the AVR (see sections 2.5 and 4.7.2).

4.7.2 - Electrical connection

Mounting the PMG-1 on a SHUNT machine

(when using an R438):

- Disconnect the connection wires from the R 230/A and remove the AVR.

- Take out both the R 230/A voltage reference wires, marked 2 and 3, by removing them from the terminals (T8 and T11) in which they are inserted.

- Use these same wires for voltage sensing on the R 438 by inserting them in terminals T2 (wire 2) and T3 (wire 3).

- Fit the AVR support plate fitted with the R 438 (2 HM6 screws tightened to 10 Nm).

- Connect the 3 PMG wires (14/15/16), the 2 exciter field wires (5/6) and the 2 previously mentioned voltage sensing wires (2/3) according to the connection diagram no. 2725-02-98.

- Modify the connection by replacing the single jumper on the connector located on the terminal box rear panel with 2 jumpers (see internal connection diagram).

Mounting the PMG-1 on an AREP machine

- Connect the 3 PMG wires (14/15/16), to terminals X1, X2, Z2 on the AVR. The 4 auxiliary winding wires X1.X2.Z1.Z2 should be isolated using the domino fitting supplied with the kit. Both exciter field wires (5/6) and the voltage sensing wires (2/3) remain in place.

Electrical characteristics of the PMG

Stator phase/phase resistance 20 °C: 0.7 Ω

No-load voltage : 73 V

4.8 - Electrical characteristics

Table of average values:

Alternator - 2 and 4 poles - 50 Hz/60 Hz - Winding n° 6 and M or M1 connected in dedicated single-phase. (400 V for the excitation values).

The voltage and current values are given for no-load operation and operation at rated load with separate field excitation. All values are given at ± 10% (for exact values, consult the test report) and are subject to change without prior warning. For 60 Hz machines, the resistance values are the same and the excitation current "i exc" is approximately 5 to 10% weaker.

4.8.1 - 3-phase LSA 43.2: 4-pole, SHUNT excitation

Resistances at 20 °C (Ω)

LSA 43.2	S1	S2	S3	M4	L6	L7
Stator L/N	0.155	0.155	0.128	0.105	0.083	0.063
Rotor	1.35	1.35	1.41	1.57	1.76	1.96
Field	19.5	19.5	19.5	19.5	19.5	19.5
Armature	0.23	0.23	0.23	0.23	0.23	0.23

Field excitation current i exc (A) - 400 V - 50 Hz

"i exc": excitation current of the exciter field

LSA 43.2	S1	S2	S3	M4	L6	L7
No load	0.5	0.5	0.5	0.5	0.4	0.5
On load	1.6	1.6	1.7	1.6	1.5	1.6

4.8.2 - 3-phase LSA 43.2: 4-pole, AREP excitation

Resistances at 20 °C (Ω)

LSA 43.2	S1	S2	S3	M4	L6	L7
Stator L/N	0.155	0.155	0.128	0.105	0.083	0.063
Rotor	1.35	1.35	1.41	1.57	1.76	1.96
X1, X2 auxil. wdgs	0.32	0.32	0.29	0.26	0.26	0.21
Z1, Z2 auxil. wdgs	0.52	0.52	0.5	0.51	0.44	0.4
Field	4.9	4.9	4.9	4.9	4.9	4.9
Armature	0.23	0.23	0.23	0.23	0.23	0.23

Field excitation current i exc (A) - 240 V - 60 Hz

"i exc": excitation current of the exciter field

LSA 43.2	S1	S2	S3	M4	L6	L7
No load	1	1	1	1	0.9	1
On load	3.2	3.2	3.4	3.2	3	3.2

LSA 43.2/44.2 - 4-POLE ALTERNATORS

SERVICING / MAINTENANCE

4.8.3 - Dedicated single-phase LSA 43.2: 4-pole, SHUNT excitation (60 Hz only)

Resistances at 20 °C (Ω)

LSA 43.2	S1	S2	S3	M4	L6	L7
Stator L/N	0.058	0.058	0.046	0.037	0.027	0.019
Rotor	1.35	1.35	1.41	1.57	1.76	1.96
Field	13.9	13.9	13.9	13.9	13.9	13.9
Armature	0.23	0.23	0.23	0.23	0.23	0.23

Field excitation current i_{exc} (A) -240 V -60 Hz

" i_{exc} ": excitation current of the exciter field

LSA 43.2	S1	S2	S3	M4	L6	L7
No load	0.59	0.59	0.66	0.61	0.62	0.74
On load	1.44	1.68	1.65	1.48	1.48	1.46

4.8.4 - 3-phase LSA 44.2: 4-pole, SHUNT excitation

Resistances at 20 °C (Ω)

LSA 44.2	VS3	VS4	S7	M9	L11	L12
Stator L/N	0.046	0.046	0.036	0.024	0.019	0.019
Rotor	2,51	2,51	2,91	3.32	3.66	3.66
Field	19.5	19.5	19.5	19.5	19.5	19.5
Armature	0.5	0.5	0.5	0.5	0.5	0.5

Field excitation current i_{exc} (A) - 400 V - 50 Hz

" i_{exc} ": excitation current of the exciter field

LSA 44.2	VS3	VS4	S7	M9	L11	L12
No load	0.5	0.5	0.5	0.6	0.6	0.6
On load	1.6	1.6	1.7	1.6	1.5	1.6

4.8.5 - 3-phase LSA 44.2: 4-pole, AREP excitation

Resistances at 20 °C (Ω)

LSA 44.2	VS3	VS4	S7	M9	L11	L12
Stator L/N	0.046	0.046	0.036	0.024	0.019	0.019
Rotor	2,51	2,51	2,91	3.32	3.66	3.66
X1, X2 auxil. wdgs	0.3	0.3	0.21	0.17	0.16	0.16
Z1, Z2 auxil. wdgs	0.5	0.5	0.32	0.28	0.21	0.21
Field	4.9	4.9	4.9	4.9	4.9	4.9
Armature	0.5	0.5	0.5	0.5	0.5	0.5

Field excitation current i_{exc} (A) -240 V -60 Hz

" i_{exc} ": excitation current of the exciter field

LSA 44.2	VS3	VS4	S7	M9	L11	L12
No load	1	1	1	1015	1.2	1.2
On load	4	4.4	4.1	3.7	3.7	4

4.8.6 - Dedicated single-phase LSA 44.2: 4-pole, SHUNT excitation (60 Hz only)

Resistances at 20 °C (Ω)

LSA 44.2	VS3	VS4	S7	M9
Stator L/N	0.0194	0.0194	0.0140	0.0088
Rotor	2.51	2.51	2.91	3.32
Field	19.5	19.5	19.5	19.5
Armature	0.5	0.5	0.5	0.5

Field excitation current i_{exc} (A) -240 V -60 Hz

" i_{exc} ": excitation current of the exciter field

LSA 44.2	VS3	VS4	S7	M9
No load	0.44	0.44	0.43	0.55
On load	1.18	1.25	1.2	1.28

LEROY-SOMER	INSTALLATION AND MAINTENANCE	Ref. 3434 GB - 4.33/a - 03.01
LSA 43.2/44.2 - 4-POLE ALTERNATORS SPARE PARTS		

5 - SPARE PARTS

5.1 - First maintenance parts

Emergency repair kits are available as an option.
They contain the following items:

Ref.	Designation	Qty	LSA 43.2/44.2 - SHUNT	Code
198	AVR	1	R 230	AEM 110 RE 001
343	Diode bridge assembly	1	LSA 432 9 03/04	ESC 040 MD 003
347	Surge suppressor	1	LSA 432 1 13	CII 111 PM 002
	AVR fuse	1	250 V - 8 A/slow-blow	

Ref.	Designation	Qty	LSA 43.2/44.2 - AREP 4 P	Code
198	AVR	1	R 438	AEM 110 RE 003
343	Diode bridge assembly	1	LSA 432 9 03/04	ESC 040 MD 003
347	Surge suppressor	1	LSA 432 1 13	CII 111 PM 002
	AVR fuse	2	250 V - 8 A/fast-blow	

5.2 - Bearing designations

Ref.	Designation	Qty	LSA 43.2	Code	LSA 44.2	Code
60	Bearing on shaft extension end	1	6312 2RS/C3	RLT060TS030	6315 2RS/C3	RLT075TS030
70	Bearing on exciter end	1	6307 2RS/C3	RLT080RB002	6309 2RS/C3	RLT100RB005

5.3 - Technical support service

Our technical support service will be pleased to provide any additional information you may require.

When ordering spare parts, you should indicate the complete machine type, its serial number and the information given on the nameplate.

Address your enquiry to your usual contact, or to:

MOTEURS LEROY-SOMER

Usine de Sillac/Alternateurs
16015 ANGOULEME CEDEX - FRANCE
Tel.: (33) 05.45.64.45.64
Technical Support Service:
(33) 05.45.64.43.66 - (33) 05.45.64.43.67 -
(33) 05.45.64.43.68 - (33) 05.45.64.43.69
Fax: (33) 05.45.64.43.24
email: sat.sil@leroy-somer.com

CAUTION

Part numbers should be identified from the exploded views and their description from the parts list.

Our extensive network of service centres can dispatch the necessary parts without delay.


To ensure correct operation and the safety of our machines, we recommend the use of original manufacturer spare parts.

In the event of failure to comply with this advice, the manufacturer cannot be held responsible for any damage.

LSA 43.2/44.2 - 4-POLE ALTERNATORS SPARE PARTS

5.4 - Exploded views, parts list


5.4.1 - Single-bearing LSA 43.2/44.2



N°	Nbr	Description	N°	Nbr	Description
1	1	Stator assembly	120	1	Terminal block support (AREP)
4	1	Rotor assembly	124	1	Terminal block
15	1	Fan	198	1	Voltage regulator (AVR)
16	6	Fixing screws (44.2 only)	207	1	AVR damper seal
28	1	Earth terminal	217	1	Terminal block
30	1	DE shield	290	1	PMG housing
33	1	Air outlet grille	291	1	Adaptation shaft
36	1	Shield on exciter end	292	1	Magnetic rotor
37	4	Tie rod	293	1	Stator
41	1	Cover front panel	294	2	Fixing screws
47	1	Cover rear panel	295	1	Tie rod
48	1	Cover top panel	296	1	Cable gland washer + nut
49	34	Fixing screws	297	1	End plate
51	1	Air intake grille	320	1	Hub (43.2 L7 & 44.2 only)
59	3	Inspection door	322	1	Coupling disc
70	1	NDE bearing	323	-	Fixing screws
79	1	Preloading wavy washer	324	1	Clamping washer
90	1	Exciter field	325	-	Spacer shim (43.2 L7 & 44.2 only)
91	4	Exciter field fixing screw	343	1	Diode bridge assembly
100	1	Exciter armature	347	1	Surge suppressor
107	1	Diode crescent support	349	1	"O" ring


LSA 43.2/44.2 - 4-POLE ALTERNATORS SPARE PARTS

5.4.2 - Two-bearing LSA 43.2/44.2



N°	Nbr	Description	N°	Nbr	Description
1	1	Stator assembly	91	4	Exciter field fixing screw
4	1	Rotor assembly	100	1	Exciter armature
15	1	Fan	107	1	Diode crescent support
16	6	Fixing screws (44.2 only)	120	1	Terminal block support (AREP)
28	1	Earth terminal	124	1	Terminal block
30	1	DE shield	198	1	Voltage regulator (AVR)
33	1	Air outlet grille	207	1	AVR damper seal
36	1	Shield on exciter end	217	1	Terminal block
37	4	Tie rod	290	1	PMG housing
41	1	Cover front panel	291	1	Adaptation shaft
47	1	Cover rear panel	292	1	Magnetic rotor
48	1	Cover top panel	293	1	Stator
49	34	Fixing screws	294	2	Fixing screws
51	1	Air intake grille	295	1	Tie rod
59	3	Inspection door	296	1	Cable gland washer + nut
60	1	DE bearing	297	1	End plate
62	2/4	Bearing retainer fixing screw	320	1	Hub (44.2 only)
63	1	Cable gland washer	343	1	Diode bridge assembly
67	1	Circlips	347	1	Surge suppressor
68	1	Inner bearing retainer	349	1	"O" ring
70	1	NDE bearing	410	1	End shield
79	1	Preloading wavy washer			
90	1	Exciter field			

LEROY-SOMER	INSTALLATION AND MAINTENANCE	Ref. 3434 GB - 4.33/a - 03.01
LSA 43.2/44.2 - 4-POLE ALTERNATORS NOTES		



MOTEURS LEROY-SOMER 16015 ANGOULÊME CEDEX - FRANCE

RCS ANGOULÊME N° B 671 820 223
Limited company with capital of 131,910,700 FF

<http://www.leroy-somer.com>