



Doosan Infracore  
Portable Power



# Truck Mounted Equipment

## Operation & Maintenance Manual

### Compressor Module

### VHP600CM

*Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.*



**This manual contains important safety information.**

**Do not destroy this manual.**

**This manual must be available to the personnel who operate and maintain this machine.**

Doosan Infracore Portable Power  
1293 Glenway Drive  
Statesville, NC 28625  
[www.doosanportablepower.com](http://www.doosanportablepower.com)

Book: 23362551 (9/08) Rev A  
**Revised (10-12)**



---

# TABLE OF CONTENTS

## Operation & Maintenance Manual

TITLE	PAGE
<b>SAFETY</b> .....	<b>5</b>
Safety Precautions .....	6
General Information .....	6
Safety Labels .....	9
 <b>INSTALLATION</b> .....	 <b>17</b>
System Description - General .....	18
Mounting Unit .....	19
Inlet Piping .....	19
Piping - General .....	20
Compressor Discharge Piping .....	20
Receiver Separator Discharge Piping .....	21
Wiring .....	21
Driver .....	21
Regulation .....	22
 <b>GENERAL DATA</b> .....	 <b>23</b>
Unit Model - VHP600CM .....	24
 <b>OPERATING INSTRUCTIONS</b> .....	 <b>25</b>
Set-Up .....	26
Procedure For Airend Oil Priming .....	26
Before Starting .....	27
Starting/Operating .....	28
Stopping .....	29
Equipment Protection .....	29
High Discharge Air Temperature .....	29
Operating Instruments .....	30
On Panel .....	30
Inside .....	30
Pressure Regulator Adjusting Instructions .....	31
Before Starting .....	31
After Starting Unit .....	31

# TABLE OF CONTENTS

## Operation & Maintenance Manual

TITLE	PAGE
<b>MAINTENANCE</b> .....	<b>33</b>
General .....	34
Scheduled Maintenance .....	34
Compressor Oil Level .....	35
Aircleaner .....	35
Gauges .....	36
Compressor Oil and Hydraulic Oil Combination Cooler .....	36
Hoses .....	37
Compressor Oil Filter .....	37
Fasteners .....	39
Receiver-Separator Systems .....	39
Scavenge Line .....	40
Oil Separator Element .....	40
Exterior Finish Care .....	41
Drive Belt .....	42
Field Repair Texture Paint .....	42
Maintenance Schedule .....	44
 <b>LUBRICATION</b> .....	 <b>45</b>
General Information .....	46
Compressor Oil Change .....	47
Portable Compressor Fluid Chart .....	48
 <b>TROUBLE SHOOTING</b> .....	 <b>51</b>
Introduction .....	52
Action Plan .....	52
Think Before Acting .....	52
Do the Simplest Things First .....	52
Double Check Before Disassembly .....	53
Find and Correct Basic Cause .....	53
Trouble Shooting Chart .....	54



# **Safety**

## Safety

### Safety Precautions

#### General Information

Ensure that the operator reads and understands the decals and consults the manuals before maintenance operation.

Ensure that the Operation and Maintenance manual, and the manual holder if equipped, are not removed permanently from the machine.

Ensure that maintenance personnel are adequately trained, competent and have read the manuals.

Make sure that all protective covers are in place and that the canopy/doors are closed during operation.

The specification of this machine is such that the machine is not suitable for use in flammable gas risk areas. If such an application is required, then all local regulations, codes of practice and site rules must be observed. To ensure that the machine can operate in a safe and reliable manner, additional equipment such as gas detection, exhaust spark arrestors, and intake (shutoff) valves may be required, dependent on local regulations or the degree of risk involved.

Air discharged from this machine may contain carbon monoxide or other contaminants, which will cause serious injury or death. Do not breathe this air.

Compressed air can be dangerous if incorrectly handled. Before doing any work on the unit, ensure that all pressure is vented from the system and that the machine cannot be started accidentally.

Ensure that the machine is operating at the rated pressure and that all relevant personnel know the rated pressure.

All air pressure equipment installed in or connected to the machine must have safe working pressure ratings of at least the machine safety valve rating.

If more than one compressor is connected to one common downstream plant, effective check valves and isolation valves must be fitted and controlled by work procedures, so that one machine cannot accidentally be pressurized or over pressurized by another.

Compressed air must not be used for a feed to any form of breathing apparatus or mask.

The discharged air contains a very small percentage of compressor lubricating oil and care should be taken to ensure that downstream equipment is compatible.

If the discharged air is to be ultimately released into a confined space, adequate ventilation must be provided.

When using compressed air, always use appropriate personal protective equipment.

All pressure containing parts, especially flexible hoses and their couplings, must be regularly inspected, be free from defects and be replaced according to the Manual instructions.

Avoid bodily contact with compressed air.

The safety valve located in the separator tank must be checked periodically for correct operation.

Never operate unit without first observing all safety warnings and carefully reading the operation and maintenance manual shipped from the factory with this machine.

Never operate the engine of this machine inside a building without adequate ventilation. Avoid breathing exhaust fumes when working on or near the machine. Do not alter or modify this machine.

A battery contains sulfuric acid and can give off gases, which are corrosive and potentially explosive. Avoid contact with skin, eyes and clothing. In case of contact, flush area immediately with water.

Exercise extreme caution when using booster battery. To jump battery, connect ends of one booster cable to the positive (+) terminal of each battery. Connect one end of other cable to the negative (-) terminal of the booster battery and other end to a ground connection away from dead battery (to avoid a spark occurring near any explosive gases that may be present). After starting unit, always disconnect cables in reverse order.

Never operate unit without first observing all safety warnings and carefully reading the operation and maintenance manual shipped from the factory with this machine.

This machine may include such materials as oil, diesel fuel, antifreeze, brake fluid, oil/air filters and batteries which may require proper disposal when performing maintenance and service tasks. Contact local authorities for proper disposal of these materials.

Air discharged from this machine may contain carbon monoxide or other contaminants, which will cause serious injury or death. Do not breathe this air.

High Pressure Air can cause serious injury or death. Relieve pressure before removing filler plugs/caps, fittings or covers.

Air pressure can remain trapped in air supply line, which can result in serious injury or death. Always carefully vent air supply line at tool or vent valve before performing any service.

This machine produces loud noise with the doors open or service valve vented. Extended exposure to loud noise can cause hearing loss. Always wear hearing protection when doors are open or service valve is vented.

Never inspect or service unit without first disconnecting battery cable(s) to prevent accidental starting.

Do not remove the pressure cap from a HOT radiator. Allow radiator to cool down before removing pressure cap.

Do not use petroleum products (solvents or fuels) under high pressure as this can penetrate the skin and result in serious illness. Wear eye protection while cleaning unit with compressed air to prevent debris from injuring eye(s).

Disconnect air hoses whip and can cause serious injury or death. Always attach a safety flow restrictor to each hose at the source of supply or branch line in accordance with OSHA Regulation 29CFR Section 1926.302 (b).

Hot pressurized fluid can cause serious burns. Do not open radiator while hot.

Rotating fan blade can cause serious injury. Do not operate without guard in place.

Use care to avoid contacting hot surfaces (engine exhaust manifold and piping, air receiver and air discharge piping, etc.).

Ether is an extremely volatile, highly flammable gas. USE SPARINGLY! If too much is injected, it may result in costly damage to the engine.

Never allow the unit to sit stopped with pressure in the receiver – separator system. As a precaution, open the manual blowdown valve.

Never operate unit with guards, covers or screens removed. Keep hands, hair, clothing, tools, etc. well away from moving parts.

Make sure wheels, tires and tow bar connectors are in safe operating condition and tow bar is properly connected before towing.

Whenever the machine is stopped, air will flow back into the compressor system from devices or systems downstream of the machine unless the service valve is closed. Install a check valve at the machine service valve to prevent reverse flow in the event of an unexpected shutdown when the service valve is open.

### **Hazardous Substance Precaution**

The following substances are used in the manufacture of this machine and may be hazardous to health if used incorrectly.

**Precaution:** Avoid ingestion, skin contact and breathing fumes for the following substances: Antifreeze, Compressor Oil, Engine Lubricating Oil, Preservative Grease, Rust Preventative, Diesel Fuel and Battery Electrolyte.

The following substances may be produced during the operation of this machine and may be hazardous to health:

- Avoid build-up of Engine Exhaust Fumes in confined spaces.
- Avoid breathing Exhaust Fumes.
- Avoid breathing Brake Lining Dust during maintenance.

## Safety Labels

Look for these signs on machines shipped to international markets outside North America, which point out potential hazards to the safety of you and others. Read and understand thoroughly. Heed warnings and instructions. If you do not understand, inform your supervisor.



Corrosion risk



Hot surface



Lifting point.




WARNING: Electrical shock risk




Parking Brake



No open flame



Diesel Fuel.  
No open flame




Do not operate the machine  
without guard being fitted.




Lifting point.



WARNING - Flammable liquid



When parking use prop stand,  
handbrake and wheel chocks



Air/gas flow or Air discharge.



WARNING - Hot and harmful  
exhaust gas.




Tie down point




Do not breathe the compressed  
air from this machine



Read the Operation and Maintenance manual before operation or maintenance of this machine is undertaken.



**WARNING** - Maintain correct tire pressure (Refer to the *GENERAL INFORMATION* section of this manual.



**WARNING** - Consult the operation and maintenance manual before commencing any maintenance.



**Rough Service Designation**  
**Wet Location Operation**



Do not stack.


Do not use fork lift truck from this side.



Replace any cracked protective shield.



**WARNING** - Before connecting the tow bar or preparing to tow, consult the operation and maintenance manual.



Do not operate with the doors or enclosure open




On (power).




Off (power).




Emergency stop




Oil Drain



Do not exceed the speed limit.



**WARNING** - Do not undertake any maintenance on this machine until the electrical supply is disconnected and the air pressure is totally relieved.




**WARNING** - For operating temperature below 0° C, consult the operation and maintenance manual



Read the Operation and Maintenance manual before operation or maintenance of this machine is undertaken.




Do not remove operating and maintenance manual and manual holder from this machine.



Pressurized vessel.



Use fork lift truck from this side only



Pressurized component or system.

Look for these signs on machines shipped to international markets outside North America, which point out potential hazards to the safety of you and others. Read and understand thoroughly. Heed warnings and instructions. If you do not understand, inform your supervisor.



(Red Background)

Indicates the presence of a hazard which **WILL** cause serious injury, death or property damage, if ignored.



(Orange Background)

Indicates the presence of a hazard which **CAN** cause serious injury, death or property damage, if ignored.



(Yellow Background)

Indicates the presence of a hazard which **WILL** or can cause injury or property damage, if ignored.



(Blue Background)

Indicates important set-up, operating or maintenance information.





**DANGER**



**Discharged air can contain carbon monoxide or other contaminants. Will cause serious injury or death.**


Do not breathe this air.




**WARNING**

**Trapped air pressure. Can cause serious injury or death**

Close service valve and operate tool to vent trapped air before performing any service







**WARNING**

**Hot pressurized fluid. Can cause severe burns.**

Do not open radiator while hot.






**WARNING**

**High pressure air. Can cause serious injury or death.**

Relieve pressure before removing filler plugs/caps, fittings or covers.





**! WARNING**

**Improper operation of this equipment.  
Can cause serious injury or death.**

Read Operator's Manual supplied with this machine before operation or servicing.

**Modification or alternation of this machine.  
Can cause serious injury or death.**

Do not alter modify this machine without the express written consent of the manufacturer.

105  
km/h

**! WARNING**

**Collapsing jackstand.  
Can cause serious injury.**

Insert locking pin completely.



**Excessive towing speed.  
Can cause serious injury  
or death.**



Do NOT exceed 65 mph (105 km/hr.)



**! WARNING**

**Rotating fan blade.  
Can cause serious injury.**

Do not operate without guard on place.



**! WARNING**

**Falling of machine.**

**Can cause serious injury  
or death.**

Access lifting bail from inside machine.



**! WARNING**

**Door under pressure.  
Can cause serious injury.**

Use both hands to open door when machine is running.



**! WARNING**

**Disconnected air hoses whip.**

**Can cause serious  
injury or death.**

When using air tools attach safety device (OSHA valve) at source of air supply for each tool.



**CAUTION**

**DO NOT WELD.  
ELECTRONIC DAMAGE  
WILL OCCUR.**

This engine is equipped with an electronic engine controller and other electronic components.



**! WARNING**

**Combustible gas.**

**Can cause serious burns,  
blindness or death.**

Keep sparks and open flames away from batteries.





## CAUTION

**DO NOT USE ETHER.**

**ENGINE DAMAGE WILL OCCUR.**

This engine is equipped with an electric heater starting aid.



## NOTICE

### COOLANT FILL INSTRUCTIONS

Adding:

Do NOT remove radiator cap. Top off at overflow reservoir. Use same anti-freeze mixture as in radiator.

Replacing:

With system cool, remove radiator cap. Drain coolant and close drain. At radiator, refill system. Replace radiator cap. At reservoir, fill to "HOT" level. Run for 30 minutes. Stop and allow to cool. At reservoir, add coolant as necessary to reach "COLD" level.




## USE DIESEL FUEL ONLY

### FREE SAFETY DECALS

Do not paint over safety warnings or instructional decals. If safety warning decals become illegible, immediately order replacements from the factory.

Safety Decals are available free of charge. Safety Decals are identified by the decal heading: **DANGER, WARNING, or CAUTION.**

Decal part numbers are on the bottom of each decal and are also listed in the compressor's parts manual. Submit orders for Safety Decals to the Portable Power Parts Service Department. The no charge order should contain only Safety Decals. Help promote safety! Assure that decals are present on the machines. Replace decals that are not readable.





# Installation

## Installation

### System Description - General

The compressor modules are semi-packaged, air-cooled units designed for power take-off applications. Each unit is designed to operate at ambient temperatures from -10° F to 125° F (-23.3° C to 51.7° C). For the actual delivery of each unit at its rated operating pressure, refer to the General Data Decal supplied with each unit.

The unit includes an oil-flooded, rotary, screw-type air compressor, a compressor inlet system, a capacity control system, a compressor lubricating oil system, a compressor discharge system as well as basic instrumentation. The compressor inlet system includes an air intake cleaner with a service indicator. The capacity control system includes a pressure regulator linked to compressor inlet unloader valve. The compressor lubricating oil system includes an air-cooled type oil cooler, an oil filter, and oil control valve and an oil separator tank and air receiver. The oil cooler is of the fin and tube-type construction that requires forced draft cooling air. Basic instrumentation includes compressor discharge air pressure, hour meter, and air restriction indicator. The enclosure cabinet, in which the components are mounted, is of heavy gauge sheet steel and is equipped with easy opening access panels for performing routine maintenance functions.

Compression in the screw-type air compressor is created by the meshing of two helical rotors (male and female) on parallel shafts enclosed in a heavy-duty cast iron housing with air inlet and outlet ports located at opposite ends. The male rotor has four lobes, 90 degrees apart and the female rotor has six grooves 60 degrees apart. The grooves of the female rotor mesh with and are driven by the male rotor.

Thrust taper roller bearings at the rear of the airend prevent longitudinal movement of the rotors. As rotation of the compressor occurs, the rotors unmesh and free air is drawn into the cavities or pockets between the male rotor lobes and the grooves of the female rotor. The air is trapped in these pockets and follows the direction of rotation of each rotor. As soon as the inlet port is closed, the compression cycle begins and the trapped air is directed to the opposite or discharge side of the rotor housing.

As the rotors mesh, the normal free volume of air is decreased and the pressure increased until the closing pocket reaches the discharge port. Cooled lubricating oil is admitted to the compressor by being injected, in metered amounts, directly into the rotor housing so that it passes on with the air being compressed. This removes the heat of compression to a large degree and results in a relatively low, final discharge air temperature.

Since the Doosan Portable Power Compressor Module Series unit is of the positive displacement type, an airflow control system must be provided to regulate the volume of air passing through the compressor to match the amount of service air required by the customer.

Constant speed control unloads the compressor at a predetermined pressure while the driving unit continues to operate at full speed. An air operated regulator closing off the intake to the compressor in an infinitely variable or stepless manner through the inlet unloader valve accomplishes this.

The discharge air pressure can be controlled between 77 and 200 psig (531 to 1379 kPa) by simple readjustment of the pressure regulator adjusting screw. Unit is shipped set at 125 psig (1005 kPa).

## Mounting Unit

Satisfactory installation depends upon the ability of the installer. Refer to the appropriate foundation plan for the dimensions of the compressor package and the appropriate separator foundation plan for the dimensions of the combination primary oil separator tank-air receiver and the secondary separator tank (hereafter called the receiver separator).

Choose a clean, relatively cool location for the compressor package, and provide ample space around the unit for general accessibility and to ensure effective heat dissipation. Extreme care must be taken in locating an air-cooled unit of this type so there is an unrestricted supply of air to the cooling fan, which pushes air over the oil cooler core. The cooler discharge air must flow away from the unit so that it may be readily dissipated to atmosphere without recirculating hot air to the fan intake.

Any recirculation of the cooling air may result in an excessively high compressor operating temperature. The compressor package must be located so the instrument panel will be fully visible (discharge pressure gauge, discharge temperature gauge, and air cleaner service indicator).

For the installation of the receiver separator, choose a location that is on the same level as or lower than the compressor package. Ample space must be provided around the receiver to ensure the proper installation of all piping connections. In addition, the receiver separator must be located so that the separator element may be removed for inspection and service. Refer to the appropriate separator foundation plan.

A condensate drain valve is factory supplied with the receiver separator. When installing the receiver separator, provision should be made for easy access to this drain valve as it will be necessary to drain the condensate daily before starting the unit.

Note: The condensate drain valve and line must be located as the lowest point in the lubricating and cooling oil system for effective condensate removal.

Exact level is not absolutely necessary, but it is recommended the unit be leveled with a sight glass or a carpenter's level set on the compressor housing. Leveling may be accomplished by shimming the unit near the unit's bolting holes. Be sure to use steel shims. Mounting holes are provided on the bottom of the base and weld nuts are provided on the sides of the frame. Either may be used for mounting.

Compressor noise levels will not benefit from using isolators on low shock and vibration applications such as a truck, due to the inherent low vibration signature of this compressor.

## Inlet Piping

Each unit is supplied with a single standard air cleaner to protect the compressor from normal airborne dust and dirt.

## Piping - General

Doosan Portable Power Compressor Module units will require customer provided piping from the compressor module to the hydraulic supply and the air service piping. These hoses are not provided with the units, as the required lengths of the hoses are dependent on the relative locations of modules in its installed location. It is left to the installer to obtain hoses of the correct type and length for each installation.

Location	Fitting Size	Hose Size	Hose Type
Compressor Module to Oil Temp Bypass Valve Outlet (Filter)	20 JIC		
Compressor Module to Separator Scavenge	-4 JIC	3/4" (-12)	Parker-Hannifin 213 or equivalent
Compressor Module to Air Pressure Regulator Outlet	-6 JIC	1" (-16)	Parker-Hannifin 213 or equivalent
Compressor Module to Separator Discharge	8 JIC	3/4" (-12)	Parker-Hannifin 213, or Aeroquip FC350, or equivalent
Compressor Module to Oil Cooler Drain	-6 JIC	1/4" - 4	Parker-Hannifin 213, or Aeroquip FC350, or equivalent
Oil Cooler to Oil Temp Bypass Valve Port "B"	20 JIC		Parker-Hannifin 206, or Aeroquip FC300, or equivalent
Oil Cooler to Oil Temp Bypass Valve Port "C"	20 JIC		Parker-Hannifin 206, or Aeroquip FC300, or equivalent
Airend Discharge to Receiver/ Separator Inlet	-32 JIC		Parker-Hannifin 206, or Aeroquip FC300, or equivalent

All hoses terminate at marked bulkhead fittings on drive end of machine, except oil cooler connections, which are on the cooler side of the compressor module.

All hoses terminate in Type 1 SAE J516 (female swivel straight), 37° JIC flare fittings.

Ports "B" and "C" on oil temperature bypass valve can be connected to either port on the oil cooler. Oil cooler performance is not sensitive to flow direction.

## Compressor Discharge Piping

The customer must furnish the connection between the compressor package and the receiver separator. It is recommended the customer use a flexible line of 2 inches or larger. All piping must be certified safe for the pressures and temperatures involved.

## Receiver Separator Discharge Piping

The receiver separator discharge piping must be furnished by the customer. Refer to the appropriate separator fitting location for a typical piping arrangement for these units. A minimum pressure valve and a manual shut-off valve is supplied with each unit and must be piped into the customer's system as indicated. The minimum pressure valve is supplied to maintain approximately 77 psig (531 kPa) in the air receiver tank to ensure proper oil circulation and also to prevent excessive oil carryover into the customer's air service system. The manual shut-off valve must be installed between the minimum pressure valve and the customer's air service system to serve as an isolation valve.

In addition, whenever this unit is connected to a customer's high volume service air system, a terminal check valve must also be installed downstream of the minimum pressure valve and the isolation valve to prevent air from the system from bleeding back into the compressor system on shutdown.

## Wiring

The compressor is protected against overheating by a thermal-type discharge air temperature switch located in the compressor discharge piping. A "normally-closed" type thermal switch, factory set at 248°F (120°C), is supplied as standard equipment on these units. This switch is supplied for 12/24 volt DC. As an option, this switch may be supplied for 125 volt AC. A thermal sensor switch, also set at 248°F (120°C), normally closed, is provided as extra protection in the receiver separator. It is to be wired in series with the airend temperature switch by the user. This switch is supplied for 12/24 volts DC, with optional AC switches available as an option (see wiring diagram located in Parts Manual).

## Driver

The installation of a CM Series Compressor with any drive such as a power take-off drive or a hydraulic motor drive is very flexible. The proper rotation of the compressor is clockwise when views from the driver end.

**NOTE:** Because the compressor is of the axial screw type, the rotation cannot be changed.

**NOTE:** Direct belt drive of this product is prohibited.

Model	Capacity		Torque Required		Power Required		Input	Pressure
	CFM	M <sup>3</sup> Min	POUND-FEET	NM	BHP	KILOWATTS	RPM	PSI
VHP600CM	600	17.0	525	712	220	164	2200	200

This unit is normally driven by a hydraulic motor directly mounted to the SAE adapter attached to the airend. The standard interface is for 1.75", 13 tooth, 8-16 DP/30° splined shaft. Mounting flange is SAE "D". Alternatively, SAE "C" is available.

A drive shaft from the source of power take-off can alternatively be used to drive the compressor. It is extremely important that the angularity of the drive shaft, including the universal joints, be within the limits specified by the manufacturer. The power take-off shaft and the compressor rotor drive shaft must always be parallel. This gives the same angle at each universal joint and prevents excessive wear. The forks of the universal joint on the drive end must be installed parallel to the forks on the driven end universal. There are many types of universal joints that can be used. However, a constant velocity universal joint as previously described will reduce the possibility of torsional vibration. If a slip joint or spline is used on the drive system, it should be placed between the two universal joints for best results.

## Regulation

The standard regulation system supplied with the CM Series Compressors is designed to provide capacity control for the compressor only. Variable speed control of a driver engine is possible with additional equipment. Consult Doosan Infracore Portable Power for technical assistance for these applications. The adjustment and operation of the standard system is described in the Operating Instructions Section.



## General Data

General Data

Unit Model - VHP600CM

Rated Delivery cfm (liters/sec)	600 (283)
Max Rated Pressure psi (kPa)	200 (1379)

Input Power Requirements @ full load:

Horsepower (kw)	220 (164)
Motor Speed (RPM)	2200

Compressor Lube Capacity (Refill) U.S. gal (liters):

10 (37.9)

Unit Measurements/Weights:

Overall Length (Compressor Module) inch (mm)	52.5 (1333)
Overall Height (Compressor Module) inch (mm)	43.0 (1091)
Overall Width (Compressor Module) inch (mm)	41.9 (1063)
Overall Length (Air Receiver Module) inch (mm)	25.0 (635)
Overall Height (Air Receiver Module) inch (mm)	48.6 (1234)
Overall Width (Air Receiver Module) inch (mm)	22.5 (572)
Weight (Compressor Module) pounds(kilograms)	2160 (980)
Weight (Air Receiver Module) pounds (kilograms)	260 (118)
Weight (System w/lubricants) pounds (kilograms)	2495 (1132)

Service Parts:

Compressor Oil Filter Element	36860336
Compressor Oil Separator Element	36845469
Air Cleaner Element (Primary)	36893840
Air Cleaner Element (Safety)	36893857

Mounting Interface:

- SAE "D" Flange
- 1.75 inch 13 tooth
- -8-16 DP/30° PA Splined Shaft



# **Operating Instructions**

## Operating Instructions

### Set-Up

Place the unit in an open, well-ventilated area. Position as level as possible. The design of these units permits a 15-degree any direction limit on out-of-level operation.

**When the unit is to be operated out of level it is important:**

1. To have the compressor oil level gauge show no more than mid-scale when unit is level, before starting.
2. Do not overfill either the engine crankcase or the compressor lubricating oil system.

### Procedure For Airend Oil Priming

**Perform prior to initial start-up:**

Airend Size	Quantity of Oil Injected (Gallons/Litres)	
	Method A	Method B
226mm	1.8/7	3.6/14

1. All airends are to be primed with oil before the first start of the unit. The prime oil quantity is part of the total fill quantity of the unit.  
The priming of single stage airends can be done by either of the two following methods:
  - A. Disconnect main oil supply hose that goes from the oil filter outlet to the airend and inject oil directly into this hose to the airend.
  - B. Disconnect the separator tank scavenge hose at the end panel and inject oil into the airend.
2. The chart shows minimum fill requirements.

## Before Starting

### **CAUTION**

Do not connect the air discharge on this unit into a common header with any other unit of any description, or any other source of compressed air, without first making sure a check valve is used between the header and the unit. If this unit is connected in parallel with another unit of higher discharge pressure and capacity, a safety hazard could occur in a back-flow condition.

Safety valve setting is 250 psig (1724 kPa). Assure external air system is safe under all operating conditions to prevent serious hazard to operations personnel.

### **WARNING**

Unrestricted airflow from a hose will result in a whipping motion of the hose, which can cause serious injury or death. A safety device must be attached to the hose at the source of supply to reduce pressure in case of hose failure or other sudden pressure release. Reference: OSHA regulation 29 CFR Section 1926.302 (b).

- Open manual blow-down valve to ensure pressure is relieved in receiver separator system. Close valve(s) in order to build up full air pressure and ensure proper oil circulation.
- Check the compressor lubricating oil level. The proper oil level is mid-way to full on the sight glass. Add oil if the level falls below. Do NOT overfill.

 **WARNING**

**This machine produces loud noise. Extended exposure to loud noise can cause hearing loss. Wear hearing protection.**

**Be sure no one is IN or ON the compressor unit. Always operate this equipment with all enclosure panels installed to avoid leakage of cooling air. Operation with panels or access covers removed will quickly result in overheating.**

 **WARNING**

**Do NOT operate machine with guards removed.**

 **CAUTION**

**Do not operate machine with safety shutdown switches by-passed.**

## **Starting/Operating**

- Close service valve.
- Engage main driver at lowest possible speed.

 **CAUTION**

**Do NOT engage compressor motor at driver speed above idle. Damage to compressor motor, pump, or other driveline components can occur.**

- Engage main driver.
- Increase driver speed to compressor operation rated speed.
- Allow compressor to run unloaded five (5) to ten (10) minutes.
- Compressor is now ready to furnish compressed air when service valve is opened.

## Stopping

- Close air service valve(s).
- Allow the unit to run at “no load” for 3 to 5 minutes to reduce the compressor temperature.
- Disengage main driver.

**NOTE:** Once the drive motor stops, the automatic blow-down valve will begin to relieve all pressure from the receiver separator system.

## CAUTION

**Never allow the unit to sit stopped with pressure in the receiver separator system. Never shut down unit while running loaded. Flooding of separator element can result. As a precaution, after the automatic blow-down period (2 minutes), open the manual blow-down valve.**


## Equipment Protection

**NOTE:** Do NOT wire around or bypass a shutdown sensor or switch.

This unit is protected by two (2) shutdown switches at the following locations:

## High Discharge Air Temperature

1. At the airend outlet.
2. In the safety valve connection on separator tank.



## Operating Instruments


### On Gauge Panel

1. Compressor Discharge Pressure Gauge - Indicates pressure in receiver tank, psig (kPa).
2. Discharge Air Temperature Gauge - Indicates discharge air temperature in °F and °C. Normal operating range: 185°F/85°C to 248°F/120°C.

### Inside

3. Air Filter Restriction Indicator - Indicates compressor air cleaner restriction.  
Normal operation (<25 in. H<sub>2</sub>O), green flag.  
Needs service, (>25-in. H<sub>2</sub>O), red flag.  
(Indicator located at base of inlet filter).

## Pressure Regulator Adjusting Instructions



Normally, pressure regulation requires no adjusting, but if proper adjustment is lost, proceed as follows. Refer to the General Data table for proper engine speeds.


### Before Starting

1. Atop separator cover at pressure regulator (PR), loosen locknut (A) counterclockwise. Turn adjusting screw (B) counterclockwise one full turn.

### After Starting Unit

2. Allow unit to warm up at least five minutes.
3. Operate compressor at rated speed with service valve closed. Loosen locknut A. Adjust screw B., until discharge pressure gauge reads rated pressure +10 psi (73 kPa). Turn B. clockwise to increase pressure, counterclockwise to decrease pressure.
4. At pressure regulator (PR), tighten locknut (A).
5. To obtain maximum CFM at any pressure between 77 PSI (531 kPa) and the rated operating pressure, proceed as in Step 3, substituting desired pressure for rated pressure, adding 10 psi (138 kPa) as before. Always lock and protect pressure setting of adjusting screw (B) with locknut (A).

**NOTE: Unit is adjusted at factory for operation at 125 psi.**





# Maintenance

## Maintenance

### CAUTION

**Any unauthorized modification or failure to maintain this equipment may make it unsafe and out of factory warranty.**

### WARNING

**If performing more than visual inspections, disconnect driver engine battery cables and open manual blowdown valve.**

Use extreme care to avoid contacting hot surfaces (heat ex-changer and piping, air receiver and air discharge piping).

Never operate this machine with any guards removed.

Inch and metric hardware was used in the design and assembly of this unit. Consult the parts manual for clarification of usage.

## General

In addition to periodic inspections, many of the components in these units require periodic servicing to provide maximum output and performance. Servicing may consist of pre-operation and post-operation procedures to be performed by the operating or maintenance personnel. The primary function of preventive maintenance is to prevent failure, and consequently, the need for repair. Preventive maintenance is the easiest and the least expensive type of maintenance. Maintaining your unit and keeping it clean at all times will facilitate servicing.

## Scheduled Maintenance

The maintenance schedule is based on normal operation of the unit. In the event unusual environmental operating conditions exist, the schedule should be adjusted accordingly.

## Compressor Oil Level

The oil level should be checked before the unit is operated. The optimum operating level is midway of the sight tube on the side of the receiver tank. See the decal beside the sight tube. If the oil level is not in the "OK" range, make appropriate corrections (ADD or DRAIN). A totally filled sight tube in which the level is not visible indicates an over-full condition and requires that oil be drained.

**NOTE: It is NOT possible to accurately read oil level in tank while compressor is running.**

## Aircleaner

This unit is equipped with an AIR FILTER RESTRICTION INDICATOR on the front panel.

This should be checked daily during operation. If the indicator shows (red) with the unit operating at full speed, servicing of the cleaner element is necessary.

Also weekly, squeeze the rubber valve (pre-cleaner dirt dump) to ensure that it is not clogged.

If flagged, the air filter restriction indicator must be reset after unit is shutdown and the air cleaner is serviced. Reset by pushing button on top of indicator.

To service the air cleaner on all units proceed as follows:

1. Remove access cover on housing.
2. Loosen outer wing nut and remove cover. Remove element.
3. Inspect air cleaner housing for any condition that might cause a leak and correct as necessary.
4. Wipe inside of air cleaner housing with a clean, damp cloth to remove any dirt accumulation, especially in the area where the element seals against the housing.
5. Inspect element by placing a bright light inside and rotating slowly. If any holes or tears are found in the paper, discard this element. If no ruptures are found, the element can be cleaned.
6. If a new air filter element is to be used, check it closely for shipping damage.
7. Install cleaned or new element in the reverse order to the above. Tighten wing nuts firmly and replace cotter pin.
8. Inspect to ensure that the end cap seals tightly 360 degrees around the air cleaner body.
9. Replace access cover.

In the event that the filter element must be reused immediately, compressed air cleaning (as follows) is recommended since the element must be thoroughly dry. Direct compressed air through the element in the direction opposite to the normal airflow through the element.

Move the nozzle up and down while rotating the element in the direction opposite to the normal airflow through the element.

**NOTE: To prevent damage to the element, never exceed a maximum air pressure of 100 psi (700 kPa).**

In the event the element is contaminated with dry dirt, oil or greasy dirt deposits, and a new element is not available, cleaning can be accomplished by washing, using the air cleaner element manufacturer's recommendations.

**NOTE: It is recommended that replacement elements be installed in the unit. The elements just removed for cleaning can be washed and stored as future replacement elements.**

In addition, the air cleaner system (housing and piping) should be inspected every month for any leakage paths or inlet obstructions. Make sure the air cleaner mounting bolts and clamps are tight.

## Gauges

The instruments or gauges are essential for safety, maximum productivity and long service life of the machine. Inspect the gauges prior to start-up. During operation observe the gauges for proper functioning. Refer to Operating Instruments and General Data for the normal readings.

## Compressor Oil and Hydraulic Oil Combination Cooler

The compressor lubricating and cooling oil is cooled by means of fin and tube-type oil coolers. The lubricating and cooling oil, flowing internally through the core section, is cooled by the air stream from the cooling fan flowing past the core section. When grease, oil and dirt accumulate on the exterior surfaces of the oil cooler, its efficiency is impaired.

Each month it is recommended that the oil cooler be cleaned by directing compressed air which contains a non-flammable safety solvent through the core of the oil cooler. This should remove the accumulation of grease, oil and dirt from the exterior surfaces of the oil cooler core so that the entire cooling area can transmit the heat of the lubricating and cooling oil to the air stream.

In the event foreign deposits, such as sludge and lacquer, accumulate in the oil cooler to the extent that its cooling efficiency is impaired, a resulting high discharge air temperature is likely to occur, causing shut down of the unit.

To correct this situation it will be necessary to clean it using a cleaning compound in accordance with the manufacturer's recommendations. After completing the cleaning procedure, the oil cooler must be flushed before returning to service.

## Hoses

Each month it is recommended that the air cleaner clamps be checked for tightness.

Premature wear of the compressor is ASSURED whenever dust-laden air is permitted to enter the compressor intake.

The flexible hoses, oil and air lines on these units are primarily used for their ability to accommodate relative movement between components. It is important they be periodically inspected for wear and deterioration. It is also important the operator does not use the hoses as convenient hand hold or steps. Such use can cause early cover wear and hose failure.

## NOTICE

**Piping systems operating at less than 200 psi (1050kPa) may use a special nylon tubing. The associated fittings are also of a special “push-in” design. If so, features are as follows:**

Pulling on the tubing will cause the inner sleeve to withdraw and compress, thus tightening the connection. The tubing can be withdrawn only while holding the sleeve against the fitting. The tubing can be removed and replaced numerous times without losing its sealing ability.

To install the nylon tubing, make a mark (with tape or grease pencil) approximately 7/8-inch from the end of the tubing. Insert the tubing into the sleeve and “push-in” past the first resistance to the bottom. The mark should be approximately 1/16 inch from the sleeve, for the 3/8-inch O.D. tubing; 1/8-inch for the 1/4-inch O.D. tubing. This will ensure that the tubing is fully engaged in the sealing mechanism.

## Compressor Oil Filter

## NOTICE

**The oil filter must be replaced every 500 hours of operation or three (3) months, whichever comes first. On new or overhauled units, replace the element after the first 50 and 150 hours of operation; thereafter, service the oil filter every 500 hours.**

To service the oil filter, it will first be necessary to shut the unit down. Wipe off any external dirt and oil from the exterior of the filter to minimize any contamination from entering the lubrication system. Proceed as follows:

## **WARNING**

**High pressure air can cause severe injury or death from hot oil and flying parts. Always relieve pressure before removing caps, plugs, covers or other parts from pressurized air system.**

1. Open the service air valve and manual blow down valve to ensure that system is relieved of all pressure. Close the valve.
2. Turn the spin-on filter element counter clockwise to remove it from the filter housing. Inspect the filter.

## **NOTICE**

**If there is any indication of formation of varnishes, shellacs or lacquers on the oil filter element, it is a warning the compressor lubricating oil has improper characteristics and should be immediately changed.**

3. Inspect the oil filter head to be sure the gasket was removed with the oil filter element. Clean the gasket seal area on the oil filter head.

## **NOTICE**

**Installing a new oil filter element when the old gasket remains on the filter head, will cause an oil leak and can cause property damage.**

4. Lubricate the new filter gasket with the same oil being used in the machine.
5. Install new filter by turning element clockwise until gasket makes initial contact. Tighten an additional 1/2 to 3/4 turns.
6. Start unit and allow to build up to rated pressure. Check for leaks before placing unit back into service.

## Fasteners

Visually check entire unit in regard to bolts, nuts and screws being properly secured. Spot-check several cap screws and nuts for proper torque. If any are found loose, a more thorough inspection must be made. Take corrective action.

## Receiver-Separator Systems



**High-pressure air can cause severe injury or death from hot oil and flying parts. Always relieve pressure before removing caps, plugs, covers or other parts from pressurized air system.**

Open service valve and manual blowdown valve.

Ensure pressure is relieved, when BOTH:

- Discharge air pressure gauge reads zero (0).
- No air discharging from service valve.

When draining oil, open manual blowdown valve to allow venting the system. Close blowdown valve prior to re-starting compressor.

When adding oil, remove and replace (make tight) plug on side of separator tank.

In the compressor lubricating and cooling system, separation of the oil from the compressed air takes place in the receiver-separator tank. As the compressed air enters the tank, the change in velocity and direction drop out most of the oil from the air.

Additional separation takes place in the spin-on oil separator element, which is located on the top of the tank.

Any oil accumulation in this separator element is continuously drained off by means of a scavenge drain which returns the accumulated oil to the system.

## Oil Separator Element

The life of the oil separator element is dependent upon the operating environment (soot, dust, etc.) and should be replaced every twelve months or 2000 hours. To replace the element proceed as follows:

1. Ensure the tank pressure is zero.
2. Disconnect the hose from the scavenge tube.
3. Remove scavenge tube from tank cover.
4. Disconnect service line from cover.
5. Remove cover mounting screws.
6. Remove cover and element.
7. Remove any gasket material on cover or tank.
8. Install new element.

## NOTICE

**Do not remove staples from the element/gasket connection.**

- Place a straightedge across top of element and measure from bottom of straightedge to bottom of element (see drawing).
- Replace scavenge tube in cover (cover is still off tank).
- Measure from bottom of cover to end of scavenge tube. Measurement should be from 1/8 inch to 1/4 inch less than the element measurement. If not, cut to size.
- Remove scavenge tube.
- Reposition cover (use care not to damage gaskets).
- Replace cover mounting screws.
- Tighten in a crisscross pattern.
- Reconnect service line. Replace scavenge tube. Reconnect hose.
- Close service valve. Start unit and look for leaks.

When replacing the element, the scavenge lines, orifice, filter and check valve should be thoroughly cleaned and the oil changed.


## Scavenge Line

### WARNING

**High-pressure air can cause serious injury or death from hot oil and flying parts. Always relieve pressure before removing caps, plugs, covers or other parts from pressurized air system.**

The scavenge line originates at the receiver separator tank cover, and terminates at the compressor rotor housing through an orifice/check valve.

Once a year or every 2000 hours of operation, whichever comes first, remove this line and orifice, thoroughly clean, then reassemble.



### NOTICE

**Excessive oil carryover may be caused by an oil logged separator element. Do not replace element without first performing the following maintenance procedure:**

1. Check oil level. Maintain as indicated earlier in this section.
2. Thoroughly clean scavenge line, orifice and check valve.
3. Assure minimum pressure valve is holding 80 to 90 psi.
4. Run unit at rated operating pressure for 30 to 40 minutes to permit element to clear itself.

## Exterior Finish Care

This unit was painted and heat cured at the factory with a high quality, thermoset polyester powder coating. The following care will ensure the longest possible life from this finish.

1. If necessary to remove dust, pollen, etc. from housing, wash with water and soap or dish-washing liquid detergent. Do not scrub with a rough cloth, pad, etc.
2. If grease removal is needed, a fast evaporating alcohol or chlorinated solvent can be used. Note: This may cause some dulling of the paint finish.
3. If the paint has faded or chalked, the use of a commercial grade, non-abrasive car wax may partially restore the color and gloss.

## Field Repair Texture Paint

1. The sheet metal should be washed and clean of foreign material and then thoroughly dried.
2. Clean and remove all grease and wax from the area to be painted using Duponts 3900S Cleaner prior to sanding.
3. Use 320 grit sanding paper to repair any scratches or defects necessary.
4. Scuff sand the entire area to be painted with a red scotch brite pad.
5. Wipe the area clean using Duponts 3900S.
6. Blow and tack the area to be painted.
7. Apply a smooth coat of Duponts 1854S Tuffcoat Primer to all bare metal areas and allow to dry.



**If performing more than visual inspections, disconnect battery cables and open manual blowdown valve.**

**Never operate this machine with any guards removed.**




Use extreme care to avoid contacting hot surfaces, air receiver and air discharge piping, etc).

Inch and metric hardware was used in the design and assembly of this unit. Consult parts manual for clarification of usage.

## Maintenance Schedule

	Daily	Monthly	3 MOS. 500 hrs.	6 MOS. 1000 hrs	12 MOS. 2000 hrs.
Compressor Oil Level	C				
Gauges/Lamps	C				
*Air Cleaner Service Indicators	C				
Hoses (oil, air, intake, hydraulic, etc.)		C			
Automatic Shutdown System      Test		C			
Air Cleaner System      Visual		C			
Hydraulic Oil Cooler      Exterior		C	Clean		
Fasteners			C		
Air Cleaner Elements			WI		
Compressor Oil Filter Element			R		
Compressor Oil				R	
Shutdown Switch Setting      Test					C
Scavenger Orifice & Related Parts					Clean
Oil Separator Element					R
* Disregard if not appropriate for this particular machine.					
R = replace, C = check (adjust if necessary), WI = OR when indicated, L = Lubricate					





# Lubrication

## Lubrication

### General Information

The compressor lubricating oil accomplishes both compressor lubrication and cooling. The oil is forced from the oil storage reservoir, under system pressure, through an oil cooler and an oil filter directly to the compressor.

When the compressor is operating at low capacity, some of the oil may bypass the cooler through a thermostatically controlled bypass valve. This valve bypasses varying amounts of oil, depending upon the temperature, until the oil being circulated reaches a temperature of 185° F (85° C) thus maintaining a higher average oil temperature, thereby reducing the possibility of water vapor condensation in the oil.

Relatively cool lubricating oil is admitted under pressure to the compressor bearings and is also injected in metered amounts, directly to the rotor chamber. All of the oil thus introduced mixes with, and passes on with the air being compressed, thus removing the heat of compression to a large degree. On its way to the final discharge connection, the air passes through a receiver/separator. A scavenger line returns any remaining separated oil back to the inlet of the compressor. Fill the oil storage reservoir in the receiver/separator with new oil before operating the unit. Prime compressor as follows. Perform prior to initial start-up.

### Procedure For Airend Oil Priming

Airend Size	Quantity of Oil Injected (Gallons/Litres)	
	Method A	Method B
226mm	1.8/7	3.6/14

1. All airends are to be primed with oil before the first start of the unit. The prime oil quantity is part of the total fill quantity of the unit.

The priming of single stage airends can be done by either of the two following methods:

- A. Disconnect main oil supply hose that goes from the oil filter outlet to the airend and inject oil directly into this hose to the airend.
- B. Disconnect the separator tank scavenge hose at the end panel and inject oil into the airend.

2. The chart shows minimum fill requirements.

**NOTE: Recharging of the compressor with oil is absolutely necessary on units that have been placed in extended storage (6 months or more).**

NOTE

## Compressor Oil Change

If the unit has been operated for 1000 hours, it should be completely drained of oil. If the unit has been operated under adverse conditions or under long shutdown periods, an earlier change may be necessary as oil deteriorates with time as well as by operating conditions.

Complete replacement of the old oil with clean oil every 500 to 1000 hours, depending upon operating conditions is recommended. This will also prevent accumulation of dirt, sludge or oxidized oil products.

Completely drain the receiver/separator and the piping. If the oil is drained immediately after the unit has been run for sometime, most of the sediment will be in suspension and will drain more readily.

### CAUTION

Shorter oil change intervals may be necessary if unit is operated under adverse conditions.

### WARNING

Do not under any circumstances, open any drain cocks, remove any plugs or the oil filler plug from the compressor lubricating and cooling oil system without making sure the air receiver system has been completely relieved of all air pressure.

### CAUTION


Some oil mixtures are incompatible with each other and result in the formation of varnishes, shellacs or lacquers, which may be insoluble. Such deposits can cause serious trouble including clogging of the filter. Where possible, try to avoid mixing oils of the same type, but different brands. A brand change is best made at the time of complete oil change. Refer to Fluid and Lubricants Chart for oil recommendations.

## Portable Compressor Fluid Chart


Refer to these charts for correct compressor fluid required. Note that the selection of fluid is dependent on the design operating pressure of the machine and the ambient temperature expected to be encountered before the next oil change.


Note: Fluids listed as “preferred” are required for extended warranty. Compressor oil carryover (oil consumption) may be greater with the use of alternative fluids.

Design Operating Pressure	Ambient Temperature	Specification
100 psi to 300 psi	-10°F to 125°F (-23°C to 52°C)	Preferred: <b>IR Pro-Tec™</b> Alternate: ISO Viscosity Grade 46 with rust and oxidation inhibitors, designed for air compressor service.
350 psi	-10°F to 125°F (-23°C to 52°C)  65°F to 125°F (18°C to 52°C)	Preferred: <b>IR XHP 605</b> Alternate: IR XHP405 ISO Viscosity Grade 68 Group 3 or 5 with rust and oxidation inhibitors designed for air compressor service. Preferred: <b>XHP605</b> <b>IR XHP1001</b>



Recommended Fluid	1 Gal. (3.8 Litre)	5 Gal. (19.0 Litre)	55 Gal. (208.2 Litre)	220 gal. (836 Litre)
IR Pro-Tec™	36899698	36899706	36899714	36899722
IR XHP605	-	22252076	22252050	22252068
IR XHP1001	-	35612738	35300516	-
IR XHP405	-	22252126	22252100	22252118
Engine Oil	54480918	36875938	36866903	-







# **Trouble Shooting**

## Trouble Shooting

### Introduction

Trouble shooting for a portable air compressor is an organized study of a particular problem or series of problems and a planned method of procedure for investigation and correction. The troubleshooting chart that follows includes some of the problems that an operator may encounter during the operation of a portable compressor.

The chart does not attempt to list all of the troubles that may occur, nor does it attempt to give all of the answers for correction of the problems. The chart does give those problems that are most apt to occur. To use the trouble shooting chart:

- A. Find the “complaint” depicted as a bold heading.
- B. Follow down that column to find the potential cause or causes. The causes are listed in order (1, 2, 3, etc.) to suggest an order to follow in troubleshooting.

### Action Plan

#### A. Think Before Acting

Study the problem thoroughly and ask yourself these questions:

1. What was the warning signals that preceded the trouble?
2. Has a similar trouble occurred before?
3. What previous maintenance work has been done?
4. If the compressor will still operate, is it safe to continue operating it to make further checks?

#### B. Do the Simplest Things First

Most troubles are simple and easily corrected. For example, most complaints are “low capacity” which may be caused by too low an engine speed or “compressor over-heats” which may be caused by low oil level.

Always check the easiest and most obvious things first; following this simple rule will save time and trouble.

**NOTE: For troubleshooting electrical problems, refer to the wiring Diagram Schematic found in Parts List Section.**

**C. Double Check Before Disassembly**

The source of most compressor troubles can be traced not to one component alone, but to the relationship of one component with another. Too often, a compressor can be partially disassembled in search of the cause of a certain trouble and all evidence is destroyed during disassembly. Check again to be sure an easy solution to the problem has not been overlooked.

**D. Find and Correct Basic Cause**

After a mechanical failure has been corrected, be sure to locate and correct the cause of the trouble so the same failure will not be repeated. A complaint of "premature breakdown" may be corrected by repairing any improper wiring connections, but something caused the defective wiring. The cause may be excessive vibration.

## Trouble Shooting Chart

**Bold Headings depict the COMPLAINT - Subheadings suggest the CAUSE**

**NOTE: Subheadings suggest sequence to follow troubleshooting.**

### **Short Air Cleaner Life:**

Dirty Operating Conditions  
Inadequate Element Cleaning  
Defective Service Indicator  
Incorrect Stopping Procedure  
Wrong Air Filter Element

### **Excessive Oil In Air:**

High Oil Level  
Out of Level > 15 degrees  
Clogged Scavenge Orifice  
Scavenge Tube Blocked  
Defective Scavenge Check Valve  
Separator Tank Blown Down too Quickly  
Defective Minimum Pressure Valve

### **Will Not Unload:**

Leak in Regulator Piping  
Incorrect Pressure Regulator Adjustment  
Malfunctioning Pressure Regulator  
Malfunctioning Inlet Unloader/Butterfly Valve  
Ice in Regulation Lines/Orifice

### **Oil In Air Cleaner:**

Incorrect Stopping Procedure

### **Safety Valve Relieves:**

Operating Pressure too High  
Leak In Regulator Piping  
Incorrect Pressure Regulator Adjustment  
Malfunctioning Pressure Regulator  
Malfunctioning Inlet Unloader/Butterfly Valve  
Defective Separator Element  
Ice in Regulation Lines/Orifice

### **Excessive Compressor Oil Temperature:**

Ambient Temperature too High  
Out of Level > 15 degrees  
Low Oil Level  
Wrong Lube Oil  
Dirty Cooler  
Dirty Operating Conditions  
Clogged Oil Filter Elements  
Operating Pressure Too High  
Defective Oil Temperature Bypass Valve  
Defective Minimum Pressure Valve  
Blocked or Restricted Oil Lines  
Airend Malfunctioning

### **Excessive Vibration:**

Defective Fan  
Damaged Airend Coupling or Drive Motor  
Airend Malfunctioning

### **Low CFM:**

Low Motor RPM  
Dirty Air Filter  
Incorrect Pressure Regulator Adjustment  
Malfunctioning Inlet Unloader/Butterfly/Valve  
Defective Minimum Pressure Valve  
Defective Separator Element

### **Unit Shutdown:**

Compressor Oil Temperature too High  
Loose Wire Connection  
Defective Discharge Air Temperature Switch  
Airend Malfunctioning  
Compressor Drive Motor Malfunctioning

### **Will Not Start/Run:**

Compressor Oil Temperature too High  
Compressor Drive Motor Malfunctioning  
Airend Malfunctioning



**Doosan Infracore**  
Portable Power



Doosan Infracore Portable Power  
1293 Glenway Drive  
Statesville, NC 28625  
[www.doosanportablepower.com](http://www.doosanportablepower.com)