




7/31, 7/41



(GB)	PARTS CATALOGUE	(E)	LISTA DE REPUESTOS
(F)	CATALOGUE DE PIÈCES DÉTACHÉES	(DK)	RESERVEDELSKATALOG
(NL)	ONDERDELENKATALOGUS	(S)	RESERVEDELSKATALOG
(D)	ERSATZTEILLISTE	(N)	RESERVEDELSKATALOG
(P)	LISTA DE PEÇAS	(SF)	VARAOSALUETTELO
(I)	LISTA RICAMBI		

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.

C.C.N : 54626494
DATE : FEBRUARY 2001
Revised (09-12)

7/31 SERIAL No: 320001 ->

7/41 SERIAL No: 360001 ->

CONTENTS

Page	Description	'T' N°	Page	Description	'T' N°	Page	Description	'T' N°
1	Running gear (Fixed Height)	T1270A	29	Engine Parts: 4IRL5N		57	Options – Lubricator	T1846
2	Running gear (Fixed Height)	T1270B		Engine gasket kit		58	Options – Regulation system	T1844
3	Running gear (Fixed Height)	T1270C		Cylinder head cover		59	Options – Generator	T1845
4	Running gear (Variable height)	T1271A		Cylinder head		60	Options – Generator 115V	T1847
5	Running gear (Variable height)	T1271B		Cylinder block		61	Options – Generator 230V	T1847
6	Running gear (Variable height)	T1271C		Oil pan and level gauge		62	Options – Generator 400V	T1847
7	Engine / Airend assembly	T1820		Camshaft and valve		63	Recommended parts	
8	Engine / Airend assembly	T1843		Crankshaft, piston and flywheel		74	Glossary of non-illustrated items	
9	Engine Parts: 3IRL4N			Flywheel housing		78	Fasteners index / Tube fittings index	
	Engine gasket kit		48	Exhaust manifold		80	CCN index	
	Cylinder head cover		49	Water pump				
	Cylinder head			Fan	T1821			
	Cylinder block			Fuel injection system				
	Oil pan and level gauge		50	Fuel filter and bracket	T1822			
	Camshaft and valve		51	Fuel pump	T1823			
	Crankshaft, piston and flywheel		52	Oil pump and oil strainer	T1824			
	Exhaust manifold		53	Engine electrical control parts	T1825			
	Water pump and corrosion resistor		54	Timing gear case	T1826			
	Fan and fan belt		55		T1827			
	Fuel injection system		56	Enclosure	T1828			
	Fuel filter and bracket			Air intake /				
	Fuel pump and pipe			Engine exhaust system				
	Oil pump and oil strainer							
	Engine electrical control parts							
	Timing gear case							

ABBREVIATIONS & SYMBOLS

->####	Up to Serial No.	*	Not illustrated	I	Italy
####->	From Serial No.	†	Option	N	Norway
####	Contact Ingersoll-Rand for Serial No.	AR	As required	NL	Netherlands
		D	Germany	P	Portugal
		DK	Denmark	S	Sweden
		E	Spain	SF	Finland
		F	France		
		GB	Great Britain		

General

This manual, which contains an illustrated parts breakdown, has been prepared as an aid in identifying and ordering parts for the machine. All of the parts, listed in the parts breakdown, are manufactured with the same precision as the original equipment.

Ingersoll-Rand Company service facilities and parts are available worldwide. There are Ingersoll-Rand Company Branch Offices and authorised distributors located in the principle cities of the United States. In Canada, our customers are serviced by the Canadian Ingersoll-Rand Company, Limited. There are also Ingersoll-Rand Company subsidiaries and authorised distributors located in the principle cities throughout the world.

Description

The illustrated parts breakdown identifies the various assemblies, sub-assemblies and detailed parts which make up this machine.

A series of illustrations show each part clearly and in its correct location relative to the other parts in the illustration. Each part in an illustration is referenced with a number. The number, description and quantity needed per assembly are listed in numerical order on the following pages.

How to use this parts manual


1. Locate the desired illustration.
2. Locate the part on the illustration by visual identification and note the reference number.
3. Find the reference number on the tabulated page, along with the Part Number and Description.

How to order parts


In order that all avoidable errors be eliminated when ordering parts, please specify the following:

1. The model number of the unit as shown on the Compressor Data Plate.
2. The serial number of the unit as shown on the Compressor Data Plate.
3. The part number of this manual.
4. The part number, description and quantity needed exactly as listed.
5. The motor data code shown on the motor data plate.

1 RUNNING GEAR (Fixed Height) M&E




Item	cpn	Qty.	Description	Item	cpn	Qty.	Description	Item	cpn	Qty.	Description
1-5	92762962	1	Propstand assembly	12-56	54427083	1	Axle tube assembly	21	92102607	4	Stud
1	92763002	1	Prop stand	12R-40	54427182	1	Hub & stub axle assy. (Right hand)	22	92102599	4	Nut
2	92762996	1	Bracket	12L-40	54427185	1	Hub & stub axle assy. (Left hand)	23	92687433	2	Cable
3	92762970	1	Pad	12R	54427240	1	Stub axle & backplate assy (Right Hand)	24	92304518	4	Nut
4	92762988	1	Handle	12L	54427257	1	Stub axle & backplate assy (Left Hand)	25	92055706	2	Adjuster
5-95	54403530	1	Running gear assembly Braked version	13	92793405	1	Hub	26	92055698	1	Bolt
*†5-95	54575154	1	Running gear (Extended drawbar option)	14	92074350	1	Bearing	27	92053487	1	Shoe
5	92793249	1	Tube, towbar	15	92102540	1	Bearing	28	92053495	1	Shoe
*†5	54576525	1	Tube, towbar (Extended drawbar option)	16	92074384	1	Seal	29	92053776	2	Carrier
6	95252524	4	Setscrew	17	92053974	1	Washer	30	92053826	2	Spring
7	92022763	4	Nut	18	95391348	1	Nut	31	92053842	1	Spring
8	92053537	2	Bolt	19	95002697	1	Pin	32	92053834	1	Spring
9	92022763	2	Nut	20	92793413	1	Cap	33	92053768	1	Expander
10	92793272	1	Pad					34	92053800	1	Spring
11	92757046	1	Clamp					35	92053818	1	Saddle
								36	92055680	1	Plug
								37	-		
								38	-		




T1270B
Revision 01
07/00

Item	cpn	Qty.	Description	Item	cpn	Qty.	Description	Item	cpn	Qty.	Description
39	—			51	—			61	95076774	1	Nut
40	92680669	1	Holder, cable	52	—			62-94	92680552	1	Coupling assembly
41	92054006	1	Plate	53	—			62	92055482	1	Eye
42	95076774	2	Nut	54	—			63	92053859	1	Bolt
43	92055433	1	Plate	*55	54427224	1	Axle, bare	64	92022540	1	Nut
44	54514310	2	Nut	56	—			65	92053859	1	Bolt
45	54514328	2	Pin	57	92687417	1	Rod	66	92053859	1	Bolt
46	54514336	2	Washer	*†57	88111349	1	Rod (Extended drawbar option)	67	92053859	1	Bolt
47	—							68	92022540	1	Nut
48	—			58	92102573	1	Clevis	69	92022540	1	Nut
49	—			59	92102565	1	Pin	70	92022540	1	Nut
50	—			60	92102557	1	Clip, retaining	71	92022540	1	Nut


3 RUNNING GEAR (Fixed Height) M&E



Item	cpn	Qty.	Description	Item	cpn	Qty.	Description	Item	cpn	Qty.	Description
72	92680602	1	Shaft	85	92055581	1	Bush	96	92259563	1	Wheel
73	92055516	2	Bush	86	95064697	1	Washer	97	92869775	1	Tyre
74	92680610	1	Collar	87	92022763	1	Nut	98	90103185	2	Setscrew
75	92302058	2	Nipple	88	92055623	1	Spring	99	92304682	2	Washer
76	92680701	1	Bracket	89	92055631	1	Cable	100	89260319	2	Bolt
77	92272343	2	Setscrew	90	92055649	1	Ring	101	92061506	2	Washer, snubber
78	95081857	2	Washer	91	92055656	1	Shackle	102	92304575	2	Locknut
79	95077442	1	Locknut	92	92680693	1	Lever, handbrake	103	92368687	2	Screw
80	95094314	1	Washer	93	92253137	1	Clip, retaining	*104	92661750	1	Strap
81	92053883	1	Bolt	94	92253137	1	Clip, retaining	105	92790831	2	Washer, tab
82	92055557	1	Damper	95	54427273	1	Cover	106	90103185	4	Screw
83	92680628	1	Frame	96-97	92869783	2	Wheel & tyre assembly				
84	92680636	1	Lever								




Item	cpn	Qty.	Description	Item	cpn	Qty.	Description	Item	cpn	Qty.	Description
1-5	92762962	1	Propstand assembly	9R	54427240	1	Stub axle & backplate assy (Right Hand)	27	92053826	2	Spring
1	92763002	1	Prop stand	9L	54427257	1	Stub axle & backplate assy (Left Hand)	28	92053842	1	Spring
2	92762996	1	Bracket	10	92793405	1	Hub	29	92053834	1	Spring
3	92762970	1	Pad	11	92074350	1	Bearing	30	92053768	1	Expander
4	92762988	1	Handle	12	92102540	1	Bearing	31	92053800	1	Spring
5-118 (F)	92782762 ->314683	1	Running gear assembly Braked version	13	92074384	1	Seal	32	92053818	1	Saddle
5-118 (D)	92789338 ->314683	1	Running gear assembly Braked version	14	92053974	1	Washer	33	92055680	1	Plug
5-118	54403605 314684->	1	Running gear assembly Braked version	15	95391348	1	Nut	34	-		
5	95252524	4	Setscrew	16	95002697	1	Pin	35	-		
6	92022763	4	Nut	17	92793413	1	Cap	36	-		
7	92793272	1	Pad	18	92102607	4	Stud	37	92680669	1	Holder, cable
8	92757046	1	Clamp	19	92102599	4	Nut	38	92054006		Plate
9-53	54427083	1	Axle tube assembly	20	92687433	2	Cable	39	95076774		Nut
9R-40	54427182	1	Hub & stub axle assy. (Right hand)	21	92304518	4	Nut	40	92055433		Plate
9L-40	54427185	1	Hub & stub axle assy. (Left hand)	22	92055706	2	Adjuster	41	54514310	2	Nut
				23	92055698	1	Bolt	42	54514328	2	Pin
				24	92053487	1	Shoe	43	54514336	2	Washer
				25	92053495	1	Shoe	44	-		
				26	92053776	1	Carrier	45	-		
								46	-		




T1271B
Revision 01
07/00

Item	cpn	Qty.	Description	Item	cpn	Qty.	Description	Item	cpn	Qty.	Description
47	—			61	92022540	1	Locknut	76	95077442	1	Locknut
48	—			62	92022540	1	Locknut	77	95094314	1	Washer
49	—			63	92302058	2	Nipple	78	92055631	1	Cable
50	—			64	92055557	1	Damper	79	92055649	1	Ring
51	—			65	92053883	1	Bolt	80	92055656	1	Shackle
52	54427224	1	Axle, bare	66	92754555	1	Frame	81	92754563	1	Bracket
53	92756907	1	Rod	67	92754530	1	Lever	82	95076790	1	Nut
54	—			68	92055581	1	Bush	83	92754589	1	Stud
55-95	92719921	1	Coupling assembly	69	92022763	1	Locknut	84	92754548	1	Clevis
55	92680602	1	Shaft	70	95064697	2	Washer	85	92102565	1	Pin
56	92055516	1	Bush	71	92055623	1	Spring	86	92102557	1	Clip, retaining
57	92680610	1	Collar	72	92680693	1	Lever, handbrake	87	92253137	1	Clip, retaining
58	92053859	1	Bolt	73	92680701	1	Bracket	88	92253137	1	Clip, retaining
59	92053859	1	Bolt	74	92272343	2	Screw	89	92022763	1	Locknut
60	92022540	1	Locknut	75	95081857	2	Washer				




T1271C
Revision 01
07/00

Item	cpn	Qty.	Description	Item	cpn	Qty.	Description	Item	cpn	Qty.	Description
90	95064697	1	Washer	103	92756774	1	Link	117	92810373	1	Handle
91	92304518	1	Nut	104	92053537	1	Bolt	118	92848647	2	Nut
92	92753789	1	Adaptor	105	92312339	2	Screw	119-120	92869783	2	Wheel & tyre assembly
93	54427273	1	Cover	106	92756865	2	Washer	119	92259563	1	Wheel
94	92022763	4	Nut	107	92756816	1	Mount	120	92869775	1	Tyre
95	92053537	1	Bolt	108	92053859	2	Bolt	121	90103185	2	Setscrew
96	92754597	1	Stop	109	92022540	2	Nut	122	92304682	2	Lockwasher
97	92754605	1	Cable	110	92756790	1	Collar	123	92061506	2	Washer
98	92756675	1	Clip, retaining	111	92756782	1	Pin	124	92304575	2	Locknut
99	92302058	1	Nipple	112	92756790	1	Collar	125	90103185	2	Screw
100 (D)	92049543	1	Eye	113	92756782	1	Pin	126	89260319	2	Bolt
101 (F)	92754571	1	Eye	114	92810373	1	Handle	127	92368687	2	Screw
101	92053859	1	Bolt	115	92848647	1	Nut	128	92790831	2	Washer, tab
102	54428289	1	Tube, towbar	116	92810381	1	Chain & pin assembly				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54497276	1	Engine 7/31	7	54505987	1	Eye
	54612239	1	Engine 7/41	†8	54506027	1	Eye
2	54619028	1	Fan 7/31	†9	54506035	2	Spacer
	54619010	1	Fan 7/41	†10	54592126	1	Washer, Spring
3	54540505	1	Bracket	11	54570908	1	Support
4	36875565	3	Mount	12	54568415	2	Bracket
5	54540539	1	Spacer	13	54581947	1	Guard
6	54540455	2	Bail, lifting	14	54540403	1	Guard LH
				15	54540422	1	Guard RH




T1843
Revision 00
10/00


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	36007813	1	Airend	19	35317379	1	Key
	36007847	1	Airend (HP95)	*20	35375369	2	Lipseal, driveshaft
2	35372986	1	Nipple	21–	54495700	1	Coupling assembly 7/31
3	36897353	1	Element, oil filter	24	54612213	1	Coupling assembly 7/41
4	35374867	1	Elbow	21	54519665	1	Hub
5	—			22	92970633	1	Element 7/31
6	36764553	1	Tube assembly		92118504	1	Element 7/41
7	35286491	2	Elbow	23	54602057	4	Pin, locating
8	36508471	1	Cover	24	54602065	4	Stud
9	95023107	1	'O' Ring	25	92118520	3	Screw
10	35611623	1	Valve	26	92789080	2	Spacer
11	35376342	1	Spring	27	36506442	1	Cover
12	35611557	4	Stem	28	95023115	1	'O' Ring
13	35376334	1	Spring	29	93151413	3	Cover
14	35611615	1	Piston	*30	95022331	1	'O' Ring
15	35376359	1	Seal				
16	35379817	1	Clip, retaining				
17	35596436	1	Switch, temperature				
18	39404165	1	'O' Ring				



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49840853	1	Kit, gasket/'O' Ring				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49849219	1	Cover	5	54429717	1	Valve PLV
2	54385984	1	Cap	6	49841281	1	Pipe
3	88080767	1	Gasket				
4	49840879	1	Gasket Part of kit 49840853				



T9542


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841638	1	Cylinder head assembly	7	49841414	4	Cup, sealing
2	49840960	1	Gasket Part of kit 49840853	8	54385893	3	Glowplug
3	49808009	6	Guide	9	49841653	1	Connector
4a	49840887	3	Seat, valve insert (Inlet)	10	49809049	1	Hanger
4b	49840895	3	Seat, valve insert (Exhaust)	11	49807324	6	Seal Part of kit 49840853
5	88081906	4	Cup, sealing	12	88080494	1	Plug
6	88080353	1	Cup, sealing	13	49809031	1	Hanger




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841695	1	Cylinder block assembly	5	88080486	4	Cup, sealing
2a	88081906	4	Cup, sealing	6	49841729	1	Adaptor
2b	49807605	1	Cup, sealing	7	49808595	1	Bearing
3	88082664	1	Plug	8	49849227	4	Dowel
4a	49807001	1	Plug	9	88080486	1	Cap
4b	54530522	1	Plug	10	49849318	1	Plug

13


3IRL4N – CYLINDER BLOCK



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841695	1	Cylinder block assembly	9	49808603	1	Plug
2	49807605	4	Cup, sealing	10	88080569	1	Cap
3a	49849037	2	Pin	11	49849136	1	Clip, retaining
3b	49849029	3	Pin	12	49807142	1	Plug
4	49849037	2	Pin	13	54429675	1	Element, oil filter
5	88080486	2	Cup, sealing	14	88082607	1	Gasket
6	49841596	1	Cover	15	54430707	1	Solenoid, stop
7	49808348	2	Pin				Part of kit 49840853
8	49807589	2	Dowel				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841570	1	Oil pan assembly	3	88080395	1	Gasket Part of kit 49840853
2	49841240	1	Gauge, oil level	4	88082656	1	Plug




T9546

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49840978	3	Valve, inlet	10	49840937	6	Rod
2	49840911	3	Valve, exhaust	11	49809460	6	Tappet
3	49841547	1	Shaft	12	49841646	1	Bracket
4	49849284	1	Plug	13	49840945	3	Spring
5	49807621	12	Collar	14	49849003	1	Pin
6	49808199	6	Spring	15	88080486	1	Cup, sealing
7	49807670	6	Seat	16	49808355	1	Cup, sealing
8	49809825	3	Arm, rocker (Inlet)	17	88082565	1	Gasket Part of kit 49840853
9	49809833	3	Arm, rocker (Exhaust)				




T9549

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54430665	1	Crankshaft	10	49841612	3	Ring set
2	49841539	1	Kit, metal	11	49841620	3	Ring set
3	49841562	1	Flywheel	12	49840804	3	Kit, metal
4	49841687	1	Pulley	13	49840796	3	Pin
5	49808041	1	Gear	14	49840929	3	Rod, assembly, connecting
6	49807811	1	Gear	15	49841224	3	Bush
7	49807597	1	Key	16	49840788	6	Ring snap
8	49841711	3	Piston	17	49840739	1	Kit, metal
9	49809387	3	Piston				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49808017	1	Manifold, exhaust				
2	49808306	1	Gasket, exhaust manifold Part of kit 49840853				
3	49808447	1	Gasket				




T9553

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49840770	1	Fan	4	88081757	1	Piece, sliding
2	54526801	1	Belt, fan	5	49809858	1	Pulley
3	49809882	1	Plate				



T9554


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841331	3	Pump assembly	11	49809510		Shim T=0.4
2	49807183	2	Clip, hose	11	49809528		Shim T=0.5
3	49841315	1	Hose	11	49809536		Shim T=0.6
4	49841323	3	Nozzle, injector	11	49809544		Shim T=0.7
5	54385935	3	Gasket Part of kit 49840853	11	49809551		Shim T=0.8
6	49841661	1	Pipe	11	49809569		Shim T=1.0
7	54385950	3	Gasket Part of kit 49840853	11	49809577		Shim T=1.2
8	49841380	3	Gasket Part of kit 49840853	12	54430566	1	Pipe
9	49841166	3	Bracket	13	54430715	2	Gasket Part of kit 49840853
10	49808165	3	Pipe assembly				
11	49809494		Shim T=0.2				
11	49809502		Shim T=0.3				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1		1	Filter assembly	5	49849284	1	Plug
2	54381306	1	Element, fuel filter	6	88082607	5	Gasket
3	88080643	1	Cover	7	49807167	1	Tube assembly
4	49809379	1	Bracket	8	49807456	1	Tube assembly

23

3IRL4N – FUEL PUMP AND PIPE




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49809809	1	Fuel pump assembly	3	49807175	4	Clip, hose
2	49809403	1	Hose	4	49809395	1	Hose
				5	49809387	1	Bracket




T9557

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49808611	1	Oil pump assembly	6	49807290	1	Plug
2	49849029	2	Pin	7	49809429	1	Spring
3	49841588	1	Filter assembly	8	49807613	1	Valve, relief
4	49809338	1	Gasket Part of kit 49840853	9	49808546	1	Oil pump sub assembly
5	49807027	1	Gasket Part of kit 49840853	10	49840903	1	Pipe




T9558

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49849086	1	Starter assembly 12V–1.4kW				
2	49809841	1	Generator 12V–35A				
3	49841513	1	Cable, earth				




T9559


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49849045	1	Shaft	14	49809486	2	Cover
2	49807910	1	Shaft	15	88080379	1	Plug
3	49841125	1	Cover	16	49849128	1	Ring
4	49807126	2	Gasket Part of kit 49840853	17	49809999	1	Pin
5	49807266	1	Cap	18	49841257	1	Cover
6	49808637	1	Lever	19	88080544	1	Cup, sealing
7	49807019	2	Gasket Part of kit 49840853	20	49841265	1	Gasket Part of kit 49840853
8	49807274	1	Eye	21	49808363	1	Spring
9	49807936	1	Spring	22	49808322	1	Bush
10	49807928	1	Lever	23	49807845	1	Cup, sealing
11	49808702	1	Gasket Part of kit 49840853	A			See next page
12	49807753	1	Bush	B			See next page
13	49807001	1	Plug	C			See next page



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49808579	1	Flyweight	13	49808223	1	Lever
2	49809684	1	Sleeve	14	49808231	1	Shifter
3	49849011	1	Shaft	15	49849052	1	Shaft
4	49807043	1	Pin	16	88082524	1	Ring
5	49809700	1	Plate	17	49809692	1	Lever
6	49808256	1	Lever	18	49841604	1	Link
7	49807944	1	Spring	19	49808975	1	Spring set
8	49841554	1	Spring	20	49809114	1	Kit, lever
9	49808983	1	Spring	A			See previous page
10	49808058	1	Lever	B			See previous page
11	49809411	1	Guide	C			See previous page
12	49807043	1	Pin				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841273	1	Cover, timing gear	4	49807159	1	Seal Part of kit 49840853
2	88080510	1	Seal Part of kit 49840853	5	49807829	1	Cap
3	49808538	1	Retainer	6	88080767	1	Gasket



T9570

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49840762	1	Kit, gasket/'O' Ring				




T9571

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841174	1	Bracket	14	49849003	1	Pin
2	49841430	1	Cover	15	88082565	1	Gasket Part of kit 49840762
3	49841182	1	Gasket Part of kit 49840762	16	49849284	1	Plug
4	54385984	1	Cap	17	49841034	1	Shaft
5	88080767	1	Gasket	18	49840945	4	Spring
6	49840911	4	Valve, exhaust	19	49808355	1	Cup, sealing
7	49840978	4	Valve, inlet	20	49809833	4	Arm, rocker (Exhaust)
8	49809460	8	Tappet	21	49809825	3	Arm, rocker (Inlet)
9	49840937	8	Rod	22	49841281	1	Pipe
10	49807621	16	Collar	23	54429717	1	Valve PCV
11	49807670	8	Seat				
12	49808199	8	Spring				
13	88080486	1	Cup, sealing				


31

4IRL5N – CYLINDER HEAD




T9572

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841157	1	Cylinder head assembly	8	49809049	1	Hanger
2	49841422	1	Gasket Part of kit 49840762	9	49841356	1	Connector
3	49809031	1	Hanger	10	49840895	4	Seat, valve insert (Exhaust)
4	88080494	1	Plug	11	49840887	4	Seat, valve insert (Inlet)
5	49808009	8	Guide	12	88081906	6	Cup, sealing
6	49807324	8	Seal Part of kit 49840762	13	49841414	5	Cup, sealing
7	54385893	4	Glowplug	14	88080353	1	Cup, sealing




T9573

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841372	1	Cylinder block assembly	6	54530522	1	Plug
2	49849227	4	Dowel	7	88082664	4	Plug
3	49808595	1	Bearing	8	49849318	1	Plug
4	88081906	1	Cup, sealing	9	49841455	1	Adaptor
5	49849219	1	Cup, sealing	10	49807605	4	Cup, sealing




T9574

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841372	1	Cylinder block assembly	11	54429675	1	Element, oil filter
2	49849219	3	Cup, sealing	12	49849136	1	Clip, retaining
3	49807605	1	Cup, sealing	13	49841042	1	Cover
4	49849037	2	Pin	14	49807142	1	Plug
5	49849029	2	Pin	15	88082607	1	Gasket Part of kit 49840762
6	49808603	1	Plug	16	88080569	1	Cap
7	49808538	1	Cover	17	49808348	2	Pin
8	49807159	1	Seal Part of kit 49840762	18	88080379	3	Plug
9	54430707	1	Solenoid, stop	19	49849185	4	Pin
10	49807712	1	Nipple	20	49807589	2	Dowel




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49808488	1	Oil pan assembly	3	88080395	1	Gasket Part of kit 49840762
2	88082656	1	Plug	4	49808504	1	Gauge, oil level



T9576

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841299	1	Camshaft	7	49841216	1	Gear
2	49809916	1	Bearing	8	49807241	1	Collar
3	49808645	1	Ring	9	49841349	1	Gear
4	49849193	1	Pin	10	49841497	1	Pin
5	49809908	1	Bearing	11	49809593	1	Shaft
6	49849110	1	Ring snap				




T9577

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841083	4	Ring set	8	49840929	4	Rod, assembly, connecting
2	49841091	AR	Ring set OS = .25 mm	9	49840804	4	Bearing
3	49840788	8	Ring snap	10	49807811	1	Gear
4	49841406	4	Piston	11	49849557	1	Flywheel
5	49841398	AR	Piston OS = .25 mm	12	49840994	1	Crankshaft
6	49840747	4	Pin OD = 25	13	49807597	1	Key
7	49841224	4	Bush	14	49808041	1	Gear
				15	49809866	1	Pulley
				16	49841109	1	Kit, bearing


37

4IRL5N – FLYWHEEL HOUSING




T9578


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841463	1	Housing				
2	88080387	1	Plug				
3	88082581	1	Gasket Part of kit 49840762				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841463	1	Manifold, exhaust				
2	49841067	1	Gasket, exhaust manifold Part of kit 49840762				
3	49808447	1	Gasket				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841075	1	Pipe	5	54385836	1	Thermostat
2	36880706	1	Switch, temperature	6	49840861	2	Plug
3	88080494	2	Plug NPT 3/8	7	49841448	1	Pump assembly
4	54385851	1	Gasket Part of kit 49840762				



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49809858	1	Pulley				
2	49841471	1	Fan				
3	54526801	1	Belt, fan				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841323	4	Nozzle, injector	8	49809510	AR	Shim T=0.4
2	49841380	4	Gasket Part of kit 49840762	8	49809528	AR	Shim T=0.5
3	49841190	1	Pipe	8	49809536	AR	Shim T=0.6
4	54385935	4	Gasket Part of kit 49840762	8	49809544	AR	Shim T=0.7
5	54385950	4	Gasket Part of kit 49840762	8	49809551	AR	Shim T=0.8
6	54537063	8	Gasket Part of kit 49840762	8	49809569	AR	Shim T=1.0
7	49841141	1	Pipe	8	49809577	AR	Shim T=1.2
8	49809494	AR	Shim T=0.2	9	49841331	4	Pump assembly
8	49809502	AR	Shim T=0.3	10	49841307	4	Pipe
				11	49807183	2	Clip, hose
				12	49841315	1	Hose
				13	49841166	4	Bracket




T9583

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	88082607	5	Gasket	4	88080643	1	Cover
2	49807167	2	Coupling assembly	5	54381306	1	Element, fuel filter
3	49849284	1	Plug M14-2.0 X 9	6	49809379	1	Bracket




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49809387	1	Bracket	3	35296342	8	Clip, retaining
2	35363498	AR	Hose 5/16" Fuel	4	49809809	1	Fuel pump assembly




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49849029	2	Pin	6	49841018	1	Filter,oil
2	49809338	1	Gasket Part of kit 49840762	7	49840903	1	Pipe
3	49808611	1	Oil pump assembly	8	49807290	1	Plug
4	49808546	1	Oil pump sub assembly	9	49809429	1	Spring
5	49807027	1	Gasket Part of kit 49840762	10	49807613	1	Valve, relief

45


4IRL5N – ENGINE ELECTRICAL CONTROL PARTS



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49840986	1	Starter assembly	4	49809882	1	Plate
2	49841513	1	Cable, earth	5	88081757	1	Piece, sliding
3	49809841	1	Alternator				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49807266	1	Cap	15	49808637	1	Lever
2	49807126	2	Gasket Part of kit 49840762	16	49841265	1	Gasket Part of kit 49840762
3	49841125	1	Cover	17	49841257	1	Cover
4	49809486	1	Cover	18	88080544	1	Cup, sealing OD = 16
5	49807001	1	Plug NPT 1/4	19	88080510	1	Seal Part of kit 49840762
6	49807019	2	Gasket Part of kit 49840762	20	49841273	1	Cover
7	49807928	1	Lever	21	88080379	1	Plug NPT 1/8
8	49808702	1	Gasket Part of kit 49840762	22	49807845	1	Cup, sealing
9	49807936	1	Spring	23	49808322	1	Bush
10	49849128	1	Ring snap	24	49809999	1	Pin
11	49807829	1	Cap	25	49849045	1	Shaft
12	88080767	1	Gasket	26	49807910	1	Shaft
13	49807274	1	Eye	27	49808363	1	Spring
14	49807753	1	Bush				




T9588


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	49841117	1	Link	12	49808256	1	Lever
2	49809700	1	Plate	13	49807944	1	Spring
3	49807043	2	Pin	14	49841000	1	Kit
4	49808983	1	Spring	15	49809684	1	Sleeve
5	49808975	1	Spring set	16	49808579	1	Flyweight
6	49809692	1	Lever	17	49808231	1	Shifter
7	49849011	1	Shaft	18	49849052	1	Shaft
8	49809411	1	Guide	19	88082524	1	Ring
9	49841133	1	Spring	20	49808058	1	Lever
10	49808223	1	Lever				
11	49809114	1	Kit, lever				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54540414	1	Frame	23	54540331	1	Panel, right hand
2	92119957	1	Seal	24	54540356	1	Panel
3	92824010	2	Handle	25	—		
4	92795095	2	Plate	26	54540380	1	Enclosure hinged
5	92119460	4	Washer	27	54572557	1	Baffle Left hand
6	93465409	1	Mudguard LH	28	54572565	1	Baffle Right hand
7	93465417	1	Mudguard RH	29	54635539	1	Gasket
8	92798727	2	Hinge Lower	30	54635547	1	Cover
9	92798719	2	Hinge Upper	31	54612247	2	Toolbox
10	92119445	2	Pin, hinge	32	54540406	1	Plate, orifice 7/31
11	92107804	2	Spring, gas		54563317	1	Plate, orifice 7/41
12-13	92794254	1	Latch	33	54542899	1	Panel
13	92094358	2	Key	34	—		
14	89257067	2	Protector	35	93477370	2	Bracket
15	92783281	18	Plug	36	93477388	2	Fog light assembly
16	—			37	92788868	2	Plug
17	—			38	54540398	1	Enclosure, fixed
18	92894609	1	Bar, bumper	39	92799501	2	Protector Front
19	92121243	4	Reflector (amber)	40	92799519	2	Protector Rear
20	92085729	4	Reflector (white)	41	92783810	2	Bracket
21	92721331	2	Reflector (red)				
22	54540349	1	Panel, left hand				



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54570734	1	Hose 7/31	9	92311224	1	Clamp
	54540612	1	Hose 7/41	10	—		
2	89204721	1	Filter assembly	11	54573845	1	Pipe 7/31
3	89232474	1	Element, air filter		54540521	1	Pipe 7/41
4	89303853	1	Clamp	12	92321926	1	Clamp
5	—			13	54540570	1	Silencer
6	54540620	1	Bracket	14	54540596	2	Bracket
7	35300615	1	Indicator, air restriction	15	54576632	1	Clamp
8	92117696	1	Clamp	16	54540588	1	Pipe




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54540646	1	Cooler	10	54596705	1	Element, separator
2	54542931	1	Tube assembly	11	54517735	1	Connector Drop-tube
3	54599352	1	Tube assembly 7/31	12	92877620	1	'O' Ring
	54599345	1	Tube assembly 7/41	13	92823921	1	Sight-glass
4	54542998	1	Hose assembly	14	36921690	1	Orifice, sonic 7/31
5	54540737	1	Tube assembly		89232854	1	Orifice, sonic 7/41
6	54540729	1	Manifold	15	93159655	1	Valve, safety
7	54575147	1	Hose assembly 7/31	16	54540745	2	Clamp
	54540711	1	Hose assembly 7/41	17	92294461	2	Valve, ball
8	54577168	1	Clamp	18	92178524	2	Coupling
9	54569405	1	Tank, separator	19	92789288	1	Hose assembly
				20	93472272	1	Seal




T1824
Revision 00
09/00


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1–2	54566328	1	Tank assembly	7	54577184	0.4m	Hose
1	54540653	1	Tank, header	8	54577176	1.3m	Hose
2	54540661	1	Cap			6mm	
3	54564273	2	Clamp	9	92762723	1	Clip, retaining
4	54540554	1	Hose	10	54540547	1	Hose
5	54577275	3	Clip, retaining	11	54577267	2	Clip, retaining
6	92253111	4	Clip, retaining				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1-2	54540489	1	Fuel tank assembly	8	54576624	1.2m	Tube 8mm
1	54542949	1	Tank, fuel	9	89260954	1.2m	Tube 4mm
2	54533047	1	Cap	10	54601901	1	Drop-tube
3	54542949	1	Strap	11	92857556	2	Clamp
4	54580139	1	Grommet	12	54525506	1	Separator, water
5	89257489	1	Grommet	13	92799485	AR	Clip, retaining
6	54580154	1	Elbow 8mm	14	92792977	1	Hose assembly
7	89257497	1	Elbow 4mm	15	92919331	1	Tube
				16	92814243	1	Chain



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	92788918	2	Adaptor	12	92490358	AR	Tube (Nylon) 6mm
2	92293661	2	Washer	13	92794266	1	Elbow
3	93174175	1	Valve, check	14	92715051	1	Connector
4	54403266	1	Elbow	15	54440102	1	Cylinder
5	92799378	AR	Tube (Nylon) 8mm	16	54438213	1	Bracket
6	54403266	1	Elbow	17	54493085	1	Ball-joint
7	35322379	1	Valve, blowdown	18	54438239	1	Link
8	89253991	2	Connector	19	92762756	1	Sensor, temperature
9	92549369	1	Orifice, silencer	20	92931401	1	Connector
10	92863810	1	Adaptor	21	35355106	1	Regulator
11	54403266	1	Elbow				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54572128	1	Panel, instrument	14	54571906	1	Resistor 7/41
2	54479654	1	Cover	15	92656925	1	Battery
3	88125752	1	Door assembly	16	92808161	1	Clamp
4	54571914	1	Decal, facia	17	89231757	1	Cable (red)
5	92306901	1	Hourmeter	18	88109988	1	Cable (black)
6	93159804	1	Eye	19	92789734	1	Cable, earth
7	93159812	1	Spacer	*20	92076173	4	Relay
8	35376342	1	Spring	*21	92969914	5	Diode
9	92086719	1	Key-switch	*22	54572151	1	Harness, main
10	92075530	1	Key	*23	89282867	1	Fuse, holder
11	92799840	1	Spring	*24	89284558	1	Fuse
12	92790187	1	Gauge, pressure	25	93466381	2	Light
†13	35255553	1	Button, start/run	*26	54598701	1	Safety, unit
14	54537303	1	Resistor 7/31	*27	54601653	1	Harness, safety



T1619
Revision 00
02/94

Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	92789742	1	Harness	KEY			
2	92280817	1	Plug	B		1	Black
3	92253194	10	Clip, retaining	BL		1	Blue
*4	92280817	1	Holder	G		1	Green
* Not illustrated				GR		1	Grey
				N		1	Brown
				O		1	Orange
				P		1	Pink
				PU		1	Purple
				R		1	Red
				W		1	White
				Y		1	Yellow




T1828
Revision 00
09/00


Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1-3	85449015	1	KIT – EXTERNAL DECALS (7/31)	4	54482989	1	Decal Engine
1	93499952	2	Decal, logotype (black)	5	92814276	1	Decal, sound power
2	93499929	1	Decal, logotype (black)				
3	54577937	2	Decal, model (white)	*6	93174068	1	KIT – INTERNAL DECALS
1-3	85449023	1	KIT – EXTERNAL DECALS (7/41)	*7	54541768	1	Manual, Operation and Maintenance, with parts catalogue
1	93499952	2	Decal, logotype (black)	*8	54626486	1	Manual, Operation and Maintenance GB
2	93499929	1	Decal, logotype (black)	*9	54681135	1	Manual, Operation and Maintenance (F, NL, D)
3	54540778	2	Decal, model (white)	*10	54681150	1	Manual, Operation and Maintenance (DK, S, N, SF)
				*11	54681143	1	Manual, Operation and Maintenance (P, I, E)
				*12	54626494	1	Manual, Parts catalogue

57


OPTIONS – Lubricator




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1-18	92856160	1	KIT-LUBRICATOR	10	92185016	1	Elbow
1	92919398	1	Head	11	92823913	2	Elbow
2	92919380	1	Housing	*12	93163897	1	Decal GB,D,F
3	92911288	1	Tube	13	92067982	1	Tube (Nylon) 0.75m
4	92919810	1	Plug	14	—		
5	92290162	1	Seal	15	54619374	1	Pipe
6	92919554	1	Valve	16	92896158	2	Screw
7	92490358	1	Tube (Nylon) 0.75m	17	92473594	2	Nut
8	54508866	1	Bracket	18	92472638	2	Screw
9	92715051	2	Connector				



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	92788918	2	Adaptor	14	92715051	1	Connector
2	92293661	2	Washer	15	54440102	1	Cylinder
3	93174175	1	Valve, check	16	54438213	1	Bracket
4	54403266	1	Elbow	17	54493085	1	Ball-joint
5	92799378	AR	Tube (Nylon) 8mm	18	54438239	1	Link
6	54403266	1	Elbow	19	92762756	1	Sensor, temperature
7	89253991	1	Valve, blowdown	20	92799436	1	Elbow
8	92549369	2	Connector	21	35355106	1	Regulator
9	92549369	1	Orifice, silencer	22	92799444	1	Elbow
10	92863810	1	Adaptor	23	92793124	1	Valve, solenoid
11	54403266	1	Elbow	24	89303655	1	Harness
12	92490358	AR	Tube (Nylon) 6mm	25	92173780	1	Connector
13	92794266	1	Elbow	26	93152593	1	Adaptor




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	92690890	1	Pulley	9	88091889	1	Bush
2	89230494	1	Generator 400V	10	—	1	Key
2	88123229	1	Generator 110 / 230V	11	54605985	1	Pulley 7/31
3	89231138	1	Bracket	11	54581160	1	Pulley 7/41
4	89231146	1	Lever	*12	54581186	1	Spacer – Fan
5	35320688	1	Bush	*13– 15	92699412	1	Kit, earth spike
6	35579523	1	Spring	*13	92699420	1	Earth spike
7	54605993	1	Belt, drive 7/31	*14	92699438	1	Cable, earth
7	54581939	1	Belt, drive 7/41	*15	93181366	1	Stud Earth point
8	92855634	1	Pulley				




Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54609706	1	Panel, front WDG	*13	89205355	1	Contactor
2	92856707	1	Valve, solenoid	*14	89231732	1	Circuit breaker
3-5	54585062	1	Panel, instrument (7/31)				63A
3-5	54585096	1	Panel, instrument (7/41)	*15	89231690	1	Socket, electrical outlet 115V, 32A
3	89204648	1	Voltmeter 0-300V	*16	89205371	2	Socket, electrical outlet 115V, 16A
4	54584511	1	Switch	*17	93174118	2	Circuit breaker
5	54637061	1	Harness, voltmeter				16A
6-25	54570544	1	Electrical socket box assembly 110V	*18	89231724	1	Circuit breaker
*6	89283527	1	Box, electrical socket 110V				32A
*7	89231716	1	Earth leakage module	*19	92951417	2	Resistor 2,2K
*8	89205397	3	Terminal, end stop	*20	89232151	1	Switch, test push button (Grey)
*9	88123153	1	Harness, alternator	*21	89232177	1	Switch, contact
*10	54582010	1	Harness, generator control panel	22	—		
*11	92876887	2	Holder, fuse	*23	89249585	1	Terminal, contact block
*12	93478899	2	Fuse 1A	*24	92829308	1	Key Box, electrical socket
				*25	92859560	1	Lock Box, electrical socket

61 OPTIONS – Generator 230V



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54609706	1	Panel, front WDG	*13	89205355	1	Contactor
2	92856707	1	Valve, solenoid	14	—		
3-5	54585062	1	Panel, instrument (7/31)	*15	89231708	2	Socket, electrical outlet 230V, 32A
3-5	54585096	1	Panel, instrument (7/41)	*16	89235389	2	Socket, electrical outlet 230V, 16A
3	89204648	1	Voltmeter 0-300V	*17	89231740	2	Circuit breaker 16A
4	54584511	1	Switch	*18	89231724	1	Circuit breaker 32A
5	54637061	1	Harness, voltmeter	*19	92951417	1	Resistor 2,2K
6-25	89230536	1	Electrical socket box assembly 230V	*20	89232169	1	Switch, test push button (Grey)
*6	89231021	1	Box, electrical socket 230V	*21	89232177	1	Switch, contact
*7	89231716	1	Earth leakage module	22	—		
*8	89205397	3	Terminal, end stop	*23	89249585	1	Terminal, contact block
*9	88123153	1	Harness, alternator	*24	92829308	1	Key Box, electrical socket
*10	89204572	1	Harness, generator control panel	*25	92859560	1	Lock Box, electrical socket
*11	92876887	2	Holder, fuse				
*12	93478899	2	Fuse 1A				



Item	ccn	Qty.	Description	Item	ccn	Qty.	Description
1	54609706	1	Panel, front WDG	*12	93478899	2	Fuse 1A
2	92856707	1	Valve, solenoid	*13	89205355	1	Contact
3-5	54585070	1	Panel, instrument (7/31)	*14	89231740	1	Circuit breaker 10A
3-5	54585104	1	Panel, instrument (7/41)	*15	89230585	1	Socket, electrical outlet 400V, 3Ph 16A
3	89231005	1	Voltmeter 0-600V	*16	89235389	2	Socket, electrical outlet 230V, 1Ph 16A
4	54584511	1	Switch	*17	89230551	2	Circuit breaker 16A
5	54637061	1	Harness, voltmeter	*18	92951417	2	Resistor 2,2K
6-25	54570585	1	Electrical socket box assembly (CE)	*19	89248678	1	Resistor, heatsink
6-25	54570593	1	Electrical socket box assembly (SCHUKO)	*20	89232151	1	Switch, test push button (Grey)
*6	89231021	1	Box, electrical socket	*21	89232177	3	Switch, contact
*7	89230577	1	Earth leakage module	*22	89249577	2	Switch, auxilliary contact MCB
*8	89205397	3	Terminal, end stop	*23	89249585	1	Terminal, contact block
*9	89231013	1	Harness, alternator	*24	92829308	1	Key Box, electrical socket
*10	54582010	1	Harness, generator control panel	*25	92859560	1	Lock Box, electrical socket
*11	92876887	2	Holder, fuse				

Item	Qty.	Description / ccn	Item	Qty.	Description / ccn	Item	Qty.	Description / ccn
1-4	1	85448686	1-5	1	85448694	3	1	36897353
GB		KIT – 500 HOUR	GB		KIT – 1000 HOUR	GB		Element, oil filter (airend)
F		KIT 500 HEURES	F		KIT 1000 HEURES	F		Élément, filtre à huile
P		KIT 500 HORAS	P		KIT 1000 HORAS	P		Elemento, filtro óleo
I		KIT 500 ORE	I		KIT 1000 ORE			(compressor)
E		KIT DE 500 HORAS	E		KIT DE 1000 HORAS	E		Elemento filtro óleo
NL		500 UUR SET	NL		1000 UUR SET	I		Elemento filtro oilio
D		KIT – 500	D		KIT – 1000			(compressore)
		BETRIEBSSTUNDEN			BETRIEBSSTUNDEN	E		Elemento filtro de aceite
DK		500 TIMERS SÆT	DK		1000 TIMERS SÆT			(unidad compresora)
S		500 TIM. SATS	S		1000 TIM. SATS	NL		Element, oliefilter (kompressor)
N		500 TIMERS SETT	N		1000 TIMERS SETT	D		Ölfilterelement
SF		500 TUNNIN SARJA	SF		1000 TUNNIN SARJA			(Verdichterblock)
						DK		Oliefilterelement for luftende
						S		Oljefilterinsats (kompressor)
						N		Kompressoroljefilter
						SF		Panos, öljynsuodatin
								(paineilmapuoli)
1	1	54429675	1	1	54429675	4	1	54525530
GB		Element, oil filter (engine)	GB		Element, oil filter (engine)	GB		Element, water separator
F		Élément, filtre à huile (moteur)	F		Élément, filtre à huile (moteur)	F		Élément séparateur
P		Elemento, filtro óleo (motor)	P		Elemento, filtro óleo (motor)	P		Elemento, separador
I		Elemento filtro oilio (motore)	I		Elemento filtro oilio (motore)	I		Elemento separatore
E		Elemento filtro de aceite	E		Elemento filtro de aceite	E		Elemento separador
		(motor)			(motor)	NL		Afscheider element
NL		Element, oliefilter (motor)	NL		Element, oliefilter (motor)	D		Abscheiderselement
D		Ölfilterelement (Motor)	D		Ölfilterelement (Motor)	DK		Filter element, separator
DK		Oliefilterelement (motor)	DK		Oliefilterelement (motor)	S		Separatorfilterinsats
S		Oljefilterinsats (motor)	S		Oljefilterinsats (motor)	N		Element
N		Motoroljefilter	N		Motoroljefilter	SF		Panos, erotin
SF		Panos, öljynsuodatin (moottori)	SF		Panos, öljynsuodatin (moottori)			
						5	1	89232474
2	1	54381306	2	1	54381306	GB		Element, air filter
GB		Element, fuel filter	GB		Element, fuel filter	F		Élément, filtre à air
F		Élément, filtre à carburant	F		Élément, filtre à carburant	P		Elemento de filtro de ar
P		Elemento filtro de combustivel	P		Elemento filtro de combustivel	I		Elemento filtro aria
I		Elemento filtro nafta	I		Elemento filtro nafta	E		Elemento filtro de aire
E		Elemento filtro de combustible	E		Elemento filtro de combustible	NL		Luchtfilter element
NL		Brandstofffilter element	NL		Brandstofffilter element	D		Luftfilterelement
D		Kraftstofffilter element	D		Kraftstofffilter element	DK		Luftfilterelement
DK		Brændstofffilterelement	DK		Brændstofffilterelement	S		Luftfilterinsats
S		Bränslefilterinsats	S		Bränslefilterinsats	N		Luftfilter
N		Brennstoff – filter	N		Brennstoff – filter	SF		Panos, ilmansuodatin
SF		Panos, polttoainesuodatin	SF		Panos, polttoainesuodatin			
3	1	36897353						
GB		Element, oil filter (airend)						
F		Élément, filtre à huile						
		(compresseur)						
P		Elemento, filtro óleo						
		(compressor)						
I		Elemento filtro oilio						
		(compressore)						
E		Elemento filtro de aceite						
		(unidad compresora)						
NL		Element, oliefilter (kompressor)						
D		Ölfilterelement						
		(Verdichterblock)						
DK		Oliefilterelement for luftende						
S		Oljefilterinsats (kompressor)						
N		Kompressoroljefilter						
SF		Panos, öljynsuodatin						
		(paineilmapuoli)						
4	1	54525530						
GB		Element, water separator						
F		Élément séparateur						
P		Elemento, separador						
I		Elemento separatore						
E		Elemento separador						
NL		Afscheider element						
D		Abscheiderselement						
DK		Filter element, separator						
S		Separatorfilterinsats						
N		Element						
SF		Panos, erotin						

1-40 1 85448389 GB KIT – SERVICE (7/31) F KIT – ENTRETIEN (7/31) P KIT DE SERVICE (7/31) I KIT – SERVIZIO (7/31) E KIT DE SERVICIO (7/31) NL KIT – SERVICE (7/31) D WARTUNGSSATZ (7/31) DK SERVICE – KIT (7/31) S SERVICE SATS (7/31) N SERVICE – SETT (7/31) SF SARJA – HUOLTO (7/31)	5 1 35596436 GB Switch, temperature F Sécurité température P Interruttore temperatura I Interruttore, temperatura E Interruptor de temperatura NL Temperatuurschakelaar D Schalter, Temperatur DK Termostat S Temperaturvakt N Temperatur vakt SF Kytkin, lämpötila	9 1 49807613 GB Valve, relief F Soupape de sûreté P Válvula de descarga I Valvola di sicurezza E Válvula de desahogo NL Ontlastklep D Entlastungsventil DK Overtryksventil S Reduceringsventil N Avlastningsventil SF Venttiili, paineenalennus–
1 1 35300615 GB Indicator, air restriction F Voyant, restriction d'air P Indicador, restrição de ar I Indicatore restrizione di aria E Indicador limitación de aire NL Indicateur luchtweerstand D Anzeige, Luftbegrenzung DK Smuds indikator S Dammindikator N Luftindikator SF Merkkivalo, ilmakanaavutukos	6 1 36878379 GB Switch, oil pressure F Interrupteur, pression d'huile P Interruptor da pressão do óleo I Interruttore, pressione olio E Interruptor, presión del aceite NL Schakelaar, olie druk D Schalter, Öldruck DK Kontakt, olietryk S Oljetrycksbrytare N Oljetrykksbryter SF Kytkin, öljynpaine	10 1 49840853 GB Kit, gasket/O' Ring engine F KIT – Joint/Joint torique P Kit – Juntas/O'Ring I Kit – Guarnizioni/O–Ring E Kit de Juntas/Tóricas NL Kit – Pakking/O'Ring D Dichtungs / O–Ring–Satz DK Paknings– og O–Rings sæt S Packnings–/O–Ringsats N Pakningsett SF Sarja, tiiviste/O–rengas
2 1 35322379 GB Valve, blowdown F Electrovanne de mise à vide P Válvula de descarga I Valvola di scarico E Válvula de purga NL Afblaasklep D Abblaseventil DK Blow down ventil S Avblåsningsventil N Avblåsningsventil SF Venttiili, paineenalennus–	7 1 36897353 GB Element, oil filter (airend) F Élément, filtre à huile (compresseur) P Elemento, filtro óleo (compressor) I Elemento filtro olio (compressore) E Elemento filtro de aceite (unidad compresora) NL Element, oliefilter (kompressor) D Ölfilterelement (Verdichterblock) DK Oliefilterelement for luftende S Oljefilterinsats (kompressor) N Kompressoroljefilter SF Panos, öljynsuodatin (paineilmapuoli)	11 1 49841315 GB Hose, fuel F Tuyau flexible à carburant P Tubo flexível, combustível I Flessibile, carburante E Manguera, combustible NL Slang, brandstof D Schlauch, Kraftstoff DK Slange, brændstof– S Slang, bränsle N Drivstoffslange SF Polttoaineletku
3 1 35327691 GB Switch, water temperature F Sécurité température d'eau P Interruttore temperatura I Interruttore alta temperatura elevata da água E Interruptor de temperatura alta acqua NL Watertemperatuur schakel aar del agua D Wassertemperaturschalter DK Vandtemperaturafbryder S Hög kylvattentemp. vakt N Vanntemperaturbryter SF Veden lämpötilakytkin	8 1 36921690 GB Orifice, sonic F Orifice, sonique P Orificio, sónico I Orificio acustico E Orificio sónico NL Sproeier D Schallöffnung DK Lydåbning S Ljudöppning N Dyse SF Aukko, akustinen	12 3 49841323 GB Nozzle, injector F Gicleur, Injecteur P Bico, injector I Ugello, iniettore E Boquilla de inyector NL Mondstuk, verstuiver D Düse, Einspritz– DK Forstøver S Insprutningsmunstycke N Innsprøytningsdyse SF suutin, suihku–
4 1 35355106 GB Regulator F Régulateur P Regulador I Regolatore E Regulador NL Regulateur D Regler DK Regulator S Regulator N Regulator SF Säädin		

13 1 54381306 GB Element, fuel filter F Élément, filtre à carburant P Elemento filtro de combustivel I Elemento filtro nafta E Elemento filtro de combustible NL Brandstofffilter element D Kraftstofffilter element DK Brændstofffilterelement S Bränslefilterinsats N Brennstoff – filter SF Panos, polttoainesuodatin	18 1 54430707 GB Solenoid, stop F Solénoïde, arrêt P Solenóide de paragem I Solenoide stop E Solenoide de parada NL Relais, stop D Magnetschalter Stop DK Magnetventil, stands S Solenoid. stopp N Stoppsolenoid SF Solenoidi, pysäytys–	23 1 54537303 GB Resistor F Résistance P Resistencia I Resistenza E Resistencia NL Weerstand D Widerstand DK Modstand S Motstånd N Motstand SF Vastus
14 1 54385836 GB Thermostat F Thermostat P Termostato I Termostato E Termostato NL Thermostaat D Thermostat DK Termostat S Termostat N Termostat SF Termostaatti	19 1 54493085 GB Ball-joint F Joint à rotule P Rótula I Giunto sferico E Junta de bola NL Stangkop D Kugelgelenk DK Kugleled S Kulled N Kuleledd SF Kuulanivel	24 1 54540661 GB Cap, header tank F Couvercle P Tampão I Tappo E Caperuza NL Kap D Kappe DK Dæksel S Lock N Hette SF Kansii
15 3 54385893 GB Glowplug F Bobine de préchauffage P Bobine pré-aquecimento I Resistenza preriscaldamento E Bobina de precalentamiento NL Gloeispiraal D Vorglühwendel DK Glødespole S Glødespiral N Glødespiral SF Esilämmityskela	20 1 54525530 GB Element, water separator F Élément séparateur P Elemento, separador I Elemento separatore E Elemento separador NL Afscheider element D Abscheiderselement DK Filter element, separator S Separatorfilterinsats N Element SF Panos, erotin	25 1 54596705 GB Element, separator F Élément séparateur P Elemento, separador I Elemento separatore E Elemento separador NL Afscheider element D Abscheiderselement DK Filter element, separator S Separatorfilterinsats N Element SF Panos, erotin
16 1 54429675 GB Element, oil filter (engine) F Élément, filtre à huile (moteur) P Elemento, filtro óleo (motor) I Elemento filtro oilio (motore) E Elemento filtro de aceite (motor) NL Element, oliefilter (motor) D Ölfilterelement (Motor) DK Oliefilterelement (motor) S Oljefilterinsats (motor) N Motoröljefilter SF Panos, öljynsuodatin (moottori)	21 1 54526801 GB Fan belt F Courroie du ventilateur P Correia de ventoinha I Cinghia della ventola E Correa del ventilador NL Ventilatorsnaar D Lüfterantriebsriemen DK Ventilatorrem S Flåktrem N Vifterem SF Tuuletinhihna	26 1 85448397 GB Kit, gasket/'O' Ring F KIT – Joint/Joint torique P Kit – Juntas/'O' Ring I Kit – Guarnizioni/'O' Ring E Kit de Juntas/Tóricas NL Kit – Pakking/'O' Ring D Dichtungs / O–Ring–Satz DK Paknings– og O–Rings sæt S Paknings–/O–Ringsats N Pakningsett SF Sarja, tiiviste/O–rengas
17 1 54429717 GB Valve, PCV F Valve P Válvula I Valvola E Válvula NL Afsluiter D Ventil DK Ventil S Ventil N Venttiili SF	22 1 54533047 GB Cap, fuel filler F Bouchon, réservoir de carburant P Tampão, bocal gasóleo I Tappo del serbatoio carburante E Tapón boca de combustible NL Tankdop D Kraftstoffeinfüllverschluß DK Brændstofdæksel S Bränslelock N Tanklokk SF kansi, polttoaineen täyttöaukon	27 1 88082656 GB Plug, oil drain F Bouchon P Tomada I Tappo E Tapón NL Plug D Stecker DK Prop S Plugg N Plugg SF Pistoke

28 1 89232474 GB Element, air filter F Élément, filtre à air P Elemento de filtro de ar I Elemento filtro aria E Elemento filtro de aire NL Luchtfilter element D Luftfilterelement DK Luftfilterelement S Luftfilterinsats N Luftfilter SF Panos, ilmansuodatin	34 1 92549369 GB Orifice, silencer F Orifice, silencieux P Orificio, silenciador I Orifizio, silenziatore E Orificio silenciador NL Sproeier, demper D Schalldämpferöffnung DK Åbning for lydæmper S Öppning, ljuddämpare N Dyse med lyddemper SF Aukko, äänenvaimentimen	39 1 93174175 GB Valve, check F Soupape d'arrêt P Válvula de retenção I Valvola di controllo E Válvula antirretorno NL Terugslagklep D Rückschlagventil DK Kontra ventil S Backventil N Tilbakeslagsventil SF Venttiili, takaisku-
29 1 89284558 GB Fuse F Fusible P Fusível I Fusibili E Fusibile NL Zekering D Sicherung DK Sikring S Säkring N Sikring SF Varoke	35 1 92762756 GB Switch, temperature F Sécurité température P Interruptor temperatura I Interruttore, temperatura E Interruptor de temperatura NL Temperatuurschakelaar D Schalter, Temperatur DK Termostat S Temperaturvakt N Temperatur vakt SF Kytkin, lämpötila	40 1 93466381 GB Light, indicator (Amber) F Indicateur (Orange) P Indicador (Ambar) I Indicatore (Ambra) E Indicador (Ambar) NL Indicateur (Oranje) D Anzeiger (orange) DK Indikator (Gul) S Indikator (Gul) N Indikator (Gul) SF Merkkivalo (keltainen)
30 1 92076173 GB Relay F Relais P Relé I Relé E Relé NL Relais D Relais DK Relæ S Relä N Rele SF Rele	36 1 92790187 GB Gauge, pressure F Manomètre P Manometro I Manometro pressione E Manómetro NL Manometer D Druckanzeige DK Manometer S Manometer N Manometer SF Mittari, paine-	1- 1 85448371 41 GB KIT – SERVICE (7/41) F KIT – ENTRETIEN (7/41) P KIT DE SERVICE (7/41) I KIT – SERVIZIO (7/41) E KIT DE SERVICIO (7/41) NL KIT – SERVICE (7/41) D WARTUNGSSATZ (7/41) DK SERVICE – KIT (7/41) S SERVICE SATS (7/41) N SERVICE – SETT (7/41) SF SARJA – HUOLTO (7/41)
31 1 92086719 GB Key-switch F Clef – commutateur P Interruptor de chave I Chiavetta interruttore E Llave interruptor NL Sleutel-schakelaar D Schlüsselschalter DK Tændingskontakt S Tändningslås N Nøkkelbryter SF Virtalukko	37 2 92969914 GB Diode F Diode P Diodo I Diodo E Diodo NL Diode D Diode DK Diode S Diod N Diode SF Diodi	1 1 35300615 GB Indicator, air restriction F Voyant, restriction d'air P Indicador, restrição de ar I Indicatore restrizione di aria E Indicador limitación de aire NL Indicateur luchtweerstand D Anzeige, Luftbegrenzung DK Smuds indikator S Dammindikator N Luftindikator SF Merkkivalo, ilmanavavutukos
32 1 92294461 GB Valve, hand F Robinet de manoeuvre P Válvula manual I Valvola a mano E Válvula de mano NL Handklep D Handventil DK Håndventil S Handventil N Ventil SF Venttiili, käsikäyttö-	38 1 93159655 GB Valve, safety F Soupape de sécurité P Válvula de segurança I Valvola di sicurezza E Válvula de seguridad NL Veiligheidsklep D Sicherheitsventil DK Sikkerhedsventil S Säkerhetsventil N Sikkerhetsventil SF Venttiili, varo-	
33 1 92306901 GB Hourmeter F Compteur horaire P Conta-horas I Contaore E Horómetro NL Urenteller D Betriebsstunden-Zähler DK Timetæller S Timräknare N Timeteller SF Käyttötuntimittari		

2	1	3532379	8	1	36897353	13	1	54381306
	GB	Valve, blowdown		GB	Element, oil filter (airend)		GB	Element, fuel filter
	F	Electrovanne de mise à vide		F	Élément, filtre à huile (compresseur)		F	Élément, filtre à carburant
	P	Válvula de descarga		P	Elemento, filtro óleo (compressor)		P	Elemento filtro de combustivel
	I	Valvola di scarico		I	Elemento, filtro óleo (compressore)		I	Elemento filtro de combustibile
	E	Válvula de purga		E	Elemento filtro olio (compressore)		E	Elemento filtro de combustibile
	NL	Afblaasklep		NL	Element, oliefilter (kompressor)		NL	Brandstoffilter element
	D	Abblaseventil		D	Ölfilterelement (Verdichterblock)		D	Kraftstoffilter element
	DK	Blow down ventil		DK	Oliefilterelement for luftende		DK	Brændstoffilterelement
	S	Avblåsningsventil		S	Oljefilterinsats (kompressor)		S	Bränslefilterinsats
N	Avblåsningsventil	NL	Element, oliefilter (kompressor)	N	Brennstoff – filter			
SF	Venttiili, paineenalennus–	D	Ölfilterelement (Verdichterblock)	SF	Panos, polttoainesuodatin			
3	1	35327691	9	1	49807613	14	1	54385836
	GB	Switch, water temperature		GB	Valve, relief		GB	Thermostat
	F	Sécurité température d'eau		F	Soupape de sûreté		F	Thermostat
	P	Interruptor temperatura		P	Válvula de descarga		P	Termostato
	I	Interruttore alta temperatura		I	Valvola di sicurezza		I	Termostato
	E	Interruttore alta temperatura elevada da água		E	Válvula de desahogo		E	Termostato
	NL	Watertemperatuur schakel aar del agua		NL	Ontlastklep		NL	Thermostaat
	D	Wassertemperaturschalter		D	Entlastungsventil		D	Thermostat
	DK	Vandtemperaturafbryder		DK	Overtryksventil		DK	Termostat
	S	Hög kylvattentemp. vakt		S	Reduceringsventil		S	Termostat
N	Vanntemperaturbryter	N	Avlastningsventil	N	Termostat			
SF	Veden lämpötilakytin	SF	Venttiili, paineenalennus–	SF	Termostaatti			
4	1	35355106	10	1	49840762	15	4	54385893
	GB	Regulator		GB	Kit, gasket/'O' Ring engine		GB	Glowplug
	F	Régulateur		F	KIT – Joint/Joint torique		F	Bobine de préchauffage
	P	Regulador		P	Kit – Juntas/'O' Ring		P	Bobine pré-aquecimento
	I	Regolatore		I	Kit – Guarnizioni/'O–Ring		I	Resistenza preriscaldamento
	E	Regulador		E	Kit de Juntas/Tóricas		E	Bobina de precalentamiento
	NL	Regulateur		NL	Kit – Pakking/'O' Ring		NL	Gloeispiraal
	D	Regler		D	Dichtungs / O–Ring–Satz		D	Vorglühwendel
	DK	Regulator		DK	Paknings– og O–Rings sæt		DK	Glødespole
	S	Regulator		S	Packnings–/O–Ringsats		S	Glödspiral
N	Regulator	N	Pakningsett	N	Glødespiral			
SF	Säädin	SF	Sarja, tiiviste/O–rengas	SF	Esilämmityskela			
5	1	35596436	11	1	49841315	16	1	54429675
	GB	Switch, temperature		GB	Hose, fuel		GB	Element, oil filter (engine)
	F	Sécurité température		F	Tuyau flexible à carburant		F	Élément, filtre à huile
	P	Interruptor temperatura		P	Tubo flexível, combustível		P	Elemento de filtro de óleo
	I	Interruttore, temperatura		I	Flessibile, carburante		I	Elemento filtro olio
	E	Interruptor de temperatura		E	Manguera, combustible		E	Elemento filtro de aceite
	NL	Temperatuurschakelaar		NL	Slang, brandstof		NL	Oliefilter element
	D	Schalter, Temperatur		D	Schlauch, Kraftstoff		D	Ölfilter element
	DK	Termostat		DK	Slange, brændstof–		DK	Oliefilterelement
	S	Temperaturvakt		S	Slang, bränsle		S	Oljefilterinsats
N	Temperatur vakt	N	Drivstoffslange	N	Oljefilter			
SF	Kytin, lämpötila	SF	Polttoaineletku	SF	Panos, öljynsuodatin			
6	1	36878379	12	4	49841323	17	1	54429717
	GB	Switch, oil pressure		GB	Nozzle, injector		GB	Valve, PCV
	F	Interrupteur, pression d'huile		F	Gicleur, Injecteur		F	Valve
	P	Interruptor da pressão do óleo		P	Bico, injector		P	Válvula
	I	Interruttore, pressione olio		I	Ugello, iniettore		I	Valvola
	E	Interruptor, presión del aceite		E	Boquilla de inyector		E	Válvula
	NL	Schakelaar, olie druk		NL	Mondstuk, verstuiver		NL	Afsluiter
	D	Schalter, Öldruck		D	Düse, Einspritz–		D	Ventil
	DK	Kontakt, olietryk		DK	Forstøver		DK	Ventil
	S	Oljetrykksbrytare		S	Innsprøtningsmunstycke		S	Ventil
N	Oljetrykksbryter	N	Innsprøytningsdyse	N	Ventil			
SF	Kytin, öljynpaine	SF	suutin, suihku–	SF	Venttiili			
7	1	36880706						
	GB	Switch, temperature						
	F	Sécurité température						
	P	Interruptor temperatura						
	I	Interruttore, temperatura						
	E	Interruptor de temperatura						
	NL	Temperatuurschakelaar						
	D	Schalter, Temperatur						
	DK	Termostat						
	S	Temperaturvakt						
N	Temperatur vakt							
SF	Kytin, lämpötila							

18 1 54430707 GB Solenoid, stop F Solénoïde, arrêt P Solenóide de paragem I Solenoide stop E Solenoide de parada NL Relais, stop D Magnetschalter Stop DK Magnetventil, stands S Solenoid. stopp N Stoppsolenoid SF Solenoidi, pysäytys–	23 1 54540661 GB Cap, header tank F Couvercle P Tampão I Tappo E Caperuza NL Kap D Kappe DK Dæksel S Lock N Hette SF Kansí	28 1 89232474 GB Element, air filter F Élément, filtre à air P Elemento de filtro de ar I Elemento filtro aria E Elemento filtro de aire NL Luchtfilter element D Luftfilterelement DK Luftfilterelement S Luftfilterinsats N Luftfilter SF Panos, ilmansuodatin
19 1 54493085 GB Ball-joint F Joint à rotule P Rótula I Giunto sferico E Junta de bola NL Stangkop D Kugelgelenk DK Kugleled S Kulledd N Kuleledd SF Kuulanivel	24 1 54571906 GB Resistor F Résistance P Resistencia I Resistenza E Resistencia NL Weerstand D Widerstand DK Modstand S Motstånd N Motstand SF Vastus	29 1 89232854 GB Orifice, sonic F Orifice, sonique P Orificio, sónico I Orifizio acustico E Orificio sónico NL Sproeier D Schallöffnung DK Lydåbning S Ljudöppning N Dyse SF Aukko, akustinen
20 1 54525530 GB Element, water separator F Élément séparateur P Elemento, separador I Elemento separatore E Elemento separador NL Afscheider element D Abscheiderselement DK Filter element, separator S Separatorfilterinsats N Element SF Panos, erotin	25 1 54596705 GB Element, separator F Élément séparateur P Elemento, separador I Elemento separatore E Elemento separador NL Afscheider element D Abscheiderselement DK Filter element, separator S Separatorfilterinsats N Element SF Panos, erotin	30 1 89284558 GB Fuse F Fusible P Fusível I Fusibili E Fusibile NL Zekering D Sicherung DK Sikring S Säkring N Sikring SF Varoke
21 1 54526801 GB Belt, fan F Courroie, ventilateur P Correia da ventoinha I Cinghia, ventola E Correa del ventilador NL Ventilatorsnaar D Riemen, Lüfterantriebs~ DK Rem, ventilator S Flåktrem N Vifterem SF hihna, tuulettimen	26 1 85448397 GB Kit, gasket/O' Ring F KIT – Joint/Joint torique P Kit – Juntas/O'Ring I Kit – Guarnizioni/O–Ring E Kit de Juntas/Tóricas NL Kit – Pakking/O'Ring D Dichtungs / O–Ring–Satz DK Paknings– og O–Rings sæt S Paknings–/O–Ringsats N Pakningsett SF Sarja, tiiviste/O–rengas	31 1 92076173 GB Relay F Relais P Relé I Relé E Relé NL Relais D Relais DK Relæ S Relä N Rele SF Rele
22 1 54533047 GB Cap, fuel filler F Bouchon, réservoir de carburant P Tampão, bocal gasóleo I Tappo del serbatoio carburante E Tapón boca de combustible NL Tankdop D Kraftstoffzufüllverschlus DK Brændstofdæksel S Bränslelock N Tanklokk SF kansi, polttoaineen täyttöaukon	27 1 88082656 GB Plug, oil drain F Bouchon P Tomada I Tappo E Tapón NL Plug D Stecker DK Prop S Plugg N Plugg SF Pistoke	32 1 92086719 GB Key-switch F Clef – commutateur P Interruptor de chave I Chiavetta interruttore E Llave interruptor NL Sleutel–schakelaar D Schlüsselschalter DK Tændingskontakt S Tändningslås N Nøkkelbryter SF Virtalukko

33 1 92294461 GB Valve, hand F Robinet de manoeuvre P Válvula manual I Valvola a mano E Válvula de mano NL Handklep D Handventil DK Håndventil S Handventil N Ventil SF Venttiili, käsikäyttö–	39 1 93159655 GB Valve, safety F Soupape de sécurité P Válvula de segurança I Valvola di sicurezza E Válvula de seguridad NL Veiligheidsklep D Sicherheitsventil DK Sikkerhedsventil S Säkerhetsventil N Sikkerhetsventil SF Venttiili, varo–	2 1 35375369 GB Lipseal, driveshaft F Joint à l'èbres, arbre de transmission P Retentor veio motor I Paraolio, albero E Sello labiado del eje motriz NL Keerring aandrijfas D Lippendichtung, Antriebswelle DK Kanttætning, drivaksel S Låpptätning, drivaxel N Tetningsring – drivaksel SF Huulitiiviste, vetoakselin
34 1 92306901 GB Hourmeter F Compteur horaire P Conta–horas I Contaore E Horómetro NL Urenteller D Betriebsstunden–Zähler DK Timetæller S Timräknare N Timeteller SF Käyttötuntimittari	40 1 93174175 GB Valve, check F Soupape d'arrêt P Válvula de retenção I Valvola di controllo E Válvula antirretorno NL Terugslagklep D Rückschlagventil DK Kontra ventil S Backventil N Tilbakeslagsventil SF Venttiili, takaisku–	3 1 35376359 GB Seal, unloader F Joint, vanne d'aspiration P Vedante do descompressor I Tenuta di scarico E Obturador del descargador NL Keerring, ontlast D Dichtung, Entlastungsventil DK Tætning, Aflaster S Tätning, Avlastare N Forsegling, avlaster SF Tiiviste, purkausventtiilin
35 1 92549369 GB Orifice, silencer F Orifice, silencieux P Orificio, silenciador I Orifizio, silenziatore E Orificio silenciador NL Sproeier, demper D Schalldämpferöffnung DK Åbning for lyddæmper S Öppning, ljuddämpare N Dyse med lyddemper SF Aukko, äänenvaimentimen	41 1 93466381 GB Light indicator (Amber) F Indicateur (Orange) P Indicador (Ambar) I Indicatore (Ambra) E Indicador (Ambar) NL Indicateur (Oranje) D Anzeiger (orange) DK Indikator (Gul) S Indikator (Gul) N Indikator (Gul) SF Merkkivalo (keltainen)	4 1 39404165 GB 'O' Ring, temperature switch F Joint torique, commutateur de température P 'O' ring interruptor temperatura I Tenuta termostato E Tórica interruptor de temp. NL 'O'Ring temperatuurschakelaar D O–Ring, Temperaturschalter DK 'O'ring termostat S O–ring, temperaturvakt N 'O'Ring, temperaturvakt SF O–rengas, lämpökytkin
36 1 92762756 GB Switch, temperature F Sécurité température P Interruptor temperatura I Interruttore, temperatura E Interruptor de temperatura NL Temperatuurschakelaar D Schalter, Temperatur DK Termostat S Temperaturvakt N Temperatur vakt SF Kytkin, lämpötila	1– 1 85448397 13 GB KIT – GASKET/'O' RING (Airend) F KIT – JOINTS/O–RING P KIT – JUNTAS/'O'RING I KIT – GUARNIZIONI/O–RING E KIT DE JUNTAS/TÓRICAS NL KIT – PAKKING/'O'RING D DICHTUNGS / O–RING–SATZ DK PAKNINGS– OG O–RINGS SÆT S PAKNINGS–/O–RINGSATS N PAKNINGSETT SF SARJA – TIIVISTE/O–RENGAS	5 1 49808447 GB Gasket, exhaust F Joint, tubulure d'échappement P Junta, colector escape I Guarnizione, scarico collettore E Junta colector de escape NL Uitlaatpakking D Dichtung, Auspuffkrümmer DK Pakning, udstødningsmanifold S Grenrørspakning N Pakning, eksosmanifold SF Tiiviste, pakosarja
37 1 92790187 GB Gauge, pressure F Manomètre P Manometro I Manometro pressione E Manómetro NL Manometer D Druckanzeige DK Manometer S Manometer N Manometer SF Mittari, paine–	1 1 35279942 GB 'O'Ring, filler plug F Joint torique, bouchon de remplissage P 'O–ring' , bujão enchimento I O–ring, tappo di riempimento E Junta tórica, tapón de llenado NL O–Ring, vulplug D O–Ring, Einfüllstopfen DK 'O'–ring, påfyldningsprop S O–ring, påfyllningsplugg N O–ring, påfyllningsplugg SF O–rengas, täyttötulppa	6 1 88080767 GB Gasket, oil filler cap F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Pakning N Pakning SF Tiiviste
38 2 92969914 GB Diode F Diode P Diodo I Diodo E Diodo NL Diode D Diode DK Diode S Diod N Diode SF Diodi		

7 5 88082607 GB Gasket, fuel filter tubes F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	12 1 95023107 GB 'O' Ring, unloader F Joint torique, vanne d'aspiration P 'O' ring descarregador I Tenuta scarico E Tórica del volumétrico NL 'O'Ring afblaas D O-Ring, Entlastungsventil DK 'O'ring, regulator S O-ring, avlastare N 'O'Ring, avlastningsventil SF O-rengas, purkausventiili	3 2 49708126 GB Gasket, plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
8 2 92788926 GB Seal F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste	13 1 95023115 GB 'O' Ring, rear bearing cover F Joint torique, couvercle du palier arrière P 'O' ring tampa rolamento trás I Tenuta , coperchio cuscinetto posteriore E Tórica de la tapa del rodamiento trasero NL 'O'Ring achter lagerdeksel D O-Ring, Rücklagerabdeckung DK 'O'ring, bageste lejedæksel S O-ring, bakre lagerlock N O'Ring, bakre lagerhus SF O-rengas, takalaakerikansi	4 1 49807159 GB Seal, oil crankshaft rear F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste
9 1 92877620 GB 'O' Ring, drop tube adaptor F Joint torique P 'O' ring I Tenuta E Junta tórica NL 'O'Ring D O-Ring DK O-Ring S O-Ring N O-Ring SF O-rengas	1 1 49840853 -21 GB Kit, gasket/'O' Ring (Engine – 7/31) F KIT – Joint/Joint torique (7/31) P Kit – Juntas/'O'Ring (7/31) I Kit – Guarnizioni/O-Ring (7/31) E Kit de Juntas/Tóricas (7/31) NL Kit – Pakking/'O'Ring (7/31) D Dichtungs / O-Ring-Satz (7/31) DK Paknings- og O-Rings sæt (7/31) S Paknings-/O-Ringsats (7/31) N Pakningsett (7/31) SF Sarja, tiiviste/O-rengas (7/31)	5 6 49807324 GB Seal, guide F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste
10 1 93472272 GB Seal F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste	1 2 49807019 GB Gasket, timing case lever F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	6 1 49808306 GB Gasket, exhaust manifold F Joint, tubulure d'échappement P Junta, colector escape I Guarnizione, scarico collettore E Junta colector de escape NL Uitlaatpakking D Dichtung, Auspuffkrümmer DK Pakning, udstødningsmanifold S Grenrørspakning N Pakning, eksosmanifold SF Tiiviste, pakosarja
11 1 95022331 GB 'O' Ring, driveshaft seal cover F Joint torique, couvercle du joint d'arbre de transmission P 'O' ring tampa veio motor I Tenuta , coperchio paraolio albero trasmissione E Tórica de la tapa del sello del eje motor NL 'O'Ring van aandrijf keering deksel D O-Ring, Abdeckung für Antriebswellendichtung DK 'O'ring, drivaksel tætningsdæksel S O-ring, drivaxeltåtn.lock N 'O'Ring, pakningshus – drivaksel SF O-rengas, vetoakselin tiivisten suojus	2 1 49807027 GB Gasket, oil pump filter F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	7 1 49808702 GB Gasket, timing case cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste

71 RECOMMENDED PARTS

8 1 49809338 GB Gasket, oil pump F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	14 3 54385935 GB Gasket, injector nozzle F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	20 1 88082607 GB Gasket, plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
9 1 49840879 GB Gasket, rocker cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	15 3 54385950 GB Gasket, injector nozzle F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	21 1 88082581 GB Gasket, plug flywheel housing F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
10 1 49840960 GB Gasket, cylinder head F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	16 6 54430715 GB Gasket, fuel injection pipe F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	1 1 49840762 -21 GB Kit, gasket/'O' Ring (Engine – 7/41) F KIT – Joint/Joint torique (7/41) P Kit – Juntas/'O'Ring (7/41) I Kit – Guarnizioni/O–Ring (7/41) E Kit de Juntas/Tóricas (7/41) NL Kit – Pakking/'O'Ring (7/41) D Dichtungs / O–Ring–Satz (7/41) DK Paknings– og O–Rings sæt (7/41) S Paknings–/O–Ringsats (7/41) N Pakningsett (7/41) SF Sarja, tiiviste/O–rengas (7/41)
11 1 49841265 GB Gasket, timing case cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	17 1 88080395 GB Gasket, oil drain plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	1 2 49807019 GB Gasket, timing case lever F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
12 3 49841380 GB Gasket, fuel injection pipe F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	18 1 88080510 GB Seal, oil crankshaft front F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste	2 1 49807027 GB Gasket, oil pump filter F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
13 1 54385851 GB Gasket, thermostat cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	19 1 88082565 GB Gasket, cylinder head plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	

3 2 49807126 GB Gasket, plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	9 1 49841182 GB Gasket, rocker cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	15 4 54385950 GB Gasket, injector nozzle F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
4 1 49807159 GB Seal, oil crankshaft rear F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste	10 1 49841265 GB Gasket, timing case cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	16 8 54537063 GB Gasket, fuel injection pipe F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
5 8 49807324 GB Seal, guide F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste	11 4 49841380 GB Gasket, fuel injection pipe F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	17 1 88080395 GB Gasket, oil drain plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
6 1 49808702 GB Gasket, timing case cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	12 1 49841422 GB Gasket, cylinder head F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	18 1 88080510 GB Seal, oil crankshaft front F Joint P Junta I Tenuta E Sello NL Keerring D Dichtung DK Tætning S Tätning N Tetning SF Tiiviste
7 1 49809338 GB Gasket, oil pump F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	13 1 54385851 GB Gasket, thermostat cover F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	19 1 88082565 GB Gasket, cylinder head plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste
8 1 49841067 GB Gasket, exhaust manifold F Joint, tubulure d'échappement P Junta, colector escape I Guarnizione, scarico collettore E Junta colector de escape NL Uitlaatpakking D Dichtung, Auspuffkrümmer DK Pakning, udstødningsmanifold S Grenrørspakning N Pakning, eksosmanifold SF Tiiviste, pakosarja	14 4 54385935 GB Gasket, injector nozzle F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packning N Pakning SF Tiiviste	

20 1 88082581 GB Gasket, plug flywheel housing F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packing N Pakning SF Tiiviste	89292973 20I GB Pro-Tec™ compressor fluid F Liquide compresseur Pro-Tec™ P Fluido de compresor Pro-Tec™ I Pro-Tec™ – fluido compressore E Líquido de compresor Pro-Tec™ NL Pro-Tec™ compressorvloeistof D Pro-Tec™ Kompressoröl DK Pro-Tec™ – kompressorvæske S Pro-Tec™ kompressorvätska N Pro-Tec™ kompressorolja SF Pro-Tec™ kompressorineste	89311716 20I 15W/40 GB Pro-Tec™ engine oil F Huile moteur Pro-Tec™ P Óleo de motor Pro-Tec™ I Pro-Tec™ – olio motore E Aceite de motor Pro-Tec™ NL Pro-Tec™ motorolie D Pro-Tec™ Motoröl DK Pro-Tec™ – motorolie S Pro-Tec™ motorolja N Pro-Tec™ motorolja SF Pro-Tec™ moottoriöljy
21 1 88082607 GB Gasket, plug F Joint P Junta I Guarnizione E Junta NL Pakking D Dichtung DK Pakning S Packing N Pakning SF Tiiviste	89292981 208I GB Pro-Tec™ compressor fluid F Liquide compresseur Pro-Tec™ P Fluido de compresor Pro-Tec™ I Pro-Tec™ – fluido compressore E Líquido de compresor Pro-Tec™ NL Pro-Tec™ compressorvloeistof D Pro-Tec™ Kompressoröl DK Pro-Tec™ – kompressorvæske S Pro-Tec™ kompressorvätska N Pro-Tec™ kompressorolja SF Pro-Tec™ kompressorineste	89311724 208I 15W/40 GB Pro-Tec™ engine oil F Huile moteur Pro-Tec™ P Óleo de motor Pro-Tec™ I Pro-Tec™ – olio motore E Aceite de motor Pro-Tec™ NL Pro-Tec™ motorolie D Pro-Tec™ Motoröl DK Pro-Tec™ – motorolie S Pro-Tec™ motorolja N Pro-Tec™ motorolja SF Pro-Tec™ moottoriöljy

Language	Translation	Language	Translation	Language	Translation
GB	* Not illustrated	GB	Capscrew Socket Head	GB	Diode assembly
F	* Non illustré	F	Boulon à tête	F	Diode
P	* Não ilustrado	P	Parafuso sextavado interior	P	Diodo
I	* Non illustrato	I	Tappo filettato	I	Diodo
E	* No dibujado	E	Tornillo de caperuza	E	Diodo
NL	* Niet geïllustreerd	NL	Imbusbout	NL	Diode
D	* Nicht abgebildet	D	Innensechskantschraube	D	Diode
DK	* Ikke illustreret	DK	Sætskrue	DK	Diode
S	* Ej visat	S	Insexskruv	S	Diod
N	* Ikke illustrert	N	Unbrakoskrue	N	Diode
SF	* Ei kuvaa	SF	Kantaruuvi, uppokantainen	SF	Diodi
GB	† Option	GB	Contacteur	GB	Earth leakage module
F	† Option	F	Contacteur	F	Module de fuite à la terre
P	† Opções	P	Contacto	P	Módulo de ligação à massa
I	† Opzionale	I	Contattore	I	Presa di terra in esercizio
E	† Opcion	E	Contacto	E	Módulo de fuga a tierra
NL	† Extra	NL	Schakelaar	NL	Aard lek modul
D	† Sonder ausstattung	D	Schutz	D	Erdschlußmodul
DK	† Tilbehør	DK	Kontaktor	DK	Jordafledningsmodul
S	† Tillval	S	Kontaktor	S	Jordfelsesmodul
N	† Ekstraustyr	N	Kontaktor	N	Jordlekkasjemodul
SF	† Lisävaruste	SF	Kontaktori	SF	Maavuotomoduuli
GB	Adaptor	GB	Circuit breaker	GB	Earth spike
F	Adapteur	F	Sectionneur	F	Fiche de mise à la terre
P	Adaptador	P	Corta-circuitos	P	Espigão de terra
I	Adattatore	I	Interruttore circuito	I	Perno di massa
E	Adaptador	E	Interruptor	E	Clavija de puesta a tierra
NL	Adapter	NL	Schakelaar	NL	Aardingsstaaf
D	Anschlußsnippel	D	Electrische Sickerung	D	Erdungsspieß
DK	Adapter	DK	Unterbrecker	DK	Jordspyd
S	Anslutning	S	Afbryderkontakt	S	Jordledartapp
N	Overgang	N	Strömbrytare	N	Jordingspiss
SF	Liitin	SF	Kretsbyrter	SF	Maadoituspiikki
GB	Bolt	GB	Connector	GB	Elbow
F	Boulon	F	Connecteur	F	Coude
P	Parafuso	P	Ligador	P	Joelho
I	Bullone	I	Connettore	I	Gomito
E	Tornillo	E	Conector	E	Codo
NL	Bout	NL	Koppelstuk	NL	Bochtstuk
D	Bolzen	D	Doppelnippel	D	Krümmern
DK	Bolt	DK	Forbindelsesnippel	DK	Vinkel
S	Bult	S	Anslutning	S	Rörkrök
N	Bolt	N	Ansats	N	Albue
SF	Pultti	SF	liitin	SF	Mutka
GB	Box, electrical socket	GB	Decal	GB	Fuse
F	Boîtier, fiche électrique	F	GB,D,F	F	Fusible
P	Caixa, terminal	F	Décalque	P	Fusível
I	Presa (di corrente)	F	GB,D,F	I	Fusibili
E	Caja, enchufes eléctricos	P	Autocolante	E	Fusibile
NL	Kontaktdoos	P	GB,D,F	NL	Zekering
D	Steckdosekasten	I	Targhetta	D	Sicherung
DK	Stikdåse	E	GB,D,F	DK	Sikring
S	Strömuttag	E	Etiqueta	S	Säkring
N	Holder	NL	GB,D,F	N	Sikring
SF	Pistorasia	NL	Sticker	SF	Varoke
GB	Cable, earth	GB	Decal		
F	Cable de terre	D	GB,D,F		
P	Cabo de terra	DK	Decal		
I	Conduttore di terra	S	GB,D,F		
E	Cable tierra	N	Dekal		
NL	Aardingskabel	N	Merke		
D	Erdungskabel	SF	GB,D,F		
DK	Jordkabel		Sirtokuva		
S	Jordkabel		GB,D,F		
N	Jordkabel				
SF	Kaapeli, maatto-				

GB Fuse, holder F Logement de fusible P Porta-fusível I Fusibile, contenitore E Fusible, portafusible NL Zekeringhouder D Sicherung, Halter DK Sikring, holder S Säkring, hållare N Sikringholder SF Varokkeenpidin	GB Key F Clef P Chave I Chiave E Llave NL Spie D Schlüssel DK Not S Kil för remskiva, skruvpaket N Kile skruue – reimhjul SF Selitys	GB Lipseal, driveshaft F Joint à lèvres, arbre de transmission P Retentor veio motor I Paraolio, albergo E Sello labiado del eje motriz NL Keerring aandrijf-as D Lippendichtung, Antriebswelle DK Kanttætning, drivaksel S Läpptätning, drivaxel N Tetningsring – drivaksel SF Huulitiiviste, vetoakselin
GB Harness F Harnais P Cablagem I Cablaggio E Mazo de cables NL Kabelboom D Kabelbaum DK Ledningsnet S Kabelhärva N Ledningsnett SF Johdinsarja	GB Kit, earth spike F Kit de fiche de mise à la terre P Jogo de ligação do espigão de terra I Kit, perno di massa E Juego de clavija de puesta a tierra NL Pakket, aardingsstaaf D Bausatz, Erdungsspieß DK Jordspysæt S Jordledningssats N Jordingspiss–sett SF Maadoituspiikkisarja	GB Lock F Serrure P Fecho I Serratura E Cerradura NL Slot D Schloß DK Lås S Lås N Lås SF Lukko
GB Harness, alternator F Harnais, alternateur P Cablagem, alternador I Cablaggio, alternatore E Mazo de cables, alternador NL Kabelboom, dynamo D Kabelbaum DK Drehstromlichtmaschine S Ledningsnet, generator N Kabelhärva, generator N Ledningsnett, vekselstrømsgenerator SF Johdinsar, laturi	GB KIT – INTERNAL DECALS F KIT – DÉCALCOMANIES INTERNES P KIT – AUTOCOLANTES INTERIORES I KIT – SERIE DI TARGHETTE INTERNE E KIT – CALCOMANÍAS INTERNAS NL KIT – STICKERS BINNENKANT D SATZ INNERE AUFKLEBER DK MONTERINGSSÆT – INDVENDIGE DECALER S SATS INVÄNDIGA DEKALER N SETT – MERKER INNVENDIGE SF SARJA – SISÄISET TARRAT	GB Locknut F Ecrou P Porca de freio I Controdado E Tuerca de seguridad NL Borgmoer D Sicherungsmutter DK Låsemøtrik S Låsmutter N Låsemutter SF Lukkomutteri
GB Harness, generator control panel F Harnais, tableau de commande du générateur P Arnês, painel de comando do gerador I Fascio di cablaggio, pannello di comando del generatore E Mazo de cables, panel de control del generador NL Kabelboom, generator bedieningspaneel D Kabelsatz, Generator Steuertafel DK Ledningsnet, generators instrumentpanel S Kabelhärva, generators styrpanel N Ledningnett, generators kontrollpanel SF Generaattorin hallintataulun johdinsarja	GB Lamp, stop/tail LH F Lampe, feu stop/arrière LH P Luz, stop/retaguarda LH I Spia luminosa, stop, coda LH E Luz, parada/trasera LH NL Gloeilamp, stop-/achterlicht LH D Lampe, Stopp/Melden LH DK Lampe, stop/bag LH S Lampa, stop/fel LH N Bremse/baklys LH SF Lamppu, jarru–takavallo LH	GB Lockwasher F Rondelle d'arrêt P Anilha de aperto I Rosetta di sicurezza E Arandela de presión NL Borgring D Sicherungsscheibe DK Låseskive S Låsbricka N Låseskive SF Lukkoaluslevy
GB Holder F Porte P Suporte I Staffa E Soporte NL Houder D Halter DK Holder S Hållare N Holder SF Pidín	GB Lamp, stop/tail RH F Lampe, feu stop/arrière RH P Luz, stop/retaguarda RH I Spia luminosa, stop, coda RH E Luz, parada/trasera RH NL Gloeilamp, stop-/achterlicht RH D Lampe, Stopp/Melden RH DK Lampe, stop/bag RH S Lampa, stop/fel RH N Bremse/baklys RH SF Lamppu, jarru–takavallo RH	

GB	Manual, Operation and Maintenance, with parts catalogue	GB	Nut	GB	Resistor, heatsink
F	Manuel d'utilisation et de pièces détachées	F	Ecrou	F	Résistances, dissipateur de chaleur
P	Manual de operação e manutenção, com lista de peças	P	Porca	P	Resistência eléctrica, amortecedor de calor
I	Libro d'uso e manutenzione, con lista ricambi	I	Dado	I	Resistenza, dissipatore di calore
E	Manual de manejo y mantenimiento, con lista de repuestos	E	Tuerca	E	Resistor, absorbedor del calor
NL	Bedienings- en onderhoudshandboek, onderdelenkatalogus	NL	Moer	NL	Weerstand, warmteafleiderq
D	Betriebs- und Wartungshandbuch mit Ersatzteilliste	D	Mutter	D	Widerstand, Wärmesenke
DK	Drifts- og vedligeholdelsesmanual, med reservedelsliste	DK	Møtrik	DK	Modstand, varmeafleder
S	Drifts- och underhållsinstruktion med reservedelslista	S	Mutter	S	Motstånd, kyldon
N	Instruksjonsbok, med delekatolog	N	Mutter	N	Motstand, varmebortleder
SF	Ohjekirja, käyttö ja huolto sekä varaosaluettelo	SF	Mutteri	SF	Jäähdytyslevyn vastus
GB	Manual, Operation and Maintenance	GB	'O' Ring	GB	Rivet
F	Manuel d'utilisation et d'entretien	F	Joint torique	F	Rivet
P	Manual de operação e manutenção	P	'O' ring	P	Rebite
I	Libro d'uso e manutenzione	I	Tenuta	I	Rivetto
E	Manual de manejo y mantenimiento	E	Junta tórica	E	Remache
NL	Bedienings- en onderhoudshandboek	NL	'O'Ring	NL	Klinknagel
D	Betriebsanleitung und Ersatzteilliste	D	O-Ring	D	Niet
DK	Drifts- og vedligeholdelsesmanual	DK	O-Ring	DK	Nitte
S	Drifts- och underhållsinstruktion	S	O-Ring	S	Nit
N	Instruksjonsbok	N	O-Ring	N	Nagle
SF	Ohjekirja, käyttö ja huolto	SF	O-rengas	SF	Niitti
GB	Manual, Parts catalogue	GB	Plug	GB	Screw
F	Catalogue de pièces détachées	F	Bouchon	F	Vis
P	Lista de peças	P	Tomada	P	Parafuso
I	Lista ricambi	I	Tappo	I	Vite
E	Lista de repuestos	E	Tapón	E	Tornillo
NL	Onderdelenkatalogus	NL	Plug	NL	Schroef
D	Teile- Liste	D	Stecker	D	Schraube
DK	Reservedelsliste	DK	Prop	DK	Skrue
S	Reservedelslista	S	Plugg	S	Skruv
N	Delekatalog	N	Plugg	N	Skrue
SF	Ohjekirja, varaosaluettelo	SF	Pistoke	SF	Ruuvi
GB	Nipple	GB	Relay	GB	Screw, self tapping
F	Mamelon	F	Relais	F	Vis autotaraudeuse
P	Casquilho	P	Relé	P	Parafuso auto-roscante
I	Nipplo	I	Relé	I	Vite autofilettante
E	Manguito	E	Relé	E	Tornillo, autorroscante
NL	Nippel	NL	Relais	NL	Schroef, zelftapper
D	Nippel	D	Relais	D	Blechschrabe
DK	Nippel	DK	Relæ	DK	Galopskrue
S	Nippel	S	Relä	S	Skruv, självgängande
N	Nippel	N	Rele	N	Treskrue
SF	Nippa	SF	Rele	SF	Itsekierteittävä ruuvi

GB Setscrew F Vis P Parafusos I Vite E Tornillo NL Instelschroef D Stellschraube DK Sætskrue S Ställskruv N Pinneskrue SF Asetusruuvi	GB Switch, contact F Commutateur, contact P Interruptor, contacto I Interruttore, contatti E Interruptor, contacto NL Schakelaar, contact D Kontaktschalter DK Afbryder, kontakt S Brytare, kontakt Bryter, N kontakt SF Kosketuskytkin	GB Terminal, end stop F Borne, embout arrêtoir P Terminal, paragem final I Terminale, fermo d'estremità E Terminal, parada final NL Klem, eindaanslag D Klemme, Endanschlag DK Terminal, endestop S Klämma, ändstopp N Terminal, endestopp SF Pääteliitin, päätyrajoitin
GB Socket, electrical outlet F Prise de sortie électrique P Tomada, saída de corrente I Presa, uscita elettricità E Enchufe, toma eléctrica NL Contactdoos D Elektrische Steckdose DK Stik, elektrisk udtag S Eluttag N Elektrisk kontakt SF Pistorasia	GB Switch, test push button (Grey) F Commutateurs, bouton– poussoir d'essai (gris) P Interruptor, botoneira de teste (Cinzeno) I Interruttore, pulsante di prova (grigio) E Interruptor, botón pulsador de pruebas NL Schakelaar, testknop (grijs) D Schalter, Prüftaster (grau) DK Afbryder, prøvetrykknapp (Grå) S Brytare, testknapp (grå) N Bryter, test–trykknapp (grå) SF Testauspainokytkin (harmaa)	GB Stud F Vis de tour P Perno I Perno E Esparrago NL Tapeind D Bolzen DK Tap S Sprint N Skive SF Vaarna
GB Spacer F Entretoise P Espassador I Distanziatore E Separador NL Vulring D Abstandsstück DK Afstandsskive S Distansring N Distansering SF Välike	GB Tee F Té P Tê I Raccordo a T E Te NL T–stuk D T–Stück DK Tee S T–rør N T–stykke SF T–kappale	GB Washer F Rondelle P Anilha I Rondella E Arandela NL Ring D Unterlegscheibe DK Skive S Bricka N Skive SF Aluslevy
GB Strap F Courroie P Fita I Cinghia E Correa NL Riem D Riemen DK Strop S Rem N Stropp SF Hihna	GB Terminal, contact block F Borne, block de contact (plot) P Terminal, bloco de contacto I Terminale, blocco contatti E Terminal, bloque de contactos NL Klem, klemmenstrook D Klemme, Kontaktblock DK Terminal, kontaktblok S Klämma, kontaktblock N Terminal, kontaktblokk SF Pääteliitin, liityntälohko	
GB Switch, auxiliary contact MCB F Commutateurs, contact auxiliaire MCB P Interruptor, contacto auxiliar MCB I Interruttore, contatti ausiliari interruttore automatico miniatura (MCB) E Interruptor, contacto auxiliar MCB NL Schakelaar, automaat (MCB) hulpcontact D Schalter, Hilfskontakt–MCB (Leistungsschutzschalter) DK Afbryder, hjælpekontakt MCB S Brytare, reservkontakt minikretsbytare N Bryteer, ekstrakontakt MCB SF Lisäkosketuskytkin (pienoisatkaisija – MCB)		

Code	Description	CCN
AV	Bolt M12 x 65	92148014
CB	Bolt 5/8" UNC x 1"	95664314
ED	Capscrew Socket Head M10 x 60	35299353
EM	Capscrew Socket Head M8 x 20	92421403
FH	Capscrew Socket Head M5 x 15	92421429
FO	Capscrew Socket Head M10 x 100	92794502
FQ	Capscrew Socket Head M8 X 50	92475276
GO	Locknut M8	92304559
GQ	Locknut M16	92311695
HA	Locknut 1/2"	95081824
HO	Lockwasher M12	92304682
HX	Lockwasher M4	92340447
HZ	Lockwasher M5	92304641
IA	Lockwasher M6	92304658
IB	Lockwasher M8	92061324
ID	Lockwasher M8	92304666
II	Lockwasher M10	92304674
IU	Screw M8 x 30	92708999
JR	Nut M12	90103854
KD	Nut M8	92304518
KR	Nut M10	92304567
LD	Nut M10	92473594
LG	Nut M8	92398114
LM	Nut M6	92304542
LO	Nut 1/2" UNC	95077798
MA	Rivet 3/16" x 5/8"	92271923
MQ	Screw M8 x 50	92472109
NU	Screw, self tapping M6 x 15	92441450
OA	Screw M6 x 12	92368687

Code	Description	CCN
OG	Screw M10 x 25	92473586
OH	Screw M10 x 30	92182138
OM	Screw M6 x 12	92184811
ON	Screw M6 x 16	92096015
OO	Screw M6 x 20	92398122
OP	Screw M6 x 25	92179043
OQ	Screw M8 x 20	92398130
OR	Screw M8 x 25	92101112
OT	Screw M6 x 12	92722990
QZ	Setscrew M10 x 25	92304401
RA	Setscrew M10 x 30	92280981
RF	Setscrew M12 x 30	90103185
RI	Setscrew M12 x 50	92304450
SG	Setscrew M6 x 20	92304484
SL	Setscrew M8 x 16	92304336
SN	Setscrew M8 x 25	90141078
SW	Setscrew M4 x 16	92050376
SY	Screw M5 x 20	92340058
TI	Screw M16 x 50	92398239
UB	Setscrew M4 x 40	92861442
UH	Setscrew M6 x 40	92476019
VP	Washer M10	92061498
VR	Washer M10	92329283
VT	Washer M12	92061506
WC	Washer M4	92340439
WG	Washer M6	92341981
WH	Washer M8	92061480
WI	Washer M8	92304609
WX	Washer 17 ID X 25 OD	35294339
XE	Washer 1/4"	95094298

Code	Description	CCN
XR	Washer M16	92757632
ZV	Stud M8 x 30	92961499
D4	Capscrew Socket Head M10 x 30	89298566
E5	Washer	49807969
E7	Washer	49807431
E8	Bolt	88081203
E9	Washer	88082466
F2	Bolt M6 X 20 Flange	49840663
F3	Bolt M8 X 25	49807878
F4	Bolt M12 X 89	49808280
F5	Bolt M8 X 16 Flange	49806797
F7	Bolt M6 X 14 Flange	49806748
F8	Bolt M10 – 1.5 X 20	49806896
F9	Bolt M6 X 13 W/WASHER	49809650
G2	Bolt M8 X 45 FLANGE	49806870
G3	Bolt M6 X 25 FLANGE	49806763
G5	Bolt	49807423
G6	Bolt	49807761
H3	Bolt M8 X 60 FLANGE	49806888
H4	Bolt M8 X 40 FLANGE	49806805
H5	Bolt M8 X 70 FLANGE	49806839
H6	Bolt M8 X 45 FLANGE	49806813
H7	Bolt M8 X 20 FLANGE	88080049
H8	Bolt M6 X 12	49806722
J3	Stud M8 X 1.25	49809973
J4	Stud M8 X 36	49809957
J7	Bolt	49840820
J8	Nut	49840838
J9	Nut	49840721
K2	Bolt M10 X 30 FLANGE	49806854
K3	Bolt M10 X 20 FLANGE	49806896
K4	Bolt M6 X 12 FLANGE	88080023

Code	Description	CCN	Code	Description	CCN	Code	Description	CCN
K5	Bolt M8 X 30 FLANGE	88080064	P6	Washer	88082433	T6	Stud	49806987
K6	Bolt M6 X 30 FLANGE	49806771	Q3	Screw	49807886	T7	Stud M6 X 19 L= 27	49807720
K7	Bolt M6 X 50 FLANGE	49806789	Q4	Screw M4 – 0.7 X 10	49809924	T8	Stud	49807712
K9	Bolt M10 x 70	49806862	Q5	Screw	49808389	U8	Bolt	88080105
L3	Nut	49806946	Q6	Screw	49807902	U9	Bolt	49840697
L4	Nut	49809668	Q7	Screw	49807696	V2	Bolt	88081393
L5	Nut	49807118	S2	Bolt M6 – 1.0 x 16	49809635	V3	Bolt	49840713
L6	Nut	49849086	S3	Bolt M6 x 22	49809643	W5	Bolt M8 – 1.25 X 80 FLANGE HEAD	48906847
L8	Nut	88080312	S5	Bolt	54530530	W6	Washer	49841539
M3	Nut M8	88082383	S6	Bolt, Eye M14 X 29	88082672	W7	Stud	49841489
M5	Nut	88080320	S8	Bolt	49840812	W8	Bolt M10 – 1.75 X 25 FLANGE HEAD	49840705
M6	Nut	49849078	S9	Bolt M8 X 53 Flange	49840846	Y3	Screw M8 – 1.25 X 80	36884187
M7	Nut	49807100	T2	Stud M8 X 79 L=92	49807092	Y4	Bolt, Eye	49840853
M8	Nut	88082367	T3	Stud	49809122	Y5	Stud	48909932
M9	Nut	49807381	T4	Stud M6 X 16 L=25	49809932	Z3	Washer	92058429
N3	Nut	49849060	T5	Stud M8 X 52	49809965	Z4	Washer	88082433
P3	Washer	49807134						
P4	Washer	49849094						
P5	Washer	49849102						

Tube Fittings Index			CCN	Tube Fittings Index			CCN	Tube Fittings Index			CCN	
AC	Adaptor	92123215		LX	Elbow	89249643		XM	Nipple	92795194		
BH	Connector	35295880		MS	'O' Ring	92338946		WP	Elbow	54485222		
BU	Connector	92104132		OA	Plug	35579630		WS	Elbow	54403191		
BW	Connector	92091990		OH	Plug	39483888		WX	Elbow	35374867		
KH	Tee	54577192		OZ	Plug	93502128						

CCN & PAGE	CCN & PAGE	CCN & PAGE	CCN & PAGE	CCN & PAGE	CCN & PAGE
92799519, 48	92848647, 6, 6	92894609, 48	93151413, 8	93465417, 48	95023115, 8, 70
92799840, 54	92855634, 59	92896158, 57	93152593, 58	93466381, 54, 66, 69	95064697, 3, 5, 6
92808161, 54	92856160, 57	92911288, 57	93159655, 50, 66, 69	93472272, 50, 70	95076774, 2, 4
92810373, 6	92856707, 60, 61, 62	92919331, 52	93159804, 54	93477370, 48	95076790, 5
92810381, 6	92857556, 52	92919380, 57	93159812, 54	93477388, 48	95077442, 3, 5
92814243, 52	92859560, 60, 61, 62	92919398, 57	93163897, 57	93478899, 60, 61, 62	95081857, 3, 5
92814276, 56	92863810, 53, 58	92919554, 57	93174068, 56	93499929, 56	95094314, 3, 5
92823913, 57	92869775, 3, 6	92919810, 57	93174118, 60	93499952, 56	95252524, 1, 4
92823921, 50	92869783, 3, 6	92931401, 53	93174175, 53, 58, 66, 69	95002697, 1, 4	95391348, 1, 4
92824010, 48	92876887, 60, 61, 62	92951417, 60, 61, 62	93181366, 59	95022331, 8, 70	
92829308, 60, 61, 62	92877620, 50, 70	92969914, 54, 66, 69	93465409, 48	95023107, 8, 70	

