



PARTS MANUAL

COMPRESSOR MODEL

P250WJDU

Code: ~

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.

Utility Equipment
P.O. Box 868 - 501 Sanford Ave
Mocksville, N.C. 27028
www.irutilityequipment.com

Book 22904759 Revision C (12/06)

Revised (09-12)



TABLE OF CONTENTS

TITLE	PAGE
Section B - COMPRESSOR PARTS	
FRAME COMPLETE	B-2
FRAME COMPLETE cont'd	B-3
FRAME COMPLETE cont'd	B-4
ENGINE COMPLETE	B-5
ENGINE COMPLETE cont'd	B-6
ENGINE COMPLETE cont'd	B-7
COOLING COMPLETE	B-8
COOLING COMPLETE cont'd	B-9
COOLING COMPLETE cont'd	B-10
OIL TEMP BYPASS VALVE ASM. Prior to S/N 355498	B-11
OIL TEMP BYPASS VALVE ASM. Begin with S/N 355498	B-12
AIREND ASSEMBLY	B-13
AIR END COMPLETE Prior to S/N 341755	B-14
AIR END COMPLETE Begin with S/N 341755	B-16
UNLOADER VALVE ASSEMBLY	B-18
UNLOADER VALVE ASSEMBLY cont'd	B-19
AIR SERVICE COMPLETE	B-20
SEPARATOR TANK COMPLETE	B-21
SEPARATOR TANK COMPLETE cont'd	B-22
SEPARATOR TANK COMPLETE cont'd	B-23
ELECTRIC START-RUN VALVE	B-24
CENTRAL DRAINS	B-25
CENTRAL DRAINS cont'd	B-26
AIR INTAKE COMPLETE	B-27
AIREND AIR CLEANER ASM.	B-28
ENGINE AIR CLEANER ASM.	B-29
FUEL TANK COMPLETE	B-30
REMOTE FILTERS COMPLETE	B-31
REMOTE FILTERS COMPLETE cont'd	B-32
REMOTE FILTERS COMPLETE cont'd	B-33
AIR and OIL PIPING	B-34
AIR and OIL PIPING cont'd	B-35
AIR and OIL PIPING cont'd	B-36
AIR and OIL PIPING cont'd	B-37
AIR and OIL PIPING cont'd	B-38
AIR and OIL PIPING cont'd	B-39
AIR and OIL PIPING for ELECT START RUN VALVE OPTION	B-40
INSTRUMENT COTROL PANEL without START RUN VAVLE	B-41
INSTRUMENT COTROL PANEL without START RUN VAVLE cont'd	B-42
BATTERY and MOUNTING	B-43
WIRING DIAGRAM	B-44
WIRING DIAGRAM cont'd	B-45
WIRING DIAGRAM cont'd	B-46
ENCLOSURE COMPLETE	B-47
ENCLOSURE COMPLETE cont'd	B-48
ENCLOSURE COMPLETE cont'd	B-49
ENCLOSURE COMPLETE cont'd	B-50
ACOUSTIC PANELS	B-51
ACOUSTIC PANELS cont'd	B-52
DECAL LOCATION	B-53
DECAL LOCATION cont'd	B-54
DECAL LOCATION cont'd	B-55

TABLE OF CONTENTS

TITLE	PAGE
-------	------

Section A - Parts Ordering



GENERAL

This publication, which contains an illustrated parts breakdown, has been prepared as an aid in locating those parts which may be required in the maintenance of the unit. Always insist on genuine Ingersoll-Rand Company parts for your compressor.

Ingersoll-Rand Company can bear no responsibility for injury or damages resulting directly from the use of non-approved repair parts.

Ingersoll-Rand Company service facilities and parts are available worldwide. Consult local yellow pages or visit: www.portablepower.irco.com.

Special order parts may not be included in this manual. Contact the Mocksville Parts Department with the unit serial number for assistance with these special parts.

Description

The illustrated parts breakdown illustrates and lists the various assemblies, subassemblies and detailed parts which make up this particular machine. This covers the standard models and the more popular options that are available.

In referring to the rear, the front or to either side of the unit, always consider the drawbar end of the unit as the front.

Standing at the rear of the unit facing the drawbar (front) will determine the right and left sides.

Fasteners

Both SAE/inch and ISO/metric hardware have been used in the design and assembly of these units. In the disassembly and reassembly of parts, extreme care must be taken to avoid damaging threads by the use of wrong fasteners.

How To Order


Always specify the model and serial number of the unit.

Specify the part number and description.

Section B - COMPRESSOR PARTS




FRAME COMPLETE



22904759_cp02_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36890457	Frame	1	
B	36890515	Corner, Vert Street Cab	1	
C	36890523	Corner, Vert Street Bed	1	
D	36890564	Frame, Door Lower	1	
E	36890556	Frame, Door Lower	1	
F	36890671	Frame, Door Upper	1	
G	36890663	Frame, Door Upper	1	
H	22329114	Rear Door	1	
J	22329122	Front Door	1	
L	36890622	Bracket, Engine Oil/Fuel	1	
N	36890465	Bridge, Cooler	1	
P	36890572	Seal, Door Long	9	
Q	36877587	Rivets, 3/16" DIA	46	


FRAME COMPLETE cont'd



22904759_cp02_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
R	36895746	Nutsert, Hex M8	8	
S	35279025	Screw, Tapping M08-1.25 X 20	50	
T	36890580	Seal, Door Short	1	
U	36890499	Corner, Vert Curb Cab	1	
V	36890507	Corner, Vert Curb Bed	1	
W	36891810	Hinge, Door	2	
X	36793602	Latch, Front Door	1	
Y	36797652	Screw, Tapping M06-1.0 X 12	8	
Z	36794816	Rivet, .187 Dia.	8	
A1	36865293	Bumper, Rubber	14	
A2	36894210	Pan, Fuel Tank	1	
A3	35114081	Clamp, Rubber Coated	2	
A4	36797652	Screw, Tapping M6-1.0 X 12	2	


FRAME COMPLETE cont'd



22904759_cp02_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A5	35140409	Foam	32"	Incl. Items A9, A10, A12
A6	36896785	Plug	1	
A7	22333843	Rear Fork Tube Cover	1	
A8	22329163	Front Louver Assembly	1	
A9	22343529	Front Louver Acoustical Foam	5	
A10	22334874	Front Louver Crossmember	5	Incl. Items A12 thru A14
A11	22331151	Rear Louver Assembly	1	
A12	36877587	Rivet	30	
A13	22334882	Rear Louver Crossmember	9	
A14	22343537	Rear Louver Acoustical Foam	9	
A15	22319867	Latch Rear Door	2	


ENGINE COMPLETE



22904759_cp04_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22302046	Engine	1	Prior to S/N 342112
	22382683	Engine	1	Begin w/ S/N 342112
B	54471651	Bracket, Front Engine	2	
D	36888055	Screw, Hex Flange HD M12-1.75 X 30	6	
F	36500197	Isolator	2	
G	35279025	Screw, Tapping M08-1.25 X 20	8	
H	35304047	Nut, Hex Nyloc M12-1.75	2	
J	96739958	Screw, Hex M12-1.75 X 70	2	
K	54429295	Washer, Snubber	2	
L	36892461	Spacer, Fan	1	
M	36878171	Fan	1	


ENGINE COMPLETE cont'd



22904759_cp04_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
P	95934998	Washer, Flat	4	
Q	36881563	Muffler	1	
R	35851377	U-Bolt	1	
S	95923322	Nut, Hex Lock 3/8-16	2	
T	36796845	Clamp, Muffler	2	
U	95935227	Screw, Hex 5/16-18 x 1 1/4	2	
V	95929782	Nut, Hex 5/16 - 18	2	
W	35209048	Clamp, Saddle	1	
X	36775690	Pipe, Exhaust Tail	1	
Y	36880839	Bracket, Muffler	1	
Z	36877223	Support, Air Cylinder	1	


ENGINE COMPLETE cont'd



22904759_cp04_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A2	35328467	Bearing, Rod end	2	
A3	96701461	Screw, Hex M06-1.0 x 25	2	
A4	36769032	Nut, Hex Lock M06-1.0	2	
A5	35592435	Cylinder, Pneumatic	1	
A6	95923074	Nut, Hex Jam 5/16-24	2	
A7	54429295	Washer Flat	2	
A10	54471669	Bracket, Isolator	2	
~	36881696	Element, Engine Oil filter	AR	
~	36534659	Element, Engine Fuel Filter	AR	


COOLING COMPLETE



22904759_cp06_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36889780	Cooler, Oil	1	
B	36889772	Radiator	1	
C	36890473	Orifice, Fan	1	
D	36891158	Hose, Radiator Bottom	1	
E	36891141	Hose, Radiator Top	1	
F	35221662	Clamp	4	
G	35291384	Elbow, 90° 1.31-12 x -16 JIC	2	
H	22287247	Tube, Oil Cooler -16 JIC	1	
J	22287254	Tube, Oil Cooler -16 JIC	1	
K	35356468	Connector, Straight 1.06-12 x -16 JIC	2	
L	54716360	Guard, Fan	1	


COOLING COMPLETE cont'd



22904759_cp06_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
M	54414420	Valve, Oil Temperature By-Pass	1	Prior to S/N 355498
	22558944	Valve, Oil Temperature By-Pass	1	Begin w/ S/N 355498
N	36890481	Bracket, Oil Bypass	1	
Q	36884948	Bottle, Coolant Recovery	1	
T	35360775	Tubing, 5/16"	38	
U	36881886	Nut, Hex Flange M08-1.25	10	
V	35279025	Screw, Tapping M08-1.25 X 20	7	
W	35294768	O-Ring	2	
X	96702055	Screw, Hex M08-1.25 X 20	8	
Y	36797652	Screw, Tapping M06-1.0 X 12	6	
Z	36895746	Nutsert, Hex M08	19	


COOLING COMPLETE cont'd



22904759_cp06_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A3	35221662	Clamp, Rubber Coated	1	
A4	36769560	Cap, Radiator	1	
A5	35221639	Clamp, Hose	1	
A6	36878221	Grommet, Radiator Hose	2	
A7	35294750	Elbow, 90° 1-1/16-12 X -12 JIC	1	
A8	35613041	Plug, Hole	2	
A9	36786382	Screw, Hex M8-1.25 X 70	2	
A10	95644019	Reducer	1	
A11	95992632	Elbow, 45° 1.31 SAE X 1" Tubing	1	


OIL TEMP BYPASS VALVE ASM. Prior to S/N 355498



22904759_cp08_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
~	54414420	Assy, Oil Temp Bypass Valve		
A	35288448	Ball	1	
B	36782019	Element, Thermal	1	
C	36788172	Seal, U-Type	1	
D	36876779	Cover, Bypass Valve, Machined	1	
E	54414305	Housing, Oil Temp Bypass Valve	1	
F	54414677	Orifice, Oil	1	
G	95022307	O-ring	1	
H	96702659	Screw, Hex M08-1.25 x 25	4	
J	35379940	Spring	1	


OIL TEMP BYPASS VALVE ASM. Begin with S/N 355498



22904759_cp08_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
~	22558944	Assy, Oil Temp Bypass Valve		
A	35288448	Ball	1	
B	35318708	Element, OTBV	1	
C	36788172	Seal, U-Type	1	
D	36876779	Cover, Bypass Valve, Machined	1	
E	54414305	Housing, Oil Temp Bypass Valve	1	
F	54414677	Orifice, Oil	1	
G	95022307	O-ring	1	
H	96702659	Screw, Hex M08-1.25 x 25	4	
J	35379940	Spring	1	


AIREND ASSEMBLY



22904759_cp14_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95989695	Adapter, Straight Tube 1/2-20	1	
B	93481570	Tube Assembly, 5/16"	1	Prior to S/N 341755
	22373377	Tube, Rear Bearing Feed	1	Begin w/ S/N 341755
C	95052387	Union, Tube Fitting -4 JIC X -5 JIC	1	Prior to S/N 341755
	95219697	Connector, Male 1/4 NPT X -5 JIC	1	Begin w/ S/N 341755
D	95951646	Tee, Tube Fitting -12 JIC	1	Prior to S/N 341755
	35330117	Tee, Male Run -12 JIC	1	Begin w/ S/N 341755
E	96739693	Adapter, M26-1.5 X -12 JIC Swivel	1	
G	93186278	Reducer, -12 JIC X -4 JIC	1	Prior to S/N 341755
	95944633	Bushing, 1/4 NPT X 3/4 NPT		Begin w/ S/N 341755
H	95986014	Connector, Female Swivel 7/16-20	1	Prior to S/N 341755
	95998001	Coupling, 3/4 NPT X 1.56"		Begin w/ S/N 341755
J	35373976	Tee, Male Branch 1/4 NPT x 3/8 Tube	1	
K	35296409	Connector, 1-7/8-12 x -24 JIC	1	
L	22287221	Tube, A/E Discharge	1	
M	36766756	Muffler, Orifice 0.140	1	
N	95944906	Elbow, 90° Union -24 JIC x -24 JIC		
P	22287189	Tube, A/E Injection Oil -12 JIC		


AIR END COMPLETE Prior to S/N 341755



22904759_cp10_A_05/06


ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54755087	Coupling	1	
B	54755111	Bushing, Hex	1	
C	54471685	Bracket, A/e Support	1	
D	96701503	Screw, Hex M16-2.0 X 90	1	
E	95935052	Washer, Flat	1	
F	22287155	Bracket, A/E Mounting	1	
G	35358274	Screw, Socket Head M16-2.00 X 25	4	
H	95376943	Screw, Socket Set 3/8-16 X 1/4"	1	
J	36880995	Screw, Hex Flange M10-1.5 X 30	8	
K	90544772	O-Ring	1	
L	35588532	Flange, Unloader Inlet	1	
M	36889202	Gasket, Unloader	1	
N	54436845	Unloader Assembly	1	
P	35282292	Tubing	14"	
Q	35316587	Adapter, Barbed 1/8" NPT	1	
R	36769289	Key, Coupling	1	
S	54471057	Isolator, Rubber	1	
T	35327212	Washer, Snubber	1	
U	96704630	Nut, Nyloc M16-2.0	1	
V	54390943	Airend	1	
W	96708201	Screw, Socket Head M10-1.50 X 80	8	
X	35323542	Adapter, Barbed 1/8" NPT	1	
Y	35323450	Stud, M16-2.0 X 55	4	
Z	96701750	Nut, Hex M16-2.0	4	
A1	35279025	Screw, Tapping M08-1.25 X 20	6	
A2	39317599	Seal, Double Element	1	
A3	39317581	Seal, Single Element	1	
A4	96720545	Screw, Socket Head M16-2.0 X 35	4	Prior to S/N 341402 Begin w/ S/N 341402
	35358274	Screw, Socket Head M16-2.0 X 25	4	
A5	35377621	Clamp, Spring	2	
A6	36766756	Muffler, Orifice 0.140	1	
A7	35114545	Tee, Street 1/4" NPT	1	
A8	35283464	Elbow, 90° 1/4" NPT X -4 JIC Swivel	2	
A9	35369347	Connector, Male 1/4" NPT X 3/8" Tube	1	
B1	35588318	Gasket, Unloader Inlet	1	
B2	96702048	Screw, Hex M08-1.25 X 16	4	
B3	93481455	Gasket, A/e Discharge	1	
B4	54413042	Plate, Discharge	1	
B5	54390950	Adapter, CF90 A/E	1	
B6	95944666	Elbow, Street 90° 1/4" NPT	1	
B7	95944690	Tee, Street 1/4" NPT	1	

AIR END COMPLETE Begin with S/N 341755



ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54755087	Coupling	1	
B	54755111	Bushing, Hex	1	
C	54471685	Bracket, A/e Support	1	
D	96701503	Screw, Hex M16-2.0 X 90	1	
E	95935052	Washer, Flat	1	
F	22287155	Bracket, A/E Mounting	1	
G	35358274	Screw, Socket Head M16-2.00 X 25	4	
H	95376943	Screw, Socket Set 3/8-16 X 1/4	1	
J	36880995	Screw, Hex Flange M10-1.5 X 30	8	
K	90544772	O-ring	1	
L	35588532	Flange, Unloader Inlet	1	
M	36889202	Gasket, Unloader	1	
N	54436845	Unloader Assembly	1	
P	35282292	Tubing	14"	
Q	35316587	Adapter, Barbed 1/8" NPT	1	
R	36769289	Key, Coupling	1	
S	54471057	Isolator, Rubber	1	
T	35327212	Washer, Snubber	1	
U	96704630	Nut, Nyloc M16-2.0	1	
V	54390943	Airend	1	
W	96708201	Screw, Socket Head M10-1.50 X 80	8	
X	35323542	Adapter, Barbed 1/8" NPT	1	
Y	35323450	Stud, M16-2.0 X 55	4	
Z	96701750	Nut, Hex M16-2.0	4	
A1	35279025	Screw, Tapping M08-1.25 X 20	6	
A2	39317599	Seal, Double Element	1	
A3	39317581	Seal, Single Element	1	
A4	35358274	Screw, Socket Head M16-2.0 X 25	4	
A5	35377621	Clamp, Spring	2	
A6	36766756	Muffler, Orifice .140	1	
A7	35114545	Tee, Street 1/4" NPT	1	
A8	35283464	Elbow, 90° 1/4" NPT X -4 JIC Swivel	2	
A9	35369347	Connector, Male 1/4 NPT X 3/8" Tube	1	
B1	35588318	Gasket, Unloader Inlet	1	
B2	96702048	Screw, Hex M08-1.25 X 16	4	
	96702816	Screw, Hex M08-1.25 X 16	4	
B3	93481455	Gasket, A/e Discharge	1	
B4	54413042	Plate, Discharge	1	
B5	54390950	Adapter, CF90 A/E	1	
B7	95944690	Tee, Street 1/4" NPT	1	


UNLOADER VALVE ASSEMBLY



22904759_cp12_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35318013	Housing Bushing	1	
B	35317205	Washer	1	
C	35322767	Piston Spring	1	
D	35318005	Piston Bushing	2	
E	35588193	Piston Unloader	1	
F	35317197	Diaphragm	1	
G	35321603	Spring	1	
H	35317239	Piston Washer	1	
J	35321595	Capscrew	1	
K	35836949	Piston Cover	1	
L	35271162	Screw	4	
M	96702287	Screw	6	


UNLOADER VALVE ASSEMBLY cont'd



22904759_cp12_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
N	35833227	Piston Housing	1	
P	35588300	Piston Gasket	1	
Q	35591122	Valve Plate	1	
R	54425335	Unloader Body	1	
S	35278555	Plug	1	
T	35318914	Pin Spring	1	
U	35317213	Unloader Pin	1	
V	35289057	Plug	1	
W	35278589	O-ring	1	
X	35279959	O-ring	1	
	35088798	Repair Kit	AR	


AIR SERVICE COMPLETE



22904759_cp16_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22287171	Tube, Service	1	
B	95219861	Elbow, 90° Tube 1.25" NPT x -20 JIC	1	
C	35114545	Tee, Street 1/4" NPT	1	
D	95048914	Nipple, 1/4" NPT X 7/8"	1	
E	35279777	Elbow, 90° Swivel 1-5/8 -12 X -20 JIC	1	
H	36923928	Nozzle Sonic 0.453	1	
J	95953378	Elbow, 90° 1-1/4" NPT	1	
K	95916268	Nipple, Long 1.25 x 8"	1	Prior to S/N 341755 Begin w/ S/N 341755
	95992897	Nipple, Long 1.25 x 9"	1	
M	36785277	Clamp, Saddle	1	
N	36881076	Valve, WYE	1	
R	35279942	O-Ring	3	
S	95944666	Elbow, Street 90° 1/4" NPT	1	
T	35324839	Valve, Ball 1/4" NPT	1	


SEPARATOR TANK COMPLETE



22904759_cp18_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22287163	Tank, Separator	1	Incl's Item S Prior to S/N 348258 Begin w/ S/N 348258
B	39831888	Element, Separator	1	
D	36781227	Tube, Scavenge	1	
F	35579630	Plug, Hex 1 5/8-12 w/ O-Ring	1	
G	36891083	Gage Assembly, Oil Level	1	
H	36877793	Screw, Hex Flange M12-1.75 X 40	8	
J	36890317	Fitting, Scavenge	1	
	35329309	Fitting, Lenz Tube	1	
K	95944708	Tee, Street 1/2" NPT	1	
L	35325224	Valve, Safety	1	
M	95955993	Connector, Tube 1-5/16 - 12 X 1-5/16 - 12	1	
N	35294750	Elbow, 90° 1-1/16-12 X -12 JIC	1	


SEPARATOR TANK COMPLETE cont'd



22904759_cp18_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
P	35246438	Hose, Discharge	1	Prior to S/N 341896 Begin w/ S/N 341896
Q	35279025	Screw, Tapping M08-1.25 X 20	4	
R	35279942	O-Ring	1	
S	36891489	Pointer Assembly, Rotating	1	
T	95928230	Plug, Hex 1/4" NPT	1	
U	95431292	Elbow, 90° 1-7/8-12 X -24 JIC	1	
V	22287197	Tube, Separator Tank/OTBV	1	
	35227909	Hose Assembly, -16 JIC	1	
W	35283506	Hose Assembly, -8 JIC	1	
X	35322379	Valve, Blowdown	1	
Y	36766772	Orifice 0.062	1	
Z	35114545	Tee, Street 1/4" NPT	1	


SEPARATOR TANK COMPLETE cont'd



22904759_cp18_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A1	95048914	Nipple, 1/4" NPT X 7/8"	3	
A2	36854149	Regulator, Pressure	1	
A4	35365774	Reducer, Tube -12 JIC X -8 JIC	1	
A5	35369354	Elbow, 90° Male 1/4" NPT x 3/8" Tube	1	
A6	95944666	Elbow, Street 90° 1/4" NPT	1	
A7	95930301	Reducer, Hex 1/4" NPT X 1/8" NPT	1	
A8	95954194	Tee, 1/4" NPT	1	
A9	35369347	Connector, Male 1/4" NPT X 3/8" Tube	1	
A10	36766756	Muffler, Orifice 0.140	1	
A11	36840437	Valve, 0.062 Inline Orifice/Check	1	
A12	36891547	Elbow, 90° Male 1/8" NPT X 1/8" Tube	1	


ELECTRIC START-RUN VALVE



22904759_cp19_A_12/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36892669	Bracket, Solenoid Valve	1	See Lengths Above
B	36843142	Valve, Solenoid	1	
C	95940748	Reducer, Bushing 3/8 NPT X 1/4 NPT	2	
D	35369354	Elbow, 90° Male 1/4" NPT x 3/8" Tube	2	
E	95928982	Screw, Hex 1/4-20 X 3/4"	2	
F	35369347	Connector, Male 1/4" NPT X 3/8" Tube	3	
G	35114545	Tee, 1/4" NPT	1	
H	35356484	Tubing, 3/8" OD Synflex	~	
J	22090278	Switch, Rocker	1	
K	35307685	Wire, Brown 14 AWG	36"	
L	35360916	Wire, Orange 14 AWG	36"	
M	36844520	Connector, Female 1/4" Insulated	2	
N	35306141	Connector, Male 1/4" Insulated	2	


CENTRAL DRAINS



22904759_cp20_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35294735	Elbow, 90° 3/4" NPT X -12 JIC	1	9/16" 1.06
B	35323807	Hose, Engine Oil Drain	1	
C	95220844	Clamp, Hose	3	
D	35114081	Clamp, Hose	1	
E	36891067	Tube, Radiator Drain	1	
F	35279025	Screw, Tapping M08-1.25 X 20	6	
G	36891588	Bracket, Drain Piping	2	
H	36892479	Hose, .50 ID	15"	
J	36892172	Hose, Drain Connector	1	
K	95220851	Clamp, Worm Gear	2	


CENTRAL DRAINS cont'd



22904759_cp20_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
L	35285451	Union, -8 JIC Bulkhead	3	
M	35283506	Hose Assembly, -8 JIC	1	
N	35294750	Elbow, 90° 1-1/16-12 X -12 JIC	1	
P	36891208	Wrench, Plate	1	
Q	95257325	Cap, Hex Tube 3/4-16	3	
R	36891042	Tube, Fuel Drain	1	
S	95730172	Cap, Hex Tube 1.06-12	1	
T	95332599	Connector, Bulkhead 1.06-12	1	
V	35365774	Reducer, Tube -12 JIC X -8 JIC	1	


AIR INTAKE COMPLETE



22904759_cp22_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36862829	Engine Air Cleaner Assembly	1	
B	35585009	Band, Air Cleaner	2	
C	36889608	Screw, Hex Flange M8-1.25 X 16	4	
D	36881886	Nut, Hex Flange M8-1.25	4	
E	22287148	Bracket, Engine Air Filter Mounting	1	
F	35279025	Screw, Tapping M08-1.25 X 20	4	
G	22287205	Hose, Engine Air Intake	1	
H	35314996	Clip	1	
J	35374073	Clip	1	
K	35165802	Clamp	2	
L	22287122	Elbow, Rubber 180°	1	
M	22287130	Bracket, Airend Air Cleaner	1	
N	36879492	Screw, Hex Flange M12-1.75 X 25	2	
O	54471826	Air End Air Cleaner Assembly	1	


AIREND AIR CLEANER ASM.



22904759_cp24_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54479811	Body, Air Cleaner	1	Optional
B	35393719	Cap, Plug	1	
C	35393669	Clip, Retaining	3	
D	35393677	Valve, Dust Ejector	1	
E	54471834	Element, Primary	1	
F	54415393	Cover Assembly	1	
G	54471842	Element, Safety	1	


ENGINE AIR CLEANER ASM.



22904759_cp26_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35388883	Body, Air Cleaner	1	
B	35326032	Cover, Air Cleaner	1	
C	35388891	Valve, Vacuator	1	
D	36876423	Element, Air Cleaner	1	
E	35291475	Nut, Air Cleaner	1	
F	36790277	Capnut, Air Cleaner	1	


FUEL TANK COMPLETE



22904759_cp28_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36889939	Tank, Fuel	1	See Lengths Above
B	36890200	Sender, Fuel Level	1	
C	36885564	Cap, Fuel	1	
D	35361849	Gasket, Fuel Sender	1	
E	36892156	Standpipe Assembly, Pickup	1	
F	35384577	Bushing, Nitrile	2	
G	36892164	Standpipe Assembly, Return	1	
H	95916532	Screw, Filister SLTD HD #10-32 X 1/2"	5	
J	35322460	Union, Barbed Tube	1	
K	95220851	Clamp, Hose	2	
L	35363498	Hose, Fuel	*	
M	35296342	Clamp, Wormgear	6	
N	36892172	Hose, Drain Connector	1	
P	35225093	Clamp, 1/2" Support	3	
Q	35279025	Screw, Tapping M08-1.25 X 20	1	
R	36767051	Foam, Closed Cell	5	
S	36845493	Filter, Fuel	1	
T	92368687	Screw, Tapping M06-1.0 X 14	1	

REMOTE FILTERS COMPLETE




** Furnished by Engine Manufacturer

22904759_cp30_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36897387	Oil Filter Assembly	1	
	36897445	Head, Filter	1	
	36897353	Element, Compressor Oil Filter	1	
B	36534659	Element, Engine Fuel Filter	1	
C	36881696	Element, Engine Oil Filter	1	
D	36891968	Tube, Oil Fill	1	
E	35294750	Elbow, 90° 1-1/16-12 X -12 JIC	2	
F	22287189	Tube, A/E Injection Oil -12 JIC	1	
G	95951646	Tee, Tube Fitting -12 JIC	1	Prior to S/N 341755
	35330117	Tee, Male Run -12 JIC	1	Begin w/ S/N 341755
H	36889350	Line, 90° Fuel	4	
J	35363498	Hose, 5/16" Fuel	*	See Length Above

REMOTE FILTERS COMPLETE cont'd




** Furnished by Engine Manufacturer

22904759_cp30_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
K	35296342	Clamp, Worm Gear	6	
L	36889947	Bulb, Fuel Primer	1	
M	35323864	Hose Assembly, -12 JIC	1	
N	36890895	Hose, Oil Fill	1	
P	35221662	Clamp, Hose	2	
Q	36891109	Adapter, Engine Oil Fill	1	
R	35114057	Clamp, Support	1	
S	35376953	Screw, Hex M10-1.50 x 20	1	
T	36879195	Nut, Hex Flange M10-1.50	1	
V	36890168	Dipstick, Remote Mount	1	
W	35114081	Clamp, Support	2	

REMOTE FILTERS COMPLETE cont'd




** Furnished by Engine Manufacturer

22904759_cp30_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
X	35300771	Screw, Tapping M06-1.0 x 20	1	
Y	96702055	Screw, Hex M08-1.25 X 20	2	
Z	95934998	Washer, Flat	2	
A1	36894160	Gasket, Engine Oil Fill	1	
A2	36895472	Connector, Fuel Filter	3	
A3	22287262	Bracket, Oil Fill Support	1	
A4	96702279	Screw, Hex M10-1.5 x 20	1	
A5	36895977	Reducer, Fuel Line	1	
A6	35279025	Screw, Tapping M08-1.25 X 20	2	


AIR and OIL PIPING



22904759_cp32_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
1	35356484	Tubing, Synflex 3/8"		
2	35324839	Valve, Ball 1/4" NPT		
3	95953378	Elbow, 90° 1-1/4" NPT		
4	36923928	Nozzle, Sonic Orifice		
5	35369347	Connector, Male 1/4" NPT X 3/8" Tube		
6	22287171	Tube Assy, Service Air		
7	36781227	Tube Assy, Oil Scavenge		
8	35370386	Elbow, 90° Male 1/8" NPT x 3/8" Tube		
9	35369354	Elbow, 90° Male 1/4" NPT x 3/8" Tube		
10	22287197	Tube, Separator Tank/OTBV		Prior to S/N 341896 Begin w/ S/N 341896
	35227909	Hose Assembly, -16 JIC		
11	36766756	Muffler, Orifice 0.140		
12	35279777	Elbow, 90° Swivel 1-5/8 -12 X -20 JIC		
13	22287247	Tube, Oil Cooler -16 JIC		


AIR and OIL PIPING cont'd



22904759_cp32_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
14	95928230	Plug, Hex 1/4" NPT		
15	95944690	Tee, Street 1/4" NPT		
16	35373976	Tee, Male Branch 1/4 NPT x 3/8 Tube		
17	95431292	Elbow, 90° 1-7/8-12 X -24 JIC		
18	35246438	Hose, Discharge		
19	95219861	Elbow, 90° Tube 1.25" NPT x -20 JIC		
20	35358662	Hose Assy, -4 JIC		
21	95916268	Nipple, Long 1.25 x 8"		Prior to S/N 341755
	95992897	Nipple, Long 1.25 x 9"		Begin w/ S/N 341755
22	36840437	Valve, 0.062 Inline Orifice/Check		
23	36766772	Orifice 0.062		
24	54414420	Valve, Oil Temperature By-Pass		Prior to S/N 355498
	22558944	Valve, Oil Temperature By-Pass		Begin w/ S/N 355498
25	35322379	Valve, Blowdown		


AIR and OIL PIPING cont'd



22904759_cp32_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
26	35325224	Valve, Safety		
27	36854149	Regulator, Pressure		
28	95944708	Tee, Street 1/2" NPT		
29	22287254	Tube, Oil Cooler -16 JIC		
30	35294750	Elbow, 90° 1-1/16-12 X -12 JIC		
31	54764964	Switch, Shutdown w/ O-Ring		
32	35356468	Connector, Straight 1.06-12 X -16 JIC		
33	36891083	Gage Assembly, Oil Level		
34	95992632	Elbow, 45° 1.31 SAE X 1" Tubing		
35	95935599	Coupling, Female 1/8" NPT X 3/4"		
36	36890317	Fitting, Scavenge		Prior to S/N 348258 Begin w/ S/N 348258
	35329309	Fitting, Lenz Tube		
37	36881076	Valve, WYE		
38	35579630	Plug, Hex 1 5/8-12 w/ O-Ring		


AIR and OIL PIPING cont'd



22904759_cp32_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
39	35279942	O-Ring		
40	95944666	Elbow, Street 90° 1/4" NPT		
41	95954194	Tee, 1/4" NPT		
42	95667341	Nipple, Close 1/4" NPT X 7/8"		
43	36891547	Elbow, 90° Male 1/8" NPT X 1/8" Tube		
44	36891562	Tubing, 1/8" Synflex		
45	35283506	Hose Assembly, -8 JIC		
46	35285451	Union, -8 JIC Bulkhead		
47	95257325	Cap, Hex Tube 3/4-16		
48	35323864	Hose Assembly, -12 JIC		
49	22287189	Tube, A/E Injection Oil -12 JIC		
50	36897445	Head, Filter		
51	35287556	Plug, Hex 9/16-18		
52	36897353	Element, Compressor Oil Filter		


AIR and OIL PIPING cont'd



22904759_cp32_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
53	95930301	Reducer, Hex 1/4" NPT X 1/8" NPT		
54	35291384	Elbow, 90° 1.31-12 X -16 JIC		
55	35294750	Elbow, 90° 1-1/16-12 X -12 JIC		
56	35283464	Elbow, 90° 1/4" NPT X -4 JIC Swivel		
57	96739693	Adapter, M26-1.5 X -12 JIC Swivel		
58	95951646	Tee, Tube Fitting -12 JIC	1	Prior to S/N 341755
	35330117	Tee, Male Run -12 JIC	1	Begin w/ S/N 341755
59	95986014	Connector, Female Swivel 7/16-20	1	Prior to S/N 341755
	95998001	Coupling, 3/4 NPT X 1.56"		Begin w/ S/N 341755
60	93186278	Reducer, -12 JIC X -4 JIC	1	Prior to S/N 341755
	95944633	Bushing, 1/4 NPT X 3/4 NPT		Begin w/ S/N 341755
61	93481570	Tube Assembly, 5/16"	1	Prior to S/N 341755
	22373377	Tube, Rear Bearing Feed	1	Begin w/ S/N 341755
62	95989695	Adapter, Straight Tube 1/2-20		


AIR and OIL PIPING cont'd



22904759_cp32_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
63	35316587	Adapter, Barbed 1/8" NPT		Prior to S/N 341755 Begin w/ S/N 341755
64	35377621	Clamp, Spring		
65	35282292	Tubing		
66	35323542	Adapter, Barbed 1/8" NPT		
67	35296409	Connector, 1-7/8-12 x -24 JIC		
68	22287221	Tube, A/E Discharge		
69	95944906	Elbow, 90° Union -24 JIC x -24 JIC		
70	95052387	Union, Tube Fitting -4 JIC X -5 JIC		
	95219697	Connector, Male 1/4 NPT X -5 JIC		
71	552A10S073P	Reducer, Straight -16 JIC X -12 JIC		
72	35365774	Reducer, Tube -12 JIC X -8 JIC		
73	95955993	Connector, Tube 1-5/16 - 12 X 1-5/16 - 12		
74	35114545	Tee, Street 1/4" NPT		


AIR and OIL PIPING for ELECT START RUN VALVE OPTION



22904759_cp34_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
1	35356484	Tubing, Synflex 3/8"		Prior to S/N 348258 Begin w/ S/N 348258
5	35369347	Connector, Male 1/4" NPT X 3/8" Tube		
7	36781227	Tube Assy, Oil Scavenge		
9	35369354	Elbow, 90° Male 1/4" NPT x 3/8" Tube		
11	36766756	Muffler, Orifice 0.140		
22	36840437	Valve, 0.062 Inline Orifice/Check		
27	36854149	Regulator, Pressure		
36	36890317	Fitting, Scavenge		
	35329309	Fitting, Lenz Tube		
41	95954194	Tee, 1/4" NPT		
42	95667341	Nipple, Close 1/4" NPT X 7/8"		
53	95930301	Reducer, Hex 1/4" NPT X 1/8" NPT		
74	35114545	Tee, Street 1/4" NPT		
75	95940748	Bushing, Hex 1/4 NPT X 3/8 NPT		
76	36843142	Valve, Solenoid		


INSTRUMENT COTROL PANEL without START RUN VAVLE



22904759_cp36_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54749601	Frame, WW Instrument Panel	1	
B	22171680	Panel, Instrument	1	
C	22171698	Decal, WW Instrument Panel	1	
D	54766704	Meter, Electronic Hour	1	
E	22054159	Nut, Plastic #4-40	2	
F	22127385	Switch, Ignition	1	
G	35604065	Gauge	1	
H	95935599	Coupling, Female 1/8" NPT X 3/4"	1	
J	36891547	Elbow, 90° Male 1/8" NPT X 1/8" Tube	1	
K	22134118	Knob, Start	1	
L	22199079	Adapter, Switch	1	
M	22107478	Hinge, Control Panel	1	
N	36897380	Door, Instrument Panel	1	


INSTRUMENT COTROL PANEL without START RUN VAVLE cont'd



22904759_cp36_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
P	22070494	Screw, Plastic Tapping	8	
Q	36920486	Rivet, Aluminum	6	
R	36877587	Rivet, Aluminum	4	
S	22058291	Gauge ASM., 4-IN-1	1	
T	35607829	Eyebolt	2	
U	95935029	Washer, Flat	2	
V	36772028	Washer, Plastic	2	
W	35607837	Spring	2	
X	95923298	Nut, Hex 1/4"-20	2	
Y	54774112	Module, 2-Light Warning	1	
Z	54774096	Gauge, Fuel	1	Prior to S/N 368445
	35604099	Gauge, Fuel	1	Begin with S/N 368445

BATTERY and MOUNTING




22904759_cp38_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36844264	Battery	1	Prior to S/N 362372 Begin with S/N 362372
B	35516582	Cable, Positive Battery	1	
C	36892685	Cable, Negative Battery	1	
D	36853257	Angle	1	
E	36890648	Tray, Battery	1	
F	35130293	Screw, Tapping 3/8-16 X 3/4"	1	
G	36860005	J-Bolt	2	
H	36853265	Washer, Plastic	2	
J	35144492	Nut, Lock 1/4-20	2	
K	35225093	Clamp, 1/2" Support	2	
	35225077	Clamp, 11/16" Support	2	
L	36783488	Strap, Ground	1	
M	35279025	Screw, Tapping M08-1.25 X 20	5	

WIRING DIAGRAM

S1 KEYSWITCH OPERATION SEQUENCE




22904759_cp40_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
B	36844264	Battery	1	
CF1	36792083	Fuse, 20 A	1	
D1	35676169	Diode	1	
D3	35676169	Diode	1	
D4	35676169	Diode	1	
D5	35676169	Diode	1	
D6	35676169	Diode	1	
D7	35676169	Diode	1	
G	36124881	Alternator	1	
FG	54774096	Gauge, Fuel	1	Prior to S/N 368705
	35604099	Gauge, Fuel	1	Begin with S/N 368705
FS	22058531	Sender, Fuel	1	Combined in 1 Lamp Module
H	54766704	Hourmeter	1	
IL1	54774112	Low Oil Press Indicator Lamp	1	Combined in 2 Lamp Module
IL2	54774112	Low Oil Press Indicator Lamp	1	Combined in 2 Lamp Module
LFS	22058531	Switch, Low Fuel	1	Combined in 1 Lamp Module

WIRING DIAGRAM cont'd


S1 KEYSWITCH OPERATION SEQUENCE



22904759_cp40_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
M	36120649	Starter	1	
PS1	54747935	Switch, Engine Oil Pressure	1	
R2	54368048	Relay, Start Protect	1	
R3	54368048	Relay, Start Inhibit	1	
R4	54368048	Relay, Fuel Solenoid	1	
R5	54368048	Relay, Fuel Shutdown	1	
R6	54368048	Relay, Crank	1	
R7	54368048	Relay, High Engine Temp	1	
S1	92086719	Switch, Key	1	
	22134118	Knob, Start	1	
SV1	36125409	Solenoid, Fuel	1	
TS1	54764964	Switch, Alarm (A/E High Temp)	1	Prior to S/N 375300
	36865756	Switch, Alarm (A/E High Temp)	1	Between S/N 375300 & 375557
	39404165	O-Ring	AR	Between S/N 375300 & 375557
	22823199	Switch, Alarm (A/E High Temp)	1	Begin w/ S/N 375557
TS2	54764956	Switch, Alarm (Dischg High Temp)	1	Prior to S/N 375300
	35596436	Switch, Alarm (Dischg High Temp)	1	Begin w/ S/N 375300
TS3	36893055	Switch, High Engine Temp	1	
W1	22060321	Harness, Engine Control	1	
W2	22828016	Adapter, Temp. Switch	2	Begin w/ S/N 375300


WIRING DIAGRAM cont'd



22904759_cp42_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
ATS	35372457	Airend Temp Sender		
ETH	35367739	Manual Ether Start		
	35377266	Automatic Ether Start		
ETS	35372457	Engine Temp Sender		Prior to S/N 341896
	54593843	Engine Temp Sender		Begin with S/N 341896
GEN	36852622	Generator, 4.5 KW		
GL	36852622	Gauge Lights		
	35333236	Bulb, Incandescent		
IL3	22061493	Low Oil Press Indicator Lamp		Combined in 4 Lamp Module
IL4	22061493	High Engine Temp Indicator Lamp		Combined in 4 Lamp Module
IL5	22061493	High A/E Temp Indicator Lamp		Combined in 4 Lamp Module
IL6	22061493	High A/E Temp Indicator Lamp		Combined in 4 Lamp Module
OPS	36870608	Oil Pressure Sender		
PB1	~	Push Button Switch		Included in Option
SV2	~	Tachometer		Included in Option
TAC	22060198	Solenoid, Ether		
TS4	~	Switch, Block Temp. Ether		Included in Option
VS1	36847838	Switch, Air Filter Restriction		
VS2	36847838	Switch, Air Filter Restriction		
W3	22074843	Harness, Gauge Illumination Option		
W4	36842839	Harness, Air Filter Restr. Option		
W5	36842821	Harness, Manual Cold Start Option		


ENCLOSURE COMPLETE



22904759_cp44_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36890531	Stringer, Cab Side	1	
B	36890549	Stringer, Bed Side	1	
C	36890762	Panel, Roof CLR End	1	
D	36891414	Channel, Roof Connector	1	
E	36890838	Panel, Roof	1	
F	36890739	Panel, Upper Engine Bed	1	
G	36890721	Panel, Lower Engine Bed	1	
H	36890812	Box, Air Inlet Bed	1	
J	36890747	Panel, Filter End Bed	1	
K	22287213	Bulkhead, Rear Bed	1	


ENCLOSURE COMPLETE cont'd



22904759_cp44_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
L	36890713	Panel, Cooler End Bed	1	See Length Above
M	36891745	Stringer, Lift Beam	1	
N	36891729	Member, Lift Beam Rear	1	
P	36891737	Member, Lift Beam Front	1	
Q	36891760	Eye, Lift Beam	2	
R	35368216	Foam	~	
S	36890796	Bulkhead, Rear Cab	1	
T	36890473	Orifice, Fan	1	
U	36890705	Panel, Filter End Cab	1	
V	36890770	Box, Air Inlet Cab	1	


ENCLOSURE COMPLETE cont'd



22904759_cp44_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
W	36892982	Spacer	1	
X	92304450	Screw, Hex Cap M12-1.75 x 50	1	
Y	36786218	Lanyard	2	
Z	36890697	Panel, Upper Engine Cab	1	
A1	36890689	Panel, Lower Engine Cab	1	
A2	36890655	Panel, Cooler End Cab	1	
A3	36895746	Nutsert, Hex M08	51	
A4	36877587	Rivet	15	
A5	35279025	Screw, Tapping M08-1.25 X 20	73	
A6	36892677	Latch, Trigger	4	


ENCLOSURE COMPLETE cont'd



22904759_cp44_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A7	36861383	S-Hook	4	
A8	35279413	Cover, Roof Access	1	
A9	36879492	Screw, Hex Flange M12-1.75 X 25	5	
	36881712	Screw, Hex Flange 1/2-13 X 1.0"	2	
B1	36879203	Nut, Hex Flange M12-1.75	7	
B2	36877793	Screw, Hex Flange M12-1.75 X 40	4	
B3	36892206	Cap, Vinyl	4	
B4	22095533	Bracket, Relay Mounting	1	
B5	36797652	Screw, Tapping M06-1.0 X 12	2	
B6	35271170	Screw, Hex M8-1.25 X 40	2	


ACOUSTIC PANELS



22904759_cp52_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22338529	Panel, Acoustic St. Door	1	
B	22338511	Panel, Acoustic CRB Door	1	
C	36892925	Panel, Acoustic BHD Cab eng	1	
D	22338636	Panel, Acoustic Exhaust Plenum	1	
E	22338628	Panel, Acoustic Fork Truck Plt	2	
F	22338545	Panel, Acoustic Cab Cooler	1	
G	22338552	Panel, Acoustic Cab Lwr Eng.	1	
H	22338560	Panel, Acoustic Cab Upper Eng.	1	
J	22338578	Panel, Acoustic Cab Fltr End	1	
K	36892776	Panel, Acoustic Cab Air Box	1	
L	22338586	Panel, Acoustic Bed Lwr Eng	1	


ACOUSTIC PANELS cont'd



22904759_cp52_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
M	22338545	Panel, Acoustic Bed Cooler End	1	
N	22338602	Panel, Acoustic Bed Fltr End	1	
P	36892834	Panel, Acoustic Bed Air Box	1	
Q	22338610	Panel, Acoustic Bed Upper Eng	1	
R	36892883	Panel, Acoustic Oil Cooler Top	1	
S	36892909	Panel, Acoustic Center Roof	1	
T	36892917	Panel, Acoustic End Roof	1	
U	22287239	Panel, Acoustic BHD Bed Side	1	
V	36892941	Panel, Acoustic BHD Ctr Upper	1	
W	36892933	Panel, Acoustic BHD Cab Fltr	1	
X	36892891	Panel, Acoustic	1	


DECAL LOCATION



22904759_cp46_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54568779	Decal, Rotating Fan	2	
B	54568761	Decal, Hot Press Fluid	1	
C	54629902	Decal, Combination 3-part	1	
E	54568787	Decal, Improper Operation	1	
F	36514602	Decal, Noise Emission	1	


DECAL LOCATION cont'd



22904759_cp48_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22099311	Decal, Operating Instructions	1	
B	22108617	Card, Standard Wiring	1	
C	22108641	Card, Option Wiring	1	
D	54568753	Decal, Battery Gas	1	
E	54604970	Decal, Oil Fill	1	
F	54568795	Decal, High Pressure Air	1	
G	54629977	Decal, Central Drains	1	
H	22389886	Plate, Serial Number	1	
J	36794816	Rivet	2	

DECAL LOCATION cont'd



22904759_cp50_A_05/06

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54568779	Decal, Rotating Fan	1	
B	54604962	Decal, Radiator Fill Hot	1	
C	54625207	Decal, Diesel Fuel	1	

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
~	B-46	22338545	B-51	35279025	B-3	35316587	B-15
22054159	B-41		B-52		B-5		B-17
22058291	B-42	22338552	B-51		B-9		B-39
22058531	B-44	22338560	B-51		B-15	35317197	B-18
22060198	B-46	22338578	B-51		B-17	35317205	B-18
22060321	B-45	22338586	B-51		B-22	35317213	B-19
22061493	B-46	22338602	B-52		B-25	35317239	B-18
22070494	B-42	22338610	B-52		B-27	35318005	B-18
22074843	B-46	22338628	B-51		B-30	35318013	B-18
22090278	B-24	22338636	B-51		B-33	35318708	B-12
22095533	B-50	22343529	B-4		B-43	35318914	B-19
22099311	B-54	22343537	B-4		B-49	35321595	B-18
22107478	B-41	22373377	B-13	35279413	B-50	35321603	B-18
22108617	B-54		B-38	35279777	B-20	35322379	B-22
22108641	B-54	22382683	B-5		B-34		B-35
22127385	B-41	22389886	B-54	35279942	B-20	35322460	B-30
22134118	B-41	22558944	B-9		B-22	35322767	B-18
.....	B-45		B-12		B-37	35323450	B-15
22171680	B-41		B-35	35279959	B-19		B-17
22171698	B-41	22823199	B-45	35282292	B-15	35323542	B-15
22199079	B-41	22828016	B-45		B-17		B-17
22287122	B-27	35088798	B-19		B-39		B-39
22287130	B-27	35114057	B-32	35283464	B-15	35323807	B-25
22287148	B-27	35114081	B-3		B-17	35323864	B-32
22287155	B-15		B-25		B-38		B-37
.....	B-17		B-32	35283506	B-22	35324839	B-20
22287163	B-21	35114545	B-15		B-26		B-34
22287171	B-20		B-17		B-37	35325224	B-21
.....	B-34		B-20	35285451	B-26		B-36
22287189	B-13		B-22		B-37	35326032	B-29
.....	B-31		B-24	35287556	B-37	35327212	B-15
.....	B-37		B-39	35288448	B-11		B-17
22287197	B-22		B-40		B-12	35328467	B-7
.....	B-34	35130293	B-43	35289057	B-19	35329309	B-21
22287205	B-27	35140409	B-4	35291384	B-8		B-36
22287213	B-47	35144492	B-43		B-38		B-40
22287221	B-13	35165802	B-27	35291475	B-29	35330117	B-13
.....	B-39	35209048	B-6	35294735	B-25		B-31
22287239	B-52	35221639	B-10	35294750	B-10		B-38
22287247	B-8	35221662	B-8		B-21	35333236	B-46
.....	B-34		B-10		B-26	35356468	B-8
22287254	B-8		B-32		B-31		B-36
.....	B-36	35225077	B-43		B-36	35356484	B-24
22287262	B-33	35225093	B-30		B-38		B-34
22302046	B-5		B-43	35294768	B-9		B-40
22319867	B-4	35227909	B-22	35296342	B-30	35358274	B-15
22329114	B-2		B-34		B-32		B-17
22329122	B-2	35246438	B-22	35296409	B-13	35358662	B-35
22329163	B-4		B-35		B-39	35360775	B-9
22331151	B-4	35271162	B-18	35300771	B-33	35360916	B-24
22333843	B-4	35271170	B-50	35304047	B-5	35361849	B-30
22334874	B-4	35278555	B-19	35306141	B-24	35363498	B-30
22334882	B-4	35278589	B-19	35307685	B-24		B-31
22338511	B-51			35314996	B-27	35365774	B-23
22338529	B-51						B-26
							B-39

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
35367739	B-46	36500197	B-5	36860005	B-43	36890515	B-2
35368216	B-48	36514602	B-53	36861383	B-50	36890523	B-2
35369347	B-15	36534659	B-7	36862829	B-27	36890531	B-47
.....	B-17		B-31	36865293	B-3	36890549	B-47
.....	B-23	36766756	B-13	36865756	B-45	36890556	B-2
.....	B-24		B-15	36870608	B-46	36890564	B-2
.....	B-34		B-17	36876423	B-29	36890572	B-2
.....	B-40		B-23	36876779	B-11	36890580	B-3
35369354	B-23		B-34		B-12	36890622	B-2
.....	B-24		B-40	36877223	B-6	36890648	B-43
.....	B-34	36766772	B-22	36877587	B-2	36890655	B-49
.....	B-40		B-35		B-4	36890663	B-2
35370386	B-34	36767051	B-30		B-42	36890671	B-2
35372457	B-46	36769032	B-7		B-49	36890689	B-49
35373976	B-13	36769289	B-15	36877793	B-21	36890697	B-49
.....	B-35		B-17		B-50	36890705	B-48
35374073	B-27	36769560	B-10	36878171	B-5	36890713	B-48
35376953	B-32	36772028	B-42	36878221	B-10	36890721	B-47
35377266	B-46	36775690	B-6	36879195	B-32	36890739	B-47
35377621	B-15	36781227	B-21	36879203	B-50	36890747	B-47
.....	B-17		B-34	36879492	B-27	36890762	B-47
.....	B-39		B-40		B-50	36890770	B-48
35379940	B-11	36782019	B-11	36880839	B-6	36890796	B-48
.....	B-12	36783488	B-43	36880995	B-15	36890812	B-47
35384577	B-30	36785277	B-20		B-17	36890838	B-47
35388883	B-29	36786218	B-49	36881076	B-20	36890895	B-32
35388891	B-29	36786382	B-10		B-36	36891042	B-26
35393669	B-28	36788172	B-11	36881563	B-6	36891067	B-25
35393677	B-28		B-12	36881696	B-7	36891083	B-21
35393719	B-28	36790277	B-29		B-31		B-36
35516582	B-43	36792083	B-44	36881712	B-50	36891109	B-32
35579630	B-21	36793602	B-3	36881886	B-9	36891141	B-8
.....	B-36	36794816	B-3		B-27	36891158	B-8
35585009	B-27		B-54	36884948	B-9	36891208	B-26
35588193	B-18	36796845	B-6	36885564	B-30	36891414	B-47
35588300	B-19	36797652	B-3	36888055	B-5	36891489	B-22
35588318	B-15		B-9	36889202	B-15	36891547	B-23
.....	B-17		B-50		B-17		B-37
35588532	B-15	36840437	B-23	36889350	B-31		B-41
.....	B-17		B-35	36889608	B-27	36891562	B-37
35591122	B-19		B-40	36889772	B-8	36891588	B-25
35592435	B-7	36842821	B-46	36889780	B-8	36891729	B-48
35596436	B-45	36842839	B-46	36889939	B-30	36891737	B-48
35604065	B-41	36843142	B-24	36889947	B-32	36891745	B-48
35604099	B-42		B-40	36890168	B-32	36891760	B-48
.....	B-44	36844264	B-43	36890200	B-30	36891810	B-3
35607829	B-42		B-44	36890317	B-21	36891968	B-31
35607837	B-42	36844520	B-24		B-36	36892156	B-30
35613041	B-10	36845493	B-30		B-40	36892164	B-30
35676169	B-44	36847838	B-46	36890457	B-2	36892172	B-25
35833227	B-19	36852622	B-46	36890465	B-2		B-30
35836949	B-18	36853257	B-43	36890473	B-8	36892206	B-50
35851377	B-6	36853265	B-43		B-48	36892461	B-5
36120649	B-45	36854149	B-23	36890481	B-9	36892479	B-25
36124881	B-44		B-36	36890499	B-3	36892669	B-24
36125409	B-45		B-40	36890507	B-3	36892677	B-49

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
36892685	B-43	54471057	B-15	95219697	B-13	95951646	B-13
36892776	B-51		B-17		B-39		B-31
36892834	B-52	54471651	B-5	95219861	B-20		B-38
36892883	B-52	54471669	B-7		B-35	95953378	B-20
36892891	B-52	54471685	B-15	95220844	B-25		B-34
36892909	B-52		B-17	95220851	B-25	95954194	B-23
36892917	B-52	54471826	B-27		B-30		B-37
36892925	B-51	54471834	B-28	95257325	B-26		B-40
36892933	B-52	54471842	B-28		B-37	95955993	B-21
36892941	B-52	54479811	B-28	95332599	B-26		B-39
36892982	B-49	54568753	B-54	95376943	B-15	95986014	B-13
36893055	B-45	54568761	B-53		B-17		B-38
36894160	B-33	54568779	B-53	95431292	B-22	95989695	B-13
36894210	B-3		B-55		B-35		B-38
36895472	B-33	54568787	B-53	95644019	B-10	95992632	B-10
36895746	B-3	54568795	B-54	95667341	B-37		B-36
	B-9	54593843	B-46		B-40	95992897	B-20
	B-49	54604962	B-55	95730172	B-26		B-35
36895977	B-33	54604970	B-54	95916268	B-20	95998001	B-13
36896785	B-4	54625207	B-55		B-35		B-38
36897353	B-31	54629902	B-53	95916532	B-30	96701461	B-7
	B-37	54629977	B-54	95923074	B-7	96701503	B-15
36897380	B-41	54716360	B-8	95923298	B-42		B-17
36897387	B-31	54747935	B-45	95923322	B-6	96701750	B-15
36897445	B-31	54749601	B-41	95928230	B-22		B-17
	B-37	54755087	B-15		B-35	96702048	B-15
36920486	B-42		B-17	95928982	B-24		B-17
36923928	B-20	54755111	B-15	95929782	B-6	96702055	B-9
	B-34		B-17	95930301	B-23		B-33
39317581	B-15	54764956	B-45		B-38	96702279	B-33
	B-17	54764964	B-36		B-40	96702287	B-18
39317599	B-15		B-45	95934998	B-6	96702659	B-11
	B-17	54766704	B-41		B-33		B-12
39404165	B-45		B-44	95935029	B-42	96702816	B-17
39831888	B-21	54774096	B-42	95935052	B-15	96704630	B-15
54368048	B-45		B-44		B-17		B-17
54390943	B-15	54774112	B-42	95935227	B-6	96708201	B-15
	B-17		B-44	95935599	B-36		B-17
54390950	B-15	552A10S073P	B-39		B-41	96720545	B-15
	B-17	90544772	B-15	95940748	B-24	96739693	B-13
54413042	B-15		B-17		B-40		B-38
	B-17	92086719	B-45	95944633	B-13	96739958	B-5
54414305	B-11	92304450	B-49		B-38		
	B-12	92368687	B-30	95944666	B-15		
54414420	B-9	93186278	B-13		B-20		
	B-11		B-38		B-23		
	B-35	93481455	B-15		B-37		
54414677	B-11		B-17	95944690	B-15		
	B-12	93481570	B-13		B-17		
54415393	B-28		B-38		B-35		
54425335	B-19	95022307	B-11	95944708	B-21		
54429295	B-5		B-12		B-36		
	B-7	95048914	B-20	95944906	B-13		
54436845	B-15		B-23		B-39		
	B-17	95052387	B-13				
			B-39				

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
----------	------	----------	------	----------	------	----------	------

WORD INDEX

A

Adapter
 Barbed 1/8" NPT B-15, B-17, B-39
 CF90 A/E B-15, B-17
 Engine Oil Fill B-32
 M26-1.5 X -12 JIC Swivel B-13, B-38
 Straight Tube 1/2-20 B-13, B-38
 Switch B-41
 Temp. Switch B-45
 Air End Air Cleaner Assembly B-27
 Aired B-15, B-17
 Aired Temp Sender B-46
 Alternator B-44
 Angle B-43
 Assy
 Oil Temp Bypass Valve B-11, B-12
 Automatic Ether Start B-46

B

Ball B-11, B-12
 Band
 Air Cleaner B-27
 Battery B-43
 Battery B-44
 Bearing
 Rod end B-7
 Body
 Air Cleaner B-28, B-29
 Bottle
 Coolant Recovery B-9
 Box
 Air Inlet Bed B-47
 Air Inlet Cab B-48
 Bracket
 A/E Mounting B-15, B-17
 A/e Support B-15, B-17
 Aired Air Cleaner B-27
 Drain Piping B-25
 Engine Air Filter Mounting B-27
 Engine Oil/Fuel B-2
 Front Engine B-5
 Isolator B-7
 Muffler B-6
 Oil Bypass B-9
 Oil Fill Support B-33
 Relay Mounting B-50
 Solenoid Valve B-24
 Bridge
 Cooler B-2
 Bulb
 Fuel Primer B-32
 Incandescent B-46
 Bulkhead
 Rear Bed B-47
 Rear Cab B-48
 Bumper
 Rubber B-3

Bushing

1/4 NPT X 3/4 NPT B-13, B-38
 Hex B-15, B-17
 Hex 1/4 NPT X 3/8 NPT B-40
 Nitrile B-30

C

Cable
 Negative Battery B-43
 Positive Battery B-43
 Cap
 Fuel B-30
 Hex Tube 1.06-12 B-26
 Hex Tube 3/4-16 B-26, B-37
 Plug B-28
 Radiator B-10
 Vinyl B-50
 Capnut
 Air Cleaner B-29
 Capscrew B-18
 Card
 Option Wiring B-54
 Standard Wiring B-54
 Channel
 Roof Connector B-47
 Clamp
 Hose B-8, B-27
 Hose B-10, B-25, B-32
 Hose B-30
 Muffler B-6
 Rubber Coated B-3, B-10
 Saddle B-6, B-20
 Spring B-15, B-17, B-39
 Support B-32
 Worm Gear B-25, B-32
 Wormgear B-30
 Clamp
 1/2" Support B-30, B-43
 11/16" Support B-43
 Clip B-27
 Retaining B-28
 Connector
 1-7/8-12 x -24 JIC B-13, B-39
 Bulkhead 1.06-12 B-26
 Female 1/4" Insulated B-24
 Female Swivel 7/16-20 B-13, B-38
 Fuel Filter B-33
 Male 1/4 NPT X 3/8" Tube B-17
 Male 1/4 NPT X -5 JIC B-13, B-39
 Male 1/4" Insulated B-24
 Male 1/4" NPT X 3/8" Tube B-15, B-23, B-24,
 B-34, B-40
 Straight 1.06-12 X -16 JIC B-36
 Straight 1.06-12 x -16 JIC B-8
 Tube 1-5/16 - 12 X 1-5/16 - 12 B-21, B-39
 Cooler
 Oil B-8

WORD INDEX

Corner
 Vert Curb BedB-3
 Vert Curb CabB-3
 Vert Street BedB-2
 Vert Street CabB-2
 CouplingB-15, B-17
 3/4 NPT X 1.56"B-13, B-38
 Female 1/8" NPT X 3/4"B-36, B-41
 Cover
 Air CleanerB-29
 Bypass Valve
 MachinedB-11, B-12
 Roof AccessB-50
 Cover AssemblyB-28
 Cylinder
 PneumaticB-7

D

Decal
 Battery GasB-54
 Central DrainsB-54
 Combination 3-partB-53
 Diesel FuelB-55
 High Pressure AirB-54
 Hot Press FluidB-53
 Improper OperationB-53
 Noise EmissionB-53
 Oil FillB-54
 Operating InstructionsB-54
 Radiator Fill HotB-55
 Rotating FanB-53, B-55
 WW Instrument PanelB-41
 DiaphragmB-18
 DiodeB-44
 Dipstick
 Remote MountB-32
 Door
 Instrument PanelB-41

E

Elbow
 45° 1.31 SAE X 1" TubingB-10, B-36
 90° 1.31-12 X -16 JICB-38
 90° 1.31-12 x -16 JICB-8
 90° 1/4" NPT X -4 JIC Swivel ..B-15, B-17, B-38
 90° 1-1/16-12 X -12 JIC .B-10, B-21, B-26, B-31,
 B-36, B-38
 90° 1-1/4" NPTB-20, B-34
 90° 1-7/8-12 X -24 JICB-22, B-35
 90° 3/4" NPT X -12 JICB-25
 90° Male 1/4" NPT x 3/8" Tube B-23, B-24, B-34,

B-40
 90° Male 1/8" NPT X 1/8" Tube B-23, B-37, B-41
 90° Male 1/8" NPT x 3/8" TubeB-34
 90° Swivel 1-5/8 -12 X -20 JICB-20, B-34
 90° Tube 1.25" NPT x -20 JICB-20, B-35
 90° Union -24 JIC x -24 JICB-13, B-39
 Rubber 180°B-27
 Street 90° 1/4" NPTB-15, B-20, B-23, B-37

Element

 Air CleanerB-29
 Compressor Oil FilterB-31, B-37
 Engine Fuel FilterB-7, B-31
 Engine Oil FilterB-31
 Engine Oil filterB-7
 OTBVB-12
 PrimaryB-28
 SafetyB-28
 SeparatorB-21
 ThermalB-11
 EngineB-5
 Engine Air Cleaner AssemblyB-27
 Engine Temp SenderB-46
 Eye
 Lift BeamB-48
 EyeboltB-42

F

 FanB-5
 Filter
 FuelB-30
 Fitting
 Lenz TubeB-21, B-36, B-40
 ScavengeB-21, B-36, B-40
 Flange
 Unloader InletB-15, B-17
 FoamB-4, B-48
 Closed CellB-30
 FrameB-2
 Door LowerB-2
 Door UpperB-2
 WW Instrument PanelB-41
 Front DoorB-2
 Front Louver Acoustical FoamB-4
 Front Louver AssemblyB-4
 Front Louver CrossmemberB-4
 Fuse
 20 AB-44

G

Gage Assembly
 Oil LevelB-21, B-36
 Gasket
 A/e DischargeB-15, B-17
 Engine Oil FillB-33
 Fuel SenderB-30
 UnloaderB-15, B-17
 Unloader InletB-15, B-17

WORD INDEX

GaugeB-41
 Fuel B-42, B-44
 Gauge ASM.
 4-IN-1B-42
 Gauge LightsB-46
 Generator
 4.5 KWB-46
 Grommet
 Radiator HoseB-10
 Guard
 FanB-8

H

Harness
 Air Filter Restr. OptionB-46
 Engine ControlB-45
 Gauge Illumination OptionB-46
 Manual Cold Start OptionB-46
 Head
 FilterB-31
 FilterB-37
 High A/E Temp Indicator LampB-46
 High Engine Temp Indicator LampB-46
 Hinge
 Control PanelB-41
 DoorB-3
 Hose
 .50 IDB-25
 5/16" FuelB-31
 Discharge B-22, B-35
 Drain ConnectorB-25
 Drain ConnectorB-30
 Engine Air IntakeB-27
 Engine Oil DrainB-25
 FuelB-30
 Oil FillB-32
 Radiator BottomB-8
 Radiator TopB-8
 Hose Assembly
 -12 JIC B-32, B-37
 -16 JIC B-22, B-34
 -8 JIC B-22, B-26, B-37
 Hose Assy
 -4 JICB-35
 HourmeterB-44
 Housing
 Oil Temp Bypass Valve B-11, B-12
 Housing BushingB-18

I

IsolatorB-5
 Rubber B-15, B-17

J

J-BoltB-43

K

Key
 CouplingB-15, B-17
 Knob
 StartB-41, B-45

L

Lanyard B-49
 Latch
 Front Door B-3
 Trigger B-49
 Latch Rear Door B-4
 Line
 90° Fuel B-31
 Low Oil Press Indicator LampB-44, B-46

M

Manual Ether Start B-46
 Member
 Lift Beam Front B-48
 Lift Beam Rear B-48
 Meter
 Electronic Hour B-41
 Module
 2-Light Warning B-42
 Muffler B-6
 Orifice .140 B-17
 Orifice 0.140 B-13, B-15, B-23, B-34, B-40

N

Nipple
 1/4" NPT X 7/8"B-20, B-23
 Close 1/4" NPT X 7/8"B-37, B-40
 Long 1.25 x 8"B-20, B-35
 Long 1.25 x 9"B-20, B-35
 Nozzle
 Sonic Orifice B-34
 Nozzle Sonic 0.453 B-20
 Nut
 Air Cleaner B-29
 Hex 1/4"-20 B-42
 Hex 5/16 - 18 B-6
 Hex Flange M08-1.25 B-9
 Hex Flange M10-1.50 B-32
 Hex Flange M12-1.75 B-50
 Hex Flange M8-1.25 B-27
 Hex Jam 5/16-24 B-7
 Hex Lock 3/8-16 B-6
 Hex Lock M06-1.0 B-7
 Hex M16-2.0 B-15, B-17
 Hex Nyloc M12-1.75 B-5
 Lock 1/4-20 B-43
 Nyloc M16-2.0 B-15, B-17
 Plastic #4-40 B-41
 Nutsert
 Hex M08B-9, B-49
 Hex M8 B-3

WORD INDEX

O

Oil Filter AssemblyB-31
 Oil Pressure SenderB-46
 Orifice
 FanB-8, B-48
 OilB-11, B-12
 Orifice 0.062B-22, B-35
 O-RINGB-45
 O-RingB-9, B-15, B-20, B-22
 O-ringB-11, B-12, B-17, B-19
 O-RingB-37

P

Pan
 Fuel TankB-3
 Panel
 AcousticB-52
 Acoustic Bed Cooler EndB-52
 Acoustic Bed Lwr EngB-51
 Acoustic BHD Bed SideB-52
 Acoustic BHD Cab engB-51
 Acoustic BHD Cab FltrB-52
 Acoustic BHD Ctr UpperB-52
 Acoustic Cab Air BoxB-51
 Acoustic Cab CoolerB-51
 Acoustic Cab Fltr EndB-51
 Acoustic Cab Lwr Eng.B-51
 Acoustic Cab Upper Eng.B-51
 Acoustic Center RoofB-52
 Acoustic CRB DoorB-51
 Acoustic End RoofB-52
 Acoustic Exhaust PlenumB-51
 Acoustic Fork Truck PltB-51
 Acoustic St. DoorB-51
 Cooler End BedB-48
 Cooler End CabB-49
 Filter End BedB-47
 Filter End CabB-48
 InstrumentB-41
 Lower Engine BedB-47
 Lower Engine CabB-49
 RoofB-47
 Roof CLR EndB-47
 Upper Engine BedB-47
 Upper Engine CabB-49
 Parts OrderingA-1
 Pin SpringB-19
 Pipe
 Exhaust TailB-6
 Piston BushingB-18
 Piston CoverB-18
 Piston GasketB-19
 Piston HousingB-19
 Piston SpringB-18
 Piston UnloaderB-18
 Piston WasherB-18

Plate

DischargeB-15, B-17
 Serial NumberB-54
 PlugB-4, B-19
 Hex 1 5/8-12 w/ O-RingB-21, B-36
 Hex 1/4" NPTB-22, B-35
 Hex 9/16-18B-37
 HoleB-10
 Pointer Assembly
 RotatingB-22
 Push Button SwitchB-46

R

RadiatorB-8
 Rear DoorB-2
 Rear Fork Tube CoverB-4
 Rear Louver Acoustical FoamB-4
 Rear Louver AssemblyB-4
 Rear Louver CrossmemberB-4
 ReducerB-10
 -12 JIC X -4 JICB-13, B-38
 Bushing 3/8 NPT X 1/4 NPTB-24
 Fuel LineB-33
 Hex 1/4" NPT X 1/8" NPTB-23, B-38, B-40
 Straight -16 JIC X -12 JICB-39
 Tube -12 JIC X -8 JICB-23, B-26, B-39
 Regulator
 PressureB-23, B-36, B-40
 Relay
 CrankB-45
 Fuel ShutdownB-45
 Fuel SolenoidB-45
 High Engine TempB-45
 Start InhibitB-45
 Start ProtectB-45
 Repair KitB-19
 RivetB-4, B-49
 .187 Dia.B-3
 AluminumB-42
 Rivets
 3/16" DIAB-2
 RivetB-54

WORD INDEX

S

Screw	B-18
Filister SLTD HD #10-32 X 1/2"	B-30
Hex 1/4-20 X 3/4"	B-24
Hex 5/16-18 x 1 1/4	B-6
Hex Cap M12-1.75 x 50	B-49
Hex Flange 1/2-13 X 1.0"	B-50
Hex Flange HD M12-1.75 X 30	B-5
Hex Flange M10-1.5 X 30	B-15, B-17
Hex Flange M12-1.75 X 25	B-27, B-50
Hex Flange M12-1.75 X 40	B-21, B-50
Hex Flange M8-1.25 X 16	B-27
Hex M06-1.0 x 25	B-7
Hex M08-1.25 X 16	B-15, B-17
Hex M08-1.25 X 20	B-9, B-33
Hex M08-1.25 x 25	B-11, B-12
Hex M10-1.5 x 20	B-33
Hex M10-1.50 x 20	B-32
Hex M12-1.75 X 70	B-5
Hex M16-2.0 X 90	B-15, B-17
Hex M8-1.25 X 40	B-50
Hex M8-1.25 X 70	B-10
Plastic Tapping	B-42
Socket Head M10-1.50 X 80	B-15, B-17
Socket Head M16-2.0 X 25	B-15, B-17
Socket Head M16-2.0 X 35	B-15
Socket Head M16-2.00 X 25	B-15, B-17
Socket Set 3/8-16 X 1/4	B-17
Socket Set 3/8-16 X 1/4"	B-15
Tapping 3/8-16 X 3/4"	B-43
Tapping M06-1.0 X 12	B-3, B-9, B-50
Tapping M06-1.0 X 14	B-30
Tapping M06-1.0 x 20	B-33
Tapping M08-1.25 X 20	B-3, B-5, B-9, B-15, B-17, B-22, B-25, B-27, B-30, B-33, B-43, B-49
Tapping M6-1.0 X 12	B-3
Seal	
Door Long	B-2
Door Short	B-3
Double Element	B-15, B-17
Single Element	B-15, B-17
U-Type	B-11, B-12
Sender	
Fuel Level	B-30
Fuel	B-44
S-Hook	B-50
Solenoid	
Ether	B-46
Fuel	B-45
Spacer	B-49
Fan	B-5
Spring	B-11, B-12, B-18, B-42
Standpipe Assembly	
Pickup	B-30
Return	B-30
Starter	B-45
Strap	
Ground	B-43

Stringer

Bed Side	B-47
Cab Side	B-47
Lift Beam	B-48

Stud

M16-2.0 X 55	B-15, B-17
--------------	------------

Support

Air Cylinder	B-6
--------------	-----

Switch

Air Filter Restriction	B-46
Alarm (A/E High Temp)	B-45
Alarm (Dischg High Temp)	B-45
Block Temp. Ether	B-46
Engine Oil Pressure	B-45
High Engine Temp	B-45
Ignition	B-41
Key	B-45
Low Fuel	B-44
Rocker	B-24
Shutdown w/ O-Ring	B-36

T

Tachometer	B-46
------------	------

Tank

Fuel	B-30
Separator	B-21

Tee

1/4" NPT	B-23, B-24, B-37, B-40
Male Branch 1/4 NPT x 3/8 Tube	B-13, B-35
Male Run -12 JIC	B-13, B-31, B-38
Street 1/2" NPT	B-21, B-36
Street 1/4" NPT	B-15, B-17, B-20, B-22, B-35, B-39, B-40
Tube Fitting -12 JIC	B-13, B-31, B-38

Tray

Battery	B-43
---------	------

Tube

A/E Discharge	B-13, B-39
A/E Injection Oil -12 JIC	B-13, B-31, B-37
Fuel Drain	B-26
Oil Cooler -16 JIC	B-8, B-34, B-36
Oil Fill	B-31
Radiator Drain	B-25
Rear Bearing Feed	B-13, B-38
Scavenge	B-21
Separator Tank/OTBV	B-22, B-34
Service	B-20

Tube Assembly

5/16"	B-13, B-38
-------	------------

Tube Assy

Oil Scavenge	B-34, B-40
Service Air	B-34

Tubing

1/8" Synflex	B-37
3/8" OD Synflex	B-24
5/16"	B-9
Synflex 3/8"	B-34, B-40

WORD INDEX

U

U-Bolt	B-6
Union	
-8 JIC Bulkhead	B-26, B-37
Barbed Tube	B-30
Tube Fitting -4 JIC X -5 JIC	B-13, B-39
Unloader Assembly	B-15, B-17
Unloader Body	B-19
Unloader Pin	B-19

V

Valve	
0.062 Inline Orifice/Check	B-23, B-35, B-40
Ball 1/4" NPT	B-20, B-34
Blowdown	B-22, B-35
Dust Ejector	B-28
Oil Temperature By-Pass	B-9, B-35
Safety	B-21, B-36
Solenoid	B-24, B-40
Vacuator	B-29
WYE	B-20, B-36
Valve Plate	B-19

W

Washer	B-18
Flat	B-6, B-15, B-17, B-33, B-42
Plastic	B-42, B-43
Snubber	B-5, B-15, B-17
Washer Flat	B-7
Wire	
Brown 14 AWG	B-24
Orange 14 AWG	B-24
Wrench	
Plate	B-26

Z

Panel	
Acoustic Bed Air Box	B-52
Acoustic Bed Fltr End	B-52
Acoustic Bed Upper Eng	B-52
Acoustic Oil Cooler Top	B-52



Ingersoll Rand Company
Utility Equipment
P.O. Box 868 - 501 Sanford Ave
Mocksville, N.C. 27028