


SERVICE TOOLS (CONT'D)	

[illegible]

CONNECTOR REPAIR KITS



[illegible]

Intentionally left blank

NUMERICAL INDEX

Part Number	Denomination	WAS	Page	Subgroup
			85	EXHAUST PIPING
18963496	NUT		127	ALTERNATOR
18963595	SCREW		119	FAN DRIVE
			131	FINAL FUEL FILTER
18963819	SCREW		141	OIL COOLER
18964932	WHEEL		143	SENSORS
18965079	HOUSING, FLYWHEEL		103	FLYWHEEL HOUSING
18969410	SCREW		109	FUEL INJECTION PUMP, CONTROLLER AND
			115	THERMOSTAT
			129	ALTERNATOR MOUNTING
18969428	SCREW		113	WATER PUMP
			121	BELT TENSIONER
22050393	COVER		3	RUNNING GEAR
22050553	LIGHT, WARNING MODULE		37	INSTRUMENT PANEL
22050991	GAUGE, FUEL		163	OPTION - FULL GAUGE PANEL
22051429	COLLAR		9	RUNNING GEAR
22051494	NUT		3	RUNNING GEAR
			5	RUNNING GEAR
			9	RUNNING GEAR
22051510	COVER		9	RUNNING GEAR
22051544	JOINT		3	RUNNING GEAR
			9	RUNNING GEAR
22051551	BUSH		9	RUNNING GEAR
22051577	NUT		3	RUNNING GEAR
			9	RUNNING GEAR
			13	RUNNING GEAR
22051585	RING		3	RUNNING GEAR
			9	RUNNING GEAR
22051833	LEVER, HANDBRAKE		5	RUNNING GEAR
22051841	CABLE		5	RUNNING GEAR
22051882	WASHER		5	RUNNING GEAR
			9	RUNNING GEAR
22054076	SWITCH, ROCKER		37	INSTRUMENT PANEL
22054159	NUT, HOURMETER		37	INSTRUMENT PANEL
			163	OPTION - FULL GAUGE PANEL
22054175	HOURLMETER		37	INSTRUMENT PANEL
			163	OPTION - FULL GAUGE PANEL
22055719	TUBE, SERVICE		63	HA SERVICE AIR
22055735	TUBE, BOTTOM SERVICE		63	HA SERVICE AIR
22055883	TACHOMETER		163	OPTION - FULL GAUGE PANEL
			165	OPTION - TACHOMETER PANEL
22058101	BRACKET, FRONT INTAKE		23	DOOR AND BAFFLE ENCLOSURE
22058325	COVER, REAR INSTRUMENT		37	INSTRUMENT PANEL
22058333	GUARD, TOOLBOX		19	FRAME
			171	OPTION - WHEEL CHOCKS
22058556	HOSE, STR-BELLOWS		83	COOLER PIPING
22060073	TUBE ASSEMBLY		65	SEPARATOR TANK PIPING

Part Number	Denomination	WAS	Page	Subgroup
			31	DECALS & DOCUMENTATION
22066823	LEVER, HANDBRAKE		13	RUNNING GEAR
22067714	CLAMP		169	OPTION - SPARK ARRESTOR
22068282	SCREW		29	DECALS & DOCUMENTATION
22068373	SEAL		23	DOOR AND BAFFLE ENCLOSURE
22070494	SCREW		37	INSTRUMENT PANEL
			163	OPTION - FULL GAUGE PANEL
22072318	BRACKET		161	OPTION - CENTRAL DRAINS
22073183	BRACKET		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
22073878	THERMISTOR SIMULATOR		187	SERVICE TOOLS
22074538	POD, LH REAR SIDE		159	OPTION - BRAKE LIGHTS WITH REVERSE LI
22084024	POD, RH REAR SIDE		159	OPTION - BRAKE LIGHTS WITH REVERSE LI
22094239	FOAM		25	FOAM INSULATION EXTERIOR
22094270	FOAM		25	FOAM INSULATION EXTERIOR
22094288	FOAM		25	FOAM INSULATION EXTERIOR
22094296	FOAM		25	FOAM INSULATION EXTERIOR
22094304	FOAM		25	FOAM INSULATION EXTERIOR
22094452	FOAM		25	FOAM INSULATION EXTERIOR
22095079	FOAM		25	FOAM INSULATION EXTERIOR
22095129	FOAM		25	FOAM INSULATION EXTERIOR
22096523	FOAM		27	FOAM INSULATION INTERIOR
22096531	FOAM		25	FOAM INSULATION EXTERIOR
22096598	FOAM		25	FOAM INSULATION EXTERIOR
22104806	WASHER		9	RUNNING GEAR
22107478	HINGE, SPRING CONTROL P		37	INSTRUMENT PANEL
22109011	PANEL, TOOLBOX SMALL		19	FRAME
22111686	RUNNING GEAR ASSEMBLY		17	DRAWBAR MOUNTING
22111694	RUNNING GEAR ASSEMBLY		17	DRAWBAR MOUNTING
22111975	ELEMENT, SEPARATOR		65	SEPARATOR TANK PIPING
			177	MAINTENANCE KIT
			179	MAINTENANCE KIT
22112478	BAFFLE, INTAKE		21	ROOF AND SIDE ENCLOSURE
22119150	BODY		93	AIR CLEANER ASSEMBLY
22119168	ELEMENT, AIR FILTER		93	AIR CLEANER ASSEMBLY
			173	MAINTENANCE KIT
			177	MAINTENANCE KIT
22119176	ELEMENT, AIR FILTER		93	AIR CLEANER ASSEMBLY
			173	MAINTENANCE KIT
			177	MAINTENANCE KIT
22119184	COVER ASSEMBLY		93	AIR CLEANER ASSEMBLY
22119192	FILTER ASSEMBLY		87	AIR INTAKE AND FILTER MOUNTING
22124093	GUARD, FAN		81	COOLER MOUNTING
22127385	SWITCH, START		37	INSTRUMENT PANEL
			163	OPTION - FULL GAUGE PANEL
22128490	HOLD DOWN, BATTERY		35	BATTERY AND MOUNTING
22134118	KNOB ASSEMBLY		37	INSTRUMENT PANEL
			163	OPTION - FULL GAUGE PANEL

Part Number	Denomination	WAS	Page	Subgroup
22137426	BULB, LIGHT		37	INSTRUMENT PANEL
22144513	CLAMP		83	COOLER PIPING
22146393	KIT, DEUTSCH TERMINAL R		187	SERVICE TOOLS
22147540	KIT, TEST ADAPTERS		187	SERVICE TOOLS
22153530	TUBE, ENGINE EXHAUST		85	EXHAUST PIPING
22164842	FOAM		25	FOAM INSULATION EXTERIOR
22164859	FOAM		25	FOAM INSULATION EXTERIOR
22164867	FOAM		27	FOAM INSULATION INTERIOR
22168868	PRESSURE TRANSDUCER S		187	SERVICE TOOLS
22171680	GAUGE HOLDER		37 163 165	INSTRUMENT PANEL OPTION - FULL GAUGE PANEL OPTION - TACHOMETER PANEL
22171698	DECAL		37 163 165	INSTRUMENT PANEL OPTION - FULL GAUGE PANEL OPTION - TACHOMETER PANEL
22172423	MODULE, 2-LIGHT WARNING		37 163	INSTRUMENT PANEL OPTION - FULL GAUGE PANEL
22173454	HARNESS, REAR BUMPER		41	BRAKE LIGHTS AND WIRING
22173579	MODULE, CONTROLLER		39	WEDGE CONTROLLER
22177588	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
22177620	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
22177687	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
22182075	JOCKEY WHEEL ASSEMBLY		17	DRAWBAR MOUNTING
22186605	POD, LH REAR SIDE		41	BRAKE LIGHTS AND WIRING
22186613	POD, RH REAR SIDE		41	BRAKE LIGHTS AND WIRING
22186811	POD, LH FRONT SIDE		41	BRAKE LIGHTS AND WIRING
22186829	POD, RH FRONT SIDE		41	BRAKE LIGHTS AND WIRING
22189302	CLAMP		83	COOLER PIPING
22189310	REDUCER		83	COOLER PIPING
22189591	TUBE, AIREND OIL		45	AIREND PIPING
22189609	TUBE, AIREND OIL		45	AIREND PIPING
22192132	BRACKET, SIDE PANEL		21	ROOF AND SIDE ENCLOSURE
22194674	PANEL		21	ROOF AND SIDE ENCLOSURE
22194682	PANEL		21	ROOF AND SIDE ENCLOSURE
22194690	PANEL, REAR		21	ROOF AND SIDE ENCLOSURE
22194708	RAIL, TOP SIDE		21	ROOF AND SIDE ENCLOSURE
22194716	PANEL, TOP		21	ROOF AND SIDE ENCLOSURE
22197776	BRACKET, WEDGE MOUNTI		39	WEDGE CONTROLLER
22198238	SUPPORT, FRONT		161	OPTION - CENTRAL DRAINS
22206148	ELEMENT, OIL FILTER		147 173 175 177 179	OIL FILTER MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT
22206213	STARTER		125	STARTER MOTOR

Part Number	Denomination	WAS	Page	Subgroup
22207013	PAN, FRONT BELLY		19	FRAME
22207021	PAN, REAR BELLY		19	FRAME
22207039	PAN, CENTER BELLY		19	FRAME
22207450	PANEL, FRONT		171	OPTION - WHEEL CHOCKS
22207815	HITCH, BALL		3 9	RUNNING GEAR RUNNING GEAR
22207823	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
22208334	ADAPTER		63	HA SERVICE AIR
22215354	DECAL, WEDGE		39	WEDGE CONTROLLER
22216667	DEUTSCH TERMINAL CRIMP		187	SERVICE TOOLS
22216683	PACKARD METRI- PACK TER		187	SERVICE TOOLS
22216691	DIGITAL MULTIMETER		187	SERVICE TOOLS
22216709	TEST LEAD SET, FLUKE		187	SERVICE TOOLS
22216725	WIRE INSULATION PIERCIN		187	SERVICE TOOLS
22216733	METER CASE, FLUKE		187	SERVICE TOOLS
22217848	MINIMUM PRESSURE VALVE		61 63	MINIMUM PRESSURE VALVE HA SERVICE AIR
22218424	BODY, MINIMUM PRESSURE		61	MINIMUM PRESSURE VALVE
22218432	CAP		61	MINIMUM PRESSURE VALVE
22218457	SPRING		61	MINIMUM PRESSURE VALVE
22218622	KIT, SERVICE MPV		61	MINIMUM PRESSURE VALVE
22218861	BRACKET		149 153	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
22218879	BRACKET		149 153	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
22221022	STRAP, FUEL TANK		95	FUEL TANK
22221030	STRAP, FUEL TANK		95	FUEL TANK
22222574	SENSOR		143	SENSORS
22222582	SENSOR, ENGINE SPEED		143	SENSORS
22222590	SENSOR, COOLANT TEMPE		143	SENSORS
22225361	ELBOW		155	OPTION - IQ FILTER AND MOUNTING
22227425	PANEL		21	ROOF AND SIDE ENCLOSURE
22227433	PANEL		21	ROOF AND SIDE ENCLOSURE
22241095	NIPPLE		3 9	RUNNING GEAR RUNNING GEAR
22241152	CABLE		13	RUNNING GEAR
22241160	PIN		5 13	RUNNING GEAR RUNNING GEAR
22241178	BOLT		9	RUNNING GEAR
22241194	WASHER		5	RUNNING GEAR
22241350	BOLT		3	RUNNING GEAR
22241368	SCREW		9	RUNNING GEAR
22241376	WASHER		5	RUNNING GEAR
22241400	NIPPLE		9	RUNNING GEAR
22241418	CABLE		13	RUNNING GEAR
22241426	CAP		3	RUNNING GEAR

Part Number	Denomination	WAS	Page	Subgroup
22241483	CLEVIS		13	RUNNING GEAR
22241491	WASHER		5	RUNNING GEAR
			13	RUNNING GEAR
22241533	SCREW		9	RUNNING GEAR
22247340	ELBOW, DISCHARGE		45	AIREND PIPING
22250179	GUARD, BELT		79	ENGINE MOUNTING
22250344	SHOE		5	RUNNING GEAR
			13	RUNNING GEAR
22250351	SHOE		5	RUNNING GEAR
			13	RUNNING GEAR
22250369	SPRING		5	RUNNING GEAR
22250377	SPRING		5	RUNNING GEAR
22250401	TUBE		9	RUNNING GEAR
22250419	WASHER		5	RUNNING GEAR
22250443	COVER		9	RUNNING GEAR
22250450	TUBE		3	RUNNING GEAR
22250492	BOLT		9	RUNNING GEAR
22250518	SLIDER		3	RUNNING GEAR
22250526	LINK, ADJUSTABLE		9	RUNNING GEAR
22250534	COUPLING ASSEMBLY		9	RUNNING GEAR
22250542	LEVER		9	RUNNING GEAR
22250559	DRAWBAR		9	RUNNING GEAR
22250567	CLAMP		9	RUNNING GEAR
22250575	COMPENSATOR		13	RUNNING GEAR
22250583	DRAWBAR		3	RUNNING GEAR
22250609	DRUM, BRAKE		5	RUNNING GEAR
			13	RUNNING GEAR
22250617	COVER		5	RUNNING GEAR
			13	RUNNING GEAR
22250625	CABLE		5	RUNNING GEAR
			13	RUNNING GEAR
22250658	KEY		5	RUNNING GEAR
			13	RUNNING GEAR
22250765	SPRING		13	RUNNING GEAR
22250781	COMPENSATOR		5	RUNNING GEAR
22250807	BOLT		5	RUNNING GEAR
22250823	BOLT		9	RUNNING GEAR
22250831	SPACER		5	RUNNING GEAR
			13	RUNNING GEAR
22250849	ROD		5	RUNNING GEAR
			13	RUNNING GEAR
22250856	WASHER		5	RUNNING GEAR
			13	RUNNING GEAR
22250864	HANDLE		9	RUNNING GEAR
22250872	EXPANDER		5	RUNNING GEAR
			13	RUNNING GEAR
22250880	CAP		5	RUNNING GEAR
			13	RUNNING GEAR

Part Number	Denomination	WAS	Page	Subgroup
22250906	SPRING		13	RUNNING GEAR
22250914	COVER		5 9	RUNNING GEAR RUNNING GEAR
22250922	EYE		5 13	RUNNING GEAR RUNNING GEAR
22250948	TAPER		5 13	RUNNING GEAR RUNNING GEAR
22250955	SCREW		5 13	RUNNING GEAR RUNNING GEAR
22250963	SPRING		5 13	RUNNING GEAR RUNNING GEAR
22250971	BEARING		5 13	RUNNING GEAR RUNNING GEAR
22250989	BEARING		5 13	RUNNING GEAR RUNNING GEAR
22250997	NUT		13	RUNNING GEAR
22251003	LOCKNUT		5	RUNNING GEAR
22251011	NUT		5	RUNNING GEAR
22251227	DAMPER		9	RUNNING GEAR
22251243	DAMPER		3	RUNNING GEAR
22251250	HANDLE		9	RUNNING GEAR
22251284	SLIDER		9	RUNNING GEAR
22251292	SPRING		5	RUNNING GEAR
22251300	CLAMP		3	RUNNING GEAR
22251318	LEVER ASSEMBLY		5	RUNNING GEAR
22251326	LINK		9	RUNNING GEAR
22251359	PIN		3	RUNNING GEAR
22251367	BUSH		3	RUNNING GEAR
22251375	NUT		13	RUNNING GEAR
22251409	BOLT		9	RUNNING GEAR
22251482	BOLT		3	RUNNING GEAR
22251483	CLEVIS		5	RUNNING GEAR
22251508	NUT		9	RUNNING GEAR
22251516	BOLT		3	RUNNING GEAR
22251524	PIN		5 13	RUNNING GEAR RUNNING GEAR
22251540	LOCKNUT		3	RUNNING GEAR
22251557	BOLT		9	RUNNING GEAR
22251573	CABLE		9 13	RUNNING GEAR RUNNING GEAR
22251599	PIN		9	RUNNING GEAR
22251896	HARNESS, WIRING		163 165	OPTION - FULL GAUGE PANEL OPTION - TACHOMETER PANEL
22251904	HARNESS, AIR FILTER REST		163	OPTION - FULL GAUGE PANEL
22252050	XHP 605 COMPRESSOR OIL		181	FLUIDS
22252076	XHP 605 COMPRESSOR OIL		181	FLUIDS
22252100	XHP 405 COMPRESSOR OIL		181	FLUIDS

Part Number	Denomination	WAS	Page	Subgroup
22252969	KIT, WIRE TERMINAL REPAI		191	CONNECTOR REPAIR KITS
22252993	KIT, WEDGE CONNECTOR R		191	CONNECTOR REPAIR KITS
22253017	KIT, ADHESIVE LINED HEAT		191	CONNECTOR REPAIR KITS
22254734	PACKARD WEATHER- PACK		187	SERVICE TOOLS
22254775	KIT, FUSES ASSORTMENT O		191	CONNECTOR REPAIR KITS
22255046	GAUGE, 4 IN 1		163	OPTION - FULL GAUGE PANEL
22255335	LAMINATE, TRAILER WIRING		29	DECALS & DOCUMENTATION
22255974	PACKARD METRI- PACK TER		187	SERVICE TOOLS
22259345	SPACER		17	DRAWBAR MOUNTING
22259352	SPACER		17	DRAWBAR MOUNTING
22260038	STRAP, FUEL TANK		95	FUEL TANK
22281588	WRENCH, T- HANDLE HEX		187	SERVICE TOOLS
22282107	SCREW DRIVER, HEX		187	SERVICE TOOLS
22282172	FLEX DRIVER		187	SERVICE TOOLS
22293138	FOAM		25	FOAM INSULATION EXTERIOR
22293484	HARNESS		155	OPTION - IQ FILTER AND MOUNTING
22299747	VALVE, SAFETY		65	SEPARATOR TANK PIPING
22299754	VALVE, SAFETY		65	SEPARATOR TANK PIPING
22299762	VALVE, SAFETY		65	SEPARATOR TANK PIPING
22331912	TANK, SEPARATOR		65	SEPARATOR TANK PIPING
22357693	PIN		5	RUNNING GEAR
			13	RUNNING GEAR
22409114	ELECTRICAL GREASE		187	SERVICE TOOLS
22413876	BATTERY		35	BATTERY AND MOUNTING
22429609	FOAM		25	FOAM INSULATION EXTERIOR
22429625	FOAM		27	FOAM INSULATION INTERIOR
22429658	FOAM		27	FOAM INSULATION INTERIOR
22429682	FOAM		25	FOAM INSULATION EXTERIOR
22429708	FOAM		25	FOAM INSULATION EXTERIOR
22429716	FOAM		25	FOAM INSULATION EXTERIOR
22429724	FOAM		27	FOAM INSULATION INTERIOR
22429732	FOAM		27	FOAM INSULATION INTERIOR
22429740	FOAM		27	FOAM INSULATION INTERIOR
22429757	FOAM		27	FOAM INSULATION INTERIOR
22429765	BAFFLE, SEPARATOR TANK		23	DOOR AND BAFFLE ENCLOSURE
22446079	MUFFLER		85	EXHAUST PIPING
22446744	CONNECTOR		63	HA SERVICE AIR
22473454	HARNESS, REAR BUMPER		159	OPTION - BRAKE LIGHTS WITH REVERSE LI
22477301	VALVE, BALL		63	HA SERVICE AIR
22481832	PLUG		63	HA SERVICE AIR
22530748	LAMINATE, WIRING DIAGRA		163	OPTION - FULL GAUGE PANEL
			165	OPTION - TACHOMETER PANEL
22530797	LAMINATE, AFRI WIRING DI		163	OPTION - FULL GAUGE PANEL
22573794	TUBE, EXHAUST		85	EXHAUST PIPING
22584791	WHEEL AND TYRE ASSEMB		13	RUNNING GEAR
			17	DRAWBAR MOUNTING

Part Number	Denomination	WAS	Page	Subgroup
22584809	WHEEL		13	RUNNING GEAR
22584817	TYRE		13	RUNNING GEAR
22655708	REDUCER		169	OPTION - SPARK ARRESTOR
22658934	SPARK ARRESTOR		169	OPTION - SPARK ARRESTOR
22685481	ELBOW		67	SEPARATOR TANK SIGHT GLASS AND OIL F
22685499	ELBOW		67	SEPARATOR TANK SIGHT GLASS AND OIL F
22685507	INSERT, TUBE		67	SEPARATOR TANK SIGHT GLASS AND OIL F
22685523	TUBE, SIGHT GAUGE		67	SEPARATOR TANK SIGHT GLASS AND OIL F
22692602	GAUGE, FUEL LEVEL		37	INSTRUMENT PANEL
22710719	PIPE, EXHAUST		85	EXHAUST PIPING
22712350	FAN		79	ENGINE MOUNTING
22715502	PANEL, EXHAUST GRILLE		167	OPTION - EXHAUST GRILLE
22746630	COVER, COOLER ACCESS		81	COOLER MOUNTING
22808786	SCREW		137	FUEL LINES
22835680	HARNESS, PANEL WIRING		37	INSTRUMENT PANEL
22869143	ELBOW		161	OPTION - CENTRAL DRAINS
22872667	RADIATOR		81	COOLER MOUNTING
22872675	COOLER, OIL		81	COOLER MOUNTING
22872683	COOLER, CHARGE AIR		81	COOLER MOUNTING
22884613	ENGINE		79	ENGINE MOUNTING
22888200	CHANNEL, MOUNTING CHAR		81	COOLER MOUNTING
22890941	BAFFLE, COOLER		81	COOLER MOUNTING
22890958	BAFFLE, COOLER		81	COOLER MOUNTING
22890966	BAFFLE, RADIATOR TOP		81	COOLER MOUNTING
22890974	SHROUD, FAN		81	COOLER MOUNTING
22891618	HOSE, TOP RADIATOR		83	COOLER PIPING
22891626	HOSE, BOTTOM RADIATOR		83	COOLER PIPING
22891675	HOSE, ENGINE AIR INTAKE		87 89	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
22892608	SUPPORT, AIR CLEANER		87 89	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
22893622	HOSE, A/E AIR INTAKE		87	AIR INTAKE AND FILTER MOUNTING
22899171	HOSE		97	ROCKER ARM COVER
22915276	SUPPORT, OIL FILTER		59	OTBV AND OIL FILTER MOUNTING
22929095	SUPPORT, RADIATOR		81	COOLER MOUNTING
22939482	HOSE, A/E AIR INTAKE		89	AIR INTAKE AND FILTER MOUNTING
22969257	ELEMENT, FUEL FILTER		131 173 175 177 179	FINAL FUEL FILTER MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT
22969265	ELEMENT, FUEL FILTER		133 173 175 177 179	PRIMARY FUEL FILTER MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT
23013022	TUBE, OIL COOLER		59 83	OTBV AND OIL FILTER MOUNTING COOLER PIPING

Part Number	Denomination	WAS	Page	Subgroup
23013030	TUBE, OIL COOLER		59 83	OTBV AND OIL FILTER MOUNTING COOLER PIPING
23017098	SHIM		109	FUEL INJECTION PUMP, CONTROLLER AND
23017189	SPACER		121	BELT TENSIONER
23017312	TUBE		115	THERMOSTAT
23017361	SCREW		123	EXHAUST MANIFOLD AND TURBOCHARGER
23017395	GASKET		123	EXHAUST MANIFOLD AND TURBOCHARGER
23017627	STUD		109	FUEL INJECTION PUMP, CONTROLLER AND
23018013	FITTING		137	FUEL LINES
23018492	RAIL		109	FUEL INJECTION PUMP, CONTROLLER AND
23018799	FILTER		131	FINAL FUEL FILTER
23019227	SEAL		115	THERMOSTAT
23019268	BRACKET		109	FUEL INJECTION PUMP, CONTROLLER AND
23019334	HOUSING, OIL COOLER		141	OIL COOLER
23019342	SEAL		115	THERMOSTAT
23019391	HOUSING, THERMOSTAT		115	THERMOSTAT
23019417	WASHER		137	FUEL LINES
23019458	SUPPORT, TENSIONER		121	BELT TENSIONER
23019482	MANIFOLD, EXHAUST		123	EXHAUST MANIFOLD AND TURBOCHARGER
23019490	O-RING		109	FUEL INJECTION PUMP, CONTROLLER AND
23019656	LINE, FUEL		137	FUEL LINES
23019714	LINE, FUEL		109	FUEL INJECTION PUMP, CONTROLLER AND
23019813	CAP		109	FUEL INJECTION PUMP, CONTROLLER AND
23019847	DEFLECTOR		97	ROCKER ARM COVER
23019854	TURBOCHARGER		123	EXHAUST MANIFOLD AND TURBOCHARGER
23019862	THERMOSTAT		115	THERMOSTAT
23019896	LINE		137	FUEL LINES
23019920	LINE, TURBO DRAIN		123	EXHAUST MANIFOLD AND TURBOCHARGER
23056930	TUBE, CHARGE AIR LOWER		83	COOLER PIPING
23056948	TUBE, CHARGE AIR UPPER		83	COOLER PIPING
23056955	TUBE, CHARGE AIR BOTTO		83	COOLER PIPING
23060288	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23077324	LAMINATE SET		29	DECALS & DOCUMENTATION
23094170	V-BELT		119	FAN DRIVE
23110497	SCREW		123	EXHAUST MANIFOLD AND TURBOCHARGER
23110539	SCREW		97 113	ROCKER ARM COVER WATER PUMP
23110661	SCREW		99 113	OIL FILLER NECK WATER PUMP
23110984	SCREW		113 141	WATER PUMP OIL COOLER
23116312	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23116320	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23116346	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23116353	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23116379	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION

Part Number	Denomination	WAS	Page	Subgroup
23116395	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23116403	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23116411	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23116429	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23127483	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23127509	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
23137821	HOUSING, OTBV		57	OIL TEMPERATURE BYPASS VALVE
23137953	VALVE, TEMPERATURE BYP		59	OTBV AND OIL FILTER MOUNTING
23145360	SUPPORT, WIRE		55	UNLOADER MOUNTING
23179310	DAMPER		9	RUNNING GEAR
23185994	ELEMENT, PRIMARY FILTER		155	OPTION - IQ FILTER AND MOUNTING
23186018	ELEMENT, SECONDARY FIL		155	OPTION - IQ FILTER AND MOUNTING
23186729	FILTER, WATER SEPARATO		149	OPTION - AFTERCOOLER AND WATER SEP
			155	OPTION - IQ FILTER AND MOUNTING
23186737	FILTER IQ, PRIMARY		155	OPTION - IQ FILTER AND MOUNTING
23186752	FILTER IQ, SECONDARY		155	OPTION - IQ FILTER AND MOUNTING
23187388	CLAMP KIT WITH O-RING		155	OPTION - IQ FILTER AND MOUNTING
23187420	CLAMP KIT		149	OPTION - AFTERCOOLER AND WATER SEP
			155	OPTION - IQ FILTER AND MOUNTING
23193667	FILTER, WATER SEPARATO		149	OPTION - AFTERCOOLER AND WATER SEP
			155	OPTION - IQ FILTER AND MOUNTING
23193675	FILTER IQ, PRIMARY		155	OPTION - IQ FILTER AND MOUNTING
23193683	FILTER IQ, SECONDARY		155	OPTION - IQ FILTER AND MOUNTING
23194210	BRACKET		149	OPTION - AFTERCOOLER AND WATER SEP
			155	OPTION - IQ FILTER AND MOUNTING
23194970	PLATE, GAUGE		155	OPTION - IQ FILTER AND MOUNTING
23209273	MANUAL, PARTS CATALOGU		31	DECALS & DOCUMENTATION
23212491	ELEMENT, PRIMARY FILTER		155	OPTION - IQ FILTER AND MOUNTING
23212509	ELEMENT, SECONDARY FIL		155	OPTION - IQ FILTER AND MOUNTING
23212863	LAMP, REVERSE		159	OPTION - BRAKE LIGHTS WITH REVERSE LI
23229511	ALTERNATOR		127	ALTERNATOR
23229529	NUT		109	FUEL INJECTION PUMP, CONTROLLER AND
23229560	O-RING		99	OIL FILLER NECK
23229602	O-RING		109	FUEL INJECTION PUMP, CONTROLLER AND
23229636	CLAMP		109	FUEL INJECTION PUMP, CONTROLLER AND
23229776	SCREW		123	EXHAUST MANIFOLD AND TURBOCHARGER
23229792	SEAL		109	FUEL INJECTION PUMP, CONTROLLER AND
23229834	BRACKET		109	FUEL INJECTION PUMP, CONTROLLER AND
23229859	HOSE		123	EXHAUST MANIFOLD AND TURBOCHARGER
23229867	WASHER, SEALING		109	FUEL INJECTION PUMP, CONTROLLER AND
23229909	CAP, OIL		99	OIL FILLER NECK
23229925	HOSE		137	FUEL LINES
23229933	PLUG		147	OIL FILTER
23229941	FITTING		137	FUEL LINES
23229958	RESTRICTOR		109	FUEL INJECTION PUMP, CONTROLLER AND
23229966	VALVE, PRESSURE RELIEF		109	FUEL INJECTION PUMP, CONTROLLER AND

Part Number	Denomination	WAS	Page	Subgroup
23229982	PUMP, FUEL		135	FUEL TRANSFER PUMP
23229990	SENSOR		133	PRIMARY FUEL FILTER
23230014	SENSOR		109	FUEL INJECTION PUMP, CONTROLLER AND
23230030	LINE, FUEL		137	FUEL LINES
23230048	FITTING		137	FUEL LINES
23230063	FUEL FILTER ASSEMBLY		95 133	FUEL TANK PRIMARY FUEL FILTER
23230071	SCREW		109	FUEL INJECTION PUMP, CONTROLLER AND
23230089	THERMOCOUPLE		143	SENSORS
23230097	FITTING		137	FUEL LINES
23230113	CONTROLLER, ENGINE		109	FUEL INJECTION PUMP, CONTROLLER AND
23230121	LINE, FUEL		109	FUEL INJECTION PUMP, CONTROLLER AND
23230139	LINE, FUEL		109	FUEL INJECTION PUMP, CONTROLLER AND
23230147	LINE, FUEL		109	FUEL INJECTION PUMP, CONTROLLER AND
23230154	LINE, FUEL		109	FUEL INJECTION PUMP, CONTROLLER AND
23230162	SCREW		109	FUEL INJECTION PUMP, CONTROLLER AND
23230170	SCREW		109	FUEL INJECTION PUMP, CONTROLLER AND
23230188	NECK, FILLER		99	OIL FILLER NECK
23230212	BRACKET		99	OIL FILLER NECK
23230238	LINE, FUEL		137	FUEL LINES
23230279	KIT, INJECTOR UNIT		109	FUEL INJECTION PUMP, CONTROLLER AND
23230295	PLUG		115	THERMOSTAT
23230329	CLAMP		109	FUEL INJECTION PUMP, CONTROLLER AND
23236912	SCREW		99	OIL FILLER NECK
23236920	SCREW		121	BELT TENSIONER
23236938	ISOLATOR		99	OIL FILLER NECK
23236946	HARNESS, FUEL FILTER WI		133	PRIMARY FUEL FILTER
23236979	SCREW		101	CRANKSHAFT PULLEY
23237225	PLATE, DATA		31	DECALS & DOCUMENTATION
23239429	PLATE, DATA		31	DECALS & DOCUMENTATION
23240310	GUARD, DOOR EDGE		81	COOLER MOUNTING
23242779	BRACKET		83	COOLER PIPING
23251754	GUARD, BELT		79	ENGINE MOUNTING
23254865	COVER, VALVE		97	ROCKER ARM COVER
23254881	PULLEY		97	ROCKER ARM COVER
23254899	SHIELD, HEAT		97	ROCKER ARM COVER
23254907	PULLEY, CRANKSHAFT		101	CRANKSHAFT PULLEY
23254915	BUSHING		101	CRANKSHAFT PULLEY
23254931	HARNESS, ENGINE FUEL WI		109	FUEL INJECTION PUMP, CONTROLLER AND
23254949	WASHER		109	FUEL INJECTION PUMP, CONTROLLER AND
23254956	SCREW		107	AIR INTAKE MANIFOLD
23254964	GASKET		117	OIL PAN
23254972	PAN, OIL		117	OIL PAN
23254980	COVER		115	THERMOSTAT
23254998	HARNESS, ENGINE WIRING		145	ENGINE WIRING HARNESS

Part Number	Denomination	WAS	Page	Subgroup
23264096	CAP		81	COOLER MOUNTING
23272420	AFTERCOOLER		149 153	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
23272774	ELBOW		155	OPTION - IQ FILTER AND MOUNTING
23292949	FOAM		27	FOAM INSULATION INTERIOR
23292956	FOAM		27	FOAM INSULATION INTERIOR
23292964	FOAM		27	FOAM INSULATION INTERIOR
23365067	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
24898801	NUT		99 109 137	OIL FILLER NECK FUEL INJECTION PUMP, CONTROLLER AND FUEL LINES
24898843	SCREW		119 125 129	FAN DRIVE STARTER MOTOR ALTERNATOR MOUNTING
24898876	SCREW		115 119	THERMOSTAT FAN DRIVE
24898884	SCREW		127	ALTERNATOR
24898918	SCREW		97	ROCKER ARM COVER
24898926	SCREW		109 127	FUEL INJECTION PUMP, CONTROLLER AND ALTERNATOR
24898934	SCREW		117	OIL PAN
24898959	SCREW		117	OIL PAN
24899056	PIN, SPRING		121	BELT TENSIONER
24899080	SCREW		137	FUEL LINES
24899106	O-RING		137	FUEL LINES
24899247	FITTING		137	FUEL LINES
24899254	O-RING		137	FUEL LINES
24899304	SEAL		147	OIL FILTER
24899338	CONNECTION, WATER PUM		113	WATER PUMP
24899452	BRACKET		131	FINAL FUEL FILTER
24899478	O-RING		103	FLYWHEEL HOUSING
24899528	FITTING		137	FUEL LINES
24899536	SCREW		135	FUEL TRANSFER PUMP
24899551	HEAD, FILTER		147	OIL FILTER
24899577	HARNESS		127	ALTERNATOR
24899601	PUMP, WATER		113	WATER PUMP
24899882	LINE, FUEL		137	FUEL LINES
24899932	KIT, O-RING		131 133	FINAL FUEL FILTER PRIMARY FUEL FILTER
35060631	VALVE ASSEMBLY, UNLOAD		55	UNLOADER MOUNTING
35103852	BUSHING, CLUTCH		43	AIREND MOUNTING
35104108	SCREW, HEX HEAD		51	AIREND REAR BEARING HSG.ASSEMBLY
35108372	SCREW, SOCKET HEAD		47	AIREND GEAR CASE
35114545	TEE		71 149 153	OIL/AIR PIPING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
35116615	CLAMP		87	AIR INTAKE AND FILTER MOUNTING

Part Number	Denomination	WAS	Page	Subgroup
			153	OPTION - AFTERCOOLER AND MOUNTING
			155	OPTION - IQ FILTER AND MOUNTING
35130707	HANDLE		21	ROOF AND SIDE ENCLOSURE
35134550	SCREW		35	BATTERY AND MOUNTING
35141423	HOSE ASSEMBLY		149	OPTION - AFTERCOOLER AND WATER SEP
			153	OPTION - AFTERCOOLER AND MOUNTING
			155	OPTION - IQ FILTER AND MOUNTING
35145408	CLAMP, SUPPORT		83	COOLER PIPING
35161025	CLAMP		89	AIR INTAKE AND FILTER MOUNTING
35190487	BRACKET, TUBE CLAMP		83	COOLER PIPING
35210087	GASKET		47	AIREND GEAR CASE
35221639	CLIP, RETAINING		83	COOLER PIPING
35225077	CLAMP		161	OPTION - CENTRAL DRAINS
35225085	CLAMP		161	OPTION - CENTRAL DRAINS
35225093	CLIP, RETAINING		35	BATTERY AND MOUNTING
35227909	TUBE ASSEMBLY		59	OTBV AND OIL FILTER MOUNTING
			65	SEPARATOR TANK PIPING
			77	OIL/AIR PIPING
35231455	HOSE ASSEMBLY		59	OTBV AND OIL FILTER MOUNTING
35248145	VALVE, CHECK		73	OIL/AIR PIPING
35252493	SCREW		59	OTBV AND OIL FILTER MOUNTING
35253038	CLAMP		83	COOLER PIPING
35255827	PLATE, CLAMP		47	AIREND GEAR CASE
35256122	HOSE ASSEMBLY		149	OPTION - AFTERCOOLER AND WATER SEP
			153	OPTION - AFTERCOOLER AND MOUNTING
35256429	STUD		23	DOOR AND BAFFLE ENCLOSURE
35256445	WASHER, RETAINING		23	DOOR AND BAFFLE ENCLOSURE
35256452	RECEPTACLE		23	DOOR AND BAFFLE ENCLOSURE
35258789	CABLE		35	BATTERY AND MOUNTING
35262690	PLATE, CLAMP		51	AIREND REAR BEARING HSG.ASSEMBLY
35262716	SPACER		47	AIREND GEAR CASE
35269224	SPACER, BEARING		47	AIREND GEAR CASE
35270131	SPACER, BEARING		49	AIREND ROTOR HOUSING
35271162	SCREW		53	UNLOADER ASSEMBLY
35273366	NUT		95	FUEL TANK
35274711	MOUNTING, BAND		87	AIR INTAKE AND FILTER MOUNTING
35278555	PLUG, ADAPTER		45	AIREND PIPING
35278571	O-RING		45	AIREND PIPING
			163	OPTION - FULL GAUGE PANEL
35278589	O-RING		45	AIREND PIPING
35279025	SCREW		19	FRAME
			21	ROOF AND SIDE ENCLOSURE
			41	BRAKE LIGHTS AND WIRING
			59	OTBV AND OIL FILTER MOUNTING
			63	HA SERVICE AIR
			81	COOLER MOUNTING
			85	EXHAUST PIPING
			87	AIR INTAKE AND FILTER MOUNTING
			89	AIR INTAKE AND FILTER MOUNTING

Part Number	Denomination	WAS	Page	Subgroup
			149	OPTION - AFTERCOOLER AND WATER SEP
			153	OPTION - AFTERCOOLER AND MOUNTING
			155	OPTION - IQ FILTER AND MOUNTING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
			171	OPTION - WHEEL CHOCKS
35279827	ELBOW		45	AIREND PIPING
35279843	TEE		45	AIREND PIPING
35279876	ELBOW		45	AIREND PIPING
35279942	O-RING		67	SEPARATOR TANK SIGHT GLASS AND OIL F
35279959	O-RING		45	AIREND PIPING
35282292	TUBING, TYGON		55	UNLOADER MOUNTING
35282920	HOSE ASSEMBLY		59	OTBV AND OIL FILTER MOUNTING
			75	OIL/AIR PIPING
35283134	CONNECTOR		161	OPTION - CENTRAL DRAINS
35283464	ADAPTOR		155	OPTION - IQ FILTER AND MOUNTING
35285162	GROMMET		83	COOLER PIPING
35286491	ELBOW		45	AIREND PIPING
35287747	CONNECTOR, BULKHEAD		161	OPTION - CENTRAL DRAINS
35287895	CONNECTOR		161	OPTION - CENTRAL DRAINS
35287945	BUSH, REDUCING		45	AIREND PIPING
35288422	SCREW		59	OTBV AND OIL FILTER MOUNTING
35290113	SCREW		19	FRAME
			43	AIREND MOUNTING
35290378	HOSE ASSEMBLY		161	OPTION - CENTRAL DRAINS
35292051	ELBOW		77	OIL/AIR PIPING
35292143	CLAMP		65	SEPARATOR TANK PIPING
			75	OIL/AIR PIPING
35293687	CONNECTOR, ORIFICE		149	OPTION - AFTERCOOLER AND WATER SEP
			153	OPTION - AFTERCOOLER AND MOUNTING
35294750	ELBOW		161	OPTION - CENTRAL DRAINS
35296342	CLIP, RETAINING		83	COOLER PIPING
			95	FUEL TANK
35302314	ADAPTOR		73	OIL/AIR PIPING
35303429	GEAR SET		47	AIREND GEAR CASE
35305499	HOSE ASSEMBLY		161	OPTION - CENTRAL DRAINS
35305622	ELBOW		45	AIREND PIPING
35306661	HOSE ASSEMBLY		155	OPTION - IQ FILTER AND MOUNTING
35313303	CLAMP		85	EXHAUST PIPING
35313535	BEARING, CYLINDRICAL RO		49	AIREND ROTOR HOUSING
35313568	BEARING		47	AIREND GEAR CASE
35313600	SHIM, .002		51	AIREND REAR BEARING HSG.ASSEMBLY
35313618	SHIM, .003		51	AIREND REAR BEARING HSG.ASSEMBLY
35314939	INDICATOR, AIR RESTRICTI		87	AIR INTAKE AND FILTER MOUNTING
			89	AIR INTAKE AND FILTER MOUNTING
35316587	ADAPTOR, BARBED		55	UNLOADER MOUNTING
35317197	DIAPHRAGM		53	UNLOADER ASSEMBLY
35317205	WASHER, PISTON		53	UNLOADER ASSEMBLY
35317239	WASHER, PISTON		53	UNLOADER ASSEMBLY

Part Number	Denomination	WAS	Page	Subgroup
35318005	BUSHING, PISTON		53	UNLOADER ASSEMBLY
35318013	BUSHING, HOUSING		53	UNLOADER ASSEMBLY
35318229	MOUNT		43	AIREND MOUNTING
35321595	SCREW		53	UNLOADER ASSEMBLY
35321603	SPRING		53	UNLOADER ASSEMBLY
35322346	CONNECTOR, ORIFICE		73	OIL/AIR PIPING
35322379	VALVE, BLOWDOWN		73 149 153	OIL/AIR PIPING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
35322395	SILENCER, PNEUMATIC		95	FUEL TANK
35322767	SPRING, PISTON		53	UNLOADER ASSEMBLY
35323450	STUD		55	UNLOADER MOUNTING
35323542	ADAPTER, UNLOADER		55	UNLOADER MOUNTING
35323799	HOSE ASSEMBLY		161	OPTION - CENTRAL DRAINS
35327212	WASHER		43 79	AIREND MOUNTING ENGINE MOUNTING
35332915	PIN, LOCATOR		49	AIREND ROTOR HOUSING
35335124	CONNECTOR		63	HA SERVICE AIR
35336304	SCREW, SOCKET HEAD CAP		47	AIREND GEAR CASE
35337328	STUD, BALL		23	DOOR AND BAFFLE ENCLOSURE
35354448	SHIM SET		51	AIREND REAR BEARING HSG.ASSEMBLY
35356484	TUBE, NYLON		69 71 73 95 149 153 155	OIL/AIR PIPING OIL/AIR PIPING OIL/AIR PIPING FUEL TANK OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING OPTION - IQ FILTER AND MOUNTING
35360775	TUBING		83	COOLER PIPING
35361328	KEY		47	AIREND GEAR CASE
35361849	GASKET		95	FUEL TANK
35363498	HOSE		95	FUEL TANK
35364306	LUBRICATOR, AIR LINE		185	AIR HOSE FITTINGS
35364314	LUBRICATOR, AIR LINE		185	AIR HOSE FITTINGS
35364322	LUBRICATOR, AIR LINE		185	AIR HOSE FITTINGS
35364769	SHIM, .010		51	AIREND REAR BEARING HSG.ASSEMBLY
35364975	KEY		43	AIREND MOUNTING
35365477	CLAMP		87	AIR INTAKE AND FILTER MOUNTING
35365774	ADAPTOR		161	OPTION - CENTRAL DRAINS
35367218	SENDER, TEMPERATURE		163	OPTION - FULL GAUGE PANEL
35367317	CV ASSEMBLY		61	MINIMUM PRESSURE VALVE
35367325	PISTON		61	MINIMUM PRESSURE VALVE
35367366	SPRING		61	MINIMUM PRESSURE VALVE
35367374	O-RING		61	MINIMUM PRESSURE VALVE
35369313	STEP, FOLDING		21	ROOF AND SIDE ENCLOSURE
35369339	CONNECTOR		95	FUEL TANK
35369347	CONNECTOR		71	OIL/AIR PIPING

Part Number	Denomination	WAS	Page	Subgroup
			149	OPTION - AFTERCOOLER AND WATER SEP
			153	OPTION - AFTERCOOLER AND MOUNTING
			155	OPTION - IQ FILTER AND MOUNTING
35369354	CONNECTOR		71	OIL/AIR PIPING
			73	OIL/AIR PIPING
35369396	TEE		155	OPTION - IQ FILTER AND MOUNTING
35369503	TEE		69	OIL/AIR PIPING
			155	OPTION - IQ FILTER AND MOUNTING
35370386	ELBOW		37	INSTRUMENT PANEL
			149	OPTION - AFTERCOOLER AND WATER SEP
			155	OPTION - IQ FILTER AND MOUNTING
			163	OPTION - FULL GAUGE PANEL
35371103	LUBRICATOR, AIR LINE		185	AIR HOSE FITTINGS
35371111	LUBRICATOR, AIR LINE		185	AIR HOSE FITTINGS
35371129	LUBRICATOR, AIR LINE		185	AIR HOSE FITTINGS
35372457	SENDER, TEMPERATURE		163	OPTION - FULL GAUGE PANEL
35373976	TEE		71	OIL/AIR PIPING
			73	OIL/AIR PIPING
35374073	CLAMP		87	AIR INTAKE AND FILTER MOUNTING
			89	AIR INTAKE AND FILTER MOUNTING
35375385	SCREW		45	AIREND PIPING
35375591	SCREW		17	DRAWBAR MOUNTING
			43	AIREND MOUNTING
35376110	HOSE ASSEMBLY		161	OPTION - CENTRAL DRAINS
35377621	CLAMP, SPRING		55	UNLOADER MOUNTING
35379064	KIT, REPAIR		73	OIL/AIR PIPING
35379700	CONNECTOR		155	OPTION - IQ FILTER AND MOUNTING
35384577	BUSHING		95	FUEL TANK
35393677	VALVE, DUST EJECTOR		91	AIR CLEANER ASSEMBLY
35393719	CAP, PLUG		91	AIR CLEANER ASSEMBLY
35393990	HOSE		183	AIR DELIVERY HOSE
35504364	CAP, RAIN		85	EXHAUST PIPING
35518497	GASKET, FRONT BEARING H		49	AIREND ROTOR HOUSING
35573070	PLATE, RETAINING		47	AIREND GEAR CASE
35575570	GASKET, AIREND DISCHAR		45	AIREND PIPING
35579630	PLUG		67	SEPARATOR TANK SIGHT GLASS AND OIL F
35581792	VALVE, BALL		63	HA SERVICE AIR
35583582	CABLE		35	BATTERY AND MOUNTING
35588193	PISTON, UNLOADER		53	UNLOADER ASSEMBLY
35588300	GASKET, PISTON		53	UNLOADER ASSEMBLY
35588318	GASKET, UNLOADER INLET		55	UNLOADER MOUNTING
35589589	GASKET, UNLOADER TO AIR		55	UNLOADER MOUNTING
35591122	VALVE, UNLOADER		53	UNLOADER ASSEMBLY
35592757	COVER, OIL SEAL		47	AIREND GEAR CASE
35593508	SEAL, OIL		47	AIREND GEAR CASE
35600261	SPRING		23	DOOR AND BAFFLE ENCLOSURE
35601517	BEARING, BALL		47	AIREND GEAR CASE
35607829	BOLT, EYE		23	DOOR AND BAFFLE ENCLOSURE

Part Number	Denomination	WAS	Page	Subgroup
35607837	SPRING		23	DOOR AND BAFFLE ENCLOSURE
35609361	BEARING, CYLINDRICAL RO		49	AIREND ROTOR HOUSING
35610856	CABLE, NEGATIVE		35	BATTERY AND MOUNTING
35833227	HOUSING, PISTON		53	UNLOADER ASSEMBLY
35834787	COUPLING, CLUTCH		43	AIREND MOUNTING
35843168	FLANGE, UNLOADER INLET		55	UNLOADER MOUNTING
35857036	CAP, RAIN		169	OPTION - SPARK ARRESTOR
35996164	CASE, GEAR		47	AIREND GEAR CASE
36008241	ROTOR SET		49	AIREND ROTOR HOUSING
36010643	AIREND ASSEMBLY		45	AIREND PIPING
36011534	AIREND ASSEMBLY		45	AIREND PIPING
36011567	VALVE ASSEMBLY, UNLOAD		53	UNLOADER ASSEMBLY
36018042	AIREND ASSEMBLY		45	AIREND PIPING
36100154	NUT		107	AIR INTAKE MANIFOLD
36100188	NUT		113	WATER PUMP
			123	EXHAUST MANIFOLD AND TURBOCHARGER
			127	ALTERNATOR
			129	ALTERNATOR MOUNTING
36101962	PLUG		137	FUEL LINES
36102838	RING, SNAP		119	FAN DRIVE
36102929	PLUG		97	ROCKER ARM COVER
36103182	ADAPTOR		123	EXHAUST MANIFOLD AND TURBOCHARGER
36103232	BUSHING		129	ALTERNATOR MOUNTING
36103828	SLEEVE		119	FAN DRIVE
36104602	COVER		99	OIL FILLER NECK
36105062	ELBOW		97	ROCKER ARM COVER
36105245	PULLEY		113	WATER PUMP
36105252	PLATE		103	FLYWHEEL HOUSING
36106060	SEAL		113	WATER PUMP
			115	THERMOSTAT
36106102	O-RING		135	FUEL TRANSFER PUMP
36106177	CLAMP		115	THERMOSTAT
36106250	GASKET		113	WATER PUMP
36106607	GASKET		141	OIL COOLER
36106615	GASKET		141	OIL COOLER
36106748	GASKET		123	EXHAUST MANIFOLD AND TURBOCHARGER
36106755	GASKET		123	EXHAUST MANIFOLD AND TURBOCHARGER
36106763	NUT		97	ROCKER ARM COVER
36106771	O-RING		97	ROCKER ARM COVER
36106821	NUT		137	FUEL LINES
36107480	PULLEY, FAN		119	FAN DRIVE
36107787	TUBE, DIPSTICK		139	DIPSTICK
36108009	PLUG		103	FLYWHEEL HOUSING
36108066	STRAP		129	ALTERNATOR MOUNTING
36108074	STRAP		129	ALTERNATOR MOUNTING
36108371	PIN		135	FUEL TRANSFER PUMP

Part Number	Denomination	WAS	Page	Subgroup
36108595	GASKET		99	OIL FILLER NECK
36108819	GEAR, RING		105	FLYWHEEL
36108918	FITTING		103	FLYWHEEL HOUSING
36109932	O-RING		117	OIL PAN
36110054	O-RING		123	EXHAUST MANIFOLD AND TURBOCHARGER
36110112	WASHER		127	ALTERNATOR
36110385	O-RING		97	ROCKER ARM COVER
36111425	O-RING		113	WATER PUMP
36111912	TEE, FITTING		137	FUEL LINES
36114015	SEAL		103	FLYWHEEL HOUSING
36114072	PLUG		107 115	AIR INTAKE MANIFOLD THERMOSTAT
36114080	PLUG		113 141	WATER PUMP OIL COOLER
36114098	PLUG		115 137 141	THERMOSTAT FUEL LINES OIL COOLER
36114106	PLUG, DRAIN		113 117	WATER PUMP OIL PAN
36114445	KIT, SEAL		131 133	FINAL FUEL FILTER PRIMARY FUEL FILTER
36114486	PULLEY, IDLE		119	FAN DRIVE
36114536	KIT, SEAL		131 133	FINAL FUEL FILTER PRIMARY FUEL FILTER
36114544	BOWL, SEDIMENT		133	PRIMARY FUEL FILTER
36115251	COOLER, OIL		141	OIL COOLER
36116036	SEAL		113	WATER PUMP
36116242	ADAPTER		137	FUEL LINES
36116648	KIT, VALVE		131	FINAL FUEL FILTER
36117885	CLAMP		123	EXHAUST MANIFOLD AND TURBOCHARGER
36118131	SCREW		141	OIL COOLER
36118149	SCREW		99 141	OIL FILLER NECK OIL COOLER
36118693	O-RING		141	OIL COOLER
36118750	CLAMP		137	FUEL LINES
36119808	O-RING		123 137	EXHAUST MANIFOLD AND TURBOCHARGER FUEL LINES
36124899	DIPSTICK		139	DIPSTICK
36125276	GASKET		107	AIR INTAKE MANIFOLD
36126019	O-RING		115 137 141	THERMOSTAT FUEL LINES OIL COOLER
36128916	O-RING		107 115 137 143	AIR INTAKE MANIFOLD THERMOSTAT FUEL LINES SENSORS
36133403	O-RING		113 141	WATER PUMP OIL COOLER
36136125	KIT, INSERT		113	WATER PUMP

Part Number	Denomination	WAS	Page	Subgroup
36137461	MANIFOLD, AIR INTAKE		107	AIR INTAKE MANIFOLD
36137586	BRACKET		137	FUEL LINES
36138006	PUMP		109	FUEL INJECTION PUMP, CONTROLLER AND
36500832	COVER, REAR BEARING		51	AIREND REAR BEARING HSG.ASSEMBLY
36751659	GEAR SET		47	AIREND GEAR CASE
36751667	GEAR SET		47	AIREND GEAR CASE
36763670	SCREW		161	OPTION - CENTRAL DRAINS
36764785	CAP, GUIDE		47	AIREND GEAR CASE
36766756	ORIFICE, SILENCER		73 149 153	OIL/AIR PIPING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
36769404	HOUSING, REAR BEARING		51	AIREND REAR BEARING HSG.ASSEMBLY
36772028	WASHER		23	DOOR AND BAFFLE ENCLOSURE
36777399	VALVE, BALL		161	OPTION - CENTRAL DRAINS
36780608	SENDER, OIL PRESSURE		163	OPTION - FULL GAUGE PANEL
36780906	SHAFT, DRIVE		47	AIREND GEAR CASE
36782019	ELEMENT, THERMOSTATIC		57	OIL TEMPERATURE BYPASS VALVE
36783488	STRAP, GROUND		35	BATTERY AND MOUNTING
36785012	BRACKET		65	SEPARATOR TANK PIPING
36786127	ELBOW		149 153	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
36788172	SEAL		57	OIL TEMPERATURE BYPASS VALVE
36788982	BINDER, 3-RING		29	DECALS & DOCUMENTATION
36793602	LATCH		23	DOOR AND BAFFLE ENCLOSURE
36794816	RIVET		23	DOOR AND BAFFLE ENCLOSURE
36795482	TUBE ASSEMBLY		45	AIREND PIPING
36797652	SCREW		19 21 23 81 83 87 89 155 167	FRAME ROOF AND SIDE ENCLOSURE DOOR AND BAFFLE ENCLOSURE COOLER MOUNTING COOLER PIPING AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING OPTION - IQ FILTER AND MOUNTING OPTION - EXHAUST GRILLE
36798205	GUARD, GEAR CASE		47	AIREND GEAR CASE
36840411	VALVE, CHECK		75	OIL/AIR PIPING
36840841	VALVE, SOLENOID		71 73	OIL/AIR PIPING OIL/AIR PIPING
36842102	SCREW		39	WEDGE CONTROLLER
36845154	MANIFOLD, OIL		45 77	AIREND PIPING OIL/AIR PIPING
36845600	TANK, HEADER		83	COOLER PIPING
36846087	TUBE, BEARING OIL SUPPL		45	AIREND PIPING
36846095	CONNECTOR, O-RING		45	AIREND PIPING
36846103	TUBE, BEARING OIL SCAVE		45	AIREND PIPING
36846111	TUBE ASSEMBLY		45	AIREND PIPING
36846129	TEE		45	AIREND PIPING

Part Number	Denomination	WAS	Page	Subgroup
36849453	BODY, UNLOADER		53	UNLOADER ASSEMBLY
36849461	COVER, PISTON		53	UNLOADER ASSEMBLY
36853265	WASHER		35	BATTERY AND MOUNTING
36853521	RELAY, STARTER / AIR PRE		87 89	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
36860005	J-BOLT		35	BATTERY AND MOUNTING
36867778	VALVE		93	AIR CLEANER ASSEMBLY
36876779	COVER, OTBV		57	OIL TEMPERATURE BYPASS VALVE
36877587	RIVET		37	INSTRUMENT PANEL
36877793	SCREW		63	HA SERVICE AIR
36878064	TRAY, BATTERY		35	BATTERY AND MOUNTING
36879195	NUT		87 149 153	AIR INTAKE AND FILTER MOUNTING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
36879302	SCREW		161	OPTION - CENTRAL DRAINS
36879492	SCREW		19 79 81	FRAME ENGINE MOUNTING COOLER MOUNTING
36880623	COVER, FLEXABLE ACCESS		19	FRAME
36880995	SCREW		45	AIREND PIPING
36881886	NUT		21 23 39 59 81 83 95 149 155 161	ROOF AND SIDE ENCLOSURE DOOR AND BAFFLE ENCLOSURE WEDGE CONTROLLER OTBV AND OIL FILTER MOUNTING COOLER MOUNTING COOLER PIPING FUEL TANK OPTION - AFTERCOOLER AND WATER SEP OPTION - IQ FILTER AND MOUNTING OPTION - CENTRAL DRAINS
36882355	SUPPORT, REAR		161	OPTION - CENTRAL DRAINS
36885093	ELBOW		161	OPTION - CENTRAL DRAINS
36888055	SCREW		19 65 161	FRAME SEPARATOR TANK PIPING OPTION - CENTRAL DRAINS
36889608	SCREW		39 81 95 149 153 155 161	WEDGE CONTROLLER COOLER MOUNTING FUEL TANK OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING OPTION - IQ FILTER AND MOUNTING OPTION - CENTRAL DRAINS
36891216	GAUGE, PRESSURE		37 155 163	INSTRUMENT PANEL OPTION - IQ FILTER AND MOUNTING OPTION - FULL GAUGE PANEL
36892669	BRACKET, SOLENOID		69	OIL/AIR PIPING
36895746	NUTSERT		21 79 81 149 153	ROOF AND SIDE ENCLOSURE ENGINE MOUNTING COOLER MOUNTING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
36896892	REGULATOR		71	OIL/AIR PIPING

Part Number	Denomination	WAS	Page	Subgroup
			77	OIL/AIR PIPING
			173	MAINTENANCE KIT
			175	MAINTENANCE KIT
			177	MAINTENANCE KIT
			179	MAINTENANCE KIT
36897437	HEAD		59	OTBV AND OIL FILTER MOUNTING
			77	OIL/AIR PIPING
36897668	CLAMP		87	AIR INTAKE AND FILTER MOUNTING
			89	AIR INTAKE AND FILTER MOUNTING
36898922	SENSOR, TEMPERATURE		45	AIREND PIPING
			65	SEPARATOR TANK PIPING
36899615	INDICATOR		155	OPTION - IQ FILTER AND MOUNTING
36920114	WASHER		127	ALTERNATOR
36920221	VALVE, CHECK		149	OPTION - AFTERCOOLER AND WATER SEP
			153	OPTION - AFTERCOOLER AND MOUNTING
36920486	RIVET		37	INSTRUMENT PANEL
36920825	TRANSDUCER, PRESSURE		71	OIL/AIR PIPING
36922987	VALVE		149	OPTION - AFTERCOOLER AND WATER SEP
			153	OPTION - AFTERCOOLER AND MOUNTING
39127287	TEE		155	OPTION - IQ FILTER AND MOUNTING
			163	OPTION - FULL GAUGE PANEL
39307871	CLAMP		169	OPTION - SPARK ARRESTOR
39435441	PLATE, CLAMP		51	AIREND REAR BEARING HSG.ASSEMBLY
39437595	BEARING, TAPERED ROLLE		51	AIREND REAR BEARING HSG.ASSEMBLY
39437629	GASKET, REAR BEARING H		49	AIREND ROTOR HOUSING
39437637	GASKET		47	AIREND GEAR CASE
39703921	HOUSING, FRONT BEARING		49	AIREND ROTOR HOUSING
39748942	HOUSING, ROTOR		49	AIREND ROTOR HOUSING
42308511	SUPPORT, AIREND		43	AIREND MOUNTING
46490942	DEUTCH TERMINAL REMOV		187	SERVICE TOOLS
46490959	PACKARD METRI- PACK TER		187	SERVICE TOOLS
46490967	PACKARD METRI- PACK TER		187	SERVICE TOOLS
46490975	PACKARD METRI- PACK TER		187	SERVICE TOOLS
46490983	KIT, DEUTSCH CONNECTOR		191	CONNECTOR REPAIR KITS
46491296	KIT, PACKARD CONNECTOR		191	CONNECTOR REPAIR KITS
46491304	KIT, CATERPILLAR C9, C15,		191	CONNECTOR REPAIR KITS
46491312	KIT, OTC AND AUTOSTART		191	CONNECTOR REPAIR KITS
46491320	AMP AMPSEAL TERMINAL C		187	SERVICE TOOLS
46491338	MOLEX 1.5 TERMINAL CRIM		187	SERVICE TOOLS
46491346	MOLEX 0.6 TERMINAL CRIM		187	SERVICE TOOLS
46491361	MOLEX 0.6 TERMINAL REMO		187	SERVICE TOOLS
46491411	KIT, JOHN DEERE AND YAN		191	CONNECTOR REPAIR KITS
46491429	KIT, CUMMINS QSX15 ENGIN		191	CONNECTOR REPAIR KITS
46491502	KIT, SECU AND REMOTE CO		191	CONNECTOR REPAIR KITS
46491569	KIT, CUMMINS OSL9 AND QS		191	CONNECTOR REPAIR KITS
46491653	MOLEX 1.5 TERMINAL REMO		187	SERVICE TOOLS
46501557	BAR ASSEMBLY, BUMPER /		159	OPTION - BRAKE LIGHTS WITH REVERSE LI
46550737	KIT, 500 HOURS		179	MAINTENANCE KIT

Part Number	Denomination	WAS	Page	Subgroup
46550738	KIT, 1000 HOURS		177	MAINTENANCE KIT
46551221	CJ4 ENGINE OIL		181	FLUIDS
46551222	CJ4 ENGINE OIL		181	FLUIDS
46551223	CJ4 ENGINE OIL		181	FLUIDS
46556137	DECAL, BLACK WEB SITE		31	DECALS & DOCUMENTATION
46565579	MANUAL, OPERATION AND		31	DECALS & DOCUMENTATION
46569661	HITCH, BALL		3 9	RUNNING GEAR RUNNING GEAR
46569682	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
46569685	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
46569700	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
46569701	EYE, TOWING		3	RUNNING GEAR
46573860	DECAL, DOOSAN TRI-COLO		31	DECALS & DOCUMENTATION
46573861	DECAL, DOOSAN TRI-COLO		31	DECALS & DOCUMENTATION
46573924	DECAL, DOOSAN LOGO		31	DECALS & DOCUMENTATION
46577126	DECAL, MODEL NUMBER 7/1		31	DECALS & DOCUMENTATION
46577127	DECAL, MODEL NUMBER 10/		31	DECALS & DOCUMENTATION
46577128	DECAL, MODEL NUMBER 14/		31	DECALS & DOCUMENTATION
46592579	FOAM FIELD KIT (no adhesive		25 27	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
46592580	FOAM FIELD KIT (no adhesive		25 27	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
54413505	WHEEL AND TYRE ASSEMB		5 13 17	RUNNING GEAR RUNNING GEAR DRAWBAR MOUNTING
54413513	WHEEL		5 13	RUNNING GEAR RUNNING GEAR
54413547	TYRE		5 13	RUNNING GEAR RUNNING GEAR
54475777	SWITCH		39	WEDGE CONTROLLER
54477740	HARNESS, FRONT SIDE		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
54614870	BUMPER, END STOP		19	FRAME
54629977	DECAL, ISO CENTRAL DRAI		161	OPTION - CENTRAL DRAINS
54639174	HINGE, SIDE DOOR		23	DOOR AND BAFFLE ENCLOSURE
54660089	CAP, FUEL TANK		95	FUEL TANK
54661889	AIR CLEANER ASSEMBLY		87 89	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
54674957	FOAM		25	FOAM INSULATION EXTERIOR
54675863	STANDPIPE ASSEMBLY		95	FUEL TANK
54688015	HOSE, DISCHARGE		65 75	SEPARATOR TANK PIPING OIL/AIR PIPING
54692967	BODY, AIR CLEANER		91	AIR CLEANER ASSEMBLY
54692975	COVER, AIR CLEANER		91	AIR CLEANER ASSEMBLY
54694831	PANEL, REAR ACCESS		23	DOOR AND BAFFLE ENCLOSURE

Part Number	Denomination	WAS	Page	Subgroup
54699624	DEUTCH TERMINAL REMOV		187	SERVICE TOOLS
54699632	DEUTCH TERMINAL REMOV		187	SERVICE TOOLS
54699640	DEUTCH TERMINAL REMOV		187	SERVICE TOOLS
54699657	DEUTCH WEDGELOCK AND		187	SERVICE TOOLS
54715891	POD, LH FRONT SIDE		159	OPTION - BRAKE LIGHTS WITH REVERSE LI
54716592	POD, RH FRONT SIDE		159	OPTION - BRAKE LIGHTS WITH REVERSE LI
54717145	ELEMENT, AIR FILTER		91	AIR CLEANER ASSEMBLY
			173	MAINTENANCE KIT
			175	MAINTENANCE KIT
			177	MAINTENANCE KIT
			179	MAINTENANCE KIT
54717152	ELEMENT, AIR FILTER		91	AIR CLEANER ASSEMBLY
			173	MAINTENANCE KIT
			177	MAINTENANCE KIT
			179	MAINTENANCE KIT
54718184	STRAP, FOAM RETAINING		21	ROOF AND SIDE ENCLOSURE
			23	DOOR AND BAFFLE ENCLOSURE
54721337	ADAPTER		75	OIL/AIR PIPING
54729660	PACKARD WEATHER- PACK		187	SERVICE TOOLS
54729710	ELECTRICAL CONTACT CLE		187	SERVICE TOOLS
54731427	SENDER, FUEL LEVEL		95	FUEL TANK
54737630	BUMPER		19	FRAME
54738091	BAR ASSEMBLY, BUMPER /		41	BRAKE LIGHTS AND WIRING
54739784	PANEL, FRONT		21	ROOF AND SIDE ENCLOSURE
54739826	PANEL		21	ROOF AND SIDE ENCLOSURE
54739842	PANEL		21	ROOF AND SIDE ENCLOSURE
54740675	SERIAL CABLE, HEAVY DUT		187	SERVICE TOOLS
54742028	PLATE, BAIL EYE		19	FRAME
54743257	DOOR, SIDE		23	DOOR AND BAFFLE ENCLOSURE
54743265	DOOR, CONTROL PANEL		37	INSTRUMENT PANEL
54749056	SPACER, FAN		79	ENGINE MOUNTING
54749544	RTD SIMULATOR		187	SERVICE TOOLS
54749551	THERMISTOR SIMULATOR		187	SERVICE TOOLS
			37	INSTRUMENT PANEL
			163	OPTION - FULL GAUGE PANEL
54749601	FRAME, INSTRUMENT PANE		165	OPTION - TACHOMETER PANEL
54749643	PACKARD METRI- PACK TER		187	SERVICE TOOLS
54756507	MOUNT, ENGINE		79	ENGINE MOUNTING
54756697	ISOLATOR, CENTRE BOND		79	ENGINE MOUNTING
54756739	MOUNT, ENGINE		79	ENGINE MOUNTING
54760483	PANEL, LOUVER ACCESS		23	DOOR AND BAFFLE ENCLOSURE
54761630	BRACKET		149	OPTION - AFTERCOOLER AND WATER SEP
			155	OPTION - IQ FILTER AND MOUNTING
54765946	SWITCH		71	OIL/AIR PIPING
54772041	PLUG		19	FRAME
			23	DOOR AND BAFFLE ENCLOSURE
54774203	BAIL, LIFTING		19	FRAME
54774229	PIPE, EXHAUST		85	EXHAUST PIPING

Part Number	Denomination	WAS	Page	Subgroup
80026123	HANDLE		9	RUNNING GEAR
80029705	KIT, 500 HOURS		175	MAINTENANCE KIT
80029903	KIT, 500 HOURS		173	MAINTENANCE KIT
85470003	SCREW		103	FLYWHEEL HOUSING
85470458	SCREW		103	FLYWHEEL HOUSING
85470474	SCREW		115	THERMOSTAT
85470508	SCREW		117	OIL PAN
85470581	ELBOW		123	EXHAUST MANIFOLD AND TURBOCHARGER
85470615	O-RING		123 147	EXHAUST MANIFOLD AND TURBOCHARGER OIL FILTER
85470623	O-RING		113 141	WATER PUMP OIL COOLER
85470631	O-RING		113 143	WATER PUMP SENSORS
85470649	O-RING		113 117 147	WATER PUMP OIL PAN OIL FILTER
85471092	SCREW		99	OIL FILLER NECK
85471142	SCREW		113	WATER PUMP
85471167	SCREW		113	WATER PUMP
85471183	SCREW		113	WATER PUMP
85471811	PLUG, DRAIN		147	OIL FILTER
85472280	SPACER		119	FAN DRIVE
85472587	O-RING		107	AIR INTAKE MANIFOLD
85473395	FLYWHEEL		105	FLYWHEEL
85473502	PLUG		113	WATER PUMP
85473676	LINE, TURBO OIL INLET		123	EXHAUST MANIFOLD AND TURBOCHARGER
85473700	SUPPORT, FAN DRIVE		119	FAN DRIVE
85473973	KIT, ADAPTOR		141	OIL COOLER
85473999	HEATER		107	AIR INTAKE MANIFOLD
85474054	ADAPTOR		123	EXHAUST MANIFOLD AND TURBOCHARGER
85474781	INTAKE, OIL PUMP		117	OIL PAN
88106224	FENDER		19	FRAME
88115498	DECAL, PRE-START		29	DECALS & DOCUMENTATION
89292973	PRO-TEC COMPRESSOR OIL		181	FLUIDS
89292981	PRO-TEC COMPRESSOR OIL		181	FLUIDS
89298491	DECAL, PROTEC OIL		31	DECALS & DOCUMENTATION
89310718	HOSE		183	AIR DELIVERY HOSE
89311716	PRO-TEC ENGINE OIL		181	FLUIDS
89311724	PRO-TEC ENGINE OIL		181	FLUIDS
92047331	HOSE		183	AIR DELIVERY HOSE
92063296	COUPLING, MALE		185	AIR HOSE FITTINGS
92063379	COUPLING, HOSE		185	AIR HOSE FITTINGS
92063387	CLAMP, HOSE		185	AIR HOSE FITTINGS
92076447	NIPPLE		63	HA SERVICE AIR
92076454	NIPPLE		63	HA SERVICE AIR

Part Number	Denomination	WAS	Page	Subgroup
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92111228	VALVE, BALL		63	HA SERVICE AIR
92112226	HOSE		183	AIR DELIVERY HOSE
92121243	REFLECTOR, AMBER		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92121250	LIGHT, FRONT SIDE		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92150978	COUPLING, HOSE		185	AIR HOSE FITTINGS
92150986	CLAMP, HOSE		185	AIR HOSE FITTINGS
92178524	COUPLING		185	AIR HOSE FITTINGS
92178532	COUPLING, FEMALE		185	AIR HOSE FITTINGS
92178565	SEAL		185	AIR HOSE FITTINGS
92271915	RIVET		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92294461	VALVE, BALL		63	HA SERVICE AIR
92304492	NUT		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92304583	WASHER		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92368687	SCREW		19	FRAME
			35	BATTERY AND MOUNTING
			81	COOLER MOUNTING
			171	OPTION - WHEEL CHOCKS
92398130	SCREW		83	COOLER PIPING
92530047	VALVE, BALL		63	HA SERVICE AIR
92721331	REFLECTOR, RED		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92726017	GROMMET		95	FUEL TANK
92737840	HOSE		183	AIR DELIVERY HOSE
92737857	HOSE		183	AIR DELIVERY HOSE
92737972	COUPLING, FEMALE		185	AIR HOSE FITTINGS
92737980	COUPLING, MALE		185	AIR HOSE FITTINGS
92737998	COUPLING, FEMALE		185	AIR HOSE FITTINGS
92738004	COUPLING, FEMALE		185	AIR HOSE FITTINGS
92808666	FILTER, FUEL		95	FUEL TANK
92867449	DECAL, REFER TO HANDBO		29	DECALS & DOCUMENTATION
			31	DECALS & DOCUMENTATION
92867530	DECAL, HOT SURFACE		31	DECALS & DOCUMENTATION
92877620	O-RING		75	OIL/AIR PIPING
92899293	CHOCK, WHEEL AND HOLDE		171	OPTION - WHEEL CHOCKS
92901222	LAMP, TAIL/STOP/FLASH		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92901230	LAMP, REGISTRATION PLAT		41	BRAKE LIGHTS AND WIRING
			159	OPTION - BRAKE LIGHTS WITH REVERSE LI
92930539	DECAL, ELECTRIC SHOCK		31	DECALS & DOCUMENTATION
92930585	DECAL, PRESSURISED VES		31	DECALS & DOCUMENTATION
92930601	DECAL, CORROSIVE SUBST		31	DECALS & DOCUMENTATION
92930627	DECAL, GENERAL WARNING		29	DECALS & DOCUMENTATION
			31	DECALS & DOCUMENTATION

Part Number	Denomination	WAS	Page	Subgroup
92930650	DECAL, EMERGENCY STOP		29	DECALS & DOCUMENTATION
92930668	DECAL, NO MAINT/READ MA		29 31	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
92949742	FOAM FIELD KIT (with adhesi		25 27	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92949759	FOAM FIELD KIT (with adhesi		25 27	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92949767	FOAM FIELD KIT (with adhesi		25 27	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92949775	FOAM FIELD KIT (with adhesi		25 27	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92976042	DECAL, EXHAUST GAS DISC		29	DECALS & DOCUMENTATION
93165959	DECAL, ROTATING FAN		29 31	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
93171239	DECAL, ENGINE OIL DRAIN		31	DECALS & DOCUMENTATION
93171247	DECAL, COOLANT DRAIN		31	DECALS & DOCUMENTATION
93171254	DECAL, DIESEL FUEL		29	DECALS & DOCUMENTATION
93171262	DECAL, LIFT/TIE POINT		29 31	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
93171270	DECAL, ENGINE OIL FILL		31	DECALS & DOCUMENTATION
93171288	DECAL, COOLANT FILL		29	DECALS & DOCUMENTATION
93181873	DECAL, TYRE PRESSURE		29 31	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
93190486	DECAL, COOLANT LEVEL		31	DECALS & DOCUMENTATION
93194413	DECAL, DO NOT STAND		31	DECALS & DOCUMENTATION
93465383	DECAL, SERVICE VALVE		29	DECALS & DOCUMENTATION
93477388	LAMP, FOG		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
95022307	O-RING		57	OIL TEMPERATURE BYPASS VALVE
95092318	NIPPLE		73	OIL/AIR PIPING
95097291	NIPPLE		63	HA SERVICE AIR
95220604	SCREW		43	AIREND MOUNTING
95223178	RING, SNAP		49	AIREND ROTOR HOUSING
95223194	RING, SNAP		49	AIREND ROTOR HOUSING
95223806	RING, SNAP		49	AIREND ROTOR HOUSING
95239919	PIN, DOWEL		47	AIREND GEAR CASE
95239927	PIN		49	AIREND ROTOR HOUSING
95264149	SCREW		47	AIREND GEAR CASE
95280541	PLUG		95	FUEL TANK
95285615	NIPPLE		63	HA SERVICE AIR
95286548	ELBOW		65	SEPARATOR TANK PIPING
95286910	ELBOW		149	OPTION - AFTERCOOLER AND WATER SEP
95302170	ELBOW		155	OPTION - IQ FILTER AND MOUNTING
95315289	CONNECTOR		59 83	OTBV AND OIL FILTER MOUNTING COOLER PIPING
95357976	O-RING		63 65 75	HA SERVICE AIR SEPARATOR TANK PIPING OIL/AIR PIPING

Part Number	Denomination	WAS	Page	Subgroup
95358131	O-RING		51	AIREND REAR BEARING HSG.ASSEMBLY
95364469	ELBOW		73	OIL/AIR PIPING
95365094	ELBOW		59 75	OTBV AND OIL FILTER MOUNTING OIL/AIR PIPING
95381109	KEY		49	AIREND ROTOR HOUSING
95402806	ADAPTER		45	AIREND PIPING
95494167	SCREW		51	AIREND REAR BEARING HSG.ASSEMBLY
95773032	ADAPTER		71	OIL/AIR PIPING
95916151	WASHER		37	INSTRUMENT PANEL
95916281	ELBOW		63	HA SERVICE AIR
95923298	NUT		23 35	DOOR AND BAFFLE ENCLOSURE BATTERY AND MOUNTING
95928040	NIPPLE		65 161	SEPARATOR TANK PIPING OPTION - CENTRAL DRAINS
95928164	ELBOW		63	HA SERVICE AIR
95928800	NUT		39	WEDGE CONTROLLER
95932802	BUSHING, REDUCING		65	SEPARATOR TANK PIPING
95932836	NIPPLE		149 153	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95934279	NIPPLE		63	HA SERVICE AIR
95934683	WASHER, LOCK		65 75	SEPARATOR TANK PIPING OIL/AIR PIPING
95934774	SCREW		155	OPTION - IQ FILTER AND MOUNTING
95934998	WASHER		23 35	DOOR AND BAFFLE ENCLOSURE BATTERY AND MOUNTING
95935003	WASHER		35	BATTERY AND MOUNTING
95935029	WASHER		23	DOOR AND BAFFLE ENCLOSURE
95935037	WASHER		59 95	OTBV AND OIL FILTER MOUNTING FUEL TANK
95935599	COUPLING		37 155 163	INSTRUMENT PANEL OPTION - IQ FILTER AND MOUNTING OPTION - FULL GAUGE PANEL
95937462	BUSHING		149 153	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95938205	PLUG		51	AIREND REAR BEARING HSG.ASSEMBLY
95940748	BUSH, REDUCING		71 73 95	OIL/AIR PIPING OIL/AIR PIPING FUEL TANK
95941639	PLUG		63	HA SERVICE AIR
95944575	NIPPLE		71 149 153	OIL/AIR PIPING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95944617	BUSHING, REDUCING		65	SEPARATOR TANK PIPING
95944641	ADAPTER		63	HA SERVICE AIR
95944666	ELBOW		75	OIL/AIR PIPING
95944732	ELBOW		65	SEPARATOR TANK PIPING
95944740	ELBOW		149 153	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95946190	ELBOW		149	OPTION - AFTERCOOLER AND WATER SEP

Part Number	Denomination	WAS	Page	Subgroup
95946532	SCREW		95	FUEL TANK
95947149	PLUG		161	OPTION - CENTRAL DRAINS
95952990	COUPLING		73	OIL/AIR PIPING
95954194	TEE		69	OIL/AIR PIPING
95954228	TEE		65	SEPARATOR TANK PIPING
95954913	REDUCER		59	OTBV AND OIL FILTER MOUNTING
95954921	ADAPTOR		59	OTBV AND OIL FILTER MOUNTING
95955993	CONNECTOR		59	OTBV AND OIL FILTER MOUNTING
95956199	ELBOW		163	OPTION - FULL GAUGE PANEL
95972188	RIVET		37	INSTRUMENT PANEL
95973228	O-RING		75	OIL/AIR PIPING
95983292	ELBOW		149	OPTION - AFTERCOOLER AND WATER SEP
95992632	ELBOW		59 65 77	OTBV AND OIL FILTER MOUNTING SEPARATOR TANK PIPING OIL/AIR PIPING
96701370	NUT		171	OPTION - WHEEL CHOCKS
96701396	WASHER		79	ENGINE MOUNTING
96701495	SCREW		35	BATTERY AND MOUNTING
96701503	SCREW		79	ENGINE MOUNTING
96701750	NUT, HEX		19 55	FRAME UNLOADER MOUNTING
96701917	SCREW		95	FUEL TANK
96702279	SCREW		87 149 153	AIR INTAKE AND FILTER MOUNTING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
96702287	SCREW		53	UNLOADER ASSEMBLY
96702311	SCREW		17	DRAWBAR MOUNTING
96702659	SCREW		21 57	ROOF AND SIDE ENCLOSURE OIL TEMPERATURE BYPASS VALVE
96702816	SCREW		55 87 89	UNLOADER MOUNTING AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
96703756	NUT		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96704408	SCREW		79	ENGINE MOUNTING
96704630	NUT		43 79	AIREND MOUNTING ENGINE MOUNTING
96704671	WASHER		171	OPTION - WHEEL CHOCKS
96705165	WASHER		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96705173	SCREW		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96705728	SCREW		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96709118	WASHER		79	ENGINE MOUNTING
96712187	SCREW		47 51	AIREND GEAR CASE AIREND REAR BEARING HSG.ASSEMBLY
96715057	SCREW		55	UNLOADER MOUNTING
96716162	SCREW		47	AIREND GEAR CASE

Part Number	Denomination	WAS	Page	Subgroup
96719810	SCREW		65 75	SEPARATOR TANK PIPING OIL/AIR PIPING
96720545	SCREW		79	ENGINE MOUNTING
96726345	SCREW		95	FUEL TANK
96726435	SCREW		79	ENGINE MOUNTING
96737556	SCREW		79	ENGINE MOUNTING
96743265	SCREW		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96745211	SCREW		171	OPTION - WHEEL CHOCKS
96745229	WASHER		171	OPTION - WHEEL CHOCKS
96745237	WASHER		41 159	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96757557	SCREW		65	SEPARATOR TANK PIPING
97319941	CHECK, SAFETY		185	AIR HOSE FITTINGS



Portable Power