





Portable Power

7/170, 10/125, 14/115

PARTS MANUAL

SERIAL No : 702800 ->





Portable Power

CONTENTS

RUNNING GEAR

RUNNING GEAR - (Fixed Height Braked)	3
RUNNING GEAR - (Fixed Height Braked)	5
RUNNING GEAR - (Variable Height Braked)	9
RUNNING GEAR - (Variable Height Braked)	13
DRAWBAR MOUNTING	17
RUNNING GEAR - (Variable Height Braked - KHD)	19
RUNNING GEAR - (Variable Height Braked - KHD)	21

MAIN FRAME

FRAME	29
ROOF AND SIDE ENCLOSURE	31
DOOR AND BAFFLE ENCLOSURE	33
FOAM INSULATION EXTERIOR	35
FOAM INSULATION INTERIOR	37
DECALS & DOCUMENTATION	39
DECALS & DOCUMENTATION	41

ELECTRICAL SYSTEM

BATTERY AND MOUNTING	45
INSTRUMENT PANEL	47
WEDGE CONTROLLER	49
BRAKE LIGHTS AND WIRING	51

AIR END

AIREND MOUNTING	53
AIREND PIPING	55
AIREND GEAR CASE	57
AIREND ROTOR HOUSING	59
AIREND REAR BEARING HSG.ASSEMBLY	61
UNLOADER ASSEMBLY	63
UNLOADER MOUNTING	65
OIL TEMPERATURE BYPASS VALVE	67
OTBV AND OIL FILTER MOUNTING	69
MINIMUM PRESSURE VALVE	71
HA SERVICE AIR - (No Aftercooler)	73
SEPARATOR TANK PIPING	75
SEPARATOR TANK SIGHT GLASS AND OIL FILL	77
OIL/AIR PIPING	79
OIL/AIR PIPING - (Separator Tank)	81
OIL/AIR PIPING - (Air End)	83
OIL/AIR PIPING	85
OIL/AIR PIPING	87

POWER UNIT

ENGINE MOUNTING	89
COOLER MOUNTING	91
COOLER PIPING	93
EXHAUST PIPING	95
AIR INTAKE AND FILTER MOUNTING - (7/170)	97

AIR INTAKE AND FILTER MOUNTING - (10/125, 14/115)	99
AIR CLEANER ASSEMBLY	101
AIR CLEANER ASSEMBLY - (7/170)	103
FUEL TANK	105
ROCKER ARM COVER	107
OIL FILLER NECK	109
CRANKSHAFT PULLEY	111
FLYWHEEL HOUSING	113
FLYWHEEL	115
AIR INTAKE MANIFOLD	117
FUEL INJECTION PUMP, CONTROLLER AND LINES	119
WATER PUMP	123
THERMOSTAT	125
OIL PAN	127
FAN DRIVE	129
BELT TENSIONER	131
EXHAUST MANIFOLD AND TURBOCHARGER	133
STARTER MOTOR	135
ALTERNATOR	137
ALTERNATOR MOUNTING	139
FINAL FUEL FILTER	141
PRIMARY FUEL FILTER	143
FUEL TRANSFER PUMP	145
FUEL LINES	147
DIPSTICK	149
OIL COOLER	151
SENSORS	153
ENGINE WIRING HARNESS	155
OIL FILTER	157

ACCESSORIES & OPTIONS


OPTION - AFTERCOOLER AND WATER SEPARATOR	159
OPTION - AFTERCOOLER AND MOUNTING	163
OPTION - IQ FILTER AND MOUNTING	165
OPTION - BRAKE LIGHTS WITH REVERSE LIGHT	169
OPTION - CENTRAL DRAINS	171
OPTION - FULL GAUGE PANEL	173
OPTION - TACHOMETER PANEL	175
OPTION - EXHAUST GRILLE	177
OPTION - SPARK ARRESTOR	179
OPTION - WHEEL CHOCKS	181

MAINTENANCE ITEMS

MAINTENANCE KIT - (500 hours) - (7/170)	183
MAINTENANCE KIT - (500 hours) - (10/125 - 14/115)	185
MAINTENANCE KIT - (1000 hours) - (7/170)	187
MAINTENANCE KIT - (1000 hours) - (10/125 - 14/115)	189
FLUIDS	191
AIR DELIVERY HOSE	193
AIR HOSE FITTINGS	195
SERVICE TOOLS	197
CONNECTOR REPAIR KITS	201

7/170_10/125_14/115_23209273-D_03/14

RUNNING GEAR **(Fixed Height Braked)**




T4252_01
10/12

RUNNING GEAR (Fixed Height Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46569661	HITCH, BALL	(50 mm)		1
1	46569661	HITCH, BALL	(non-standard) - (50 mm)		1
2	22177588	EYE, TOWING	(Ø 40 mm)		1
2	46569700	EYE, TOWING	(non-standard)(UK) - (Ø 40 mm)		1
3	22177687	EYE, TOWING	(Ø 50 mm)		1
3	46569685	EYE, TOWING	(non-standard) - (Ø 50 mm)		1
4	46569682	EYE, TOWING	(non-standard) - (Ø 68 mm)		1
4	22207823	EYE, TOWING	(non-standard)(France) - (Ø 68 mm)		1
5	22177620	EYE, TOWING	(Ø 76 mm)		1
6	46569701	EYE, TOWING	(non-standard)(Italy) - (Ø 45 mm)		1
7	22241350	BOLT			8
8	22250450	TUBE			1
9	22251359	PIN			1
10	22241095	NIPPLE, GREASE			2
11	22391858	CAP, GREASE NIPPLE			2
12	22251243	DAMPER			1
13	22051577	NUT			1
14	22051585	RING			1
15	22051494	NUT			1
16	22251367	BUSH			2
17	22051544	JOINT			1
18	22251482	BOLT			1
19	22250518	SLIDER			1
20	22250583	DRAWBAR			1
21	22251300	CLAMP			1
22	22251516	BOLT			4
23	22251540	LOCKNUT			4
24	22050393	COVER			1

RUNNING GEAR **(Fixed Height Braked)**




T4253_00
07/12

**RUNNING GEAR
(Fixed Height Braked)**

Item	Part Number	Description	Remarks	Serial Number	Qty
1	22250807	BOLT			1
2	22251292	SPRING			1
3	22051833	LEVER, HANDBRAKE			1
4	22051841	CABLE			1
5	22241376	WASHER			3
6	22051882	WASHER			1
7	22250419	WASHER			2
8	22357693	PIN			1
9	22241491	WASHER			1
10	22251483	CLEVIS			1
11	22241160	PIN			1
12	22251318	LEVER ASSEMBLY	W/Ref. 8-11		1
13	22241194	WASHER			1
14	22051494	NUT			1
15	22250781	COMPENSATOR			1
16	22250617	COVER			2
17	22250625	CABLE			2
18	22250922	CONNECTOR			2
19	22250914	COVER			4
20	22250955	SCREW			2
21	22250658	KEY			4
22	22250948	TAPER			2
23	22250344	SHOE			2
24	22250351	SHOE			2
25	22250377	SPRING	(lower)		2
26	22250369	SPRING	(upper)		2
27	22250963	SPRING			2
28	22250849	ROD			2
29	22392658	EXPANDER			2
30	22871214	SPACER			2
31	22250989	BEARING			2


RUNNING GEAR (CONT'D) **(Fixed Height Braked)**



T4253_00
07/12

[illegible][illegible]

RUNNING GEAR (Variable Height Braked)




T4254_01
10/12

RUNNING GEAR (Variable Height Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46569661	HITCH, BALL	(50 mm)		1
1	46569661	HITCH, BALL	(non-standard) - (50 mm)		1
2	22177588	EYE, TOWING	(Ø 40 mm)		1
2	46569700	EYE, TOWING	(non-standard)(UK) - (Ø 40 mm)		1
3	22177687	EYE, TOWING	(Ø 50 mm)		1
3	46569685	EYE, TOWING	(non-standard) - (Ø 50 mm)		1
4	46569682	EYE, TOWING	(non-standard) - (Ø 68 mm)		1
4	22207823	EYE, TOWING	(non-standard)(France) - (Ø 68 mm)		1
5	22177620	EYE, TOWING	(Ø 76 mm)		1
6	46569701	EYE, TOWING	(non-standard)(Italy) - (Ø 45 mm)		1
7	22251508	NUT			4
8	22251557	BOLT			4
9	22250567	CLAMP ASSEMBLY			1
10	22250559	DRAWBAR			1
11	22250823	BOLT			1
12	22241400	NIPPLE			1
13	22250526	ARM ASSEMBLY			1
14	80026123	HANDLE			1
15	22241178	BOLT			1
16	22251250	HANDLE			1
17	22250542	LEVER			1
18	22051882	WASHER			2
19	22104806	WASHER			1
20	22051494	NUT			2
21	22251573	CABLE			1
22	22051577	NUT			2
23	22241533	SCREW			3
24	22250443	COVER			1
25	22250534	COUPLING	W/Ref. 17-20		1
26	22250492	BOLT			1
27	22241095	NIPPLE, GREASE			2


RUNNING GEAR (CONT'D) (Variable Height Braked)



RUNNING GEAR (CONT'D) (Variable Height Braked)	
1	100
2	100
3	100
4	100
5	100
6	100
7	100
8	100
9	100
10	100
11	100
12	100
13	100
14	100
15	100
16	100
17	100
18	100
19	100
20	100
21	100
22	100
23	100
24	100
25	100
26	100
27	100
28	100
29	100
30	100
31	100
32	100
33	100
34	100
35	100
36	100
37	100
38	100
39	100
40	100
41	100
42	100
43	100
44	100
45	100
46	100
47	100
48	100
49	100
50	100
51	100
52	100
53	100
54	100
55	100
56	100
57	100
58	100
59	100
60	100
61	100
62	100
63	100
64	100
65	100
66	100
67	100
68	100
69	100
70	100
71	100
72	100
73	100
74	100
75	100
76	100
77	100
78	100
79	100
80	100
81	100
82	100
83	100
84	100
85	100
86	100
87	100
88	100
89	100
90	100
91	100
92	100
93	100
94	100
95	100
96	100
97	100
98	100
99	100
100	100

[illegible]

RUNNING GEAR (Variable Height Braked)




T4255_00
07/12

RUNNING GEAR (Variable Height Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	22066823	LEVER, HANDBRAKE			1
2	22241418	CABLE			1
3	22250765	SPRING			1
4	22241160	PIN			2
5	22241152	CABLE			1
6	22241491	WASHER			2
7	22357693	PIN			2
8	54413505	WHEEL AND TYRE ASSEMBLY	(not used for French variable height) - W/Ref. 35-36		2
8	22584791	WHEEL AND TYRE ASSEMBLY	(French variable height only) - W/Ref. 35-36		2
9	22251375	NUT			12
10	22241483	CLEVIS			2
11	22051577	NUT			4
12	22251573	CABLE			1
13	22250575	COMPENSATOR			1
14	22250625	CABLE			2
15	22250617	COVER			2
16	22250922	CONNECTOR			2
17	22250955	SCREW			2
18	22250658	KEY			4
19	22250948	TAPER			2
20	22250351	SHOE			2
21	22250344	SHOE			2
22	22250897	SPRING			2
23	22250906	SPRING			2
24	22250963	SPRING			2
25	22392658	EXPANDER			2
26	22250849	ROD			2
27	22871214	SPACER			2
28	22250989	BEARING			2
29	22250971	BEARING			2
30	22392229	WASHER			2

RUNNING GEAR (CONT'D) **(Variable Height Braked)**




T4255_00
07/12

RUNNING GEAR (CONT'D) (Variable Height Braked)	
1	100
2	100
3	100
4	100
5	100
6	100
7	100
8	100
9	100
10	100
11	100
12	100
13	100
14	100
15	100
16	100
17	100
18	100
19	100
20	100
21	100
22	100
23	100
24	100
25	100
26	100
27	100
28	100
29	100
30	100
31	100
32	100
33	100
34	100
35	100
36	100
37	100
38	100
39	100
40	100
41	100
42	100
43	100
44	100
45	100
46	100
47	100
48	100
49	100
50	100
51	100
52	100
53	100
54	100
55	100
56	100
57	100
58	100
59	100
60	100
61	100
62	100
63	100
64	100
65	100
66	100
67	100
68	100
69	100
70	100
71	100
72	100
73	100
74	100
75	100
76	100
77	100
78	100
79	100
80	100
81	100
82	100
83	100
84	100
85	100
86	100
87	100
88	100
89	100
90	100
91	100
92	100
93	100
94	100
95	100
96	100
97	100
98	100
99	100
100	100

[illegible]

DRAWBAR MOUNTING





T4256_00
07/12

DRAWBAR MOUNTING

[illegible]

RUNNING GEAR (Variable Height Braked - KHD)




T4340_00
02/13

RUNNING GEAR
(Variable Height Braked - KHD)

[illegible]

RUNNING GEAR (Variable Height Braked - KHD)




T4341_01
02/13

RUNNING GEAR
(Variable Height Braked - KHD)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46551503	DRAWBAR, COMPLETE	W/Ref. 2		1
2	46551483	SET, BUSH			1
3	46551401	UPPER ARM ASSEMBLY	W/Ref. 4		1
4	46551484	SET, BUSH			1
5	46551402	LOWER ARM ASSEMBLY	W/Ref. 6-7		1
6	46551485	SET, BUSH			1
7		COVER	NAP - Order Ref. 5		2
8	46551514	CENTRING MECHANISM ASSEMBLY	W/Ref. 9-12		1
9		SCREW	NAP - Order Ref. 8		1
10		NUT, ADJUSTMENT	NAP - Order Ref. 8		1
11		SCREW	NAP - Order Ref. 8		1
12	46551409	NIPPLE, GREASE			1
13	46551420	HOUSING ASSEMBLY	W/Ref. 14-26		1
14	46551380	HOUSING			1
15	46551412	ROD, PISTON			1
16	46551382	RING, STOP			1
17	46551408	KIT, COVER	W/Ref. 18		1
18		CABLE, TIE	NAP - Order Ref. 17		2
19	46551404	ABSORBER, SHOCK			1
20	46551486	BRACKET ASSEMBLY			1
21	22250864	HANDLE			1
22	22241350	BOLT			1
23	46551391	SCREW			2
24	46551409	NIPPLE, GREASE			1
25	46551417	LEVER ASSEMBLY			1
26	46551487	PIVOT ASSEMBLY			1
27	46551515	LEVER, HANDBRAKE	W/Ref. 28		1
28		CABLE	NAP - Order Ref. 27		1
29	46551403	SPRING ASSEMBLY			1
30	46551416	BRAKE CABLE ASSEMBLY			1
31	46551411	HANDLE ASSEMBLY	W/Ref. 32		1

RUNNING GEAR (CONT'D) (Variable Height Braked - KHD)




T4341_01
02/13

RUNNING GEAR (CONT'D)
(Variable Height Braked - KHD)

Item	Part Number	Description	Remarks	Serial Number	Qty
32		KNOB	NAP - Order Ref. 31		1
33	46551418	JIG, CLAMPING			1
34	46551488	PIVOT ASSEMBLY	W/Ref. 35-38		1
35		BOLT	NAP - Order Ref. 34		1
36		SCREW	NAP - Order Ref. 34		2
37		WASHER	NAP - Order Ref. 34		2
38		SEAL	NAP - Order Ref. 34		2
39	46551489	PIVOT ASSEMBLY	W/Ref. 40-43		2
40		PIN, PIVOT	NAP - Order Ref. 39		1
41		SCREW	NAP - Order Ref. 39		
42		WASHER	NAP - Order Ref. 39		2
43		SEAL	NAP - Order Ref. 39		2
44	46551490	PIVOT ASSEMBLY	W/Ref. 45-48		1
45		PIN, PIVOT	NAP - Order Ref. 44		1
46		SCREW	NAP - Order Ref. 44		2
47		WASHER	NAP - Order Ref. 44		2
48		SEAL	NAP - Order Ref. 44		2
49	46551422	CLIP, SPRING			1
50	46551491	SHIELD ASSEMBLY	W/Ref. 51		1
51		RIVET	NAP - Order Ref. 50		3
52	46551492	SHIELD ASSEMBLY	W/Ref. 53		1
53		RIVET	NAP - Order Ref. 52		4
54	46551400	SHIELD			1
55	46551384	ROD ASSEMBLY	W/Ref. 56-58		1
56		COUPLING ASSEMBLY	NAP - Order Ref. 55		1
57		SPRING	NAP - Order Ref. 55		1
58		BUSH	NAP - Order Ref. 55		1
59	46551415	LEVER ASSEMBLY			1
60	46551406	DECAL	(English/German)		1
61	46551407	DECAL	(English/French)		1
62	46551405	DECAL	(English/German)		1

RUNNING GEAR (CONT'D) (Variable Height Braked - KHD)




T4341_01
02/13

RUNNING GEAR (CONT'D)
(Variable Height Braked - KHD)

Item	Part Number	Description	Remarks	Serial Number	Qty
63	46551493	KIT, CONNECTING			2
64	46551494	BRAKE HUB COMPLETE	W/Ref. 65, 70-77 (order 2 per machine)		2
65	46551495	HUB ASSEMBLY			1
66	80027980	KIT, BRAKE SHOE	(order 1 kit per machine)		1
67	46551496	KIT, BRAKE OVERHAUL	W/Ref. 68,69,79,80 (order 1 Kit per machine)		1
68		EXPANDER	NAP - Order Ref. 67		2
69		CONNECTOR	NAP - Order Ref. 67		2
70		LOCKWASHER	NAP - Order Ref. 96		6
71		NUT	NAP - Order Ref. 96		6
72		SPACER	NAP - Order Ref. 98		1
73		BEARING	NAP - Order Ref. 98		1
74		BEARING	NAP - Order Ref. 98		1
75		WASHER	NAP - Order Ref. 98		1
76		PIN	NAP - Order Ref. 98		1
77		LOCKNUT	NAP - Order Ref. 98		1
78	22392153	CAP, DUST			1
79		KIT, ADJUSTING	NAP - Order Ref. 67		1
80		COVER	NAP - Order Ref. 67		2
81	46551497	KIT, COVER	W/Ref. 82-83		2
82		COVER	NAP - Order Ref. 81		2
83		CAP	NAP - Order Ref. 81		1
84		BOLT	NAP - Order Ref. 97		4
85		NUT	NAP - Order Ref. 97		4
86	46551518	ADAPTOR			1
87	22177588	EYE, TOWING	(Ø 40 mm)		1
88	46569661	HITCH, BALL	(50 mm)		1
89	22177687	EYE, TOWING	(Ø 50 mm)		1
90	46551378	EYE, TOWING			1
91	22177620	EYE, TOWING	(Ø 76 mm)		1
92	22207823	EYE, TOWING	(Ø 68 mm)		1
93	46569682	EYE, TOWING	(Ø 68 mm)		1


RUNNING GEAR (CONT'D) (Variable Height Braked - KHD)



T4341_01
02/13

[illegible][illegible]


FRAME



FRAME

[illegible]


ROOF AND SIDE ENCLOSURE



T4292_00
07/12

[illegible]

DOOR AND BAFFLE ENCLOSURE




T4293_01
02/14

DOOR AND BAFFLE ENCLOSURE

Item	Part Number	Description	Remarks	Serial Number	Qty
1	35256429	STUD			12
2	54694831	PANEL, REAR ACCESS			2
2	54760483	PANEL, LOUVER ACCESS	(high ambient option only)		2
3	35256445	WASHER, RETAINING			12
4	35256452	RECEPTACLE			12
5	54639174	HINGE, SIDE DOOR			2
6	36797652	SCREW			53
7	36793602	LATCH			2
8	36794816	RIVET			8
9	54743257	DOOR, SIDE			2
10	54718184	STRAP, FOAM RETAINING			4
11	35607829	BOLT, EYE			1
12	36772028	WASHER			1
13	35607837	SPRING			1
14	95935029	WASHER			1
15	95923298	NUT			1
16	36881886	NUT			8
17	95934998	WASHER	(front panel only)		2
18	22068373	SEAL	(1,98 m long)		2
19	22058101	BRACKET, FRONT INTAKE			1
20	22429765	BAFFLE, SEPARATOR TANK			1
21	54772041	PLUG			12
22	35600261	SPRING			4
23	35337328	STUD, BALL			8
24	22058119	BAFFLE, FRONT INTAKE			1


FOAM INSULATION EXTERIOR



T4294_00
07/12

[illegible]


FOAM INSULATION INTERIOR



T4295_01
02/14

[illegible]

DECALS & DOCUMENTATION




T4296_01
02/14

DECALS & DOCUMENTATION

[illegible]

DECALS & DOCUMENTATION



T4297_03
11/13


**OPERATION AND
MAINTENANCE MANUAL**

PARTS MANUAL

DECALS & DOCUMENTATION


Item	Part Number	Description	Remarks	Serial Number	Qty
1	92867530	DECAL, HOT SURFACE			1
2	93194413	DECAL, DO NOT STAND			1
3	93165959	DECAL, ROTATING FAN			1
4	92930668	DECAL, NO MAINT/READ MANUAL			1
5	93171239	DECAL, ENGINE OIL DRAIN			1
6	93181873	DECAL, TYRE PRESSURE			1
7	93171270	DECAL, ENGINE OIL FILL			1
8	92930627	DECAL, GENERAL WARNING			1
9	92930601	DECAL, CORROSIVE SUBSTANCE			1
10	92930593	DECAL, ELECTRIC SHOCK			1
11	93190486	DECAL, COOLANT LEVEL			1
12	92867449	DECAL, REFER TO HANDBOOK			1
13	92930585	DECAL, PRESSURISED VESSEL			1
14	22062335	DECAL, SOUND POWER			1
15	93171262	DECAL, LIFT/TIE POINT			2
16	93171247	DECAL, COOLANT DRAIN			1
17	23239429	PLATE, DATA	(non-EC certified)		1
17	23237225	PLATE, DATA	(EC certified)		1
18	89298491	DECAL, PROTEC OIL			1
19	46556137	DECAL, BLACK WEB SITE			1
20	46577126	DECAL, MODEL NUMBER 7/170			2
20	46577127	DECAL, MODEL NUMBER 10/125			2
20	46577128	DECAL, MODEL NUMBER 14/115			2
21	46573924	DECAL, DOOSAN LOGO	(45")		2
22	46573861	DECAL, DOOSAN TRI-COLOUR			1
23	46573860	DECAL, DOOSAN TRI-COLOUR			1
24	46627615	DECAL, HORIZONTAL POSITION			1
25	23060288	MANUAL, OPERATION AND MAINTENANCE	(en)		1
25	23127509	MANUAL, OPERATION AND MAINTENANCE	(bg)		1
25	23116320	MANUAL, OPERATION AND MAINTENANCE	(da)		1
25	23116403	MANUAL, OPERATION AND MAINTENANCE	(nl)		1

DECALS & DOCUMENTATION (CONT'D)



[illegible]

BATTERY AND MOUNTING




T4279_00
07/12

BATTERY AND MOUNTING

[illegible]

INSTRUMENT PANEL




T4285_00
07/12

INSTRUMENT PANEL

Item	Part Number	Description	Remarks	Serial Number	Qty
1	54749601	FRAME, INSTRUMENT PANEL			1
2	22107478	HINGE, SPRING CONTROL PANEL			1
3	36877587	RIVET			4
4	54743265	DOOR, CONTROL PANEL			1
5	22127385	SWITCH, START			1
6	22054175	HOURLMETER			1
7	22171680	PANEL, INSTRUMENT			1
8	22171698	DECAL			1
9	22070494	SCREW			8
10	22054076	SWITCH, ROCKER			1
11	22050553	LIGHT, WARNING MODULE			1
12	22134118	KNOB ASSEMBLY			1
13	22692602	GAUGE, FUEL LEVEL	(24 V)		1
14	35370386	ELBOW			1
15	95935599	COUPLING			1
16	36891216	GAUGE, PRESSURE	(250 psi)		1
17	22172423	MODULE, 2-LIGHT WARNING			1
18	22054159	NUT, HOURLMETER			2
19	36920486	RIVET			4
20	22137426	BULB, LIGHT	(28 V)		2
21	22835680	HARNESS, PANEL WIRING			1
22	22058325	COVER, REAR INSTRUMENT PANEL			1
23	92271923	RIVET			3
24	92304583	WASHER			3

WEDGE CONTROLLER




T4286_00
07/12

WEDGE CONTROLLER

[illegible]

BRAKE LIGHTS AND WIRING




T4291_01
02/14

BRAKE LIGHTS AND WIRING

Item	Part Number	Description	Remarks	Serial Number	Qty
1	92121250	LIGHT, FRONT SIDE			2
2	92085729	REFLECTOR, WHITE			2
3	22186811	POD, LH FRONT SIDE			1
4	92121243	REFLECTOR, AMBER			4
5	22186605	POD, LH REAR SIDE			1
6	35279025	SCREW			8
7	22186829	POD, RH FRONT SIDE			1
8	22186613	POD, RH REAR SIDE			1
9	54477740	HARNESS, FRONT SIDE			2
10	54738091	BAR ASSEMBLY, BUMPER / LIGHTS			1
11	22173454	HARNESS, REAR BUMPER			1
12	92901230	LAMP, REGISTRATION PLATE			2
13	22073183	BRACKET			2
14	93477388	LAMP, FOG			2
15	92721331	REFLECTOR, RED			2
16	92901222	LAMP, TAIL/STOP/FLASH			2
17	92304583	WASHER			20
18	92304492	NUT			20
19	96705728	SCREW			4
20	96743265	SCREW			16
21	92271915	RIVET			10
22	96703756	NUT			4
23	96745237	WASHER			4
24	96705173	SCREW			4
25	96705165	WASHER			4
26	54614870	BUMPER, END STOP			2
27	46540217	PLINTH			2
28	46500021	GROMMET			6
29	23181704	BULB			2

AIREND MOUNTING




T4261_01
02/14

AIREND MOUNTING

[illegible]

AIREND PIPING




T4262_00
07/12

AIREND PIPING

Item	Part Number	Description	Remarks	Serial Number	Qty
1	36010643	AIREND ASSEMBLY	(7/170)		1
1	36011534	AIREND ASSEMBLY	(10/125)		1
1	36018042	AIREND ASSEMBLY	(14/115)		1
2	22247340	ELBOW, DISCHARGE			1
3	35575570	GASKET, AIREND DISCHARGE			1
4	23294820	SENSOR, TEMPERATURE			1
5	22189609	TUBE, AIREND OIL			1
6	96716162	SCREW			4
7	95402806	ADAPTOR			1
8	36845154	MANIFOLD, OIL			1
9	36846095	CONNECTOR, O-RING			2
10	35286491	ELBOW			1
11	36846111	TUBE ASSEMBLY			1
12	36846129	TEE			1
13	36846103	TUBE, BEARING OIL SCAVENGE			1
14	35305622	ELBOW			1
15	35278555	PLUG, ADAPTER			1
16	36880995	SCREW			12
17	35287945	BUSH, REDUCING			2
18	35279827	ELBOW			1
19	36795482	TUBE ASSEMBLY			1
20	35279843	TEE			1
21	36846087	TUBE, BEARING OIL SUPPLY			1
22	22189591	TUBE, AIREND OIL			1
23	35279876	ELBOW			1
24	35279959	O-RING			3
25	35278571	O-RING			1
26	35278589	O-RING			1

AIREND GEAR CASE




T4263_00
07/12

AIREND GEAR CASE

Item	Part Number	Description	Remarks	Serial Number	Qty
1	96716162	SCREW			8
2	39437637	GASKET			1
3	35108372	SCREW, SOCKET HEAD			1
4	35255827	PLATE, CLAMP			1
5	36751659	GEAR SET	(7/170)		1
5	36751667	GEAR SET	(10/125)		1
5	35303429	GEAR SET	(14/115)		1
6	35262716	SPACER			1
7	35269224	SPACER, BEARING			1
8	95264149	SCREW			4
9	35573070	PLATE, RETAINING			1
10	35601517	BEARING, BALL			1
11	95239919	PIN, DOWEL			2
12	35996164	CASE, GEAR			1
13	35336304	SCREW, SOCKET HEAD CAP			1
14	36764785	CAP, GUIDE			1
15	35313568	BEARING			1
16	36780906	SHAFT, DRIVE			1
17	95358024	O-RING			1
18	35593508	SEAL, OIL			1
19	35210087	GASKET			1
20	35592757	COVER, OIL SEAL			1
21	96712187	SCREW			6
22	36798205	GUARD, GEAR CASE			2
23	35361328	KEY			1

AIREND ROTOR HOUSING




T4264_00
07/12

AIREND ROTOR HOUSING	
---	--


[illegible]

AIREND REAR BEARING HSG.ASSEMBLY



[illegible]


UNLOADER ASSEMBLY



T4266_00
07/12

[illegible]


UNLOADER MOUNTING



T4267_00
07/12

[illegible]


OIL TEMPERATURE BYPASS VALVE



OIL TEMPERATURE BYPASS VALVE	
------------------------------	--


[illegible]

OTBV AND OIL FILTER MOUNTING



[illegible]

MINIMUM PRESSURE VALVE




T4270_00
07/12

MINIMUM PRESSURE VALVE

[illegible]


HA SERVICE AIR
(No Aftercooler)



T4268_00
07/12

[illegible]


SEPARATOR TANK PIPING



T4272_00
07/12

[illegible]

SEPARATOR TANK SIGHT GLASS AND OIL FILL




T4273_00
07/12

SEPARATOR TANK SIGHT GLASS AND OIL FILL

[illegible]

OIL/AIR PIPING




T4274_00
07/12

OIL/AIR PIPING	

[illegible]

**OIL/AIR PIPING
(Separator Tank)**




T4275_01
02/14

OIL/AIR PIPING (Separator Tank)	
---	--

[illegible]

OIL/AIR PIPING (Air End)




T4296_01
02/14

OIL/AIR PIPING (Air End)

[illegible]

OIL/AIR PIPING




T4277_01
02/14

OIL/AIR PIPING	

[illegible]

OIL/AIR PIPING




T4269_00
07/12

OIL/AIR PIPING	

[illegible]


ENGINE MOUNTING



T4257_01
02/14

[illegible]


COOLER MOUNTING



T4258_00
07/12

[illegible]

COOLER PIPING




T4259_00
07/12

COOLER PIPING

Item	Part Number	Description	Remarks	Serial Number	Qty
1	22189310	REDUCER			2
2	23056930	TUBE, CHARGE AIR LOWER			1
3	22058556	HOSE, STR-BELLOWS			3
4	23056955	TUBE, CHARGE AIR BOTTOM			1
5	35145408	CLAMP, SUPPORT			1
6	22144513	CLAMP			8
7	95315289	CONNECTOR			4
8	23013022	TUBE, OIL COOLER			1
9	23013030	TUBE, OIL COOLER			1
10	22891618	HOSE, TOP RADIATOR			1
11	23056948	TUBE, CHARGE AIR UPPER			1
12	36845600	TANK, HEADER			1
13	36797652	SCREW			4
14	22891626	HOSE, BOTTOM RADIATOR			1
15	35190487	BRACKET, TUBE CLAMP			1
16	35285162	GROMMET			1
17	35360775	TUBING	(1,65 m long)		1
18	22189302	CLAMP			2
19	35221639	CLIP, RETAINING			4
20	35253038	CLAMP			2
21	35296342	CLIP, RETAINING			1
22	23242779	BRACKET			1
23	92398130	SCREW			1
24	36881886	NUT			1

EXHAUST PIPING




T4260_00
07/12

EXHAUST PIPING	
----------------	--

[illegible]

AIR INTAKE AND FILTER MOUNTING (7/170)




T4280_01
02/14

AIR INTAKE AND FILTER MOUNTING (7/170)

[illegible]

AIR INTAKE AND FILTER MOUNTING (10/125, 14/115)




T4281_01
02/14

AIR INTAKE AND FILTER MOUNTING (10/125, 14/115)

[illegible]

AIR CLEANER ASSEMBLY




T4282_00
07/12

AIR CLEANER ASSEMBLY

[illegible]

AIR CLEANER ASSEMBLY (7/170)




T4283_00
07/12

AIR CLEANER ASSEMBLY (7/170)

[illegible]

FUEL TANK




T4284_02
02/14

FUEL TANK

Item	Part Number	Description	Remarks	Serial Number	Qty
1	54774260	TANK, FUEL			1
2	54660089	CAP, FUEL TANK			1
3	54731427	SENDER, FUEL LEVEL			1
4	35361849	GASKET			1
5	36842102	SCREW			5
6	22959936	SCREW			2
7	23230063	FUEL FILTER ASSEMBLY	W/Ref. 9		1
8	22969265	ELEMENT, FUEL FILTER	(primary)		1
9	36881886	NUT			2
10	35296342	CLIP, RETAINING			6
11	35363498	HOSE	(432 mm long) - (8 mm (5/16") ID)		1
12	35363498	HOSE	(432 mm long) - (8 mm (5/16") ID)		1
13	35363498	HOSE	(1,53 m long) - (8 mm (5/16") ID)		1
14	54675863	STANDPIPE ASSEMBLY			2
15	35384577	BUSH			2
16	22221022	STRAP, FUEL TANK			1
17	22221030	STRAP, FUEL TANK			1
18	22260038	STRAP, FUEL TANK			1
19	22776090	SCREW			2
20	92280981	SCREW			1
21	35273366	NUT			1
22	95280541	PLUG			1
23	35369347	CONNECTOR			1
24	95940748	BUSH, REDUCING			1
25	35356484	TUBE, NYLON	(152 mm long)		1
26	35369339	CONNECTOR			1
27	35322395	SILENCER, PNEUMATIC			1
28	95935037	WASHER			2
29	92808666	FILTER, FUEL			1
30	92726017	GROMMET			1
31	36889608	SCREW			2

ROCKER ARM COVER




T4298_00
07/12

ROCKER ARM COVER

[illegible]

OIL FILLER NECK




T4299_00
07/12

OIL FILLER NECK

[illegible]

CRANKSHAFT PULLEY




T4300_00
07/12

CRANKSHAFT PULLEY

[illegible]

FLYWHEEL HOUSING




T4301_00
07/12

FLYWHEEL HOUSING

[illegible]

FLYWHEEL




T4302_00
07/12

FLYWHEEL

[illegible]

AIR INTAKE MANIFOLD




T4303_00
07/12

AIR INTAKE MANIFOLD

[illegible]

FUEL INJECTION PUMP, CONTROLLER AND LINES




T4304_00
07/12

FUEL INJECTION PUMP, CONTROLLER AND LINES

Item	Part Number	Description	Remarks	Serial Number	Qty
1	23254931	HARNESS, ENGINE FUEL WIRING			1
2	23229792	SEAL			1
3	23230329	CLAMP			2
4	23230162	SCREW			4
5	23230071	SCREW			1
6	23229834	BRACKET			1
7	23019813	CAP			6
8	23229529	NUT			12
9	23019714	LINE, FUEL			2
10	23230139	LINE, FUEL			2
11	23230121	LINE, FUEL			2
12	23018492	RAIL			1
13	23229966	VALVE, PRESSURE RELIEF			1
14	23017098	SHIM			1
15	23230014	SENSOR			1
16	23229958	RESTRICTOR			6
17	23017098	SHIM			6
18	23017627	STUD			3
19	24898926	SCREW			2
20	24898801	NUT			3
21	23229867	WASHER, SEALING			6
22	23229602	O-RING			6
23	23230279	KIT, INJECTOR UNIT			6
24	23229636	CLAMP			6
25	23230170	SCREW			6
26	23254949	WASHER			6
27	23019268	BRACKET			1
28	18969410	SCREW			2
29	36138006	PUMP			1
30	23229974	SENDER, FUEL TEMPERATURE			1
31	23019490	O-RING			1

FUEL INJECTION PUMP, CONTROLLER AND LINES (CONT'D)




T4304_00
07/12

FUEL INJECTION PUMP, CONTROLLER AND LINES (CONT'D)

[illegible]


WATER PUMP



T4305_00
07/12

[illegible]

THERMOSTAT




T4306_00
07/12

THERMOSTAT

[illegible]

OIL PAN




T4307_00
07/12

OIL PAN	
---------	--

[illegible]

FAN DRIVE




T4308_00
07/12

FAN DRIVE

[illegible]

BELT TENSIONER




T4309_00
07/12

BELT TENSIONER

[illegible]


EXHAUST MANIFOLD AND TURBOCHARGER



T4310_00
07/12

[illegible]


STARTER MOTOR



STARTER MOTOR

[illegible]


ALTERNATOR



ALTERNATOR

[illegible]



ALTERNATOR MOUNTING



ALTERNATOR MOUNTING

[illegible]

FINAL FUEL FILTER




T4314_00
07/12

FINAL FUEL FILTER


[illegible]

PRIMARY FUEL FILTER



PRIMARY FUEL FILTER


FUEL TRANSFER PUMP



T4316_00
07/12

FUEL TRANSFER PUMP	
--------------------	--

FUEL LINES




T4317_00
07/12

FUEL LINES

Item	Part Number	Description	Remarks	Serial Number	Qty
1	24899254	O-RING			2
2	24899247	FITTING			1
3	24899882	LINE, FUEL			1
4	36116242	ADAPTOR			2
5	36126019	O-RING			8
6	23229941	FITTING			1
7	36119808	O-RING			2
8	23229925	HOSE			1
9	36114098	PLUG			1
10	23018013	FITTING			1
11	24899080	SCREW			6
12	23019656	LINE, FUEL			1
13	22808786	SCREW			1
14	36137586	BRACKET			1
15	36118750	CLAMP			1
16	24898801	NUT			1
17	24899528	FITTING			1
18	24899106	O-RING			2
19	23230030	LINE, FUEL			1
20	23230097	FITTING			1
21	36128916	O-RING			1
22	23230238	LINE, FUEL			1
23	36101962	PLUG			1
24	36106821	NUT			1
25	23230048	FITTING			1
26	36111912	TEE, FITTING			1
27	23019896	LINE, FUEL			1
28	23019417	WASHER			6


DIPSTICK



T4318_00
07/12





DIPSTICK

OIL COOLER



OIL COOLER	
------------	--

SENSORS




T4320_00
07/12

SENSORS


[illegible]

ENGINE WIRING HARNESS



T4321_00
07/12


OIL FILTER



OIL FILTER

[illegible]

OPTION - AFTERCOOLER AND WATER SEPARATOR




T4323_00
07/12

OPTION - AFTERCOOLER AND WATER SEPARATOR

Item	Part Number	Description	Remarks	Serial Number	Qty
1	95286910	ELBOW			2
2	23193667	FILTER, WATER SEPARATOR	(7/170)		1
2	23186729	SEPARATOR, WATER	(10/125) (14/115)		1
3	23187420	KIT, CLAMP			1
4	23194210	BRACKET			2
5	36889608	SCREW			4
6	35279025	SCREW			6
7	35370386	ELBOW			1
8	35356484	TUBE, NYLON	(0,77m long)		1
9	35356484	TUBE, NYLON	(0,92m long)		1
10	35141423	HOSE ASSEMBLY			1
11	54761630	BRACKET			1
12	35256122	HOSE ASSEMBLY			1
13	92398114	NUT			4
14	95944740	ELBOW			2
15	23272420	AFTERCOOLER			1
16	35114545	TEE			1
17	35369347	CONNECTOR			2
18	96702279	SCREW			8
19	36879195	NUT			8
20	22218879	BRACKET			1
21	36895746	NUTSERT			2
22	22218861	BRACKET			1
23	35293687	ADAPTOR			1
24	95944575	NIPPLE			1
25	35322379	VALVE, BLOWDOWN			1
26	36766756	ORIFICE, SILENCER			1
27	35121763	HOSE ASSEMBLY			1
28	95946190	ELBOW			1
29	36786127	ELBOW			1
30	36920221	VALVE, CHECK			1

OPTION - AFTERCOOLER AND WATER SEPARATOR (CONT'D)




T4323_00
07/12

OPTION - AFTERCOOLER AND WATER SEPARATOR (CONT'D)

[illegible]

OPTION - AFTERCOOLER AND MOUNTING




T4324_00
07/12

OPTION - AFTERCOOLER AND MOUNTING

Item	Part Number	Description	Remarks	Serial Number	Qty
1	35256122	HOSE ASSEMBLY			1
2	95944740	ELBOW			2
3	23272420	AFTERCOOLER			1
4	96702279	SCREW			8
5	36879195	NUT			8
6	22218861	BRACKET			1
7	35279025	SCREW			2
8	35121763	HOSE ASSEMBLY			1
9	35293687	ADAPTOR			1
10	95944575	NIPPLE			1
11	35322379	VALVE, BLOWDOWN			1
12	36766756	ORIFICE, SILENCER			1
13	35369347	CONNECTOR			2
14	35356484	TUBE, NYLON	(640 mm long)		1
15	35114545	TEE			1
16	22218879	BRACKET			1
17	36889608	SCREW			2
18	36895746	NUTSERT			2
19	35141423	HOSE ASSEMBLY			1
20	36786127	ELBOW			1
21	36920221	VALVE, CHECK			1
22	95937462	BUSH			1
23	95932836	NIPPLE			1
24	36922987	VALVE			1
25	95946190	ELBOW			1

OPTION - IQ FILTER AND MOUNTING




T4325_00
07/12

OPTION - IQ FILTER AND MOUNTING

Item	Part Number	Description	Remarks	Serial Number	Qty
1	35356484	TUBE, NYLON	(153 mm long)		1
2	35356484	TUBE, NYLON	(204 mm long)		1
3	35356484	TUBE, NYLON	(381 mm long)		1
4	35356484	TUBE, NYLON	(711 mm long)		1
5	35356484	TUBE, NYLON	(889 mm long)		1
6	35369503	TEE			1
7	23272774	ELBOW	(7/170)		2
7	22225361	ELBOW	(10/125) (14/115)		2
8	35141423	HOSE ASSEMBLY			1
9	23193683	FILTER IQ, SECONDARY	(7/170)		1
9	23186752	FILTER IQ, SECONDARY	(10/125) (14/115)		1
10	23212509	ELEMENT, SECONDARY FILTER	(7/170)		1
10	23186018	ELEMENT, SECONDARY FILTER	(10/125) (14/115)		1
11	23187388	KIT, CLAMP			2
12	23187420	KIT, CLAMP			1
13	23193675	FILTER IQ, PRIMARY	(7/170)		1
13	23186737	FILTER IQ, PRIMARY	(10/125) (14/115)		1
14	23212491	ELEMENT, PRIMARY FILTER	(7/170)		1
14	23185994	ELEMENT, PRIMARY FILTER	(10/125) (14/115)		1
15	23193667	FILTER, WATER SEPARATOR	(7/170)		1
15	23186729	SEPARATOR, WATER	(10/125) (14/115)		1
16	39127287	TEE			1
17	95302170	ELBOW			1
18	35369396	TEE			1
19	35370386	ELBOW			3
20	23194210	BRACKET			2
21	35279025	SCREW			4
22	35379700	CONNECTOR			2
23	35283464	ELBOW			1
24	54761630	BRACKET			1
25	36889608	SCREW			4

OPTION - IQ FILTER AND MOUNTING (CONT'D)




T4325_00
07/12

OPTION - IQ FILTER AND MOUNTING (CONT'D)

[illegible]

OPTION - BRAKE LIGHTS WITH REVERSE LIGHT




T4326_00
07/12

OPTION - BRAKE LIGHTS WITH REVERSE LIGHT

Item	Part Number	Description	Remarks	Serial Number	Qty
1	92121250	LIGHT, FRONT SIDE			2
2	92085729	REFLECTOR, WHITE			2
3	22186811	POD, LH FRONT SIDE			1
4	92121243	REFLECTOR, AMBER			4
5	22186605	POD, LH REAR SIDE			1
6	35279025	SCREW			8
7	22186829	POD, RH FRONT SIDE			1
8	22186613	POD, RH REAR SIDE			1
9	54477740	HARNESS, FRONT SIDE			2
10	46501557	BAR ASSEMBLY, BUMPER / LIGHT			1
11	22173454	HARNESS, REAR BUMPER			1
12	92901230	LAMP, REGISTRATION PLATE			2
13	22073183	BRACKET			2
14	93477388	LAMP, FOG			1
15	92721331	REFLECTOR, RED			2
16	92901222	LAMP, TAIL/STOP/FLASH			2
17	92304583	WASHER			20
18	92304492	NUT			20
19	96705728	SCREW			4
20	96743265	SCREW			16
21	92271915	RIVET			10
22	96703756	NUT			4
23	96745237	WASHER			4
24	96705173	SCREW			4
25	96705165	WASHER			4
26	23212863	LAMP, REVERSE			1

OPTION - CENTRAL DRAINS




T4327_01
02/14

OPTION - CENTRAL DRAINS

Item	Part Number	Description	Remarks	Serial Number	Qty
1	36882355	SUPPORT			4
2	46569942	BRACKET			1
3	36879302	SCREW			2
4	36889608	SCREW			4
5	36881886	NUT			4
6	36888055	SCREW			8
7	35287747	CONNECTOR, BULKHEAD			5
8	95928040	NIPPLE			5
9	36777399	VALVE, BALL			5
10	95947149	PLUG			5
11	36885093	ELBOW			1
12	35323799	HOSE ASSEMBLY			1
13	22869143	ELBOW			1
14	35323807	HOSE ASSEMBLY			1
15	35287895	CONNECTOR			1
16	35305499	HOSE ASSEMBLY			1
17	35114081	CLAMP			10
18	35283134	CONNECTOR			1
19	35294750	ELBOW			1
20	35376110	HOSE ASSEMBLY			1
21	54629977	DECAL, ISO CENTRAL DRAIN			1
22	22198238	SUPPORT, FRONT			2
23	36879302	SCREW			4
24	35225085	CLAMP			3
25	35365774	ADAPTOR			2


OPTION - FULL GAUGE PANEL



OPTION - FULL GAUGE PANEL

Item	Part Number	Description	Remarks	Serial Number	Qty
1	54749601	FRAME, INSTRUMENT PANEL			1
2	22171680	PANEL, INSTRUMENT			1
3	22171698	DECAL			1
4	22054175	HOURLMETER			1
5	22054159	NUT, HOURLMETER			2
6	22127385	SWITCH, START			1
7	36891216	GAUGE, PRESSURE	(250 psi)		1
8	95935599	COUPLING			1
9	35370386	ELBOW			1
10	22134118	KNOB ASSEMBLY			1
11	22255046	GAUGE, 4 IN 1			1
12	22055883	TACHOMETER			1
13	22070494	SCREW			8
14	22692602	GAUGE, FUEL LEVEL	(24 V)		1
15	35367218	SENDER, TEMPERATURE			1
16	35372457	SENDER, TEMPERATURE			1
17	35278571	O-RING			1
18	22172423	MODULE, 2-LIGHT WARNING			1
19	95956199	ELBOW			1
20	36847838	SENSOR, AIR RESTRICTION			1
21	22251896	HARNESS, WIRING			1
22	39127287	TEE			1
23	22251904	HARNESS, AIR FILTER RESTRICTION			1
24	35278571	O-RING			1
25	36870608	SENSOR, OIL PRESSURE			1


OPTION - TACHOMETER PANEL



OPTION - TACHOMETER PANEL

[illegible]


OPTION - EXHAUST GRILLE



OPTION - EXHAUST GRILLE

[illegible]

OPTION - SPARK ARRESTOR




T4331_01
02/14

OPTION - SPARK ARRESTOR

[illegible]

OPTION - WHEEL CHOCKS





T4332_00
07/12

OPTION - WHEEL CHOCKS

[illegible]

**MAINTENANCE KIT
(500 hours)
(7/170)**










T4336_00
10/12

MAINTENANCE KIT (500 hours) (7/170)

[illegible]

**MAINTENANCE KIT
(500 hours)
(10/125 - 14/115)**











T4337_00
10/12

MAINTENANCE KIT (500 hours) (10/125 - 14/115)

[illegible]

**MAINTENANCE KIT
(1000 hours)
(7/170)**





T4338_00
10/12

MAINTENANCE KIT (1000 hours) (7/170)
--

[illegible]

**MAINTENANCE KIT
(1000 hours)
(10/125 - 14/115)**




T4338_00
10/12

MAINTENANCE KIT (1000 hours) (10/125 - 14/115)
--

[illegible]

FLUIDS



T2591_01
07/12


FLUIDS

[illegible]


AIR DELIVERY HOSE

This range of air delivery hose is readily available in the two most commonly used sizes of 3/4" and 1" I/D, in three lengths; 15m (50') complete with fittings, 4m (13') complete with fittings and random lengths. Please note the CPN given for the random lengths is a per metre measurement, therefore when ordering please specify the number of metres required.

The chart is by no means exhaustive, additional sizes or fitted lengths can be made available on request to suit your individual needs. Similarly the chart only gives details of air delivery hose at 15.5 bar (225 psi) working pressures. Should you require higher working pressures or different types of hose please contact Portable Power Aftermarket, via your normal channels.



Hose
I.D.: 19 mm (3/4")
O.D.: 30 mm
Working pressure: 15.5 bar (225 psi)
Burst pressure: 46.54 bar (675 psi)
Weight: 0.580 kg/m




Hose
I.D.: 25 mm (1")
O.D.: 36 mm
Working pressure: 15.5 bar (225 psi)
Burst pressure: 46.54 bar (675 psi)
Weight: 0.830 kg/m

T2593_00
02/11

AIR DELIVERY HOSE

[illegible]

AIR HOSE FITTINGS



Some air tools are manufactured with an integral oil supply built into the handle. In cases where no such supply exists a lubricator installed within the air line ensures that air tools operate at peak efficiency and reduce costly repair and downtime.




The lubricator should be located as near to the tool as possible but satisfactory lubrication will be provided if installed as far away as 25ft (7.62m). Immediately upon operation of an air tool a fog of oil is automatically injected into the air stream and lubrication of the tool will continue as long as there is oil in the lubricator.

The oil supply, which is adjustable, is easily checked through the pressure proof window, and refilling is made simple by use of a large filler cap. Whenever the cap is removed it automatically vents the reservoir pressure allowing refilling without shutting down the air supply.

T2594_01
07/12

[illegible]

SERVICE TOOLS






T2595_01
08/12

SERVICE TOOLS

Item	Part Number	Description	Remarks	Serial Number	Qty
1	22216691	DIGITAL MULTIMETER	(fluke 87)		1
1	22216733	METER CASE, FLUKE			1
1	22216709	TEST LEAD SET, FLUKE			1
1	22216725	WIRE INSULATION PIERCING PROBE, FLUKE			1
2	22147540	KIT, TEST ADAPTERS			1
2	22146393	KIT, DEUTSCH TERMINAL REMOVAL TOOL	(size 20 through 8)		1
3	22281588	WRENCH, T- HANDLE HEX	5/32"		1
3	22282107	SCREW DRIVER, HEX	5/32"		1
3	22282172	FLEX DRIVER	3/4"		1
3	54740675	SERIAL CABLE, HEAVY DUTY	RS232		1
3	54699640	DEUTCH TERMINAL REMOVAL	tool size 20		1
3	54699632	DEUTCH TERMINAL REMOVAL	size 16		1
3	46490942	DEUTCH TERMINAL REMOVAL	size 14		1
3	54699624	DEUTCH TERMINAL REMOVAL	size 12		1
3	54699616	DEUTCH TERMINAL REMOVAL	size 8		1
3	54699657	DEUTCH WEDGELOCK AND TERMINAL REMOVAL TOOL			1
3	22216667	DEUTSCH TERMINAL CRIMP TOOL			1
3	54729660	PACKARD WEATHER- PACK TERMINAL REMOVAL TOOL			1
3	54749643	PACKARD METRI- PACK TERMINAL REMOVAL TOOL			1
3	46490959	PACKARD METRI- PACK TERMINAL REMOVAL TOOL			1
3	22254734	PACKARD WEATHER- PACK TERMINAL CRIMP TOOL			1
3	22216683	PACKARD METRI- PACK TERMINAL CRIMP TOOL			1
3	22255974	PACKARD METRI- PACK TERMINAL CRIMP TOOL			1
3	46490967	PACKARD METRI- PACK TERMINAL CRIMP TOOL			1
3	46490975	PACKARD METRI- PACK TERMINAL CRIMP TOOL			1
3	54749544	RTD SIMULATOR			1
3	54749551	THERMISTOR SIMULATOR			1
3	22073878	THERMISTOR SIMULATOR			1
3	22168868	PRESSURE TRANSDUCER SIMULATOR			1
3	54729710	ELECTRICAL CONTACT CLEANER			1
3	22409114	ELECTRICAL GREASE			1


SERVICE TOOLS (CONT'D)



T2595_01
08/12

[illegible][illegible]

CONNECTOR REPAIR KITS



[illegible]

NUMERICAL INDEX

Part Number	Denomination	WAS	Page	Subgroup
			137	ALTERNATOR
18963595	SCREW		129	FAN DRIVE
			141	FINAL FUEL FILTER
18963819	SCREW		151	OIL COOLER
18964932	WHEEL		153	SENSORS
18965079	HOUSING, FLYWHEEL		113	FLYWHEEL HOUSING
18969410	SCREW		119	FUEL INJECTION PUMP, CONTROLLER AND
			125	THERMOSTAT
			139	ALTERNATOR MOUNTING
18969428	SCREW		123	WATER PUMP
			131	BELT TENSIONER
22050393	COVER		3	RUNNING GEAR
22050553	LIGHT, WARNING MODULE		47	INSTRUMENT PANEL
22051429	COLLAR		9	RUNNING GEAR
22051494	NUT		3	RUNNING GEAR
			9	RUNNING GEAR
22051510	COVER		9	RUNNING GEAR
22051544	JOINT		3	RUNNING GEAR
			9	RUNNING GEAR
22051551	BUSH		9	RUNNING GEAR
22051577	NUT		3	RUNNING GEAR
			9	RUNNING GEAR
			13	RUNNING GEAR
22051833	LEVER, HANDBRAKE		5	RUNNING GEAR
22051841	CABLE		5	RUNNING GEAR
22054076	SWITCH, ROCKER		47	INSTRUMENT PANEL
22054159	NUT, HOURMETER		47	INSTRUMENT PANEL
			173	OPTION - FULL GAUGE PANEL
22054175	HOURMETER		47	INSTRUMENT PANEL
			173	OPTION - FULL GAUGE PANEL
22055719	TUBE, SERVICE		73	HA SERVICE AIR
22055735	TUBE, BOTTOM SERVICE		73	HA SERVICE AIR
22055883	TACHOMETER		173	OPTION - FULL GAUGE PANEL
			175	OPTION - TACHOMETER PANEL
22058101	BRACKET, FRONT INTAKE		33	DOOR AND BAFFLE ENCLOSURE
22058119	BAFFLE, FRONT INTAKE		33	DOOR AND BAFFLE ENCLOSURE
22058325	COVER, REAR INSTRUMENT		47	INSTRUMENT PANEL
22058333	GUARD, TOOLBOX		29	FRAME
			181	OPTION - WHEEL CHOCKS
22058556	HOSE, STR-BELLOWS		93	COOLER PIPING
22060073	TUBE ASSEMBLY		75	SEPARATOR TANK PIPING
22062335	DECAL, SOUND POWER		39	DECALS & DOCUMENTATION
			41	DECALS & DOCUMENTATION
22066823	LEVER, HANDBRAKE		13	RUNNING GEAR
22067714	CLAMP		99	AIR INTAKE AND FILTER MOUNTING
22068373	SEAL		33	DOOR AND BAFFLE ENCLOSURE
22070494	SCREW		47	INSTRUMENT PANEL

Part Number	Denomination	WAS	Page	Subgroup
22073183	BRACKET		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
22073878	THERMISTOR SIMULATOR		197	SERVICE TOOLS
22094239	FOAM		35	FOAM INSULATION EXTERIOR
22094270	FOAM		35	FOAM INSULATION EXTERIOR
22094288	FOAM		35	FOAM INSULATION EXTERIOR
22094296	FOAM		35	FOAM INSULATION EXTERIOR
22094304	FOAM		35	FOAM INSULATION EXTERIOR
22094452	FOAM		35	FOAM INSULATION EXTERIOR
22095079	FOAM		35	FOAM INSULATION EXTERIOR
22095129	FOAM		35	FOAM INSULATION EXTERIOR
22096515	FOAM		37	FOAM INSULATION INTERIOR
22096523	FOAM		37	FOAM INSULATION INTERIOR
22096531	FOAM		35	FOAM INSULATION EXTERIOR
22096598	FOAM		35	FOAM INSULATION EXTERIOR
22107478	HINGE, SPRING CONTROL P		47	INSTRUMENT PANEL
22109011	PANEL, TOOLBOX SMALL		29	FRAME
22111686	RUNNING GEAR ASSEMBLY		17	DRAWBAR MOUNTING
22111694	RUNNING GEAR ASSEMBLY		17	DRAWBAR MOUNTING
22111975	ELEMENT, SEPARATOR		75 187 189	SEPARATOR TANK PIPING MAINTENANCE KIT MAINTENANCE KIT
22112478	BAFFLE, INTAKE		31	ROOF AND SIDE ENCLOSURE
22119150	BODY		103	AIR CLEANER ASSEMBLY
22119168	ELEMENT, AIR FILTER		103 183 187	AIR CLEANER ASSEMBLY MAINTENANCE KIT MAINTENANCE KIT
22119176	ELEMENT, AIR FILTER		103 183 187	AIR CLEANER ASSEMBLY MAINTENANCE KIT MAINTENANCE KIT
22119184	COVER ASSEMBLY		103	AIR CLEANER ASSEMBLY
22119192	FILTER ASSEMBLY		97	AIR INTAKE AND FILTER MOUNTING
22124093	GUARD, FAN		91	COOLER MOUNTING
22127385	SWITCH, START		47 173	INSTRUMENT PANEL OPTION - FULL GAUGE PANEL
22134118	KNOB ASSEMBLY		47 173	INSTRUMENT PANEL OPTION - FULL GAUGE PANEL
22137426	BULB, LIGHT		47	INSTRUMENT PANEL
22144513	CLAMP		93	COOLER PIPING
22146393	KIT, DEUTSCH TERMINAL R		197	SERVICE TOOLS
22147540	KIT, TEST ADAPTERS		197	SERVICE TOOLS
22153530	TUBE, ENGINE EXHAUST		95	EXHAUST PIPING
22164842	FOAM		35	FOAM INSULATION EXTERIOR
22164859	FOAM		35	FOAM INSULATION EXTERIOR
22164867	FOAM		37	FOAM INSULATION INTERIOR
22168868	PRESSURE TRANSDUCER S		197	SERVICE TOOLS
22171680	PANEL, INSTRUMENT		47	INSTRUMENT PANEL

Part Number	Denomination	WAS	Page	Subgroup
			175	OPTION - TACHOMETER PANEL
22171698	DECAL		47	INSTRUMENT PANEL
			173	OPTION - FULL GAUGE PANEL
			175	OPTION - TACHOMETER PANEL
22172423	MODULE, 2-LIGHT WARNING		47	INSTRUMENT PANEL
			173	OPTION - FULL GAUGE PANEL
22173454	HARNESS, REAR BUMPER		51	BRAKE LIGHTS AND WIRING
			169	OPTION - BRAKE LIGHTS WITH REVERSE LI
22173579	MODULE, CONTROLLER		49	WEDGE CONTROLLER
22177588	EYE, TOWING		3	RUNNING GEAR
			9	RUNNING GEAR
			21	RUNNING GEAR
22177620	EYE, TOWING		3	RUNNING GEAR
			9	RUNNING GEAR
			21	RUNNING GEAR
22177687	EYE, TOWING		3	RUNNING GEAR
			9	RUNNING GEAR
			21	RUNNING GEAR
22182075	JOCKEY WHEEL ASSEMBLY		17	DRAWBAR MOUNTING
			21	RUNNING GEAR
22186605	POD, LH REAR SIDE		51	BRAKE LIGHTS AND WIRING
			169	OPTION - BRAKE LIGHTS WITH REVERSE LI
22186613	POD, RH REAR SIDE		51	BRAKE LIGHTS AND WIRING
			169	OPTION - BRAKE LIGHTS WITH REVERSE LI
22186811	POD, LH FRONT SIDE		51	BRAKE LIGHTS AND WIRING
			169	OPTION - BRAKE LIGHTS WITH REVERSE LI
22186829	POD, RH FRONT SIDE		51	BRAKE LIGHTS AND WIRING
			169	OPTION - BRAKE LIGHTS WITH REVERSE LI
22189302	CLAMP		93	COOLER PIPING
22189310	REDUCER		93	COOLER PIPING
22189591	TUBE, AIREND OIL		55	AIREND PIPING
22189609	TUBE, AIREND OIL		55	AIREND PIPING
22192132	BRACKET, SIDE PANEL		31	ROOF AND SIDE ENCLOSURE
22194674	PANEL		31	ROOF AND SIDE ENCLOSURE
22194682	PANEL		31	ROOF AND SIDE ENCLOSURE
22194690	PANEL, REAR		31	ROOF AND SIDE ENCLOSURE
22194708	RAIL, TOP SIDE		31	ROOF AND SIDE ENCLOSURE
22194716	PANEL, TOP		31	ROOF AND SIDE ENCLOSURE
22197776	BRACKET, WEDGE MOUNTI		49	WEDGE CONTROLLER
22198238	SUPPORT, FRONT		171	OPTION - CENTRAL DRAINS
22206148	ELEMENT, OIL FILTER		157	OIL FILTER
			183	MAINTENANCE KIT
			185	MAINTENANCE KIT
			187	MAINTENANCE KIT
			189	MAINTENANCE KIT
22206213	STARTER		135	STARTER MOTOR
22206387	FRAME		29	FRAME
22207013	PAN, FRONT BELLY		29	FRAME
22207021	PAN, REAR BELLY		29	FRAME
22207039	PAN, CENTER BELLY		29	FRAME

Part Number	Denomination	WAS	Page	Subgroup
22207823	EYE, TOWING		3 9 21	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22208334	ADAPTOR		73	HA SERVICE AIR
22215354	DECAL, WEDGE		49	WEDGE CONTROLLER
22216667	DEUTSCH TERMINAL CRIMP		197	SERVICE TOOLS
22216683	PACKARD METRI- PACK TER		197	SERVICE TOOLS
22216691	DIGITAL MULTIMETER		197	SERVICE TOOLS
22216709	TEST LEAD SET, FLUKE		197	SERVICE TOOLS
22216725	WIRE INSULATION PIERCIN		197	SERVICE TOOLS
22216733	METER CASE, FLUKE		197	SERVICE TOOLS
22217848	MINIMUM PRESSURE VALVE		71 73	MINIMUM PRESSURE VALVE HA SERVICE AIR
22218424	BODY, MINIMUM PRESSURE		71	MINIMUM PRESSURE VALVE
22218432	CAP		71	MINIMUM PRESSURE VALVE
22218457	SPRING		71	MINIMUM PRESSURE VALVE
22218622	KIT, SERVICE MPV		71	MINIMUM PRESSURE VALVE
22218861	BRACKET		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
22218879	BRACKET		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
22221022	STRAP, FUEL TANK		105	FUEL TANK
22221030	STRAP, FUEL TANK		105	FUEL TANK
22222574	SENSOR		153	SENSORS
22222582	SENSOR, ENGINE SPEED		153	SENSORS
22222590	SENSOR, COOLANT TEMPE		153	SENSORS
22225361	ELBOW		165	OPTION - IQ FILTER AND MOUNTING
22227086	FOAM		37	FOAM INSULATION INTERIOR
22227425	PANEL		31	ROOF AND SIDE ENCLOSURE
22227433	PANEL		31	ROOF AND SIDE ENCLOSURE
22241152	CABLE		13	RUNNING GEAR
22241160	PIN		5 13	RUNNING GEAR RUNNING GEAR
22241178	BOLT		9	RUNNING GEAR
22241194	WASHER		5	RUNNING GEAR
22241350	BOLT		3 21	RUNNING GEAR RUNNING GEAR
22241368	SCREW		9	RUNNING GEAR
22241376	WASHER		5	RUNNING GEAR
22241400	NIPPLE		9	RUNNING GEAR
22241418	CABLE		13	RUNNING GEAR
22241483	CLEVIS		13	RUNNING GEAR
22241491	WASHER		5 13	RUNNING GEAR RUNNING GEAR
22241533	SCREW		9	RUNNING GEAR
22247340	ELBOW, DISCHARGE		55	AIREND PIPING
22250179	GUARD, BELT		89	ENGINE MOUNTING

Part Number	Denomination	WAS	Page	Subgroup
			13	RUNNING GEAR
22250369	SPRING		5	RUNNING GEAR
22250377	SPRING		5	RUNNING GEAR
22250401	TUBE		9	RUNNING GEAR
22250419	WASHER		5	RUNNING GEAR
22250443	COVER		9	RUNNING GEAR
22250450	TUBE		3	RUNNING GEAR
22250518	SLIDER		3	RUNNING GEAR
22250526	ARM ASSEMBLY		9	RUNNING GEAR
22250534	COUPLING		9	RUNNING GEAR
22250542	LEVER		9	RUNNING GEAR
22250559	DRAWBAR		9	RUNNING GEAR
22250567	CLAMP ASSEMBLY		9	RUNNING GEAR
22250575	COMPENSATOR		13	RUNNING GEAR
22250583	DRAWBAR		3	RUNNING GEAR
22250609	HUB ASSEMBLY		5	RUNNING GEAR
			13	RUNNING GEAR
22250625	CABLE		5	RUNNING GEAR
			13	RUNNING GEAR
22250765	SPRING		13	RUNNING GEAR
22250781	COMPENSATOR		5	RUNNING GEAR
22250807	BOLT		5	RUNNING GEAR
22250823	BOLT		9	RUNNING GEAR
22250849	ROD		5	RUNNING GEAR
			13	RUNNING GEAR
22250864	HANDLE		9	RUNNING GEAR
			21	RUNNING GEAR
22250897	SPRING		13	RUNNING GEAR
22250906	SPRING		13	RUNNING GEAR
22251227	DAMPER		9	RUNNING GEAR
22251243	DAMPER		3	RUNNING GEAR
22251250	HANDLE		9	RUNNING GEAR
22251292	SPRING		5	RUNNING GEAR
22251300	CLAMP		3	RUNNING GEAR
22251318	LEVER ASSEMBLY		5	RUNNING GEAR
22251326	LINK ASSEMBLY		9	RUNNING GEAR
22251359	PIN		3	RUNNING GEAR
22251367	BUSH		3	RUNNING GEAR
22251482	BOLT		3	RUNNING GEAR
22251483	CLEVIS		5	RUNNING GEAR
22251508	NUT		9	RUNNING GEAR
22251557	BOLT		9	RUNNING GEAR
22251573	CABLE		9	RUNNING GEAR
			13	RUNNING GEAR
22251896	HARNESS, WIRING		173	OPTION - FULL GAUGE PANEL
			175	OPTION - TACHOMETER PANEL
22251904	HARNESS, AIR FILTER REST		173	OPTION - FULL GAUGE PANEL

Part Number	Denomination	WAS	Page	Subgroup
22252050	XHP 605 COMPRESSOR OIL		191	FLUIDS
22252076	XHP 605 COMPRESSOR OIL		191	FLUIDS
22252100	XHP 405 COMPRESSOR OIL		191	FLUIDS
22252126	XHP 405 COMPRESSOR OIL		191	FLUIDS
22252969	KIT, WIRE TERMINAL REPAI		201	CONNECTOR REPAIR KITS
22252993	KIT, WEDGE CONNECTOR R		201	CONNECTOR REPAIR KITS
22253017	KIT, ADHESIVE LINED HEAT		201	CONNECTOR REPAIR KITS
22254734	PACKARD WEATHER- PACK		197	SERVICE TOOLS
22254775	KIT, FUSES ASSORTMENT O		201	CONNECTOR REPAIR KITS
22255046	GAUGE, 4 IN 1		173	OPTION - FULL GAUGE PANEL
22255974	PACKARD METRI- PACK TER		197	SERVICE TOOLS
22259345	SPACER		17	DRAWBAR MOUNTING
22259352	SPACER		17	DRAWBAR MOUNTING
22260038	STRAP, FUEL TANK		105	FUEL TANK
22281588	WRENCH, T- HANDLE HEX		197	SERVICE TOOLS
22282107	SCREW DRIVER, HEX		197	SERVICE TOOLS
22282172	FLEX DRIVER		197	SERVICE TOOLS
22293138	FOAM		35	FOAM INSULATION EXTERIOR
22293484	HARNESS		165	OPTION - IQ FILTER AND MOUNTING
22299747	VALVE, SAFETY		75	SEPARATOR TANK PIPING
22299754	VALVE, SAFETY		75	SEPARATOR TANK PIPING
22299762	VALVE, SAFETY		75	SEPARATOR TANK PIPING
22331912	TANK, SEPARATOR		75	SEPARATOR TANK PIPING
22357693	PIN		5	RUNNING GEAR
			13	RUNNING GEAR
22391858	CAP, GREASE NIPPLE		3	RUNNING GEAR
			9	RUNNING GEAR
22392153	CAP, DUST		5	RUNNING GEAR
			13	RUNNING GEAR
			21	RUNNING GEAR
22409114	ELECTRICAL GREASE		197	SERVICE TOOLS
22413876	BATTERY		45	BATTERY AND MOUNTING
22429609	FOAM		35	FOAM INSULATION EXTERIOR
22429625	FOAM		37	FOAM INSULATION INTERIOR
22429633	FOAM		37	FOAM INSULATION INTERIOR
22429658	FOAM		37	FOAM INSULATION INTERIOR
22429682	FOAM		35	FOAM INSULATION EXTERIOR
22429708	FOAM		35	FOAM INSULATION EXTERIOR
22429716	FOAM		35	FOAM INSULATION EXTERIOR
22429732	FOAM		37	FOAM INSULATION INTERIOR
22429740	FOAM		37	FOAM INSULATION INTERIOR
22429757	FOAM		37	FOAM INSULATION INTERIOR
22429765	BAFFLE, SEPARATOR TANK		33	DOOR AND BAFFLE ENCLOSURE
22431936	HOLD DOWN, BATTERY		45	BATTERY AND MOUNTING
22446744	CONNECTOR		73	HA SERVICE AIR
22477301	VALVE, BALL		73	HA SERVICE AIR

Part Number	Denomination	WAS	Page	Subgroup
22496079	MUFFLER		95	EXHAUST PIPING
22517502	CABLE, NEGATIVE		45	BATTERY AND MOUNTING
22573794	TUBE, EXHAUST		95	EXHAUST PIPING
22584791	WHEEL AND TYRE ASSEMB		13 17	RUNNING GEAR DRAWBAR MOUNTING
22584809	WHEEL		13	RUNNING GEAR
22584817	TYRE		13	RUNNING GEAR
22655708	REDUCER		179	OPTION - SPARK ARRESTOR
22658934	SPARK ARRESTOR		179	OPTION - SPARK ARRESTOR
22685481	ELBOW		77	SEPARATOR TANK SIGHT GLASS AND OIL F
22685499	ELBOW		77	SEPARATOR TANK SIGHT GLASS AND OIL F
22685507	INSERT, TUBE		77	SEPARATOR TANK SIGHT GLASS AND OIL F
22685523	TUBE, SIGHT GAUGE		77	SEPARATOR TANK SIGHT GLASS AND OIL F
22692602	GAUGE, FUEL LEVEL		47 173	INSTRUMENT PANEL OPTION - FULL GAUGE PANEL
22710719	PIPE, EXHAUST		95	EXHAUST PIPING
22712350	FAN		89	ENGINE MOUNTING
22715502	PANEL, EXHAUST GRILLE		177	OPTION - EXHAUST GRILLE
22746630	COVER, COOLER ACCESS		91	COOLER MOUNTING
22776090	SCREW		105	FUEL TANK
22808786	SCREW		147	FUEL LINES
22835680	HARNESS, PANEL WIRING		47	INSTRUMENT PANEL
22869143	ELBOW		171	OPTION - CENTRAL DRAINS
22872667	RADIATOR		91	COOLER MOUNTING
22872675	COOLER, OIL		91	COOLER MOUNTING
22872683	COOLER, CHARGE AIR		91	COOLER MOUNTING
22888200	CHANNEL, MOUNTING CHAR		91	COOLER MOUNTING
22890941	BAFFLE, COOLER		91	COOLER MOUNTING
22890958	BAFFLE, COOLER		91	COOLER MOUNTING
22890966	BAFFLE, RADIATOR TOP		91	COOLER MOUNTING
22890974	SHROUD, FAN		91	COOLER MOUNTING
22891618	HOSE, TOP RADIATOR		93	COOLER PIPING
22891626	HOSE, BOTTOM RADIATOR		93	COOLER PIPING
22891675	HOSE, ENGINE AIR INTAKE		97 99	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
22893622	HOSE, A/E AIR INTAKE		97	AIR INTAKE AND FILTER MOUNTING
22899171	HOSE		107	ROCKER ARM COVER
22915276	SUPPORT, OIL FILTER		69	OTBV AND OIL FILTER MOUNTING
22929095	SUPPORT, RADIATOR		91	COOLER MOUNTING
22939482	HOSE, A/E AIR INTAKE		99	AIR INTAKE AND FILTER MOUNTING
22959936	SCREW		95 105	EXHAUST PIPING FUEL TANK
22969257	ELEMENT, FUEL FILTER		141 183 185 187 189	FINAL FUEL FILTER MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT

Part Number	Denomination	WAS	Page	Subgroup
			143	PRIMARY FUEL FILTER
			183	MAINTENANCE KIT
			185	MAINTENANCE KIT
			187	MAINTENANCE KIT
			189	MAINTENANCE KIT
23013022	TUBE, OIL COOLER		69	OTBV AND OIL FILTER MOUNTING
			93	COOLER PIPING
23013030	TUBE, OIL COOLER		69	OTBV AND OIL FILTER MOUNTING
			93	COOLER PIPING
23017098	SHIM		119	FUEL INJECTION PUMP, CONTROLLER AND
23017189	SPACER		131	BELT TENSIONER
23017312	TUBE		125	THERMOSTAT
23017361	SCREW		133	EXHAUST MANIFOLD AND TURBOCHARGER
23017395	GASKET		133	EXHAUST MANIFOLD AND TURBOCHARGER
23017627	STUD		119	FUEL INJECTION PUMP, CONTROLLER AND
23018013	FITTING		147	FUEL LINES
23018492	RAIL		119	FUEL INJECTION PUMP, CONTROLLER AND
23018799	FILTER		141	FINAL FUEL FILTER
23019227	SEAL		125	THERMOSTAT
23019268	BRACKET		119	FUEL INJECTION PUMP, CONTROLLER AND
23019334	HOUSING, OIL COOLER		151	OIL COOLER
23019342	SEAL		125	THERMOSTAT
23019391	HOUSING, THERMOSTAT		125	THERMOSTAT
23019417	WASHER		147	FUEL LINES
23019458	SUPPORT, TENSIONER		131	BELT TENSIONER
23019482	MANIFOLD, EXHAUST		133	EXHAUST MANIFOLD AND TURBOCHARGER
23019490	O-RING		119	FUEL INJECTION PUMP, CONTROLLER AND
23019656	LINE, FUEL		147	FUEL LINES
23019714	LINE, FUEL		119	FUEL INJECTION PUMP, CONTROLLER AND
23019813	CAP		119	FUEL INJECTION PUMP, CONTROLLER AND
23019847	DEFLECTOR		107	ROCKER ARM COVER
23019854	TURBOCHARGER		133	EXHAUST MANIFOLD AND TURBOCHARGER
23019862	THERMOSTAT		125	THERMOSTAT
23019896	LINE, FUEL		147	FUEL LINES
23019920	LINE, TURBO DRAIN		133	EXHAUST MANIFOLD AND TURBOCHARGER
23056930	TUBE, CHARGE AIR LOWER		93	COOLER PIPING
23056948	TUBE, CHARGE AIR UPPER		93	COOLER PIPING
23056955	TUBE, CHARGE AIR BOTTO		93	COOLER PIPING
23060288	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23094170	V-BELT		129	FAN DRIVE
23110497	SCREW		133	EXHAUST MANIFOLD AND TURBOCHARGER
23110539	SCREW		107	ROCKER ARM COVER
			123	WATER PUMP
23110661	SCREW		109	OIL FILLER NECK
			123	WATER PUMP
23110984	SCREW		123	WATER PUMP
			151	OIL COOLER

Part Number	Denomination	WAS	Page	Subgroup
23116320	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116346	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116353	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116379	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116387	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116395	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116403	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116411	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23116429	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23127483	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23127509	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23137821	HOUSING, OTBV		67	OIL TEMPERATURE BYPASS VALVE
23137953	VALVE, TEMPERATURE BYP		69	OTBV AND OIL FILTER MOUNTING
23145360	SUPPORT, WIRE		65	UNLOADER MOUNTING
23179310	DAMPER		9	RUNNING GEAR
23181704	BULB		51	BRAKE LIGHTS AND WIRING
23185994	ELEMENT, PRIMARY FILTER		165	OPTION - IQ FILTER AND MOUNTING
23186018	ELEMENT, SECONDARY FIL		165	OPTION - IQ FILTER AND MOUNTING
23186729	SEPARATOR, WATER		159 165	OPTION - AFTERCOOLER AND WATER SEP OPTION - IQ FILTER AND MOUNTING
23186737	FILTER IQ, PRIMARY		165	OPTION - IQ FILTER AND MOUNTING
23186752	FILTER IQ, SECONDARY		165	OPTION - IQ FILTER AND MOUNTING
23187388	KIT, CLAMP		165	OPTION - IQ FILTER AND MOUNTING
23187420	KIT, CLAMP		159 165	OPTION - AFTERCOOLER AND WATER SEP OPTION - IQ FILTER AND MOUNTING
23193667	FILTER, WATER SEPARATO		159 165	OPTION - AFTERCOOLER AND WATER SEP OPTION - IQ FILTER AND MOUNTING
23193675	FILTER IQ, PRIMARY		165	OPTION - IQ FILTER AND MOUNTING
23193683	FILTER IQ, SECONDARY		165	OPTION - IQ FILTER AND MOUNTING
23194210	BRACKET		159 165	OPTION - AFTERCOOLER AND WATER SEP OPTION - IQ FILTER AND MOUNTING
23194970	PLATE, GAUGE		165	OPTION - IQ FILTER AND MOUNTING
23209273	MANUAL, PARTS CATALOGU		41	DECALS & DOCUMENTATION
23212491	ELEMENT, PRIMARY FILTER		165	OPTION - IQ FILTER AND MOUNTING
23212509	ELEMENT, SECONDARY FIL		165	OPTION - IQ FILTER AND MOUNTING
23212863	LAMP, REVERSE		169	OPTION - BRAKE LIGHTS WITH REVERSE LI
23229511	ALTERNATOR		137	ALTERNATOR
23229529	NUT		119	FUEL INJECTION PUMP, CONTROLLER AND
23229560	O-RING		109	OIL FILLER NECK
23229602	O-RING		119	FUEL INJECTION PUMP, CONTROLLER AND
23229636	CLAMP		119	FUEL INJECTION PUMP, CONTROLLER AND
23229776	SCREW		133	EXHAUST MANIFOLD AND TURBOCHARGER
23229792	SEAL		119	FUEL INJECTION PUMP, CONTROLLER AND
23229834	BRACKET		119	FUEL INJECTION PUMP, CONTROLLER AND
23229859	HOSE		133	EXHAUST MANIFOLD AND TURBOCHARGER
23229867	WASHER, SEALING		119	FUEL INJECTION PUMP, CONTROLLER AND

Part Number	Denomination	WAS	Page	Subgroup
23229925	HOSE		147	FUEL LINES
23229933	PLUG		157	OIL FILTER
23229941	FITTING		147	FUEL LINES
23229958	RESTRICTOR		119	FUEL INJECTION PUMP, CONTROLLER AND
23229966	VALVE, PRESSURE RELIEF		119	FUEL INJECTION PUMP, CONTROLLER AND
23229974	SENDER, FUEL TEMPERATU		119	FUEL INJECTION PUMP, CONTROLLER AND
23229982	PUMP, FUEL		145	FUEL TRANSFER PUMP
23229990	SENSOR		143	PRIMARY FUEL FILTER
23230014	SENSOR		119	FUEL INJECTION PUMP, CONTROLLER AND
23230030	LINE, FUEL		147	FUEL LINES
23230048	FITTING		147	FUEL LINES
23230063	FUEL FILTER ASSEMBLY		105 143	FUEL TANK PRIMARY FUEL FILTER
23230071	SCREW		119	FUEL INJECTION PUMP, CONTROLLER AND
23230089	THERMOCOUPLE		153	SENSORS
23230097	FITTING		147	FUEL LINES
23230113	CONTROLLER, ENGINE		119	FUEL INJECTION PUMP, CONTROLLER AND
23230121	LINE, FUEL		119	FUEL INJECTION PUMP, CONTROLLER AND
23230139	LINE, FUEL		119	FUEL INJECTION PUMP, CONTROLLER AND
23230147	LINE, FUEL		119	FUEL INJECTION PUMP, CONTROLLER AND
23230154	LINE, FUEL		119	FUEL INJECTION PUMP, CONTROLLER AND
23230162	SCREW		119	FUEL INJECTION PUMP, CONTROLLER AND
23230170	SCREW		119	FUEL INJECTION PUMP, CONTROLLER AND
23230188	NECK, FILLER		109	OIL FILLER NECK
23230212	BRACKET		109	OIL FILLER NECK
23230238	LINE, FUEL		147	FUEL LINES
23230279	KIT, INJECTOR UNIT		119	FUEL INJECTION PUMP, CONTROLLER AND
23230295	PLUG		125	THERMOSTAT
23230329	CLAMP		119	FUEL INJECTION PUMP, CONTROLLER AND
23236912	SCREW		109	OIL FILLER NECK
23236920	SCREW		131	BELT TENSIONER
23236938	ISOLATOR		109	OIL FILLER NECK
23236946	HARNESS, FUEL FILTER WI		143	PRIMARY FUEL FILTER
23236979	SCREW		111	CRANKSHAFT PULLEY
23237225	PLATE, DATA		41	DECALS & DOCUMENTATION
23239429	PLATE, DATA		41	DECALS & DOCUMENTATION
23240310	GUARD, DOOR EDGE		91	COOLER MOUNTING
23242779	BRACKET		93	COOLER PIPING
23251754	GUARD, BELT		89	ENGINE MOUNTING
23254865	COVER, VALVE		107	ROCKER ARM COVER
23254881	PULLEY		107	ROCKER ARM COVER
23254899	SHIELD, HEAT		107	ROCKER ARM COVER
23254907	PULLEY, CRANKSHAFT		111	CRANKSHAFT PULLEY
23254915	BUSH		111	CRANKSHAFT PULLEY
23254931	HARNESS, ENGINE FUEL WI		119	FUEL INJECTION PUMP, CONTROLLER AND

Part Number	Denomination	WAS	Page	Subgroup
23254956	SCREW		117	AIR INTAKE MANIFOLD
23254964	GASKET		127	OIL PAN
23254972	PAN, OIL		127	OIL PAN
23254980	COVER		125	THERMOSTAT
23254998	HARNESS, ENGINE WIRING		155	ENGINE WIRING HARNESS
23255383	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
23259187	CLAMP		179	OPTION - SPARK ARRESTOR
23259195	CLAMP		179	OPTION - SPARK ARRESTOR
23264096	CAP		91	COOLER MOUNTING
23272420	AFTERCOOLER		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
23272774	ELBOW		165	OPTION - IQ FILTER AND MOUNTING
23292949	FOAM		37	FOAM INSULATION INTERIOR
23292956	FOAM		37	FOAM INSULATION INTERIOR
23292964	FOAM		37	FOAM INSULATION INTERIOR
23294820	SENSOR, TEMPERATURE		55 75	AIREND PIPING SEPARATOR TANK PIPING
23346869	SUPPORT, AIR CLEANER		97 99	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
23365067	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
24898801	NUT		109 119 147	OIL FILLER NECK FUEL INJECTION PUMP, CONTROLLER AND FUEL LINES
24898843	SCREW		129 135 139	FAN DRIVE STARTER MOTOR ALTERNATOR MOUNTING
24898876	SCREW		125 129	THERMOSTAT FAN DRIVE
24898884	SCREW		137	ALTERNATOR
24898918	SCREW		107	ROCKER ARM COVER
24898926	SCREW		119 137	FUEL INJECTION PUMP, CONTROLLER AND ALTERNATOR
24898934	SCREW		127	OIL PAN
24898959	SCREW		127	OIL PAN
24899056	PIN, SPRING		131	BELT TENSIONER
24899080	SCREW		147	FUEL LINES
24899106	O-RING		147	FUEL LINES
24899247	FITTING		147	FUEL LINES
24899254	O-RING		147	FUEL LINES
24899304	SEAL		157	OIL FILTER
24899338	CONNECTION, WATER PUM		123	WATER PUMP
24899452	BRACKET		141	FINAL FUEL FILTER
24899478	O-RING		113	FLYWHEEL HOUSING
24899528	FITTING		147	FUEL LINES
24899536	SCREW		145	FUEL TRANSFER PUMP
24899551	HEAD, FILTER		157	OIL FILTER
24899577	HARNESS		137	ALTERNATOR

Part Number	Denomination	WAS	Page	Subgroup
24899882	LINE, FUEL		147	FUEL LINES
24899932	KIT, O-RING		141	FINAL FUEL FILTER
			143	PRIMARY FUEL FILTER
35060631	UNLOADER VALVE ASSEMB		65	UNLOADER MOUNTING
35103852	BUSH, CLUTCH		53	AIREND MOUNTING
35104108	SCREW, HEX HEAD		61	AIREND REAR BEARING HSG.ASSEMBLY
35108372	SCREW, SOCKET HEAD		57	AIREND GEAR CASE
35114081	CLAMP		171	OPTION - CENTRAL DRAINS
35114545	TEE		81	OIL/AIR PIPING
			159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
35116615	CLAMP		97	AIR INTAKE AND FILTER MOUNTING
35121763	HOSE ASSEMBLY		159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
			165	OPTION - IQ FILTER AND MOUNTING
35130707	HANDLE		31	ROOF AND SIDE ENCLOSURE
35134550	SCREW		45	BATTERY AND MOUNTING
35141423	HOSE ASSEMBLY		159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
			165	OPTION - IQ FILTER AND MOUNTING
35145408	CLAMP, SUPPORT		93	COOLER PIPING
35190487	BRACKET, TUBE CLAMP		93	COOLER PIPING
35210087	GASKET		57	AIREND GEAR CASE
35221639	CLIP, RETAINING		93	COOLER PIPING
35225085	CLAMP		171	OPTION - CENTRAL DRAINS
35225093	CLIP, RETAINING		45	BATTERY AND MOUNTING
35227909	TUBE ASSEMBLY		69	OTBV AND OIL FILTER MOUNTING
			75	SEPARATOR TANK PIPING
			87	OIL/AIR PIPING
35231455	HOSE ASSEMBLY		69	OTBV AND OIL FILTER MOUNTING
35248145	VALVE, CHECK		83	OIL/AIR PIPING
35253038	CLAMP		93	COOLER PIPING
35255827	PLATE, CLAMP		57	AIREND GEAR CASE
35256122	HOSE ASSEMBLY		159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
35256429	STUD		33	DOOR AND BAFFLE ENCLOSURE
35256445	WASHER, RETAINING		33	DOOR AND BAFFLE ENCLOSURE
35256452	RECEPTACLE		33	DOOR AND BAFFLE ENCLOSURE
35258789	CABLE		45	BATTERY AND MOUNTING
35262690	PLATE, CLAMP		61	AIREND REAR BEARING HSG.ASSEMBLY
35262716	SPACER		57	AIREND GEAR CASE
35269224	SPACER, BEARING		57	AIREND GEAR CASE
35270131	SPACER, BEARING		59	AIREND ROTOR HOUSING
35271162	SCREW		63	UNLOADER ASSEMBLY
35273366	NUT		105	FUEL TANK
35274711	MOUNTING, BAND		97	AIR INTAKE AND FILTER MOUNTING
35278555	PLUG, ADAPTER		55	AIREND PIPING

Part Number	Denomination	WAS	Page	Subgroup
			173	OPTION - FULL GAUGE PANEL
35278589	O-RING		55	AIREND PIPING
35279025	SCREW		29	FRAME
			31	ROOF AND SIDE ENCLOSURE
			51	BRAKE LIGHTS AND WIRING
			69	OTBV AND OIL FILTER MOUNTING
			73	HA SERVICE AIR
			91	COOLER MOUNTING
			97	AIR INTAKE AND FILTER MOUNTING
			99	AIR INTAKE AND FILTER MOUNTING
			159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
			165	OPTION - IQ FILTER AND MOUNTING
			169	OPTION - BRAKE LIGHTS WITH REVERSE LI
			181	OPTION - WHEEL CHOCKS
35279827	ELBOW		55	AIREND PIPING
35279843	TEE		55	AIREND PIPING
35279876	ELBOW		55	AIREND PIPING
35279942	O-RING		77	SEPARATOR TANK SIGHT GLASS AND OIL F
35279959	O-RING		55	AIREND PIPING
35282292	TUBING, TYGON		65	UNLOADER MOUNTING
35282920	HOSE ASSEMBLY		69	OTBV AND OIL FILTER MOUNTING
			85	OIL/AIR PIPING
35283134	CONNECTOR		171	OPTION - CENTRAL DRAINS
35283464	ELBOW		165	OPTION - IQ FILTER AND MOUNTING
35285162	GROMMET		93	COOLER PIPING
35286491	ELBOW		55	AIREND PIPING
35287747	CONNECTOR, BULKHEAD		171	OPTION - CENTRAL DRAINS
35287895	CONNECTOR		171	OPTION - CENTRAL DRAINS
35287945	BUSH, REDUCING		55	AIREND PIPING
35288422	BOLT		69	OTBV AND OIL FILTER MOUNTING
35290113	SCREW		29	FRAME
35292051	ELBOW		87	OIL/AIR PIPING
35292143	CLAMP		75	SEPARATOR TANK PIPING
			85	OIL/AIR PIPING
35293687	ADAPTOR		159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
35294750	ELBOW		171	OPTION - CENTRAL DRAINS
35296342	CLIP, RETAINING		93	COOLER PIPING
			105	FUEL TANK
35303429	GEAR SET		57	AIREND GEAR CASE
35305499	HOSE ASSEMBLY		171	OPTION - CENTRAL DRAINS
35305622	ELBOW		55	AIREND PIPING
35306661	HOSE ASSEMBLY		165	OPTION - IQ FILTER AND MOUNTING
35313303	CLAMP		95	EXHAUST PIPING
35313535	BEARING, CYLINDRICAL RO		59	AIREND ROTOR HOUSING
35313568	BEARING		57	AIREND GEAR CASE
35313600	SHIM, .002		61	AIREND REAR BEARING HSG.ASSEMBLY
35313618	SHIM, .003		61	AIREND REAR BEARING HSG.ASSEMBLY

Part Number	Denomination	WAS	Page	Subgroup
			99	AIR INTAKE AND FILTER MOUNTING
35316587	ADAPTOR, BARBED		65	UNLOADER MOUNTING
35317197	DIAPHRAGM		63	UNLOADER ASSEMBLY
35317205	WASHER, PISTON		63	UNLOADER ASSEMBLY
35317239	WASHER, PISTON		63	UNLOADER ASSEMBLY
35318005	BUSH, PISTON		63	UNLOADER ASSEMBLY
35318013	BUSH, HOUSING		63	UNLOADER ASSEMBLY
35318229	MOUNT		53	AIREND MOUNTING
35321595	SCREW		63	UNLOADER ASSEMBLY
35321603	SPRING		63	UNLOADER ASSEMBLY
35322379	VALVE, BLOWDOWN		83 159 163	OIL/AIR PIPING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
35322395	SILENCER, PNEUMATIC		105	FUEL TANK
35322767	SPRING, PISTON		63	UNLOADER ASSEMBLY
35323450	STUD		65	UNLOADER MOUNTING
35323542	ADAPTOR, UNLOADER		65	UNLOADER MOUNTING
35323799	HOSE ASSEMBLY		171	OPTION - CENTRAL DRAINS
35323807	HOSE ASSEMBLY		171	OPTION - CENTRAL DRAINS
35327212	WASHER		53 89	AIREND MOUNTING ENGINE MOUNTING
35332915	PIN, LOCATOR		59	AIREND ROTOR HOUSING
35335124	CONNECTOR		73	HA SERVICE AIR
35336304	SCREW, SOCKET HEAD CAP		57	AIREND GEAR CASE
35337328	STUD, BALL		33	DOOR AND BAFFLE ENCLOSURE
35354448	SHIM SET		61	AIREND REAR BEARING HSG.ASSEMBLY
35356484	TUBE, NYLON		79 81 83 105 159 163 165	OIL/AIR PIPING OIL/AIR PIPING OIL/AIR PIPING FUEL TANK OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING OPTION - IQ FILTER AND MOUNTING
35360775	TUBING		93	COOLER PIPING
35361328	KEY		57	AIREND GEAR CASE
35361849	GASKET		105	FUEL TANK
35363498	HOSE		105	FUEL TANK
35364306	LUBRICATOR, AIR LINE		195	AIR HOSE FITTINGS
35364314	LUBRICATOR, AIR LINE		195	AIR HOSE FITTINGS
35364322	LUBRICATOR, AIR LINE		195	AIR HOSE FITTINGS
35364769	SHIM, .010		61	AIREND REAR BEARING HSG.ASSEMBLY
35364975	KEY		53	AIREND MOUNTING
35365477	CLAMP		97	AIR INTAKE AND FILTER MOUNTING
35365774	ADAPTOR		171	OPTION - CENTRAL DRAINS
35367218	SENDER, TEMPERATURE		173	OPTION - FULL GAUGE PANEL
35367317	CV ASSEMBLY		71	MINIMUM PRESSURE VALVE
35367325	PISTON		71	MINIMUM PRESSURE VALVE

Part Number	Denomination	WAS	Page	Subgroup
35367374	O-RING		71	MINIMUM PRESSURE VALVE
35367846	ADAPTOR		81	OIL/AIR PIPING
35369313	STEP, FOLDING		31	ROOF AND SIDE ENCLOSURE
35369339	CONNECTOR		105	FUEL TANK
35369347	CONNECTOR		81	OIL/AIR PIPING
			105	FUEL TANK
			159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
			165	OPTION - IQ FILTER AND MOUNTING
35369354	ELBOW		81	OIL/AIR PIPING
			83	OIL/AIR PIPING
35369396	TEE		165	OPTION - IQ FILTER AND MOUNTING
35369503	TEE		79	OIL/AIR PIPING
			83	OIL/AIR PIPING
			165	OPTION - IQ FILTER AND MOUNTING
35370386	ELBOW		47	INSTRUMENT PANEL
			159	OPTION - AFTERCOOLER AND WATER SEP
			165	OPTION - IQ FILTER AND MOUNTING
			173	OPTION - FULL GAUGE PANEL
35371103	LUBRICATOR, AIR LINE		195	AIR HOSE FITTINGS
35371111	LUBRICATOR, AIR LINE		195	AIR HOSE FITTINGS
35371129	LUBRICATOR, AIR LINE		195	AIR HOSE FITTINGS
35372457	SENDER, TEMPERATURE		173	OPTION - FULL GAUGE PANEL
35374073	CLAMP		97	AIR INTAKE AND FILTER MOUNTING
			99	AIR INTAKE AND FILTER MOUNTING
35375591	SCREW		17	DRAWBAR MOUNTING
			53	AIREND MOUNTING
35376110	HOSE ASSEMBLY		171	OPTION - CENTRAL DRAINS
35377621	CLAMP, SPRING		65	UNLOADER MOUNTING
35379064	KIT, REPAIR		83	OIL/AIR PIPING
35379700	CONNECTOR		165	OPTION - IQ FILTER AND MOUNTING
35384577	BUSH		105	FUEL TANK
35393677	VALVE, DUST EJECTOR		101	AIR CLEANER ASSEMBLY
35393719	CAP, PLUG		101	AIR CLEANER ASSEMBLY
35393990	HOSE		193	AIR DELIVERY HOSE
35504364	CAP, RAIN		95	EXHAUST PIPING
35518497	GASKET, FRONT BEARING H		59	AIREND ROTOR HOUSING
35573070	PLATE, RETAINING		57	AIREND GEAR CASE
35575570	GASKET, AIREND DISCHAR		55	AIREND PIPING
35579630	PLUG		77	SEPARATOR TANK SIGHT GLASS AND OIL F
35581792	VALVE, BALL		73	HA SERVICE AIR
35583582	CABLE		45	BATTERY AND MOUNTING
35588193	PISTON, UNLOADER		63	UNLOADER ASSEMBLY
35588300	GASKET, PISTON		63	UNLOADER ASSEMBLY
35588318	GASKET, UNLOADER INLET		65	UNLOADER MOUNTING
35589589	GASKET, UNLOADER TO AIR		65	UNLOADER MOUNTING
35591122	VALVE, UNLOADER		63	UNLOADER ASSEMBLY
35592757	COVER, OIL SEAL		57	AIREND GEAR CASE

Part Number	Denomination	WAS	Page	Subgroup
35600261	SPRING		33	DOOR AND BAFFLE ENCLOSURE
35601517	BEARING, BALL		57	AIREND GEAR CASE
35607829	BOLT, EYE		33	DOOR AND BAFFLE ENCLOSURE
35607837	SPRING		33	DOOR AND BAFFLE ENCLOSURE
35609361	BEARING, CYLINDRICAL RO		59	AIREND ROTOR HOUSING
35833227	HOUSING, PISTON		63	UNLOADER ASSEMBLY
35834787	COUPLING, CLUTCH		53	AIREND MOUNTING
35843168	FLANGE, UNLOADER INLET		65	UNLOADER MOUNTING
35857036	CAP, RAIN		179	OPTION - SPARK ARRESTOR
35996164	CASE, GEAR		57	AIREND GEAR CASE
36008241	ROTOR SET		59	AIREND ROTOR HOUSING
36010643	AIREND ASSEMBLY		55	AIREND PIPING
36011534	AIREND ASSEMBLY		55	AIREND PIPING
36011567	VALVE ASSEMBLY, UNLOAD		63	UNLOADER ASSEMBLY
36018042	AIREND ASSEMBLY		55	AIREND PIPING
36100154	NUT		117	AIR INTAKE MANIFOLD
36100188	NUT		123 133 137 139	WATER PUMP EXHAUST MANIFOLD AND TURBOCHARGER ALTERNATOR ALTERNATOR MOUNTING
36101962	PLUG		147	FUEL LINES
36102838	RING, SNAP		129	FAN DRIVE
36102929	PLUG		107	ROCKER ARM COVER
36103182	ADAPTOR		133	EXHAUST MANIFOLD AND TURBOCHARGER
36103232	BUSH		139	ALTERNATOR MOUNTING
36103828	SLEEVE		129	FAN DRIVE
36104602	COVER		109	OIL FILLER NECK
36105062	ELBOW		107	ROCKER ARM COVER
36105245	PULLEY		123	WATER PUMP
36105252	PLATE		113	FLYWHEEL HOUSING
36106060	SEAL		123 125	WATER PUMP THERMOSTAT
36106102	O-RING		145	FUEL TRANSFER PUMP
36106177	CLAMP		125	THERMOSTAT
36106250	GASKET		123	WATER PUMP
36106607	GASKET		151	OIL COOLER
36106615	GASKET		151	OIL COOLER
36106748	GASKET		133	EXHAUST MANIFOLD AND TURBOCHARGER
36106755	GASKET		133	EXHAUST MANIFOLD AND TURBOCHARGER
36106763	NUT		107	ROCKER ARM COVER
36106771	O-RING		107	ROCKER ARM COVER
36106821	NUT		147	FUEL LINES
36107480	PULLEY, FAN		129	FAN DRIVE
36107787	TUBE, DIPSTICK		149	DIPSTICK
36108009	PLUG		113	FLYWHEEL HOUSING
36108066	STRAP		139	ALTERNATOR MOUNTING

Part Number	Denomination	WAS	Page	Subgroup
36108371	PIN		145	FUEL TRANSFER PUMP
36108579	BOLT		113	FLYWHEEL HOUSING
36108595	GASKET		109	OIL FILLER NECK
36108819	GEAR, RING		115	FLYWHEEL
36108918	FITTING		113	FLYWHEEL HOUSING
36109932	O-RING		127	OIL PAN
36110054	O-RING		133	EXHAUST MANIFOLD AND TURBOCHARGER
36110112	WASHER		137	ALTERNATOR
36110385	O-RING		107	ROCKER ARM COVER
36111425	O-RING		123	WATER PUMP
36111912	TEE, FITTING		147	FUEL LINES
36114015	SEAL		113	FLYWHEEL HOUSING
36114072	PLUG		117	AIR INTAKE MANIFOLD
			125	THERMOSTAT
36114080	PLUG, FITTING		123	WATER PUMP
			151	OIL COOLER
36114098	PLUG		125	THERMOSTAT
			147	FUEL LINES
			151	OIL COOLER
36114106	PLUG, DRAIN		123	WATER PUMP
			127	OIL PAN
36114445	KIT, SEAL		141	FINAL FUEL FILTER
			143	PRIMARY FUEL FILTER
36114486	PULLEY, IDLE		129	FAN DRIVE
36114536	KIT, SEAL		141	FINAL FUEL FILTER
			143	PRIMARY FUEL FILTER
36114544	BOWL, SEDIMENT		143	PRIMARY FUEL FILTER
36115251	COOLER, OIL		151	OIL COOLER
36116036	SEAL		123	WATER PUMP
36116242	ADAPTOR		147	FUEL LINES
36116648	KIT, VALVE		141	FINAL FUEL FILTER
36117885	CLAMP		133	EXHAUST MANIFOLD AND TURBOCHARGER
36118131	SCREW		151	OIL COOLER
36118149	SCREW		109	OIL FILLER NECK
			151	OIL COOLER
36118693	O-RING		151	OIL COOLER
36118750	CLAMP		147	FUEL LINES
36119808	O-RING		133	EXHAUST MANIFOLD AND TURBOCHARGER
			147	FUEL LINES
36124899	DIPSTICK		149	DIPSTICK
36125276	GASKET		117	AIR INTAKE MANIFOLD
36126019	O-RING		125	THERMOSTAT
			147	FUEL LINES
			151	OIL COOLER
36128916	O-RING		117	AIR INTAKE MANIFOLD
			125	THERMOSTAT
			147	FUEL LINES
			153	SENSORS
36133403	O-RING		123	WATER PUMP

Part Number	Denomination	WAS	Page	Subgroup
36136125	KIT, INSERT		123	WATER PUMP
36136869	TENSIONER, BELT		131	BELT TENSIONER
36137461	MANIFOLD, AIR INTAKE		117	AIR INTAKE MANIFOLD
36137586	BRACKET		147	FUEL LINES
36138006	PUMP		119	FUEL INJECTION PUMP, CONTROLLER AND
36500832	COVER, REAR BEARING		61	AIREND REAR BEARING HSG.ASSEMBLY
36751659	GEAR SET		57	AIREND GEAR CASE
36751667	GEAR SET		57	AIREND GEAR CASE
36764785	CAP, GUIDE		57	AIREND GEAR CASE
36766756	ORIFICE, SILENCER		83 159 163	OIL/AIR PIPING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
36769404	HOUSING, REAR BEARING		61	AIREND REAR BEARING HSG.ASSEMBLY
36772028	WASHER		33	DOOR AND BAFFLE ENCLOSURE
36777399	VALVE, BALL		171	OPTION - CENTRAL DRAINS
36780906	SHAFT, DRIVE		57	AIREND GEAR CASE
36782019	ELEMENT, THERMOSTATIC		67	OIL TEMPERATURE BYPASS VALVE
36783488	STRAP, GROUND		45	BATTERY AND MOUNTING
36785012	BRACKET		75	SEPARATOR TANK PIPING
36786127	ELBOW		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
36788172	SEAL		67	OIL TEMPERATURE BYPASS VALVE
36793602	LATCH		33	DOOR AND BAFFLE ENCLOSURE
36794816	RIVET		33	DOOR AND BAFFLE ENCLOSURE
36795482	TUBE ASSEMBLY		55	AIREND PIPING
36797652	SCREW		29 31 33 91 93 97 99 165 177	FRAME ROOF AND SIDE ENCLOSURE DOOR AND BAFFLE ENCLOSURE COOLER MOUNTING COOLER PIPING AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING OPTION - IQ FILTER AND MOUNTING OPTION - EXHAUST GRILLE
36798205	GUARD, GEAR CASE		57	AIREND GEAR CASE
36840411	VALVE, CHECK		85	OIL/AIR PIPING
36840841	VALVE, SOLENOID		81 83	OIL/AIR PIPING OIL/AIR PIPING
36842102	SCREW		49 105	WEDGE CONTROLLER FUEL TANK
36845154	MANIFOLD, OIL		55 87	AIREND PIPING OIL/AIR PIPING
36845600	TANK, HEADER		93	COOLER PIPING
36846087	TUBE, BEARING OIL SUPPL		55	AIREND PIPING
36846095	CONNECTOR, O-RING		55	AIREND PIPING
36846103	TUBE, BEARING OIL SCAVE		55	AIREND PIPING
36846111	TUBE ASSEMBLY		55	AIREND PIPING
36846129	TEE		55	AIREND PIPING
36847838	SENSOR, AIR RESTRICTION		173	OPTION - FULL GAUGE PANEL

Part Number	Denomination	WAS	Page	Subgroup
36849453	BODY, UNLOADER		63	UNLOADER ASSEMBLY
36849461	COVER, PISTON		63	UNLOADER ASSEMBLY
36853265	WASHER		45	BATTERY AND MOUNTING
36853521	RELAY, STARTER / AIR PRE		97 99	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
36860005	J-BOLT		45	BATTERY AND MOUNTING
36867778	VALVE		103	AIR CLEANER ASSEMBLY
36870608	SENSOR, OIL PRESSURE		173	OPTION - FULL GAUGE PANEL
36876779	COVER, OTBV		67	OIL TEMPERATURE BYPASS VALVE
36877587	RIVET		47	INSTRUMENT PANEL
36877793	SCREW		73	HA SERVICE AIR
36878064	TRAY, BATTERY		45	BATTERY AND MOUNTING
36879195	NUT		97 159 163	AIR INTAKE AND FILTER MOUNTING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
36879302	SCREW		171	OPTION - CENTRAL DRAINS
36879492	SCREW		29 91	FRAME COOLER MOUNTING
36880623	COVER, FLEXIBLE ACCESS		29	FRAME
36880995	SCREW		55 89	AIREND PIPING ENGINE MOUNTING
36881175	CLAMP, EXHAUST		95	EXHAUST PIPING
36881886	NUT		31 33 49 69 91 93 105 165 171	ROOF AND SIDE ENCLOSURE DOOR AND BAFFLE ENCLOSURE WEDGE CONTROLLER OTBV AND OIL FILTER MOUNTING COOLER MOUNTING COOLER PIPING FUEL TANK OPTION - IQ FILTER AND MOUNTING OPTION - CENTRAL DRAINS
36882355	SUPPORT		171	OPTION - CENTRAL DRAINS
36885093	ELBOW		171	OPTION - CENTRAL DRAINS
36888055	SCREW		29 75 171	FRAME SEPARATOR TANK PIPING OPTION - CENTRAL DRAINS
36889608	SCREW		49 89 91 105 159 163 165 171	WEDGE CONTROLLER ENGINE MOUNTING COOLER MOUNTING FUEL TANK OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING OPTION - IQ FILTER AND MOUNTING OPTION - CENTRAL DRAINS
36891216	GAUGE, PRESSURE		47 165 173	INSTRUMENT PANEL OPTION - IQ FILTER AND MOUNTING OPTION - FULL GAUGE PANEL
36892669	BRACKET, SOLENOID		79	OIL/AIR PIPING
36895746	NUTSERT		31 89 91 159	ROOF AND SIDE ENCLOSURE ENGINE MOUNTING COOLER MOUNTING OPTION - AFTERCOOLER AND WATER SEP

Part Number	Denomination	WAS	Page	Subgroup
36897346	ELEMENT, OIL FILTER		69	OTBV AND OIL FILTER MOUNTING
			87	OIL/AIR PIPING
			183	MAINTENANCE KIT
			185	MAINTENANCE KIT
			187	MAINTENANCE KIT
			189	MAINTENANCE KIT
36897437	HEAD, OIL FILTER		69	OTBV AND OIL FILTER MOUNTING
			87	OIL/AIR PIPING
36897668	CLAMP		97	AIR INTAKE AND FILTER MOUNTING
			99	AIR INTAKE AND FILTER MOUNTING
36899615	INDICATOR		165	OPTION - IQ FILTER AND MOUNTING
36920114	WASHER		137	ALTERNATOR
36920221	VALVE, CHECK		159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
36920486	RIVET		47	INSTRUMENT PANEL
36920825	TRANSDUCER, PRESSURE		81	OIL/AIR PIPING
36922987	VALVE		159	OPTION - AFTERCOOLER AND WATER SEP
			163	OPTION - AFTERCOOLER AND MOUNTING
39127287	TEE		165	OPTION - IQ FILTER AND MOUNTING
			173	OPTION - FULL GAUGE PANEL
39435441	PLATE, CLAMP		61	AIREND REAR BEARING HSG.ASSEMBLY
39437595	BEARING, TAPERED ROLLE		61	AIREND REAR BEARING HSG.ASSEMBLY
39437629	GASKET, REAR BEARING H		59	AIREND ROTOR HOUSING
39437637	GASKET		57	AIREND GEAR CASE
39703921	HOUSING, FRONT BEARING		59	AIREND ROTOR HOUSING
39748942	HOUSING, ROTOR		59	AIREND ROTOR HOUSING
43208511	SUPPORT, AIREND		53	AIREND MOUNTING
46490942	DEUTCH TERMINAL REMOV		197	SERVICE TOOLS
46490959	PACKARD METRI- PACK TER		197	SERVICE TOOLS
46490967	PACKARD METRI- PACK TER		197	SERVICE TOOLS
46490975	PACKARD METRI- PACK TER		197	SERVICE TOOLS
46490983	KIT, DEUTSCH CONNECTOR		201	CONNECTOR REPAIR KITS
46491296	KIT, PACKARD CONNECTOR		201	CONNECTOR REPAIR KITS
46491304	KIT, CATERPILLAR C9, C15,		201	CONNECTOR REPAIR KITS
46491312	KIT, OTC AND AUTOSTART		201	CONNECTOR REPAIR KITS
46491320	AMP AMPSEAL TERMINAL C		197	SERVICE TOOLS
46491338	MOLEX 1.5 TERMINAL CRIM		197	SERVICE TOOLS
46491346	MOLEX 0.6 TERMINAL CRIM		197	SERVICE TOOLS
46491361	MOLEX 0.6 TERMINAL REMO		197	SERVICE TOOLS
46491411	KIT, JOHN DEERE AND YAN		201	CONNECTOR REPAIR KITS
46491429	KIT, CUMMINS QSX15 ENGIN		201	CONNECTOR REPAIR KITS
46491502	KIT, SECU AND REMOTE CO		201	CONNECTOR REPAIR KITS
46491569	KIT, CUMMINS OSL9 AND QS		201	CONNECTOR REPAIR KITS
46491653	MOLEX 1.5 TERMINAL REMO		197	SERVICE TOOLS
46500021	GROMMET		51	BRAKE LIGHTS AND WIRING
46501557	BAR ASSEMBLY, BUMPER /		169	OPTION - BRAKE LIGHTS WITH REVERSE LI
46539714	ELBOW		81	OIL/AIR PIPING

Part Number	Denomination	WAS	Page	Subgroup
46550737	KIT, 500 HOURS		189	MAINTENANCE KIT
46550738	KIT, 1000 HOURS		187	MAINTENANCE KIT
46551221	CJ4 ENGINE OIL		191	FLUIDS
46551222	CJ4 ENGINE OIL		191	FLUIDS
46551223	CJ4 ENGINE OIL		191	FLUIDS
46551378	EYE, TOWING		21	RUNNING GEAR
46551380	HOUSING		21	RUNNING GEAR
46551382	RING, STOP		21	RUNNING GEAR
46551384	ROD ASSEMBLY		21	RUNNING GEAR
46551391	SCREW		21	RUNNING GEAR
46551400	SHIELD		21	RUNNING GEAR
46551401	UPPER ARM ASSEMBLY		21	RUNNING GEAR
46551402	LOWER ARM ASSEMBLY		21	RUNNING GEAR
46551403	SPRING ASSEMBLY		21	RUNNING GEAR
46551404	ABSORBER, SHOCK		21	RUNNING GEAR
46551405	DECAL		21	RUNNING GEAR
46551406	DECAL		21	RUNNING GEAR
46551407	DECAL		21	RUNNING GEAR
46551408	KIT, COVER		21	RUNNING GEAR
46551409	NIPPLE, GREASE		21	RUNNING GEAR
46551411	HANDLE ASSEMBLY		21	RUNNING GEAR
46551412	ROD, PISTON		21	RUNNING GEAR
46551415	LEVER ASSEMBLY		21	RUNNING GEAR
46551416	BRAKE CABLE ASSEMBLY		21	RUNNING GEAR
46551417	LEVER ASSEMBLY		21	RUNNING GEAR
46551418	JIG, CLAMPING		21	RUNNING GEAR
46551420	HOUSING ASSEMBLY		21	RUNNING GEAR
46551422	CLIP, SPRING		21	RUNNING GEAR
46551424	EYE, TOWING		21	RUNNING GEAR
46551483	SET, BUSH		21	RUNNING GEAR
46551484	SET, BUSH		21	RUNNING GEAR
46551485	SET, BUSH		21	RUNNING GEAR
46551486	BRACKET ASSEMBLY		21	RUNNING GEAR
46551487	PIVOT ASSEMBLY		21	RUNNING GEAR
46551488	PIVOT ASSEMBLY		21	RUNNING GEAR
46551489	PIVOT ASSEMBLY		21	RUNNING GEAR
46551490	PIVOT ASSEMBLY		21	RUNNING GEAR
46551491	SHIELD ASSEMBLY		21	RUNNING GEAR
46551492	SHIELD ASSEMBLY		21	RUNNING GEAR
46551493	KIT, CONNECTING		21	RUNNING GEAR
46551494	BRAKE HUB COMPLETE		21	RUNNING GEAR
46551495	HUB ASSEMBLY		21	RUNNING GEAR
46551496	KIT, BRAKE OVERHAUL		21	RUNNING GEAR
46551497	KIT, COVER		21	RUNNING GEAR
46551498	KIT, CONNECTING		21	RUNNING GEAR

Part Number	Denomination	WAS	Page	Subgroup
46551499	KIT, BEARING		21	RUNNING GEAR
46551503	DRAWBAR, COMPLETE		21	RUNNING GEAR
46551514	CENTRING MECHANISM ASS		21	RUNNING GEAR
46551515	LEVER, HANDBRAKE		21	RUNNING GEAR
46551516	KIT, CONNECTING		21	RUNNING GEAR
46551517	CABLE, BRAKE		21	RUNNING GEAR
46551518	ADAPTOR		21	RUNNING GEAR
46553810	REGULATOR, PRESSURE		81	OIL/AIR PIPING
46556137	DECAL, BLACK WEB SITE		41	DECALS & DOCUMENTATION
46556772	RUNNING GEAR ASSEMBLY		19	RUNNING GEAR
46556773	DRAWBAR ASSEMBLY		19	RUNNING GEAR
46556774	AXLE TUBE ASSEMBLY		19	RUNNING GEAR
46565579	MANUAL, OPERATION AND		41	DECALS & DOCUMENTATION
46569661	HITCH, BALL		3 9 21	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46569682	EYE, TOWING		3 9 21	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46569685	EYE, TOWING		3 9 21	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46569700	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
46569701	EYE, TOWING		3 9	RUNNING GEAR RUNNING GEAR
46569942	BRACKET		171	OPTION - CENTRAL DRAINS
46573860	DECAL, DOOSAN TRI-COLO		41	DECALS & DOCUMENTATION
46573861	DECAL, DOOSAN TRI-COLO		41	DECALS & DOCUMENTATION
46573924	DECAL, DOOSAN LOGO		41	DECALS & DOCUMENTATION
46577126	DECAL, MODEL NUMBER 7/1		41	DECALS & DOCUMENTATION
46577127	DECAL, MODEL NUMBER 10/		41	DECALS & DOCUMENTATION
46577128	DECAL, MODEL NUMBER 14/		41	DECALS & DOCUMENTATION
46585199	ENGINE		89	ENGINE MOUNTING
46592579	FOAM FIELD KIT (no adhesive		35 37	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
46592580	FOAM FIELD KIT (no adhesive		35 37	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
46622654	ADAPTOR		83	OIL/AIR PIPING
46627615	DECAL, HORIZONTAL POSIT		41	DECALS & DOCUMENTATION
46656632	ADAPTOR		83	OIL/AIR PIPING
46656633	ELBOW		83	OIL/AIR PIPING
54413505	WHEEL AND TYRE ASSEMB		5 13 17 19	RUNNING GEAR RUNNING GEAR DRAWBAR MOUNTING RUNNING GEAR
54475777	SWITCH		49	WEDGE CONTROLLER
54477740	HARNESS, FRONT SIDE		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI

Part Number	Denomination	WAS	Page	Subgroup
54614870	BUMPER, END STOP		29 51	FRAME BRAKE LIGHTS AND WIRING
54625702	ADAPTOR		81	OIL/AIR PIPING
54629977	DECAL, ISO CENTRAL DRAI		171	OPTION - CENTRAL DRAINS
54639174	HINGE, SIDE DOOR		33	DOOR AND BAFFLE ENCLOSURE
54660089	CAP, FUEL TANK		105	FUEL TANK
54661889	AIR CLEANER ASSEMBLY		97 99	AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
54674957	FOAM		35	FOAM INSULATION EXTERIOR
54675863	STANDPIPE ASSEMBLY		105	FUEL TANK
54688015	HOSE, DISCHARGE		75 85	SEPARATOR TANK PIPING OIL/AIR PIPING
54692967	BODY, AIR CLEANER		101	AIR CLEANER ASSEMBLY
54692975	COVER, AIR CLEANER		101	AIR CLEANER ASSEMBLY
54694831	PANEL, REAR ACCESS		33	DOOR AND BAFFLE ENCLOSURE
54699616	DEUTCH TERMINAL REMOV		197	SERVICE TOOLS
54699624	DEUTCH TERMINAL REMOV		197	SERVICE TOOLS
54699632	DEUTCH TERMINAL REMOV		197	SERVICE TOOLS
54699640	DEUTCH TERMINAL REMOV		197	SERVICE TOOLS
54699657	DEUTCH WEDGELOCK AND		197	SERVICE TOOLS
54717145	ELEMENT, AIR FILTER		101 183 185 187 189	AIR CLEANER ASSEMBLY MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT
54717152	ELEMENT, AIR FILTER		101 183 187 189	AIR CLEANER ASSEMBLY MAINTENANCE KIT MAINTENANCE KIT MAINTENANCE KIT
54718184	STRAP, FOAM RETAINING		31 33	ROOF AND SIDE ENCLOSURE DOOR AND BAFFLE ENCLOSURE
54721337	ADAPTOR		85	OIL/AIR PIPING
54729660	PACKARD WEATHER- PACK		197	SERVICE TOOLS
54729710	ELECTRICAL CONTACT CLE		197	SERVICE TOOLS
54731427	SENDER, FUEL LEVEL		105	FUEL TANK
54737630	BUMPER		29	FRAME
54738091	BAR ASSEMBLY, BUMPER /		51	BRAKE LIGHTS AND WIRING
54739784	PANEL, FRONT		31	ROOF AND SIDE ENCLOSURE
54739826	PANEL		31	ROOF AND SIDE ENCLOSURE
54739842	PANEL		31	ROOF AND SIDE ENCLOSURE
54740675	SERIAL CABLE, HEAVY DUT		197	SERVICE TOOLS
54742028	PLATE, BAIL EYE		29	FRAME
54743257	DOOR, SIDE		33	DOOR AND BAFFLE ENCLOSURE
54743265	DOOR, CONTROL PANEL		47	INSTRUMENT PANEL
54749056	SPACER, FAN		89	ENGINE MOUNTING
54749544	RTD SIMULATOR		197	SERVICE TOOLS
54749551	THERMISTOR SIMULATOR		197	SERVICE TOOLS
54749601	FRAME, INSTRUMENT PANE		47	INSTRUMENT PANEL

Part Number	Denomination	WAS	Page	Subgroup
			175	OPTION - TACHOMETER PANEL
54749643	PACKARD METRI- PACK TER		197	SERVICE TOOLS
54756507	MOUNT, ENGINE		89	ENGINE MOUNTING
54756697	ISOLATOR, CENTRE BOND		89	ENGINE MOUNTING
54756739	MOUNT, ENGINE		89	ENGINE MOUNTING
54760483	PANEL, LOUVER ACCESS		33	DOOR AND BAFFLE ENCLOSURE
54761630	BRACKET		159 165	OPTION - AFTERCOOLER AND WATER SEP OPTION - IQ FILTER AND MOUNTING
54765946	TRANSDUCER, PRESSURE		81	OIL/AIR PIPING
54772041	PLUG		29 33	FRAME DOOR AND BAFFLE ENCLOSURE
54774203	BAIL, LIFTING		29	FRAME
54774229	PIPE, EXHAUST		95	EXHAUST PIPING
54774260	TANK, FUEL		105	FUEL TANK
80026123	HANDLE		9	RUNNING GEAR
80027980	KIT, BRAKE SHOE		21	RUNNING GEAR
80029705	KIT, 500 HOURS		185	MAINTENANCE KIT
80029903	KIT, 500 HOURS		183	MAINTENANCE KIT
85470003	SCREW		113	FLYWHEEL HOUSING
85470458	SCREW		113	FLYWHEEL HOUSING
85470474	SCREW		125	THERMOSTAT
85470508	SCREW		127	OIL PAN
85470581	ELBOW		133	EXHAUST MANIFOLD AND TURBOCHARGER
85470615	O-RING		133 157	EXHAUST MANIFOLD AND TURBOCHARGER OIL FILTER
85470623	O-RING		123 151	WATER PUMP OIL COOLER
85470631	O-RING		123 153	WATER PUMP SENSORS
85470649	O-RING		123 127 157	WATER PUMP OIL PAN OIL FILTER
85471092	SCREW		109	OIL FILLER NECK
85471142	SCREW		123	WATER PUMP
85471167	SCREW		123	WATER PUMP
85471183	SCREW		123	WATER PUMP
85471811	PLUG, DRAIN		157	OIL FILTER
85472280	SPACER		129	FAN DRIVE
85472587	O-RING		117	AIR INTAKE MANIFOLD
85473395	FLYWHEEL		115	FLYWHEEL
85473502	PLUG		123	WATER PUMP
85473676	LINE, TURBO OIL INLET		133	EXHAUST MANIFOLD AND TURBOCHARGER
85473700	SUPPORT, FAN DRIVE		129	FAN DRIVE
85473973	KIT, ADAPTOR		151	OIL COOLER
85473999	HEATER		117	AIR INTAKE MANIFOLD
85474054	ADAPTOR		133	EXHAUST MANIFOLD AND TURBOCHARGER
85474781	INTAKE, OIL PUMP		127	OIL PAN

Part Number	Denomination	WAS	Page	Subgroup
88115498	DECAL, PRE-START		39	DECALS & DOCUMENTATION
89292973	PRO-TEC COMPRESSOR OIL		191	FLUIDS
89292981	PRO-TEC COMPRESSOR OIL		191	FLUIDS
89298491	DECAL, PROTEC OIL		41	DECALS & DOCUMENTATION
89310718	HOSE		193	AIR DELIVERY HOSE
89311716	PRO-TEC ENGINE OIL		191	FLUIDS
89311724	PRO-TEC ENGINE OIL		191	FLUIDS
92047331	HOSE		193	AIR DELIVERY HOSE
92063296	COUPLING, MALE		195	AIR HOSE FITTINGS
92063379	COUPLING, HOSE		195	AIR HOSE FITTINGS
92063387	CLAMP, HOSE		195	AIR HOSE FITTINGS
92076447	NIPPLE		73	HA SERVICE AIR
92076454	NIPPLE		73	HA SERVICE AIR
92085729	REFLECTOR, WHITE		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92111228	VALVE, BALL		73	HA SERVICE AIR
92112226	HOSE		193	AIR DELIVERY HOSE
92121243	REFLECTOR, AMBER		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92121250	LIGHT, FRONT SIDE		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92150978	COUPLING, HOSE		195	AIR HOSE FITTINGS
92150986	CLAMP, HOSE		195	AIR HOSE FITTINGS
92178524	COUPLING		195	AIR HOSE FITTINGS
92178532	COUPLING, FEMALE		195	AIR HOSE FITTINGS
92178565	SEAL		195	AIR HOSE FITTINGS
92271915	RIVET		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92271923	RIVET		47	INSTRUMENT PANEL
92280981	SCREW		105	FUEL TANK
92294461	VALVE, BALL		73	HA SERVICE AIR
92304492	NUT		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92304583	WASHER		47 51 169	INSTRUMENT PANEL BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92368687	SCREW		29 45 91 181	FRAME BATTERY AND MOUNTING COOLER MOUNTING OPTION - WHEEL CHOCKS
92398114	NUT		159	OPTION - AFTERCOOLER AND WATER SEP
92398130	SCREW		93	COOLER PIPING
92478387	ADAPTOR		81	OIL/AIR PIPING
92530047	VALVE, BALL		73	HA SERVICE AIR
92721331	REFLECTOR, RED		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92726017	GROMMET		105	FUEL TANK
92737840	HOSE		193	AIR DELIVERY HOSE

Part Number	Denomination	WAS	Page	Subgroup
92737857	HOSE		193	AIR DELIVERY HOSE
92737972	COUPLING, FEMALE		195	AIR HOSE FITTINGS
92737980	COUPLING, MALE		195	AIR HOSE FITTINGS
92737998	COUPLING, FEMALE		195	AIR HOSE FITTINGS
92738004	COUPLING, FEMALE		195	AIR HOSE FITTINGS
92808666	FILTER, FUEL		105	FUEL TANK
92867449	DECAL, REFER TO HANDBO		39 41	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
92867530	DECAL, HOT SURFACE		41	DECALS & DOCUMENTATION
92899293	CHOCK, WHEEL AND HOLDE		181	OPTION - WHEEL CHOCKS
92901222	LAMP, TAIL/STOP/FLASH		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92901230	LAMP, REGISTRATION PLAT		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
92930585	DECAL, PRESSURISED VES		41	DECALS & DOCUMENTATION
92930593	DECAL, ELECTRIC SHOCK		41	DECALS & DOCUMENTATION
92930601	DECAL, CORROSIVE SUBST		41	DECALS & DOCUMENTATION
92930627	DECAL, GENERAL WARNING		39 41	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
92930650	DECAL, EMERGENCY STOP		39	DECALS & DOCUMENTATION
92930668	DECAL, NO MAINT/READ MA		39 41	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
92949742	FOAM FIELD KIT (with adhesi		35 37	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92949759	FOAM FIELD KIT (with adhesi		35 37	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92949767	FOAM FIELD KIT (with adhesi		35 37	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92949775	FOAM FIELD KIT (with adhesi		35 37	FOAM INSULATION EXTERIOR FOAM INSULATION INTERIOR
92976042	DECAL, EXHAUST GAS DISC		39	DECALS & DOCUMENTATION
93165959	DECAL, ROTATING FAN		39 41	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
93171239	DECAL, ENGINE OIL DRAIN		41	DECALS & DOCUMENTATION
93171247	DECAL, COOLANT DRAIN		41	DECALS & DOCUMENTATION
93171254	DECAL, DIESEL FUEL		39	DECALS & DOCUMENTATION
93171262	DECAL, LIFT/TIE POINT		39 41	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
93171270	DECAL, ENGINE OIL FILL		41	DECALS & DOCUMENTATION
93171288	DECAL, COOLANT FILL		39	DECALS & DOCUMENTATION
93181873	DECAL, TYRE PRESSURE		39 41	DECALS & DOCUMENTATION DECALS & DOCUMENTATION
93190486	DECAL, COOLANT LEVEL		41	DECALS & DOCUMENTATION
93194413	DECAL, DO NOT STAND		41	DECALS & DOCUMENTATION
93465383	DECAL, SERVICE VALVE		39	DECALS & DOCUMENTATION
93477388	LAMP, FOG		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
95022307	O-RING		67	OIL TEMPERATURE BYPASS VALVE

Part Number	Denomination	WAS	Page	Subgroup
95219853	ELBOW		75	SEPARATOR TANK PIPING
95220604	SCREW		53	AIREND MOUNTING
95223178	RING, SNAP		59	AIREND ROTOR HOUSING
95223194	RING, SNAP		59	AIREND ROTOR HOUSING
95223806	RING, SNAP		59	AIREND ROTOR HOUSING
95239919	PIN, DOWEL		57	AIREND GEAR CASE
95239927	PIN		59	AIREND ROTOR HOUSING
95264149	SCREW		57	AIREND GEAR CASE
95280541	PLUG		105	FUEL TANK
95285615	NIPPLE		73	HA SERVICE AIR
95286910	ELBOW		159	OPTION - AFTERCOOLER AND WATER SEP
95302170	ELBOW		165	OPTION - IQ FILTER AND MOUNTING
95315289	CONNECTOR		69 93	OTBV AND OIL FILTER MOUNTING COOLER PIPING
95357976	O-RING		73 75 85	HA SERVICE AIR SEPARATOR TANK PIPING OIL/AIR PIPING
95358024	O-RING		57	AIREND GEAR CASE
95358131	O-RING		61	AIREND REAR BEARING HSG.ASSEMBLY
95364469	ELBOW		83	OIL/AIR PIPING
95365094	ELBOW		69 85	OTBV AND OIL FILTER MOUNTING OIL/AIR PIPING
95381109	KEY		59	AIREND ROTOR HOUSING
95402806	ADAPTOR		55	AIREND PIPING
95494167	SCREW		61	AIREND REAR BEARING HSG.ASSEMBLY
95773032	ADAPTOR		81	OIL/AIR PIPING
95923298	NUT		33 45	DOOR AND BAFFLE ENCLOSURE BATTERY AND MOUNTING
95928040	NIPPLE		75 171	SEPARATOR TANK PIPING OPTION - CENTRAL DRAINS
95928164	ELBOW		73	HA SERVICE AIR
95932802	BUSH, REDUCING		75	SEPARATOR TANK PIPING
95932836	NIPPLE		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95934279	NIPPLE		73	HA SERVICE AIR
95934550	SCREW		69	OTBV AND OIL FILTER MOUNTING
95934683	WASHER, LOCK		75 85	SEPARATOR TANK PIPING OIL/AIR PIPING
95934774	SCREW		165	OPTION - IQ FILTER AND MOUNTING
95934998	WASHER		33 45	DOOR AND BAFFLE ENCLOSURE BATTERY AND MOUNTING
95935003	WASHER		45	BATTERY AND MOUNTING
95935029	WASHER		33	DOOR AND BAFFLE ENCLOSURE
95935037	WASHER		69 105	OTBV AND OIL FILTER MOUNTING FUEL TANK
95935052	WASHER		53	AIREND MOUNTING
95935599	COUPLING		47 165	INSTRUMENT PANEL OPTION - IQ FILTER AND MOUNTING

Part Number	Denomination	WAS	Page	Subgroup
95937462	BUSH		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95938205	PLUG		61	AIREND REAR BEARING HSG.ASSEMBLY
95940748	BUSH, REDUCING		81 83 105	OIL/AIR PIPING OIL/AIR PIPING FUEL TANK
95941639	PLUG		73	HA SERVICE AIR
95944575	NIPPLE		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95944617	BUSH, REDUCING		75	SEPARATOR TANK PIPING
95944641	ADAPTOR		73	HA SERVICE AIR
95944666	ELBOW		85	OIL/AIR PIPING
95944732	ELBOW		75	SEPARATOR TANK PIPING
95944740	ELBOW		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95946190	ELBOW		159 163	OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
95946281	ELBOW		73	HA SERVICE AIR
95947149	PLUG		171	OPTION - CENTRAL DRAINS
95952990	COUPLING		83	OIL/AIR PIPING
95953790	NIPPLE		73	HA SERVICE AIR
95954194	TEE		79	OIL/AIR PIPING
95954228	TEE		75	SEPARATOR TANK PIPING
95954913	REDUCER		69	OTBV AND OIL FILTER MOUNTING
95954921	ADAPTOR		69	OTBV AND OIL FILTER MOUNTING
95955993	CONNECTOR		69	OTBV AND OIL FILTER MOUNTING
95956199	ELBOW		173	OPTION - FULL GAUGE PANEL
95992632	ELBOW		69 75 87	OTBV AND OIL FILTER MOUNTING SEPARATOR TANK PIPING OIL/AIR PIPING
96701370	NUT		181	OPTION - WHEEL CHOCKS
96701396	WASHER		89 181	ENGINE MOUNTING OPTION - WHEEL CHOCKS
96701495	SCREW		45	BATTERY AND MOUNTING
96701503	BOLT		53 89	AIREND MOUNTING ENGINE MOUNTING
96701750	NUT, HEX		29 65	FRAME UNLOADER MOUNTING
96702279	SCREW		97 159 163	AIR INTAKE AND FILTER MOUNTING OPTION - AFTERCOOLER AND WATER SEP OPTION - AFTERCOOLER AND MOUNTING
96702287	SCREW		63	UNLOADER ASSEMBLY
96702311	SCREW		17	DRAWBAR MOUNTING
96702659	SCREW		31 67	ROOF AND SIDE ENCLOSURE OIL TEMPERATURE BYPASS VALVE
96702816	SCREW		65 97 99	UNLOADER MOUNTING AIR INTAKE AND FILTER MOUNTING AIR INTAKE AND FILTER MOUNTING
96703756	NUT		51	BRAKE LIGHTS AND WIRING

Part Number	Denomination	WAS	Page	Subgroup
96704408	SCREW		89	ENGINE MOUNTING
96704580	NUT		49	WEDGE CONTROLLER
96704630	NUT		53 89	AIREND MOUNTING ENGINE MOUNTING
96705165	WASHER		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96705173	SCREW		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96705728	SCREW		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96709118	WASHER		89	ENGINE MOUNTING
96712187	SCREW		57 61	AIREND GEAR CASE AIREND REAR BEARING HSG.ASSEMBLY
96715057	SCREW		65	UNLOADER MOUNTING
96716162	SCREW		55 57 59	AIREND PIPING AIREND GEAR CASE AIREND ROTOR HOUSING
96719810	SCREW		75 85	SEPARATOR TANK PIPING OIL/AIR PIPING
96720545	SCREW		89	ENGINE MOUNTING
96726435	SCREW		89	ENGINE MOUNTING
96727177	SCREW		89	ENGINE MOUNTING
96743265	SCREW		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96745211	SCREW		181	OPTION - WHEEL CHOCKS
96745229	WASHER		181	OPTION - WHEEL CHOCKS
96745237	WASHER		51 169	BRAKE LIGHTS AND WIRING OPTION - BRAKE LIGHTS WITH REVERSE LI
96757557	SCREW		75	SEPARATOR TANK PIPING
97319941	CHECK, SAFETY		195	AIR HOSE FITTINGS

Intentionally left blank



Portable Power