

PARTS MANUAL



Doosan Infracore
Portable Power

HP1300WCU-T3 (B84)

HP1600WCU-T3 (B83)

COMPRESSOR MODEL

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.

Doosan Infracore Portable Power
1293 Glenway Drive
Statesville, N.C. 28625
www.doosanportablepower.com

Book: 22523831 (02/07) Rev A
Revised (09-12)



TABLE OF CONTENTS

Parts Book

TITLE	PAGE
Parts Ordering	
General	6
Description	6
Fasteners	6
How to Order	6
 Parts List	
Fast Track Frame Assembly	8
Wagon Wheel Frame Assembly	9
High Speed Running Gear	10
High Speed Running Gear	11
High Speed Running Gear	12
Fast Track Wiring	13
Fast Track Wiring	13
Wagon Wheel Running Gear	15
Wagon Wheel Running Gear	16
Wagon Wheel Running Gear	17
Wagon Wheel Running Gear	18
LRG Pedestal Mount on Wagon Wheel Frame Assembly	19
LRG Shock Mount on Wagon Wheel Frame Assembly	20
Engine Assembly	21
Engine Assembly	22
Exhaust Assembly	23
285 Air End Complete	24
285 Air End Complete	25
285 Air End Complete	26
285 Air End Complete	27
285 Air End Complete	28
285 Air End Complete	29
Unloader Assembly	30
Unloader Assembly	31
Starting Aid Assembly	32
Radiator and Oil Cooler	33
Radiator Piping	34
High Speed Running Gear Fuel Tank Vent Piping	35
Wagon Wheel Running Gear Fuel Tank Vent Piping	36
High Speed Running Gear Fuel Piping	37
Wagon Wheel Running Gear Fuel Piping	38
High Speed Running Gear Remote Fill Fuel Piping	39
High Speed Running Gear Remote Fill Fuel Piping	40
Wagonwheel Running Gear Remote Fill Fuel Piping	41
Wagonwheel Running Gear Remote Fill Fuel Piping	42
Air Intake & Filters	43
Separator Tank Assembly	44
Separator Tank Assembly	45
285 Oil Piping	46
Air Piping	48
Air Piping	49

TABLE OF CONTENTS

Parts Book

TITLE	PAGE
Air Piping	50
Air Piping	51
Minimum Pressure Check Valve Assembly	52
Oil Temperature By-Pass Valve Assembly	53
Instrument Panel Assembly	54
Instrument Panel Assembly	55
Instrument Panel Assembly	56
Instrument Panel Assembly	57
Battery & Mounting	58
Common Enclosure Assembly	59
Top Enclosure Assembly	60
Top Enclosure Assembly	61
Fast Track Enclosure	62
Wagon Wheel Enclosure	63
Common Foam	64
High Speed Running Gear Foam	65
Wagon Wheel Foam	66
Wiring Parts Lists	68
AC Heater Kit	69
Wagon Wheel Parking Brake Assembly	70
Wagon Wheel Parking Brake Assembly	71
Separator Air Piping	72
Charge Air Piping	73
IQ Air Piping	(
Option)	74
IQ Air Piping	(
Option)	75
IQ Air Piping	(
Option)	76
IQ Cooler Piping	(
Option)	77
IQ Filter Piping	78
IQ Indicator Piping	79
Engine Oil Drain Piping	80
Fuel Tank Drain Piping	81
Radiator Drain Piping	82
Separator Tank Drain Piping	83
Decal Location	84
Decal Location	85

Electrical Schematics

Wiring Parts Lists	2
Wiring Parts Lists	3
Wiring Parts Lists	4

TABLE OF CONTENTS
Parts Book

TITLE	PAGE
Control System Wiring Diagram.....	6
Control System Wiring Diagram.....	7
Control System Wiring Diagram.....	8
Control System Wiring Diagram.....	9
Control System Wiring Diagram.....	10
IQ Wiring Diagram.....	11

TABLE OF CONTENTS
Parts Book

TITLE	PAGE
--------------	-------------

Parts Ordering



Parts Ordering

General

This publication, which contains an illustrated parts breakdown, has been prepared as an aid in locating those parts which may be required in the maintenance of the unit. Always insist on genuine Ingersoll-Rand Company parts for your compressor.

NOTICE

Ingersoll-Rand Company can bear no responsibility for injury or damages resulting directly from the use of non-approved repair parts.

Ingersoll-Rand Company service facilities and parts are available worldwide. Consult local yellow pages or visit: www.portablepower.irco.com.

Special order parts may not be included in this manual. Contact the Mocksville Parts Department with the unit serial number for assistance with these special parts.

Description

The illustrated parts breakdown illustrates and lists the various assemblies, subassemblies and detailed parts which make up this particular machine. This covers the standard models and the more popular options that are available.

In referring to the rear, the front or to either side of the unit, always consider the **drawbar end** of the unit as the **front**. Standing at the rear of the unit facing the drawbar (front) will determine the right and left sides.

Fasteners

Both SAE/inch and ISO/metric hardware have been used in the design and assembly of these units. In the disassembly and reassembly of parts, extreme care must be taken to avoid damaging threads by the use of wrong fasteners.

How to Order


Always specify the model and serial number of the unit.

Specify the part number and description.

Parts List




Fast Track Frame Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54760202	Frame Assembly	1	
B	54542543	Bail, Lifting	1	
C	96720610	Screw	4	

Wagon Wheel Frame Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54501796	Frame Assembly	1	
B	22186845	Bail, Lifting	1	
C	96720610	Screw	4	

High Speed Running Gear




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36880235	Hanger, Rear	2	
B	36880219	Bar, Equalizer	2	
C	36880243	Bolt, Equalizer	2	
D	36880250	Locknut	2	
E	36880193	Hanger, Center	2	
F	36880284	Spring, Leaf	4	
G	36880201	Hanger, Front	2	
H	36880227	Bolt, Shackle	8	
J	35336700	Locknut	8	
K	36880136	Bolt	4	
L	95935011	Washer	4	
M	95077608	Locknut	4	
N	35144336	Screw	8	
P	36880151	Bumper, Rubber	4	
Q	36880144	Jack, Dropleg	1	
R	36880128	Eye, Pintle	1	

High Speed Running Gear




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35272150	Stud	8	
B	36880276	Nut	8	
	36853091	Nut	4	
C	36853109	Washer	2	
D	36853117	Washer, Lock	2	
E	36851624	Inner Bearing Cup	1	
F	36851616	Outer Bearing Cup	1	
G	36851608	Inner Bearing	1	
H	36851590	Outer Bearing	1	
J	36851632	Seal	1	
K	36776813	Cap, Dust	8	
L	36880268	Hub Assembly	4	
M	36880292	LH Electric Brake	2	
N	36880300	RH Electric Brake	2	
P	36880318	Shield, Bottom Dust	4	
Q	36880326	Shield, Top Dust	4	
R	36880334	Bolt	7	
S	95939955	Washer, Lock	7	
T	36880342	Locknut	7	
U	35603190	Chock, Wheel	2	
V	35333830	Strap, Rubber	2	
W	36877991	Tire	4	
X	22077515	Wheel	4	
Y	36878049	Clamp, Plate	4	

High Speed Running Gear




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36895860	Light, License Plate	1	
B	36922144	3 Light Assembly	1	
C	36788081	Stop, Turn and Tail Light	2	
D	36787968	Grommet (Use on Item C & E)	6	
E	36859320	Stop, Turn and Tail Light	4	
F	35367051	Yellow Light	4	
G	36893642	Grommet (Use on Item F)	2	
H	36893634	Grommet (Use on Item F)	2	
J	35367044	Red Clearance Light	4	
K	36894129	7-Way Connector	1	
L	36896306	ID Bracket	1	
M	36880169	Plate, U-Bolt	2	
N	36880177	U-Bolt	4	
P	36880185	Nut	8	
Q	95934741	Washer, Lock	8	

Fast Track Wiring




Fast Track Wiring



STOP, TAIL & TURN LIGHT OPTION
(AS VIEWED FROM REAR OF SOCKET)


LIST OF MATERIALS									
CKT	TERMINATION A	TYPE	SIZE	TERMINATION B	TYPE	SIZE	GAUGE	LENGTH	COLOR
1	RECEPTACLE 1	E		GROUND	A	1/4	14	46	WHT
2	RECEPTACLE 6	E		SPLICE 1	D		14	24	BRN
3	SPLICE 1			LH FRT CLEARANCE	B		14	95	BRN
4	LH FRT CLEAR W/CKT 3B			RH FRT CLEARANCE	B		14	89	BRN
5	SPLICE 1 W/CKT 3A			SPLICE 2	D		14	218	BRN
6	RECEPTACLE 3	E		RH TURN	G		14	342	YEL
7	RECEPTACLE 5	E		LH TURN	G		14	255	GRN
8									
9									
10	RH TURN/TAIL W/CKT 27B			RH REAR CLEAR BOT	B		14	22	BRN
11									
12	SPLICE 2			LH REAR CLEARANCE	B		14	19	BRN
13	LH REAR CLEAR W/CKT 12B			LH REAR TOP CLEAR	B		14	74	BRN
14	LH REAR TOP CLEAR W/CKT 13B			REAR ID W/CKT 15A	B		14	61	BRN
15	R ID W/CKT 14B			RH REAR TOP CLEAR	B		14	56	BRN
16	SPLICE 2 W/CKT 12A			LICENSE LAMP	B		14	31	BRN
17	SPLICE 2 W/CKT 12A			LH TURN/TAIL	G		14	13	BRN
18	RECEPTACLE 4	E		LH STOP LAMP	G		14	261	RED
19	LIGHT GRD W/CKT 24A			LIGHT GROUND			14	36	WHT
20	LEFT STOP LAMP W/CKT 18B			RIGHT STOP LAMP	G		14	99	RED
21	RECEPTACLE 7	E		ELECTRIC BRAKES			14	29	BLU
22	LEFT TURN GRD			LH ST/GRD W/CKT 23A	G		14	30	WHT
23	LEFT STOP GRD			RT ST/GRD W/CKT 24A	G		14	99	WHT
24	RIGHT STOP GRD			RH TURN GRD	G		14	30	WHT
25	LH TURN/TAIL W/CKT 17B			LEFT STOP/TAIL	G		14	30	BRN
26	LH STOP/TAIL W/CKT 25B			RIGHT STOP/TAIL	G		14	99	BRN
27	RH STOP/TAIL W/CKT 26B			RIGHT TURN/TAIL	G		14	30	BRN
28	RECEPTACLE 2	E		AUX	B		14	29	BLK

Wagon Wheel Running Gear




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36504389	Rod, Tie	2	
B	36140730	Nut, Jam	2	
C	35588961	Ball Joint, Outer	2	
D	35221894	Fitting, Lube	2	
E	36753259	Axle, Front	1	
F	95717369	Pin, Roll	1	
G	35221894	Fitting, Lube	1	
H	95338554	Pin, Roll	2	
J	95239927	Washer	4	
K	36851566	LH Knuckle Assembly	1	
L	36851574	RH Knuckle Assembly	1	
M	95673042	Pin, Roll	2	
N	35319045	Pin, King	2	
P	95018982	Pin, Cotter	2	
Q	36719169	Bracket	2	
R	36719466	Spring	2	
S	36719177	Bracket	2	
T	35111590	Bolt, Shackle	2	
				Continued.....

Wagon Wheel Running Gear




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
U	95318556	Fitting, Lube	2	 <i>Continued</i>
V	35588755	Pin, Center	1	
W	95717377	Pin, Roll	2	
X	95934956	Washer	2	
Y	36719557	Drawbar	1	
Z	35107168	Pin, Hinge	1	
A1	95201455	Pin, Cotter	2	
A2	36753242	Arm, Center	1	
A3	35588953	Balljoint, Inner	2	
A4	35140722	Nut, Jam	2	
A5	36719219	Latch	1	
A6	35141167	Spring	1	
A7	95098703	Pin, Roll	2	
A8	36851376	Front Axle Assembly	1	
A9	36851384	Rear Axle Assembly	1	
B1	36853042	Tie Rod Assy. (Includes A, B, C, A3, A4)	2	
	22077515	Wheel	4	
	36877991	Tire	4	
	36878049	Ring, Clamp	4	

Wagon Wheel Running Gear




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95318556	Fitting, Lube	2	
B	35588839	Rivet	2	
C	35589241	Plate, Clamp	2	
D	35111566	Nut	8	
E	36851640	Axle, Rear	1	
F	36719466	Spring	2	
G	35111590	Bolt Shackle	2	
H	95018982	Pin, Cotter	2	
J	35834621	U-Bolt	4	
K	36851665	Hub Assembly (Includes Items N, L, A2)	2	
L	36764983	Stud	8	
M	36851590	Outer Bearing	2	
N	36851616	Outer Race	2	
P	36853109	Washer, Flat	2	
Q	36853091	Nut	2	
R	36776813	Pin, Cotter	2	
S	95272902	Cap, Grease	2	
T	36853117	Washer, Lock	2	Continued.....

Wagon Wheel Running Gear



ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
U	36A2D326Z1	Bolt	8	Continued
V	95934741	Washer, Flat	8	
W	95916573	Nut	8	
X	36776839	Flange, Brake Mounting	2	
Y	36719177	Bracket	2	
Z	36719169	Bracket	2	
A1	36851608	Inner Bearing	2	
A2	36851624	Inner Race	2	
A3	36851632	Seal	2	
A4	36776821	Nut, Stud	8	


LRG Pedestal Mount on Wagon Wheel Frame Assembly



22742951_005_06/04_A

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54501796	Frame Assembly	1	
B	22186845	Bail, Lifting	1	
C	96700901	Screw	6	
D	22051304	Support, LRG	4	
E	22053706	Crossmember, LRG	2	
F	39179072	Screw, M16 X 50	24	
G	96701750	Nut, M16	24	


LRG Shock Mount on Wagon Wheel Frame Assembly



22742951_006_06/04_A


ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54501796	Frame Assembly	1	
B	22186845	Bail, Lifting	1	
C	96700901	Screw	6	
D	22112171	Bar, Shock Mount Rest	8	
E	22110761	Support, Upper Shock Mount	4	
F	36847002	Isolator, Shear Mount	4	
G	22110753	Support, Lower Shock Mount	4	
H	95994877	Screw, Hex 1/2-20 X 2.0	16	
J	39179072	Bolt, M16 X 50	8	
K	96701750	Nut, M16	8	
L	95954079	Screw, Hex 1/2-20 X 1.0	16	

Engine Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95940920	Screw	6	<i>Continued.....</i>
B	36884047	Fan Assembly	1	
C	54409339	Spacer, Fan	1	
D	54661533	Engine, QSX-15 Cummins - Tier 2	1	
	22648414	Engine, QSX-15-C600 Cummins - Tier 3	1	
E	95923363	Nut	1	
F	35584556	Mount, Rubber	1	
G	35273937	Washer	1	
H	35297340	Nut	2	
J	54570122	Bracket, Engine	1	
K	95934253	Screw	1	
L	95935011	Washer	2	
M	36763670	Screw	2	
N	54687322	Guard, Turbo	1	
P	36879492	Screw	2	

Engine Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
Q	22524508	Bracket, Overflow	1	 <i>Continued</i>
R	36845600	Bottle, Overflow		
S	35360775	Hose		
T	95220844	Clamp		
	36870608	Sender, Pressure (RH Side of Engine)	1	
	36841138	Sender, Temp. (Side of Water Pump in Bushing)	1	
		Engine Filters		
	54662036	Engine Fuel Filter	1	
	54662028	Engine Oil Filter	1	
	54662051	Engine Water Separator Filter	1	
	22065916	Alternator Belt	1	
	22765374	Engine Belt	1	

Exhaust Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54603774	Pipe, Engine Turbo	1	
B	54616552	Pipe, Exhaust (Standard)	1	
	54738752	Pipe, Exhaust (IQ)	1	
C	35127653	Clamp	1	
D	35611235	Support, Pipe	1	
E	36880995	Screw	12	
F	36879195	Nut	12	
G	54616560	Pipe, Exhaust	1	
H	35307131	Clamp, Seal	3	
J	54629589	Step	1	
K	35851351	Cap, Rain	1	
L	54629126	Pipe, Exhaust	1	
M	36799807	Clamp, Seal	1	
N	54603204	Muffler	1	
	54662010	Wrap, Exhaust	1	
	54721105	Kit, Wrap Wire Kit	1	

285 Air End Complete




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35367069	Key, Bushing	1	
B	35307784	Bushing	1	
C	54540141	Coupling	1	
D	95941092	Screw	12	
E	54542535	Bracket, Air End	2	
F	35584556	Mount, Rubber	2	
G	35375385	Screw	8	
H	35273937	Washer	2	
J	96700919	Screw	2	
K	42469809	Air End Assembly	1	
L	36754059	Gasket	1	
M	36729531	Unloader Assembly	1	
N	35375377	Screw	8	
P	95934626	Screw	12	

285 Air End Complete




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	96706080	Screw	8	
B	35367069	Key	1	
C	35849348	Cover	1	
D	39927512	Shim (1.016mm)	1	
	39927520	Shim (1.016mm)	1	
	39927538	Shim (1.016mm)	1	
	39927546	Shim (1.016mm)	6	
E	95358214	O-Ring	1	
F	35596626	Seal	1	
G	35299775	Locknut	1	
H	35300227	Spacer	1	
J	35605203	Bearing	1	
K	35365261	Pin	1	
L	36711083	Gear Case	1	
M	35295336	Dowel	1	
N	35299569	Screw	4	
P	35300177	Plate, Clamp	1	Continued.....

285 Air End Complete




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
Q	96706262	Screw	18	 <i>Continued</i>
R	35300227	Spacer	1	
S	35300136	Key	1	
T	35298470	Gear Set, HP-1300	1	
	36758142	Gear Set, HP-1600	1	
U	35300144	Key	1	
V	35851195	Shaft	1	
W	35610286	Spacer	1	
X	95285599	Retaining Ring	1	
Y	35610591	Bearing	1	
Z	35605203	Bearing	1	

285 Air End Complete




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35293869	Screw	4	
B	39926787	Bearing	1	
C	35373877	Plate, Clamp	1	
D	35820646	Gasket	1	
E	36754141	Housing, Front Bearing	1	
F	35365279	Pin	2	
G	54363536	Housing, Rotor	1	
H	96706262	Screw	20	
J	35365279	Dowel	1	
K	35820661	Gasket	1	
L	36856060	Housing, Rear Bearing	1	
M	39101472	Screw	4	
	35299767	Screw	12	
N	42469676	Rotor Set	1	
P	35295336	Dowel	2	
Q	35820653	Gasket	1	

285 Air End Complete




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	39927496	Shim	6	
B	35299403	Bearing	2	
C	35610278	Plate, Clamp	1	
D	35299569	Screw	4	
E	39927058	Shim (.051mm)	3	
	95358446	Shim (.076mm)	3	
	35321520	Shim (.254mm)	3	
F	95352944	O-Ring	1	
G	96716162	Screw	8	
H	36504330	Cap	1	
J	95603130	O-Ring	1	
K	36504355	Cap	1	
L	39926902	Shim (.051mm)	3	
	39926910	Shim (.076mm)	3	
	39926928	Shim (.254mm)	3	
				Continued.....

285 Air End Complete




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
M	35606920	Plate, Clamp	1	 <i>Continued</i>
N	35299429	Bearing	2	
P	39927504	Shim (.051mm)	5	

Unloader Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35594878	Spring, Piston	1	<i>Continued.....</i>
B	35594910	Spring, Valve	1	
C	35594829	Piston	1	
D	35594837	Diaphragm	1	
E	35332618	Washer, Piston	1	
F	95104147	Screw	1	
G	35594811	Cover, Piston	1	
H	96702659	Screw	8	
J	36729416	Body, Unloader	1	
K	95928222	Plug	1	
L	35594860	Valve, Unloader	1	
M	35332659	Bushing	2	
N	35332675	Stem, Valve	1	

Unloader Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
P	35332634	Bushing, Housing	1	Continued
Q	35332642	Seal	1	
R	35594845	Gasket	1	
S	36729465	Housing, Piston	1	
T	96702287	Screw	12	
U	35331586	Grommet	2	
V	36897148	Valve	1	
W	35332626	Spacer	1	
X	39102355	O-Ring	1	
Y	95928222	Plug	1	

Starting Aid Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35103498	Elbow	1	84"
B	35132166	Tubing	1	
C	35602812	Atomizer	1	
D	35322908	Screw	4	
E	35103506	Clamp	1	
F	35357052	Valve and Bracket Assembly	1	
G	95043196	Washer	4	
H	92304500	Nut	4	
J	35112911	Cylinder, Ether	1	
K	95930301	Bushing	1	
L	54720719	Adapter (To Engine Charge Air Return)	1	

Radiator and Oil Cooler




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54774526	Fan Guard Assembly	1	
B	54661426	Plate, Cover	4	
C	54661459	Bracket	2	
D	54507488	Orifice RH Fan	1	
E	54507470	Orifice LH Fan	1	
F	54507454	Support, RH Shroud	1	
G	54507447	Support, Bottom Shroud	1	
H	54507462	Support, LH Shroud	1	
J	22496269	Support, LH Rear Shroud	1	
K	54507439	Support, Top Shroud	1	
L	22496277	Support RH Rear Shroud	1	
M	22495311	Support, Top Rear Shroud	1	
N	54501846	Cooler, A/C Fuel	1	
P	22767453	Radiator	1	
Q	54501853	Cooler Oil	2	

Radiator Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54637996	Tube, Lower Radiator	1	
B	95220844	Clamp	2	
C	54638101	Tube, Upper Radiator	1	
D	35330570	Hose, Connector	3	
E	22767453	Radiator	1	
F	95235131	Clamp	2	
G	35135458	Hose, By-Pass	1	55"
H	35310598	Fitting, Barbed	1	
J	43212216	Adapter	1	
K	35285600	Hose, Vent	1	52"
L	95264776	Clamp	2	
M	35222017	Clamp	8	
N	35326560	Adapter	1	
P	35326578	Hose, Drain	1	115"
Q	35576115	Valve, Ball	1	
R	95953949	Adapter	1	
	54474572	Switch, Level	1	

High Speed Running Gear Fuel Tank Vent Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22699201	Tank, R.H. Fuel	1	
B	54594080	Tank, L.H. Fuel	1	
C	35356484	Tubing (18 Inches)	1	
D	92368687	Screw	1	
E	35253038	Clamp	1	
F	35369339	Reducer	1	
G	35322395	Breather	1	
H	35369354	Elbow	1	

Wagon Wheel Running Gear Fuel Tank Vent Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22699219	Tank, R.H. Fuel	1	
B	54594106	Tank, L.H. Fuel	1	
C	35356484	Tubing (18 Inches)	1	
D	92368687	Screw	1	
E	35253038	Clamp	1	
F	35369339	Reducer	1	
G	35322395	Breather	1	
H	35369354	Elbow	1	

High Speed Running Gear Fuel Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35279801	Elbow	1	
B	35305499	Hose Assembly	1	
C		Fuel Return on Engine	-	
D		Into Fuel filter on Engine	-	
E	22500607	Hose Assembly	1	
F	95279378	Connector	1	
G	22060156	Hose Assembly	1	
H	35309210	Elbow	1	
J	22062566	Cover, Fuel Tank Clean-out	1	
K	36845014	Cap, Fuel Tank	1	
L	35389964	Gasket, Cover	1	
M	35389972	Filler, Neck And Cover	1	
N	36845022	Strainer, Fuel Tank	1	
P	35144328	Screw	10	
	54672811	Sender, Fuel Level	1	

Wagon Wheel Running Gear Fuel Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35279801	Elbow	1	
B	35305499	Hose Assembly	1	
C		Fuel Return on Engine	-	
D		Into Fuel filter on Engine	-	
E	35136548	Hose Assembly	1	
F	35286756	Elbow	1	
G	22060156	Hose Assembly	1	
H	35309210	Elbow	1	
J	22062566	Cover, Fuel Tank Clean-out	1	
K	36845014	Cap, Fuel Tank	1	
L	35389964	Gasket, Cover	1	
M	35389972	Filler, Neck And Cover	1	
N	36845022	Strainer, Fuel Tank	1	
P	35144328	Screw	10	
	54672803	Sender, Fuel Level	1	

High Speed Running Gear Remote Fill Fuel Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	92368687	Screw	6	
B	36845733	Hinge	1	
C	35327303	Eyebolt	1	
D	36894467	Door, Fuel Fill	1	
E	35327311	Spring, Door Latch	1	
F	95923314	Nut	1	
G	95934998	Washer	2	
H	22501324	Panel, Center Side	1	
J	22331557	Door, Fuel Access Side	1	
K	35285451	Union	1	Continued.....

High Speed Running Gear Remote Fill Fuel Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
L	95730172	Cap	2	Continued
M	22332589	Foam, Center Panel	1	
N	22331839	Foam, Side Door	1	
P	-----	Into Fuel Filter on Engine		
Q	22500607	Hose Assembly	1	
R	95279378	Connector	1	
S	22060156	Hose Assembly	1	
T	35389972	Cover, Fuel Fill	1	
U	36845022	Strainer	1	
V	36845014	Cap, Fuel Fill	1	

Wagonwheel Running Gear Remote Fill Fuel Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	92368687	Screw	6	Continued.....
B	36845733	Hinge	1	
C	35327303	Eyebolt	1	
D	36894467	Door, Fuel Fill	1	
E	35327311	Spring, Door Latch	1	
F	95923314	Nut	1	
G	95934998	Washer	2	
H	22329544	Panel, Center Side	1	
J	22331557	Door, Fuel Access Side	1	
K	35285451	Union	1	
L	95730172	Cap	2	

Wagonwheel Running Gear Remote Fill Fuel Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
M	95332599	Connector, Bulkhead	1	Continued
N	22331839	Foam, Side Door	1	
P	22332589	Foam, Center Panel	1	
Q	-----	Into Fuel Filter on Engine	1	
R	35325083	Hose Assembly	1	
S	35286756	Elbow, 90	1	
T	22060149	Hose Assembly	1	
U	35389972	Cover, Fuel	1	
V	36845022	Strainer, Fuel	1	
W	36845014	Cap, Fuel Fill	1	
X	35313428	Cap	2	

Air Intake & Filters




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36755163	Bracket, Air Cleaner	1	
B	36880995	Screw	12	
C	36879195	Nut	12	
D	35161025	Clamp	1	
E	54599956	Elbow, Rubber	1	
F	35112648	Tube	1	
G	36758902	Elbow Rubber	1	
H	35123272	Tube	1	
J	35112630	Elbow, Rubber	1	
K	35505866	Tube	1	
L	35119858	Clamp	8	
M	35141290	Hose, Hump	1	
N	35129071	Clamp	1	
P	35129071	Clamp	4	
Q	36862886	Elbow, Rubber	2	
R	35300110	Tube	1	
S	36867778	Evacuator	2	
T	36864361	Element, Primary	2	
U	36864379	Element, Safety	2	
V	35388982	Nut, Wing	2	
W	36864346	Air Cleaner Assembly	2	
	36847838	Switch, Air Filter	2	

Separator Tank Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95219747	Connector	1	Continued.....
B	36878254	Hose Assembly	1	
C	35294750	Elbow	1	
D	36757581	Switch, Pressure	1	
E	22189831	Glass, Sight	1	
F	54627799	Elbow	2	
G	36879492	Screw	4	
H	36765121	Screw	16	
J	36856656	Gasket	1	
K	54612437	Discharge Hose Assembly	1	
L	95930301	Bushing	1	
M	36762961	Gasket	1	
N	36754414	Liner, Shell	1	
P	22402317	Element, Separator	1	
	35610617	Gasket (Top Of Element)	1	
Q	54612429	Cover, Tank	1	
R	95934170	Screw	16	

Separator Tank Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
S	54612403	Tank, Separator	1	Continued
	22139026	Tank, Separator (Japanese)	1	
	22068811	Tank, Separator (EEC)	1	
T	35277797	O-Ring	1	
U	35802933	Plug, Oil Fill	1	
V	95954285	Tee	1	
W	95942108	Adapter	1	
X	36764371	Valve, Safety	1	
Y	95953311	Elbow	1	
Z	36764389	Adapter	1	
A1	35192178	Clamp	1	
A2	54744149	Pipe, Safety Valve	1	
A3	36898922	Sensor, Temperature	1	
A4	95940912	Bushing	1	
A5	95940748	Bushing, Reducing	1	
A6	35610674	Fitting, Scavenge	1	
A7	36794303	Tube, Scavenge	1	
A8	22209779	Hose	1	
A9	22209787	Clamp	2	

285 Oil Piping



ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35335124	Connector	1	
B	36897346	Element, Filter	1	
C	95286910	Elbow	1	
D	54625348	Tube Assembly	1	
E	36506756	Clamp	1	
F	35296409	Connector	1	
G	39871306	Head, Filter	1	
H	54625173	Bracket, Filter	1	
J	36756906	Tee	1	
K	54628185	Tube Assembly	1	
L	54625363	Tube Assembly	1	
M	54628177	Tube Assembly	1	
N	54625355	Tube Assembly	1	
P	95357976	O-Ring	4	


Air Piping



Air Piping

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36762623	Silencer		
B	95989554	Coupling		
C	35290147	Connector		
D	35282987	Hose Assembly		
E	35335017	Valve, Blowdown		
F	95944575	Nipple		
G	95944633	Bushing		
H	35279116	Adapter		
J	35283126	Connector		
K	35298512	Hose Assembly		
L	35248145	Valve, Check		
M	95954095	Elbow		
N	95930301	Bushing		
P	95287629	Adapter		
Q	35358662	Hose Assembly		
R	95287629	Adapter		
S	36840460	Valve, Check		
T	35294453	Elbow		
U	95940748	Bushing		
V	36840841	Valve, Solenoid		
W	35279835	Elbow		
X	95944575	Nipple		
Y	95954194	Tee		
Z	35283050	Tee		
A1	95944690	Tee		
A2	35322346	Orifice, .156		
A3	95930301	Bushing		
A4	36920825	Reducer		
A5	36841815	Tube Assembly		
A6	35284538	Hose Assembly		
A7	35280510	Adapter		
A8	95944617	Bushing		
A9	35330117	Tee		
B1	35365774	Reducer		
B2	35287911	Elbow		
B3	35298512	Hose Assembly		
B4	95944625	Bushing		
B5	95944575	Nipple		
B6	36854495	Regulator		
B7	35279934	Elbow		
B8	35282953	Hose Assembly		
B9	35283092	Tee		
				Continued.....


Air Piping



Air Piping


ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
C1	35290253	Elbow		Continued
C2	35123124	Orifice		
C3	95940748	Bushing		
C4	36840841	Valve, Solenoid		
	36842086	Bracket, Top		
	36842094	Bracket, Bottom		
C5	95944690	Tee		
C6	95930301	Bushing		
C7	54496773	Reducer		
C8	35279934	Elbow		
C9	35282961	Hose Assembly		
D1	95954210	Tee		
D2	35324839	Valve, Ball		
D3	95944633	Reducer		
D4	95954285	Tee		
D5	35330117	Tee		
D6	36863702	Adapter		
D7	22061394	Valve, Safety		
D8	35301506	Elbow		
D9	35280098	Elbow		
E1	35282979	Hose Assembly		
E2	36852499	Elbow		
E3	35310994	Hose Assembly		
E4	35283092	Tee		
E5	35282961	Hose Assembly		
E6	35336189	Fitting, Bulkhead		
E7	35367846	Connector		

Minimum Pressure Check Valve Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54699731	Body, Check Valve	1	
B	36792380	Check Valve Assembly	1	
C	54699749	Spring, Check Valve	1	
D	36792927	Piston	1	
E	54699756	O-Ring	1	
F	36794790	Spring, Main	1	
G	36794808	Cap	1	

Oil Temperature By-Pass Valve Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	96701917	Screw	4	
B	35307537	Body, Valve	1	
C	35307545	Seat, Valve	1	
D	35307552	Sleeve, Valve	1	
E	35307560	Seal, Valve	1	
F	22694640	Element, Valve	1	
G	35307586	Gasket, Valve	1	
	22711774	Oil Temp. By-pass Valve Assembly	1	
	22711766	Service Kit (Includes Items: E, F, & G)	1	

Instrument Panel Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22053896	Switch, Lamps	1	
B	22054050	Switch, Heater	1	
C	22054142	Plug, Switch	5	
D	22054076	Switch, After Warm-Up	1	
E	22105571	Panel, Instrument	1	
F	22277057	Gage, Engine Oil Pressure	1	Before S/N 375132
	22692628	Gage, Engine Oil Pressure	1	After S/N 375131
G	22055800	Overlay, Module	1	
H	22399349	Gage, Voltage	1	Before S/N 375132
	22692594	Gage, Voltage	1	After S/N 375131
J	22327266	Gage, Air Discharge Temperature	1	Before S/N 375132
	22692610	Gage, Air Discharge Temperature	1	After S/N 375131
K	22327266	Gage, Water Temperature	1	
	22692610	Gage, Water Temperature	1	After S/N 375131
				Continued.....

Instrument Panel Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
L	22050991	Gage, Fuel Level	1	 Continued
	22692602	Gage, Fuel Level	1	Before S/N 375132
M	36852622	Light, Instrument Panel	1	After S/N 375131
N	36898096	Screw	3	
P	36840908	Hinge	1	
Q	36898104	Nut	3	
R	95928800	Nut	4	
S	22173579	Module, Wedge	1	
T	22134118	Knob, Switch	1	
U	22127385	Switch, Starter	1	
V	36844124	Screw, Quarter Turn	6	
W	35314582	Receptacle	3	

Instrument Panel Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
X	36840767 36841468	Gage, Discharge Pressure Gage, Discharge Pressure	1	 Continued Before S/N 375132 After S/N 375131
Y	54766704	Hourmeter	1	
Z	22055883	Tachometer	1	

Instrument Panel Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95923314	Nut	2	
B	95934998	Washer	2	
C	35327311	Spring	2	
D	92368687	Screw	7	
E	35327303	Eyebolt	2	
F	22471882	Door, Instrument Panel	1	
G	36740405	Hinge	1	
H	22471890	Panel, Vertical	1	

Battery & Mounting




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36870350	Tray, Battery	1	
B	35225788	Battery	2	
C	54715479	Stud	4	
D	95935037	Washer	8	
E	95923322	Nut	8	
F	35562156	Frame	2	
G	35108216	Clip	4	
H	54765367	Cable, Negative	1	
J	35128982	Cable, Jumper	1	
K	54765375	Cable, Positive	1	
L	36896975	Switch, Master Cut-Off	1	
M	54737400	Bracket, Switch	1	
N	35279025	Screw	2	
P	23268105	Cable, Master Switch	1	
Q	54706825	Cover, Battery	1	
	36783488	Ground Strap From Starter	1	
	36783488	Ground Strap To RH of Engine	1	

Common Enclosure Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36793602	Latch, Door Slam	5	
B	54576871	Brace, Front Panel	1	
C	22471890	Panel, LH Front	1	
	22475560	Panel, LH Front (IQ Units)	1	
D	54576947	Panel, RH Front	1	
	22055750	Panel, RH Front (IQ Units)	1	
E	36863363	Door, Front	1	
F	54718184	Brace, Front	2	
G	54587944	Grille, LH Front Side	1	
H	36863413	Hinge	5	
J	36863660	Door, Side	1	
K	54587969	Panel, Center	1	
L	36863652	Door, Side	1	
M	54587977	Panel, LH Rear Side	1	
N	54663240	Panel, Rear Side	1	
P	54587985	Panel, RH Rear Side	1	
Q	36863371	Angle, Door Drip	5	
R	54587951	Grille, RH Front Side	1	
S	36849925	Latch, Door	5	

Top Enclosure Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54576970	Cap, Front End	1	Continued.....
B	36755981	Cap, Corner	4	
C	54690110	Cap, LH Front Side	1	
D	36755742	Bracket, Filler	6	
E	54690128	Cap, LH Rear Side	1	
F	54584784	Cap, Rear End	1	
G	54747316	Brace, Top Foam	8	
H	54747324	Brace, Top Foam	8	
J	54663224	Cap, RH Front Top	1	
K	54663232	Cap, RH Rear Top	1	
L	54700091	Brace, Center Roof	2	

Top Enclosure Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
M	54599915	Panel, Front Top	1	Continued
N	54599923	Panel, 2nd and 4th Top	1	
P	54599931	Panel, Center Top	1	
Q	54599949	Panel, Rear Top	1	
R	54690136	Plate, Radiator Fill	1	
S	35131051	Latch, Door	1	
T	36864403	Door, Roof	1	
U	36864304	Cable	1	
V	36864288	Hinge, Door	1	

Fast Track Enclosure




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54640982	Baffle, LH Outside	1	
B	54641022	Strip, Support	1	
C	54640966	Baffle, LH Inside	1	
D	54640974	Baffle, RH Inside	1	
E	54641006	Plate, Tie	1	
F	54672761	Panel, RH Rear	1	
G	54718184	Strip, Foam Retention	6	
H	54663299	Panel, RH Rear Corner	1	
J	54672779	Door, Rear	1	
	36793602	Latch, Door Slam	1	
K	54692744	Hinge	1	
L	54663281	Panel, LH Rear Corner	1	
M	54576921	Strip, Panel Support	1	
N	54672753	Panel, LH Rear Side	1	

Wagon Wheel Enclosure




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54688239	Baffle, RH	1	
B	54688221	Baffle, LH	1	
C	54641022	Support, Baffle	4	
D	54576921	Angle, Rear Mounting	1	

Common Foam




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54721204	Foam, LH Front Top	1	
B	54719703	Foam, Door	2	
C	54719711	Foam, Door	3	
D	54719646	Foam, Center Panel	2	
E	54719695	Foam, LH Side	1	
F	54759519	Foam, RH/LH Rear Side	4	
G	54759527	Foam, Rear	2	
H	54721675	Foam, RH Front	1	
J	54720065	Foam, Door	2	
K	54719661	Foam, Center Door	5	
L	54720057	Foam, Door	3	
M	54719653	Foam, RH Rear Side	1	
N	54699046	Foam, Top	7	
P	54699087	Foam, Center Top	2	
Q	54710041	Foam, Rear Top	1	

High Speed Running Gear Foam



ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54675848	Foam, Splitter Baffle	1	
B	54675830	Foam, Splitter Baffle	1	
C	54675822	Foam, LH Baffle	1	
D	54675806	Foam, LH Baffle	1	
E	54675814	Foam, LH	1	
F	54685334	Foam, RH	1	
G	54685326	Foam, RH	1	
H	54759550	Foam, Bottom Door	1	
J	54759543	Foam, Center Door	1	
K	54759535	Foam, Top Door	1	
	54737606	Foam, LH Baffle (IQ Units)	1	
	54737598	Foam, LH Baffle (IQ Units)	1	

Wagon Wheel Foam



ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54691134	Foam, LH Splitter Baffle	1	
B	54691175	Foam, LH Splitter Baffle	1	
C	54691118	Foam, Splitter Baffle	1	
D	54691191	Foam, RH Splitter Baffle	1	
E	54691159	Foam, RH Splitter Baffle	1	
F	54670459	Foam, Bottom Door	1	
G	54760442	Foam, Middle Door	1	
H	54760434	Foam, Top Door	1	
	54737606	Foam, LH Baffle (IQ units)	1	
	54737598	Foam, LH Baffle (IQ units)	1	

Wiring Parts Lists

ELECTRICAL COMPONENTS


PART NO.	QTY	DESCRIPTION	PART NO.	QTY	DESCRIPTION
54757224	1	IQ WIRING HARNESS	35128982	1	BATTERY JUMPER
54474572	1	COOLANT LEVEL SWITCH	35578194	1	FRAME GROUND STRAP
36896975	1	BATTERY DISCONNECT SWITCH	35293075	1	ENGINE GROUND STRAP
36920825	1	0-100 PSI PRESSURE TRANSDUCER	54672803	1	FUEL LEVEL SENDER (WAGON WHEEL)
36892362	1	24V SEALED RELAY	54672811	1	FUEL LEVEL SENDER (HIGH SPEED)
36785319	1	MAG SPEED SENSOR	22173579	1	WEDGE CONTROLLER
36898922	2	THERMISTOR TEMPERATURE PROBE	22614416	1	W1 CHASSIS HARNESS
36840841	1	START / RUN SOLENOID	36864677	2	REGULATOR-HEATER & CONTROL HEATER
36842318	1	COMPRESSOR SOLENOID	36792083	2	FUSE 20 AMP BLADE
22071591	1	15 AMP BLADE FUSE	35376169	4	DIODE
36847838	2	AIR FILTER SWITCH	22108690	1	CONTROL PANEL HARNESS
36870608	1	ENGINE OIL PRESSURE SENDER	22162549	1	E-STOP SWITCH ASSEMBLY
36841138	2	ENG. & COMP. TEMP SENDER	54752308	4	DIODE
54765649	1	ADDRESS PLUG	22639728	1	CONTROL PANEL HARNESS
36850691	1	START-UP COMPRESSOR	22635387	1	E-STOP SWITCH ASSEMBLY
35577873	1	AUXILARY START RELAY			
54720701	1	ENG. TEMP. SENDER ADAPTOR			
54765367	1	NEGATIVE BATTERY CABLE			
54765375	1	POSITIVE BATTERY CABLE			
54765383	1	POSITIVE JUMPER BATTERY CABLE			

IQ OPTION		
PART NO.	QTY	DESCRIPTION
54757224	1	IQ WIRING HARNESS
54775887	1	IQ HEATER HARNESS
36841526	5	IQ ORIFICE HEATERS
36898310	1	ACTUATOR
36898922	1	THERMISTOR TEMP. PROBE
36892362	1	24V SEALED RELAY
36920643	1	ICU
36899599	1	IQ FILTER SWITCH - 20 PSI
36899615	1	IQ FILTER SWITCH - 25 PSI

AC Heater Kit


ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
	36851533	Bracket, Pressure Switch	1	
	36880995	Screw (Attach Bracket)	2	
	36879195	Nut (Attach Bracket)	2	
	54464607	AC Powered Cold Start Assy.	1	
	54464664	Harness, Pressure Switch	1	
	54480298	Well, Thermostat	1	
	54464623	Heater, Oil Pan	1	
	36920346	Pad, Heater 8D Battery	1	
	36920338	Pad, Heater 8D Battery	1	
	35283464	Elbow (In Threaded Port of Press. Switch)	1	
	35114545	Tee (In Adapter at Engine Oil Port)	1	
	35283472	Connector (In Tee Facing Lifting Bail)	1	
	22474878	DC Heater Harness (Connect to R3 on W1 Harness)	1	
	22476063	DC Heater Harness (Connect to R1 on W1 Harness)	1	
	36841526	24 Volt Heater	1	
	35283464	Elbow, 90 (In Thread Port at Press. Sw.)	1	
	35114545	Tee (In Adapter at Eng. Oil Port)	1	
	35282920	Hose Assembly (Between Elbow & Tee)	1	
	35326560	Adapter (In End of Engine Blow-by Hose-Remove Cummins)	1	

Wagon Wheel Parking Brake Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95941100	Screw	2	
B	36847432	Bracket, RH Lever	1	
C	36782878	Lever, Brake	1	
D	35603224	Plate, Spacer	2	
E		Furnished with Lever	2	
F	35603208	Clevis, Brake Lever	1	
G	35252618	Nut	4	
H	36877793	Screw	4	
J	36847440	Bracket, LH Lever	1	
K	35145077	Nut	4	
L	36786887	Bracket, LH Cable Latch	1	
	36786895	Bracket, RH Cable Latch	1	
M	95916573	Nut	8	
N	95934741	Washer	8	
P	36783306	Bracket, Front Cable Latch	1	
Q	36783785	Pin Clevis	2	
R	36786697	Bushing	2	
S	95935037	Washer	2	
T	95928867	Pin, Cotter	2	
U	36880995	Screw	2	

Wagon Wheel Parking Brake Assembly




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36782878	Lever, Brake	1	
B	35603208	Clevis, Brake Lever	1	
C	35118728	Nut	2	
D	35603182	Rod, Link	1	
E	95935086	Nut	2	
F	35603216	Equalizer, Clevis	1	
G	35602846	Equalizer, Cable	1	
H	35357151	Pin, Clevis	3	
J	95934998	Washer	3	
K	95928867	Pin, Cotter	3	
L	36783306	Bracket, Front Cable Latch	1	
M	22064141	Cable, RH Brake	1	
N	22064000	Cable, LH Brake	1	

Separator Air Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95935003	Washer	4	
B	95922902	Nut	4	
C	54668314	Support, Pipe	1	
D	35130293	Screw	4	
E	36898120	Pipe	1	
F	95927273	Screw	8	
G	54642152	Valve, Minimum Pressure	1	
H	36799419	Clamp	1	
J	35586288	Clamp	1	
K	54642137	Pipe	1	
L	95929089	Screw	4	
M	95358040	O-Ring	1	
N	95940946	Nipple	2	
P	36755718	Valve, Ball	1	
Q	95916581	Elbow	1	

Charge Air Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54632690	Tube, Bottom A/C	1	
B	54501846	Cooler, Air Charge	1	
C	54444427	Clamp	8	
D	54632682	Tube, Upper A/C	1	
E	54422522	Hose, Ribbed	4	

IQ Air Piping (Option)




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36799419	U-Bolt	2	
B	95935003	Washer	8	
C	95922902	Nut	8	
D	35586288	Clamp	2	
E	36898120	Pipe, Service (No PED with IQ)	2	
	22205090	Pipe, Service (PED with IQ)	2	
F	54642152	Valve, Minimum Pressure (No PED)	2	
	22207534	Valve, Minimum Pressure (With PED)	2	
G	95927273	Screw	36	
H	35130293	Screw	8	
J	95357976	O-Ring	3	
K	22104558	Pipe, Bypass (No PED with IQ)	1	
	22205181	Pipe, Bypass (PED with IQ)	1	
L	54735055	Pipe,Outlet (No PED with IQ)	1	
	22205207	Pipe,Outlet (PED with IQ)	1	
M	35113646	Clamp	1	
N	54734983	Pipe, Filter (No PED with IQ)	1	
	22205199	Pipe, Filter (PED with IQ)	1	Continued.....

IQ Air Piping (Option)




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
P	36893220	Adapter, Flange	3	Continued
Q	95940946	Nipple	6	
R	54738984	Filter, Secondary	1	
S	54739065	Element, Filter	1	
T	54738976	Filter, Primary	1	
U	54739057	Element, Filter	1	
V	54738968	Separator, Water	1	
W	54734090	Pipe, Filter (No PED with IQ)	1	
	22205215	Pipe, Filter (PED with IQ)	1	
X	54739016	Kit, Bracket / Wedge	1	
Y	54739024	Kit, Wedge	1	
Z	54732250	Bracket, Filters	1	
A1	54699129	Cooler Assembly	1	
A2	54700943	Louver Assembly	1	
A3	22104541	Tube, Inlet (No PED with IQ)	1	
	22205173	Tube, Inlet (PED with IQ)	1	
A4	22097489	Pipe, Tee (No PED with IQ)	1	
	22205116	Pipe, Tee (PED with IQ)	1	
				Continued.....

IQ Air Piping (Option)




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A5	54668314	Support, Pipe	2	 <i>Continued</i>
A6	95929089	Screw	32	
A7	95941027	Elbow	2	
A8	95953790	Nipple	2	
A9	95951398	Bushing	2	
B1	36755718	Valve, Ball (MSA)	3	
	22225213	Valve, Ball (PED, with IQ)	1	
B2	54393210	Nipple	1	
B3	36922995	Valve, Ball (No PED, with IQ)	1	
B4	95358040	O-Ring	8	
B5	22110571	ESA Service Valve Adapter	1	

IQ Cooler Piping (Option)




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A		To Side Outlet of Tee LH Side of Auto- Blowdown Valve		
B	35284082	Connector	1	
C	35310994	Hose Assembly	1	
D	35282995	Hose Assembly	1	
E	35322379	Valve, Blowdown	1	
	35379064	Diaphragm Kit	1	
F	35367846	Reducer	1	
G	35284082	Connector	1	
H	35283050	Tee	1	
J	35248319	Orifice, .094	1	
	36898922	Probe, Temperature	1	

IQ Filter Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54738968	Separator, Water	1	
B	95245353	Adapter	1	
C	95772562	Nipple	1	
D	36844579	Y-Strainer	1	
E	95940748	Adapter	1	
F	37081528	Orifice .063	1	
G	35283472	Connector	1	
H	36882223	Tee	1	
J	95452025	Nipple	1	
K	35310960	Hose Assembly	1	
L	35284082	Connector	1	
M	35284538	Hose Assembly	1	
N	35321983	Connector	1	
P	54738976	Filter, Primary	1	
Q	54738984	Filter, Secondary	1	
R	35283241	Hose Assembly	1	
S	35283464	Elbow	1	

IQ Indicator Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	36898401	Connector	1	
B	35290352	Elbow	1	
C	35310226	Hose Assembly	1	
D	36899599	Indicator (20 psi)	1	
E	35283464	Elbow	1	
F	35310960	Hose Assembly	1	
G	-----	To Water Separator Tube		
H	-----	To Filter Crossover Tube		
J	-----	To Filter Outlet Tube		
K	35323757	Hose Assembly	1	
L	35323591	Tee	1	
M	36899615	Indicator (25 psi)	1	
N	36920650	Hose Assembly	1	

Engine Oil Drain Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	22063937	Elbow	1	
B	35323880	Hose Assembly	1	
C	95219747	Connector	1	
D	35576115	Valve, Ball	1	
E	95928040	Nipple	1	
F	95928172	Elbow	1	

Fuel Tank Drain Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	95953535	Nipple	2	
B	95937454	Connector	1	
C	54762190	Fitting, Hose	2	
D	54762182	Hose (19")	1	
E	35221662	Clamp	2	
F	95954285	Tee	1	
G	95953873	Reducer	1	
H	95219747	Connector	1	
J	36898328	Hose Assembly	1	
K	95219747	Connector	1	
L	35576115	Valve, Ball	1	
M	95928040	Nipple	1	
N	95928172	Elbow	1	

Radiator Drain Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35326560	Connector	1	
B	95220844	Clamp	2	
C	35326578	Hose (110")	1	
D	95928172	Elbow	1	
E	95953949	Reducer	1	
F	35576115	Valve, Ball	1	
G	95928040	Nipple	1	

Separator Tank Drain Piping




ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	35294750	Elbow	1	
B	36878254	Hose Assembly	1	
C	95219747	Connector	1	
D	35576115	Valve, Ball	1	
E	95928040	Nipple	1	
F	95928172	Elbow	1	

Decal Location



ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54568803	Towing Decal (High Speed Running Gear)	1	
B	54629902	3-Part Warning Decal	1	
C	22055701	Towing Decal (Wagon Wheel)	1	
D	54568787	Improper Operation Decal	1	
E	54568779	Rotating Fan Decal	4	
F	54749205	No Weld Decal	4	
G	54604939	Fall Off Unit Decal	4	
H	36514602	Noise Emission Decal	1	
J	54568761	High Pressure Fluid Decal	2	
K	54604962	Radiator Fill Decal	1	
L	54699400	Lift Point Decal	2	
M	22383319	Oil Level Decal	1	
N	54604970	Oil Fill Decal	1	
P	54568795	High Pressure Air Decal	1	
Q	22054365	IQ Operation Decal	1	
R	22205603	Operating Instructions Decal (Instr. Pnl.)	1	
S	22056378	Operating Instructions Decal	1	
T	22164305	Containment Decal	4	

Decal Location



ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
A	54604988	Door Under Pressure Decal	1	
B	54625207	Diesel Fuel Decal	2	
C	54568753	Battery Gas Decal	1	
	54629977	Central Drain Decal	1	
	22189583	Cummins Engine Filter Decals	1	
	22846364	Wiring Diagram Laminates	1	

Section 4 - Electrical Schematics

Wiring Parts Lists

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
B2	36850691	Startup Compressor		
D1-D4	35376169	Diode		
F1,F3	36792083	20 Amp Fuse		
F2	89303184	15 Amp Fuse		
G2	36870665	Mag Speed Sensor		
K1	35577873	Auxiliary Start Relay		
K2	36892362	Relay, 24VDC SPDT		
K3	36892362	Relay, 24VDC SPDT		
L1,L2	36842300	Start / Run Solenoid Valve		
M1	36840767	Gage, 200 psi Pressure		Before S/N 375132
	36841468	Gage, 600 psi Pressure		After S/N 375131
M2	22277057	Gage, 150 psi Pressure		Before S/N 375132
	22692628	Gage, 150 psi Pressure		After S/N 375131
M3	22050991	Gage, Fuel Level		Before S/N 375132
	22692602	Gage, Fuel Level		After S/N 375131
M4	22327266	Gage, Temperature (Eng. Coolant)		Before S/N 375132
	22692610	Gage, Temperature (Eng. Coolant)		After S/N 375131
M5	54766704	Hourmeter		
M6	22055883	Tachometer		
M7	22399349	Voltmeter		Before S/N 375132
	22692594	Voltmeter		After S/N 375131
M8	22327266	Gage, Temperature (Air Discharge)		Before S/N 375132
	22692610	Gage, Temperature (Air Discharge)		After S/N 375131
PT1	54496773	0-225 psi Pressure Transducer		
PT2	36920825	0-100 psi Pressure Transducer		
R1	36864677	Regulator Heater		
R3	36841526	Control Orifice Heater		
R4	-----	Terminator, CAN		
R6	-----	Resistor, 150 ohm		
RP1	36870608	Engine Oil Press Sender		
RT1,RT2, RT5	36898922	Thermistor Temperature Sensor		
RT3, RT4	36841138	Temperature Sender		Continued.....


Wiring Parts Lists

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
S1	22127385	Switch, Start		Continued
S2	22054076	Switch, Load		
S3	22053896	Switch, Light		
S5	22054050	Switch, Heater		
S6	22054084	Switch, Hi / Lo		
S8	22054068	Switch, Ether		
S9	36757581	Switch, Air End Oil Pressure		
S10, S11	36847838	Air Filter Switch		
S12	36899615	IQ Filter Switch		
S13	36899599	IQ Filter Switch		
S14	36757581	Safety Valve Press Switch		
S15	22162549	Switch, E-stop		
U1	54672803	Sender, Fuel (Wagon)		
	54672811	Sender, Fuel (High Speed)		
U2	54474572	Switch, Water Level		
W1	22661854	Chassis Harness		


Wiring Parts Lists

ITEM	COMM. NO.	DESCRIPTION	QTY	DIMENSIONS/NOTES
		IQ OPTION PARTS		
K3	36892362	Relay, IQ		
S12	36899615	Indicator, 25 psi Pressure		
S13	36899599	Indicator, 20 psi Pressure		
RT5	36898922	Sensor, Temperature		
	54757224	IQ Wiring Harness		
	54775887	IQ Heater Harness		
	36841526	IQ Orifice Heaters		
	36898310	IQ Actuator		
	22173579	Wedge Controller		
	22108690	Control Panel Harness		Before S/N 375132
	22817829	Control Panel Harness		After S/N 375131
	36896975	Battery Disconnect Switch		
	54765367	Negative Battery Cable		
	54765375	Positive Battery Cable		
	23268105	Positive Jumper Cable		
	35128982	Battery Jumper		


0 / 1600 CUMMINS TIER 3 DL SYSTEM SCHEMATIC





INSTRUMENT PANEL SCHEMATIC




USE BEFORE SERIAL NUMBER 375132









CPN	QTY	DESCRIPTION
54757224	1	IQ WIRING HARNESS
54775887	1	IQ HEATER HARNESS
36841526	5	IQ ORIFICE HEATERS
36898310	1	ACTUATOR
36898922	1	THERMISTOR TEMP. PROBE
36892362	1	24V SEALED RELAY
36920643	1	ICU
36899599	1	IQ FILTER SWITCH

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
-----	40	22186845	9	22699201	35
-----	42	-----	19	22699219	36
-----	79	-----	20	22711766	53
-----	2	22189583	85	22711774	53
22050991	55	22189831	44	22765374	22
-----	2	22205090	74	22767453	33
22051304	19	22205116	75	-----	34
22053706	19	22205173	75	22817829	4
22053896	54	22205181	74	22846364	85
-----	3	22205199	74	23268105	58
22054050	54	22205207	74	35103498	32
-----	3	22205215	75	35103506	32
22054068	3	22205603	84	35107168	16
22054076	54	22207534	74	35108216	58
-----	3	22209779	45	35111566	17
22054084	3	22209787	45	35111590	15
22054142	54	22225213	76	-----	17
22054365	84	22277057	54	35112630	43
22055701	84	-----	2	35112648	43
22055750	59	22327266	54	35112911	32
22055800	54	-----	2	35113646	74
22055883	56	22329544	41	35114545	69
-----	2	22331557	39	35118728	71
22056378	84	-----	41	35119858	43
22060149	42	22331839	40	35123124	51
22060156	37	-----	42	35123272	43
-----	38	22332589	40	35127653	23
-----	40	-----	42	35128982	58
22061394	51	22383319	84	-----	4
22062566	37	22399349	54	35129071	43
-----	38	-----	2	35130293	72
22063937	80	22402317	44	-----	74
22064000	71	22471882	57	35131051	61
22064141	71	22471890	57	35132166	32
22065916	22	-----	59	35135458	34
22068811	45	22474878	69	35136548	38
22077515	11	22475560	59	35140722	16
-----	16	22476063	69	35141167	16
22097489	75	22495311	33	35141290	43
22104541	75	22496269	33	35144328	37
22104558	74	22496277	33	-----	38
22105571	54	22500607	37	35144336	10
22108690	4	-----	40	35145077	70
22110571	76	22501324	39	35161025	43
22110753	20	22524508	22	35192178	45
22110761	20	22648414	21	35221662	81
22112171	20	22661854	3	35221894	15
22127385	55	22692594	54	35222017	34
-----	3	-----	2	35225788	58
22134118	55	22692602	55	35248145	49
22139026	45	-----	2	35248319	77
22162549	3	22692610	54	35252618	70
22164305	84	-----	2	35253038	35
22173579	55	22692628	54	-----	36
-----	4	-----	2	35272150	11
		22694640	53		

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
35273937	21	35299767	27	35332618	30
.....	24	35299775	25	35332626	31
35277797	45	35300110	43	35332634	31
35279025	58	35300136	26	35332642	31
35279116	49	35300144	26	35332659	30
35279801	37	35300177	25	35332675	30
.....	38	35300227	25	35333830	11
35279835	49		26	35335017	49
35279934	49	35301506	51	35335124	46
.....	51	35305499	37	35336189	51
35280098	51		38	35336700	10
35280510	49	35307131	23	35356484	35
35282920	69	35307537	53		36
35282953	49	35307545	53	35357052	32
35282961	51	35307552	53	35357151	71
35282979	51	35307560	53	35358662	49
35282987	49	35307586	53	35360775	22
35282995	77	35307784	24	35365261	25
35283050	49	35309210	37	35365279	27
.....	77		38	35365774	49
35283092	49	35310226	79	35367044	12
.....	51	35310598	34	35367051	12
35283126	49	35310960	78	35367069	24
35283241	78		79		25
35283464	69	35310994	51	35367846	51
.....	78		77		77
.....	79	35313428	42	35369339	35
35283472	69	35314582	55		36
.....	78	35319045	15	35369354	35
35284082	77	35321520	28		36
.....	78	35321983	78	35373877	27
35284538	49	35322346	49	35375377	24
.....	78	35322379	77	35375385	24
35285451	39	35322395	35	35376169	2
.....	41		36	35379064	77
35285600	34	35322908	32	35388982	43
35286756	38	35323591	79	35389964	37
.....	42	35323757	79		38
35287911	49	35323880	80	35389972	37
35290147	49	35324839	51		38
35290253	51	35325083	42		40
35290352	79	35326560	34		42
35293869	27		69	35505866	43
35294453	49		82	35562156	58
35294750	44	35326578	34	35576115	34
.....	83		82		80
35295336	25	35327303	39		81
.....	27		41		82
35296409	46		57		83
35297340	21	35327311	39	35577873	2
35298470	26		41	35584556	21
35298512	49		57		24
35299403	28	35330117	49	35586288	72
35299429	29		51		74
35299569	25	35330570	34	35588755	16
.....	28	35331586	31	35588839	17

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
35588953	16	36753259	15	36841468	56
35588961	15	36754059	24		2
35589241	17	36754141	27	36841526	69
35594811	30	36754414	44		2
35594829	30	36755163	43		4
35594837	30	36755718	72	36841815	49
35594845	31		76	36842086	51
35594860	30	36755742	60	36842094	51
35594878	30	36755981	60	36842300	2
35594910	30	36756906	46	36844124	55
35596626	25	36757581	44	36844579	78
35602812	32		3	36845014	37
35602846	71	36758142	26		38
35603182	71	36758902	43		40
35603190	11	36762623	49		42
35603208	70	36762961	44	36845022	37
	71	36763670	21		38
35603216	71	36764371	45		40
35603224	70	36764389	45		42
35605203	25	36764983	17	36845600	22
	26	36765121	44	36845733	39
35606920	29	36776813	11		41
35610278	28		17	36847002	20
35610286	26	36776821	18	36847432	70
35610591	26	36776839	18	36847440	70
35610617	44	36780609	4	36847838	43
35610674	45	36782878	70		3
35611235	23		71	36849925	59
35802933	45	36783306	70	36850691	2
35820646	27		71	36851376	16
35820653	27	36783488	58	36851384	16
35820661	27	36783785	70	36851533	69
35834621	17	36786697	70	36851566	15
35849348	25	36786887	70	36851574	15
35851195	26	36786895	70	36851590	11
35851351	23	36787968	12		17
36140730	15	36788081	12	36851608	11
36504330	28	36792083	2		18
36504355	28	36792380	52	36851616	11
36504389	15	36792927	52		17
36506756	46	36793602	59	36851624	11
36514602	84		62		18
36711083	25	36794303	45	36851632	11
36719169	15	36794790	52		18
	18	36794808	52	36851640	17
36719177	15	36799419	72	36851665	17
	18		74	36852499	51
36719219	16	36799807	23	36852622	55
36719466	15	36840460	49	36853042	16
	17	36840767	56	36853091	11
36719557	16		2		17
36729416	30	36840841	49	36853109	11
36729465	31		51		17
36729531	24	36840908	55	36853117	11
36740405	57	36841138	22		17
36753242	16		2	36854495	49

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
36856060	27	36880342	11	39927058	28
36856656	44	36880995	23	39927496	28
36859320	12		43	39927504	29
36862886	43		69	39927512	25
36863363	59		70	39927520	25
36863371	59	36882223	78	39927538	25
36863413	59	36884047	21	39927546	25
36863652	59	36892362	2	42469676	27
36863660	59		4	42469809	24
36863702	51	36893220	75	43212216	34
36864288	61	36893634	12	54363536	27
36864304	61	36893642	12	54393210	76
36864346	43	36894129	12	54409339	21
36864361	43	36894467	39	54422522	73
36864379	43		41	54444427	73
36864403	61	36895860	12	54464607	69
36864677	2	36896306	12	54464623	69
36867778	43	36896975	58	54464664	69
36870350	58		4	54474572	34
36870608	22	36897148	31		3
	2	36897346	46	54480298	69
36870665	2	36898096	55	54496773	51
36877793	70	36898104	55		2
36877991	11	36898120	72	54501796	9
	16		74		19
36878049	11	36898310	4		20
	16	36898328	81	54501846	33
36878254	44	36898401	79		73
	83	36898922	45	54501853	33
36879195	23		77	54507439	33
	43		2	54507447	33
	69		4	54507454	33
36879492	21	36899599	79	54507462	33
	44		3	54507470	33
36880128	10		4	54507488	33
36880136	10	36899615	79	54540141	24
36880144	10		3	54542535	24
36880151	10		4	54542543	8
36880169	12	36920338	69	54568753	85
36880177	12	36920346	69	54568761	84
36880185	12	36920650	79	54568779	84
36880193	10	36920825	49	54568787	84
36880201	10		2	54568795	84
36880219	10	36922144	12	54568803	84
36880227	10	36922995	76	54570122	21
36880235	10	36A2D326Z1	18	54576871	59
36880243	10	37081528	78	54576921	62
36880250	10	39101472	27		63
36880268	11	39102355	31	54576947	59
36880276	11	39179072	19	54576970	60
36880284	10		20	54584784	60
36880292	11	39871306	46	54587944	59
36880300	11	39926787	27	54587951	59
36880318	11	39926902	28	54587969	59
36880326	11	39926910	28	54587977	59
36880334	11	39926928	28	54587985	59

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
54594080	35	54668314	72	54734090	75
54594106	36		76	54734983	74
54599915	61	54670459	66	54735055	74
54599923	61	54672753	62	54737400	58
54599931	61	54672761	62	54737598	65
54599949	61	54672779	62		66
54599956	43	54672803	38	54737606	65
54603204	23		3		66
54603774	23	54672811	37	54738752	23
54604939	84		3	54738968	75
54604962	84	54675806	65		78
54604970	84	54675814	65	54738976	75
54604988	85	54675822	65		78
54612403	45	54675830	65	54738984	75
54612429	44	54675848	65		78
54612437	44	54685326	65	54739016	75
54616552	23	54685334	65	54739024	75
54616560	23	54687322	21	54739057	75
54625173	46	54688221	63	54739065	75
54625207	85	54688239	63	54744149	45
54625348	46	54690110	60	54747316	60
54625355	46	54690128	60	54747324	60
54625363	46	54690136	61	54749205	84
54627799	44	54691118	66	54757224	4
54628177	46	54691134	66	54759519	64
54628185	46	54691159	66	54759527	64
54629126	23	54691175	66	54759535	65
54629589	23	54691191	66	54759543	65
54629902	84	54692744	62	54759550	65
54629977	85	54699046	64	54760202	8
54632682	73	54699087	64	54760434	66
54632690	73	54699129	75	54760442	66
54637996	34	54699400	84	54762182	81
54638101	34	54699731	52	54762190	81
54640966	62	54699749	52	54765367	58
54640974	62	54699756	52	54765375	58
54640982	62	54700091	60		4
54641006	62	54700943	75	54765383	4
54641022	62	54706825	58	54766704	56
.....	63	54710041	64		2
54642137	72	54715479	58	54774526	33
54642152	72	54718184	59	54775887	4
.....	74		62	89303184	2
54661426	33	54719646	64	92304500	32
54661459	33	54719653	64	92368687	35
54661533	21	54719661	64		36
54662010	23	54719695	64		39
54662028	22	54719703	64		41
54662036	22	54719711	64		57
54662051	22	54720057	64	95018982	15
54663224	60	54720065	64		17
54663232	60	54720719	32	95043196	32
54663240	59	54721105	23	95077608	10
54663281	62	54721204	64	95098703	16
54663299	62	54721675	64	95104147	30
		54732250	75	95201455	16

NUMERICAL INDEX

COMM.NO.	PAGE	COMM.NO.	PAGE	COMM.NO.	PAGE
95219747	44	95928222	30	95953949	34
.....	80		31		82
.....	81	95928800	55	95954079	20
.....	83	95928867	70	95954095	49
95220844	22		71	95954194	49
.....	34	95929089	72	95954210	51
.....	82		76	95954285	45
95235131	34	95930301	32		51
95239927	15		44		81
95245353	78		49	95989554	49
95264776	34		51	95994877	20
95272902	17	95934170	44	96700901	19
95279378	37	95934253	21		20
.....	40	95934626	24	96700919	24
95285599	26	95934741	12	96701750	19
95286910	46		18		20
95287629	49		70	96701917	53
95318556	16	95934956	16	96702287	31
.....	17	95934998	39	96702659	30
95332599	42		41	96706080	25
95338554	15		57	96706262	26
95352944	28		71		27
95357976	46	95935003	72	96716162	28
.....	74		74	96720610	8
95358040	72	95935011	10		9
.....	76		21		
95358214	25	95935037	58		
95358446	28		70		
95452025	78	95935086	71		
95603130	28	95937454	81		
95673042	15	95939955	11		
95717369	15	95940748	45		
95717377	16		49		
95730172	40		51		
.....	41		78		
95772562	78	95940912	45		
95916573	18	95940920	21		
.....	70	95940946	72		
95916581	72		75		
95922902	72	95941027	76		
.....	74	95941092	24		
95923314	39	95941100	70		
.....	41	95942108	45		
.....	57	95944575	49		
95923322	58	95944617	49		
95923363	21	95944625	49		
95927273	72	95944633	49		
.....	74		51		
95928040	80	95944690	49		
.....	81		51		
.....	82	95951398	76		
.....	83	95953311	45		
95928172	80	95953535	81		
.....	81	95953790	76		
.....	82	95953873	81		
.....	83				

WORD INDEX

CPN

0-100 psi Pressure Transducer	2
0-225 psi Pressure Transducer	2
15 Amp Fuse	2
20 Amp Fuse	2
24 Volt Heater	69
3 Light Assembly	12
3-Part Warning Decal	84
7-Way Connector	12

A

AC Powered Cold Start Assy.	69
Adapter	
Flange	75
Adapter (In End of Engine Blow-by Hose-	69
Adapter (To Engine Charge Air Return)	32
Air Cleaner Assembly	43
Air End Assembly	24
Air Filter Switch	3
Alternator Belt	22
Angle	
Door Drip	59
Rear Mounting	63
Arm	
Center	16
Atomizer	32
Auxiliary Start Relay	2
Axle	
Front	15
Rear	17

B

Baffle	
LH	63
LH Inside	62
LH Outside	62
RH	63
RH Inside	62
Bail	
Lifting	8, 9, 19, 20
Ball Joint	
Outer	15
Balljoint	
Inner	16
Bar	
Equalizer	10
Shock Mount Rest	20
Battery	58
Battery & Mounting	58
Battery Disconnect Switch	4
Battery Gas Decal	85
Battery Jumper	4
Body	
Check Valve	52
Unloader	30
Valve	53

Bolt

Equalizer	10
M16 X 50	20
Shackle	10, 15
Bolt Shackle	17

Bottle

Overflow	22
----------	----

Brace

Center Roof	60
Front	59
Front Panel	59
Top Foam	60

Bracket

Air Cleaner	43
Air End	24
Bottom	51
Engine	21
Filler	60
Filter	46
Filters	75
Front Cable Latch	70, 71
LH Cable Latch	70
LH Lever	70
Overflow	22
Pressure Switch	69
RH Cable Latch	70
RH Lever	70
Switch	58
Top	51

Breather	35, 36
----------	--------

Bumper

Rubber	10
--------	----

Bushing

Housing	31
Reducing	45

C

Cable	61
Jumper	58
LH Brake	71
Master Switch	58
Negative	58
Positive	58
RH Brake	71

Cap

Corner	60
Dust	11
Front End	60
Fuel Fill	40, 42
Fuel Tank	37, 38
Grease	17
LH Front Side	60
LH Rear Side	60
Rain	23
Rear End	60
RH Front Top	60
RH Rear Top	60
Central Drain Decal	85

WORD INDEX

Chassis Harness	3
Check Valve Assembly	52
Chock	
Wheel	11
Clamp	
Plate	11
Seal	23
Clevis	
Brake Lever	70, 71
Clip	58
Connector	
Bulkhead	42
Connector (In Tee Facing Lifting Bail)	69
Containment Decal	84
Control Orifice Heater	2
Control Panel Harness	4
Control System Wiring Diagram	6, 7, 8, 9
Cooler	
A/C Fuel	33
Air Charge	73
Cooler Assembly	75
Cooler Oil	33
Cover	
Battery	58
Fuel	42
Fuel Fill	40
Fuel Tank Clean-out	37, 38
Piston	30
Tank	44
Crossmember	
LRG	19
Cummins Engine Filter Decals	85
Cylinder	
Ether	32

D

DC Heater Harness (Connect to R1 on W1	69
DC Heater Harness (Connect to R3 on W1	69
Diaphragm	30
Diaphragm Kit	77
Diesel Fuel Decal	85
Diode	2
Discharge Hose Assembly	44
Door	
Front	59
Fuel Access Side	39, 41
Fuel Fill	39, 41
Instrument Panel	57
Rear	62
Roof	61
Side	59
Door Under Pressure Decal	85
Dowel	25, 27
Drawbar	16

E

Elbow	
90	42
90 (In Thread Port at Press. Sw.)	69
Rubber	43
Elbow (In Threaded Port of Press. Switch)	69
Elbow Rubber	43
Element	
Filter	46, 75
Primary	43
Safety	43
Separator	44
Valve	53
Engine	
QSX-15 Cummins - Tier 2	21
QSX-15-C600 Cummins - Tier 3	21
Engine Belt	22
Engine Filters	22
Engine Fuel Filter	22
Engine Oil Filter	22
Engine Oil Press Sender	2
Engine Water Separator Filter	22
Equalizer	
Cable	71
Clevis	71
ESA Service Valve Adapter	76
Evacuator	43
Eye	
Pintle	10
Eyebolt	39, 41, 57

F

Fall Off Unit Decal	84
Fan Assembly	21
Fan Guard Assembly	33
Filler	
Neck And Cover	37, 38
Filter	
Primary	75, 78
Secondary	75, 78
Fitting	
Barbed	34
Bulkhead	51
Hose	81
Lube	15, 16, 17
Scavenge	45
Flange	
Brake Mounting	18

WORD INDEX

Foam

Bottom Door	65, 66
Center Door	64, 65
Center Panel	40, 42, 64
Center Top	64
Door	64
LH	65
LH Baffle	65
LH Baffle (IQ Units)	65
LH Baffle (IQ units)	66
LH Front Top	64
LH Side	64
LH Splitter Baffle	66
Middle Door	66
Rear	64
Rear Top	64
RH	65
RH Front	64
RH Rear Side	64
RH Splitter Baffle	66
RH/LH Rear Side	64
Side Door	40, 42
Splitter Baffle	65, 66
Top	64
Top Door	65, 66

Frame	58
Frame Assembly	8, 9, 19, 20
Front Axle Assembly	16
Fuel Piping	37, 38, 39, 40, 41, 42
Fuel Return on Engine	37, 38
Fuel Tank Vent Piping	35, 36
Furnished with Lever	70

G

Gage

150 psi Pressure	2
200 psi Pressure	2
600 psi Pressure	2
Air Discharge Temperature	54
Discharge Pressure	56
Engine Oil Pressure	54
Fuel Level	55, 2
Temperature (Air Discharge)	2
Temperature (Eng. Coolant)	2
Voltage	54
Water Temperature	54

Gasket

Cover	37, 38
Valve	53

Gasket (Top Of Element)	44
---------------------------	----

Gear Case	25
-----------	----

Gear Set

HP-1300	26
HP-1600	26

Glass

Sight	44
-------	----

Grille

LH Front Side	59
RH Front Side	59

Grommet (Use on Item C & E)	12
-----------------------------	----

Grommet (Use on Item F)	12
-------------------------	----

Ground Strap From Starter	58
---------------------------	----

Ground Strap To RH of Engine	58
------------------------------	----

Guard

Turbo	21
-------	----

H

Hanger

Center	10
Front	10
Rear	10

Harness

Pressure Switch	69
-----------------	----

Harness)	69
-----------	----

Head

Filter	46
--------	----

Heater

Oil Pan	69
---------	----

High Pressure Air Decal	84
-------------------------	----

High Pressure Fluid Decal	84
---------------------------	----

Hinge	39, 41, 55, 57, 59, 62
-------	------------------------

Door	61
------	----

Hose

By-Pass	34
---------	----

Connector	34
-----------	----

Drain	34
-------	----

Hump	43
------	----

Ribbed	73
--------	----

Vent	34
------	----

Hose (110")	82
---------------	----

Hose (19")	81
--------------	----

Hose Assembly (Between Elbow & Tee)	69
---------------------------------------	----

Hourmeter	56, 2
-----------	-------

Housing

Front Bearing	27
---------------	----

Piston	31
--------	----

Rear Bearing	27
--------------	----

Rotor	27
-------	----

Hub Assembly	11
--------------	----

Hub Assembly (Includes Items N

L

A2)	17
-----	----

I

ID Bracket	12
------------	----

Improper Operation Decal	84
--------------------------	----

Indicator

20 psi Pressure	4
-----------------	---

25 psi Pressure	4
-----------------	---

Indicator (20 psi)	79
----------------------	----

Indicator (25 psi)	79
----------------------	----

Inner Bearing	11, 18
---------------	--------

Inner Bearing Cup	11
-------------------	----

WORD INDEX

Inner Race 18
Instrument Panel Assembly 57
Instrument Panel Assembly (Begins with S/N 332157)
54, 55, 56
Into Fuel Filter on Engine 40, 42
Into Fuel filter on Engine 37, 38
IQ Actuator 4
IQ Air Piping 74, 75, 76
IQ Cooler Piping 77
IQ Filter Switch 3
IQ Heater Harness 4
IQ Operation Decal 84
IQ OPTION PARTS 4
IQ Orifice Heaters 4
IQ Wiring Diagram 11
IQ Wiring Harness 4
Isolator
 Shear Mount 20

J

Jack
 Dropleg 10

K

Key 25, 26
 Bushings 24
Kit
 Bracket / Wedge 75
 Wedge 75
 Wrap Wire Kit 23
Knob
 Switch 55

L

Latch 16
 Door 59, 61
 Door Slam 59, 62
Lever
 Brake 70, 71
LH Electric Brake 11
LH Knuckle Assembly 15
Lift Point Decal 84
Light
 Instrument Panel 55
 License Plate 12
Liner
 Shell 44
Louver Assembly 75
LRG Pedestal Mount on Wagon Wheel Frame
Assembly 19
LRG Shock Mount on Wagon Wheel Frame Assembly
20

M

Mag Speed Sensor 2
Module
 Wedge 55

Mount
 Rubber 21, 24
Muffler 23

N

Negative Battery Cable 4
No Weld Decal 84
Noise Emission Decal 84
Nut 58
 Jam 15, 16
 M16 19, 20
 Stud 18
 Wing 43
Nut (Attach Bracket) 69

O

Oil Fill Decal 84
Oil Level Decal 84
Oil Temp. By-pass Valve Assembly 53
Operating Instructions Decal 84
Operating Instructions Decal (Instr. Pnl.) 84
Orifice 51
 .094 77
 .156 49
Orifice .063 78
Orifice LH Fan 33
Orifice RH Fan 33
Outer Bearing 11, 17
Outer Bearing Cup 11
Outer Race 17
Overlay
 Module 54

P

Pad
 Heater 8D Battery 69
Panel
 2nd and 4th Top 61
 Center 59
 Center Side 39, 41
 Center Top 61
 Front Top 61
 Instrument 54
 LH Front 59
 LH Front (IQ Units) 59
 LH Rear Corner 62
 LH Rear Side 59, 62
 Rear Side 59
 Rear Top 61
 RH Front 59
 RH Front (IQ Units) 59
 RH Rear 62
 RH Rear Corner 62
 RH Rear Side 59
 Vertical 57

WORD INDEX

Pin	25, 27
Center	16
Clevis	71
Cotter	15, 16, 17, 70, 71
Hinge	16
King	15
Roll	15, 16
Pin Clevis	70
Pipe	72
Bypass (No PED with IQ)	74
Bypass (PED with IQ)	74
Engine Turbo	23
Exhaust	23
Exhaust (IQ)	23
Exhaust (Standard)	23
Filter (No PED with IQ)	74, 75
Filter (PED with IQ)	74, 75
Outlet (No PED with IQ)	74
Outlet (PED with IQ)	74
Safety Valve	45
Service (No PED with IQ)	74
Service (PED with IQ)	74
Tee (No PED with IQ)	75
Tee (PED with IQ)	75
Piston	30, 52
Plate	
Clamp	17, 25, 27, 28, 29
Cover	33
Radiator Fill	61
Spacer	70
Tie	62
U-Bolt	12
Plug	
Oil Fill	45
Switch	54
Positive Battery Cable	4
Positive Jumper Cable	4
Probe	
Temperature	77

R

Radiator	33, 34
Radiator Fill Decal	84
Rear Axle Assembly	16
Receptacle	55
Red Clearance Light	12
Reducer	35, 36, 49, 51, 77, 81, 82
Regulator	49
Regulator Heater	2
Relay	
24VDC SPDT	2
IQ	4
Remove Cummins)	69
Resistor	
150 ohm	2
RH Electric Brake	11
RH Knuckle Assembly	15

Ring	
Clamp	16
Rod	
Link	71
Tie	15
Rotating Fan Decal	84
Rotor Set	27

S

Safety Valve Press Switch	3
Screw	58
Hex 1/2-20 X 1.0	20
Hex 1/2-20 X 2.0	20
M16 X 50	19
Quarter Turn	55
Screw (Attach Bracket)	69
Seal	
Valve	53
Seat	
Valve	53
Sender	
Fuel (High Speed)	3
Fuel (Wagon)	3
Fuel Level	37, 38
Pressure (RH Side of Engine)	22
Temp. (Side of Water Pump in Bushing)	22
Sensor	
Temperature	45, 4
Separator	
Water	75, 78
Service Kit (Includes Items	
E	
F	
& G)	53
Shield	
Bottom Dust	11
Top Dust	11
Shim (.051mm)	28, 29
Shim (.076mm)	28
Shim (.254mm)	28
Shim (1.016mm)	25
Silencer	49
Sleeve	
Valve	53
Spacer	
Fan	21
Spring	
Check Valve	52
Door Latch	39, 41
Leaf	10
Main	52
Piston	30
Valve	30
Start / Run Solenoid Valve	2
Startup Compressor	2
Stem	
Valve	30
Step	23

WORD INDEX

Stop
 Turn and Tail Light 12
 Strainer 40
 Fuel 42
 Fuel Tank 37, 38
 Strap
 Rubber 11
 Strip
 Foam Retention 62
 Panel Support 62
 Support 62
 Stud 11, 17, 58
 Support
 Baffle 63
 Bottom Shroud 33
 LH Rear Shroud 33
 LH Shroud 33
 Lower Shock Mount 20
 LRG 19
 Pipe 23, 72, 76
 RH Shroud 33
 Top Rear Shroud 33
 Top Shroud 33
 Upper Shock Mount 20
 Support RH Rear Shroud 33
 Switch
 After Warm-Up 54
 Air Filter 43
 E-stop 3
 Ether 3
 Heater 3
 Heather 54
 Hi / Lo 3
 Lamps 54
 Level 34
 Light 3
 Load 3
 Master Cut-Off 58
 Pressure 44
 Start 3
 Starter 55
 Water Level 3

T

Tachometer 56, 2
 Tank
 L.H. Fuel 35, 36
 R.H. Fuel 35, 36
 Separator 45
 Separator (EEC) 45
 Separator (Japanese) 45
 Tee (In Adapter at Eng. Oil Port) 69
 Tee (In Adapter at Engine Oil Port) 69
 Temperature Sender 2
 Terminator
 CAN 2
 Thermistor Temperature Sensor 2

Tie Rod Assy. (Includes A
 B
 C
 A3
 A4) 16
 Tire 11, 16
 To Filter Crossover Tube 79
 To Filter Outlet Tube 79
 To Side Outlet of Tee LH Side of Auto-Blowdown Valve
 77
 To Water Separator Tube 79
 Towing Decal (High Speed Running Gear) 84
 Towing Decal (Wagon Wheel) 84
 Tray
 Battery 58
 Tube 43
 Bottom A/C 73
 Inlet (No PED with IQ) 75
 Inlet (PED with IQ) 75
 Lower Radiator 34
 Scavenge 45
 Upper A/C 73
 Upper Radiator 34
 Tube Assembly 46, 49
 Tubing 32
 Tubing (18 Inches) 35, 36

U

Union 39, 41
 Unloader Assembly 24

V

Valve 31
 Ball 34, 51, 72, 80, 81, 82, 83
 Ball (MSA) 76
 Ball (No PED
 with IQ) 76
 Ball (PED
 with IQ) 76
 Blowdown 49, 77
 Check 49
 Minimum Pressure 72
 Minimum Pressure (No PED) 74
 Minimum Pressure (With PED) 74
 Safety 45, 51
 Solenoid 49, 51
 Unloader 30
 Valve and Bracket Assembly 32
 Voltmeter 2

W

Washer 10, 11, 15, 16, 21, 24, 32, 39, 41, 57, 58, 70,
 71, 72, 74
 Flat 17, 18
 Lock 11, 12, 17
 Piston 30
 Wedge Controller 4

WORD INDEX

Well

Thermostat 69

Wheel 11, 16

Wiring Diagram Laminates 85

Wiring Parts Lists 2, 3, 4

Wrap

Exhaust 23

Y

Yellow Light 12

Y-Strainer 78

WORD INDEX



Ingersoll Rand Company
Utility Equipment
P.O. Box 868 - 501 Sanford Ave
Mocksville, N.C. 27028