




Portable Power

G45/60XW/XF-50Hz - G48/71XW/XF-60Hz

PARTS MANUAL

**SERIAL No : G45XWNCJ500001->, G45XFNCJ500001->, G48XWNCJ600001->, G48XFNCJ600001->,
G60XWNCJ500001->, G60XFNCJ500001->, G71XWNCJ600001->, G71XFNCJ600001->.**





Portable Power

CONTENTS

MAIN FRAME

MAIN FRAME (G40/48)	2
MAIN FRAME (G60/71)	4
ENCLOSURE	6
DECALS AND DOCUMENTATION	8

ELECTRICAL SYSTEM

ALTERNATOR MOUNTING (G45/48)	10
ALTERNATOR S1L2-N1 SINGLE BEARING (G45/48)	12
ALTERNATOR MOUNTING (G60/71)	14
ALTERNATOR S1L2-Y1 SINGLE BEARING (G60/71)	16
POWER PEDESTAL ASSEMBLY	18

POWER UNIT

EXHAUST SYSTEM	20
ENGINE ASSEMBLY (G45/48)	22
ENGINE ASSEMBLY (G60/71)	24
ALTERNATOR	26
CAM SHAFT & ROCKER ARM	28

CONTENTS

CONNECTING ROD ASSEMBLY	32
COOLING SYSTEM	34
CRANKSHAFT	36
CYLINDER BLOCK	38
CYLINDER HEAD	42
DIPSTICK ARRANGEMENT	44
EXHAUST MANIFOLD	46
FUEL FILTER	48
FUEL INJECTION PUMP	50
FLYWHEEL	52
INJECTOR	54
LUBRICATION SYSTEM	56
PISTON ASSEMBLY	60
STARTER	62
TURBO CHARGER	64
SENSOR, MAGNETIC PICKUP (G45/60)	66
AIR FILTER INSTALLATION HEAVY DUTY (G45/60)	68
AIR FILTER INSTALLATION NORMAL DUTY (G48/71)	70
AIR FILTER EXPLODE NORMAL DUTY (G48/71)	72
COOLING SYSTEM INSTALLATION S3.8 G6 (G45)	74
COOLING SYSTEM INSTALLATION S3.8 G8 (G48)	76

CONTENTS

COOLING SYSTEM INSTALLATION S3.8 G7 (G60)	78
COOLING SYSTEM INSTALLATION S3.8 G10 (G71)	80
ELECTRICAL COIL INSTALLATION	84
ENGINE INSTALLATION S3.8 G6 (G45)	86
ENGINE INSTALLATION S3.8 G8 (G48)	88
ENGINE INSTALLATION S3.8 G7 (G60)	90
ENGINE INSTALLATION S3.8 G10 (G71)	92
SENSOR INSTALLATION	94

MAINTENANCE ITEMS

CLASS 1 MAINTENANCE AND REPAIR ITEMS (G45/48)	96
CLASS 2 EXTENDED DOWNTIME PREVENTION (G45/48)	98
CLASS 1 MAINTENANCE AND REPAIR ITEMS (G60/71)	102
CLASS 2 EXTENDED DOWNTIME PREVENTION (G60/71)	104

INDEXES	1
---------	---


Numerical Index	1
-----------------	---

CONTENTS

Word Index	1
------------------	---

G45/60XW/XF-50Hz - G48/71XW/XF-60Hz_46720010_B_08/18


**MAIN FRAME
(G40/48)**



MAIN FRAME (G40/48)	
---	--

[illegible]


MAIN FRAME
(G60/71)



MAIN FRAME (G60/71)	
---	--

[illegible]

ENCLOSURE



ENCLOSURE

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46720032	PANEL	LH CORNER, ALT SIDE		1
2	46720033	PANEL	RH CORNER, ALT SIDE		1
3	46720034	PANELE	LH CORNER, RAD SIDE		1
4	46720035	PANEL	RH CORNER, RAD SIDE		1
5	46720036	DOOR	BARE LH		1
6	46720037	DOOR	BARE RH		2
7	46720038	CUTOUT DOOR, PANEL			1
8	46720039	JOINT	VERT LH/RH		2
9	46720040	JOINT	LH HORIZ EMERGENCY		1
10	46720041	JOINT	LH HORIZ		1
11	46720042	JOINT	RH HORIZ		2
12	46720043	HORIZONTAL	ALTERNATOR SIDE		2
13	46720044	RADIATOR PANEL	SIDE HORIZ		2
14	46720045	LOUVER ASSY	ALT SIDE		1
15	46720046	RADIATOR SIDE COVER			1
16	46720047	ROOF PANEL	ALT SIDE		1
17	46720048	ROOF PANEL	RAD SIDE		1
18	46721259	BOLT	M8 X 25 LG		170
19	46721260	NUT	M8		170
20	46721261	WASHER FLAT	M8 GI		340
21	46706518	LOCK ASSY	SAME KEY NUMBER		1
22	46706654	DOOR CATCH			1
23	46706653	HINGE	120X60MM		2
24	46717245	NUT	M6		6
25	46716436	BOLT	M6 X 20 LG		2
26	46706638	RADIATOR COVER			1
27	46726125	ROOF, MIDDLE			1

4 — **G45XF**

11 — **G45XW**

20 — **G48XF**



24 — **G48XW**

25 — **G60XF**

26 — **G60XW**

27 — **G71XF**

28 — **G71XW**







23 — **DoosanPortablePower.eu**



21 — **DOOSAN**

1 — **DOOSAN**

2 — **DoosanPortablePower.eu**



18




19



DECALS AND DOCUMENTATION

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46573921	DECAL, DOOSAN LOGO			2
2	46656744	DECAL, WEB SITE			1
3	46573860	DECAL, DOOSAN TRI-COLOUR 12"			1
4	46721856	DECAL, MODEL NUMBER	45XF		1
5	46573859	DECAL, DOOSAN TRI-COLOUR 8"			1
6	92930593	DECAL, ELECTRIC SHOCK			5
7	92867449	DECAL, REFER TO HANDBOOK			1
8	93171254	DECAL, DIESEL FUEL SYMBOL			1
9	54629977	DECAL, ISO CENTRAL DRAIN			1
10	23047624	DECAL, COOLANT LEVEL			1
11	46718030	DECAL, MODEL NUMBER	45XW		2
12	92867530	DECAL, HOT SURFACE ISO			4
13	23047566	DECAL, NO WATER			2
14	93171288	DECAL, COOLANT FILL			1
15	92912559	DECAL, EARTH WARNING			2
16	23047582	DECAL, WARNING			2
17	93171262	DECAL, LIFT HERE			4
18	46717252	MANUAL, OPERATION MAINTENANCE			1
19	46720010	MANUAL, PARTS			1
20	46721858	DECAL, MODEL NUMBER	48XF		1
21	46715886	DECAL, DOOSAN LOGO			2
22	54642327	DECAL, BATTERY DISCONNECT			1
23	46715887	DECAL, WEB SITE WHITE			1
24	46718033	DECAL, MODEL NUMBER	48XW		2
25	46721862	DECAL, MODEL NUMBER	60XF		1
26	46718032	DECAL, MODEL NUMBER	60XW		2
27	46721865	DECAL, MODEL NUMBER	71XF		1
28	46718034	DECAL, MODEL NUMBER	71XW		2


ALTERNATOR MOUNTING (G45/48)



ALTERNATOR MOUNTING (G45/48)

[illegible]


ALTERNATOR S1L2-N1 SINGLE BEARING (G45/48)



**ALTERNATOR S1L2-N1 SINGLE BEARING
(G45/48)**

[illegible]


ALTERNATOR MOUNTING (G60/71)



ALTERNATOR MOUNTING (G60/71)

[illegible]


ALTERNATOR S1L2-Y1 SINGLE BEARING (G60/71)



**ALTERNATOR S1L2-Y1 SINGLE BEARING
(G60/71)**

[illegible]


POWER PEDESTAL ASSEMBLY



POWER PEDESTAL ASSEMBLY

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46717262	PANEL, CONTROL			3
2	46721912	CIRCUIT BREAKER	G45/48 80A TP		1
2	46730726	CIRCUIT BREAKER	G48 160A TP		1
2	46716438	CIRCUIT BREAKER	G71 200A TP		1
2	46716441	CIRCUIT BREAKER	G60/71 100A TP		1
3	46716452	DOOR, CONTROL			1
4	46717291	WIRE TERMINAL BLOCK STOPPER			2
5	46716442	COVER PLATE, BREAKER			1
6	46717225	BRACKET, BREAKER GI MOUNTING			1
7	46717227	BOX, CONTROL PANEL GI MOUNTING			1
8	46717226	BOX, BREAKER GI MOUNTING			1
9	46706537	CONTROLLER	DSE 6010		1
10	46721250	DIN RAIL	Lenght 0.3m		1
11	46721251	TRUNKING	25X40 mm		1
12	46706563	FUSE CYLINDRICAL	10X38 20A		1
13	46706564	FUSE CYLINDRICAL	10X38 2A		3
14	46706643	RELAY	12VDC		3
15	46706560	FUSE CARRIER	ABN32A - STI 10.38X38		4
16	46706649	BUS BAR	20X5MM - Length 0.3m		1
17	46719980	BUSBAR INSULATOR	30X6MM		2
18	46719985	CABLE GLAND			1
19	46719986	CABLE GLAND			2
20	46706536	CURRENT TRANSFORMER	100/5A		3
20	46720067	CURRENT TRANSFORMER	G48/71 200/5A		3
21	46719987	RELAY	12V DC 40A (FOR FUEL)		1
22	46719988	WIRE TERMINAL BLOCK	2.5MM		8
23	46706619	LOCKABLE KNOB	WITH LATCH AND KEY		1
24	46706618	HINGES			2
25	46716428	BOLT	M6 X 15 LG HEX GI		16
26	46719990	BOLT	M8 X 30 LG HEX GI		16


EXHAUST SYSTEM



EXHAUST SYSTEM	
----------------	--

[illegible]


ENGINE ASSEMBLY (G45/48)



ENGINE ASSEMBLY (G45/48)

[illegible]


ENGINE ASSEMBLY (G60/71)



ENGINE ASSEMBLY (G60/71)

[illegible]


ALTERNATOR



ALTERNATOR	
--	--

[illegible]


CAM SHAFT & ROCKER ARM



CAM SHAFT & ROCKER ARM

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46709490	CAMSHAFT			1
2	46716786	CAMSHAFT GEAR			1
3	46727507	THRUST WASHER			1
4	46717086	SCREW			4
5	46716891	DRIVE GEAR			1
6	46716789	BUTTING RING			1
7	46722670	PARALLEL KEY			1
8	46722673	PIN			1
9	46722814	VALVE TAPPET			8
10	46727473	PUSH ROD			8
11	46716736	ASSY. ROCKER ARM			4
12	46716740	ASSY. ROCKER ARM			4
13	46716785	BUSH			4
14	46716741	TAPPET ADJUSTER			4
15	46717084	NUT			4
16	46722771	SPRING			3
17	46716738	ASSY. ROCKER ARM SHAFT			1
18	46727488	SEALING CAP			2
19	46722710	ROCKER ARM SUPPORT	w/Ref. 1		1
20	46722712	ROCKER ARM SUPPORT	w/Ref. 2, 5, 6		2
21	46722714	ROCKER ARM SUPPORT	w/Ref. 3, 4		1
22	46716759	BOLT			3
23	46717082	BOLT	M12X75		1
24	46717048	GRUB SCREW	EM6X10		1
25	46722775	SPRING			2
26	46722774	SPRING CLIP			2
27	46722805	VALVE SPRING			8
28	46722806	VALVE SPRING			8
29	46722809	VALVE SPRING			8
30	46722807	VALVE SPRING WASHER			8
31	46717151	LOCK RETAINER			8


CAM SHAFT & ROCKER ARM



CAM SHAFT & ROCKER ARM	
------------------------	--

[illegible]


CONNECTING ROD ASSEMBLY



CONNECTING ROD ASSEMBLY

[illegible]


COOLING SYSTEM



COOLING SYSTEM	
----------------	--

[illegible]


CRANKSHAFT



CRANKSHAFT	
-------------------	--

[illegible]


CYLINDER BLOCK



CYLINDER BLOCK

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46716568	ASSY. CYL. BLOCK			1
2	46716647	CYLINDER LINER			4
#	46722715	SCREW PLUG			1
3	46722815	WASHER	18X22		1
4	46722815	SEALING PLUG	18X1.5		1
5	46722766	SLEEVE			1
6	TBD	CLAMPING SLEEVE			1
7	46722766	CYL. PIN	12H 8X30		2
8	46716635	CYL. PIN			2
9	46716642	CYL. PIN	8M 6X16		10
#	46722715	SCREW PLUG			1
10	46717089	SCREW			10
#	46717148	LOCATING PIN			1
11	46705614	ASSY. TUBE			1
12	46705610	ASSY. OIL DIPSTICK			1
13	46716992	FLYWHEEL HSG.			1
15	46716739	ASSY. T IMING GEAR			1
15	46716563	ASSY TIMING GEAR HOUSING			1
16	46716642	CYL. PIN	8M 6X16		2
17	46705597	GASKET			1
18	46717153	LOCKING PLATE			3
19	46717085	SCREW	M10X25		3
20	46716627	COVER FRONT			1
20	46716625	COVER FRONT			1
21	46722721	SEAL			1
22	46705690	GASKET			1
23	46716562	ASSY. BREATHER			1
24	46716565	ASSY. COVER			1
25	46705602	GASKET			1
26	46716731	ASSY. OIL SUMP			1
27	46722815	WASHER	18X22		1


CYLINDER BLOCK



CYLINDER BLOCK	
----------------	--

[illegible]


CYLINDER HEAD



CYLINDER HEAD	
---------------	--

[illegible]


DIPSTICK ARRANGEMENT



DIPSTICK ARRANGEMENT

[illegible]


EXHAUST MANIFOLD



EXHAUST MANIFOLD	
------------------	--

[illegible]


FUEL FILTER



FUEL FILTER	
-------------	--

[illegible]


FUEL INJECTION PUMP



FUEL INJECTION PUMP	
---------------------	--

[illegible]


FLYWHEEL



FLYWHEEL	
----------	--

[illegible]


INJECTOR



INJECTOR	
----------	--

[illegible]


LUBRICATION SYSTEM



LUBRICATION SYSTEM

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46716733	ASSY. OIL PUMP	WITHOUT STRAINER		1
2	46722669	OIL PUMP HOUSING			1
3	46716561	ASSY STRAINER			1
4	46722764	SHAFT DRIVEN GEAR			1
5	46722667	OIL PUMP GEAR			1
6	46716892	DRIVE SHAFT			1
7	46727494	SHAFT			1
8	46727401	WOODRUFF KEY	3X6.5		2
9	46716890	DRIVE GEAR			1
#	46722803	PRESSURE RELEASE VALVE HOUSING			1
10	46722772	PRESSURE RELIEF VALVE			1
11	46722699	PLUNGER			1
12	46727467	PLUG			1
13	46705698	GASKET			1
#	TBD	KIT, OIL PUMP GEAR	w/Ref. 5, 7		1
14	46705686	ASSY OIL FILTER			1
15	46705607	ELEMENT LUBE OIL FILTER			1
#	46705692	HEAD ASSY			1
16	46705606	GASKET			1
#	46716730	ASSY. LUBE LINE			1
17	46716555	ASSY OIL COOLER			1
18	46705596	GASKET			1
19	46717083	BOLT	M8X40		27
#	46716735	ASSY. OIL SUPPLY LINE			1
#	46717098	HOSE			1
#	46722675	PIPE UNION BOLT	M12X1.5		1
#	46722734	SEALING WASHER	12X16		1
#	46722733	SEALING WASHER	14X18		2
#	46717025	GASKET			1
#	46717098	HOSE			1
21	46716792	CLAMP HOSE			1


LUBRICATION SYSTEM



LUBRICATION SYSTEM	
--------------------	--

[illegible]


PISTON ASSEMBLY



PISTON ASSEMBLY

[illegible]


STARTER



STARTER	
---------	--

[illegible]


TURBO CHARGER



TURBO CHARGER	
---------------	--

[illegible]


SENSOR, MAGNETIC PICKUP (G45/60)



**SENSOR, MAGNETIC PICKUP
(G45/60)**

[illegible]


AIR FILTER INSTALLATION HEAVY DUTY (G45/60)



AIR FILTER INSTALLATION HEAVY DUTY (G45/60)

[illegible]





AIR FILTER INSTALLATION NORMAL DUTY (G48/71)



AIR FILTER INSTALLATION NORMAL DUTY (G48/71)

[illegible]


AIR FILTER EXPLODE NORMAL DUTY (G48/71)



**AIR FILTER EXPLODE NORMAL DUTY
(G48/71)**

[illegible]


COOLING SYSTEM INSTALLATION S3.8 G6 (G45)



**COOLING SYSTEM INSTALLATION S3.8 G6
(G45)**

[illegible]


COOLING SYSTEM INSTALLATION S3.8 G8 (G48)



COOLING SYSTEM INSTALLATION S3.8 G8 (G48)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46703827	RADIATOR			1
2	46705567	GUARD, RADIATOR			1
3	46703786	SCREW, HEX FLANGE HEAD			9
4	46722830	WASHER, FLAT			11
5	46714006	SCREW, HEX FLANGE HEAD			4
6	46703774	WASHER SPR, LK			4
7	46722665	NUT, HEX			4
8	46705552	HOSE, WATER			1
9	46705547	HOSE, WATER			1
10	46709484	BRACKET, RADIATOR			1
11	46714000	SCREW, HEX FLANGE HEAD			1
12	46705570	CLAMP, HOSE			1
13	46705548	CLAMP, HOSE			2
14	46705569	CLAMP, HOSE			1
15	46709369	GUARD, BELT			1
16	46703770	WASHER, FLAT			3
17	46705560	SCREW, HEX HEAD			3
18	46714007	SCREW, HEX FLANGE HEAD			1
19	46705578	GUARD, RADIATOR			1
20	46717115	ISOLATOR, VIBRATION			4
21	46705543	TANK-COOLANT			1
22	TBD	SHROUD			1
23	46727468	PLUG-DRAIN			1
24	TBD	PRESURE CAP			1


COOLING SYSTEM INSTALLATION S3.8 G7 (G60)



COOLING SYSTEM INSTALLATION S3.8 G7 (G60)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46703824	RADIATOR			1
#	46717110	COOLER-CHARGE AIR			1
#	46727327	BRACKET,COOLANT RECOVERY			1
#	46705543	TANK COOLANT			1
2	46722103	TUBE,WATER			1
3	46709353	HOSE,VACUUM			2
4	46716772	BRACKET,TUBE			1
5	46705550	TUBE,AIR			1
6	46705545	TUBE,AIR			1
7	46705544	TUBE,AIR			1
8	46722693	PLUG,PIPE			1
9	46703770	WASHER,FLAT			10
10	46703623	WASHER-SPR LK			4
11	46713921	NUT,HEX			4
12	46709368	ELBOW,HOSE			2
13	46703655	CLAMP,HOSE			8
14	46727319	BOLT-U			2
15	46705652	WASHER,FLAT			4
16	46714021	SCREW,HEX HEAD			4
17	46703774	WASHER-SPR LK			4
18	46722665	NUT,HEX			4
19	46722830	WASHER,FLAT			8
20	46709355	HOSE,COOLANT			1
21	46705548	CLAMP,HOSE			4
22	46722076	GUARD,FAN			1
23	46713991	PLUG-DRAIN			2
24	46714080	WASHER-SPR LK			6
25	46722717	SCREW,HEX HEAD			6
26	46705552	HOSE, WATER			1
27	46705570	CLAMP, HOSE			1


COOLING SYSTEM INSTALLATION S3.8 G10 (G71)



COOLING SYSTEM INSTALLATION S3.8 G10 (G71)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46703828	RADIATOR			1
2	46705652	WASHER, FLAT			4
3	46722830	WASHER, FLAT			15
4	46714021	SCREW, HEX HD			4
5	46703774	WASHER-SPR, LOCK			4
6	46722665	NUT, HEX			4
7	46705567	GUARD, RADIATOR			1
8	46703786	SCREW, HEX FLANGE HEAD			7
9	46705552	HOSE, WATER			1
10	46705547	HOSE, WATER			1
11	46709353	HOSE, VACCUM			2
12	46705550	TUBE, AIR			1
13	46705544	TUBE, AIR			1
14	46709368	ELBOW, HOSE			2
15	46705545	TUBE, AIR			1
16	46716772	BRACKET, TUBE			1
17	46709500	CLAMP, TUBE			2
18	46703770	WASHER, FLAT			7
19	46714013	SCREW, HEX HEAD			4
20	46703623	WASHER-SPR LOCK			4
21	46713921	NUT, HEX			4
22	46709484	BRACKET, RADIATOR			1
23	46714000	SCREW, HEX FLANGE HEAD			1
24	46705566	CLAMP, HOSE			8
25	46705548	CLAMP, HOSE			2
26	46705570	CLAMP, HOSE			1
27	46705569	CLAMP, HOSE			1
28	46714007	SCREW, HEX FLANGE HEAD			1
29	46709369	GUARD, BELT			1
30	46705560	SCREW, HEX HEAD			3
31	46705578	GUARD, RADIATOR			1



COOLING SYSTEM INSTALLATION S3.8 G10 (G71)



**COOLING SYSTEM INSTALLATION S3.8 G10
(G71)**

[illegible]


ELECTRICAL COIL INSTALLATION



ELECTRICAL COIL INSTALLATION

[illegible]


ENGINE INSTALLATION S3.8 G6 (G45)



ENGINE INSTALLATION S3.8 G6 (G45)

[illegible]


ENGINE INSTALLATION S3.8 G8 (G48)



ENGINE INSTALLATION S3.8 G8 (G48)

[illegible]


ENGINE INSTALLATION S3.8 G7 (G60)



ENGINE INSTALLATION S3.8 G7 (G60)

[illegible]


ENGINE INSTALLATION S3.8 G10 (G71)



ENGINE INSTALLATION S3.8 G10 (G71)

[illegible]


SENSOR INSTALLATION



SENSOR INSTALLATION

[illegible]


**CLASS 1 MAINTENANCE AND REPAIR ITEMS
(G45/48)**



CLASS 1 MAINTENANCE AND REPAIR ITEMS (G45/48)					
--	--	--	--	--	--

[illegible]


CLASS 2 EXTENDED DOWNTIME PREVENTION (G45/48)



**CLASS 2 EXTENDED DOWNTIME PREVENTION
(G45/48)**

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46705624	INJECTOR FUEL			1
2	46705651	WASHER,COPPER			1
3	46705482	MOTOR STARTER			1
4	46705687	ALTERNATOR WITH PULLEY	12V,35AMP		1
5	46709350	FUEL INJECTION PUMP	G45		1
5	46717019	FUEL INJECTION PUMP	G48		1
6	46705618	WATER PUMP ASSEMBLY			1
7	46705643	RUBBER HOSE	THERMOSTAT TO WATER PUMP		1
7	46703641	RUBBER HOSE	COOLING WATER LINE TO THERMOSTAT		1
8	46709355	HOSE-COOLANT	G45		1
9	46709359	HOSE-COOLANT	G45		1
10	46709367	TUBE-WATER	G45		1
11	46709351	HOSE-VACCUM	G45		1
12	46705552	HOSE,WATER	G48		1
13	46705547	HOSE,WATER	G48		1
14	46705639	CLAMP HOSE			6
14	46703767	CLAMP HOSE	G45		6
14	46703642	CLIP WATER CONNECTION HOSE			6
14	46705548	CLAMP HOSE	G48		6
14	46705570	CLAMP HOSE	G48		6
14	46705569	CLAMP HOSE	G48		1
15	46709346	CAP-PRESSURE	G45		1
16	46706651	ALTERNATOR S1L2-N1			1
17	46703791	KIT, AVR AS540			1
18	46705524	KIT, RECTIFIER SERVICE			1
19	46706537	CONTROLLER	DIGITAL DSE 6010		1
20	46728729	CIRCUIT BREAKER (MCCB)	80A TP		1
20	46728730	CIRCUIT BREAKER (MCCB)	150A TP (220/127V OPTION ONLY) G48		1
21	46706556	FUEL LEVEL GAUGE			1
22	46706615	HEAVY DUTY SOLENOID 12V			1
23	46719987	RELAY 12V DC 40A	FOR FUEL		1


CLASS 2 EXTENDED DOWNTIME PREVENTION (G45/48)



CLASS 2 EXTENDED DOWNTIME PREVENTION (G45/48)	
--	--


[illegible]

**CLASS 1 MAINTENANCE AND REPAIR ITEMS
(G60/71)**



[illegible][illegible]


CLASS 2 EXTENDED DOWNTIME PREVENTION (G60/71)



**CLASS 2 EXTENDED DOWNTIME PREVENTION
(G60/71)**

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46705624	INJECTOR FUEL			1
2	46705651	WASHER,COPPER			1
3	46705482	MOTOR STARTER			1
4	46705687	ALTERNATOR WITH PULLEY	12V,35AMP		1
5	46709352	FUEL INJECTION PUMP	G60		1
5	46717022	FUEL INJECTION PUMP	G71		1
6	46705618	WATER PUMP ASSEMBLY			1
7	46705643	RUBBER HOSE	THERMOSTAT TO WATER PUMP		1
7	46722088	HOSE-RADIATOR	G60		1
7	46722089	HOSE-RADIATOR	G60		1
8	46705636	RUBBER HOSET	COOLING WATER LINE TO THERMOSTAT		1
8	46709353	HOSE-VACUUM	G60		6
8	46709355	HOSE-COOLANT	G60		6
9	46709359	HOSE-COOLANT	G60		1
10	46713844	HOSE,WATER	G71		1
11	46713845	HOSE,WATER	G71		1
12	46705552	HOSE,WATER			1
13	46705547	HOSE,WATER	G71		1
14	46705639	CLAMP HOSE			6
14	46722065	CLAMP HOSE	G60		6
14	46703642	CLIP WATER CONNECTION HOSE			6
14	46705548	CLAMP,HOSE			6
14	46705570	CLAMP,HOSE			6
14	46703787	CLAMP,HOSE	G71		6
14	46705569	CLAMP,HOSE	G71		6
15	46709360	CAP	G71		1
16	46706650	ALTERNATOR S1L2-Y1			1
17	46703791	KIT, AVR AS540			1
18	46705540	KIT, RECTIFIER SERVICE			1
19	46706537	CONTROLLER	DIGITAL DSE 6010		1
20	46716441	CIRCUIT BREAKER (MCCB)	100A TP		1

CLASS 2 EXTENDED DOWNTIME PREVENTION (G60/71)



CLASS 2 EXTENDED DOWNTIME PREVENTION (G60/71)	
--	--

[illegible]

Intentionally left blank

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
23047566	9	46705550	79, 81	46705688	43	46709484	77, 81
23047582	9	46705552	77,	46705690	39	46709486	87, 91
23047624	9	79, 81, 99, 105		46705692	57	46709488	13, 17
36875565	23, 25	46705554	49	46705693	27	46709490	29
46573859	9	46705559	87,	46705694	35, 97, 103	46709498	69
46573860	9	89, 91, 93		46705695	27	46709500	81
46573921	9	46705560	77, 81	46705696	27	46709529	13, 17
46656744	9	46705566	81	46705697	17	46709532	13, 17
46703623	71, 79,	46705567	77, 81	46705698	57	46709568	97, 103
81, 87, 89, 91, 93		46705569	77,	46705699	17	46709585	97, 103
46703641	99	81, 99, 105		46706514	11, 15	46709603	25, 93
46703642	99, 105	46705570	77,	46706517	21	46709604	23, 87
46703649	67,	79, 81, 99, 105		46706518	7	46709605	25, 91
87, 97, 103		46705571	87, 91	46706526	95, 97, 103	46709606	23, 89
46703655	79	46705572	87, 91	46706536	19	46713844	91, 105
46703662	95	46705574	47, 65	46706537	19, 99, 105	46713845	91, 105
46703665	95	46705575	71	46706556	99, 107	46713851	69, 97
46703666	95	46705578	77, 81	46706560	19	46713858	13, 17
46703767	75, 91, 99	46705596	57	46706563	19,	46713921	79, 81
46703770	71,	46705597	39	101, 107		46713922	91
77, 79, 81		46705602	39	46706564	19,	46713924	13, 17
46703774	69, 75,	46705606	57	101, 107		46713925	73
77, 79, 81		46705607	57, 97, 103	46706615	99, 107	46713927	87
46703786	77, 81	46705610	39, 45	46706618	19	46713985	89, 93
46703787	91, 105	46705612	43,	46706619	19	46713991	75,
46703791	13,	101, 107		46706636	95, 97, 103	79, 87, 91	
17, 99, 105		46705614	39, 45	46706638	7	46713993	87, 91
46703823	75	46705618	35, 99, 105	46706642	97, 103	46714000	77, 81
46703824	79	46705623	51, 97, 103	46706643	19,	46714006	75, 77
46703827	77	46705624	55, 99, 105	101, 107		46714007	77, 81
46703828	81	46705629	47	46706649	19	46714008	87, 89, 93
46705473	91, 93	46705631	41	46706650	15, 105	46714012	75
46705478	71, 103	46705633	47	46706651	11, 99	46714013	71, 81
46705482	63, 99, 105	46705636	35, 105	46706653	7	46714021	79, 81
46705494	69	46705638	87, 91	46706654	7	46714023	91
46705497	91	46705639	35, 99, 105	46709346	75, 99	46714024	53
46705500	89, 93	46705643	35, 99, 105	46709347	75	46714027	61
46705521	13,	46705644	47, 65	46709348	75	46714029	83
17, 101, 107		46705645	47, 65	46709350	51, 99	46714049	13, 17
46705524	13, 17, 99	46705647	35, 97, 103	46709351	75, 99	46714076	75
46705525	27	46705651	55, 99, 105	46709352	51, 105	46714078	75
46705527	27	46705652	49, 79, 81	46709353	79, 81, 105	46714080	75, 79
46705528	71	46705654	35	46709355	75,	46714081	91
46705529	87, 89	46705656	35,	79, 99, 105		46715886	9
46705532	27	101, 107		46709356	13	46715887	9
46705533	47, 65	46705670	27	46709357	13	46716428	19
46705535	49	46705671	27	46709359	75, 99, 105	46716430	21
46705537	13, 17	46705675	63	46709360	83, 105	46716431	11,
46705540	13, 17, 105	46705677	71	46709367	75, 99	15, 23, 25	
46705543	77, 79, 83	46705678	27	46709368	79, 81	46716433	11,
46705544	79, 81	46705679	71	46709369	77, 81	15, 23, 25	
46705545	79, 81	46705682	43, 87	46709370	47, 65	46716436	7
46705547	77,	46705684	49, 97, 103	46709371	45	46716438	19, 107
81, 99, 105		46705685	41	46709441	13, 17	46716441	19, 105
46705548	77,	46705686	57	46709475	97, 103	46716442	19
79, 81, 99, 105		46705687	27, 99, 105	46709483	75	46716452	19

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
46716471	87	46716789	29	46717151	29	46721248	11, 15, 23, 25
46716472	49	46716792	47, 57, 65	46717152	35	46721249	11, 15, 23, 25
46716473	49	46716807	33	46717153	39, 53	46721250	19
46716518	65	46716808	33	46717164	37	46721251	19
46716531	89, 93	46716809	33	46717165	37	46721259	7
46716536	97, 103	46716810	33	46717166	37	46721260	7
46716554	69	46716811	33	46717179	47	46721261	7
46716555	57	46716814	59	46717181	47	46721856	9
46716560	41	46716889	41	46717225	19	46721858	9
46716561	57	46716890	57	46717226	19	46721859	3
46716562	39	46716891	29	46717227	19	46721862	9
46716563	39	46716892	57	46717244	21	46721865	9
46716565	39	46716900	73	46717245	7	46721912	19
46716567	33	46716902	69, 97, 103	46717247	11, 15, 23, 25	46722065	105
46716568	39	46716903	91	46717252	9	46722076	79
46716569	43	46716905	73, 97, 103	46717262	19	46722085	75
46716622	87, 89, 93	46716906	73, 97, 103	46717279	21	46722088	105
46716625	39	46716908	69, 97, 103	46717291	19	46722089	105
46716627	39	46716983	51	46717298	11, 15, 23, 25	46722099	95, 97, 103
46716633	37	46716992	39, 53	46718030	9	46722101	75
46716635	39	46717019	99	46718032	9	46722102	97, 103
46716639	37	46717022	51, 105	46718033	9	46722103	79
46716642	39	46717023	51	46718034	9	46722665	69, 75, 77, 79, 81
46716647	39	46717025	57	46719980	19	46722667	57
46716696	3	46717026	65	46719985	19	46722669	57
46716701	5	46717027	35	46719986	19	46722670	29
46716706	21	46717028	51	46719987	19, 99, 107	46722673	29
4671672	37	46717034	73	46719988	19	46722675	57
46716726	43	46717040	51	46719990	19	46722691	43
46716728	43	46717048	29	46720010	9	46722693	79
46716729	53	46717054	87	46720027	21	46722699	57
46716730	57	46717081	59	46720032	7	46722700	41, 45
46716731	39	46717082	29	46720033	7	46722703	37
46716732	47	46717083	57	46720034	7	46722710	29
46716733	57	46717084	29	46720035	7	46722712	29
46716734	41	46717085	39	46720036	7	46722714	29
46716735	47, 57, 65	46717086	29	46720037	7	46722715	39
46716736	29	46717087	43	46720038	7	46722716	69
46716737	37	46717089	39	46720039	7	46722717	79
46716738	29	46717091	41	46720040	7	46722721	39
46716739	39	46717093	73	46720041	7	46722723	69
46716740	29	46717094	69	46720042	7	46722725	59
46716741	29	46717095	87, 91	46720043	7	46722728	37
46716743	35	46717096	89, 93	46720044	7	46722730	59
46716759	29	46717097	51	46720045	7	46722731	31
46716761	43	46717098	47, 57, 65	46720046	7	46722733	57
46716762	49	46717110	79, 83	46720047	7	46722734	57
46716765	35	46717115	75, 77	46720048	7	46722742	85, 97, 103
46716766	73	46717122	37	46720052	21	46722745	37
46716767	49	46717128	37	46720057	21	46722746	37
46716771	69	46717143	51	46720064	21	46722764	57
46716772	79, 81	46717146	49	46720067	19	46722766	39
46716774	49	46717147	49	46720071	21	46722771	29
46716775	71	46717148	37, 39				
46716785	29	46717149	31				
46716786	29	46717150	31				

NUMERICAL INDEX

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
46722772	57	46722811	37	46727468	77, 83	54629977	9
46722774	29	46722813	41	46727473	29	54642327	9
46722775	29	46722814	29	46727476	87,	92867449	9
46722776	43	46722815	39	89, 91, 93		92867530	9
46722777	41	46722819	43	46727488	29	92912559	9
46722790	51	46722830	69,	46727489	37	92930593	9
46722792	37	77, 79, 81		46727493	37	93171254	9
46722794	51	46722831	37	46727494	57	93171262	9
46722797	43	46724125	21	46727507	29	93171288	9
46722799	43	46725947	25	46727509	31		
46722800	43	46725965	25	46728729	99		
46722801	43	46726125	7	46728730	99	N	
46722803	57	46727319	79	46729682	53	NAP . . . 13, 17, 31, 33,	
46722804	43	46727327	79	46729689	73	35, 61, 87, 89, 91, 93	
46722805	29	46727401	57	46729690	71		
46722806	29	46727423	73	46730726	19	T	
46722807	29	46727463	43	46738385	21	TBD . . . 39, 57, 61, 77	
46722808	43	46727466	43	46738390	21		
46722809	29	46727467	57	46738391	21		

WORD INDEX

250 Hour Maintenance Kit 97, 103
500 Hour Maintenance Kit 97, 103

A

ADAPTER HOSE 65
ADAPTER SAE 3 13, 17
AIR CLEANER 69
AIR FILTER 71
ALTERNATOR 11, 15, 27
ALTERNATOR S1L2-N1 99
ALTERNATOR S1L2-Y1 105
ALTERNATOR WITH PULLEY 99, 105
ASSY OIL COOLER 57
ASSY OIL FILTER 57
ASSY STRAINER 57
ASSY TIMING GEAR HOUSING 39
ASSY. BREATHER 39
ASSY. CAP 43, 101, 107
ASSY. COMBI SCREW 41
ASSY. CON ROD 33
ASSY. COVER 39
ASSY. CYL. BLOCK 39
ASSY. CYL.HEAD 43
ASSY. CYLINDER HEAD COVER 43
ASSY. FLYWHEEL 37
ASSY. FLYWHEEL WITH RING GEAR 53
ASSY. LUBE LINE 57
ASSY. MAGNETIC DRAIN PLUG 41
ASSY. OIL DIPSTICK 39, 45
ASSY. OIL OUTLET TUBE 47
ASSY. OIL PUMP 57
ASSY. OIL SUMP 39
ASSY. OIL SUPPLY LINE 47, 57, 65
ASSY. PULLEY 37
ASSY. ROCKER ARM 29
ASSY. ROCKER ARM SHAFT 29
ASSY. T IMING GEAR 39
ASSY. THERMOSTAT 35
ASSY. TUBE 39
ASSY. TUBE (DIPSTICK) 45
ASSY. UPPER COOLING WATER LINE 35
ASSY. WATER PUMP 35
AVR AS540 13, 17

B

BACK COVER 35
BACKPLATE, FAN 87, 91
BEARING NDE 13, 17
BEARING, CONNECTING ROD 33
BOLT 7, 11, 15, 19, 21, 23, 25, 27, 29, 35, 43, 49, 57
BOLT-BANJO 49
BOLT-U 79
BOX, BREAKER GI MOUNTING 19
BOX, CONTROL PANEL GI MOUNTING 19
BRACKET 13, 17, 27, 49

BRACKET NDE 13, 17
BRACKET, AIR FILTER 71, 73
BRACKET, BREAKER GI MOUNTING 19
BRACKET, RADIATOR 75, 77, 81
BRACKET, TUBE 81
BRACKET-AIR CLEANER 69
BRACKET,COOLANT RECOVERY 79
BRACKET,TUBE 79
BUS BAR 19
BUSBAR INSULATOR 19
BUSH 29
BUSHING REDUCER 87
BUSHING, REDUCER 91, 95
BUTTING RING 29

C

CABLE GLAND 19
CAMSHAFT 29
CAMSHAFT BEARING NO. 1 31
CAMSHAFT BEARING NO. 2,3 31
CAMSHAFT BEARING SET 31
CAMSHAFT GEAR 29
CAP 83, 105
CAP, PRESSURE 75
CAP-PRESSURE 99
CIRCLIP 61
CIRCUIT BREAKER 19
CIRCUIT BREAKER (MCCB) 99, 105, 107
CLAMP 27, 71
CLAMP HOSE 47, 57, 65, 99, 105
CLAMP, HOSE 77, 79, 81, 87, 91
CLAMP, TUBE 81
CLAMP-AIR CLEANER 73
CLAMP,HOSE 79, 105
CLAMP-HOSE 35, 69, 75
CLAMP-TUBE 69
CLAMPING SLEEVE 39
CLIP WATER CONNECTION HOSE 99, 105
COIL, ELECTRICAL 85, 97, 103
COMPRESSION RING 61
CON. ROD BEARING HALF R/S 1 33
CON. ROD BEARING HALF R/S II 33
CON. ROD BEARING HALF STD 33
CON. ROD BUSH 33
CONNECTING ROD BEARING SET 33
CONNECTING ROD BEARING SET R/S I1
(SELECTION) 33
CONNECTING ROD BOLT 33
CONNECTOR 59
CONTROLLER 19, 99, 105
COOLANT TEMP SENDER/SWITCH 97, 103
COOLER-CHARGE AIR 79, 83
COUPLING SAE 10 13, 17
COVER FRONT 39
COVER PLATE, BREAKER 19
COVER, END 13, 17

WORD INDEX

COVER-FLYWHEEL 87, 89, 93
 CRANKSHAFT 37
 CRANKSHAFT GEAR 37
 CROSS PIPE 47, 65
 CURRENT TRANSFORMER 19
 CUTOOT DOOR, PANEL 7
 CYL. PIN. 39
 CYLINDER LINER. 39

D

DE SCREEN SAE 3. 13, 17
 DECAL, BATTERY DISCONNECT 9
 DECAL, COOLANT FILL 9
 DECAL, COOLANT LEVEL 9
 DECAL, DIESEL FUEL SYMBOL 9
 DECAL, DOOSAN LOGO. 9
 DECAL, DOOSAN TRI-COLOUR 12" 9
 DECAL, DOOSAN TRI-COLOUR 8" 9
 DECAL, EARTH WARNING 9
 DECAL, ELECTRIC SHOCK 9
 DECAL, HOT SURFACE ISO 9
 DECAL, ISO CENTRAL DRAIN 9
 DECAL, LIFT HERE 9
 DECAL, MODEL NUMBER 9
 DECAL, NO WATER 9
 DECAL, REFER TO HANDBOOK. 9
 DECAL, WARNING 9
 DECAL, WEB SITE 9
 DECAL, WEB SITE White 9
 DIN RAIL 19
 DOOR 7
 DOOR CATCH 7
 DOOR, CONTROL 19
 DOUBLE SOCKET 41
 DRIVE GEAR 29, 57
 DRIVE SHAFT 57

E

ELBOW, HOSE 81
 ELBOW, PIPE 91
 ELBOW,HOSE 79
 ELEMENT AIR FILTER 73
 ELEMENT FUEL WATER SEPERATOR 49, 97, 103
 ELEMENT LUBE OIL FILTER. 57, 97, 103
 ELEMENT-AIR CLEANER 69, 97, 103
 EMERGENCY STOP 97, 103
 ENGINE 23, 25
 ENGINE DIESEL 87, 91
 ENGINE, DIESEL 89, 93
 EXCITER ROTOR 13, 17
 EXCITER STATOR 13, 17
 EXHAUST INSULATION 21
 EXHAUST VALVE 31

F

FAN 13, 17
 FAN, RADIATOR 87, 89, 91, 93
 FEED PUMP 51, 97, 103
 FLYWHEEL HSG. 39, 53
 FRAME 3, 5
 FRAME EXTENSION FOR CANOPY 21
 FUEL INJECTION PUMP. 99, 105
 FUEL INJECTION PUMP -S3.8G10 51
 FUEL INJECTION PUMP -S3.8G6 51
 FUEL INJECTION PUMP -S3.8G7 51
 FUEL INJECTION PUMP -S3.8G8 51
 FUEL LEVEL GAUGE 99, 107
 FUEL SYSTEM 89, 93
 FUSE CARRIER 19
 FUSE CYLINDRICAL 19
 FUSE CYLINDRICAL 10X38 20A 101, 107
 FUSE CYLINDRICAL 10X38 2A 101, 107

G

GASKET 21, 35, 39, 41, 43, 47, 57, 65, 73
 GASKET FIP SUPPORT 51
 GASKET FLANGE 45
 GASKET KIT 97, 103
 GASKET, COVER 87
 GEAR-SPUR. 51
 GRUB SCREW 29
 GUARD, BELT 77, 81
 GUARD, FAN 75
 GUARD, RADIATOR 75, 77, 81
 GUARD,FAN 79

H

HARNESS, SENSOR 87, 95
 HEAD ASSY 57
 HEAD-FILTER 49
 HEAVY DUTY SOLENOID 12V 99, 107
 HEX BOLT 59
 HINGE 7
 HINGES 19
 HORIZONTAL 7
 HOSE 47, 51, 57, 65, 71
 HOSE CLAMP 65
 HOSE, BREATHER 87, 91
 HOSE, COOLANT 75
 HOSE, FUEL 89, 93
 HOSE, VACCUM 81
 HOSE, VACUUM 75
 HOSE, WATER 77, 79, 81, 91
 HOSE-AIR 69
 HOSE,COOLANT 79
 HOSE-COOLANT 99, 105
 HOSE-RADIATOR 105
 HOSE-VACCUM 99
 HOSE,VACUUM 79

WORD INDEX

HOSE-VACUUM 105
 HOSE, WATER 99, 105
 HOUSING, WATER PUMP 35

I

INDICATOR, SERVICE 71
 INDICATOR-SERVICE 69, 97, 103
 INJECTOR FUEL 55, 99, 105
 INLET VALVE 31
 INTERNALLY STEPPED RING 61
 ISOLATOR 11, 15, 23, 25
 ISOLATOR, VIBRATION 75, 77

J

JOINT 7

K

KEY 37
 KIT BEARING NDE 101, 107
 KIT, AVR AS540 99, 105
 KIT, CRANKSHAFT 37
 KIT, OIL PUMP GEAR 57
 KIT, RECTIFIER SERVICE 99, 105

L

LINE FUEL 49, 51
 LOCATING PIN 37, 39
 LOCK ASSY 7
 LOCK HALF - VALVE SPRING 31
 LOCK PLATE 35
 LOCK RETAINER 29, 31
 LOCKABLE KNOB 19
 LOCKING PLATE 39, 53
 LOUVER ASSY 7

M

MAIN BEARING SET 37
 MAIN BEARING SET RS I 37
 MAIN BEARING SET RS II 37
 MANIFOLD EXHAUST 47
 MANUAL, OPERATION MAINTENANCE 9
 MANUAL, PARTS 9
 MOTOR STARTER 99, 105

N

NAME PLATE, ENGINE 89, 93
 NAMEPLATE 91
 NAMEPLATE ENGINE 87
 NUT 7, 11, 15, 21, 23, 25, 27, 29
 NUT, HEX 73, 75, 77, 81, 91
 NUT, WING 73

NUT, HEX 79
 NUT-HEX 69

O

O RING 51
 OIL PRESSURE SENDER/SWITCH 97, 103
 OIL PUMP GEAR 57
 OIL PUMP HOUSING 57
 OIL RING 61
 OIL SLINGER 37

P

PANEL 7
 PANEL, CONTROL 19
 PANELE 7
 PARALLEL KEY 29
 PARTITION, RADIATOR 21
 PIN 29, 61
 PIPE EXHAUST 21
 PIPE UNION BOLT 57
 PIPE, EXHAUST 87, 89, 93
 PISTON 61
 PISTON RINGS SET 61
 PISTON SET BARE 61
 PLUG 43, 57
 PLUG, DRAIN 83, 87, 91
 PLUG-DRAIN 75, 77, 79, 91
 PLUG, PIPE 79
 PLUNGER 57
 PRESSURE RELEASE VALVE HOUSING 57
 PRESSURE RELIEF VALVE 57
 PRESURE CAP 77
 PULLEY 35
 PUSH ROD 29

R

RADIATOR 75, 77, 79, 81
 RADIATOR COVER 7
 RADIATOR PANEL 7
 RADIATOR SIDE COVER 7
 RAIN CAP 21
 RECTIFIER ASSEMBLY 13, 17
 RECTIFIER SERVICE 13, 17
 REINFORCEMENT, ENGINE 25
 RELAY 19
 RELAY 12V DC 40A 99, 107
 RELAY 12VDC 101, 107
 RETAINING FLANGE 41
 RETAINING FLANGE (DIPSTICK) 45
 RING GEAR 37, 53
 RIVET-RND HD BLIND 87, 89, 91, 93
 ROCKER ARM SUPPORT 29
 ROD 27
 ROOF PANEL 7

WORD INDEX

ROOF, MIDDLE 7
 RUBBER HOSE 35, 99, 105
 RUBBER HOSET 105

S

SCREW 29, 39, 41, 49, 53, 71
 SCREW PLUG 39
 SCREW, HEX EHAD 89, 93
 SCREW, HEX FLANGE HEAD . 75, 77, 81, 87, 89, 93
 SCREW, HEX HD 81
 SCREW, HEX HEAD 75, 77, 81, 87, 91
 SCREW-HEX FLG HD 69
 SCREW-HEX HD 69
 SCREW,HEX HEAD 79
 SEAL 39, 73
 SEALING CAP 29
 SEALING PLUG 39
 SEALING RING HALF 37
 SEALING WASHER 57, 59
 SENDER, COOLANT LEVEL 95
 SENDER, PRESSURE 95
 SENDER,LOW COOLANT 97, 103
 SENSOR, MAGNETIC PICKUP 67, 87
 SENSOR, TEMPERATURE 95
 SENSOR,MAGNETIC PICKUP 97, 103
 SET, THRUST WASHER 37
 SET, THRUST WASHER RS I 37
 SHAFT 57
 SHAFT DRIVEN GEAR 57
 SHROUD 77, 83
 SHROUD, FAN 75
 SILENCER 21
 SLEEVE 39
 SPACER 37, 63
 SPRING 27, 29
 SPRING CLIP 29
 SPRING WASHER 11, 15, 23, 25, 41
 STARTER MOTOR 63
 STRAINER,FUEL 97, 103

T

TANK COOLANT 79
 TANK, COOLANT 75
 TANK-COOLANT 77, 83
 TAPPET ADJUSTER 29
 TERMINAL BOARD 13, 17
 TERMINAL ENCLOSURE 13, 17
 TERMINAL ENCLOSURE PANEL 13, 17
 THERMOSTAT 97, 103

THRUST SPACER 37
 THRUST WASHER 29
 TRUNKING 19
 TUBE, AIR 81
 TUBE, FUEL 51
 TUBE, WATER 75
 TUBE,AIR 79
 TUBE,WATER 79
 TUBE-WATER 99
 TURBO CHARGER 47, 65

V

V-BELT 35, 97, 103
 VALVE GUIDE - EXHAUST 43
 VALVE GUIDE INLET 43
 VALVE GUIDE SEAL EXHAUST 43
 VALVE GUIDE SEAL INLET 43
 VALVE SEAT RING EXHAUST 43
 VALVE SEAT RING INLET 43
 VALVE SET 31
 VALVE SPRING 29
 VALVE SPRING WASHER 29
 VALVE TAPPET 29
 VALVE, BALL 87, 89, 91, 93
 VALVE-INTAKE 73
 VIBRATION DAMPER LOCK 37

W

WASHER 21, 39, 41, 43, 49, 71
 WASHER FLAT 7, 11, 15, 23, 25
 WASHER SPR, LK 77
 WASHER, COPPER 55
 WASHER, FLAT 75, 77, 81, 87
 WASHER, LOCK 91
 WASHER, THRUST 37
 WASHER,COPPER 99, 105
 WASHER-FL 69
 WASHER,FLAT 79
 WASHER-SPR LK 69, 79, 87, 89, 91, 93
 WASHER-SPR LOCK 81
 WASHER-SPR, LOCK 75, 81
 WATER PUMP ASSEMBLY 99, 105
 WATER PUMP REPAIR KIT 35
 WATER PUMP REPAIR KIT (MAJOR) 101, 107
 WIRE TERMINAL BLOCK 19
 WIRE TERMINAL BLOCK STOPPER 19
 WOODRUFF KEY 57
 Wound Main Rotor with Complete Assembly 13, 17
 Wound Main Stator with Frame Assembly 13, 17



Portable Power