




Doosan Infracore
Portable Power



LIGHTSOURCE V9

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.



cs	KATALOG DÍLŮ	lv	DETAĻU KATALOGS
da	RESERVEDELSKATALOG	mt	KATALGU TAL-PARTIJET
de	ERSATZTEILLISTE	nl	ONDERDELENKATALOGUS
el	ΚΑΤΑΛΟΓΟΣ ΕΞΑΡΤΗΜΑΤΩΝ	no	RESERVEDELSKATALOG
en	PARTS CATALOGUE	pl	KATALOG CZĘŚCI
es	LISTA DE REPUESTOS	pt	LISTA DE PEÇAS
et	OSADE SPETSIFIKATSIOON	sk	KATALÓG DIELOV
fi	VARAOSALUETTELO	sl	KATALOG DELOV
fr	CATALOGUE DE PIÈCES DÉTACHÉES	sv	RESERVEDELSKATALOG
hu	ALKATRÉSZ-KATALÓGUS	ru	КАТАЛОГ ДЕТАЛЕЙ
it	LISTA RICAMBI	zh	零件目录
lt	DALIŲ KATALOGAS		

C.C.N : 46500047
REV : B
DATE : OCTOBER 2010

V9 SERIAL No: 368000 ->

CONTENTS

RUNNING GEAR

RUNNING GEAR - (Fixed Height) (Braked)	3
RUNNING GEAR - (Fixed Height) (Braked) - (Folding)	11
RUNNING GEAR - (Variable Height) (Braked)	19

MAIN FRAME

FRAME ASSEMBLY	27
ENCLOSURE - (Front)	29
ENCLOSURE - (Rear)	33
TOWER SUPPORT	37
TOWER ASSEMBLY - (Section A through E)	39
TOWER ASSEMBLY - (Section F through K)	41
DECALS AND DOCUMENTATION	43
DECALS AND DOCUMENTATION	45

HYDRAULIC SYSTEM

HYDRAULIC ASSEMBLY	47
--------------------------	----

ELECTRICAL SYSTEM

CONTROL PANEL - (Housing)	49
CONTROL PANEL - (Fascia)	51
CONTROL PANEL - (Sockets) - (110V)	53
CONTROL PANEL - (Sockets) - (230V)	55
CONTROL PANEL - (Electrical System) - (110V)	57
CONTROL PANEL - (Electrical System) - (230V)	61
BATTERY	63
ALTERNATOR AND MOUNTING	65
LAMP ASSEMBLY	67
LAMP UNIT	69
LAMP CONNECTION BOX ASSEMBLY	71
TRAILER LIGHTING	73

POWER UNIT

ENGINE MOUNTING	75
ENGINE ASSEMBLY	77
OIL PAN	79
GEAR CASE / OIL FILTER	81
HEAD COVER	83
DIPSTICK AND GUIDE	85
STOP SOLENOID	87
FUEL INJECTION PUMP	89
GOVERNOR	91
SPEED CONTROL PLATE	93
NOZZLE HOLDER & GLOW PLUGS	95
NOZZLE HOLDER COMPONENT PARTS	97
FUEL PUMP MECHANICAL	99
ALTERNATOR AND PULLEY	101
STARTER	103
WATER FLANGE AND THERMOSTAT	105
WATER PUMP	107

WATER PIPE	109
FAN	111
INLET AND EXHAUST MANIFOLD	113
STARTER SWITCH	115
AIR INTAKE / ENGINE EXHAUST SYSTEM	117
COOLING SYSTEM	119
FUEL SYSTEM	121
CENTRAL DRAIN	125

ACCESSORIES & OPTIONS

OPTION LIGHTS - (L1 - non CE countries)	127
OPTION LAMP TILTING AND FIELD KIT	129
OPTION DRIVING LIGHTS PROTECTION	133
FIELD KIT FUEL GAUGE ASSEMBLY	135


MAINTENANCE ITEMS

RECOMMENDED PARTS - (Class 1)	137
RECOMMENDED PARTS - (Class 2)	139

Intentionally left blank

V9 Light Tower

RUNNING GEAR (Fixed Height) (Braked)




T2923_00
10/08

RUNNING GEAR (Fixed Height) (Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	54774492	EYE	A - (Ø 28mm)		1
1	54774500	EYE	B - (Ø 40mm)		1
1	54774518	EYE	C - (Ø 50mm)		1
1	54774534	EYE	D - (Ø 68mm)		1
1	54774542	EYE	E - (Ø 76mm)		1
1	22112908	HITCH, BALL	F		1
2	46517710	KIT, COVER	W/Ref. 2-3		1
2		CLIP, RETAINING	NAP - Order Ref. 2		2
3		COVER	NAP - Order Ref. 2		1
4	46517728	KIT, TUBE SLIDER	W/Ref. 4-6		1
4		TUBE	NAP - Order Ref. 4		1
5		SLIDER	NAP - Order Ref. 4		1
6		PIN	NAP - Order Ref. 4		1
7	46517827	KIT, DAMPER	W/Ref. 7-10		1
7		DAMPER	NAP - Order Ref. 7		1
8		NUT	NAP - Order Ref. 7		1
9		RING	NAP - Order Ref. 7		1
10		JOINT	NAP - Order Ref. 7		1
11	22051460	WASHER			4
12	22051403	SCREW			2
13	22051676	SCREW			2
14	46517751	KIT, SLEEVE	W/Ref. 14-16		1
14		NUT	NAP - Order Ref. 14		1
15		SLEEVE	NAP - Order Ref. 14		2
16		BOLT	NAP - Order Ref. 14		1
17	46517736	KIT, LEVER AND CONNECTOR	W/Ref. 17-27		1
17		WASHER	NAP - Order Ref. 17		1
18		NUT	NAP - Order Ref. 17		1
19		WASHER	NAP - Order Ref. 17		1
20		LEVER	NAP - Order Ref. 17		1
21		PIN, SPLIT	NAP - Order Ref. 17		1

RUNNING GEAR (CONT'D) (Fixed Height) (Braked)




T2923_00
10/08

RUNNING GEAR (CONT'D)
(Fixed Height) (Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
22		WASHER	NAP - Order Ref. 17		1
23		CONNECTOR	NAP - Order Ref. 17		1
24		NUT	NAP - Order Ref. 17		1
25		PIN	NAP - Order Ref. 17		1
26		BUSH	NAP - Order Ref. 17		1
27		WASHER	NAP - Order Ref. 17		1
28	46517702	CABLE, HANDBRAKE			1
29	46517520	HANDBRAKE ASSEMBLY			1
30	46517744	KIT, PISTON	W/Ref. 30-32		1
30		CLIP, RETAINING	NAP - Order Ref. 30		2
31		PISTON	NAP - Order Ref. 30		1
32		NUT	NAP - Order Ref. 30		1
33	22053763	JOCKEY WHEEL ASSEMBLY			1
34	22067003	CLAMP ASSEMBLY			1
35	22357503	SCREW			2
36	46517462	NUT			2
37	22357511	WASHER			2
38	46517389	BOLT			8
39	46517835	T-BAR			1
40	46517884	KIT, CABLE			1
40		CABLE	NAP - Order Ref. 40		1
41		NUT	NAP - Order Ref. 40		1
42	46517769	KIT, ROD	W/Ref. 42-50		1
42		NUT	NAP - Order Ref. 42		8
43		NUT	NAP - Order Ref. 42		1
44		ROD	NAP - Order Ref. 42		1
45		SPRING	NAP - Order Ref. 42		1
46		BUSH	NAP - Order Ref. 42		1
47		NUT	NAP - Order Ref. 42		2
48		NUT	NAP - Order Ref. 42		2
49		PLATE	NAP - Order Ref. 42		1

RUNNING GEAR (CONT'D) (Fixed Height) (Braked)




T2923_00
10/08

RUNNING GEAR (CONT'D)
(Fixed Height) (Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
50		NUT	NAP - Order Ref. 42		1
51	46517397	CABLE			2
52	46517611	FRAME			1
53	46517579	PLATE			1
54	46517595	WASHER			20
55	22051494	NUT			14
56	46517603	SCREW			6
57	46517777	KIT, DRUM	W/Ref. 57-61		2
57		NUT	NAP - Order Ref. 57		2
58		CAP	NAP - Order Ref. 57		2
59		CLIP, RETAINING	NAP - Order Ref. 57		4
60		BEARING	NAP - Order Ref. 57		2
61		DRUM	NAP - Order Ref. 57		2
62	22312441	BOLT			8
63	46517819	KIT, LEVER SPRING	W/Ref. 63-64		2
63		LEVER	NAP - Order Ref. 63		2
64		ATTACHMENT	NAP - Order Ref. 63		2
65	46517801	KIT, SHOE	W/Ref. 65-69		2
65		SPRING	NAP - Order Ref. 65		2
66		SPRING	NAP - Order Ref. 65		2
67		SHOE	NAP - Order Ref. 65 - front		2
68		SHOE	NAP - Order Ref. 65 - rear		2
69		SPRING	NAP - Order Ref. 65		2
70	46517793	KIT, TAPER	W/Ref. 70-72		2
70		TAPER	NAP - Order Ref. 70		2
71		KEY	NAP - Order Ref. 70		4
72		SCREW	NAP - Order Ref. 70		2
73	46517371	CAP			4
74	46517629	COVER			2
75	46517637	AXLE TUBE ASSEMBLY			1
76	46500732	RUNNING GEAR ASSEMBLY	Complete		1

RUNNING GEAR (CONT'D) (Fixed Height) (Braked)




T2923_00
10/08

RUNNING GEAR (CONT'D) (Fixed Height) (Braked)	
1	1.00
2	1.00
3	1.00
4	1.00
5	1.00
6	1.00
7	1.00
8	1.00
9	1.00
10	1.00
11	1.00
12	1.00
13	1.00
14	1.00
15	1.00
16	1.00
17	1.00
18	1.00
19	1.00
20	1.00
21	1.00
22	1.00
23	1.00
24	1.00
25	1.00
26	1.00
27	1.00
28	1.00
29	1.00
30	1.00
31	1.00
32	1.00
33	1.00
34	1.00
35	1.00
36	1.00
37	1.00
38	1.00
39	1.00
40	1.00
41	1.00
42	1.00
43	1.00
44	1.00
45	1.00
46	1.00
47	1.00
48	1.00
49	1.00
50	1.00
51	1.00
52	1.00
53	1.00
54	1.00
55	1.00
56	1.00
57	1.00
58	1.00
59	1.00
60	1.00
61	1.00
62	1.00
63	1.00
64	1.00
65	1.00
66	1.00
67	1.00
68	1.00
69	1.00
70	1.00
71	1.00
72	1.00
73	1.00
74	1.00
75	1.00
76	1.00
77	1.00
78	1.00
79	1.00
80	1.00
81	1.00
82	1.00
83	1.00
84	1.00
85	1.00
86	1.00
87	1.00
88	1.00
89	1.00
90	1.00
91	1.00
92	1.00
93	1.00
94	1.00
95	1.00
96	1.00
97	1.00
98	1.00
99	1.00
100	1.00

[illegible]

RUNNING GEAR (Fixed Height) (Braked) (Folding)




T2921_00
10/08

**RUNNING GEAR
(Fixed Height) (Braked)
(Folding)**

Item	Part Number	Description	Remarks	Serial Number	Qty
1	54774492	EYE	A - (Ø 28mm)		1
1	54774500	EYE	B - (Ø 40mm)		1
1	54774518	EYE	C - (Ø 50mm)		1
1	54774534	EYE	D - (Ø 68mm)		1
1	54774542	EYE	E - (Ø 76mm)		1
1	22112908	HITCH, BALL	F		1
2	46517710	KIT, COVER	W/Ref. 2-3		1
2		CLIP, RETAINING	NAP - Order Ref. 2		2
3		COVER	NAP - Order Ref. 2		1
4	46517728	KIT, TUBE SLIDER	W/Ref. 4-6		1
4		TUBE	NAP - Order Ref. 4		1
5		SLIDER	NAP - Order Ref. 4		1
6		PIN	NAP - Order Ref. 4		1
7	46517827	KIT, DAMPER	W/Ref. 7-10		1
7		DAMPER	NAP - Order Ref. 7		1
8		NUT	NAP - Order Ref. 7		1
9		RING	NAP - Order Ref. 7		1
10		JOINT	NAP - Order Ref. 7		1
11	22051460	WASHER			4
12	22051403	SCREW			2
13	22051676	SCREW			2
14	46517751	KIT, SLEEVE	W/Ref. 14-16		1
14		NUT	NAP - Order Ref. 14		1
15		SLEEVE	NAP - Order Ref. 14		2
16		BOLT	NAP - Order Ref. 14		1
17	46517736	KIT, LEVER AND CONNECTOR	W/Ref. 17-27		1
17		WASHER	NAP - Order Ref. 17		1
18		NUT	NAP - Order Ref. 17		1
19		WASHER	NAP - Order Ref. 17		1
20		LEVER	NAP - Order Ref. 17		1
21		PIN, SPLIT	NAP - Order Ref. 17		1

RUNNING GEAR (CONT'D) **(Fixed Height) (Braked)** **(Folding)**




T2921_00
10/08

RUNNING GEAR (CONT'D)
(Fixed Height) (Braked)
(Folding)

Item	Part Number	Description	Remarks	Serial Number	Qty
22		WASHER	NAP - Order Ref. 17		1
23		CONNECTOR	NAP - Order Ref. 17		1
24		NUT	NAP - Order Ref. 17		1
25		PIN	NAP - Order Ref. 17		1
26		BUSH	NAP - Order Ref. 17		1
27		WASHER	NAP - Order Ref. 17		1
28	46517538	DRAWBAR			1
29	46517702	CABLE, HANDBRAKE			1
30	46517520	HANDBRAKE ASSEMBLY			1
31	46517744	KIT, PISTON	W/Ref. 31-33		1
31		CLIP, RETAINING	NAP - Order Ref. 31		2
32		PISTON	NAP - Order Ref. 31		1
33		NUT	NAP - Order Ref. 31		1
34	22051726	BOLT			1
35	22051718	HANDLE			1
36	22051734	CLIP ASSEMBLY			1
37	22053763	JOCKEY WHEEL ASSEMBLY			1
38	22067003	CLAMP ASSEMBLY			1
39	22357503	SCREW			2
40	46517462	NUT			2
41	22357511	WASHER			2
42	46517363	PLUG			4
43	46517389	BOLT			8
44	46517835	T-BAR			1
45	46517884	KIT, CABLE	W/Ref. 45-46		1
45		CABLE	NAP - Order Ref. 45		1
46		NUT	NAP - Order Ref. 45		1
47	46517769	KIT, ROD	W/Ref. 47-55		1
47		NUT	NAP - Order Ref. 47		8
48		NUT	NAP - Order Ref. 47		1
49		ROD	NAP - Order Ref. 47		1

RUNNING GEAR (CONT'D) **(Fixed Height) (Braked)** **(Folding)**




T2921_00
10/08

RUNNING GEAR (CONT'D)
(Fixed Height) (Braked)
(Folding)

Item	Part Number	Description	Remarks	Serial Number	Qty
50		SPRING	NAP - Order Ref. 47		1
51		BUSH	NAP - Order Ref. 47		1
52		NUT	NAP - Order Ref. 47		2
53		NUT	NAP - Order Ref. 47		2
54		PLATE	NAP - Order Ref. 47		1
55		NUT	NAP - Order Ref. 47		1
56	46517397	CABLE			2
57	46517611	FRAME			1
58	46517579	PLATE			1
59	46517595	WASHER			20
60	22051494	NUT			14
61	46517603	SCREW			6
62	46517777	KIT, DRUM	W/Ref. 62-66		2
62		NUT	NAP - Order Ref. 62		2
63		CAP	NAP - Order Ref. 62		2
64		CLIP, RETAINING	NAP - Order Ref. 62		4
65		BEARING	NAP - Order Ref. 62		2
66		DRUM	NAP - Order Ref. 62		2
67	22312441	BOLT			8
68	46517819	KIT, LEVER SPRING	W/Ref. 68-69		2
68		LEVER	NAP - Order Ref. 68		2
69		ATTACHMENT	NAP - Order Ref. 68		2
70	46517801	KIT, SHOE	W/Ref. 70-74		2
70		SPRING	NAP - Order Ref. 70		2
71		SPRING	NAP - Order Ref. 70		2
72		SHOE	NAP - Order Ref. 70 - front		2
73		SHOE	NAP - Order Ref. 70 - rear		2
74		SPRING	NAP - Order Ref. 70		2
75	46517793	KIT, TAPER	W/Ref. 75-77		2
75		TAPER	NAP - Order Ref. 75		2
76		KEY	NAP - Order Ref. 75		4

RUNNING GEAR (CONT'D) **(Fixed Height) (Braked)** **(Folding)**




T2921_00
10/08

RUNNING GEAR (CONT'D) (Fixed Height) (Braked) (Folding)	
--	--

[illegible]

RUNNING GEAR (Variable Height) (Braked)




T2922_00
10/08

RUNNING GEAR (Variable Height) (Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	54774492	EYE	A - (Ø 28mm)		1
1	54774500	EYE	B - (Ø 40mm)		1
1	54774518	EYE	C - (Ø 50mm)		1
1	54774534	EYE	D - (Ø 68mm)		1
1	54774542	EYE	E - (Ø 76mm)		1
1	22112908	HITCH, BALL	F		1
2	46517710	KIT, COVER	W/Ref. 2-3		1
2		CLIP, RETAINING	NAP - Order Ref. 2		2
3		COVER	NAP - Order Ref. 2		1
4	46517728	KIT, TUBE SLIDER	W/Ref. 4-6		1
4		TUBE	NAP - Order Ref. 4		1
5		SLIDER	NAP - Order Ref. 4		1
6		PIN	NAP - Order Ref. 4		1
7	46517827	KIT, DAMPER	W/Ref. 7-10		1
7		DAMPER	NAP - Order Ref. 7		1
8		NUT	NAP - Order Ref. 7		1
9		RING	NAP - Order Ref. 7		1
10		JOINT	NAP - Order Ref. 7		1
11	22051460	WASHER			4
12	22051403	SCREW			2
13	22051676	SCREW			2
14	46517751	KIT, SLEEVE	W/Ref. 14-16		1
14		NUT	NAP - Order Ref. 14		1
15		SLEEVE	NAP - Order Ref. 14		2
16		BOLT	NAP - Order Ref. 14		1
17	46517736	KIT, LEVER AND CONNECTOR	W/Ref. 17-27		1
17		WASHER	NAP - Order Ref. 17		1
18		NUT	NAP - Order Ref. 17		1
19		WASHER	NAP - Order Ref. 17		1
20		LEVER	NAP - Order Ref. 17		1
21		PIN, SPLIT	NAP - Order Ref. 17		1


RUNNING GEAR (CONT'D) **(Variable Height) (Braked)**



RUNNING GEAR (CONT'D)
(Variable Height) (Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
22		WASHER	NAP - Order Ref. 17		1
23		CONNECTOR	NAP - Order Ref. 17		1
24		NUT	NAP - Order Ref. 17		1
25		PIN	NAP - Order Ref. 17		1
26		BUSH	NAP - Order Ref. 17		1
27		WASHER	NAP - Order Ref. 17		1
28	46517538	DRAWBAR			1
29	46517702	CABLE, HANDBRAKE			1
30	46517520	HANDBRAKE ASSEMBLY			1
31	46517744	KIT, PISTON	W/Ref. 31-33		1
31		CLIP, RETAINING	NAP - Order Ref. 31		2
32		PISTON	NAP - Order Ref. 31		1
33		NUT	NAP - Order Ref. 31		1
34	22051726	BOLT			2
35	22051718	HANDLE			2
36	22051734	CLIP ASSEMBLY			2
37	22053763	JOCKEY WHEEL ASSEMBLY			1
38	22067003	CLAMP ASSEMBLY			1
39	22357503	SCREW			2
40	46517462	NUT			2
41	22357511	WASHER			2
42	22051247	PLUG			2
43	46517389	BOLT			8
44	46517488	T-BAR			1
45	46517785	KIT, CABLE	W/Ref. 45-46		1
45		CABLE	NAP - Order Ref. 45		1
46		NUT	NAP - Order Ref. 45		1
47	46517769	KIT, ROD	W/Ref. 47-55		1
47		NUT	NAP - Order Ref. 47		8
48		NUT	NAP - Order Ref. 47		1
49		ROD	NAP - Order Ref. 47		1

RUNNING GEAR (CONT'D) (Variable Height) (Braked)




T2922_00
10/08

RUNNING GEAR (CONT'D)
(Variable Height) (Braked)

Item	Part Number	Description	Remarks	Serial Number	Qty
50		SPRING	NAP - Order Ref. 47		1
51		BUSH	NAP - Order Ref. 47		1
52		NUT	NAP - Order Ref. 47		2
53		NUT	NAP - Order Ref. 47		2
54		PLATE	NAP - Order Ref. 47		1
55		NUT	NAP - Order Ref. 47		1
56	46517397	CABLE			2
57	46517611	FRAME			1
58	46517579	PLATE			1
59	46517595	WASHER			20
60	22051494	NUT			14
61	46517603	SCREW			6
62	46517777	KIT, DRUM	W/Ref. 62-66		2
62		NUT	NAP - Order Ref. 62		2
63		CAP	NAP - Order Ref. 62		2
64		CLIP, RETAINING	NAP - Order Ref. 62		4
65		BEARING	NAP - Order Ref. 62		2
66		DRUM	NAP - Order Ref. 62		2
67	22312441	BOLT			8
68	46517819	KIT, LEVER SPRING	W/Ref. 68-69		2
68		LEVER	NAP - Order Ref. 68		2
69		ATTACHMENT	NAP - Order Ref. 68		2
70	46517801	KIT, SHOE	W/Ref. 70-74		2
70		SPRING	NAP - Order Ref. 70		2
71		SPRING	NAP - Order Ref. 70		2
72		SHOE	NAP - Order Ref. 70 - front		2
73		SHOE	NAP - Order Ref. 70 - rear		2
74		SPRING	NAP - Order Ref. 70		2
75	46517793	KIT, TAPER	W/Ref. 75-77		2
75		TAPER	NAP - Order Ref. 75		2
76		KEY	NAP - Order Ref. 75		4


RUNNING GEAR (CONT'D) **(Variable Height) (Braked)**



T2922_00
10/08


[illegible]

FRAME ASSEMBLY



[illegible]

ENCLOSURE (Front)




T2914-A_01
06/08

ENCLOSURE (Front)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	92121243	REFLECTOR, AMBER			2
2	46551569	RIVET			2
3	23287923	COVER, FORK LIFT			1
4	23281868	PANEL			1
5	23243744	BAIL, LIFTING			1
6	23281801	COVER, LIFTING BAIL			1
7	23281850	EYE, LIFTING			1
8	23281942	PANEL, RH			1
9	23330681	PANEL, LH			1
10	23281959	PANEL, FRONT			1
11	23326689	COVER			1
12	22068373	SEAL	0,65 m long		1
13	36794816	RIVET			4
14	46502738	COVER, INSTRUMENT PANEL			1
15	23253487	LOCK			1
16	23283146	CAM, LOCK			1
17	23253107	HINGE, UPPER			2
18	23253560	SPACER, HINGE			2
19	96732623	SCREW			8
20	92304583	WASHER			8
21	96704580	NUT			8
22	23247117	SEAL			1
23	23282098	COVER, PANEL			1
24	96728480	SCREW			42
25	92783281	PLUG			36
26	96727789	SCREW			2
27	23295058	COVER			1
28	96733746	SCREW			4
29	46540258	SPACER, REFLECTOR			2
30	23076656	WASHER			2
31	46553730	LAMP, AUTO START	auto start option		1

ENCLOSURE (CONT'D) (Front)




T2914-A_01
06/08

ENCLOSURE (CONT'D) (Front)

[illegible]

ENCLOSURE (Rear)




T2914-B_01
06/08

ENCLOSURE (Rear)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	23348113	CANOPY ASSEMBLY	W/Ref. 1-16		1
1	23287154	CANOPY, HINGED			1
2	89288757	LATCH			1
3	46550645	KEY, LATCH			2
4	36889608	SCREW			4
5	92119957	SEAL	2,35 m long		1
6	92119957	SEAL	2,29 m long		1
8	23351778	FOAM			1
9	23355217	PLATE, HINGE			1
10	92184811	SCREW			4
11	36794816	RIVET			4
12	92398130	SCREW			4
13	92441450	SCREW			2
14	92798727	HINGE, LOWER			2
15	92799501	PROTECTOR			2
16	35130707	HANDLE			2
17	92119445	PIN, HINGE			2
18	92798719	HINGE, UPPER			2
19	92119460	WASHER			4
20	92304559	NUT			2
21	35337328	STUD, BALL			4
22	23325541	SPRING, GAS			1
23	92121243	REFLECTOR, AMBER			2
24	92271923	RIVET			6
25	36887701	REFLECTOR, RED			2
26	54772041	PLUG			2
27	92890037	PLUG			8
28	46538757	WASHER			8
29	36881886	NUT			4
30	46501391	INSULATION, ENGINE SIDE			1
31	46501979	INSULATION, ENGINE REAR SIDE			1

ENCLOSURE (CONT'D) (Rear)




T2914-B_01
06/08

ENCLOSURE (CONT'D)
(Rear)

[illegible]


TOWER SUPPORT



T2918-A_00
11/10


[illegible]

TOWER ASSEMBLY (Section A through E)



[illegible]


TOWER ASSEMBLY (Section F through K)



**TOWER ASSEMBLY
(Section F through K)**

Item	Part Number	Description	Remarks	Serial Number	Qty
23	23351661	STIFFENER			1
24	23244155	TUBE, MAST			1
25	23244163	SLIDE	9 mm		2
26	23244106	SLIDE	4 mm		12
27	23329931	STIFFENER			1
28	23244064	TUBE, MAST			1
29	23244114	GUIDE	type 1		4
30	23244031	TUBE, MAST			1
31	23276124	BRACKET			2
32	96702816	SCREW			4
33	92061480	WASHER			22
34	23245947	GUIDE, ROLLER			6
35	23260946	SCREW			6
36	23318256	SUPPORT			1
37	23298409	BUSH			1
38	96724679	NUT			1
39	96746664	PIN, SPLIT			1
40	22959936	SCREW			4
41	23340185	COVER			1
42	23244148	CABLE			7
43	23244130	PIN			7
44	95935037	WASHER			7
45	95223251	CLIP, RETAINING			7
46	92304351	SCREW			7
47	96704606	NUT			13
48	92339688	SCREW			8
49	95928321	WASHER			1

DECALS AND DOCUMENTATION




T2939_00
10/10

DECALS AND DOCUMENTATION

[illegible]

DECALS AND DOCUMENTATION




1



2



3



4




5



6



7




8



9




10




11




13



18



12



14



15



16



17


CLASS 1 - RECOMMENDED MAINTENANCE AND REPAIR ITEMS		
ITEM	CPN	DESCRIPTION
1	80311716	PROTECT ENGINE OIL (20 LITERS)
2	22314322	INLINE FUEL FILTER
3	22283360	FUEL FILTER ELEMENT
4	22284640	FUEL WATER SEPARATOR ELEMENT
5	22355481	OIL FILTER
6	36800135	AIR, FILTER ELEMENT
7	15908098	V-BELT
8	36878379	OIL PRESSURE SWITCH
9	36868479	TEMPERATURE SWITCH
10	15907066	THERMOSTAT
11	22518184	LAMP BULB

CPN 46502803 A


19

OPERATING INSTRUCTIONS	
MANUAL MODE	
AUTOSTART MODE	

20



21




22

DECALS AND DOCUMENTATION

Item	Part Number	Description	Remarks	Serial Number	Qty
1	92930593	DECAL, ELECTRIC SHOCK			4
2	92867530	DECAL, HOT SURFACE			11
3	92930601	DECAL, CORROSIVE SUBSTANCE			1
4	92912559	DECAL, EARTH WARNING			1
5	92930668	DECAL, NO MAINT/READ MANUAL			2
6	93165959	DECAL, ROTATING FAN			1
7	92867449	DECAL, REFER TO HANDBOOK			1
8	92930650	DECAL, EMERGENCY STOP			1
9	92930627	DECAL, GENERAL WARNING			3
10	22508147	DECAL, ESA 3-PART WARNING			1
11	93171254	DECAL, DIESEL FUEL			1
12	22508147	DECAL, ULTRA VIOLET			1
13	93171262	DECAL, LIFT/TIE POINT			6
14	93178184	DECAL, TYRE PRESSURE	3,5 bar		2
15	93171288	DECAL, COOLANT FILL			1
16	92976042	DECAL, EXHAUST GAS DISCHARGE			2
17	46538773	DECAL, NOISE LEVEL	86 dB		2
18	54629977	DECAL, ISO CENTRAL DRAIN			2
19	46502803	DECAL, CLASS 1 RECOMMENDED PARTS			
20	23209398	DECAL, OPERATING INSTRUCTIONS	autostart option		1
21	46553637	DECAL, TILTING	lamp tilting option and field kit		1
22	46553728	DECAL, AUTO START	auto start option		1
23	46500039	MANUAL, OPERATION AND MAINTENANCE	(en) - not shown on illustration		1
24	46500526	MANUAL, OPERATION AND MAINTENANCE	(fr)- not shown on illustration		1
25	46500534	MANUAL, OPERATION AND MAINTENANCE	(it) - not shown on illustration		1
26	46500542	MANUAL, OPERATION AND MAINTENANCE	(es) - not shown on illustration		1
27	46500559	MANUAL, OPERATION AND MAINTENANCE	(de) - not shown on illustration		1
28	46500567	MANUAL, OPERATION AND MAINTENANCE	(nl) - not shown on illustration		1
29	46500575	MANUAL, OPERATION AND MAINTENANCE	(hu) - not shown on illustration		1
30	46500047	MANUAL, PARTS CATALOGUE	(en) - not shown on illustration		1


HYDRAULIC ASSEMBLY



HYDRAULIC ASSEMBLY

Item	Part Number	Description	Remarks	Serial Number	Qty
1	23228729	MODULE, HYRAULIC	W/Ref. 1-9		1
1	46500328	MOTOR			1
2	46500336	SWITCH, START			1
3	46500344	KIT, PUMP			1
4	46500351	DOG, DRIVE			1
5	46500369	VALVE, LOWERING			1
6	46500385	CAP, FILLER			1
7	46500393	KIT, TANK			1
8	46500377	COIL	not shown on illustration		1
9	46500401	KIT, SEAL	not shown on illustration		1
10	92472638	SCREW			2
11	96753645	ELBOW			1
12	23355969	HOSE, HYDRAULIC			1
13	96739461	CONNECTOR			1
14	46501987	CYLINDER, HYDRAULIC			1
15	46502001	KIT, SEAL	not shown on illustration		1
16	46551644	VALVE, HOSE BURST	not shown on illustration		1
17	23259518	PIN, CYLINDER			1
18	23259526	PIN, CYLINDER			1
19	96711189	CLIP, RETAINING			4
20	23334840	SENSOR, INDUCTIVE			1
21	46501938	COVER, SWITCH			1
22	23350721	SWITCH			1
23	35300771	SCREW			2
24	92341981	WASHER			2
25	96725270	SCREW			3
26	92304583	WASHER			3
27	96704580	NUT			3
28	92829316	NUT			2
29	23356124	HARNESS, HYDRAULIC PUMP	not shown on illustration		1
30	23356033	HARNESS, SWITCH	not shown on illustration		1


CONTROL PANEL (Housing)



CONTROL PANEL (Housing)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	23235310	BOX, CONTROL PANEL			1
2	23335375	BRACKET			1
3	36797652	SCREW			12
4	46552237	PANEL, CONTROL			1
5	22947337	COVER ASSEMBLY	W/Ref. 5-6		1
6	95954525	SCREW			4
7	23239411	PANEL			1
8	46551544	BASE, PIN			2
9	46551544	BASE, PIN	external power option		1
10	46551635	SCREW			2
11	96704580	NUT			2
12	23346307	SEAL			1
13	46553713	PLUG, TIMER			1
14	92340439	WASHER			4
15	46541223	NUT			4
16	96743653	SCREW			4
17	22125165	BOLT	auto start option		2
18	92304583	WASHER	auto start option		2
19	96704580	NUT	auto start option		2
20	46552240	RAIL, DIN	auto start option		1
21	46552238	HOLDER, TIMER	auto start option		2
22	46553747	TIMER	auto start option		1
23	46553748	DECAL, TIMER	auto start option		1
24	36785145	DEVICE, SIGNAL	autostart option		1
25	46552152	HOLDER, BALLAST	auto start option		1
26	36797652	SCREW	auto start option		4
27	23102395	PLUG			1

CONTROL PANEL (Fascia)




T2919_01
10/08

CONTROL PANEL (Fascia)

[illegible]


CONTROL PANEL (Sockets) (110V)



**CONTROL PANEL
(Sockets)
(110V)**

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46539417	SOCKET ASSEMBLY	W/Ref. 2-13		1
2	46540845	BOX, REAR			1
3	46540811	COVER, SOCKET BOX			1
4	46539219	PLATE, COVER			1
5	46540977	SOCKET	110 V		2
6	92340439	WASHER			16
7	92304583	WASHER			4
8	92340447	WASHER, SPRING			8
9	92304641	WASHER			4
10	46541223	NUT			8
11	96737531	SCREW			4
12	96743653	SCREW			8
13	23259104	SCREW			8
14	23339021	ELBOW			3
15	23354921	CONDUIT	0,5 m long		1
16	23354921	CONDUIT	0,4 m long		1
17	23339039	SLEEVE, CONDUIT			1
18	22938336	BLOCK, CONTACT	NC Emergency stop button		1
19	89303135	BLOCK, CONTACT	Emergency stop button		2
20	89303127	BUTTON, EMERGENCY STOP			1
21	46539755	INLET, APPLIANCE	external power option		1
22	46551716	COVER	external power option		1
23	96704408	SCREW			4
24	96745211	SCREW			4
25	96704408	SCREW			5


CONTROL PANEL (Sockets) (230V)



**CONTROL PANEL
(Sockets)
(230V)**


Item	Part Number	Description	Remarks	Serial Number	Qty
1	46540985	SOCKET ASSEMBLY	W/Ref. 2-13		1
2	46540845	BOX, REAR			1
3	46540811	COVER, SOCKET BOX			1
4	46539219	PLATE, COVER			1
5	46540993	SOCKET	230 V		2
6	92340439	WASHER			16
7	92304583	WASHER			4
8	92340447	WASHER, SPRING			8
9	92304641	WASHER			4
10	46541223	NUT			8
11	96737531	SCREW			4
12	96743653	SCREW			8
13	23259104	SCREW			8
14	23339021	ELBOW			3
15	23354921	CONDUIT	0,5 m long		1
16	23354921	CONDUIT	0,4 m long		1
17	23339039	SLEEVE, CONDUIT			1
18	22938336	BLOCK, CONTACT	NC Emergency stop button		1
19	89303135	BLOCK, CONTACT	Emergency stop button		2
20	89303127	BUTTON, EMERGENCY STOP			1
21	46539755	INLET, APPLIANCE	external power option		1
22	46551716	COVER	external power option		1
23	96704408	SCREW			5
24	96745211	SCREW			4
25	96704408	SCREW			4

CONTROL PANEL **(Electrical System)** **(110V)**



CONTROL PANEL (Electrical System) (110V)					
Item	Part Number	Description	Remarks	Serial Number	Qty
1	22881668	BREAKER, CIRCUIT			1
2	23183627	BREAKER, CIRCUIT	30 A		1
3	46540100	BREAKER, CIRCUIT			2
4	22125165	BOLT			2
5	46539748	TERMINAL ASSEMBLY	110 - 130 V		1
6	46539722	RELAY, OVER CURRENT			1
7	96743653	SCREW			2
8	22499164	CONTACTOR	25 A		1
9	22743314	CONTROLLER, ELECTRONIC	auto start option		1
10	92184811	SCREW	auto start option		2
11	22947345	BUSBAR			1
12	22953228	INSULATOR, BUSBAR			1
13	46552246	BALLAST	1000 W		4
14	92184811	SCREW			36
15	92281369	RIVET			2
16	22947360	SUPPORT, BUSBAR			2
17	22562847	CAPACITOR	50 μ F		4
18	22562821	IGNITOR, IMPULSER			4
19	46540027	TRANSFORMER			1
20	36878361	RELAY, FUEL SHUTDOWN	auto start option		5
21	46551522	CONTACTOR ASSEMBLY	external power option - W/Ref. 21-23		1
22	46551521	BLOCK, AUXILIARY CONTACT	external power option - 1 off per assembly		2
23	23238793	CONTACTOR, 3 POLE	external power option		1
24	46551547	RELAY, DELAYED TIMER	external power option		1
25	46551556	RELAY	external power option		2
26	92659432	SCREW	external power option		2
27	36797652	SCREW			2
28	46540043	RESISTOR			1
29	46551549	DIAGRAM, HARNESS AND WIRING	external power option - not shown on illustration		1
30	46551582	HARNESS, AC	not shown on illustration		1
31	46551580	HARNESS, DC	not shown on illustration		1


CONTROL PANEL (CONT'D) **(Electrical System)** **(110V)**



CONTROL PANEL (CONT'D) (Electrical System) (110V)


[illegible]

CONTROL PANEL **(Electrical System)** **(230V)**



CONTROL PANEL (Electrical System) (230V)					
Item	Part Number	Description	Remarks	Serial Number	Qty
1	22881668	BREAKER, CIRCUIT			1
2	23183627	BREAKER, CIRCUIT	30 A		1
3	23062565	BREAKER, CIRCUIT			2
4	22125165	BOLT			2
5	23288376	TERMINAL ASSEMBLY	230 V		1
6	46551580	HARNESS, DC	not shown on illustration		1
7	96743653	SCREW			2
8	22499164	CONTACTOR	25 A		1
9	22743314	CONTROLLER, ELECTRONIC	auto start option		1
10	92184811	SCREW	auto start option		2
11	22947345	BUSBAR			1
12	22953228	INSULATOR, BUSBAR			1
13	46552246	BALLAST	1000 W		4
14	92184811	SCREW			36
15	92281369	RIVET			2
16	22947360	SUPPORT, BUSBAR			2
17	22562847	CAPACITOR	50 μ F		4
18	22562821	IGNITOR, IMPULSER			4
19	46551581	HARNESS, AC	not shown on illustration		1
20	36878361	RELAY, FUEL SHUTDOWN	auto start option		5
21	46551522	CONTACTOR ASSEMBLY	external power option - W/Ref. 21-23		1
22	46551521	BLOCK, AUXILIARY CONTACT	external power option - 1 off per assembly		2
23	23238793	CONTACTOR, 3 POLE	external power option		1
24	46551547	RELAY, DELAYED TIMER	external power option		1
25	46551556	RELAY	external power option		2
26	92659432	SCREW	external power option		2
27	46551549	DIAGRAM, HARNESS AND WIRING	external power option - not shown on illustration		1
28	46553732	HARNESS, AUTOSTART	auto start option - not shown on illustration		1
29	46553740	DIAGRAM, WIRING	auto start option - not shown on illustration		1

BATTERY




T2918-B_01
11/10

BATTERY	
---------	--

[illegible]


ALTERNATOR AND MOUNTING



T2905_00
05/08

[illegible]


LAMP ASSEMBLY



T2911_01
10/10

[illegible]


LAMP UNIT



T2912_00
06/08

LAMP UNIT	
-----------	--


LAMP CONNECTION BOX ASSEMBLY



T2965_00
12/10

[illegible]

TRAILER LIGHTING




T2924_01
11/10

TRAILER LIGHTING	
------------------	--

[illegible]





ENGINE MOUNTING



T2906_00
09/08

[illegible]


ENGINE ASSEMBLY



T2920
Revision 00
10/08

[illegible]

OIL PAN




T2940_00
11/10

OIL PAN

[illegible]

GEAR CASE / OIL FILTER




T2963_00
11/10

GEAR CASE / OIL FILTER	
------------------------	--

[illegible]


HEAD COVER	
------------	--



HEAD COVER

[illegible]

DIPSTICK AND GUIDE




T2944_00
11/10

DIPSTICK AND GUIDE

[illegible]


STOP SOLENOID



STOP SOLENOID

[illegible]


FUEL INJECTION PUMP



T2946_00
11/10

[illegible]

GOVERNOR




T2947_00
11/10

GOVERNOR

[illegible]


SPEED CONTROL PLATE



T2948_00
11/10

[illegible]


NOZZLE HOLDER & GLOW PLUGS



T2949_00
11/10

[illegible]


NOZZLE HOLDER COMPONENT PARTS



T2950_00
11/10

[illegible]

FUEL PUMP MECHANICAL




T2951_00
11/10

FUEL PUMP MECHANICAL	
----------------------	--


[illegible]

ALTERNATOR AND PULLEY



[illegible]

STARTER




T2953_00
11/10

STARTER


[illegible]

WATER FLANGE AND THERMOSTAT



[illegible]

WATER PUMP




T2955_00
11/10

WATER PUMP

[illegible]

WATER PIPE




T2956_00
11/10

WATER PIPE	
------------	--

[illegible]



FAN



FAN

[illegible]


INLET AND EXHAUST MANIFOLD



T2964_00
11/10

[illegible]

STARTER SWITCH




T2960_00
11/10

STARTER SWITCH

[illegible]


AIR INTAKE / ENGINE EXHAUST SYSTEM



T2908_01
10/10

[illegible]

COOLING SYSTEM




T2913_01
07/08

COOLING SYSTEM

Item	Part Number	Description	Remarks	Serial Number	Qty
1	23250673	BAFFLE			1
2	92184811	SCREW			6
3	23083405	RADIATOR			1
4	36884948	RADIATOR			1
5	96728480	SCREW			4
6	54576624	HOSE	4 mm x 0,8 m long		1
7	22817365	CLIP, RETAINING			2
8	54576624	HOSE	8 mm x 0,65 m long		1
9	36898096	SCREW			1
10	36898104	WASHER			6
11	36868727	GUARD, FAN			1
12	92803998	CLIP, RETAINING			4
13	36888469	HOSE			1
14	36888477	HOSE			1
15	23370752	PIN, SPLIT			2
16	23370794	CAP			4
17	23370786	ISOLATOR, UPPER			2
18	23370778	ISOLATOR, LOWER			2
19	23370760	SCREW			2
20	23332125	PLATE, RETAINING			2
21	96704408	SCREW			2
22	23341738	BRACKET			2
23	23332091	BRACKET			2
24	36871614	BRACKET			1
25	36797652	SCREW			1

FUEL SYSTEM




T2907_01
10/10

FUEL SYSTEM

Item	Part Number	Description	Remarks	Serial Number	Qty
1	23219074	FUEL TANK ASSEMBLY	W/Ref. 1-9		1
1	23226582	TANK, FUEL			1
2	23331176	CAP			1
3	23285646	COVER			1
4	23286065	GASKET			1
5	96701958	SCREW			10
6	23292121	SWITCH ASSEMBLY	fuel level W/Ref. 6-8		1
7	35361849	GASKET			1
8	95916532	SCREW			5
9	23287501	ELBOW			2
10	22314322	PRE-FILTER, FUEL			1
11	15908361	SEPARATOR, WATER			1
12	15908369	ELEMENT, WATER SEPARATOR			1
13	15908742	FILTER, FUEL			1
14	15908792	ELEMENT, FUEL FILTER			1
15	22817365	CLIP, RETAINING			8
16	22921092	CLIP, RETAINING			3
17	22306229	SCREW			1
18	22167084	HOSE	bulk sold per metre		6
19	23331234	CLIP, RETAINING			3
20	22687552	CLIP, RETAINING			2
21	22981393	COUPLING			1
22	46502845	DECAL, FUEL LEVEL			1
23	54403191	ELBOW			2
24	46502886	TUBE, SIGHT			1
25	35225093	CLIP, RETAINING			1
26	93150977	SCREW			1
27	36881886	NUT			1
28	46538922	PUMP, FUEL			1
29	92184811	SCREW			2
30	23325756	TRAY, DRIP			1

FUEL SYSTEM (CONT'D)




T2907_01
10/10

FUEL SYSTEM (CONT'D)	
----------------------	--

[illegible]


CENTRAL DRAIN



CENTRAL DRAIN

[illegible]


OPTION LIGHTS (L1 - non CE countries)



OPTION LIGHTS (L1 - non CE countries)	
--	--

[illegible]


OPTION LAMP TILTING AND FIELD KIT



OPTION LAMP TILTING AND FIELD KIT

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46553608	SUPPORT	left crossarm and actuator		1
2	46553609	SUPPORT	right crossarm and actuator		1
3	46553610	CROSSARM, TILTING			1
4	22557946	TRUNNION			4
5	46553389	SUPPORT, JUNCTION BOX			1
6	46553387	SPACER			2
7	46553390	BUSH			2
8	46553607	BUSH			2
9	46553391	PIN			1
10	46553388	BRACKET			2
11	46553636	PROTECTOR			1
12	46553632	ENDSTOP			2
13	46553615	PIN			1
14	46553623	SPACER			2
15	46553637	DECAL, TILTING			1
16	46553633	GLAND AND NUT	only supplied with field kit		1
17	22967236	ACTUATOR			1
18	96727540	BOLT			1
19	46553794	PIN, SPLIT			2
20	46553796	PIN, SPLIT			2
21	92311703	BOLT			2
22	35273366	NUT			4
23	35304047	NUT			1
24	36763670	SCREW			2
25	92182138	SCREW			4
26	95935003	WASHER			1
27	95935037	WASHER			6
28	95935052	WASHER			6
29	96701743	NUT			1
30	96704630	NUT			2
31	35375377	SCREW			2


OPTION LAMP TILTING AND FIELD KIT (CONT'D)



T2938_00
10/10

[illegible]


OPTION DRIVING LIGHTS PROTECTION



OPTION DRIVING LIGHTS PROTECTION

[illegible]













FIELD KIT FUEL GAUGE ASSEMBLY



T2937_00
10/10

[illegible]

RECOMMENDED PARTS (Class 1)

































T2961_00
11/10

RECOMMENDED PARTS (Class 1)
--

[illegible]

RECOMMENDED PARTS (Class 2)



T2962_00
11/10

RECOMMENDED PARTS (Class 2)

Item	Part Number	Description	Remarks	Serial Number	Qty
1	46517959	FUEL INJECTION ASSEMBLY			1
2	23370943	STARTER ASSEMBLY			1
3	23370935	ALTERNATOR, CHARGING			1
4	15907108	PUMP, WATER			1
5	23226558	ALTERNATOR			1
6	15908239	STOP SOLENOID ASSEMBLY			1
7	80025828	BUTTON, EMERGENCY STOP			2
8	36888501	FAN			1
9	23083405	RADIATOR			1
10	36888469	HOSE			2
11	36888477	HOSE			2
12	46552246	BALLAST			4
13	23324619	PULLEY ASSEMBLY			7
14	23244148	CABLE			2
15	22167084	HOSE	8 mm x 3 m long		1
16	54576624	HOSE	4 mm x 1,5 m long		1
17	35376169	DIODE ASSEMBLY			2
18	23244304	GUIDE	type 7		1
19	23244296	GUIDE	type 6		1
20	23244270	GUIDE	type 5		1
21	23244262	GUIDE	type 4		1
22	23244205	GUIDE	type 3		5
23	23244197	GUIDE	type 2		5
24	23244114	GUIDE	type 1		4
25	23247455	SLIDE	2 mm		10
26	23244106	SLIDE	4 mm		12
27	23244189	SLIDE	6 mm		16
28	23244163	SLIDE	9 mm		2
29	23247463	SLIDE	10 mm		8
30	23292923	CABLE, RETRACTABLE			1
31	22966766	GLASS, LAMP COVER			2

Intentionally left blank

NUMERICAL INDEX

Part Number	Denomination	WAS	Page	Subgroup
			77	ENGINE ASSEMBLY
15905136	GASKET		83	HEAD COVER
15905144	JOINT, BREATHER PIPE		113	INLET AND EXHAUST MANIFOLD
15905193	SCREW AND WASHER ASSE		83	HEAD COVER
15905201	NUT		83	HEAD COVER
15905219	GASKET		83	HEAD COVER
15905755	GAUGE, OIL		85	DIPSTICK AND GUIDE
15905763	GUIDE, OIL GAUGE		85	DIPSTICK AND GUIDE
15905847	BOLT		93	SPEED CONTROL PLATE
15906639	WASHER		81	GEAR CASE / OIL FILTER
15906647	JOINT, PIPE		81	GEAR CASE / OIL FILTER
15906654	SPRING		81	GEAR CASE / OIL FILTER
15906662	SEAT, VALVE		81	GEAR CASE / OIL FILTER
15906670	BALL		81	GEAR CASE / OIL FILTER
15906753	BOLT		105	WATER FLANGE AND THERMOSTAT
15906803	WASHER, SPRING		89	FUEL INJECTION PUMP
15906829	STUD		93	SPEED CONTROL PLATE
15906886	GASKET, INDUCTION MANIF		113	INLET AND EXHAUST MANIFOLD
15906894	BOLT		113	INLET AND EXHAUST MANIFOLD
15906902	BOLT		113	INLET AND EXHAUST MANIFOLD
15906928	MANIFOLD		77	ENGINE ASSEMBLY
15906936	GASKET, EXHAUST MANIFO		77	ENGINE ASSEMBLY
			113	INLET AND EXHAUST MANIFOLD
15906944	STUD		113	INLET AND EXHAUST MANIFOLD
15906951	NUT		113	INLET AND EXHAUST MANIFOLD
15906985	PIPE, WATER RETURN		105	WATER FLANGE AND THERMOSTAT
15907017	GASKET		105	WATER FLANGE AND THERMOSTAT
15907025	PIPE, WATER RETURN		105	WATER FLANGE AND THERMOSTAT
15907033	CLIP, RETAINING		105	WATER FLANGE AND THERMOSTAT
15907066	THERMOSTAT		77	ENGINE ASSEMBLY
			105	WATER FLANGE AND THERMOSTAT
			137	RECOMMENDED PARTS
15907082	GASKET, THERMOSTAT		77	ENGINE ASSEMBLY
15907090	BOLT		105	WATER FLANGE AND THERMOSTAT
15907108	PUMP, WATER		77	ENGINE ASSEMBLY
			107	WATER PUMP
			139	RECOMMENDED PARTS
15907199	PIPE, WATER		109	WATER PIPE
15907207	HOSE, WATER		109	WATER PIPE
15907231	SHIM		89	FUEL INJECTION PUMP
15907249	SHIM		89	FUEL INJECTION PUMP
15907256	SHIM		89	FUEL INJECTION PUMP
15907272	STUD		89	FUEL INJECTION PUMP
15907280	NUT		89	FUEL INJECTION PUMP

Part Number	Denomination	WAS	Page	Subgroup
15907520	SCREW AND WASHER ASSE		89	FUEL INJECTION PUMP
15907538	GASKET		89	FUEL INJECTION PUMP
15907546	PLUG		89	FUEL INJECTION PUMP
15907553	GASKET		89	FUEL INJECTION PUMP
15907611	GASKET		93 95	SPEED CONTROL PLATE NOZZLE HOLDER & GLOW PLUGS
15907678	OVERFLOW PIPE ASSEMBL		95	NOZZLE HOLDER & GLOW PLUGS
15907686	SCREW, BLEED		95	NOZZLE HOLDER & GLOW PLUGS
15907694	OVERFLOW PIPE ASSEMBL		95	NOZZLE HOLDER & GLOW PLUGS
15907710	KIT, NOZZLE HOLDER		95	NOZZLE HOLDER & GLOW PLUGS
15907728	NOZZLE HOLDER ASSEMBL		95 97	NOZZLE HOLDER & GLOW PLUGS NOZZLE HOLDER COMPONENT PARTS
15907736	GASKET		95	NOZZLE HOLDER & GLOW PLUGS
15907744	SEAL, HEAT		95	NOZZLE HOLDER & GLOW PLUGS
15907751	PIPE, INJECTION		95	NOZZLE HOLDER & GLOW PLUGS
15907769	PIPE, INJECTION		95	NOZZLE HOLDER & GLOW PLUGS
15907777	PIPE, INJECTION		95	NOZZLE HOLDER & GLOW PLUGS
15907785	CLAMP, PIPE		95	NOZZLE HOLDER & GLOW PLUGS
15907793	CLAMP, PIPE		95	NOZZLE HOLDER & GLOW PLUGS
15907801	SCREW AND WASHER ASSE		95	NOZZLE HOLDER & GLOW PLUGS
15907827	CORD, GLOW PLUG		95	NOZZLE HOLDER & GLOW PLUGS
15907835	NUT, FLANGE		95	NOZZLE HOLDER & GLOW PLUGS
15907892	NUT		97	NOZZLE HOLDER COMPONENT PARTS
15907900	WASHER, ADJUSTING		97	NOZZLE HOLDER COMPONENT PARTS
15907918	SPRING, NOZZLE		97	NOZZLE HOLDER COMPONENT PARTS
15907926	SPACER		97	NOZZLE HOLDER COMPONENT PARTS
15907934	ROD, PUSH		97	NOZZLE HOLDER COMPONENT PARTS
15907942	NUT, NOZZLE		97	NOZZLE HOLDER COMPONENT PARTS
15907959	WASHER		97	NOZZLE HOLDER COMPONENT PARTS
15907967	PIECE, NOZZLE		97	NOZZLE HOLDER COMPONENT PARTS
15908015	BOLT		101	ALTERNATOR AND PULLEY
15908023	NUT		101	ALTERNATOR AND PULLEY
15908031	WASHER		101	ALTERNATOR AND PULLEY
15908049	WASHER, SPRING		101	ALTERNATOR AND PULLEY
15908064	PULLEY, FAN		77 101	ENGINE ASSEMBLY ALTERNATOR AND PULLEY
15908080	BOLT		101	ALTERNATOR AND PULLEY
15908098	V-BELT		77 101 137	ENGINE ASSEMBLY ALTERNATOR AND PULLEY RECOMMENDED PARTS
15908130	COUPLER ASSEMBLY		101	ALTERNATOR AND PULLEY
15908155	TERMINAL		101	ALTERNATOR AND PULLEY
15908184	CONNECTOR		101	ALTERNATOR AND PULLEY
15908239	STOP SOLENOID ASSEMBLY		77 87 139	ENGINE ASSEMBLY STOP SOLENOID RECOMMENDED PARTS
15908361	SEPARATOR, WATER		121	FUEL SYSTEM

Part Number	Denomination	WAS	Page	Subgroup
15908369	ELEMENT, WATER SEPARAT		121 137	FUEL SYSTEM RECOMMENDED PARTS
15908577	GASKET		93	SPEED CONTROL PLATE
15908585	BOLT		93	SPEED CONTROL PLATE
15908676	COVER		91	GOVERNOR
15908684	GASKET		91	GOVERNOR
15908692	BOLT		79	OIL PAN
15908700	COLLAR		91	GOVERNOR
15908718	BEARING		91	GOVERNOR
15908742	FILTER, FUEL		121	FUEL SYSTEM
15908759	ADJUSTER WASHER ASSEM		97	NOZZLE HOLDER COMPONENT PARTS
15908792	ELEMENT, FUEL FILTER		121 137	FUEL SYSTEM RECOMMENDED PARTS
22051247	PLUG		19	RUNNING GEAR
22051403	SCREW		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22051460	WASHER		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22051494	NUT		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22051676	SCREW		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22051718	HANDLE		11 19	RUNNING GEAR RUNNING GEAR
22051726	BOLT		11 19	RUNNING GEAR RUNNING GEAR
22051734	CLIP ASSEMBLY		11 19	RUNNING GEAR RUNNING GEAR
22053763	JOCKEY WHEEL ASSEMBLY		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22067003	CLAMP ASSEMBLY		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22068373	SEAL		29	ENCLOSURE
22112908	HITCH, BALL		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22123525	ROD, GROUND		27	FRAME ASSEMBLY
22125165	BOLT		49 57 61 127	CONTROL PANEL CONTROL PANEL CONTROL PANEL OPTION LIGHTS
22137624	BATTERY		63	BATTERY
22167084	HOSE		121 139	FUEL SYSTEM RECOMMENDED PARTS
22173561	FILTER, AIR		117	AIR INTAKE / ENGINE EXHAUST SYSTEM

Part Number	Denomination	WAS	Page	Subgroup
22306229	SCREW		121	FUEL SYSTEM
22307409	GASKET, EXHAUST		77	ENGINE ASSEMBLY
22312441	BOLT		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22314322	PRE-FILTER, FUEL		121 137	FUEL SYSTEM RECOMMENDED PARTS
22347033	CARRIER, WHEEL CHOCK		27	FRAME ASSEMBLY
22347041	CHOCK, WHEEL		27	FRAME ASSEMBLY
22349625	STAY		101	ALTERNATOR AND PULLEY
22355481	FILTER, ENGINE OIL		77 137	ENGINE ASSEMBLY RECOMMENDED PARTS
22357503	SCREW		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22357511	WASHER		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
22499164	CONTACTOR		57 61	CONTROL PANEL CONTROL PANEL
22508147	DECAL, ULTRA VIOLET		45	DECALS AND DOCUMENTATION
22514277	SOCKET ASSEMBLY		69	LAMP UNIT
22514285	HOUSING		69	LAMP UNIT
22514293	SEAL		69	LAMP UNIT
22518096	BLOCK, TERMINAL		69	LAMP UNIT
22518104	BULB		69 137	LAMP UNIT RECOMMENDED PARTS
22518112	REFLECTOR ASSEMBLY		69	LAMP UNIT
22518146	RESTRAINT		69	LAMP UNIT
22518153	PLATE, REFLECTOR		69	LAMP UNIT
22518161	PLATE, TEE RESTRAINT		69	LAMP UNIT
22518195	SEAL		69	LAMP UNIT
22518203	STRAIN, RELIEF		69	LAMP UNIT
22518211	SUPPORT, TERMINAL		69	LAMP UNIT
22518237	TEE, HINGE		69	LAMP UNIT
22522023	WASHER, NYLON		67	LAMP ASSEMBLY
22557946	TRUNNION		67 129	LAMP ASSEMBLY OPTION LAMP TILTING AND FIELD KIT
22557953	SUPPORT		67	LAMP ASSEMBLY
22558738	TRUNNION		67	LAMP ASSEMBLY
22562821	IGNITOR, IMPULSER		57 61	CONTROL PANEL CONTROL PANEL
22562847	CAPACITOR		57 61	CONTROL PANEL CONTROL PANEL
22567796	BOLT		103	STARTER
22568224	PLUG		85	DIPSTICK AND GUIDE
22578942	KNOB		51	CONTROL PANEL
22586382	CLAMP, HOSE		83	HEAD COVER

Part Number	Denomination	WAS	Page	Subgroup
22588800	VALVE, BREATHER		83	HEAD COVER
22594139	BOLT		105	WATER FLANGE AND THERMOSTAT
22594345	BOLT		101	ALTERNATOR AND PULLEY
22594535	NUT		93 99	SPEED CONTROL PLATE FUEL PUMP MECHANICAL
22595581	COVER, BREATHER		83	HEAD COVER
22687552	CLIP, RETAINING		121 135	FUEL SYSTEM FIELD KIT FUEL GAUGE ASSEMBLY
22743314	CONTROLLER, ELECTRONIC		57 61	CONTROL PANEL CONTROL PANEL
22817365	CLIP, RETAINING		119 121	COOLING SYSTEM FUEL SYSTEM
22881668	BREAKER, CIRCUIT		51 57 61	CONTROL PANEL CONTROL PANEL CONTROL PANEL
22904270	HOSE		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
22904296	SUPPORT		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
22921092	CLIP, RETAINING		121	FUEL SYSTEM
22926034	STRAP		37	TOWER SUPPORT
22938336	BLOCK, CONTACT		53 55	CONTROL PANEL CONTROL PANEL
22938369	CONNECTOR, GLAND CABL		71	LAMP CONNECTION BOX ASSEMBLY
22947337	COVER ASSEMBLY		49	CONTROL PANEL
22947345	BUSBAR		57 61	CONTROL PANEL CONTROL PANEL
22947360	SUPPORT, BUSBAR		57 61	CONTROL PANEL CONTROL PANEL
22953228	INSULATOR, BUSBAR		57 61	CONTROL PANEL CONTROL PANEL
22959316	INSERT		69	LAMP UNIT
22959936	SCREW		37 41	TOWER SUPPORT TOWER ASSEMBLY
22966766	GLASS, LAMP COVER		69 139	LAMP UNIT RECOMMENDED PARTS
22967236	ACTUATOR		129	OPTION LAMP TILTING AND FIELD KIT
22981393	COUPLING		121	FUEL SYSTEM
22986517	MOTOR, STARTER		77	ENGINE ASSEMBLY
23002496	LAMP ASSEMBLY WITHOUT		69	LAMP UNIT
23002504	LAMP ASSEMBLY		67 69	LAMP ASSEMBLY LAMP UNIT
23003924	SCREW		69	LAMP UNIT
23062565	BREAKER, CIRCUIT		51 61	CONTROL PANEL CONTROL PANEL
23076656	WASHER		29	ENCLOSURE
23083405	RADIATOR		119 139	COOLING SYSTEM RECOMMENDED PARTS
23102395	PLUG		49	CONTROL PANEL
23164866	SWITCH, PHOTO CELL ADJU		51	CONTROL PANEL
23183627	BREAKER, CIRCUIT		51	CONTROL PANEL

Part Number	Denomination	WAS	Page	Subgroup
			61	CONTROL PANEL
23196660	FENDER		27	FRAME ASSEMBLY
23209398	DECAL, OPERATING INSTRU		43	DECALS AND DOCUMENTATION
			45	DECALS AND DOCUMENTATION
23212863	LAMP, REVERSE		73	TRAILER LIGHTING
23217433	FRAME ASSEMBLY		27	FRAME ASSEMBLY
23219074	FUEL TANK ASSEMBLY		121	FUEL SYSTEM
23226525	RUNNING GEAR ASSEMBLY		19	RUNNING GEAR
23226558	ALTERNATOR		65	ALTERNATOR AND MOUNTING
			139	RECOMMENDED PARTS
23226582	TANK, FUEL		121	FUEL SYSTEM
23228729	MODULE, HYRAULIC		47	HYDRAULIC ASSEMBLY
23230659	ENGINE		75	ENGINE MOUNTING
			77	ENGINE ASSEMBLY
23231236	SWITCH, LAMP ON/OFF		51	CONTROL PANEL
23234081	SWITCH, MAST CONTROL		51	CONTROL PANEL
23234131	SUPPORT, TOWER		37	TOWER SUPPORT
23235310	BOX, CONTROL PANEL		49	CONTROL PANEL
23238793	CONTACTOR, 3 POLE		57	CONTROL PANEL
			61	CONTROL PANEL
23239411	PANEL		49	CONTROL PANEL
23243744	BAIL, LIFTING		29	ENCLOSURE
23243967	TUBE, FLEXIBLE		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
23244031	TUBE, MAST		41	TOWER ASSEMBLY
23244064	TUBE, MAST		41	TOWER ASSEMBLY
23244106	SLIDE		41	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244114	GUIDE		41	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244130	PIN		41	TOWER ASSEMBLY
23244148	CABLE		41	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244155	TUBE, MAST		41	TOWER ASSEMBLY
23244163	SLIDE		41	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244189	SLIDE		39	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244197	GUIDE		39	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244205	GUIDE		39	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244213	TUBE, MAST		39	TOWER ASSEMBLY
23244221	TUBE, MAST		39	TOWER ASSEMBLY
23244247	TUBE, MAST		39	TOWER ASSEMBLY
23244254	TUBE, MAST		39	TOWER ASSEMBLY
23244262	GUIDE		39	TOWER ASSEMBLY
			139	RECOMMENDED PARTS
23244270	GUIDE		39	TOWER ASSEMBLY
			139	RECOMMENDED PARTS

Part Number	Denomination	WAS	Page	Subgroup
23244288	TUBE, MAST		39	TOWER ASSEMBLY
23244296	GUIDE		39 139	TOWER ASSEMBLY RECOMMENDED PARTS
23244304	GUIDE		39 139	TOWER ASSEMBLY RECOMMENDED PARTS
23244353	PIPE, EXHAUST		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
23244361	SUPPORT		67	LAMP ASSEMBLY
23244874	MUFFLER, EXHAUST		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
23245947	GUIDE, ROLLER		41	TOWER ASSEMBLY
23247117	SEAL		29	ENCLOSURE
23247455	SLIDE		39 139	TOWER ASSEMBLY RECOMMENDED PARTS
23247463	SLIDE		39 139	TOWER ASSEMBLY RECOMMENDED PARTS
23250673	BAFFLE		119	COOLING SYSTEM
23251960	SOCKET		71	LAMP CONNECTION BOX ASSEMBLY
23252026	JUNCTION BOX ASSEMBLY		71	LAMP CONNECTION BOX ASSEMBLY
23252034	TERMINAL ASSEMBLY		71	LAMP CONNECTION BOX ASSEMBLY
23252141	LAMP CONNECTION BOX AS		67 71	LAMP ASSEMBLY LAMP CONNECTION BOX ASSEMBLY
23253107	HINGE, UPPER		29	ENCLOSURE
23253487	LOCK		29	ENCLOSURE
23253560	SPACER, HINGE		29	ENCLOSURE
23259104	SCREW		53 55	CONTROL PANEL CONTROL PANEL
23259500	CROSSBAR, MAST		67	LAMP ASSEMBLY
23259518	PIN, CYLINDER		47	HYDRAULIC ASSEMBLY
23259526	PIN, CYLINDER		47	HYDRAULIC ASSEMBLY
23260946	SCREW		41	TOWER ASSEMBLY
23261209	OUTRIGGER		27	FRAME ASSEMBLY
23265010	BRACKET		27	FRAME ASSEMBLY
23272115	ISOLATOR		65	ALTERNATOR AND MOUNTING
23276124	BRACKET		41	TOWER ASSEMBLY
23281801	COVER, LIFTING BAIL		29	ENCLOSURE
23281850	EYE, LIFTING		29	ENCLOSURE
23281868	PANEL		29	ENCLOSURE
23281942	PANEL, RH		29	ENCLOSURE
23281959	PANEL, FRONT		29	ENCLOSURE
23282098	COVER, PANEL		29	ENCLOSURE
23283146	CAM, LOCK		29	ENCLOSURE
23285646	COVER		121	FUEL SYSTEM
23286065	GASKET		121	FUEL SYSTEM
23287154	CANOPY, HINGED		33	ENCLOSURE
23287501	ELBOW		121	FUEL SYSTEM
23287766	HOSE		121 125	FUEL SYSTEM CENTRAL DRAIN
23287923	COVER, FORK LIFT		29	ENCLOSURE

Part Number	Denomination	WAS	Page	Subgroup
23288368	SWITCH, LAMP TILT		51 129	CONTROL PANEL OPTION LAMP TILTING AND FIELD KIT
23288376	TERMINAL ASSEMBLY		61	CONTROL PANEL
23289671	BRACKET		37	TOWER SUPPORT
23290307	HARNESS, ENGINE		75	ENGINE MOUNTING
23292121	SWITCH ASSEMBLY		121	FUEL SYSTEM
23292923	CABLE, RETRACTABLE		67 139	LAMP ASSEMBLY RECOMMENDED PARTS
23295058	COVER		29	ENCLOSURE
23298409	BUSH		41	TOWER ASSEMBLY
23300866	PLUG AND CABLE ASSEMBL		71	LAMP CONNECTION BOX ASSEMBLY
23302755	TUBE, JACK MOUNTING		27	FRAME ASSEMBLY
23304389	RUNNING GEAR ASSEMBLY		11	RUNNING GEAR
23310824	PIN, PULLEY		39	TOWER ASSEMBLY
23317159	SPACER		125	CENTRAL DRAIN
23318256	SUPPORT		41	TOWER ASSEMBLY
23318272	NUT, WING		27	FRAME ASSEMBLY
23318280	NUT		27	FRAME ASSEMBLY
23318298	SCREW		27	FRAME ASSEMBLY
23318306	LOCKWASHER		27	FRAME ASSEMBLY
23324619	PULLEY ASSEMBLY		39 139	TOWER ASSEMBLY RECOMMENDED PARTS
23324965	FITTING		125	CENTRAL DRAIN
23325541	SPRING, GAS		33	ENCLOSURE
23325756	TRAY, DRIP		121	FUEL SYSTEM
23326689	COVER		29	ENCLOSURE
23327307	HARNESS, LIGHTING		73	TRAILER LIGHTING
23329931	STIFFENER		41	TOWER ASSEMBLY
23330582	OIL, HYDRAULIC		137	RECOMMENDED PARTS
23330681	PANEL, LH		29	ENCLOSURE
23331176	CAP		121	FUEL SYSTEM
23331234	CLIP, RETAINING		121	FUEL SYSTEM
23332091	BRACKET		119	COOLING SYSTEM
23332125	PLATE, RETAINING		119	COOLING SYSTEM
23333891	STRAINER		121	FUEL SYSTEM
23334840	SENSOR, INDUCTIVE		47	HYDRAULIC ASSEMBLY
23335375	BRACKET		49	CONTROL PANEL
23338437	BRACKET		75	ENGINE MOUNTING
23338650	CABLE, POSITIVE		63	BATTERY
23338668	CABLE, NEGATIVE		63	BATTERY
23339021	ELBOW		53 55	CONTROL PANEL CONTROL PANEL
23339039	SLEEVE, CONDUIT		53 55	CONTROL PANEL CONTROL PANEL
23339153	ADAPTOR		125	CENTRAL DRAIN
23339450	PLUG, BLANKING		51	CONTROL PANEL

Part Number	Denomination	WAS	Page	Subgroup
23339609	PLUG, BLANKING		51	CONTROL PANEL
23340185	COVER		41	TOWER ASSEMBLY
23341738	BRACKET		119	COOLING SYSTEM
23344054	BOLT, BANJO		125	CENTRAL DRAIN
23344088	WASHER, COPPER		125	CENTRAL DRAIN
23344146	BANJO		125	CENTRAL DRAIN
23346190	LAMP, SIGNAL		51	CONTROL PANEL
23346307	SEAL		49	CONTROL PANEL
23348113	CANOPY ASSEMBLY		33	ENCLOSURE
23350721	SWITCH		47	HYDRAULIC ASSEMBLY
23351620	SCREW		71	LAMP CONNECTION BOX ASSEMBLY
23351661	STIFFENER		41	TOWER ASSEMBLY
23351778	FOAM		33	ENCLOSURE
23354921	CONDUIT		53 55	CONTROL PANEL CONTROL PANEL
23355217	PLATE, HINGE		33	ENCLOSURE
23355969	HOSE, HYDRAULIC		47	HYDRAULIC ASSEMBLY
23356033	HARNESS, SWITCH		47	HYDRAULIC ASSEMBLY
23356124	HARNESS, HYDRAULIC PUM		47	HYDRAULIC ASSEMBLY
23360977	PIN		37	TOWER SUPPORT
23361538	HANDLE		37	TOWER SUPPORT
23362155	CLIP, RETAINING		37	TOWER SUPPORT
23362684	SPRING		37	TOWER SUPPORT
23362692	LOCKING PIN ASSEMBLY		37	TOWER SUPPORT
23370752	PIN, SPLIT		119	COOLING SYSTEM
23370760	SCREW		119	COOLING SYSTEM
23370778	ISOLATOR, LOWER		119	COOLING SYSTEM
23370786	ISOLATOR, UPPER		119	COOLING SYSTEM
23370794	CAP		119	COOLING SYSTEM
23370935	ALTERNATOR, CHARGING		139	RECOMMENDED PARTS
23370943	STARTER ASSEMBLY		139	RECOMMENDED PARTS
23372857	PUMP, FUEL		77	ENGINE ASSEMBLY
23372865	GASKET, FUEL PUMP		77	ENGINE ASSEMBLY
35114057	CLAMP, SUPPORT		27	FRAME ASSEMBLY
35130707	HANDLE		33	ENCLOSURE
35222538	CLIP, RETAINING		37	TOWER SUPPORT
35225093	CLIP, RETAINING		121	FUEL SYSTEM
35273366	NUT		129	OPTION LAMP TILTING AND FIELD KIT
35279025	SCREW		75	ENGINE MOUNTING
35300771	SCREW		47	HYDRAULIC ASSEMBLY
35304047	NUT		129	OPTION LAMP TILTING AND FIELD KIT
35322395	SILENCER, PNEUMATIC		135	FIELD KIT FUEL GAUGE ASSEMBLY
35337328	STUD, BALL		33	ENCLOSURE
35361849	GASKET		121	FUEL SYSTEM
35369339	CONNECTOR		135	FIELD KIT FUEL GAUGE ASSEMBLY

Part Number	Denomination	WAS	Page	Subgroup
			129	OPTION LAMP TILTING AND FIELD KIT
35376169	DIODE ASSEMBLY		139	RECOMMENDED PARTS
36763670	SCREW		129	OPTION LAMP TILTING AND FIELD KIT
36785145	DEVICE, SIGNAL		49	CONTROL PANEL
36786457	KEY SWITCH ASSEMBLY		51	CONTROL PANEL
36794816	RIVET		29	ENCLOSURE
			33	ENCLOSURE
36797652	SCREW		49	CONTROL PANEL
			57	CONTROL PANEL
			119	COOLING SYSTEM
36841245	HOURLMETER		51	CONTROL PANEL
36848224	PIN		27	FRAME ASSEMBLY
36868479	SWITCH, COOLANT TEMPER		77	ENGINE ASSEMBLY
			137	RECOMMENDED PARTS
36868727	GUARD, FAN		119	COOLING SYSTEM
36871614	BRACKET		119	COOLING SYSTEM
36875565	MOUNT		75	ENGINE MOUNTING
36878361	RELAY, FUEL SHUTDOWN		57	CONTROL PANEL
			61	CONTROL PANEL
36878379	SWITCH, OIL PRESSURE		77	ENGINE ASSEMBLY
			137	RECOMMENDED PARTS
36881886	NUT		33	ENCLOSURE
			121	FUEL SYSTEM
36884948	RADIATOR		119	COOLING SYSTEM
36887701	REFLECTOR, RED		33	ENCLOSURE
36888170	ALTERNATOR, ENGINE		77	ENGINE ASSEMBLY
36888469	HOSE		119	COOLING SYSTEM
			139	RECOMMENDED PARTS
36888477	HOSE		119	COOLING SYSTEM
			139	RECOMMENDED PARTS
36888501	FAN		77	ENGINE ASSEMBLY
			139	RECOMMENDED PARTS
36889608	SCREW		33	ENCLOSURE
36890135	ELEMENT, AIR FILTER		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
			137	RECOMMENDED PARTS
36898096	SCREW		37	TOWER SUPPORT
			119	COOLING SYSTEM
36898104	WASHER		119	COOLING SYSTEM
36899037	WASHER, SNUBBING		65	ALTERNATOR AND MOUNTING
			67	LAMP ASSEMBLY
			75	ENGINE MOUNTING
36923415	JACK ASSEMBLY		27	FRAME ASSEMBLY
39139316	WASHER, NYLON		67	LAMP ASSEMBLY
46500039	MANUAL, OPERATION AND		45	DECALS AND DOCUMENTATION
46500047	MANUAL, PARTS CATALOGU		45	DECALS AND DOCUMENTATION
46500100	BREAKER, RCD		51	CONTROL PANEL
46500278	TEE		135	FIELD KIT FUEL GAUGE ASSEMBLY
46500328	MOTOR		47	HYDRAULIC ASSEMBLY
46500336	SWITCH, START		47	HYDRAULIC ASSEMBLY

Part Number	Denomination	WAS	Page	Subgroup
46500351	DOG, DRIVE		47	HYDRAULIC ASSEMBLY
46500369	VALVE, LOWERING		47	HYDRAULIC ASSEMBLY
46500377	COIL		47	HYDRAULIC ASSEMBLY
46500385	CAP, FILLER		47	HYDRAULIC ASSEMBLY
46500393	KIT, TANK		47	HYDRAULIC ASSEMBLY
46500401	KIT, SEAL		47	HYDRAULIC ASSEMBLY
46500526	MANUAL, OPERATION AND		45	DECALS AND DOCUMENTATION
46500534	MANUAL, OPERATION AND		45	DECALS AND DOCUMENTATION
46500542	MANUAL, OPERATION AND		45	DECALS AND DOCUMENTATION
46500559	MANUAL, OPERATION AND		45	DECALS AND DOCUMENTATION
46500567	MANUAL, OPERATION AND		45	DECALS AND DOCUMENTATION
46500575	MANUAL, OPERATION AND		45	DECALS AND DOCUMENTATION
46500732	RUNNING GEAR ASSEMBLY		3	RUNNING GEAR
46501391	INSULATION, ENGINE SIDE		33	ENCLOSURE
46501938	COVER, SWITCH		47	HYDRAULIC ASSEMBLY
46501979	INSULATION, ENGINE REAR		33	ENCLOSURE
46501987	CYLINDER, HYDRAULIC		47	HYDRAULIC ASSEMBLY
46502001	KIT, SEAL		47	HYDRAULIC ASSEMBLY
46502738	COVER, INSTRUMENT PANE		29	ENCLOSURE
46502803	DECAL, CLASS 1 RECOMME		45	DECALS AND DOCUMENTATION
46502845	DECAL, FUEL LEVEL		121 135	FUEL SYSTEM FIELD KIT FUEL GAUGE ASSEMBLY
46502886	TUBE, SIGHT		121	FUEL SYSTEM
46517363	PLUG		11 19	RUNNING GEAR RUNNING GEAR
46517371	CAP		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46517389	BOLT		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46517397	CABLE		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46517462	NUT		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46517488	T-BAR		19	RUNNING GEAR
46517520	HANDBRAKE ASSEMBLY		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46517538	DRAWBAR		11 19	RUNNING GEAR RUNNING GEAR
46517546	ARM ASSEMBLY		11 19	RUNNING GEAR RUNNING GEAR
46517579	PLATE		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
46517587	DRAWBAR ASSEMBLY		11	RUNNING GEAR

Part Number	Denomination	WAS	Page	Subgroup
			11	RUNNING GEAR
			19	RUNNING GEAR
46517603	SCREW		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517611	FRAME		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517629	COVER		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517637	AXLE TUBE ASSEMBLY		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517645	LINK, ADJUSTABLE		19	RUNNING GEAR
46517652	DRAWBAR ASSEMBLY		19	RUNNING GEAR
46517660	WHEEL		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517678	TYRE		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517686	WHEEL ASSEMBLY		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517702	CABLE, HANDBRAKE		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517710	KIT, COVER		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517728	KIT, TUBE SLIDER		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517736	KIT, LEVER AND CONNECTO		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517744	KIT, PISTON		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517751	KIT, SLEEVE		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517769	KIT, ROD		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517777	KIT, DRUM		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517785	KIT, CABLE		19	RUNNING GEAR
46517793	KIT, TAPER		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517801	KIT, SHOE		3	RUNNING GEAR

Part Number	Denomination	WAS	Page	Subgroup
			19	RUNNING GEAR
46517819	KIT, LEVER SPRING		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517827	KIT, DAMPER		3	RUNNING GEAR
			11	RUNNING GEAR
			19	RUNNING GEAR
46517835	T-BAR		3	RUNNING GEAR
			11	RUNNING GEAR
46517884	KIT, CABLE		3	RUNNING GEAR
			11	RUNNING GEAR
46517959	FUEL INJECTION ASSEMBLY		139	RECOMMENDED PARTS
46538757	WASHER		33	ENCLOSURE
46538773	DECAL, NOISE LEVEL		45	DECALS AND DOCUMENTATION
46538922	PUMP, FUEL		121	FUEL SYSTEM
46539219	PLATE, COVER		53	CONTROL PANEL
			55	CONTROL PANEL
46539300	SHIELD, HEAT		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
46539326	CLAMP		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
46539417	SOCKET ASSEMBLY		53	CONTROL PANEL
46539722	RELAY, OVER CURRENT		57	CONTROL PANEL
46539748	TERMINAL ASSEMBLY		57	CONTROL PANEL
46539755	INLET, APPLIANCE		53	CONTROL PANEL
			55	CONTROL PANEL
46540027	TRANSFORMER		57	CONTROL PANEL
46540043	RESISTOR		57	CONTROL PANEL
46540100	BREAKER, CIRCUIT		57	CONTROL PANEL
46540217	PLINTH		73	TRAILER LIGHTING
			127	OPTION LIGHTS
46540258	SPACER, REFLECTOR		29	ENCLOSURE
46540811	COVER, SOCKET BOX		53	CONTROL PANEL
			55	CONTROL PANEL
46540845	BOX, REAR		53	CONTROL PANEL
			55	CONTROL PANEL
46540977	SOCKET		53	CONTROL PANEL
46540985	SOCKET ASSEMBLY		55	CONTROL PANEL
46540993	SOCKET		55	CONTROL PANEL
46541223	NUT		49	CONTROL PANEL
			53	CONTROL PANEL
			55	CONTROL PANEL
46550641	PAN, OIL		79	OIL PAN
46550645	KEY, LATCH		33	ENCLOSURE
46550651	PLUG, DRAIN		79	OIL PAN
46550652	GASKET		79	OIL PAN
46550653	TUBE, BREATHER		83	HEAD COVER
46550654	CLAMP, HOSE		83	HEAD COVER
46550655	CAP, OIL FILLER		83	HEAD COVER
46550656	O-RING		83	HEAD COVER
46550657	ELEMENT, OIL FILTER		81	GEAR CASE / OIL FILTER

Part Number	Denomination	WAS	Page	Subgroup
46550658	BOLT		87	STOP SOLENOID
46550659	FUEL INJECTION ASSEMBLY		89	FUEL INJECTION PUMP
46550660	SHIM		89	FUEL INJECTION PUMP
46550661	SHIM		89	FUEL INJECTION PUMP
46550662	BOLT		89	FUEL INJECTION PUMP
46550663	SPRING, START		91	GOVERNOR
46550664	SPRING, GOVENOR		91	GOVERNOR
46550665	LEVER FORK ASSEMBLY		91	GOVERNOR
46550666	COMPLETE LEVER FORK AS		91	GOVERNOR
46550667	BOLT		91	GOVERNOR
46550668	CONTROL PLATE ASSEMBL		93	SPEED CONTROL PLATE
46550669	PIPE, FUEL OVERFLOW		95	NOZZLE HOLDER & GLOW PLUGS
46550670	CLIP, RETAINING		95	NOZZLE HOLDER & GLOW PLUGS
46550671	GLOW PLUG ASSEMBLY		95	NOZZLE HOLDER & GLOW PLUGS
46550672	FUEL PUMP ASSEMBLY		99	FUEL PUMP MECHANICAL
46550673	GASKET, FUEL PUMP		99	FUEL PUMP MECHANICAL
46550674	ALTERNATOR ASSEMBLY		101	ALTERNATOR AND PULLEY
46550675	BOLT		101	ALTERNATOR AND PULLEY
46550676	PULLEY, FAN DRIVE		101	ALTERNATOR AND PULLEY
46550677	STARTER ASSEMBLY		103	STARTER
46550678	WATER FLANGE ASSEMBLY		105	WATER FLANGE AND THERMOSTAT
46550679	PLUG, OIL GAUGE		105	WATER FLANGE AND THERMOSTAT
46550680	COVER, THERMOSTAT		105	WATER FLANGE AND THERMOSTAT
46550681	GASKET		105	WATER FLANGE AND THERMOSTAT
46550682	CLAMP		109	WATER PIPE
46550683	FAN		111	FAN
46550684	BOLT, FLANGE		111	FAN
46550685	COLLAR		111	FAN
46550686	INLET MANIFOLD ASSEMBL		113	INLET AND EXHAUST MANIFOLD
46550687	BOLT		113	INLET AND EXHAUST MANIFOLD
46550688	MANIFOLD, EXHAUST		113	INLET AND EXHAUST MANIFOLD
46550689	SWITCH, START		115	STARTER SWITCH
46550690	KEY		115	STARTER SWITCH
46550691	LABEL, START SWITCH		115	STARTER SWITCH
46550712	KIT, DRIVING LIGHTS PROTE		133	OPTION DRIVING LIGHTS PROTECTION
46550713	KIT, FIELD		135	FIELD KIT FUEL GAUGE ASSEMBLY
46551521	BLOCK, AUXILIARY CONTAC		57 61	CONTROL PANEL CONTROL PANEL
46551522	CONTACTOR ASSEMBLY		57 61	CONTROL PANEL CONTROL PANEL
46551523	DIAGRAM, FIELD KIT		135	FIELD KIT FUEL GAUGE ASSEMBLY
46551544	BASE, PIN		49	CONTROL PANEL
46551547	RELAY, DELAYED TIMER		57 61	CONTROL PANEL CONTROL PANEL
46551549	DIAGRAM, HARNESS AND W		57 61	CONTROL PANEL CONTROL PANEL

Part Number	Denomination	WAS	Page	Subgroup
			61	CONTROL PANEL
46551559	SCREW		73	TRAILER LIGHTING
			127	OPTION LIGHTS
46551569	RIVET		29	ENCLOSURE
46551580	HARNESS, DC		57	CONTROL PANEL
			61	CONTROL PANEL
46551581	HARNESS, AC		61	CONTROL PANEL
46551582	HARNESS, AC		57	CONTROL PANEL
46551635	SCREW		49	CONTROL PANEL
46551644	VALVE, HOSE BURST		47	HYDRAULIC ASSEMBLY
46551716	COVER		53	CONTROL PANEL
			55	CONTROL PANEL
46551763	DECAL, LOGO		43	DECALS AND DOCUMENTATION
46551765	DECAL, LOGO		43	DECALS AND DOCUMENTATION
46551785	HARNESS, LIGHTING		127	OPTION LIGHTS
46551787	PLUG		127	OPTION LIGHTS
46551794	DECAL, LOGO		43	DECALS AND DOCUMENTATION
46552152	HOLDER, BALLAST		49	CONTROL PANEL
46552237	PANEL, CONTROL		49	CONTROL PANEL
46552238	HOLDER, TIMER		49	CONTROL PANEL
46552239	DECAL, FASCIA		51	CONTROL PANEL
46552240	RAIL, DIN		49	CONTROL PANEL
46552246	BALLAST		57	CONTROL PANEL
			61	CONTROL PANEL
			139	RECOMMENDED PARTS
46553227	SCREW		133	OPTION DRIVING LIGHTS PROTECTION
46553328	SCREW		129	OPTION LAMP TILTING AND FIELD KIT
46553387	SPACER		129	OPTION LAMP TILTING AND FIELD KIT
46553388	BRACKET		129	OPTION LAMP TILTING AND FIELD KIT
46553389	SUPPORT, JUNCTION BOX		129	OPTION LAMP TILTING AND FIELD KIT
46553390	BUSH		129	OPTION LAMP TILTING AND FIELD KIT
46553391	PIN		129	OPTION LAMP TILTING AND FIELD KIT
46553607	BUSH		129	OPTION LAMP TILTING AND FIELD KIT
46553608	SUPPORT		129	OPTION LAMP TILTING AND FIELD KIT
46553609	SUPPORT		129	OPTION LAMP TILTING AND FIELD KIT
46553610	CROSSARM, TILTING		129	OPTION LAMP TILTING AND FIELD KIT
46553615	PIN		129	OPTION LAMP TILTING AND FIELD KIT
46553623	SPACER		129	OPTION LAMP TILTING AND FIELD KIT
46553631	SET, CONNECTORS		129	OPTION LAMP TILTING AND FIELD KIT
46553632	ENDSTOP		129	OPTION LAMP TILTING AND FIELD KIT
46553633	GLAND AND NUT		129	OPTION LAMP TILTING AND FIELD KIT
46553635	SET, CABLES		129	OPTION LAMP TILTING AND FIELD KIT
46553636	PROTECTOR		129	OPTION LAMP TILTING AND FIELD KIT
46553637	DECAL, TILTING		43	DECALS AND DOCUMENTATION
			45	DECALS AND DOCUMENTATION
			129	OPTION LAMP TILTING AND FIELD KIT
46553646	STOP, BLIND		71	LAMP CONNECTION BOX ASSEMBLY

Part Number	Denomination	WAS	Page	Subgroup
46553713	PLUG, TIMER		49	CONTROL PANEL
46553717	PHOTO SENSOR ASSEMBLY		67	LAMP ASSEMBLY
46553728	DECAL, AUTO START		43 45	DECALS AND DOCUMENTATION DECALS AND DOCUMENTATION
46553730	LAMP, AUTO START		29	ENCLOSURE
46553732	HARNESS, AUTOSTART		57 61	CONTROL PANEL CONTROL PANEL
46553740	DIAGRAM, WIRING		57 61	CONTROL PANEL CONTROL PANEL
46553747	TIMER		49 51	CONTROL PANEL CONTROL PANEL
46553748	DECAL, TIMER		49 51	CONTROL PANEL CONTROL PANEL
46553763	PLUG		29	ENCLOSURE
46553775	SWITCH, COMPACT		51	CONTROL PANEL
46553794	PIN, SPLIT		129	OPTION LAMP TILTING AND FIELD KIT
46553796	PIN, SPLIT		129	OPTION LAMP TILTING AND FIELD KIT
46704663	WASHER		39	TOWER ASSEMBLY
54403191	ELBOW		121	FUEL SYSTEM
54576624	HOSE		119 139	COOLING SYSTEM RECOMMENDED PARTS
54629977	DECAL, ISO CENTRAL DRAI		45	DECALS AND DOCUMENTATION
54762927	SCREW		65	ALTERNATOR AND MOUNTING
54772041	PLUG		33	ENCLOSURE
54774492	EYE		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
54774500	EYE		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
54774518	EYE		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
54774534	EYE		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
54774542	EYE		3 11 19	RUNNING GEAR RUNNING GEAR RUNNING GEAR
80025828	BUTTON, EMERGENCY STO		139	RECOMMENDED PARTS
89288757	LATCH		33	ENCLOSURE
89303127	BUTTON, EMERGENCY STO		53 55	CONTROL PANEL CONTROL PANEL
89303135	BLOCK, CONTACT		53 55	CONTROL PANEL CONTROL PANEL
89311716	PROTEC ENGINE OIL		137	RECOMMENDED PARTS
92061480	WASHER		41	TOWER ASSEMBLY
92085729	REFLECTOR, WHITE		27	FRAME ASSEMBLY
92101112	SCREW		121	FUEL SYSTEM
92104264	PROTECTOR		33	ENCLOSURE

Part Number	Denomination	WAS	Page	Subgroup
92111335	HOSE, TRANSPARENT		135	FIELD KIT FUEL GAUGE ASSEMBLY
92119445	PIN, HINGE		33	ENCLOSURE
92119460	WASHER		33	ENCLOSURE
92119957	SEAL		33	ENCLOSURE
92121243	REFLECTOR, AMBER		29	ENCLOSURE
			33	ENCLOSURE
92178896	SCREW		39	TOWER ASSEMBLY
92179043	SCREW		37	TOWER SUPPORT
92182138	SCREW		129	OPTION LAMP TILTING AND FIELD KIT
92184811	SCREW		33	ENCLOSURE
			57	CONTROL PANEL
			61	CONTROL PANEL
			119	COOLING SYSTEM
			121	FUEL SYSTEM
92253129	CLAMP		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
92271923	RIVET		27	FRAME ASSEMBLY
			33	ENCLOSURE
92281369	RIVET		57	CONTROL PANEL
			61	CONTROL PANEL
92281427	TIE, CABLE		127	OPTION LIGHTS
			135	FIELD KIT FUEL GAUGE ASSEMBLY
92304351	SCREW		41	TOWER ASSEMBLY
92304542	NUT		27	FRAME ASSEMBLY
92304559	NUT		33	ENCLOSURE
92304567	NUT		75	ENGINE MOUNTING
92304583	WASHER		29	ENCLOSURE
			47	HYDRAULIC ASSEMBLY
			49	CONTROL PANEL
			53	CONTROL PANEL
			55	CONTROL PANEL
92304591	WASHER		27	FRAME ASSEMBLY
92304641	WASHER		53	CONTROL PANEL
			55	CONTROL PANEL
92304658	WASHER, SPRING		133	OPTION DRIVING LIGHTS PROTECTION
92304674	LOCKWASHER		75	ENGINE MOUNTING
92304951	WASHER		37	TOWER SUPPORT
92311703	BOLT		129	OPTION LAMP TILTING AND FIELD KIT
92339688	SCREW		41	TOWER ASSEMBLY
92340439	WASHER		49	CONTROL PANEL
			53	CONTROL PANEL
			55	CONTROL PANEL
92340447	WASHER, SPRING		53	CONTROL PANEL
			55	CONTROL PANEL
92341981	WASHER		39	TOWER ASSEMBLY
			47	HYDRAULIC ASSEMBLY
92398122	SCREW		27	FRAME ASSEMBLY
92398130	SCREW		33	ENCLOSURE
92441450	SCREW		33	ENCLOSURE
92472638	SCREW		27	FRAME ASSEMBLY
			47	HYDRAULIC ASSEMBLY

Part Number	Denomination	WAS	Page	Subgroup
92659432	SCREW		57 61	CONTROL PANEL CONTROL PANEL
92783281	PLUG		29	ENCLOSURE
92798719	HINGE, UPPER		33	ENCLOSURE
92798727	HINGE, LOWER		33	ENCLOSURE
92799501	PROTECTOR		33	ENCLOSURE
92803998	CLIP, RETAINING		119	COOLING SYSTEM
92829316	NUT		37 39 47	TOWER SUPPORT TOWER ASSEMBLY HYDRAULIC ASSEMBLY
92861640	TIE, CABLE		37 135	TOWER SUPPORT FIELD KIT FUEL GAUGE ASSEMBLY
92866458	GRILLE		133	OPTION DRIVING LIGHTS PROTECTION
92867076	GRILLE		133	OPTION DRIVING LIGHTS PROTECTION
92867449	DECAL, REFER TO HANDBO		45	DECALS AND DOCUMENTATION
92867530	DECAL, HOT SURFACE		45 67	DECALS AND DOCUMENTATION LAMP ASSEMBLY
92890037	PLUG		33	ENCLOSURE
92894542	RETAINER, FOAM		33	ENCLOSURE
92898576	CLAMP		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
92901222	LAMP, TAIL/STOP/FLASH		73	TRAILER LIGHTING
92901230	LAMP, REGISTRATION PLAT		73 127	TRAILER LIGHTING OPTION LIGHTS
92912559	DECAL, EARTH WARNING		45	DECALS AND DOCUMENTATION
92930593	DECAL, ELECTRIC SHOCK		45	DECALS AND DOCUMENTATION
92930601	DECAL, CORROSIVE SUBST		45	DECALS AND DOCUMENTATION
92930627	DECAL, GENERAL WARNING		45	DECALS AND DOCUMENTATION
92930650	DECAL, EMERGENCY STOP		45	DECALS AND DOCUMENTATION
92930668	DECAL, NO MAINT/READ MA		45	DECALS AND DOCUMENTATION
92976042	DECAL, EXHAUST GAS DISC		45	DECALS AND DOCUMENTATION
93150977	SCREW		117 121	AIR INTAKE / ENGINE EXHAUST SYSTEM FUEL SYSTEM
93165959	DECAL, ROTATING FAN		45	DECALS AND DOCUMENTATION
93171254	DECAL, DIESEL FUEL		45	DECALS AND DOCUMENTATION
93171262	DECAL, LIFT/TIE POINT		45	DECALS AND DOCUMENTATION
93171288	DECAL, COOLANT FILL		45	DECALS AND DOCUMENTATION
93178184	DECAL, TYRE PRESSURE		45	DECALS AND DOCUMENTATION
93477388	LAMP, FOG		73	TRAILER LIGHTING
93501930	GLAND, CABLE		65	ALTERNATOR AND MOUNTING
93524007	PLATE, CABLE TIE		127 135	OPTION LIGHTS FIELD KIT FUEL GAUGE ASSEMBLY
95042603	SCREW		69	LAMP UNIT
95067864	SCREW		65	ALTERNATOR AND MOUNTING
95220844	CLAMP, HOSE		121 125 135	FUEL SYSTEM CENTRAL DRAIN FIELD KIT FUEL GAUGE ASSEMBLY
95223251	CLIP, RETAINING		41	TOWER ASSEMBLY

Part Number	Denomination	WAS	Page	Subgroup
95920674	SCREW		65	ALTERNATOR AND MOUNTING
95928321	WASHER		41	TOWER ASSEMBLY
95929022	LOCKWASHER		69	LAMP UNIT
95935003	WASHER		129	OPTION LAMP TILTING AND FIELD KIT
95935011	WASHER		67	LAMP ASSEMBLY
95935029	WASHER		133	OPTION DRIVING LIGHTS PROTECTION
95935037	WASHER		41 65 67 75 129	TOWER ASSEMBLY ALTERNATOR AND MOUNTING LAMP ASSEMBLY ENGINE MOUNTING OPTION LAMP TILTING AND FIELD KIT
95935052	WASHER		129	OPTION LAMP TILTING AND FIELD KIT
95942520	SCREW		69	LAMP UNIT
95942553	SCREW		69	LAMP UNIT
95954525	SCREW		49	CONTROL PANEL
96701743	NUT		129	OPTION LAMP TILTING AND FIELD KIT
96701958	SCREW		121	FUEL SYSTEM
96702352	SCREW		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
96702741	NUT, SELF LOCKING		67	LAMP ASSEMBLY
96702816	SCREW		41	TOWER ASSEMBLY
96704309	SCREW		75	ENGINE MOUNTING
96704408	SCREW		53 55 65 119	CONTROL PANEL CONTROL PANEL ALTERNATOR AND MOUNTING COOLING SYSTEM
96704508	SCREW		117	AIR INTAKE / ENGINE EXHAUST SYSTEM
96704580	NUT		29 47 49	ENCLOSURE HYDRAULIC ASSEMBLY CONTROL PANEL
96704606	NUT		41	TOWER ASSEMBLY
96704630	NUT		129	OPTION LAMP TILTING AND FIELD KIT
96705124	SCREW		67	LAMP ASSEMBLY
96711189	CLIP, RETAINING		47	HYDRAULIC ASSEMBLY
96711213	CLIP, RETAINING		39	TOWER ASSEMBLY
96715354	SCREW		67	LAMP ASSEMBLY
96716782	SCREW		75	ENGINE MOUNTING
96719182	NUT		75	ENGINE MOUNTING
96724679	NUT		41	TOWER ASSEMBLY
96725270	SCREW		47	HYDRAULIC ASSEMBLY
96725494	SCREW		75	ENGINE MOUNTING
96727540	BOLT		129	OPTION LAMP TILTING AND FIELD KIT
96727789	SCREW		29	ENCLOSURE
96728480	SCREW		27 29 117 119	FRAME ASSEMBLY ENCLOSURE AIR INTAKE / ENGINE EXHAUST SYSTEM COOLING SYSTEM
96732623	SCREW		29	ENCLOSURE
96733746	SCREW		29	ENCLOSURE

Part Number	Denomination	WAS	Page	Subgroup
			67	LAMP ASSEMBLY
96736749	PIN, SPLIT		39	TOWER ASSEMBLY
96737531	SCREW		53	CONTROL PANEL
			55	CONTROL PANEL
96737556	SCREW		37	TOWER SUPPORT
96739461	CONNECTOR		47	HYDRAULIC ASSEMBLY
96743653	SCREW		49	CONTROL PANEL
			53	CONTROL PANEL
			55	CONTROL PANEL
			57	CONTROL PANEL
			61	CONTROL PANEL
96745211	SCREW		53	CONTROL PANEL
			55	CONTROL PANEL
96746664	PIN, SPLIT		41	TOWER ASSEMBLY
96753645	ELBOW		47	HYDRAULIC ASSEMBLY

