

[illegible]

Description
Hydraulic Tank Filter
Hydraulic Tank Cap
Oil Tank Cap
Water Tank Cap (BX-60WH, 80-WH, 120WH)
Brake Lever
Forward/Reverse Lever Knob
V-belt
Fuel Tank Cap (Includes Item 6)
Ignition Switch Assembly (Includes Items 2 & 3)
Ignition Key
Oil Filter
Fuel Filter Assembly (Includes Items 11 thru 17)
Radiator Cap (Includes Item 25)
Filter
Oil Filter
Air Cleaner Element
Element Assembly
V-belt
Throttle Lever Knob
Vibration Cable
Pump Control Lever
Forward/Reverse Lever
Vibration Lever
Throttle Lever
Throttle Cable
Battery Cable
Battery Cable
Oil Switch
Oil Gauge
Starter Assembly
Fuel Gauge
Pump Assembly
Oil Seal Kit
Charge Oil Seal
Flange Oil Seal
Drive Motor Assembly
Seal Kit
Shaft Arm
Muffler
Muffler Gasket
Trunnion Oil Seal