



## LSC-60HZ-T4F RECOMMENDED SPARES

Available within Parts Manual through Dealer Passport– SmartEquip [[www.doosanpassport.com](http://www.doosanpassport.com)]

Part Number	Description	Qty Used Per
22054175	HOURMETER ELEC/MECH	1
22246797	BATTERY, 12V GROUP 24	1
22516207	RELAY, 12VDC COIL 40AMP	1
22885016	CONE, OUTER BEARING	4
22885024	CUP, OUTER BEARING	4
22885040	WASHER, SPINDLE	2
22885057	NUT, SPINDLE	2
22885065	PIN, COTTER	2
22885073	CAP, GREASE DUST	2
22885081	STUD, WHEEL	10
23084965	LAMP 1000W MH SMALL	1
23177363	GLASS/LENS CLIP	8
23177371	GLASS/LENS CLIP COVER	8
23315310	FENDER, PLASTIC	2
35315274	NUT WHEEL	10
35335991	PLUG,1.12/1.09DIA HL	1
35371772	BRKR 1P 20A 250V	1
35371798	RCPT 20A 125V DX	1
35374925	Light, License	1
36783009	PUL,76.2X15.9LG	4
36783868	PIN,CLV9.5X25.4PL	4
36786218	LNVD, 1.6X355.6	4
36787398	LEVEL CIR	1
36794170	PIN,.31"LYNCH	2
36848224	PIN OUTFRIGGER	4
36868545	CABLE, 3430MM LG	1
36869246	PIN CLEVIS 9.5DIA	4
36869253	PIN 22.2DIA 134LG	2
36870020	PIN 22.2DIA 215LG	1
36876225	CABLE, 5460MMLNG	2
36883791	BALLAST 60HZ	4
36888683	CAPACITOR	1
36890135	PRIMARY FILTER	1
36895449	SWT, SING POLE DBL THROW	2
36923415	JACK, DRAWBAR, LT SOURCE	2
36923654	WINCH MNL 1500 LB CAP	2
36923662	HDL WN 9"	1
46496337	BREAKER CIRCUIT 2P,20A	1
46496345	BLOCK TERMINAL 8 ROW	1
46496410	CORD ASM BALLAST	1
46496782	SOCKET, RELAY DIN	2
46496907	ASSEMBLY, LAMP	4
46497012	CABLE, UL LISTED ELEC	1
46497186	LENS, CLEAR GLASS	1
46497194	GASKET, GLASS/LENS	1
46498630	HOSE RADIATOR TOP	1
46498648	HOSE RADIATOR LOWER	1
46499430	RELAY TIME DELAY 10 SEC	1
46499471	SWITCH KEY	1
46499505	KEY FOR 46499471	1
46543708	CAP, FUEL	1
46544540	HUB 5-LUG	2
46544557	GREASE SEAL	2
46548715	CAP, RADIATOR	1
46549580	FILTER OIL ENGINE	1
46549598	FILTER FUEL ENGINE	1
46549721	DIODE ALT	2
46549754	CAPACITOR ALT	1
95220851	CLAMP HOSE	4
95928867	PIN COT.09	8
46556077	BELT, FAN	1
46556078	KIT, MAINTENANCE	1



*Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.*