



Doosan Infracore
Portable Power

EMEA Portable Power product serial number locations





Doosan Infracore
Portable Power

Airend



Airend SN locations

Non Duplicating Serial Number


Manufactured in US

Year of Manufacture

Air End Product Code



Airend SN locations






Doosan Infracore
Portable Power

Engines



Engine SN locations


KUBOTA



Engine SN locations

YANMAR


Stage 2 & 3A mechanical engine – Engine serial number



Engine SN locations

YANMAR

Stage3A electronic engine – Engine serial number



“Engine Serial Number”
official plate

Engine Model

Engine Serial Number

MDL: 4TNV98T-7NSA2
E/N: 75969
090_090_090_095_100
100_100_100_E371




“Engine Serial Number” label


Engine SN locations

YANMAR


Stage3A electronic engine – Fuel Injection Pump serial number



“FIP Pump Serial Number”




Fuel Injection Pump
Serial Number



Engine SN locations

JOHN DEERE




CD Engine Manufacturing Location
CD Saran, France
T0 Dubuque, Iowa
PE Torreon, Mexico
J0 Rosario, Argentina
4 Number of Cylinders
045 Displacement in Liters (4.5 Liters)
L Aspiration Code (Early Engines) or Emission
Tier Level (Later Engines)
D Naturally aspirated
T Turbocharged, no aftercooling
A Turbocharged and air-to-coolant aftercooled
H Turbocharged and air-to-air aftercooled
S Turbocharged and air-to sea water aftercooled
B Non-certified engine
C, E or F Tier 1/Stage I emission certified engine
G, J or K Tier 2/Stage II emission certified engine
L, M, N or P Tier 3/Stage IIIA emission certified engine
123456 6-digit unique sequence number






 <p>Cummins Engine Company, Inc. Box 3005 Columbus, Indiana 47202-0005</p> <p>Warning: Injury May Result And Warranty Is Voided If Fuel Rate RPM Or AIR/Fuel Ratio Exceed Published Maximum Value For This Model And Application.</p> <p>Date of Mfg. Made in U.S.A.</p>	Engine Cert. ID.	C.I.D./ L	SERIES	CPL	Engine Serial No.
	Timing TDC				Injector P/N.
Valve lash cold Int. Exh.				Cust Spec.	
Firing Order				Rated HP at rpm	
Low Idle RPM				Fuel rate at rated HP mm 3/stroke	
E.C.S.				Model Name	




- 1 Engine serial number (ESN)
- 2 Engine model information
- 3 Valve lash (overhead) setting
- 4 Horsepower and rpm rating
- 5 Emission control system (E.C.S.).

 CUMMINS INC. Assembled in the USA Date of Mfg XXX-XX-XX				Engine No. XXXXXXXX	Ref. No. XXXXXXXXXX	Model XXXXXXXXXXXXX	Fuel Rate at Adv. HP/ka (mm3/ef) XXX	FR XXXXX	CPI XXXX
Idle Speed (rpm) XXXX				Advertised HP XXXXX at XXXX rpm		Family XXXXXXXXXXXXX	STD/FEL	EPA	CAR
Firing Order XXXXXX				Timing - T.D.C. ELECTRONIC		Category XXX - XXX	XXXX	X.X	X.X
Valve lash cold X.XXX int.				Exh. C.I. D./L XXX/XXX		E. C. S. XXXXXXXXXXXX	PM	X.X	
XXXXXXXXXXXXXXXXXXXXXXXXXXXX WARNING: Injury may result and warranty is voided if fuel rate, rpm or altitudes exceed published maximum values for this model and application.									

Engine SN locations

CATERPILLAR



1. Serial Number plate
2. Information plate





Doosan Infracore
Portable Power

Running Gear



Running Gear SN locations






Doosan Infracore
Portable Power

Compressors



Machine SN locations



Compressors produced in the EU will show this dataplate on the outside of the unit.

The info we require is the full serialnumber as pointed out with the red arrow.




Doosan Infracore
Portable Power

Generators



Machine SN locations



All EU supplied LightTowers will have a metal dataplate on the outside of the unit.

The info we require is the full serialnumber starting with CZ.

DOOSAN	
DOOSAN TRADING LIMITED	
APPROVAL	
VIN	
GROSS P.T.A.C.	_____ Kg
AXLE 1	_____ Kg
AXLE 2	_____ Kg
COUPLING/CROCHET	_____ Kg
MACHINE MODEL	
CODE	YEAR/ANNEE/BAUJAHR
MAX ALLOWABLE WORKING PRESSURE (BAR)	
NORMAL WORKING PRESSURE (BAR)	
INPUT SHAFT POWER (kW)	
MOTOR/ENGINE SPEED (rev/min)	
GROSS MASS (kg)	
MAX TOWBAR VERTICAL WEIGHT (N)	
MAX TOWBAR HORIZ. LOAD (N)	
PRODUCER/HERSTELLER TYPE	
DOOSAN TRADING LIMITED Co DUBLIN IRELAND 23237225.C	



Doosan Infracore
Portable Power

Lighttower



Machine SN locations



All EU supplied LightTowers will have a metal dataplate on the outside of the unit.

The info we require is the full serialnumber starting with CZ.

DOOSAN	
DOOSAN TRADING LIMITED	
APPROVAL	
VIN	
GROSS P.T.A.C.	
AXLE 1	1 Kg
AXLE 2	2 Kg
COUPLING/CROCHET	
MACHINE MODEL	
CODE	YEAR/ANNEE/BAUJAHR
MAX ALLOWABLE WORKING PRESSURE (BAR)	
NORMAL WORKING PRESSURE (BAR)	
INPUT SHAFT POWER (kW)	
MOTOR/ENGINE SPEED (rev/min)	
GROSS MASS (kg)	
MAX TOWBAR VERTICAL WEIGHT (N)	
MAX TOWBAR HORIZ. LOAD (N)	
PRODUCER/HERSTELLER TYPE	
DOOSAN TRADING LIMITED Co DUBLIN IRELAND	




Doosan Infracore
Portable Power

Construction Tools



Construction Tools SN locations



All EU supplied Construction Tools will have a metal dataplate or decal on the tool body.

The info we require is the full serialnumber starting with CZ.

THANK YOU

