


B - BATTERY - 36844967
 CB - WINCH CIRCUIT BREAKER - 368504042
 GO - ALTERNATOR 36888170
 H- HOURMETER - 36841245
 L2 - LOW FUEL LAMP (OPTION) - 36883825
 M1 - STARTER MOTOR - 36888188
 PSI = OIL PRESSURE SWITCH - 36878379
 RI - FUEL SHUTDOWN RELAY - 36878361
 SI - MAIN SWITCH - 36786457
 S2 - LOW FUEL SWITCH (OPTION) - 54414669
 SV1 = FUEL SOLENOID - 36878189
 TS1 - WATER TEMPERATURE SWITCH - 36868479
 U2 - ELECTRIC WINCH - 36878056

ENGINE WIRING HARNESS - 54364856
 CONTROL PANEL HARNESS - 54364864



KEY

CB1 - CIRCUIT BREAKER/
RESIDUAL CURRENT DEVICE

CB2-CB5 - CIRCUIT BREAKER/SWITCH

C1-4 - BALLAST CAPACITOR

C5 - GENERATOR CAPACITOR

EM - EMERGENCY STOP PUSHBUTTON


G1 - GENERATOR

R2 - TRIP RESISTER

SBI - SOCKET OUTLET BOX (LIGHTS)

SKI-4 - SOCKET OUTLET (LIGHTS)

T1-4 - BALLAST TRANSFORMER



SCHEMATIC AC