

Technical Service Bulletin

Number: PC8-021

Date: June 22, 2004 **Revised (10-12)**

Subject: COMPRESSOR FLUID LEVEL

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Doosan Company or the products of either.

MODELS AFFECTED:

XHP1070AWCAT, XHP1070ASCAT, XHP1170WCAT, XHP1170SCAT,
XHP1170WCU, XHP1170SCU, HP1600WCU, HP1300CWCU

SYMPTOMS: Compressor Fluid Varies

CAUSE: The compressor fluid level is affected by the type fluid and whether the level is checked when the machine is operating or stopped.

REMEDY: The compressor oil level for the listed air compressor models should be checked with the machine in the stopped/static state. On some machines the decal located on the separator tank and in the Operator, Maintenance and Parts Manual instructs the operator to check while running. Although this is an acceptable practice, changes have been made to the separator tank decal and the Operation, Maintenance and Parts Manual instructing the operator to check the compressor oil level while in the stopped/static state. New separator tank decals are available by ordering part number 22383319.

WARRANTY ACTION: NONE. INFORMATION ONLY. THIS IS NOT A CAMPAIGN.